

Open front screen

**INDUSTRIAL  
DIESEL ENGINE**

**AA-6SD1T  
MODEL**

**WORKSHOP MANUAL**

**ISUZU MOTORS LIMITED**

## **Foreword**

This Workshop Manual has been prepared as a guide for the service and repair of the Model AA-6SD1T diesel engine.

A general table of contents is shown on the following page, and more detailed subsections are listed at the beginning of each respective chapter.

This manual was first prepared in April, 2001, but subsequent changes in design may result in modifications to certain values and other information in this Manual.

## TABLE OF CONTENTS

<b>Chapter 1</b>	<b>General Information .....</b>	<b>1</b>
<b>Chapter 2</b>	<b>Maintenance .....</b>	<b>21</b>
<b>Chapter 3</b>	<b>Engine I (Disassembly) .....</b>	<b>37</b>
<b>Chapter 4</b>	<b>Engine II (Inspection and Repair) .....</b>	<b>55</b>
<b>Chapter 5</b>	<b>Engine III (Assembly) .....</b>	<b>85</b>
<b>Chapter 6</b>	<b>Lubricating System .....</b>	<b>117</b>
<b>Chapter 7</b>	<b>Cooling system .....</b>	<b>129</b>
<b>Chapter 8</b>	<b>Fuel System .....</b>	<b>139</b>
<b>Chapter 9</b>	<b>Turbocharger .....</b>	<b>153</b>
<b>Chapter 10</b>	<b>Engine Electrical .....</b>	<b>173</b>
<b>Chapter 11</b>	<b>Troubleshooting .....</b>	<b>197</b>
<b>Chapter 12</b>	<b>Special Tools .....</b>	<b>219</b>
<b>Chapter 13</b>	<b>Repair Standard .....</b>	<b>223</b>

**Note:**

**Before using this manual to perform maintenance and repairs, be sure to read the section "General Servicing Precautions" included in Chapter 1 (General Information).**

---

# CHAPTER 1


## GENERAL INFORMATION

### CONTENTS

ITEM	PAGE
General servicing precautions .....	2
Notes on the Format of this Manual .....	3
About Angular Tightening .....	6
Main Data and Specifications .....	7
External View .....	8
Tightening Torque Specifications .....	9
Tightening Torques for Main Parts .....	11
Model and Identification Serial Numbers .....	19

## GENERAL SERVICING PRECAUTIONS

1. Before performing any inspections or maintenance work, disconnect the battery's ground cable to prevent any damage from shorted wires.
2. Always use the proper tool for the job.  
When a special tool is designated for a job, be sure to use only that special tool.
3. When replacement parts are required, consult the appropriate Isuzu parts catalog and use only "Genuine Isuzu Parts."
4. Never reuse any cotter pins, gaskets, seals, o-ring, lock washers, or self-locking nuts removed in the course of disassembly.
5. To facilitate reassembly, lay out engine parts in logical groups in the order in which they are removed. Be especially careful to replace nuts and bolts in their proper locations, since characteristics such as length and hardness may differ depending on the installation position.
6. Use identification labels or tags to mark valves, bearings, and pistons, to prevent confusing their proper order and sequence.




F06E100031

7. Clean all parts before inspection and reassembly.  
Be particularly sure to use compressed air to blow out oil ports and openings, to assure that they are free of obstructions.
8. Be sure to apply oil or grease as appropriate to all rotating and sliding surfaces before reassembly.
9. Use sealants to prevent leaks where necessary.
10. Tighten all nuts and bolts to specified tightening torques.
11. After completing inspections and repairs, double check your work to confirm that the job has been done properly.

## NOTES ON THE FORMAT OF THIS MANUAL

1. Use the Table of Contents at the beginning of the Manual to find the general areas required.
2. Common technical data such as general maintenance, repair specifications, and tightening torques are listed in the General Information chapter.
3. Each chapter is composed of "disassembly, inspection" and "repair, assembly" sections. the only exception is the treatment of the engine body itself, which is divided into three independent chapters for ease of explanation.
4. When similar maintenance procedures are applicable to multiple operations or parts, the manual will cross-reference the page where the appropriate information can be found.
5. To provide brevity and conciseness, simple disassembly and repair operations are omitted, while more space is devoted to explaining complex procedures such as adjustments and tightening torques.
6. The descriptions given in each chapter begin with an exploded diagram of the applicable parts, with numbers indicated as shown below.



**General Information**

7. The following is a sample of the text in the Workshop Manual.

**Measurement of cylinder Liner Projection**

- Place a straight edge ① along the top edge of the cylinder liner to be measured.
- Using a feeler gauge ②, measures the projection of each cylinder liner.

Cylinder liner projection	mm (in)
Standard	0.106 – 0.134 (0.0042 – 0.0053)

The difference in cylinder liner projection between any two neighboring cylinders must not exceed 0.02 mm.

**Cylinder Liner Removal**

- Attach a cylinder liner remover to the cylinder liner.  
Cylinder liner remover : 1-85231-016-0
- Confirm that the remover's shaft anchor is hooked firmly on the bottom of the cylinder liner.
- Slowly rotate the remover's shaft handle clockwise to remove the cylinder liner.

**Note:**  
Be careful not to damage the upper face of the cylinder block when removing cylinder liners.

**Cylinder Block Bore Measurement**

- At measuring point ①, measure the cylinder block bore in the four directions (W-W, X-X, Y-Y, Z-Z).  
Measuring point ①: 120 mm from upper face.
- Calculate the average value of the four measurements to determine the correct liner grade.

● These tables indicate repair standards.


● Special tools are identified by name and/or number.  
The illustration also indicates the proper procedure for using the special tool.

● Symbols indicate the type of operation or sequence to be performed. A detailed explanation of these symbols is given below.

8. The following symbols appear throughout this Manual, indicating the type of service operation or procedure to be performed.

- |  |                             |  |   |
|--|-----------------------------|--|---|
|  | .... Removal                |  | .... Adjustment                                 |
|  | .... Installation           |  | .... Cleaning                                   |
|  | .... Disassembly            |  | .... Important operation; special care required |
|  | .... Assembly               |  | .... Tighten to specified torque                |
|  | .... Alignment (marks)      |  | .... Special tool use required (Isuzu Tools)    |
|  | .... Directional indication |  | .... Use commercially available special tool    |
|  | .... Inspection             |  | .... Lubrication with engine oil                |
|  | .... Measurement            |  | .... Apply grease                               |
|  | .... Apply sealant          |  |   |

9. Measurements are indicated by "standard" or "limit";  
 a "standard" value refers to the standard values at time of assembly.  
 A "limit" value is a maximum or minimum; measurements up to that value are usable.  
 Measurements falling beyond that value mean the part must be serviced, adjusted, or replaced.
10. Directional indications adopted within this manual are as follows;  
 Front: Toward the cooling fan when viewed from the flywheel side.  
 Right: Toward the fuel injection pump when viewed from the flywheel side.  
 Left: Toward the exhaust manifold when viewed from the flywheel side.  
 Rear: Toward the engine's flywheel side.
11. "Cylinder numbers" and "Engine rotation direction": Cylinder numbers are counted in sequence beginning from the front side of the engine.  
 As a result, the first cylinder at the very front of the engine is cylinder No. 1, while the last cylinder toward the rear is cylinder No. 6. The direction of engine rotation is clockwise when viewed from the cooling fan side.



F06E100032

12. "ASM" is an abbreviation for "assembly."



## ABOUT ANGULAR TIGHTENING

At present, the method most commonly used to tighten bolts is to specify a torque value to which the bolts should be tightened. This method, however, has the disadvantage of being characterized by considerable fluctuation in axial force for a given torque, with the result that when attempting to maintain the minimum necessary axial force, the bolt may be sheared at its upper limit value.

In order to produce less fluctuation in axial force, the ideal method would be to tighten the bolt while measuring the amount of its stretch, but since this is impossible in practice, a substitute method was conceived, namely considering the relationship of thread pitch to bolt stretch. The angular tightening method thus focuses on the amount the bolt is turned — directly related to thread pitch — in order to allow tightening of the bolt up unto the region of plasticity, thus reducing the variation in axial force.

### TIGHTENING METHOD


1. Apply molybdenum disulfide grease to the threads and setting faces of the nuts and bolts.
2. Tighten all bolts to the designated tightening torque values.
3. Next, make a mark at a point corresponding to one edge of the bolt as shown in the accompanying illustration, then tighten the bolt by turning it by the designated angle.

Afterwards, be sure to check the mark to confirm whether the bolt has been tightened to the specified angle.


If this confirmation is not performed, and if the bolt is subsequently retightened using the angular tightening method, it may break.

#### Note:

1. Tighten bolts in their designated sequence.
2. When using the angular tightening method, do not retighten.



Use a wrench to rotate the bolt until the line (A — B) on the bolt is aligned with the designated angle line on the material (line E — F).



On the surface of the bolt and material to be tightened, draw a line extending through the center of the bolt (A — B on the bolt, C — D on the material), and a line on the material surface which is aligned with the center of the bolt at the designated tightening angle (line E — F).

### LOCATIONS OF USE OF ANGULAR TIGHTENING METHOD

1. Cylinder head bolts (M14 bolts only)
2. Lower crankcase bolts (M14 bolts only)
3. Connecting rods, bearing cap nuts
4. Flywheel bolts
5. Idle gear shaft bolt (A)


## MAIN DATA AND SPECIFICATIONS

Item	Engine Model	AA-6SD1T
Engine type		4-cycle, water-cooled vertical in-line overhead camshaft
Combustion chamber type		Direct injection
Cylinder liner type		Dry type
Number of cylinders; bore x stroke	mm	6 – 120 x 145
Total exhaust displacement	L (cid)	9.839 (601)
Compression ratio		16.8 : 1
Dimensions (L x W x H)	mm	* 1379 x 859 x 1158
Weight	kg	* 693
Ignition sequence		1-5-3-6-2-4
Fuel used		Diesel (2-D)
Fuel-injection pump type		In-line Bosch
Governor		Variable speed, mechanical, RSV type or electrically controlled type (Red IV)
Injection nozzle type		Multi-hole type
Injection starting pressure	MPa (kg/cm <sup>2</sup> /psi)	* 17.7 – 22.1 (180 – 225/2570 – 3200)
Fuel injection timing (BTDC)		* 7°
Compression pressure (warm engine, 200 rpm)	MPa (kg/cm <sup>2</sup> /psi)	2.84 (29/412)
Inlet valve	Open (BTDC)	15°
	Close (ATDC)	39°
Exhaust valve	Open (BTDC)	40°
	Close (ATDC)	14°
Valve clearance (cold engine)	Inlet valve mm	0.4
	Exhaust valve	0.4
Lubricating system		Forced circulation type
Engine oil capacity; Oil pan	L (qts)	* Max 30 (31.7), Min 25 (26.4)
Total system capacity	L (qts)	* Max 35 (37), Min 30 (31.7)
Lubricating engine oil		API service type CD, or Isuzu Besco S-3
Oil cooler		Water-cooled, internally mounted
Cooling method		Forced circulation, pressurized water-cooled type
Cooling system volume	L (qts)	About 19 (20) (engine only)
Cooling fan		* Dia. 850 mm, 6-blade, sucker type
Alternator	V-A	* 24 – 50
Starter	V-kW	* 24 – 5.5

Specifications marked with an asterisk (\*) will vary according to engine application.

**EXTERNAL VIEW  
MODEL AA-6SD1T**

**Note:**  
Engine details may vary depending on the specifications.











## TIGHTENING TORQUE SPECIFICATIONS

The tightening torque values given in the table below are applicable to the bolts unless otherwise specified.

### STANDARD BOLT




kgf·m (lb.ft/N·m)

Bolt Identification Bolt Diameter × pitch (mm)				
				
<b>M6 × 1.0</b>	4 – 8 (0.4 – 0.8/3 – 6)	5 – 10 (0.5 – 1.0/4 – 7)		—————
<b>M8 × 1.25</b>	8 – 18 (0.8 – 1.8/6 – 13)	12 – 23 (1.2 – 2.3/9 – 17)		17 – 30 (1.7 – 3.1/12 – 22)
<b>M10 × 1.25</b>	21 – 34 (2.1 – 3.5/5 – 25)	28 – 46 (2.8 – 4.7/20 – 33)		37 – 62 (3.8 – 6.4/28 – 46)
* <b>M10 × 1.5</b>	20 – 33 (2.0 – 3.4/15 – 25)	28 – 45 (2.8 – 4.6/20 – 33)		36 – 60 (3.7 – 6.1/27 – 44)
<b>M12 × 1.25</b>	49 – 74 (5.0 – 7.5/36 – 54)	61 – 91 (6.2 – 9.3/45 – 67)		76 – 114 (7.7 – 11.6/56 – 84)
* <b>M12 × 1.75</b>	45 – 69 (4.6 – 7.0/33 – 51)	57 – 84 (5.8 – 8.6/42 – 62)		72 – 107 (7.3 – 10.9/53 – 79)
<b>M14 × 1.5</b>	77 – 115 (7.8 – 11.7/56 – 85)	93 – 139 (9.5 – 14.2/69 – 103)		114 – 171 (11.6 – 17.4/84 – 126)
* <b>M14 × 2.0</b>	72 – 107 (7.3 – 10.9/53 – 79)	88 – 131 (9.0 – 13.4/65 – 97)		107 – 160 (10.9 – 16.3/79 – 118)
<b>M16 × 1.5</b>	104 – 157 (10.6 – 16.0/77 – 116)	135 – 204 (13.8 – 20.8/100 – 150)		160 – 240 (16.3 – 24.5/118 – 177)
* <b>M16 × 2.0</b>	100 – 149 (10.2 – 15.2/74 – 110)	129 – 194 (13.2 – 19.8/96 – 143)		153 – 230 (15.6 – 23.4/113 – 169)
<b>M18 × 1.5</b>	151 – 226 (15.4 – 23.0/110 – 166)	195 – 293 (19.9 – 29.9/144 – 216)		230 – 345 (23.4 – 35.2/169 – 255)
* <b>M18 × 2.5</b>	151 – 226 (15.4 – 23.0/110 – 166)	196 – 294 (20.0 – 30.0/145 – 217)		231 – 346 (23.6 – 35.5/171 – 255)
<b>M20 × 1.5</b>	206 – 310 (21.0 – 31.6/152 – 229)	270 – 405 (27.5 – 41.3/199 – 299)		317 – 476 (32.3 – 48.5/234 – 351)
* <b>M20 × 2.5</b>	190 – 286 (19.4 – 29.2/140 – 211)	249 – 375 (25.4 – 38.2/184 – 276)		293 – 440 (29.9 – 44.9/216 – 325)
<b>M22 × 1.5</b>	251 – 414 (25.6 – 42.2/185 – 305)	363 – 544 (37.0 – 55.5/268 – 401)		425 – 637 (43.3 – 64.9/313 – 469)
* <b>M22 × 2.5</b>	218 – 328 (22.2 – 23.4/161 – 242)	338 – 507 (34.5 – 51.7/250 – 374)		394 – 592 (40.2 – 60.4/291 – 437)
<b>M24 × 2.0</b>	359 – 540 (36.6 – 55.0/265 – 398)	431 – 711 (43.9 – 72.5/318 – 524)		554 – 831 (56.5 – 84.7/409 – 613)
* <b>M24 × 3.0</b>	338 – 507 (34.5 – 51.7/250 – 374)	406 – 608 (41.4 – 62.0/299 – 448)		521 – 782 (53.1 – 79.7/384 – 576)

An asterisk (\*) indicates that the bolts are used for female threaded parts that are made of soft materials such as casting. Those shown in parentheses in the strength class indicate the classification by the old standard.

**FLANGED HEAD BOLT**

kgf·m (lb.ft/N·m)

Bolt Identification  Bolt Diameter × pitch (mm)			
<b>M6 × 1.0</b>	5 – 9 (0.5 – 0.9/4 – 7)	6 – 12 (0.6 – 1.2/4 – 9)	—————
<b>M8 × 1.25</b>	11 – 20 (1.1 – 2.0/8 – 15)	15 – 28 (1.6 – 2.9/12 – 21)	18 – 34 (2.1 – 3.4/15 – 25)
<b>M10 × 1.25</b>	23 – 39 (2.4 – 3.9/17 – 28)	35 – 59 (3.6 – 6.1/26 – 44)	42 – 71 (4.3 – 7.2/31 – 52)
* <b>M10 × 1.5</b>	22 – 37 (2.3 – 3.8/17 – 28)	35 – 58 (3.5 – 5.8/25 – 42)	40 – 67 (4.1 – 6.8/30 – 49)
<b>M12 × 1.25</b>	55 – 82 (5.6 – 8.4/40 – 61)	77 – 117 (7.9 – 11.9/57 – 86)	85 – 128 (8.7 – 13.0/63 – 94)
* <b>M12 × 1.75</b>	51 – 77 (5.2 – 7.8/38 – 56)	71 – 107 (7.3 – 10.9/53 – 79)	80 – 119 (8.1 – 12.2/59 – 88)
<b>M14 × 1.5</b>	83 – 125 (8.5 – 12.7/62 – 92)	115 – 172 (11.7 – 17.6/85 – 127)	123 – 185 (12.6 – 18.9/91 – 137)
* <b>M14 × 2.0</b>	77 – 116 (7.9 – 11.8/57 – 85)	108 – 162 (11.1 – 16.6/80 – 120)	116 – 173 (11.8 – 17.7/85 – 128)
<b>M16 × 1.5</b>	116 – 173 (11.8 – 17.7/85 – 128)	171 – 257 (17.4 – 26.2/126 – 190)	177 – 265 (18.0 – 17.1/130 – 196)
* <b>M16 × 2.0</b>	109 – 164 (11.2 – 16.7/81 – 121)	163 – 244 (16.6 – 24.9/120 – 180)	169 – 253 (17.2 – 25.8/124 – 187)


A bolt with an asterisk (\*) is used for female screws of soft material such as cast iron.

## TIGHTENING TORQUES FOR MAIN PARTS



Cylinder head cover, cylinder head, camshaft bracket, rocker arm shaft bracket

N·m (kgf·m/lb·ft)




F08E100027



Lower crankcase, connecting rod bearing caps, crank damper pulley, flywheel, oil pan

N·m (kgf·m/lb·ft)




F05E100051



Front cover, flywheel housing, idler gear

N·m (kgf·m/lb·ft)




F06E100065





# Intake manifold, exhaust manifold, turbocharger

N·m (kgf·m/lb·ft)




F06E100024



Cooling system

N·m (kgf·m/lb·ft)




F06E100029



Lubricating system

N·m (kgf·m/lb·ft)




F06E100025



Fuel system

N·m (kgf·m/lb·ft)




F08E100061




Engine electrical, mounting bracket

N·m (kgf·m/lb·ft)



## MODEL AND IDENTIFICATION SERIAL NUMBERS

### ENGINE MODEL AND SERIAL NUMBER



The engine model and serial number are stamped in the middle of the lower left side of the cylinder block (crankcase).



---

**CHAPTER 2**  
**MAINTENANCE**  
**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
Lubricating system .....	22
Fuel system .....	24
Cooling system .....	27
Valve clearance adjustment .....	28
Fuel injection timing .....	30
Recommended lubricating oil .....	33
Cylinder compression pressure .....	34
Engine repair kit .....	35


**Note:**

See the "Operating Manual" for specifications regarding fuel filter and oil filter replacement periods.




## LUBRICATING SYSTEM

### REPLACEMENT OF MAIN OIL FILTER ELEMENT (CARTRIDGE TYPE)



#### Removal

1. Remove the drain plug and drain the oil from the filter. Place a receptacle beneath the drain port to contain the drained oil. Removing the plug at the top of the main filter will facilitate draining the oil.




2. After draining the oil, replace the filter's drain plug.

Drain plug tightening torque N·m (kgf·m/lb·ft)

First	Second	Third
22 ~ 31 (2.2 ~ 3.2/16 ~ 23)	Loosen	13 ~ 23 (1.3 ~ 2.3/9 ~ 17)


3. Place a wrench on the cartridge's second hex lug and rotate counter-clockwise to remove the cartridge. Discard the removed cartridge.



#### Installation

1. Clean the cartridge mounting surface on the engine.
2. Lightly apply a film of clean engine oil to the gasket on the new cartridge.
3. Screw the cartridge in lightly until the gasket surface contacts the mounting surface on the engine.
4. Using a filter wrench, tighten the filter by turning one revolution more.
5. After replenishing engine oil to the designated capacity, start the engine and check for leaks around the filter.
6. Stop the engine, wait for 10 — 20 minutes, then recheck the engine oil level and replenish if necessary.



**REPLACING THE PARTIAL FLOW OIL FILTER ELEMENT (CARTRIDGE TYPE)**

050E100014

**Removal**


Use an oil filter wrench to rotate the filter cartridge counter-clockwise and remove. Be careful not to spill the oil contained in the filter.

**Installation**

1. Apply a thin film of clean engine oil to the new cartridge gasket.
2. Screw in the new filter element until its gasket contacts the mounting surface, then use the filter wrench to tighten the element by turning between 1 and 1 and 1/8 turns more.


## FUEL SYSTEM

### REPLACING THE FUEL FILTER ELEMENT (CARTRIDGE TYPE)



#### Removal

1. Remove the drain plug at the bottom of the filter, and drain out any fuel inside the cartridge. Place a receptacle beneath the cartridge to prevent soiling surrounding engine parts.
2. Using a filter wrench, rotate the cartridge counter-clockwise to loosen. Discard the removed filter cartridge. Filter wrench: commercially available




#### Installation



1. Clean the cartridge installation surface on the engine.
2. Apply a thin film of clean engine oil to gasket surface of the new filter cartridge.
3. To facilitate air bleeding, fill the filter with fuel.
4. Lightly screw in the filter cartridge until its gasket contacts the installation surface on the engine.
5. Using a filter wrench, tighten the cartridge by an additional 1/2 to 3/4 turn.

#### Note:

**Be careful not to overtighten the cartridge, since it could twist and cause a fuel leak.**



#### Inspection of overflow valve


Inspect the overflow valve for clogging. Check for suction leakage on the ball side.

Overflow valve opening pressure                      kPa (kgf/cm<sup>2</sup>/psi)

245 (2.5 / 36)
----------------

041E10007

## INJECTION NOZZLE




### Opening Pressure and Spray Condition Check

- Use an injection nozzle tester to check the nozzle opening pressure.  
If the opening pressure is above or below the specified value, the injection nozzle must be replaced or adjusted.  
Refer to "Adjustment of Injection Nozzle Opening Pressure."

injection nozzle opening pressure          MPa (kg/cm<sup>2</sup>/psi)

1st stage	17.7 (180/2570)
2nd stage	22.1 (225/3200)



### WARNING:

**Test fluid from the injection nozzle tester will spray out of the injection nozzle under great pressure. It can easily puncture a person's skin.**


**Keep your hands away from the injection nozzle at all times.**

- Check the spray condition.  
If the spray condition is bad, the injection nozzle must be replaced or reconditioned.
  - Correct
  - Incorrect (Restrictions in orifice)
  - Incorrect (Dripping)

### Injection Nozzle Adjustment

Refer to "Injection Nozzle" in this manual.

## FEED PUMP STRAINER



04DA100001




### Cleaning the strainer

1. Remove the feed pump joint bolt (1).
2. Use a screwdriver to remove the strainer (2) from inside the joint bolt.
3. Wash the strainer in clean diesel fuel.



## WATER SEPARATOR (WATER SEDIMENTER)

(If so equipped)



### Inspect Float Level

Inspect the water separator's float level.

If the float is above the "water bleed level," loosen the drain plug and allow the water to drain, then retighten the drain plug securely.




Drain plug tightening torque N·m (kgf·m/lb·ft)

2.9 ~ 3.9 (0.3 ~ 0.4 / 2.2 ~ 2.9)
-----------------------------------

## AIR BLEEDING

### Air bleeding


1. Loosen the fuel injection pump's feed pump cap (1).
2. Loosen the fuel filter's overflow valve (2).
3. Operate the feed pump's handle up and down, and fill the filter with fuel, then retighten the level loosened in step 2.
4. Continue to operate the feed pump; the air bleeding is completed when the handle becomes difficult to move and the sound of air passing through the orifice can be heard.
5. Operate the feed pump several times, and check to confirm that no fuel leaks from the feed pump or fuel filter.
6. Tighten the feed pump cap securely.



041E100009

## COOLING SYSTEM

### COOLING FAN DRIVE BELT



033E100002




#### Inspection and Adjustment of Belt Tension

1. Check the cooling fan drive belt for cracking and other damage.
2. Exert a force of 100 N (10kg/22lb) at a point midway between the fan pulley ① and alternator pulley ②, and measure the belt deflection.
3. Loosen the alternator mounting bolt and adjust plate bolt, and adjust the tension by moving the alternator. Following adjustment, be sure to retighten the loosened bolts.

Fan belt deflection mm (in)

8.5 – 10.5 (0.30 – 0.41)
--------------------------



031EY00027



### THERMOSTAT

#### Inspection

Visually inspect the thermostat; if excessive wear or damage is detected, replace the thermostat. Measure the amount of valve lift.

Valve lift at 90 °C (194 °F) mm (in)

10 (39) or more
-----------------

Valve opening temperature °C (°F)

76.5 (170)
------------

## VALVE CLEARANCE ADJUSTMENT

**Note:**

Tightening of cylinder head bolts is performed by the "angular tightening method"; as a result, no re-tightening is necessary prior to valve clearance adjustment. Adjust the valve clearance when the engine is cold.


**Checking for mounting bolt looseness**

Before adjusting the valve clearance, check the rocker arm bracket mounting bolts for looseness, and retighten if necessary.


Rocker arm bracket mounting bolt tightening torque

N·m (kgf·m/lb·ft)

14 – 24 (1.4 – 2.4 / 10 – 17)
-------------------------------



020E100001



040E100030


**Adjustment**

1. Rotate the crankshaft clockwise to bring the TDC mark ① on the flywheel in alignment with the timing pointer ② on the flywheel housing. At this time, if the S-mark on the drive-side flange of the injection pump coupling is in alignment with the pointer, the No. 1 cylinder's piston is in the TDC position of the compression stroke.

2. Adjust the valve clearance when either the No. 1 cylinder or No. 6 cylinder is in the TDC position as noted below.

Valve clearance (intake and exhaust) mm (in)

0.4 (0.016) (cold engine)
---------------------------



3. When the No. 1 cylinder is at the TDC position on the compression stroke, adjust the valves indicated by arrows in the illustration (valve indicated by a circle in the table).

4. Loosen the locknut on the adjust screw affixed to the rocker arm, and place a feeler gauge of the proper thickness between the rocker arm and valve stem end.

5. Tighten the adjust screw until a slight amount of resistance is felt in the movement of the feeler gauge.

6. Taking care not to allow the adjust screw to turn, tighten the locknut.




Locknut tightening torque N·m (kgf·m/lb·ft)


15 – 25 (1.5 – 2.5 / 11 – 18)
-------------------------------

7. Following adjustment with the No. 1 cylinder at the TDC position, rotate the crankshaft one full turn.

8. Once again, align the flywheel's TDC mark with the pointer on the flywheel housing (the No. 6 cylinder will be at compression TDC).



014E100002




9. Adjust the clearance of the remaining valves noted by the arrows in the illustration (indicated by •• in the table).

Cylinder No.	1		2		3		4		5		6	
	In-take	Ex-haust	In-take	Ex-haust	In-take	Ex-haust	In-take	Ex-haust	In-take	Ex-haust	In-take	Ex-haust
No.1 cylinder (compression TDC)	•	•	•			•	•			•		•
No. 6 cylinder (compression TDC)				•	•			•	•		•	•



## FUEL INJECTING TIMING

### INJECTION TIMING INSPECTION



015E100049




#### Inspection

1. To set the injection for the proper timing, rotate the crankshaft clockwise, aligning the engraved line (compression BTDC) on the flywheel (1) with the flywheel housing pointer (2).

Injection timing (B.T.D.C) deg

$7^{\circ}$	
-------------	--




040E100037



2. Confirm that the line engraved on the pump body is aligned with the line engraved on the timer side.
3. If the line engraved on the pump body is not aligned with the line engraved on the timer side, align the timer mark with the pump body mark, adjusting the coupling bolts.  
After adjusting, tighten the coupling bolts to the specified torque.

### ADJUSTING THE INJECTION TIMING




040E100026



#### Adjustment

1. Remove the No. 1 injection pipe.  
This is done to allow visual confirmation of the beginning of the fuel injection at the No. 1 plunger.



040E100023



2. Remove the No. 1 delivery valve holder (1), washer (2), valve spring (3), and delivery valve (4).

#### Note:

**When removing the delivery valve, be careful not to allow dirt to enter the injection pipe.**




3. Install the delivery valve holder, and tighten to the designated torque.  
Do not install the delivery valve spring or delivery valve at this time, since they are installed only after completing this procedure.

Delivery valve holder tightening torque N·m (kgf·m/lb·ft)


108 – 118 (11.0 – 12.0 / 80 – 87)
-----------------------------------

**Note:**


**Over-tightening or under-tightening the delivery valve holder may cause engine hunting or fuel leakage.**




4. Keep the fuel control lever at the full open position.



5. Loosen the coupling plate's two joint bolts.
6. Rotate the automatic timer clockwise.




7. While operating the feed pump, confirm that fuel flows out from the No. 1 delivery valve holder.
8. While confirming the outflow of fuel, slowly rotate the automatic timer counterclockwise, and the fuel flow will gradually decrease, and finally stop. This position is the fuel injection beginning point.



9. Tighten the two coupling plate joint bolts to the designated torque.

Joint bolt tightening torque N·m (kgf·m/lb·ft)


103 – 113 (10.5 – 11.5 / 76 – 83)
-----------------------------------



015E100049



10. While operating the feed pump, slowly rotate the crankshaft clockwise, and at the point the fuel flow stops from the No. 1 delivery valve holder, confirm that the pointer (2) on the flywheel housing is aligned with the 7° mark engraved on the flywheel (1).



040E100023




11. Remove the No. 1 plunger delivery valve holder (1), and insert the valve spring (3) and delivery valve (4). Install the washer (2) and delivery valve holder, and tighten to the designated torque.



Delivery valve holder tightening torque N·m (kgf·m/lb·ft)

108 – 118 (11.0 – 12.0 / 80 – 87)
-----------------------------------



040E100026



12. Install the No. 1 plunger delivery valve, and screw on the feed pump cap.

**Note:**


**The feed pump may be damaged if the engine is started when the feed pump cap is not screwed on.**

## RECOMMENDED LUBRICATING OIL

### ENGINE CLASS AND ENGINE OIL GRADE

Engine class	Turbocharged diesel engine
Engine oil grade (API service class)	CD grade


### ENGINE OIL VISCOSITY CHART



Since the choice of engine oil viscosity influences the engine's starting characteristics, driving characteristics, oil consumption, friction wear, piston scorching, and other aspects of engine performance, be sure to choose the oil used in accordance with the ambient temperature, as indicated in the chart.

## CYLINDER COMPRESSION PRESSURE

### MEASURING THE COMPRESSION PRESSURE



F06E100003

#### Measurement

1. Start the engine and operate until warm.  
(The radiator coolant must be about 80°C at the time of this measurement)
2. Remove all glow plugs.
3. Install the adapter and compression gauge in the No. 1 cylinder's glow-plug hole.  
Compression gauge: (commercially available)  
Gauge adapter: 5-85317-001-0
4. Make sure that the fuel delivery lever is close (no fuel being sent to the engine).
5. Use the starter to crank the engine, and read the value from the compression gauge's indicator needle.  
Perform each measurement at least twice.

Cylinder compression pressure (Sea level, 200 rpm)

MPa (kgf/cm<sup>2</sup>/psi)

Standard	Limit
2.84 (29/410)	2.06 (21/300)

The measured compression pressure at each cylinder indicates the approximate value. The variation in pressure between cylinders must not exceed the limit value noted below.

kPa (kgf/cm<sup>2</sup>/psi)


Limit variation of pressure between cylinders	196 (2/28)
---	------------

If the measured pressure exceeds the absolute limit value or the limit for variation between cylinders, inspect all items related to compression pressure.

6. Repeat steps 3 and 5 for the remaining cylinders. If the measured value is less than the designated value, consult the troubleshooting section of this manual, and repair as required.

## ENGINE REPAIR KIT

THE PARTS SHOWN BELOW ARE INCLUDED IN THE ENGINE REPAIR KIT.



005E100001

- |                              |                                     |
|------------------------------|-------------------------------------|
| 1. Head cover nut seal       | 17. Leakoff pipe gasket             |
| 2. Head cover gasket         | 18. Injection nozzle gasket         |
| 3. Cylinder head gasket      | 19. Bearing case gasket             |
| 4. Valve guide seal          | 20. Water pump gasket               |
| 5. thermostat housing gasket | 21. Water pump gasket               |
| 7. Intake cover gasket       | 22. Oil level switch gasket         |
| 9. Exhaust manifold gasket   | 23. Thermostat housing gasket       |
| 10. Drain plug gasket        | 24. Intake pipe gasket              |
| 11. Fuel pipe gasket         | 26. Turbocharger gasket             |
| 12. Oil pan gasket           | 27. Turbocharger feed pipe gasket   |
| 13. Front oil seal           | 28. Turbocharger return pipe gasket |
| 14. Rear oil seal            | 29. Turbocharger return pipe gasket |
| 15. Oil relief valve gasket  | 30. Turbocharger return pipe gasket |
| 16. Oil cooler gasket        |                                     |



---


**CHAPTER 3**  
**ENGINE I**  
**(DISASSEMBLY)**  
**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
External view .....	38
Disassembly 1 .....	39
Disassembly 2 .....	42
Disassembly 3 .....	45
Cylinder head ASM disassembly .....	49
Rocker arm shaft ASM disassembly .....	51
Piston and connecting rod disassembly .....	52




## EXTERNAL VIEW

(Left side view)



F06E100010


(Right side view)



**Note:**  
Specification may vary according to the type of equipment on which the engine is installed.

F06EY00171


## DISASSEMBLY 1



FORE100011

### Disassembly sequence

- |                               |                                 |
|-------------------------------|---------------------------------|
| 1. Cooling fan                | 14. Oil pipe                    |
| 2. Fan guide                  | 15. Oil pipe                    |
| 3. Alternator                 | ▲16. Injection pump             |
| 4. Fan belt                   | 17. Coupling ASM                |
| 5. Water pipe                 | ▲18. Intake cover               |
| 6. Air duct                   | 19. Starter motor               |
| 7. Intake pipe                | 20. Oil dipstick                |
| 8. Fuel pipes                 | 21. Oil feed pipe               |
| ▲9. Injection pipe            | 22. Oil return pipe             |
| 10. Fuel leakoff pipe         | ▲23. Turbocharger               |
| 11. Fuel filter               | 24. Oil pipe                    |
| ▲12. Glow plug and connectors | ▲25. Oil cooler with oil filter |
| ▲13. Nozzle holder            | 26. Partial oil filter          |
|                               | 27. Exhaust manifold            |



040E100003




## IMPORTANT OPERATIONS

### 9. Fuel injection pipe

- (1) Loosen the sleeve nut ① on the delivery valve side of the fuel injection pipe. Take care not to exert excessive force on the injection pipe when doing this.
- (2) Loosen the clip ②.
- (3) Remove the fuel injection pipe ③.

#### Note:

**In order to prevent dirt and other foreign materials from entering the delivery valve, place a plastic cap over the hole in the delivery valve holder.**



040E100004

### 12. Glow plugs and connectors


#### 13. Nozzle holders

If the nozzle is to be reused, it must be installed in its original position.

#### Note:

**Use paper labels or tags to mark the cylinder numbers of the nozzles.**


**Take care not to damage the nozzle tips.**



040E100009

### 16. Injection pump

- (1) Remove the two coupling bolts and separate the injection pump from the coupling.
- (2) Remove the injection pump's four mounting bolts.
- (3) Remove the injection pump.




025E100001

### 18. Intake cover

A sealant has been applied to the intake cover at time of assembly.


Screw holes (M8 x 1.25) are provided at both ends of the intake cover; using bolts of the appropriate size (M8 x 1.25, shaft length 30 mm or more), screw in the bolts evenly on both sides to press away the cover, and remove.



038E100002

**23. Turbocharger**

To prevent entry of foreign material, attach a cap to the turbocharger's oil port after removal of the oil pipe.




050E100015

**25. Oil cooler (with oil filter)**

- (1) Remove the oil drain plug (1) and allow the oil to drain from inside the filter.
- (2) Loosen the water drain plug (2) and drain the coolant.
- (3) Remove the oil cooler mounting bolt.
- (4) Use a plastic hammer to lightly strike the periphery of the oil cooler case, and remove the oil cooler.

## DISASSEMBLY 2




F05E100035



### Disassembly sequence

- |   |                                      |
|---|--------------------------------------|
| 1. Cylinder head cover                          | 8. Cylinder head gasket              |
| 2. Head cover gasket                            | 9. Water pump pulley                 |
| 3. Camshaft upper bracket                       | 10. Water pump                       |
| ▲4. Camshaft                                    | ▲11. Crankshaft pulley (with damper) |
| ▲5. Rocker arm shaft assembly                   | 12. Front cover                      |
| 6. Thermostat housing<br>(with thermostat unit) | ▲13. Flywheel                        |
| ▲7. Cylinder head                               | 14. Flywheel housing                 |



014E100045



## IMPORTANT OPERATIONS



### 4. Camshaft

- (1) Fully loosen the rocker arm's adjust screw, and measure the gap at the end of the camshaft.


Camshaft axis gap mm (in)

Standard	Limit
0.055 ~ 0.205 (0.0022 ~ 0.0081)	0.40 (0.016)

- (2) Gradually loosen the camshaft bracket bolts in the order shown.

#### Note:

The camshaft may be adversely affected if one bracket bolt is fully loosened all at once. As a result, be sure to loosen the bolts gradually in the numbered sequence. Protect the bearing surface of the camshaft upper bracket to prevent damage.




014E100005

### 5. Rocker arm shaft assembly

- Gradually loosen the rocker arm lower bracket bolts in the sequence shown.

#### Note:

The rocker arm shaft may be adversely affected if one bolt is fully loosened all at once. As a result, be sure to loosen the bolts gradually in the numbered sequence.




014E100006

### 7. Cylinder head

- Loosen the cylinder head bolts evenly in the sequence shown.

#### Note:


The lower surface of the head may be damaged if one bolt is fully loosened at once. As a result, be sure to loosen the bolts gradually in the numbered sequence.




011E100025

### 11. Crankshaft pulley (with damper)

- (1) Insert a steel bar or wedge into the flywheel ring gear to prevent the crankshaft from turning.
- (2) Loosen the crankshaft pulley's mounting bolts, and remove the pulley.



015E100001




015E100057

**13. Flywheel**

Stop the crankshaft from turning, and loosen the bolts gradually in the sequence shown.

## DISASSEMBLY 3



F08E100005



### Disassembly sequence

- ▲15. Idler gear "A"
- 16. Idler gear shaft "A"
- ▲17. Idler gear "B"
- 18. Idler gear shaft "B"
- 19. Oil pan
- 20. Oil pump
- 21. Anti-drain valve
- ▲22. Connecting rod bearing cap  
(with lower bearing)
- ▲23. Piston and connecting rod  
(with upper bearing)
- ▲24. Cylinder block lower crankcase
- ▲25. Crankshaft lower bearing
- ▲26. Thrust bearing
- 27. Crankshaft
- ▲28. Crankshaft upper bearing
- 29. Oil jet
- 30. Cylinder block






**IMPORTANT OPERATIONS**



- 15. Idler gear "A"
- 17. Idler gear "B"

Before removing the idle gear, measure each gear's backlash and end play.



014E100007



**Backlash measurement**

- (1) Attach a dial gauge to the idle gear to be measured.


**Note:**

**When the gear to be measured is meshed with another gear, fix that gear in position and prevent it from moving.**

- (2) Move the gear to be measured to left and right, and read the fluctuation of the needle on the dial gauge. If the measured value exceeds the limit value, replace the timing gear.

Backlash mm (in)

Standard	Limit
0.1 (0.0039) or less	0.3 (0.012)



014E100008




**Measuring idler gear end play**


- (1) Insert a feeler gauge between the idle gear and the thrust washer, and measure the gap.
- (2) If the measured value exceeds the limit value, replace the thrust washer or the gear.

Idle gear end play mm (in)


Standard	Limit
0.04 ~ 0.19 (0.0016 ~ 0.0075)	0.30 (0.012)




012E10003



015E10003



015E10004



012E100031

**22. Connecting rod bearing cap (with lower bearing)**

**23. Piston and connecting rod (with upper bearing)**

- (1) Before removing the piston and connecting rod, remove any carbon deposits on the upper portion of the cylinder liner.
- (2) Set the piston at the BDC position, remove the connecting rod cap, then rotate the crankshaft and bring the piston to the TDC position. Lightly tap the connecting rod's large end with the handle of a hammer to drive the piston out with the connecting rod attached.

**Note:**

**When removing the piston, take care not to damage the cylinder liner and oiling jet.**

**If the connecting rod bearings are to be reused, attach a tag clearly indicating the position from which each is removed.**

**24. Cylinder block lower crankcase**



- (1) As shown in the illustration, measure the end play at the rear end of the crankshaft. Perform this measurement before removing the lower crankcase. If the measurement exceeds the limit value, replace the thrust bearing.

Crankshaft end play mm (in)

Standard	Limit
0.10 ~ 0.285 (0.0039 ~ 0.0112)	0.40 (0.016)



- (2) Loosen the lower crankcase bolts in the following sequence:


First stage: Loosen the M10 bolts on the outer edge of the crankcase

Second stage: Gradually loosen the M14 bolts ① — ⑭ on the inside edge of the crankcase in the numerical order shown.

Third stage: Screw the removed M10 bolts in the replacer holes (1) and tighten evenly, pressing the lower crankcase out and away to remove.

**Note:**

**The cylinder block and lower crankcase are manufactured as a single unit; as a result, if it is necessary to replace either one, both must be replaced together.**



012E100005


**25. Crankshaft lower bearing**

**26. Thrust bearing**

**28. Crankshaft upper bearing**

If the bearings are to be reused, be sure to attach a tag clearly indicating the position from which each one is removed.

## CYLINDER HEAD DISASSEMBLY



012E100006




### Disassembly sequence

1. Thermostat housing
2. Idler gear cover
3. Idler gear gasket
4. Idler gear shaft "C"
- ▲5. Idler gear "C"
- ▲6. Split collar
7. Valve spring upper seat
8. Valve spring
9. Valve spring lower seat
- ▲10. Intake and exhaust valves
11. Cylinder head



**IMPORTANT OPERATIONS**



014E100009




**5. Idler gear "C"**

- (1) Using a feeler gauge, measure the idler gear "C" end play.

Idler gear "C" end play mm (in)

Standard	Limit
0.047 ~ 0.218 (0.0019 ~ 0.0086)	0.40 (0.016)

- (2) Remove the idler gear.




014E100010



**6. Split collar**

- (1) Lay the cylinder head on a flat surface.
- (2) Use a spring compressor to remove the split collar.  
Take care not to allow the valve to fall from the head.  
Spring compressor: 1-85235-007-0




014A100001

**10. Intake and exhaust valves**

Attach a tag to each valve noting the position from which it was removed.  
When installing new valves, be sure to install new valve guides at the same time.

## ROCKER ARM SHAFT ASM DISASSEMBLY



014E100012




### Disassembly sequence

- |                            |                       |
|----------------------------|-----------------------|
| 1. Split pin               | 4. Rocker arm spring  |
| ▲2. Camshaft lower bracket | 5. Rocker arm bracket |
| ▲3. Rocker arm             | 6. Rocker arm shaft   |




### IMPORTANT OPERATIONS



014E100046

2. **Camshaft lower bracket**  
Be sure to store the removed upper (1) and lower (2) brackets together (note alignment mark (3) ).




014E100047

3. **Rocker arm**  
If the removed rocker arms are to be reused, be sure to label with tags noting the cylinder number and whether for intake or exhaust.

**Note:**  
**In the movable portion of the adjust screw, the "ball" is peened to match the "pan", so do not subject it to excessive shock.**

## PISTON AND CONNECTING ROD DISASSEMBLY



015E100047




### Disassembly sequence

- ▲1. Connecting rod bearing
- ▲2. Piston ring
- ▲3. Snap ring
- ▲4. Piston pin
- 5. Connecting rod
- 6. Piston




## IMPORTANT OPERATIONS



015E100006

### 1. Connecting rod bearing

If the connecting rod bearings are to be reused, mark each one with the cylinder number so that they are reinstalled in the same position.




014E100060



### 2. Piston ring


- (1) Fix the connecting rod in a vice.  
Take care not to damage the connecting rod.
- (2) Use a piston pin replacer to remove the piston rings.  
Piston ring replacer: 1-85221-029-0  
Do not use other tools to remove the rings, since they may stretch the rings, resulting in reduced ring tension.



015E100023

### 3. Snap ring

Use a pair of snap ring pliers to remove the piston pin snap ring.



015E100007

### 4. Piston pin

Remove the piston pin by lightly tapping with a hammer and a brass bar.  
If the piston pins are to be reused, label each one with the cylinder number, and be sure to replace in the same location.





---


**CHAPTER 4**  
**ENGINE II**  
**(INSPECTION AND REPAIR)**  
**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
<b>Inspection and repair (1) (Cylinder head)</b>	
Cylinder head .....	56
Valve guides .....	57
Valve seat insert .....	58
Valve springs .....	61
Rocker arm shaft, rocker arm .....	62
Camshaft .....	64
<b>Inspection and repair (2) (Cylinder block)</b>	
Cylinder block, cylinder liner .....	66
Pistons .....	71
Piston ring .....	72
Piston pins .....	73
Connecting rods .....	74
Crankshaft .....	75
Crankshaft and bearings .....	76
Front cover oil seal .....	83
Crankshaft rear oil seal .....	84

## INSPECTION AND REPAIR (1) (Cylinder Head)

If excessive wear or damage is discovered during inspection, the appropriate parts must be adjusted, repaired, or replaced.

### CYLINDER HEAD



011EY00066



#### Warpage of lower face of cylinder head


1. Use a straight edge (ruler) and a feeler gauge to measure the warpage of the four sides and the two diagonals of the lower face of the cylinder head as shown.
2. If the measured values are greater than the specified limit, the cylinder head must be replaced.

Warpage of lower face of cylinder head mm (in)


Standard	Limit
0.05 (0.002) or less	0.2 (0.0079)

#### Note:

**Lower face of cylinder head can not be reground because 6SD1 model has overhead camshaft construction with the valve gear train.**



011EY00067



011E100004




#### Cylinder head height

Cylinder head height (reference); H mm (in)

Standard	Limit
173.0 ~ 173.025 (6.811 ~ 6.812)	172.775 (6.8022)

#### Note:

**Do not regrind the lower face of the cylinder head.**



011E100005


#### Water jacket pressure test

1. Blow air in the water jacket to check for blockages.
2. In the hydraulic pressure test, apply the designated pressure for 3 minutes and check all parts for water leaks.

kPa(kgf/cm<sup>2</sup>/psi)

Test Pressure	490 (5/71)
---------------	------------

## VALVE GUIDES



014EY00062




### Clearance between valve stem and valve guide Measurement

1. With the valve stem inserted in the valve guide as shown, set a dial gauge with its needle to "0" at a point about 10 mm from the upper end of the guide.
2. Move the valve head forward and back and read the dial indicator, recording the maximum measurement. If the measured value is less than the limit value, the valve and valve guide must be replaced as a set.

Valve stem and valve guide clearance mm (in)

	Standard	Limit
Intake valve	0.040 ~ 0.077 (0.0016 ~ 0.0030)	0.15 (0.006)
Exhaust valve	0.065 ~ 0.102 (0.0026 ~ 0.0040)	0.20 (0.008)




011E100006



### Valve guide replacement

#### Removal

Use a hammer and valve remover to tap out the valve guide from the head's lower side toward the upper side.  
Valve guide remover: 9-8523-1202-2



011E100007



#### Installation

1. Apply clean engine oil the outer periphery of the valve guide.
2. Attach the installer to the valve guide.
3. Use a hammer to drive in the valve guide from the upper face of the head until the installer's lower edge meets the head surface.

Valve guide installer: 9-8523-1202-0


4. After installation, measure the distance (height) from the cylinder head's upper surface to the upper edge of the valve guide.

Height to valve guide upper edge; H mm (in)

22.0 (0.87)
-------------


#### Note:

**Whenever the valve guide is removed, always replace both valve and valve guide together with a new set.**



011EY00069

**VALVE AND VALVE SEAT INSERT**



014EY00185




**Valve stem diameter**

Use a micrometer to measure the valve stem diameter in three locations as shown.

If the measured value is less than the limit value, replace the valve and valve guide as a single set.

mm (in)

	Standard	Limit
Intake valve	10 (0.39)	9.92 (0.391)
Exhaust valve	10 (0.39)	9.90 (0.390)



**Valve thickness**


Inspect the valve seat for damage or step wear, then measure the thickness.

If the measured value is less than the limit value, both the valve and valve guide must be replaced with a new set.

Valve thickness mm (in)

	Standard	Limit
Intake valve	2.50 (0.098)	2.00 (0.079)
Exhaust valve	2.35 (0.092)	1.85 (0.073)

The same values apply to valves which have been reground



014EY00064




**Valve depression**

1. Install the valve (1) in the cylinder head (2).
2. Using a depth gauge or two rulers, measure the amount of depression from the lower face of the cylinder head to the surface of the valve head. If the measured value exceeds the limit, the valve seat insert must be replaced.

Valve depression mm (in)

	Standard	Limit
Intake valve	0.48 (0.019)	1.48 (0.058)
Exhaust valve	1.60 (0.063)	2.60 (0.10)



014EY0065




**Valve contact width**

1. Inspect the valve contact for roughness and unevenness.  
If necessary, smooth the surface of the valve contact.
2. Measure the contact surface width.  
If the measured value exceeds the limit, the valve seat insert must be replaced.

Valve contact width mm (in)

	Standard	Limit
Intake valve	2.7 (0.106)	3.5 (0.138)
Exhaust valve	2.4 (0.094)	3.2 (0.126)



011E100931




**Valve insert replacement**

**Removal**



1. Use an acetylene torch to heat the inner surface of the valve seat insert on two opposing sides (700 ~ 800°C).
2. Allow the insert to cool for 3 ~ 5 minutes (do not cool too suddenly).
3. Use a screwdriver as shown to pry out the insert.  
Take care not to scar the cylinder liner.
4. Carefully remove any carbon deposits or other debris from the insert installation holes.



011EY0071



**Installation**

1. Place the attachment (1) (with smaller outside diameter than the valve seat insert) on top of the valve seat insert (2) as shown.

**Note:**

**Be sure the smooth surface of the attachment contacts the valve seat insert.**


2. Using a bench press (3), gradually apply pressure on the attachment so as to drive the valve seat insert into the head.

kN (kg)


Insertion pressure	9.81 ~ 14.7 (1000 ~ 1500)
--------------------	---------------------------

**Note:**


**When pressing the valve seat insert, to not apply excessive pressure since damage to the valve seat will result.**



011EY00032



011EY00072



011E100013

**Correction of the valve seat insert**

1. Remove carbon deposits from the surface of the valve seat insert.
2. Using valve cutters (blade angles 15°, 45°, 60°, 75°), or a valve seat grinder, trim the contact edge of the valve seat to remove scratches and roughness. This procedure can be used to return the contact surface width to standard values. When performing this repair, take care to remove only scratches and roughness, and do not cut away sound parts of the valve seat.

Valve seat angle

Intake side	30°
Exhaust side	45°


**Note:**

**Use an adjustable valve cutter.**

**Take care not to allow the valve cutter or seat grinder to wobble inside the valve guide.**

3. Apply cutting compound to the surface of the valve seat insert.
4. Use a valve grinder to lap the valve.
5. Following lapping, inspect for proper valve contact.

## VALVE SPRINGS




### Valve spring free height

Use calipers to measure the valve spring free height. If the measured value is less than the limit value, replace the spring.

Inner and outer spring free length mm (in)

	Intake side		Exhaust side	
	Standard	Limit	Standard	Limit
Inner	62.5 (2.46)	60.5 (2.38)	69.2 (2.72)	67.2 (2.65)
Outer	59.3 (2.33)	57.3 (2.26)	80.7 (3.18)	78.7 (3.10)




### Valve spring inclination

Using a surface plate and square, measure the valve spring inclination.

Inner and outer spring inclination mm (in)


	Limit
Inner	3.0 (0.12)
Outer	3.5 (0.14)



### Valve spring tension

Using a spring tester, measure the valve spring tension. If the measured value is more than 10% under the standard value, replace the spring.

	Intake side		Exhaust side	
	Compressed length (mm)	Standard N (kg)	Compressed length (mm)	Standard N (kg)
Inner	46.2	111.8 (11.4)	46.2	284.4 (29.0)
Outer	48.7	292.2 (29.8)	48.7	500.1 (51.0)




### Color Coding

Intake side spring (1)	Inner	Green
	Outer	Green
Exhaust side spring (2)	Inner	Yellow
	Outer	Yellow

014E100061



## ROCKER ARM SHAFT AND ROCKER ARM



014E100015




### Rocker arm shaft runout

1. Place the rocker arm shaft on a V-block.
2. Using a dial gauge, measure the rocker arm shaft runout in the center of the shaft. If the runout is very slight, it may be corrected with a bench press while cold.

If the measured value exceeds the limit value, the rocker arm shaft must be replaced.

Rocker arm shaft deflection (1/2 of runout) mm (in)

Limit
0.3 (0.012)



014E100016




### Rocker arm shaft diameter

Use a micrometer to measure the shaft diameter at the points where the rocker arms are attached.

If the measured value is less than the limit value, the rocker arm shaft must be replaced.

Rocker arm shaft diameter mm (in)

Standard	Limit
19.00 (0.748)	18.85 (0.742)



014E100017




### Rocker arm shaft and rocker arm clearance

1. Use inside calipers or an inside dial gauge to measure the inside diameter of the rocker arm bushing.
2. Measure the outside diameter of the rocker arm shaft.
3. Use the two measurements to calculate the clearance.


If the measured value exceeds the limit, replace either the rocker arm shaft or the rocker arm.

Rocker arm and rocker arm shaft clearance mm (in)

Standard	Limit
0.01 ~ 0.05 (0.0004 ~ 0.0020)	0.2 (0.0079)




014E100018



014E100017



4. Inspect the rocker arm oil ports to confirm that no clogging is present. If clogged, clean out debris by blowing with compressed air. Also check for any friction or unevenness on the roller surface.



014E100019



- Lower camshaft bracket**  
Inspect the oil ports on the bracket (rear side) for any clogging, and clean if necessary.


**CAMSHAFT**



**Inspection**

Visually check journals, cams, and camshaft brackets for excessive wear and other damage.

If any damage is evident, replace with a new part.



014E100062




**Journal diameter**

Use a micrometer to measure the diameter of each journal in both directions (1) and (2) as shown in the illustration.

If the measured value is less than the limit value, replace the camshaft.

Journal diameter mm (in)

Standard	Limit
39.915 ~ 39.940 (1.5726 ~ 1.5724)	39.89 (1.5704)



014E100020



**Camshaft and camshaft bracket clearance**

Use a dial gauge to measure the inner diameter of the bracket.


If the clearance between the camshaft bracket (inner diameter) and the camshaft journal (outer diameter) exceeds the limit value, replace either the camshaft bracket, or the camshaft, or both.

Camshaft bracket clearance mm (in)

Standard	Limit
0.06 ~ 0.11 (0.0024 ~ 0.0043)	0.16 (0.0062)

**Note:**

**when replacing one camshaft bracket, replace the entire parts set.**



014E100049

Cam height ; H = ① - ②


**Cam lobe height**

Use a micrometer to measure the cam lobe height.

If the measured value is less than the limit, the camshaft must be replaced.

Cam height; H mm (in)

Standard	Limit
5.92 (0.233)	5.56 (0.219)




**Camshaft runout**

Set a dial gauge on the No. 3 or No. 4 journal; rotate the shaft gently on full turn, and read the gauge. If the measured value exceeds the limit, the camshaft must be replaced.

Camshaft Runout mm (in)

Standard	Limit
0.05 (0.002)	0.10 (0.004)



014E10022



**Camshaft gear removal**

1. Remove the camshaft gear bolt.
2. Using a gear puller, remove the camshaft gear.


**Note:**

**When removing the gear, be careful not to damage the gear teeth.**

If the gear puller pressed directly against the teeth, the teeth may be deformed; as a result, a brass plate should be placed between the puller tip and the gear.

**Inspection**

Visually inspect the teeth of the camshaft gear; if any wear or damage is found, replace the gear.



014E10023



**Camshaft gear installation**

1. Insert the key in the camshaft key slot.
2. Apply clean engine oil to the threads of the gear bolt and the gear setting surface.
3. Install the gear with the large bossing (arrow) mounted toward the camshaft.



Camshaft gear tightening torque N·m (kgf·m/lb·ft)


114 ~ 171 (11.6 ~ 17.4 / 84 ~ 126)
------------------------------------

## INSPECTION AND REPAIR (2) (Cylinder block)



Visually inspect the cylinder block for wear, cracks, water leaks, and other abnormalities.

### CYLINDER BLOCK, CYLINDER LINER



012EY00030




#### Warpage of upper face of cylinder block

1. Remove the block's dowel pins.
2. Remove the cylinder liner.  
The procedure for removal is listed in the section "cylinder liner replacement."
3. Use a ruler (1) and feeler gauge (2) as shown to measure the four sides and diagnosis of the cylinder block's upper face for warpage.  
If the measured value exceeds the limit, replace the cylinder block.

Cylinder block upper face warpage mm (in)

Standard	Limit
0.05 (0.0020) or less	0.2 (0.0079)



011EY00067


#### Note:

**Do not attempt to use a surface grinder to regrind the upper face of the cylinder block.**

4. If the height of the cylinder block is less than the standard value, replace the cylinder block.

Cylinder block height (reference); H mm (in)

Standard
369.47 ~ 370.54 (14.546 ~ 14.588)



012E100009

5. Refer to the section "Cylinder Block Bore Measurement" for instructions on installation of the cylinder liner.
6. Install the dowel pins.




#### Cylinder liner bore measurement


Use a cylinder gauge to measure the bore of the cylinder liner at points ① and ④ in order to measure the thrust direction (② — ②) and axial (③ — ③) directions. Measuring point ① is 24 mm from the top face, while measuring point ④ is 120 mm from the top face. If the maximum measured values exceed the limit, replace the cylinder liner.

Cylinder liner bore mm (in)

Standard	Limit
120 (4.724)	120.3 (4.736)



012E100010



012E100011




### Measurement of cylinder liner projection

1. Place a straight edge ① along the top edge of the cylinder liner to be measured.
2. Using a feeler gauge ②, measures the projection of each cylinder liner.

Cylinder liner projection mm (in)

Standard
0.106 ~ 0.134 (0.0042 ~ 0.0053)

The difference in cylinder liner projection between any two neighboring cylinders must not exceed 0.02 mm.



012E100012




### Cylinder liner removal

1. Attach a cylinder liner remover to the cylinder liner.  
Cylinder liner remover : 1-85231-016-0
2. Confirm that the remover's shaft anchor is hooked firmly on the bottom of the cylinder liner.
3. Slowly rotate the remover's shaft handle clockwise to remove the cylinder liner.

#### Note:

**Be careful not to damage the upper face of the cylinder block when removing cylinder liners.**




012EY00036




### Cylinder block bore measurement


1. At measuring point ①, measure the cylinder block bore in the four directions (W-W, X-X, Y-Y, Z-Z).  
Measuring point ①: 120 mm from upper face.
2. Calculate the average value of the four measurements to determine the correct liner grade.



012E100014



012E100015



012E100016

**Selection of liner grade**

The "liner grade" mentioned here refers to the combination of the cylinder block bore (before insertion of the liner), and the outer diameter of the liner.

A liner which has an outside diameter that is too small (loose) for the cylinder block will result in poor cooling efficiency, leading to engine damage. Conversely, a liner that is too big for the block will be impossible to install properly.

In order to avoid such problems, it is important to measure the cylinder block bore to allow selection of the proper liner grade.



**Cylinder liner O.D. measurement**

1. Measure the outside diameter of the cylinder liner for both directions (X-X and Y-Y) at each of the three measuring points ①, ②, and ③.


Measuring points (distance from top face)	mm (in)
①	18 (0.71)
②	114 (4.49)
③	210 (8.27)

2. Calculate the average of the six measurements and use that figure when selecting the liner grade.

Standard Liner Interference	mm (in)
0.011 ~ 0.029 (0.00043 ~ 0.00114)	

Combination of cylinder block bore diameter and liner O.D.

Grade	Cylinder block bore	Liner O.D.
1	123.001 ~ 123.010 (4.8426 ~ 4.8429)	123.021 ~ 123.030 (4.8433 ~ 4.8437)
2	123.011 ~ 123.020 (4.8429 ~ 4.8433)	123.031 ~ 123.040 (4.8437 ~ 4.8441)
3	123.021 ~ 123.030 (4.8433 ~ 4.8437)	123.041 ~ 123.050 (4.8441 ~ 4.8445)



012E100017




### Cylinder liner installation

#### 1. When using special tools

- (1) Clean the outside of the liner and the inside walls of the cylinder block with clean kerosene or diesel fuel.
- (2) Used compressed air to dry off all cleaned surfaces.

#### Note:

**All engine oil and other foreign matter must be removed from the liner and cylinder block bore before installation.**



012E100018



- (3) Press in the liner ① from the top of the cylinder block ②.
- (4) Set the liner installer ③ on top of the liner as shown.  
Cylinder liner installer: 1-85221-073-0
- (5) Position the body so that the centerline of the installer ③ is aligned with the centerline of the bench press shaft ④.

#### Note:

**Set the body so that the liner is perpendicular to the bench press, taking care that no unevenness occurs between the liner and bench press.**

- (6) Use the bench press to apply an initial force of 5 kN (500 kg) on the liner, to press it into the cylinder block.
- (7) Next, apply 25 kN (2500 kg) of force to seat the liner fully.
- (8) After installation of the liner, measure the cylinder liner projection.

#### Note:

**The projection cannot be a negative value. Refer to the section "Measurement of Cylinder Liner Projection" (P.67).**

#### 2. Installation Using Dry Ice

Cooling the liner with dry ice will cause it to contract, facilitating installation.

#### Note:

**This method must be performed immediately after cooling the liner.**

#### WARNING:


**Dry ice must be handled with great care, since careless handling can result in severe frostbite.**



**Piston grade selection**

"Piston grade" means that the proper piston for the combination of piston O.D. and cylinder liner bore measurements.

Selection of the proper piston grade is important to allow optimum engine operation without damage to liner and pistons.



**Cylinder liner bore measurement**

After installation of the cylinder liner, measure the liner bore to allow selection of the proper piston grade.


1. Follow the instructions in the previous section on Cylinder Liner Bore Measurement, and measure the liner bore.  
 Measuring point ① .....120 mm from upper face  
 Measuring point ② .....216 mm from upper face
2. Take measurements in the four radial directions (W-W, X-X, Y-Y, X-X) at each of the measuring points ① and ②.
3. Calculate the average value from the eight measurements taken, and use that figure as the cylinder liner bore.

Cylinder liner bore		mm (in)
Standard		Limit
120 (4.724)		120.3 (4.7362)

**Note:**

**Selection of the proper piston grade is very important, since using an improper piston size will result in engine failure.**

# PISTON



015EY00062



### Piston outside diameter measurement

Measure the piston O.D., and select from either grade AX or CX so that the standard clearance is obtained between liner and piston.

Measurement point ① .....98 mm (3.86 in.) from piston face

Clearance between cylinder liner and piston	mm (in)
0.131 ~ 0.175 (0.0052 ~ 0.0069)	


Cylinder liner bore and piston O.D. for service parts  
mm (in)

Grade	Cylinder liner bore	Piston O.D.
AX	120.000 ~ 120.020 (4.7244 ~ 4.7252)	119.849 ~ 119.864 (4.7185 ~ 4.7191)
CX	120.021 ~ 120.040 (4.7252 ~ 4.7260)	119.865 ~ 119.890 (4.7191 ~ 4.17201)

### Note:

The clearance between liner and piston is correct at time of manufacture, but when a liner is removed from the cylinder block and later reinstalled, the amount of clearance may be reduced.

As a result, it is always necessary to measure the clearance again after any reinstallation of a removed liner.



015HY00030



### Clearance between piston rings and piston ring grooves


Use a feeler gauge to measure the clearance between the piston ring and the piston ring groove at several points around the piston.

If the clearance between the piston ring and the ring groove exceeds the limit, the piston ring must be replaced.


Clearance between piston ring and piston ring groove  
mm (in)

	Standard	Limit
No. 1 compression ring	0.105 ~ 0.140 (0.0041 ~ 0.0055)	0.20 (0.0079)
No. 2 compression ring	0.105 ~ 0.140 (0.0041 ~ 0.0055)	0.20 (0.0079)
No. 3 compression ring	0.085 ~ 0.120 (0.0033 ~ 0.0047)	0.20 (0.0079)
Oil ring	0.020 ~ 0.060 (0.0008 ~ 0.0024)	0.15 (0.0059)

**PISTON RING**



015EY00099



015E100009



**Piston ring gap measurement**

1. Holding the piston ring horizontally, insert it into the cylinder liner to the liner's bore measuring point.
2. As shown in the illustration, use an inverted piston to press the ring inside the liner until it reaches either measuring point ① or measuring point ②.  
The liner diameter is narrowed at these two points. Be sure that the inserted ring is kept perfectly horizontal while being inserted.  
Measuring point ①: 10 mm  
Measuring point ②: 160 mm
3. Using a feeler gauge, measure the gap where the ends of the ring come together.  
If the measured value exceeds the limit, replace the ring for that piston.

Piston ring opening gap mm (in)

	Standard	Limit
No. 1 compression ring	0.35 ~ 0.50 (0.0138 ~ 0.0197)	1.0 (0.039)
No. 2, 3 compression ring		
Oil ring	0.25 ~ 0.45 (0.0098 ~ 0.018)	0.8 (0.031)

4. Visually inspect the piston ring grooves.  
If any of the grooves are damaged or deformed, replace the piston.


**Ring tension**

Measure piston ring tension with a piston ring tension gauge.

Ring tension N (kgf)

	Standard	Limit
No. 1 compression	24.1 ~ 31.8 (2.46 ~ 3.24)	14.7 (1.5)
No. 2 compression	15.4 ~ 21.3 (1.57 ~ 2.17)	9.8 (1.0)
No. 3 compression	17.7 ~ 24.5 (1.80 ~ 2.58)	11.8 (1.2)
Oil	53.9 ~ 73.5 (5.5 ~ 7.5)	37.3 (3.8)

## PISTON PIN



015E100010




### Piston pin diameter

Use a micrometer to measure the diameter of the piston pin at each of the six locations shown in the illustration. If the measured value is less than the limit, replace the pin.

Piston pin diameter mm (in)

Standard	Limit
43.0 (1.693)	42.98 (1.692)



015E100011




### Clearance between piston pin and piston pin hole

Use an internal dial gauge to measure the diameter of the piston pin hole, and use that figure to calculate the clearance with the piston pin.

Clearance of piston pin and piston pin hole mm (in)

Standard	Limit
0.004 ~ 0.017 (0.00016 ~ 0.00067)	0.05 (0.00197)




015E100012

If an internal dial gauge is not available, use the following procedure to check the piston pin clearance.

1. Use a piston heater to heat the piston to about 100°C.
2. Strongly push the piston pin into the piston pin hole with your thumbs. With proper pin clearance, the piston pin should go into the hole without any, or with very little, resistance.

**CONNECTING RODS**




**Connecting rod twist and parallelism**

Use a connecting rod aligner to measure the connecting rod's twist distortion and parallelism between the rod's large and small ends.

If the measured value exceeds the limit, replace the connecting rod.

Connecting rod parallelism (per 100 mm length) mm (in)

	Standard	Limit
Twist, parallelism	0.03 (0.0012) or less	0.10 (0.0039)



015EY00102




**Connecting rod small end bushing clearance**

Use an inside dial gauge and micrometer to measure the inside diameter of the connecting rod's small hole bushing and the outside diameter of the piston pin.

If the measured clearance exceeds the limit value, the piston pin, or the connecting rod's small hole bushing must be replaced.

Connecting rod small end bushing clearance mm (in)

Standard	Limit
0.012 ~ 0.027 (0.00047 ~ 0.0011)	0.10 (0.0039)



**Connecting rod side face clearance**


1. Install the connecting rod to the crankpin.
2. Use a feeler gauge to measure the clearance between the side face of the connecting rod's big end and the side face of the crankpin's arm.  
If the measured value exceeds the limit, the connecting rod must be replaced.

Connecting rod large end side face clearance mm (in)

Standard	Limit
0.17 ~ 0.28 (0.0067 ~ 0.0110)	0.35 (0.014)

## CRANKSHAFT

- The crankshaft of the model 6SD1T engine has been treated by soft nitriding (tufftriding) in order to enhance the crankshaft's strength. As a result, crankshaft wear cannot be rectified by shaft grinding and use of undersize bearings. Further, no undersize bearings are made available for the crankshaft.
- If surface scorching or other damage to the crankshaft exceeds the limit values, the crankshaft assembly must be replaced.



### Inspection of the crankshaft's tufftriding layer

1. Thoroughly clean the crankshaft. Be particularly careful to clean the inspection area by using an organic solvent to clean away all oil.
2. Prepare a solution of 5 ~ 10 % ammonium cuprous chloride (dissolved in distilled water).
3. Using a dropper, place a drop of the solution on the test area of the crankshaft. Be sure to stabilize the test area and hold flat so the solution does not run.

#### Note:

**Do not allow the test solution to drip in or around the oil ports.**




### Results

1. Wait 30 ~ 40 seconds after dripping the solution. If no color change occurs after 30 ~ 40 seconds, the crankshaft is usable. If a color change occurs (test surface turns copper color), the crankshaft must be replaced. (The test solution is originally thin blue in color).
2. Following completion of the test, quickly wipe the test solution from the surface of the crankshaft and clean well with steam.

#### Note:

**Since ammonium cuprous chloride is highly corrosive, it must be cleaned from the test surface immediately following completion of the test.**

## CRANKSHAFT AND BEARINGS



012E100020



### Basic measurement procedures:

When the

1. Main bearing inside diameter = A,
2. Crankshaft journal diameter = B, and
3. Clearance between crankshaft journal and main bearing = C,


the relationship between the three is

$$A - B = C$$

This section discusses the method used to measure the "C" dimension.

The same description is also applicable to measuring the clearance C' between the crankpin and the control rod bearing.

These C and C' dimensions are decisive for determining whether the crankshaft or the crank bearing must be replaced.




015E100013



### Inspection of crankshaft and bearing

1. Visually inspect the crankshaft journal and pin for excessive friction and damage.
2. Inspect the oil seal contact surfaces at the front and back of the crankshaft for excessive wear and damage.
3. If any excessive wear or damage is discovered, the crankshaft must be replaced or repaired.
4. Inspect the oil ports for clogging, and if necessary blow out with compressed air.



014EY00120




### Crankshaft runout

1. Set up a dial gauge on the No. 4 journal of the crankshaft.
2. Slowly rotate the crankshaft one full turn clockwise, and read the dial gauge.

If the measured value exceeds the limit, the crankshaft must be replaced with a new one.

Crankshaft runout mm (in)

Standard	Limit
0.08 (0.003) or less	0.15 (0.0059)



015EY00110




**Bearing spread**

Use calipers to measure the spread of the bearing arc. If the measured value is less than the limit, the bearing must be replaced.

Bearing arc spread mm (in)

	Limit
Crank bearing	96 (3.779)
Control rod bearing	85 (3.346)



015EY00195

**Outside diameter of crank journal and crank pin**

1. Use a micrometer to measure the diameter of each crank journal at each of the measuring points ③ and ④ shown in the illustration.
2. At each measuring point, measure in both directions ①-① and ②-②.
3. Use the same method to measure the diameter of the crank pin. If the measured value is less than the limit, the crankshaft must be replaced.

Crank journal outside diameter mm (in)

Standard
89.909 ~ 89.929 (3.5397 ~ 3.5405)


Crankpin outside diameter mm (in)

Standard
79.894 ~ 79.914 (3.1454 ~ 3.1462)

Crank journal and crankpin uneven wear mm (in)

Standard	Limit
0.001 (0.00004)	0.05 (0.002)





012E100032




**Measuring the crank journal and bearing inside diameter and clearance**



Measure the crank bearing's inside diameter and its clearance with the crank journal.

1. Clean the mounting surfaces of the cylinder block and lower crankcase, and the bearing installation surfaces.
2. Apply a thin coat of molybdenum disulfide grease to the threads ① and the seating area ② of the mounting bolts, and to the surfaces of the washers.
3. Install the lower crankcase (with bearings) to the cylinder block, and tighten the bolts as noted in the following:



012E100034




**Sequence 1 (M14 bolts)**

Using the angular tightening method, evenly tighten the inner layer of crankcase bolts in the order shown (① to ⑭).

Crankcase M14 bolts tightening torque N·m (kgf·m/lb·ft)

98 (10/72) → 142 ~ 152 (14.5 ~ 15.5 / 105 ~ 112) → 30° ~ 60°



012E100033




**Sequence 2 (M10 bolts)**

Next, evenly tighten the outer layer of crankcase bolts in the order shown ① to ⑳.

Crankcase M10 bolts tightening torque N·m (kgf·m/lb·ft)

31 ~ 45 (3.2 ~ 4.6 / 23 ~ 33)



014EY00121



4. Using a dial gauge, measure the inside diameter of the crank journal bearing, and calculate its clearance with the outer diameter of the crank journal. If the clearance with the crank journal exceeds the limit value, the bearing or the crankshaft must be replaced.


Crank journal and bearing clearance mm (in)

Standard	Limit
0.045 ~ 0.110 (0.0018 ~ 0.0043)	0.16 (0.0063)

**Note:**

The cylinder block and the lower crankcase are manufactured as a single unit. As a result, if either part requires replacement, both parts must be replaced as a single set.


### Using Plastigage to measure clearance between the crank journal and bearing



012E100035




1. Thoroughly clean the cylinder block, particularly the bearing installation parts, lower crankcase and bearings.
2. Install the bearings in their mounts.
3. Carefully set the crankshaft on the bearings.
4. Next, rotate the crankshaft about 30 times to stabilize the bearings.
5. As shown in the illustration, set the plastigage across the entire width of the bearing.
6. Install the crankcase with bearings.



012E100026



7. Tighten the crankcase bolts using the designated order and method. Refer to the section Engine, "Crank Journal and Bearing Clearance." When installing the crankcase, take care to prevent the Plastigage from slipping.
8. Remove the crankcase.




012E100036



9. Measure the width of Plastigage affixed to the crankshaft or bearing, using the gauge printed on the plastigage box. If the measured value exceeds the limit, take the following additional steps:
  - (1) Use a micrometer to measure the diameter of the crank journal.
  - (2) Using an inside dial gauge, measure the bearing's inner diameter. If the clearance calculated between the journal and bearing exceeds the limit value, the crankshaft or the bearing must be replaced.

Crankshaft and bearing clearance		mm (in)
Standard	Limit	
0.045 ~ 0.110 (0.0018 ~ 0.0043)	0.16 (0.0063)	



015E100015




**Connecting rod bearing clearance**

1. Install the bearing on the large end of the connecting rod.
2. Apply molybdenum disulfide grease to the bolt threads and nut setting faces.
3. Use the following angular tightening method to tighten the bearing cap nuts.

Bearing cap nut torque N·m (kgf·m/lb·ft)

Order	Tightening nut	Tightening torque and angle
1	Tighten nuts ① and ② alternately	37 ~ 41 (3.8 ~ 4.2 / 27 ~ 30)
2	Right side nut ①	60°
3	Left side nut ②	120°
4	Right side nut ①	60°



015E100016



4. Using a dial gauge, measure the bearing's inside diameter and calculate the clearance between the bearing and crankpin. If the clearance between the bearing and crankpin exceeds the limit, replace the bearing or the crankshaft.

Crankpin and bearing clearance mm (in)

Standard	Limit
0.04 ~ 0.106 (0.0016 ~ 0.0042)	0.16 (0.0063)

### Using plastigage to measure the connecting rod bearing clearance



1. Thoroughly clean the crankshaft, connecting rod, bearing cap and bearing.
2. Assemble the bearing in the large end of the connecting rod and the bearing cap. Keep the crankshaft immobile so that it does not move while assembling the bearing cap.
3. Stabilize the connecting rod so that it does not move.
4. Apply Plastigage to the crankpin. If the Plastigage is stuck on with some engine oil, it will stick better and make the job easier.



5. Install the bearing cap, and tighten the bolts in the designated order, using the designated tightening method and torque. (Apply the Plastigage flat, and avoid the area of the crankpin's oil port.) Consult the section "Engine II: Connecting Rod Bearing Clearance."




Keep the connecting rod steady so that it does not move during assembly and tightening of the bearing cap.

6. Remove the bearing cap.
7. Measure the width of Plastigage affixed to the crankpin or bearing, using the gauge printed on the Plastigage box.




If the measured value exceeds the limit, perform the following procedure:

- (1) Use a micrometer to measure the diameter of the crankpin.
- (2) Using an inside dial gauge, measure the inside diameter of the bearing. From these two figures calculate the crankpin and bearing clearance, and if it exceeds the limit, replace the crankshaft or bearing.



015E100052




015E100053

Crankpin and bearing clearance mm (in)

Standard	Limit
0.04 ~ 0.106 (0.0016 ~ 0.0042)	0.16 (0.0063)

**Crank gear replacement**




**Removal**

1. Using the crank gear puller, pull off the crank gear.  
Crank gear remover: 1-85210-051-0
2. Remove the key from the crankshaft.



**Note:**

**When removing the crank gear, take care not to damage the gear teeth with the gear puller.**



**Installation**

1. Warm the crank gear with an oil heater (oil temperature 170 ~ 180°C).
2. With the timing mark "0" facing the flywheel side (front), align the gear's key groove with the crankshaft's knock pin, and install so that there is no gap with the crankshaft's end.



Crank gear installer: 1-85221-072-0

015E100018

**Oil pump drive gear replacement**



**Removal**

See the section "Crank Gear Replacement."




**Installation**

1. Warm the drive gear with an oil heater (oil temperature 170 ~ 180°C).
2. Install the gear facing the direction shown in the illustration, and allow no gap with the crankshaft's end.




Drive gear installer: 1-85221-075-0



015E100021



## FRONT COVER OIL SEAL

### Front cover oil seal replacement



#### Removal

Use the oil seal remover to remove the oil seal slinger.  
Oil seal remover: 1-85220-052-0




#### Installation

1. If there is some small scratch on the crankshaft after removing the oil seal, apply threebond 1207C or equivalent on the slinger as shown in the illustration.

2. Use the oil seal installer to install the oil seal with slinger.


- Tighten the center bolt until the installer comes into contact with the guide.
- Check that the oil seal is flush with front cover.

Oil seal installer: 1-85220-057-0





## CRANKSHAFT REAR OIL SEAL

### Crankshaft rear oil seal replacement



#### Removal


Use the oil seal remover to remove the oil seal slinger.  
Oil seal remover: 1-85220-052-0



#### Installation

Use the oil seal installer to install the oil seal with slinger.

- Tighten the center bolt until the installer comes into contact with the guide.
- Check that oil seal is flush with flywheel housing.  
Oil seal installer: 1-85220-057-0



If there is some scratch on the crankshaft after removing the oil seal, apply threebond 1207C or equivalent on the slinger as shown in the illustration.


---

**CHAPTER 5****ENGINE III****(ASSEMBLY)****CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
<b>Rocker arm shaft assembly . . . . .</b>	<b>86</b>
<b>Cylinder head assembly . . . . .</b>	<b>88</b>
<b>Piston and connecting rod assembly . . . . .</b>	<b>91</b>
<b>Assembly 1 . . . . .</b>	<b>94</b>
<b>Assembly 2 . . . . .</b>	<b>101</b>
<b>Assembly 3 . . . . .</b>	<b>107</b>
<b>Timing gear train diagram . . . . .</b>	<b>116</b>



## ROCKER ARM SHAFT ASSEMBLY



014E100024




### Assembly sequence

- 1. Rocker arm shaft
- 2. Rocker arm spring
- ▲3. Rocker arm
- 4. Rocker arm bracket
- ▲5. Camshaft lower bracket
- 6. Camshaft upper bracket
- 7. Cotter pin




### IMPORTANT OPERATIONS

- 3. **Rocker arm**
- 5. **Camshaft lower bracket**



014E100025



014E100050




- (1) Apply engine oil to the rocker arm shaft, each rocker arm, rocker arm bushing, and the lower bracket's shaft holes.

- (2) Install all parts in accordance with the assembly sequence.

1) When reusing parts

- ① When reusing the rocker arms, replace them in the original positions as noted on tags attached during removal.
- ② When reusing the camshaft bracket, confirm the alignment mark positioning number, and return it to its original position.




2) When using new parts


When installing new parts as the result of "Inspection and Repair" performed under chapter 4 ("Engine II"):

- ① Replace all four upper and lower brackets together as a single set. Never replace only one bracket.
- ② Confirm position numbers when installing


New parts (service parts) position numbers



- 3) Install the camshaft upper bracket and hand tighten.




014E100067



014E100068

## CYLINDER HEAD ASSEMBLY




011E100014

### Assembly sequence

- |                                     |                        |
|-------------------------------------|------------------------|
| 1. Cylinder head                    | ▲7. Split collar       |
| 2. Valve spring lower seat          | 8. Idle gear shaft "C" |
| ▲3. Valve stem seal                 | 9. Idle gear "C"       |
| ▲4. Intake and exhaust valves       | 10. Idle gear gasket   |
| 5. Intake and exhaust valve springs | 11. Idle gear cover    |
| 6. Valve spring upper seat          | 12. Thermostat housing |



## IMPORTANT OPERATIONS



011E100007



### 3. Valve stem seal

When inserting valve stem seals, apply oil to the periphery of the valve guide and press in securely until it strikes the upper surface of the seal guard.



#### Note 1:


Take care not to scar the seal lip.



#### Note 2:

After inserting the seal, confirm that the spring does not fall out.

Special tool: 1-85232-001-0




014E100029



### 4. Intake and exhaust valves

- (1) Before installing, apply clean engine oil to each valve stem.
- (2) Install the intake and exhaust valves.
- (3) Turn over the cylinder head to install the valve springs.  
Take care when doing this so that the valves do not fall out.




014E100030



### 5. Intake and exhaust valve springs


The valve springs are installed so that the end with narrow pitched coils (the side with color) are installed pointing down.



014E100064

### Spring color coding

Intake side (1)	Inner	Green
	Outer	
Exhaust side (2)	Inner	Yellow
	Outer	




014E100010



**7. Split collar**


- (1) Use the spring compressor to compress the valve springs in their mounted position.  
Spring compressor: 1-58235-007-0
- (2) Install the split collar onto the valve stem.



014E100031

- (3) Use a rubber hammer to tap the edge of the split collar to seat it properly.

## PISTON AND CONNECTING ROD ASSEMBLY




D15E100048

### Assembly sequence


- ▲1. Piston
- ▲2. Snap ring
- ▲3. Connecting rod
- ▲4. Piston pin
- ▲5. Snap ring
- ▲6. Piston ring
- ▲7. Connecting rod bearing




**IMPORTANT OPERATIONS**



015E100023



015E100040



015EY00098

1. **Piston**
2. **Snap ring**
3. **Connecting rod**

Use a piston heater to heat the piston to about 100°C.

- (1) Using snap-ring pliers, install one snap ring in the piston.
- (2) Fix the connecting rod in a vice.  
Hold the connecting rod in copper plates to prevent damage to the connecting rod.
- (3) Assemble the piston to the connecting rod. Install the piston so that the front mark (1) on the piston's head and the forged "ISUZU" mark on the connecting rod (2) are pointing toward the engine's front.




4. **Piston pin**
5. **Snap ring**

- (1) Apply a liberal coat of clean engine oil to the piston pin, connecting rod, and the piston's hole.
- (2) Align the piston and the connecting rod's piston hole, and press in the piston pin strongly.
- (3) Use snap ring pliers to install the other snap ring in the position.

**Note:**

**Confirm that the snap ring is securely installed in the ring groove.**

- (4) Remove the piston and connecting rod assembly from the vise and check that the connecting rod moves smoothly.



015E100054



6. **Piston rings**


- (1) Assemble the oil ring and expander ring.



**Note:**

**Assemble the two rings so that their gaps are located on opposite sides (180° apart) from each other.**

- (2) Apply clean engine to the piston rings and piston ring grooves.



015E100050




- (3) Use a piston ring replacer to install the piston rings in the sequence shown.
- (1) Oil ring
  - (2) 3rd compression ring
  - (3) 2nd compression ring
  - (4) 1st compression ring

**Note:**

Install the 1st, 2nd and 3rd compression rings so that the "1R", "2R" and "3R" marks are oriented toward the top of the piston respectively.

Piston ring replacer: 1-85221-029-0

- (4) Confirm that each piston ring moves smoothly in its groove.



015E100026



**7. Connecting rod bearing**


While clean the rear surface of the connecting rod bearing and the inner surface of the large end of the connecting rod, and confirm that no foreign material is on either surface.

**Note:**

Do not apply engine oil to the rear surface of the connecting rod bearing and the inner surface of the large end of the connecting rod.



## ASSEMBLY 1



F06E10006



### Assembly sequence


1. Cylinder block
- ▲2. Oil jet
- ▲3. Crankshaft upper bearing
- ▲4. Crankshaft
- ▲5. Thrust bearings
- ▲6. Crankshaft lower bearing
- ▲7. Cylinder block lower crankcase
- ▲8. Piston and connecting rod (with upper bearing)
- ▲9. Connecting rod bearing cap (with lower bearing)
- ▲10. Front cover
- ▲11. Oil pump
- ▲12. Oil pan
- ▲13. Idler gear shaft "B"
- ▲14. Idler gear "B"
- ▲15. Idler gear shaft "A"
- ▲16. Idler gear "A"



## IMPORTANT OPERATIONS

**Note:**

Before assembling, use compressed air to thoroughly blow out the inside of the cylinder block, particular the oil ports and water jacket.



011E100015



### 2. Oil jet


Tighten the oil jets with the designated torque.

**Note:**

When installing the jets, take care not to damage the nozzles, or to deform the nozzle angle by impact.

Oil jet tightening torque N·m (kgf·m/lb·ft)

16 ~ 25 (1.6 ~ 2.6 / 12 ~ 19)
-------------------------------




015E100027



### 3. Crankshaft upper bearing

Thoroughly clean the upper bearing.

When reusing bearings which were previously removed, be sure to reinstall them in the same positions from which they were removed, in accordance with the tags affixed at the time of removal.




015E100041



Be sure the bearing's locking lip fits securely in the slot machined in the bearing mount.

**Note:**

The upper bearings can be discriminated from lower bearings since the upper bearings have oil ports and a groove along their entire surface. In contrast, the lower bearings have no oil port and only a partial groove. Be sure to install the bearings in their correct locations.



015E100058




### 4. Crankshaft

Before installing the crankshaft, apply a liberal coat of clean engine oil to the journals and the inner surface of the bearings.

**Note:**

Do not apply engine oil to the rear surface of the bearings, or to the bearing mounts in the cylinder block.




015E100042



**5. Thrust bearings (upper)**

Before installing, apply a liberal coat of clean engine oil to the thrust bearings. The oil groove of the thrust bearings must be facing the crankshaft's No. 7 contact surface.



015E100043




**5. Thrust bearings (lower)**


**6. Crankshaft lower bearing**

**7. Cylinder block lower crankcase**

- (1) Thoroughly clean the lower bearings, thrust bearings, and lower crankcase.
- (2) Apply clean engine oil to the lower bearings and the contact surface of the thrust bearings. Do not apply engine oil to the rear surface of the lower bearings, or to the bearing mounts in the lower crankcase.
- (3) Install the bearings in the lower crankcase. Be sure the bearing's alignment notch fits securely in the slot machined in the bearing mount.
- (4) Pack sealant into the crankcase groove as shown.



011E100039




012E100032



- (5) Apply a light coat of molybdenum disulfide grease to the threads ① and seating faces ② of the lower crankcase's M14 bolts.
- (6) Install the crankcase (with bearings) to the cylinder block, and tighten the bolts in the following sequence.

**Note:**

**Take care not to drop the lower bearings and thrust bearings.**



012E100034




**Sequence 1 (M14 bolts)**

Using the angular tightening method, evenly tighten the inner row of crankcase bolts in the sequence shown in the illustration (① to ⑭).

Crankcase M14 bolts tightening torque N·m (kgf·m/lb·ft)

98 (10/72) → 142~152 (14.5~15.5/105~112) → 30° ~ 60°



012E10023



**Sequence 2 (M10 bolts)**

Evenly tighten the outer row of crankcase bolts in the sequence shown in the illustration (① to ⑳).

Crankcase M10 bolt tightening torque N·m (kgf·m/lb·ft)

31 ~ 45 (3.2 ~ 4.6 / 23 ~ 33)
-------------------------------

**Note:**

The cylinder block and lower crankcase are manufactured as a single unit. As a result, if either part requires replacement, both parts must be replaced as a single set.

See Engine II "Inspection and Repair" (2).

**Note:**


Crankcase bolts may be reused only two times.

**8. Piston and connecting rod (with upper bearing)**

**9. Connecting rod cap (with lower bearing)**



(1) Apply clean engine oil to the piston and piston rings.



015E10051




(2) Turn the piston rings so that their gaps are positioned in the positions shown in the illustration.

- ① No. 1 compression ring
- ② No. 2 compression ring
- ③ No. 3 compression ring
- ④ Oil ring

**Note:**

The piston ring gaps must not be positioned in the direction of horizontal thrust, but in the direction of the piston end, namely, in the position where they will not be exposed to side pressure.


Also, the oil ring and expander ring gaps should be positioned on opposite sides (180°) from each other.



015E10033




(3) Apply molybdenum disulfide grease to the piston's skirts as shown; this will facilitate smooth break-in when the engine is first started after reassembly.



015E100044



- (4) Apply a coat of clean engine oil to the upper bearing's contact surface and to the bore of the cylinder liner.
- (5) Install the piston so that the "front mark" (△) on the head is oriented toward the front end of the engine.



015E100045




- (6) Using a ring compressor, compress the piston rings.  
Piston ring compressor: 1-85221-082-0
- (7) Use the handle of a hammer to push in the piston until the connecting rod's large end makes contact with the crankpin.  
While pushing in the piston, turn the crankshaft as necessary to bring the crankpin to the BDC position.

**Note:**

Take special care to prevent the large end of the connecting rod from contacting the oil jets.

**Note:**


The ring compressor must be set flush with the cylinder block or the piston rings will be damaged.



015E100036



- (8) Orient the bearing cap's cylinder number and the connecting rod's cylinder number marks as shown in the illustration.  
The engraved cylinder number marks must be facing toward the injection pump side.
- (9) Apply a coat of molybdenum disulfide grease to the threads and seating area of the connecting rod bearing cap bolts.



015E100037




- (10) Using the angular tightening method, tighten the bearing cap nuts.  
Bearing cap nut tightening data

N·m (kgf·m/lb·ft)

	Sequence	Tightening torque and angle
1	Tighten ① and ② alternately.	37 ~ 41 (3.8 ~ 4.2/27 ~ 30)
2	Nut ①	60°
3	Nut ②	120°
4	Nut ①	60°

**Note:**

After tightening the bearing cap nuts, confirm that the oil jet is facing toward the oil channel hole for piston cooling.




020E100040



**10. Front cover**

- (1) As shown in the illustration, apply sealant "Belco Bond No. 4" to the front cover ①, and "Three Bond No. 1207C" to the cylinder block ② and the ladder frame ③.



020E100041



- (2) Install the front cover to the cylinder block and ladder frame, then tighten the bolts and nuts alternately to the proper torque.


Front cover bolts and nuts tightening torque

N·m (kgf·m/lb·ft)

Bolts	Nuts
14 ~ 24 (1.4 ~ 2.4/10 ~ 17)	34 ~ 46 (3.5 ~ 4.7/25 ~ 34)

**Note:**

**Take care not to damage the oil seal.**



020E100009




**11. Oil pump**

- Install the oil pump together with the anti-drain valve and tighten the bolts to the designated torque.

Oil pump bolts tightening torque

N·m (kgf·m/lb·ft)

31 ~45 (3.2 ~ 4.6 / 23 ~33)
-----------------------------



012E100028




**12. Oil pan**

- (1) Apply a coat of sealant "Seal End No. 242" about 2 mm thick and 3 mm wide to the joining surfaces of the cylinder block, flywheel housing, and front cover.

**Note:**

**Take care not to apply so much sealant that it drips inside the engine.**



013E100003




- (2) Install the oil pan with the sealant's silicon coating facing the oil pan side, then tighten the bolts evenly in the designated order.

Oil pan bolts tightening torque

N·m (kgf·m/lb·ft)

14 ~ 24 (1.4 ~ 2.4/10 ~ 17)
-----------------------------



014E100032




**13. Idler gear shaft "B"**

Install the shaft so that its oil port is facing up.

Idler gear shaft "B" tightening torque N·m (kgf·m/lb·ft)

20 ~ 29 (2.0 ~ 3.0/14 ~ 22)



014E100033




**14. Idler gear "B"**

- (1) Apply clean engine oil to the inside surface and thrust section of the idler gear "B."
- (2) Install and tighten the idler gear as shown in the illustration.

Idler gear "B" bolt tightening torque N·m (kgf·m/lb·ft)

76 ~ 116 (7.8 ~ 11.8/56 ~ 85)




**15. Idler gear shaft "A"**

**16. Idler gear "A"**


- (1) Install the thrust plate and the shaft to the idler gear "A."
- (2) Apply clean engine oil to the inside and thrust areas of the idle gear.
- (3) Align the timing mark "O" on the crankshaft gear ② with the timing mark "O" on the idle gear.
- (4) Tighten the idler gear "A" to the specified torque.

Idler gear "A" tightening torque N·m (kgf·m/lb·ft)

32 ~ 36 (3.3 ~ 3.7 / 24 ~ 27) → 60° ~ 90°



014E100053




- (5) Tighten the idle gear shaft to the specified torque from the flywheel side after installing the flywheel housing.

Idler gear shaft "A" tightening torque N·m (kgf·m/lb·ft)

20 ~ 29 (2.0 ~ 3.0 / 14 ~ 22)

## ASSEMBLY 2



F08E100007




### Assembly sequence

- ▲18. Flywheel housing
- ▲19. Flywheel
- ▲20. Crankshaft pulley (with damper)
- ▲21. Water pump
- 22. Water pump pulley
- ▲23. Cylinder head gasket
- ▲24. Cylinder head
- ▲25. Thermostat housing (with thermostat)
- ▲26. Rocker arm shaft assembly
- ▲27. Camshaft
- ▲28. Camshaft upper bracket
- ▲29. Cylinder head cover gasket
- ▲30. Cylinder head cover





**IMPORTANT OPERATIONS**




020E100010



**18. Flywheel housing**

- (1) Apply sealant "Belco Bond No. 4" to the flywheel housing mounting surface ①, and to the areas indicated by arrows in the illustration.



011E100019




- (2) Apply sealant "Three Bond No. 1207C" to the joining surfaces of the cylinder block and ladder frame.



- (3) Install the flywheel housing to the cylinder block and tighten the bolts evenly to the specified torque.

Flywheel housing tightening torque	N·m (kgf·m/lb·ft)
68 ~ 83 (6.9 ~ 8.5 / 50 ~ 61)	



015E100057




**19. Flywheel**

- (1) Apply molybdenum disulfide grease to the threads and seating surfaces of the flywheel's installation bolts and washers.
- (2) Use the angular tightening method to tighten the flywheel bolts in the sequence shown.



Flywheel tightening torque	N·m (kgf·m/lb·ft)
74 ~ 83 (7.5 ~ 8.5 / 54 ~ 61) → 60° → 30° ~ 60°	

**Note:**  
**The flywheel installation bolts may be reused only tow times.**



030E100001




**20. Crankshaft pulley (with damper)**

- (1) Apply clean engine oil to the threads and seating surfaces of the four pulley bolts, and to the washers.
- (2) Install the pulley (with damper) to the crankshaft and tighten.  
The front end of the crankshaft has eight bolt holes; installation can be performed in any desired position.

Crankshaft pulley tightening torque	N·m (kgf·m/lb·ft)
160 ~ 240 (16.3 ~ 24.5 / 118 ~ 177)	

There is normally no need to remove the damper from the pulley.  
If the damper is removed, reused, or replaced, be sure to tighten to specified torque.

Damper tightening torque	N·m (kgf·m/lb·ft)
86 ~ 106 (8.8 ~ 10.8 / 64 ~ 78)	



030E100002




**21. Water pump**

- (1) Install the water pump together with its gasket, and tighten in place.

Water pump tightening torque	N·m (kgf·m/lb·ft)	
	M8 bolts	M10 bolts
	14 ~ 24 (1.4 ~ 2.4/10 ~ 17)	31 ~ 45 (3.2 ~ 4.6/23 ~ 33)



- (2) Apply molybdenum disulfide grease to the o-ring and install on the water pump.




011E100029



**23. Cylinder head gasket**

- (1) Apply a coating of sealant "Parmatex No. 6" about 2 mm thick and 3 mm wide to the joint between the cylinder block (1) and flywheel housing (2).

**Note:**  
Do not block the cylinder's oil ports (3) with the sealant.




011E100027



- (2) Install the head gasket, aligning it with the cylinder block's dowel pins.

**Note:**  
Install the gasket with the part number (at the No. 3 cylinder position) facing up.



011E100022




**24. Cylinder head**

- (1) Align the teeth of the idler gear "C" and idler gear "B", and carefully install the cylinder head.

**Note:**

Be sure to securely align the three dowel holes in the cylinder head with the dowel pins in the cylinder block. Take care not to damage the gasket when setting the cylinder head on top of the gasket.



011E100023




- (2) Apply molybdenum disulfide grease to the threads and seating surfaces of the cylinder head bolts.
- (3) Use the angular tightening method to tighten the cylinder head bolts to in the sequence shown.

Cylinder head bolt tightening torque N·m (kgf·m/lb·ft)

M14 bolts ① ~ ②⑥	98 (10/72) → 142 ~ 152 (14.5 ~ 15.5 / 105 ~ 112) → 30° ~ 60°
M10 bolts ②⑦ ~ ②⑨	31 ~ 45 (3.2 ~ 4.6 / 23 ~ 33)

**Note:**

The cylinder head bolts may be reused only two times. After tightening the cylinder head bolts, plug the timing gear hole with a rag, etc., in order to prevent entry of any foreign matter.



031E100002




**25. Thermostat housing (with thermostat unit)**

Install the thermostat housing, thermostat and water outlet pipe assembly to the cylinder head.

Thermostat housing bolt tightening torque

N·m (kgf·m/lb·ft)

14 ~ 24 (1.4 ~ 2.4 / 10 ~ 17)
-------------------------------




020E100001



**26. Rocker arm shaft assembly**

- (1) Rotate the crankshaft clockwise, and align the flywheel's TDC mark with the flywheel housing's pointer.




014E100066



- (2) Apply clean engine oil to the roller section of the rocker arm.
- (3) Install the rocker arm shaft assembly to the cylinder head.

**Note:**

**Be careful during installation, since the rocker arm must be stood on end and lowered to be installed.**




014E100052



**27. Camshaft**


- (1) Apply clean engine oil liberally to the bearing surfaces of the camshaft lower brackets.
- (2) Apply molybdenum disulfide grease to the cam profiles of the camshaft.



014E100051



- (3) Install the camshaft to the lower bracket, aligning the V-groove on the camshaft with the alignment surface of the bracket (intake manifold side).



014E100050



**28. Camshaft upper bracket**

Install the brackets, align the stamped numbers, and first tighten by hand from the camshaft gear side, finally tightening to the designated torque.

**Note:**

**Confirm that the V-groove and bracket alignment surface are securely joined.**

**See the "Important Operations" entry in the section Engine III, "Rocker Arm Shaft Assembly."**


Camshaft upper bracket nut tightening torque

N·m (kgf·m/lb·ft)

20 ~ 24 (2.0 ~ 2.4 / 14 ~ 17)
-------------------------------

**Note:**

**The rocker arm's adjust screw must be fully loosened (increase valve clearance) before installing the camshaft.**




014E10002



**Valve clearance adjustment**

See the section "Valve Clearance Adjustment" in chapter 2 (Maintenance) (P. 28).



011E100024



**29. Cylinder head cover gasket**

**30. Cylinder head**


- (1) Apply sealant " Three Bond No. 1208" to the head cover gasket.
- (2) Install the head cover, tightening the bolts in the sequence shown.



Head cover bolt tightening torque                      N·m (kgf·m/lb·ft)

2.9 ~ 6.9 (0.3 ~ 0.7 / 2.2 ~ 5.1)
-----------------------------------

## ASSEMBLY 3



FORE100015




## Disassembly sequence

- ▲ 1. Exhaust manifold
- 2. Partial oil filter
- ▲ 3. Oil cooler
- 4. Oil pipe (partial oil filter)
- ▲ 5. Turbocharger
- ▲ 6. Oil feed pipe
- ▲ 7. Oil return pipe
- 8. Oil dipstick
- ▲ 9. Starter motor
- ▲ 10. Intake cover
- ▲ 11. Coupling ASM
- ▲ 12. Injection pump
- ▲ 13. Oil return pipe
- ▲ 14. Oil feed pipe
- ▲ 15. Nozzle holder
- ▲ 16. Glow plug
- ▲ 17. Injection pipe
- 18. Fuel filter
- ▲ 19. Fuel pipes
- 20. Intake pipe
- 21. Intake duct
- ▲ 22. Alternator
- ▲ 23. Water pump pulley and adapter
- ▲ 24. Fan belt
- 25. Cooling fan
- 26. Fan guide
- 27. Water pipe



## IMPORTANT OPERATIONS



027E100003




### 1. Exhaust manifold

- (1) Install the exhaust manifold gasket on the stud bolts.
- (2) Install the exhaust manifold and tighten to the designated torque.

Exhaust manifold bolt tightening torque N·m (kgf·m/lb·ft)

36 ~ 46 (3.7 ~ 4.7 / 27 ~ 34)



050E100007




### 3. Oil cooler (with oil filter)

- (1) Apply sealant "Helmes Seal No. 123T" to the oil cooler gasket, and stick the gasket to the cylinder block.
- (2) Install the oil cooler and tighten the bolts alternately from inside to outside.



Oil cooler bolt tightening torque      N·m (kgf·m/lb·ft)

18 ~ 26 (1.8 ~ 2.7 / 13 ~ 20)



036E100001




### 5. Turbocharger

- (1) Install the turbocharger gasket, with the upper surface of the gasket facing up. The illustration shows the upper surface of the gasket.
- (2) Install the turbocharger, taking care not to damage the gasket.

**Note:**

**Always use new nuts and washers when installing.**



036E100002




**6. Oil pipe (turbo feed)**

**7. Oil pipe (turbo return)**

- (1) Before installing the oil pipe, fill the pipe through the pipe mounting hole with about 100 ~ 130 cc of CD grade engine oil.
- (2) Turn the rotor shaft by hand to lubricate the bearing.

**Note:**

**If steps (1) and (2) are not performed, the turbocharger may seize upon engine startup.**



036E100003




- (3) Install the oil feed pipe and oil return pipe and tighten the turbocharger's mounting nut.
- (4) Tighten the oil pipe.

Turbocharger nut tightening torque N·m (kgf·m/lb·ft)

34 ~ 46 (3.5 ~ 4.7 / 25 ~ 34)
-------------------------------

Oil pipe bolt tightening torque N·m (kgf·m/lb·ft)

	Turbocharger side	Cylinder block side
Feed pipe	25 ~ 31 (2.5 ~ 3.2 / 18 ~ 23)	20 ~ 29 (2.0 ~ 3.0 / 14 ~ 22)
Return pipe	31 ~ 45 (3.2 ~ 4.6 / 23 ~ 33)	20 ~ 29 (2.0 ~ 3.0 / 14 ~ 22)



060E100001




**9. Starter**

Install the starter and tighten to the designated torque.

Starter tightening torque N·m (kgf·m/lb·ft)

125 ~ 150 (12.7 ~ 15.3 / 92 ~ 111)
------------------------------------



025E100002




**10. Intake cover**

- (1) Apply sealant "Three Bond No. 1207C" to the intake cover.
- (2) Install the intake cover and tighten the bolts gradually in two passes, using the tightening sequence shown.

Intake cover bolt tightening torque N·m (kgf·m/lb·ft)

25 ~ 30 (2.5 ~ 3.1 / 18 ~ 22)
-------------------------------






### 11. Coupling ASM

- (1) Align the V-groove on the camshaft with the alignment surface of the cam bracket on the intake manifold side (at compression TDC on the No. 1 cylinder). Confirm that the pointer on the flywheel housing points to the TDC mark on the flywheel.
- (2) If the injection pump drive gear has been removed from the coupling, reinstall it to the gear, being sure to align the key correctly.

Injection drive gear tightening torque    N·m (kgf·m/lb·ft)  
 206 ~ 304 (21.0 ~ 31.0 / 152 ~ 224)

- (3) As shown in the illustration, align the **A mark** with the coupling pointer.
- (4) Apply sealant "Three Bond No. 1208" to three points around the o-ring, and insert the o-ring into the coupling's groove.
- (5) Install the coupling to the timing gear case and tighten to the designated torque.
- (6) After installing the coupling, confirm that the coupling's pointer is in alignment with the **S mark**.

Coupling bolt tightening torque    N·m (kgf·m/lb·ft)  
 83 ~ 102 (8.5 ~ 10.4 / 61 ~ 75)




040E100008



### 12. Injection pump

- (1) Install the injection pump bracket, aligning it with the positioning pins on the cylinder block.

Pump bracket bolt tightening torque    N·m (kgf·m/lb·ft)  
 31 ~ 45 (3.2 ~ 4.6 / 23 ~ 33)




015E100049



- (2) Rotate the crankshaft clockwise and align the timing pointer (2) with the engraved lines on the flywheel (1), so that the No. 1 cylinder is set to injecting timing.

Injection timing (BTDC)  
 7°




040E100029



- (3) Hand-tighten the injection pump on the bracket, aligning the line engraved on the pump body with the line on the timer, and tighten the coupling.

Coupling tightening torque N·m (kgf·m/lb·ft)

103 ~ 113 (10.5 ~ 11.5 / 76 ~ 83)




040E100009



- (4) Tighten the injection pump bolts in the sequence shown.

Injection pump bolts tightening torque N·m (kgf·m/lb·ft)

31 ~ 45 (3.2 ~ 4.6 / 23 ~ 33)



052E100001



### 13. Oil return pipe

- Install the oil return pipe (2) and tighten to the designated torque.

Tightening torque N·m (kgf·m/lb·ft)


33 ~ 49 (3.4 ~ 5.0 / 25 ~ 36)

### 14. Oil feed pipe

- Install the oil feed pipe (1) and tighten to the designated torque.

Tightening torque N·m (kgf·m/lb·ft)

24 ~ 31 (2.4 ~ 3.2 / 17 ~ 23)



040E100013

### 15. Nozzle holder

- (1) Install the dust cover and nozzle gasket to the nozzle holder.

**Note:**

**Take care not to damage the nozzle tip.**

- (2) Install the nozzle holder flange and nuts, and hand tighten.

**Note:**

**Do not fully tighten until after installing the injection pipe.**



### 16. Glow plug

- Install the glow plugs, and tighten to the designated torque, then fasten the connectors.

Glow plug tightening torque N·m (kgf·m/lb·ft)

22 ~ 27 (2.25 ~ 2.75 / 16.3 ~ 19.9)



**17. Injection pipe**

- (1) Install the injection pipe and hand tighten
- (2) Tighten the nozzle holder flange nuts in alternate order, finally tightening evenly to the designated torque.

Flange nut tightening torque	N·m (kgf·m/lb·ft)
20 ~ 24 (2.0 ~ 2.4 / 14 ~ 17)	


- (3) Tighten the injection pipe to designated torque.

Injection pipe tightening torque	N·m (kgf·m/lb·ft)
Nozzle holder side	28 ~ 31 (2.9 ~ 3.2 / 21 ~ 23)
Injection pump side	34 ~ 44 (3.5 ~ 4.5 / 25 ~ 32)

- (4) Install the injection pipe clip in the designated position, and tighten.

**Note:**

**If the pipe clip is installed in the incorrect position, the pipe may be damaged and fuel pulsing sound may be heard.**



040E100011



**19. Fuel pipes**


- (1) Install fuel pipes ①, ②, ③ and ④, together with the return pipe ⑤.

Fuel pipe tightening torque	N·m (kgf·m/lb·ft)
33 ~ 49 (3.4 ~ 5.0 / 25 ~ 36)	


- (2) Install the clips in their designated positions.

**Note:**


**When tightening the fuel pipes, take care not to allow the pipes to turn together with the nuts, since the pipes may be deformed.**



042E100001



042E100003



060E10075



## 22. Alternator

Install the alternator bracket and alternator, and tighten to the designated torque.


Alternator bracket tightening torque ① N·m (kgf·m/lb·ft)

31 ~ 45 (3.2 ~ 4.6 / 23 ~ 33)

Alternator bolt tightening torque ② N·m (kgf·m/lb·ft)

93 ~ 139 (9.5 ~ 14.2 / 69 ~ 103)

Tighten the alternator bolts first by hand; then adjust the fan belt tension and finally tighten the bolts to the designated torque.



030E10023




## 23. Water pump pulley and adapter

Attach the pulley and adapter to the water pump and tighten to the designated torque.

Tightening torque N·m (kgf·m/lb·ft)

44 ~ 60 (4.5 ~ 6.1 / 33 ~ 44)



033E10003



## 24. Fan belt

Adjust the belt tension by moving the generator and adjusting plate.

- (1) Crank pulley
- (2) Water pump pulley
- (3) Alternator pulley

See chapter 2, Maintenance, "Cooling system." (P. 27)

### Note:


**When replacing a belt, replace both belts as a single set.**

**25. Cooling fan**

Install the cooling fan to the water pump pulley adapter.

Tighten the bolt to the designed torque.

Tightening torque	N·m (kg/cm <sup>2</sup> /lb·ft)
44 ~ 60 (4.5 ~ 6.1 / 33 ~ 44)	




**26. Fan guide**

(1) Install the fan guide brackets.


Tighten the nuts and bolt to the designed torque.

Tightening torque	N·m (kg/cm <sup>2</sup> /lb·ft)
Nut A	43 ~ 57 (4.4 ~ 5.8 / 32 ~ 42)
Bolt B	20 ~ 29 (2.0 ~ 3.0 / 14 ~ 22)



Tighten the bracket bolt to the designed torque.


Tightening torque	N·m (kg/cm <sup>2</sup> /lb·ft)
Bolt C	20 ~ 29 (2.0 ~ 3.0 / 14 ~ 22)




(2) Install the stay (1) to the fan guide bracket.

Tighten the bolts to the designed torque.

Tightening torque	N·m (kg/cm <sup>2</sup> /lb·ft)
44 ~ 60 (4.5 ~ 6.1 / 33 ~ 44)	






033E100006

- (3) Install the fan guide and fan guard.  
Tighten the bolts to the designed torque.

Tightening torque		N·m (kg/cm <sup>2</sup> /lb·ft)
Bolt A and B	44 ~ 60 (4.5 ~ 6.1 / 33 ~ 44)	




033E100012

- (4) Adjust the fan tip clearance.

Tip clearance	mm(in)
10 (0.39)	

# TIMING GEAR TRAIN DIAGRAM



014E100054


**CHAPTER 6**  
**LUBRICATION SYSTEM**

**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
<b>Introduction</b> .....	<b>118</b>
<b>Oil pump</b> .....	<b>119</b>
<b>Oil filter</b> .....	<b>123</b>
<b>Oil cooler</b> .....	<b>124</b>




# INTRODUCTION



F06E100019

## OIL PUMP

### DISASSEMBLY



051E100001




#### Disassembly sequence

- |                      |                        |
|----------------------|------------------------|
| 1. Oil strainer stay | 8. Oil relief valve    |
| 2. Oil strainer      | 9. Oil pump body cover |
| 3. Gasket            | 10. Driven gear        |
| 4. Oil pump          | ▲11. Drive gear        |
| 5. Gasket            | 12. Key                |
| 6. Spring seat       | 13. Drive gear shaft   |
| 7. Spring            | 14. Oil pump body      |



#### IMPORTANT OPERATIONS


- 11. Drive gear**  
Use a gear puller to remove the drive gear.



051E100002

## INSPECTION AND REPAIR

If excessive wear or damage is discovered during inspection, the appropriate parts must be adjusted, repaired, or replaced.




051E100010



### Oil relief valve and spring

Visually inspect the relief valve and spring, and replace if any damage is discovered.



051E100003




### Clearance between gear and pump cover inner wall

Use a feeler gauge to measure the clearance between the gear and the cover's inner wall.

If the measured clearance exceeds the limit, replace either the gear or the cover assembly.

Gear and cover inner-wall clearance mm (in)

Standard	Limit
0.100 ~ 0.196 (0.0039 ~ 0.0077)	0.15 (0.0059)



051E100004



### Clearance between gear face and upper surface of cover


Use a feeler gauge and square to measure the clearance between the gear face and the upper surface of the cover.

If the measured clearance exceeds the limit, the gear or the gear assembly must be replaced.

Gear face and cover clearance mm (in)

Standard	Limit
0.040 ~ 0.093 (0.0016 ~ 0.0037)	0.15 (0.0059)

ASSEMBLY



051E100005




**Assembly sequence**

- |                          |                            |
|--------------------------|----------------------------|
| 1. Oil pump body         | 8. Spring                  |
| 2. Drive gear shaft      | 9. Spring seat             |
| 3. Key                   | 10. Gasket                 |
| ▲ 4. Drive gear          | ▲ 11. Oil pipe             |
| 5. Driven gear           | 12. Gasket                 |
| ▲ 6. Oil pump body cover | ▲ 13. Oil strainer         |
| 7. Oil relief valve      | 14. Oil pump strainer stay |



**IMPORTANT OPERATIONS**




061E100001



**4. Drive gear**

- (1) Apply clean engine oil to the drive gear and the drive gear shaft.
- (2) Use a bench press to press the drive gear onto the shaft.  
Install the gear with its large bossing toward the shaft.  
Hold the shaft perpendicular and never apply pressure at an angle.




051E100007



**6. Oil pump body cover**

After installing the driven gear, tighten the oil pump body cover at the designated torque.

Body cover bolt tightening torque	N·m (kgf·m/lb·ft)
13 ~ 23 (1.3 ~ 2.3 / 9.4 ~ 16.6)	




051E100008



**11. Oil pipe**

Install the oil pipe on the pump body cover, and tighten to the designated torque.

Oil pipe bolt tightening torque	N·m (kgf·m/lb·ft)
14 ~ 24 (1.4 ~ 2.4 / 10 ~ 17)	



051E100009



**13. Oil strainer**

Install the oil strainer to the pump body cover and tighten to the designated torque.

Oil strainer bolt tightening torque	N·m (kgf·m/lb·ft)
14 ~ 24 (1.4 ~ 2.4 / 10 ~ 17)	

## OIL FILTER


### MAIN OIL FILTER

### PARTIAL OIL FILTER

See Chapter 2 Maintenance, "Lubrication System" (p. 22, 23)

## OIL COOLER

### DISASSEMBLY




#### Disassembly sequence

- |                              |                 |
|------------------------------|-----------------|
| 1. Water guide               | 6. Plug         |
| 2. Oil cooler                | 7. Gasket       |
| 3. Gasket                    | 8. Spring       |
| 4. Gasket                    | 9. Bypass valve |
| 5. Oil filter warning switch | 10. Body case   |

## INSPECTION AND REPAIR

If excessive wear or damage is discovered during inspection, the appropriate parts must be adjusted, repaired, or replaced.




050E100017



### Oil cooler core

If necessary, use red dye to check for cracks in the core.



050E100008



### Bypass valve

1. Check for wear or damage to the bypass valve seat.
2. Inspect the valve spring for weakening.



### Oil cooler element inspection

- Fill the element with cleaning fluid and allow to stand for about 10 hours.

Then drain about 1/3 of the cleaning fluid and apply about 200 (2) kPa (kgf/cm<sup>2</sup>) of pressurized air to the oil port, to force out the cleaning solution through the element.


Repeat this procedure to clean out the element as required.

Never use cleaning fluid in the vicinity of fire or flame; when handling cleaning fluid, always wear goggles and gas mask, and use only in a well-ventilated room.

	Straight solution	Diluted with diesel fuel
Haiarom 25 (Nisseki)	○	—
Suwazol 310 (Maruzen)	○	—
Haizol (Showa shell)	○	—
Mobizol A (Mobil Oil)	—	○



ASSEMBLY



050E100010




**Assembly sequence**

- |                  |                               |
|------------------|-------------------------------|
| 1. Body case     | ▲6. Oil filter warning switch |
| ▲2. Bypass valve | 7. Gasket                     |
| 3. Spring        | 8. Gasket                     |
| 4. Gasket        | ▲9. Oil cooler element        |
| 5. Plug          | 10. Water guide               |



## IMPORTANT OPERATIONS



050E100013




### 2. Bypass valve

- (1) Install the bypass valve and spring in the body case.
- (2) Apply clean engine to the gasket and install together with the plug, then tighten to the designated torque.

Bypass valve plug tightening torque      N·m (kgf·m/lb·ft)

29 ~ 39. (3.0 ~ 4.0 / 22 ~ 29)



050E100011




### 6. Oil filter warning switch

- (1) Install the valve and spring in the body case.
- (2) Install the warning switch and tighten to the designated torque.

Warning switch tightening torque      N·m (kgf·m/lb·ft)

39 (4/29)



050E100012



### 9. Oil cooler element

- (1) Apply sealant to the body case's o-ring groove.
- (2) Install the o-ring and gasket to the element.
- (3) Install the oil cooler element to the body case and tighten to the designated torque.

Oil cooler element tightening torque      N·m (kgf·m/lb·ft)


15 ~ 25 (1.5 ~ 2.5 / 11 ~ 18)



**CHAPTER 7**  
**COOLING SYSTEM**  
**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
<b>Introduction</b> .....	<b>130</b>
<b>Water pump</b> .....	<b>131</b>
<b>Thermostat</b> .....	<b>138</b>


# INTRODUCTION



F08E100020

## WATER PUMP

### DISASSEMBLY



030E100003




#### Disassembly sequence

- |                                  |  |
|----------------------------------|--|
| 1. Gasket                        | 6. Snap ring                             |
| ▲2. Impeller                     | ▲7. Water pump shaft (with ball bearing) |
| 3. Impeller seal unit            | 8. Oil seal (impeller side)              |
| ▲4. Pulley center                | 9. Water pump body                       |
| 5. Oil seal (pulley center side) |  |



## IMPORTANT OPERATIONS



030E100004


### 2. Impeller

- (1) Support the pulley center with a vice.
- (2) Use an impeller remover to remove the impeller.  
Impeller remover: 1-85210-047-0



#### Note:


**Do not remove the impeller by striking it, since it may be damaged.**



030E100005

### 4. Pulley center

Use a pulley remover to remove the pulley center.




030E100006

### 7. Water pump shaft (with ball bearing)

- (1) Remove the snap ring on the pulley center side.
- (2) Remove the water pump shaft by using a plastic hammer to tap the shaft free from the water pump body.

## INSPECTION AND REPAIR

If excessive wear or damage is discovered during inspection, the appropriate parts must be adjusted, repaired, or replaced.



03DE100007




### Impeller

1. Inspect the impeller for corrosion, excessive wear on the seal unit fitting face, and other damage.
2. Measure the interference between the pump shaft and impeller.



Interference mm (in)

0.025 ~ 0.060 (0.0010 ~ 0.0024)
---------------------------------




03DE100006



### Pulley center

Inspect the pulley center's oil seal fitting face for excessive wear or damage.



03DE100009




### Pump shaft (with ball bearing)

1. Inspect the pump shaft's oil seal fitting face for excessive wear or damage.
2. Inspect the bearing for separation, wear and abnormal noise.
  - (1) Check between the balls for scratches and separation in the race.
  - (2) Check for rattling between the balls and race.
  - (3) Rotate the bearings by hand and check for any abnormal resistance. If any abnormalities are discovered, replace the ball bearings.



### Ball bearing replacement




030E100010



#### Removal

Place the water pump shaft (1) with the bearing attached, between the base plates (2) of a bench press, and slowly apply pressure to force the shaft from the bearing.



030E100011




#### Installation

1. Apply clean engine oil to the inside surface (shaft side) of the bearing's inner race.
2. Place the water pump shaft (1) between the base plates (2) of a bench press.



#### Note:

**To prevent damage to the water pump shaft, place soft brass or copper sheets between the base plates and the water pump shaft.**




030E100012

3. Place the small-diameter bearings (3) on the shaft, and using a pipe with the same diameter as the shaft, slowly press the bearing onto the shaft.
4. Install the spacer (4).
5. Insert the large-diameter bearing (5) and slowly press onto the shaft. Press on the final large-diameter bearing in the same way.

#### Note:

1. **When pressing the bearings, be sure to maintain the pump shaft in a perpendicular position.**
2. **When pressing, do not hit the outer race with the pressing pipe.**

## ASSEMBLY




030E100013

**Assembly sequence**

- |   |                         |
|---|-------------------------|
| 1. Water pump body                        | ▲6. Pulley center       |
| ▲2. Oil seal (impeller side)              | ▲7. Seal unit           |
| ▲3. Water pump shaft (with ball bearings) | ▲8. Water pump impeller |
| 4. Snap ring                              | 9. Gasket               |
| ▲5. Oil seal (pulley center side)         |                         |



## IMPORTANT OPERATIONS




030E100014



### 2. Oil seal (impeller side)

- (1) Apply molybdenum disulfide grease to the inner periphery of the oil seal lip.
- (2) Apply clean engine oil to the outer periphery of the oil seal.
- (3) Press the oil seal into place with the lip facing the outside, and taking care not to deform the oil seal.




030E100015



### 3. Water pump shaft (with bearings)

- (1) Set the pump with the impeller mounting side facing down, and set on top of the base plates of a bench press.
- (2) Apply engine oil to the outer periphery of the bearing outer face.
- (3) Use the bench press to slowly press in the pump shaft (with bearings) from the pulley center side.

**When pressing the pump shaft, take care not to damage the oil seal.**




030E100018



### 5. Oil seal (pulley-center side)


- (1) Apply molybdenum disulfide grease to the inner periphery of the seal lip.
- (2) Press in the oil seal with the lip facing the inside and taking care not to deform the seal.



030E100017

### 6. Pulley center

Use a bench press to press in the pulley center, taking care not to damage the oil seal.




030E100019



### 7. Seal unit

- (1) Apply sealant to the pump body contact surface of the seal unit.
- (2) Press in the seal unit fully until its collar strikes the pump body.

**Take care not to damage the seal unit.**




030E100020



### 8. Water pump impeller

Use a bench press to press in the impeller until the designated clearance exists between it and the pump body facing.

Pump body and impeller clearance	mm (in)
0.5 (0.020)	



030E100021

#### Note:

1. The fan center and impeller have been installed on the pump shaft with a press, and no attempt must be made to remove or reinstall them separately. Always replace the assembly as a single unit. Removing and installing the fan center and impeller alone may result in the failure of the water pump during engine operation, leading to serious overheating.

#### Note:

2. The water pump assembly must be replaced any time the fan center and impeller pressure can be pulled off with a force of less than falls below 1,960 N (200 kgf).


#### Note:

3. Do not strike bearings with a hammer to install, since damage may result.

## THERMOSTAT

### INSPECTION AND REPAIR

If excessive wear or damage is discovered during inspection, the appropriate parts must be adjusted, repaired, or replaced.



#### Operation test

1. Completely submerge the thermostat in water as shown.
2. Heat the water while constantly stirring so that the thermostat never come into contact with direct heat from the bottom.
3. Check the temperature at which the thermostat valve opens.



Thermostat valve operation temperature °C (°F)

74.5 ~ 78.5 (166 ~ 173)


4. Check the temperature at which the valve is fully open.

Thermostat full-open temperature °C (°F)

90 (194)

Valve lift when fully open mm (in)


10 (0.39)



**CHAPTER 8**  
**FUEL SYSTEM**  
**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
<b>Introduction</b> .....	<b>140</b>
<b>Injection nozzle</b> .....	<b>141</b>


# INTRODUCTION



F06E100028

## INJECTION NOZZLE – 2 Stage Injection Type

### DISASSEMBLY



040E100016



### Disassembly sequence

- |  |  |
|--|--|
| 1. Retaining nut                                       | 9. Collar  |
| 2. Nozzle & pin  | 10. Spring seat  |
| 3. Spacer & pin  | 11. First spring                                       |
| 4. Lift piece  | 12. Shim (First nozzle opening<br>pressure adjustment) |
| 5. Spring seat   | 13. Nozzle holder body                                 |
| 6. Push rod  | 14. Eye bolt   |
| 7. Shim (Second nozzle opening<br>pressure adjustment) | 15. Gasket   |
| 8. Second spring                                       |  |


(1) Before disassembly remove carbon deposit from nozzle and nozzle holder using a wire brush and wash the outside nozzle holder assembly.

**Caution: Do not touch nozzle holes with the wire brush during cleaning it.**

(2) Disassemble the nozzle holder assembly to numerical order.



**REASSEMBLY AND OPENING PRESSURE ADJUSTMENT**




040E100017








**Reassembly sequence**

- |   |  |
|---|--|
| 1. Nozzle holder body                       | 8. Shim (Second opening pressure adjustment) |
| 2. Shim (First opening pressure adjustment) | 9. Spring seat                               |
| 3. First spring                             | 10. Lift piece                               |
| 4. Spring seat                              | 11. Spacer & pin                             |
| 5. Collar                                   | 12. Nozzle & pin                             |
| 6. Second spring                            | 13. Retaining nut                            |
| 7. Push rod                                 | 14. Gasket                                   |
|   | 15. Eye bolt                                 |


The nozzle holder is adjusted as the components are reassembled in the sequence above. As adjustment of the 2 stage injection type nozzle holder is made in hundredths of a millimeter, clean the parts thoroughly in light oil to completely remove any dirt or foreign matter.

**REASSEMBLY AND ADJUSTMENT PROCEDURE**




### First nozzle opening pressure adjustment


1. Clamp the nozzle holder in a vise.
2. Install the shim, first spring and spring seat in the nozzle holder.
3. Install the collar, second spring, shim, spring seat and push rod in the nozzle holder.
4. Install the pins, lift piece and spacer in the nozzle holder.
5. Install the pins in the spacer.
6. Install the nozzle on the spacer.



040MV010



040MV014-1



040MV030

7. Hand-tighten the adjustment retaining nut together with the gasket to the nozzle holder.  
Retaining nut: 157892-4000 (ZEXEL)  
Gasket: 157892-1500 (ZEXEL)

8. Tighten the adjustment retaining nut to the specified torque.

Torque	N·m (kg·m)
29 – 39 (3.0 – 4.0)	


9. Set the nozzle holder to the nozzle tester.
10. Operate the nozzle tester and measure the first nozzle opening pressure.

MPa (psi)	
Nominal	Adjustment
17.7 (2570)	18.1 – 18.9 (2630 – 2740)

11. If the first nozzle opening pressure is not as specified, disassemble the nozzle holder and replace the shim until the pressure is as specified.





**CAUTION:**  
Use a micrometer to measure shim thickness.

First nozzle opening pressure adjusting shim



040MV023

Part No. (ZEXEL)	Thickness
150539-0700	0.40
150539-0800	0.50
150539-0900	0.52
150539-1000	0.54
150539-1100	0.56
150539-1200	0.58
150539-1300	0.60
150539-1400	0.70



### Full needle valve lift confirmation

1. Install the gasket and plug on the adjustment retaining nut.  
Gasket: 026508-1140 (ZEXEL)  
Plug: 157892-1600 (ZEXEL)

2. Position the nozzle holder with the nozzle facing down and install the dial gauge holder on the nozzle holder.  
Dial gauge holder: 157892-5000 (ZEXEL)

3. Install the nut on the dial gauge holder.  
Nut: 157892-1000 (ZEXEL)


4. Install the pin to the dial gauge.

### Note:

The lengths of the pins do not include the threaded portions.

Pin (ℓ=85 mm): 157892-4700 (ZEXEL)

Dial gauge: 157954-3800 (ZEXEL)




040MV009

5. Secure the dial gauge to the nozzle holder using the nut so that the pin contacts the tip of the first spring seat.


**CAUTION:**

- Secure the dial gauge so that a stroke of 2 mm can be measured.
- Do not over-tighten the nut as the dial gauge shaft may jam. (Confirm from the dial gauge that the shaft moves smoothly.)



040MV030

6. Set the nozzle holder to the nozzle tester and put needle to zero on the dial gauge.
7. Operate the nozzle tester to bleed any air from inside the retaining nut and to confirm that no fuel leaks.




040MV008


8. Operate the nozzle tester and increase the in-line pressure to 34.3 – 44.1 MPa (350 – 450 kg/cm<sup>2</sup>) so that the nozzle's needle valve moves through its full lift.  
Record full lift 'L'. (Read dial gauge)

**Note:**


The above operation is used to determine whether the nozzle seat is worn and whether the nozzle assembly is in good condition.




040MV007




040MV006



040MV025-1



040MV005



040MV031

**Pre-lift confirmation**

1. With the needle valve at full lift, release the nozzle tester handle.

**Note:**

The in-line pressure will decrease and needle valve lift (as indicated on the dial gauge) will also decrease a little.

2. Read the needle valve lift ' $\ell$ ' from the dial gauge indication (once the needle valve has descended when the second spring has stopped operating). Refer to the pre-lift measuring point for ' $\ell$ '.

**Pre-lift measuring point:**

Read the dial gauge at first nozzle opening pressure + approx 1 MPa (10 kg/cm<sup>2</sup>).

**Note:**


This point can be found while the pressure is decreasing.

3. Confirm that pre-lift ' $\ell$ ' is as specified.


Pre-lift	mm (in)
	0.06 (0.0024)

4. If pre-lift is not as specified, replace the pins, lift piece, spacer and nozzle assembly as a set with the service kit.


Service kit: 105019-0290 (ZEXEL)




040MV030



040MV022



040MV024



040MV026

### Second nozzle opening pressure confirmation

1. After pre-lift confirmation, operate the nozzle tester to increase in-line pressure to 34.3 – 44.1 MPa (350 – 450 kg/cm<sup>2</sup>) so that the nozzle's needle valve moves through its full lift.

Full lift	mm (in)
	0.4 (0.0157)


2. Release the nozzle tester handle so that in-line pressure decreases.

**Note:**

The in-line pressure will decrease and needle valve lift (as indicated on the dial gauge) will also decrease a little.

3. Then, read the pressure gauge indication (second nozzle opening pressure) the instant that the dial gauge indicates the specified needle valve lift (usually pre-lift  $l + 0.05\text{ mm}$ ).





040MV017

## Second nozzle opening pressure adjustment


If the second nozzle opening pressure is not as specified, disassemble the nozzle from the nozzle holder and replace the shim until the pressure is as specified.

MPa (psi)

Nominal	Adjustment
22.1 (3200)	23.1 – 24.1 (3350 – 3500)

### CAUTION:

- Because the second opening pressure changes when the first opening pressure changes, the second opening pressure must be adjusted when the first opening pressure changes.
- Use a micrometer to measure shim thickness.




040MV027


## Second nozzle opening pressure adjusting shim

mm

Part No. (ZEXEL)	Thickness
150590-0600	0.40
150590-0700	0.50
150590-0800	0.52
150590-0900	0.54
150590-1000	0.56
150590-1100	0.58
150590-1200	0.60
150590-1300	0.70



040MV028



040MV014-1


## Final inspection

1. Remove the dial gauge, nut and dial gauge holder.
2. Remove the adjustment retaining nut and gasket.
3. Install the original retaining nut, confirm that the pins are inserted fully into the nozzle, and then hand-tighten the retaining nut. Then, tighten the original retaining nut to the specified torque.

Torque

N·m (kg·m)

59 – 79 (6.0 – 8.0)
---------------------



4. Set the nozzle holder to the nozzle tester and check first nozzle opening pressure, spray condition, seat oil tightness and each part for oil leaks.
5. When replacing the nozzle, replace the nozzle, lift piece, pins and spacer as a set with the nozzle service kit.

**CAUTION:**

**Pre-lift will not be as specified if only the nozzle is replaced.**

# MEMO

A series of horizontal dotted lines for writing, spanning the width of the page.

---

**CHAPTER 9**  
**TURBOCHARGER**  
**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
<b>Turbocharger servicing</b> .....	<b>154</b>
<b>Troubleshooting</b> .....	<b>155</b>
<b>Construction</b> .....	<b>157</b>
<b>Disassembly</b> .....	<b>158</b>
<b>Cleaning</b> .....	<b>161</b>
<b>Inspection</b> .....	<b>163</b>
<b>Reassembly</b> .....	<b>165</b>
<b>Service standard</b> .....	<b>171</b>

## **TURBOCHARGER SERVICING**

1. Refer to TROUBLESHOOTING in this Section to determine whether or not turbocharger repair or overhaul is required.
2. The following procedures should also be performed (either with the turbocharger on the equipment or removed from the equipment but not disassembled) to determine whether or not turbocharger repair or overhaul is required.
  - \* Visual checks
  - \* Clearance measurements
  - \* End play measurements
3. The turbocharger compressor and turbine housing may be removed from the center housing and rotating assembly for further visual inspection.

## TROUBLESHOOTING

If the engine does not run well (insufficient output or irregular acceleration) -

1. Run the engine at idle.
2. Check for oil leakage from the turbocharger.
3. Listen for abnormal turbocharger noise.
4. Write down any abnormal conditions and their location.
5. Stop the engine.
6. Allow sufficient time for the turbocharger to cool.
7. Check the turbocharger air inlet hose and outlet hose. The bands attaching the hoses to the turbocharger must be tight. There must be no oil leakage.

**WARNING: The turbocharger generates very high temperatures during operation. It will remain dangerously hot for some time after the engine is stopped. Allow sufficient time for the turbocharger to cool before touching it.**

### OIL LEAK

Leak point	Cause	Countermeasure
Turbine housing gas inlet and outlet tightening area	Bearing abrasion (Trouble in the oil supply system)	Check the turbocharger air inlet
Turbine and bearing housing mating surfaces		
Turbocharger oil inlet tightening area	Loose bolts	Tighten bolts
	O-ring damage	Replace O-ring
Compressor housing case	Oil leak from tightening area (Air compressor oil leak)	Turbocharger OK

### ABNORMAL NOISE

Description	Cause	Countermeasure
Whistling sound	High-speed turbocharger operation	Normal sound of rotor rotation
Grinding sound	Foreign particles in turbocharger	Check the turbocharger air inlet
	Bearing abrasion (Trouble in the oil supply system)	
Hissing sound	Loose air or gas pipe	Tighten bolts, screws, and/or hose bands as required

### INSUFFICIENT OUTPUT OR IRREGULAR ACCELERATION

Problem	Cause	Countermeasure
Poor engine performance because of air and/or gas leakage	Loose air and/or gas pipes running to the turbocharger	Tighten bolts, screws, and/or hose bands as required


## Turbocharger

---

Disconnect the air inlet hose at the turbocharger to perform the following inspection.

Checkpoint	Problem	Countermeasure
Air inlet	Oil on air inlet inside and outside surfaces resulting from oil leakage	Turbocharger OK
Shaft end nuts or blades	Loose or missing	Replace turbocharger
	Foreign particles in turbocharger	
	Bearing abrasion (Trouble in the oil supply system)	
Compressor housing	Blade and housing interference	
	Bearing abrasion (Trouble in the oil supply system)	
Oil feed pipe	Clogged	Remove restrictions

## CONSTRUCTION



03/7E100039


**Legend**

- (1) Compressor cover
- (2) Bearings
- (3) Turbine back plate
- (4) Turbine housing

- (5) Turbine wheel
- (6) Bearing housing
- (7) Oil deflector
- (8) Compressor wheel
- (9) Nut




DISASSEMBLY



037E100004

**Legend**

- |                           |                         |
|---------------------------|-------------------------|
| (1) Coupling ASM          | (12) Gasket             |
| (2) Turbine housing       | (13) Oil deflector      |
| (3) Snap ring             | (14) Thrust ring        |
| (4) Compressor cover      | (15) Thrust bearing     |
| (5) Nut                   | (16) Thrust ring        |
| (6) Compressor wheel      | (17) Piston ring        |
| (7) Snap ring             | (18) Turbine back plate |
| (8) Shaft & turbine wheel | (19) Bearings           |
| (9) Insert                | (20) Snap ring          |
| (10) Thrust sleeve        | (21) Gasket             |
| (11) Piston ring          | (22) Bearing housing    |




037E100005

1. Remove the coupling assembly (1).


**Note:**

When you reassemble the turbocharger the exact positioning of the compressor cover, bearing housing (3), and turbine housing (2) are important. Before disassembly, use a felt-tip pen or punch to mark these parts so you can match them correctly at reassembly.




037E100006

2. Remove the turbine housing (1).



037E100007

3. Remove the snap ring (1).




037E100008

4. Remove the compressor cover (1) by tapping around it lightly with a plastic hammer or wooden mallet.


**Note:**

Do not bump the compressor wheel against the compressor cover.




037E100009


5. Fit bearing housing (3) to turbine housing (1) by clamping them in a vise. Fix the boss of the shaft & turbine wheel with the 17 mm box wrench. Remove the compressor wheel (2) and mounting lock nut with a 14 mm box wrench.




037E100010



037E100011



037E100012



037E100042

6. Restrain the turbine wheel by hand, then turn the compressor wheel (1) to lift it off the shaft.

7. Remove snap ring (1) with a pair of snap ring pliers (2).



**WARNING:**

**If the ring ends slip off the ends of the pliers, the ring may fly off. Use your hand to hold down the snap ring while you pinch the ring ends with the snap ring pliers.**

8. Use two screwdrivers to gently lift the insert (1) off the bearing housing. Remove the following parts after the insert is removed:

- (1) Insert
- (2) Piston ring
- (3) Thrust sleeve
- (4) Gasket
- (5) Oil deflector
- (6) Thrust ring
- (7) Thrust bearing
- (8) Thrust ring

9. Remove the following parts from the bearing housing (6). Use snap ring pliers to remove the snap ring (5).


- (1) Shaft & turbine wheel
- (2) Piston ring
- (3) Turbine back plate
- (4) Bearing
- (5) Snap ring
- (7) Gasket
- (8) Gasket

**Note:**

- 1. **If you see the blades of the turbine wheel are bent or damaged, replace it.**
- 2. **Do not attempt to straighten the bent blades. Replace the part.**
- 3. **Use snap ring pliers to remove the snap ring.**

## CLEANING

This section will show you how to clean the turbocharger without using blasting equipment, a common practice at most maintenance factories and shops.



037E100035


### Legend

- |                            |                       |
|----------------------------|-----------------------|
| (1) Bearing housing        | (12) Thrust sleeve    |
| (2) Snap ring              | (13) Gasket           |
| (3) Bearings               | (14) Insert           |
| (4) Thrust ring            | (15) Snap ring        |
| (5) Thrust bearing         | (16) Compressor wheel |
| (6) Thrust ring            | (17) Nut              |
| (7) Oil deflector          | (18) Gasket           |
| (8) Turbine back plate     | (19) Compressor cover |
| (9) Piston ring            | (20) Snap ring        |
| (10) Shaft & turbine wheel | (21) Turbine housing  |
| (11) Piston ring           | (22) Coupling ASM     |

### Note:

1. Never blast the parts marked in the drawing above, the end surfaces of the compressor wheel (5), or the shaft of the shaft & turbine wheel (13).
2. If you use a household detergent, choose one that is chemically neutral (non-corrosive).


## Turbocharger




1. Before cleaning, visually inspect all parts for signs of wear or burning.
2. Soak the parts in a pan filled with solvent. Wash each part separately to remove all oil, grease, and carbon scale.

**Note:**

1. **Do not soak in solvent the gaskets, bearing, and thrust bearing.**
2. **Commercially available "Oil Clean", an alcohol base organic solvent, should be diluted with water (5-10 parts water to 1 part solvent).**




3. Blow compressed air on the parts to clean them.




4. With a plastic scraper or wire brush, remove scale from the parts.

**Note:**

**If shot blasting is used to clean parts, the surfaces of the compressor wheel, and the threads, rings and grooves of the shaft & turbine wheel should be covered to protect them.**



5. Blow compressed air on the parts to clean them.




6. Apply clean engine oil to all sliding surfaces. Buff to remove rust from screw threads, shaft, and ring grooves.

**Note:**

**Do not use a file to clean the surfaces.**

## INSPECTION




037HY00024

### Bearing housing

Measure the inside diameter of the bearing bores in the housing. If they exceed the service limit, replace the housing.

Limit mm (in)

$\varnothing$ 20.506 (0.80732)
--------------------------------




037HY00025

### Bearing

1. Measure the outside diameter of the bearing. If it is less than the service limit, replace the bearing.

Limit mm (in)

$\varnothing$ 20.382 (0.80244)
--------------------------------




037HY00026

2. Measure the inside diameter of the bearing. If it exceeds the service limit, replace the bearing.

Limit mm (in)

$\varnothing$ 12.042 (0.47409)
--------------------------------




037HY00027


3. Measure the length of the bearing. If it is less than the service limit, replace the bearing.

Limit mm (in)


11.94 (0.4701)
----------------



037HY00028



037HY00029



037E100037

**Shaft & turbine wheel**

1. Measure the diameter of the shaft journals.  
If it is less than the service limit, replace the shaft & turbine wheel.

Limit	mm (in)
∅ 11.996 (0.4722)	

2. Use a dial indicator and V-block to measure the runout of the shaft. If it exceeds the service limit, replace the shaft & turbine wheel.

**Note:**

1. **Replace the shaft & turbine wheel if it is bent. Never attempt to straighten a bent shaft.**
2. **Check the surfaces of the shaft journals. If they are rough, hold the shaft on a lathe by tightening it in the chucks at the center. Turn it at 300 to 600 rpm to lightly polish the journals with #400 (or finer) sandpaper and engine oil.**

**Insert**

Place a new piston ring in the groove of the insert. Measure the end gaps of the ring. If the gap exceeds the standard clearance, replace the insert.


Standard clearance	mm (in)
0.05 – 0.25 (0.0020 – 0.0098)	

**Replacement parts**

The following parts should be replaced at disassembly:

- (1) Piston rings
- (2) Gaskets

## REASSEMBLY



037E100039

**Legend**


- (1) Compressor cover
- (2) Bearings
- (3) Turbine back plate
- (4) Turbine housing

- (5) Turbine wheel
- (6) Bearing housing
- (7) Oil deflector
- (8) Compressor wheel
- (9) Nut


**Note:**

After installing an overhauled turbocharger on the engine, crank the engine with the starter to permit the engine oil to flow to the turbocharger.





037HY00084



037E100019


1. Reassemble the following parts.

- (1) Bearing housing
- (2) Snap ring
- (3) Bearing
- (4) Turbine back plate
- (5) Piston ring
- (6) Shaft & turbine wheel

**Note:**


1. Use snap ring pliers (49160-90200) to attach snap ring (2). Insert the snap ring (2) into the bearing housing (3). The side with the round edge has to contact the bearing (1). Upon inserting the snap ring, do not compress it too much with the snap ring pliers.
2. After applying oil to the outer and inner surfaces of the bearing (1), install it.
3. Apply a light coat of oil to the piston ring of the shaft & turbine wheel.  
Do not expand the ring more than necessary, and do not twist its end gap.
4. Do not push the shaft & turbine wheel unless it is aligned properly.

Do not damage the blades of the shaft & turbine wheel. Align the shaft properly before you insert it. Excessive force can bend the shaft if it is not properly aligned.




037E100020

2. After the assembly above is completed, mount the bearing housing (1) on the turbine housing (2). Tighten temporarily with the coupling assembly (1).




037E100021

3. install the thrust bearing (1) after applying engine oil to its inside and outside surfaces. Wipe dust and oil from the shaft and end surfaces of the thrust ring.



037E100022

4. Apply engine oil to the O-ring (1) then install it.




037E100023

5. Assemble the insert (2) sub-assembly parts in the following order.

- (1) Oil deflector
- (4) Thrust sleeve
- (3) Piston ring
- (2) Insert

**Note:**


- 1. When you install the piston ring (3) to the thrust sleeve (4), do not expand the ring more than necessary and do not twist its end gaps.
- 2. Apply engine oil to the piston ring (3) fitted to the thrust sleeve (4), then install the sleeve to the insert (2). To avoid damage to the ring, fit the ring gently, end gap first.




037E100038

After completing the above assembly, mount the sub-assembly to the bearing housing (2). Keep the end surface of the thrust ring and both ends of the thrust sleeve clean and free of dust and oil.


**In the drawing shown on the right shows, apply Molykote, engine oil, or grease to the specified parts. Remove all oil from parts of thick line.**




037E100025



037E100026



037E100027



037E100044

- Using snap ring pliers (49160-90100), install snap ring (1) to the bearing housing (2) with its tapered side facing up.

**Note:**

- When you install the snap ring (2), position it in the specified direction.
- Use a hammer and screwdriver to tap lightly the ends of the snap ring so it fits snugly in the groove of the bearing housing (1).
- When tapping the snap ring in position, do not damage the bearing housing with the screwdriver.

- Set up a dial indicator on the shaft & turbine wheel (1). Move the shaft & turbine wheel in the axial direction to measure the clearance. If it is not within standard clearance, disassemble the parts and check for the cause.


Standard clearance	mm (in)
0.39 – 1.00 (0.0154 – 0.0394)	

- Keep the ends of the thrust sleeve and both end surfaces of the compressor wheel clean and free of dust and oil.
- Install the compressor wheel. Apply Molykote to the threads of lock nut. Tighten the nut to the specified torque

Tighten torque	N·m (kgf·m/lb·ft)
20 (2.0 / 14)	

**Note:**

- To tighten, set the turbocharger at a right angle with the wrench at a right angle to the shaft. Be careful not to bend the shaft.
- To tighten, hold down the compressor wheel with your fingers to prevent it from rotating with the wrench.




037E100029

10. Set up a dial indicator on the shaft and turbine wheel (2) as shown. Move the compressor wheel (1) in the axial direction to measure the play. If the play is not within standard clearance, disassemble the parts and check for the cause.

Standard clearance mm (in)

0.075 – 0.155 (0.00295 – 0.00610)
-----------------------------------



037E100030

11. Remove the turbine housing from the bearing housing (1). Install the compressor cover (2).


With feeler gauges, measure the clearance between turbine back plate and turbine wheel. If the clearance is not within standard clearance, disassemble the parts and check for cause.

**Note:**

**Measure the clearance with two feeler gauge from the tips of the vanes as shown.**


Standard clearance mm (in)

0.48 – 0.92 (0.0199 – 0.0362)
-------------------------------




037E100031

12. Install the compressor cover (2). Be sure that it is correctly positioned with respect to the turbine housing. Apply grease to O-ring (1) before you install it.




037E100007

13. Install snap ring (1).



037E100006

14. Be sure the turbine housing (1) is correctly positioned with the compressor housing.



037E100043

15. Apply Molykote to the threads of the coupling assembly (1), then tighten it to the specified torque.

Tightening torque	N·m (kgf·m/lb·ft)
6 (0.6 / 4.3)	

## SERVICE STANDARD

Units: mm (in.)

Part or Item		Nominal Value	Assembly Standard (Standard Clearance)	Service Limit (Clearance)	Remarks
Inside diameter of bearing housing bores		ø20.5 (0.807)		ø20.506 (0.80732)	
Bearing	Outside diameter			ø20.382 (0.80244)	
	Inside diameter			ø12.042 (0.47409)	
	Length			11.94 (0.4701)	
Shaft & turbine wheel	Diameter of journals	ø12.0 (0.47)		ø11.996 (0.47228)	
	Runout of shaft			0.015 (0.00059)	
End gap of piston ring			0.05 – 0.25 (0.0020 – 0.0098)		With ring fitted in the insert
Clearance between shaft & turbine wheel and turbine housing			0.39 – 1.00 (0.0154 – 0.0394)		
Axial play of shaft & turbine wheel			0.075 – 0.155 (0.00295 – 0.00610)		
Clearance between turbine back plate and turbine wheel			0.48 – 0.92 (0.0189 – 0.0362)		



**CHAPTER 10**  
**ENGINE ELECTRICAL**  
**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
<b>Starter</b> .....	<b>174</b>
<b>Alternator</b> .....	<b>186</b>




## STARTER

### MAIN DATA AND SPECIFICATIONS


Isuzu Part No.		1 – 81100 – 230 – 1
Nippon Denso Code No.		1 – 28000 – 245 – 0
Rated voltage	(V)	24
Rated output	(kW)	5.5
Rating	(Sec)	30
Direction of rotation (Viewed from the pinion side)		Clockwise
Clutch type		Roller
Terminal voltage (No Load)	(V)	24
Minimum current (No Load)	(A)	120
Minimum operating speed (No Load)	(rpm)	4100
Pinion gear		
Modules		3
Number of teeth		11
Outside diameter	mm (in.)	40.5 (1.6)
Travel distance	mm (in.)	0.82 (0.032)
Yoke outside diameter	mm (in.)	100 (3.94)
Number of poles		4
Magnetic switch (at 20°C [68°F] )		
Series coil resistance	(Ω)	0.76 – 0.84
Shunt coil resistance	(Ω)	2.42 – 2.64
Brush length		
Standard	mm (in.)	20 (0.79)
Limit	mm (in.)	13 (0.51)
Brush spring standard fitting load	kg (lbs.)	3.3 (7.3)
Commutator		
Outside diameter		
Standard	mm (in.)	43 (1.69)
Limit	mm (in.)	42 (1.65)
Difference between the largest and smallest diameters		
Standard	mm (in.)	0.02 (0.0008)
Limit	mm (in.)	0.05 (0.0020)
Depth of undercut mica		
Standard	mm (in.)	0.5 – 0.8 (0.02 – 0.03)
Limit	mm (in.)	0.2 (0.008)

### SECTIONAL DRAWING




060E100004

### OUTPUT CHARACTERISTICS




060E100042

CIRCUIT ARRANGEMENT



060E10034

## DISASSEMBLY



060E100007




### Disassembly sequence

- |                              |                               |
|------------------------------|-------------------------------|
| 1. Hexagon nut               | ▲10. Starter housing          |
| 2. Connecting lead wire      | ▲11. Pinion clutch            |
| 3. Through bolts             | ▲12. Steel ball               |
| ▲4. End frame                | ▲13. Starter pinion           |
| 5. Starter seal              | ▲14. Idler gear               |
| ▲6. Yoke                     | ▲15. Retainer                 |
| ▲7. Brushes and brush holder | ▲16. Clutch roller            |
| ▲8. Armature                 | 17. Compression return spring |
| 9. Screw                     | ▲18. Magnetic switch body     |




**IMPORTANT OPERATIONS**



060E100005


- 4. End frame
- 6. Yoke
- 10. Starter housing
- 18. Magnetic switch body

Apply setting marks across the end frame, the yoke, and the magnetic switch body. This will ensure reassembly of the parts in their original positions.




060E100009

- 6. Yoke  
Remove the yoke ① from the magnetic switch ②.



060E100010


- 7. Brushes and brush holder  
Use a long nose pliers to remove the brushes and pull out the brush holder.



060E100011

- 8. Armature  
Remove the armature from the yoke.

**Note:**  
If necessary, tap the yoke end with a plastic hammer to remove the armature.




060E100012

**11. Pinion clutch**

Remove the magnetic sub-switch from the starter housing.

**Note:**


**If the pinion is installed to the starter housing (externally attached to the magnetic sub-switch shaft, it must be removed before the magnetic sub-switch.**



060E100013

**12. Steel ball**

Remove the steel ball from the pinion clutch.




060E100014

**13. Starter pinion**

**14. Idler gear**

Remove the starter pinion and the idler gear from the starter housing.



060E100015

**15. Retainer**


**16. Clutch roller**

Remove the retainer and the clutch roller from the starter housing.



## INSPECTION AND REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.



060E100077


### ARMATURE

#### Armature short circuit test

1. Place the armature on a growler tester ①.
2. Hold a hacksaw blade ② against the armature core while slowly rotating the armature.

If the armature is short circuited, the hacksaw blade will vibrate and will be attracted to the armature core.

A short circuited armature must be replaced.




060E100036



#### Armature winding ground test

Check for continuity across the commutator segments and the core.

If there is continuity, the armature is internally grounded due to insulation failure and must be replaced.




060E100076



#### Armature winding continuity test

Check for continuity across the commutator segment.

If there is no continuity, the armature coil is open and must be replaced.



060E100037


#### Commutator run-out test

Use a dial indicator and a V-block to measure the commutator runout.

If the measure value exceeds the limit, the commutator must be replaced.

Commutator run-out mm (in.)

Standard	Limit
0.02 (0.0008)	0.05 (0.002)



060E100020


**Commutator outside diameter measurement**

Use a vernier caliper to measure the commutator outside diameter.

If the measured value exceeds the limit, the armature must be replaced.

Commutator outside diameter mm (in.)

Standard	Limit
43.0 (1.7)	42.0 (1.65)



060EY00016




**Segment mica depth measurement**

Use a depth gauge to measure the segment mica depth.

If the measured value exceeds the limit, the segment mica must be undercut.

Segment mica depth mm (in.)

Standard	Limit
0.7 - 0.9 (0.028 - 0.035)	0.2 (0.008)




060E100018



**Bearing inspection**

Visually inspect the bearing.

If the bearing is worn or damaged, it must be replaced.



060EY00017

**YOKE**

**Field winding ground test**

Use a circuit tester to check the field winding ground.


1. Touch one probe to the brush field winding end.
2. Touch the other probe to the bare surface of the yoke body.

There should be no continuity.

If there is continuity, the field windings are grounded.

Repair or replace the field windings.





060EY00016


**Field winding continuity test**

Use a circuit tester to check the field winding continuity.

1. Touch one probe to the field winding lead wire.
2. Touch the other probe to the brush.

There should be continuity.

If there is no continuity, the field windings are open. Repair or replace the field windings.



060E100038

**BRUSH AND BRUSH HOLDER**

**Brush length measurement**

Measure the brush length to check for wear.


If the measured value exceeds the limit, the brush and/or the yoke must be replaced.

Brush length (H) mm (in.)

Standard	Limit
20.0 (0.79)	13.0 (0.51)

**Brush spring inspection**

Visually check the brush spring for weakness and rusting. Replace the brush spring if it is weak or rusted.



060E100079


**Brush holder insulation test**

Use a circuit tester to check the brush holder insulation.

1. Touch one probe to the field winding lead wire.
2. Touch the other probe to the brush.

There should be continuity.

If there is continuity, the brush holder must be repaired or replaced.



060E100080


**PINION CLUTCH**

**Pinion inspection**

Use your hand to turn the pinion in the direction of starter motor rotation. The pinion should turn freely.

Try to turn the pinion in the opposite direction. The pinion should lock.

REASSEMBLY



060E100028



**Reassembly sequence**

- |                               |                               |
|-------------------------------|-------------------------------|
| 1. Magnetic switch body       | 10. Screw                     |
| ▲2. Compression return spring | 11. Armature                  |
| ▲3. Clutch roller             | ▲12. Brushes and brush holder |
| ▲4. Retainer                  | ▲13. Yoke                     |
| 5. Idler gear                 | 14. Starter seal              |
| 6. Starter pinion             | ▲15. End frame                |
| 7. Steel ball                 | ▲16. Through bolt             |
| 8. Pinion clutch              | 17. Connecting lead wire      |
| 9. Starter housing            | 18. Hexagon nut               |



## IMPORTANT OPERATIONS



### 2. Compression return spring


Apply a coat of engine oil to the compression return spring.



### 3. Clutch roller

### 4. Retainer


Apply a coat of engine oil to the clutch roller and the retainer.



060E100029

## 12. Brushes and brush holder


- 1) Install the negative brush (1) on the brush holder side to the brush holder negative hole (2).  
The brush holder negative hole is not insulated.
- 2) Install the positive brush (3) on the yoke side to the brush holder positive hole (4).  
The brush holder positive hole is separated from the plate with the insulator (5).
- 3) Check that the positive brush lead wires are not grounded.
- 4) Install the brush holder to the yoke.  
Take care not to damage the brush holder or the yoke.  
Do not spill oil on the brush holder or the yoke.



060E10039

**13. Yoke**

- 1) Install the yoke to the magnetic switch.  
The yoke must engage the notch on the magnetic switch.
- 2) Securely set the rubber boot to the magnetic switch C-terminal.



060E10040

**15. End frame**

- Install the end frame to the yoke.  
The end frame tab engage the yoke lead wire grommet.



**16. Through bolt**


Tighten the through bolt to the specified torque.

Through bolt torque kg·m (lb·ft/N·m)

$1.0 \pm 0.2$ (7.1 ± 1.4 / 9.8 ± 2.0)
---------------------------------------

## ALTERNATOR

### GENERAL DESCRIPTION



060EY00002

#### Legend

- |                  |                          |
|------------------|--------------------------|
| (1) Rear bracket | (6) Rotor                |
| (2) IC regulator | (7) Bearing              |
| (3) Bearing      | (8) Pulley               |
| (4) Rectifier    | (9) Front bracket        |
| (5) Stator       | (10) Field coil assembly |

The engine uses a brushless alternator. Main alternator components are the rotor, the stator, the rectifier, the front and rear brackets, the IC regulator, the bearings, and the pulley. Moving parts include the rotor and the pulley. The field coil is installed to the rear bracket. 6 main diodes (3 positive and 3 negative) in conjunction with 2 sub-diodes provide 3-phase rectification. The diodes are installed to the stator coil. An additional 3 diodes (diode trio) are used to provide field current.

The alternator has 3 terminals.

- a. Terminal B: DC power output
- b. Terminal L: Exciting current input
- c. Terminal R: Exciting current input


Terminal R is active only until the alternator begins to generate electricity.

Terminal L also serves as a voltage output terminal. When the voltage across terminal L is equal to the battery voltage, the indicator lamp (no charging) turns off.

Sealed bearings requiring no lubrication are used throughout the alternator.

The IC regulator is a solid-state device and is serviced as a unit. It cannot be disassembled.

**MITSUBISHI IDENTIFICATION PLATE**



- A: Isuzu part number
- B: Manufacturer's abbreviated name
- C: System voltage output
- D: Manufacturer's lot No.
- E: Bar code

**IDENTIFICATION**

The alternator identification plate is attached to the alternator rear bracket. The ISUZU part number, the manufacturer's code number, and other important information are stamped on the plate.


Refer to the identification plate together with the "Main Data and Specifications" Tables and accompanying charts in this Manual when requesting service assistance from a qualified electrical repair shop.

If you are unable to locate the data applicable to your engine, please contact ISUZU MOTORS LIMITED through your machine supplier.


**MAIN DATA AND SPECIFICATIONS**

Isuzu Part No.	181200-6031
Manufacturer's code No. (MITSUBISHI)	A004T06285
Rated voltage (V)	24
Rated output (A)	50
Rated speed (min <sup>-1</sup> )	5000
Rated output (Amp./Volt/min <sup>-1</sup> )	50/27/5000
No-load output at 0 Amp. (Volt/min <sup>-1</sup> )	24/900
Direction of rotation as viewed from pulley side	Clockwise
Ground polarity	(-)
Pulley diameter mm (in.)	80 (3.15)
Coil resistance at 20°C	
Field coil (Ω)	4.5 – 5.2

**CHARGING CIRCUIT**




**ALTERNATOR OUTPUT PERFORMANCE**



066E10006

DISASSEMBLY




060E100041

- (1) IC regulator
- (2) Terminal stud
- (3) Rectifier assembly

- (4) Nut
- (5) Terminal B
- (6) Tube






1. Scratch setting marks between the front and rear brackets and the alternator body (2 locations). This will ensure installation to its original position.
2. Remove the 4 through bolts.
3. Use the blade of a screwdriver to pry the front bracket and the stator apart.
4. Carefully separate the front bracket, pulley, and rotor from the stator and rear bracket.

**Note:**

- Do not push the screwdriver blade too deeply into the stator. Coil damage will result.
- A vise may be used to secure the rotor. Be sure to clamp the vise at points A (see illustration below). Do not clamp the vise at points B. Damage to the rotor will result.



5. Remove the 2 screws (A) attaching the coil terminal plate to the IC regulator.
6. Hold the coil assembly in your hand. Be careful not to damage the terminal plate.
7. Remove the 3 screws (B) and the coil assembly.
8. Remove the clame.

**Note:**

**It is very important that Steps 5, 6 and 7 be performed in that order. If Step 6 is performed before Step 5, terminal damage will result.**

9. Remove the cap and nut from the rectifier terminal stud.

**Note:**

**The tube will remain in the rear bracket. Take care not to lose it.**

10. Remove the rectifier retaining screw and the 2 IC regulator retaining screws.
11. Remove the stator and rectifier assembly (as a single unit) from the rear bracket.
12. Remove the IC regulator.
13. Unsolder the 4 stator coil leads from the rectifier terminals.
14. Remove the stator from the rectifier.

**Note:**

**High temperature solder with a melting point of 230°C connects the stator coil leads to the rectifier. Use a 180~280 watt soldering iron to free the leads as quickly as possible. Do not apply the soldering iron for more than 5 seconds. Diode damage will result.**

### BEARING REMOVAL

**Note:**

**Bearings are not normally removed. If they are removed, they must be replaced with new ones.**


- **Front bracket bearing**

Remove the 4 retainer screws. Press out the bearing with a suitable tool.


- **Rotor bearing**

Use an ordinary bearing puller.


## INSPECTION AND REPAIR



069EY00007



069EY00008



069EY00005

### Stator

1. Check the stator for damage, loose connections, and discolored windings.
2. Use a circuit tester to check for continuity between each pair of stator coil leads (1). Replace the stator if there is no continuity.
3. Use a circuit tester to check for continuity between each of the stator coil leads (1) and the stator core (2). Replace the stator if there is no continuity.

### Rotor

1. Turn the rotor. Listen for bearing noise (a scraping sound). Feel for rough rotation. Replace the rotor if either of these conditions is present.
2. Check for grease leakage. If leakage is minimal, wipe it away. If leakage is excessive, replace the rotor.

### Note:


**It is recommended that inspection be made with the bearing fitted to the rotor shaft.**

### Coil

Use an ohmmeter to measure the coil resistance between both terminals (1) and the terminal plate (2). Replace the coil assembly if the resistance is outside the specifications.

Coil resistance at 20°C

4.5 – 5.2 ohms
----------------



### Rectifier

- (1) Positive diode
- (2) Diode terminals
- (3) A part of negative diode

1. Use a circuit tester to test for continuity between each diode terminal (2) and the positive heat sink. Test in both directions. If there is continuity and/or an open circuit in both directions, the rectifier must be replaced.
2. Use a circuit tester to test for continuity between each diode terminal (2) and the negative heat sink. Test in both directions. If there is continuity and/or an open circuit in both directions, the rectifier must be replaced.
3. Check the diode trio for continuity in both directions. If there is continuity and/or an open circuit in both directions, the rectifier must be replaced.

### Front bracket

Turn the bracket. Listen for bearing noise (a scraping sound). Feel for rough rotation. Replace the bracket if either of these conditions is present.

Check for grease leakage. If leakage is minimal, wipe it away. If leakage is excessive, replace the bracket.

### Regulator

The regulator cannot be checked in the absence of the other components. Check regulator operation after alternator reassembly.

## REASSEMBLY

Follow the disassembly steps in the reverse order.

Note the following precautions.

- No lubrication is required. Bearings are prelubricated.
- Wipe away any grease leakage from the bearing area.
- Use high-temperature solder (melting point of 230°C).
- Use a 180 – 280 watt soldering iron to solder the leads as quickly as possible. Do not apply the soldering iron for more than 5 seconds. Diode damage will result.
- Bracket, rotor, and stator reassembly is difficult because of the tight fit of the components. To make reassembly easier, heat the area around the rear bracket bearing box to approximately 55°C.
- Check that the rotor turns smoothly after alternator reassembly.

### Tightening torques

**Pulley fixing nut: 147 N·m (15 kgm/108 lbft)**

**Through bolts: 5.1 N·m (0.52 kgm/3.8 lbft)**

**Bearing retainer screws: 3.6 N·m (0.37 kgm/2.7 lbft)**

**Coil retaining screws: 3.6 N·m (0.37 kgm/2.7 lbft)**

**Rectifier retaining screws: 3.6 N·m (0.37 kgm/2.7 lbft)**

**Regulator retaining screws: 3.4 N·m (0.35 kgm/2.5 lbft)**


**Nuts for stud bolts: 8.8 N·m (0.9 kgm/6.5 lbft)**

### Bench testing

Perform bench tests on the reassembled alternator.

#### Voltage regulation

1. Make connections as shown in the illustration on the following page. Use an ammeter with a scale of 0 – 100 amperes and voltmeter with a scale of 0 – 30 volts.
2. Close switch 1 and open switch 2. The lamp should light.  
If the lamp does not light, check the voltage at terminal-L.  
If the voltage is nearly equal to battery voltage (24V), check the alternator.  
If the voltage is low, check for an open lamp and related circuitry.
3. Slowly increase alternator speed.  
The lamp should turn off as alternator speed approaches 1,300 min<sup>-1</sup>.
4. Check the voltage as alternator speed increases.  
If the voltage fluctuates wildly during alternator speed increase and rises above 30 volts, the IC regulator is probably defective.  
If the voltage does not exceed battery voltage (24V), the alternator is defective (no generation of electricity). Check alternator components again.



5. Increase alternator speed to approximately 5000  $\text{min}^{-1}$ .
6. Note the ammeter reading.  
If the reading is 5 amperes or less, note the voltmeter reading (be sure that alternator speed remains constant). This is the regulated voltage.  
If the reading is more than 5 amperes, continue to operate the ammeter at 5000  $\text{min}^{-1}$  until the reading falls to 5 amperes or less.  
If the reading does not fall, replace the battery.  
If the reading still does not fall, the alternator is defective and must be repaired or replaced.

**Current output**

1. Operate the alternator at minimum speed.
2. Close switch 1. Check that the lamp lights.
3. Set the load resistor to its maximum resistance (minimum current).
4. Close switch 2.
5. Increase the alternator speed to a constant 5,000  $\text{min}^{-1}$ .
6. Adjust the load resistor for maximum current output.
7. Allow the alternator to run for 15 minutes. Output should increase as alternator temperature increases.
8. Once again, adjust the load resistor for maximum current output.  
The maximum current output must equal the specified value. If it does not, the alternator must be rechecked.

Alternator output

50 amp/27 volt/5,000 $\text{min}^{-1}$
--

**TROUBLESHOOTING**

Condition	Possible Cause	Correction
No output	Bad terminal connection	Repair
	Open or shorted circuit	Repair
	Open field coil	Replace
	Defective diode	Replace
	Defective IC regulator	Replace
Low output	Loose terminal connection	Tighten
	Loose cooling fan belt	Adjust belt tension
	Defective diode	Replace
	Shorted field coil	Replace
	Shorted stator coil	Replace
	Defective regulator	Replace
	Defective battery	Replace
	Poor terminal contact	Repair
Overcharging	Defective regulator	Replace
	Defective battery	Replace
Unstable current	Poor terminal contact	Repair
	Loose cooling fan belt	Adjust belt tension
	Short field coil	Replace
	Shorted stator coil	Replace
	Intermittent contact in wiring	Replace
	Poor terminal contact	Repair
	Defective regulator	Replace
Abnormal noise	Improper alternator installation	Correct
	Defective bearing	Replace
	Contact between the rotor core and stator core	Replace the rotor core and/or stator core
	Defective diode	Replace
	Shorted stator coil	Replace



**CHAPTER 11**  
**TROUBLESHOOTING**  
**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
<b>Starting difficulties</b> .....	<b>198</b>
<b>1. Starter doesn't turn</b> .....	<b>198</b>
<b>2. Starter turns, but engine doesn't turn over</b> .....	<b>199</b>
<b>3. The engine turns and fuel reaches the injection pump, but it doesn't start</b> .....	<b>200</b>
<b>4. The engine turns, but doesn't turn</b> .....	<b>200</b>
<b>5. Fuel isn't supplied to the injection pump</b> .....	<b>201</b>
<b>Unstable idling rpm</b> .....	<b>202</b>
<b>Lack of power</b> .....	<b>204</b>
<b>Excessive fuel consumption</b> .....	<b>207</b>
<b>Excessive oil consumption</b> .....	<b>209</b>
<b>Overheating</b> .....	<b>210</b>
<b>White smoke in exhaust</b> .....	<b>211</b>
<b>Black smoke in exhaust</b> .....	<b>212</b>
<b>Low oil pressure</b> .....	<b>213</b>
<b>Engine sounds</b> .....	<b>215</b>
<b>1. Knocking</b> .....	<b>215</b>
<b>2. Gas leak sounds</b> .....	<b>215</b>
<b>3. Continuing sounds</b> .....	<b>216</b>
<b>4. Clanking sounds</b> .....	<b>217</b>

**Comments:**


This chapter has been prepared to provide quick guidance for responding to common engine problems. Each troubleshooting column is explained in the following topical order, from left to right:

(1) Inspection items      (2) Possible Causes      (3) Remedies




## STARTING DIFFICULTIES


### 1. Starter doesn't turn




## 2. Starter turns, but engine doesn't turn




**3. The engine turns and fuel reaches the injection pump, but it doesn't start**




**4. The engine turns, but doesn't start**



### 5. Fuel isn't supplied to the injection pump



## UNSTABLE IDLING RPM




Continued on next page

Inspection Item


Possible Causes

Remedies

Continued from previous page



## LACK OF POWER



Continued to next page


Inspection Item

Possible Causes

Remedies

Continued from previous page


OK ↓




Continued to next page



## Troubleshooting



## EXCESSIVE FUEL CONSUMPTION




Continued on next page

## Troubleshooting


---

Inspection Item	Possible Causes	Remedies
Continued from previous page		
OK ↓ Turbocharger	NG → Faulty turbocharger	Replace
OK ↓ Valve clearance	NG → Improper adjustment	Readjust
OK ↓ Cylinder compression pressure	NG → Gasket leak, liner wear, ring sticking or damaged; or improper valve contact	Replace appropriate parts
OK ↓ Valve spring	NG → Valve tension too low or broken	Replace


## EXCESSIVE OIL CONSUMPTION




## OVERHEATING




## WHITE SMOKE IN EXHAUST



## BLACK SMOKE IN EXHAUST




## LOW OIL PRESSURE





## Troubleshooting

---



## ENGINE SOUNDS


### 1. Knocking

Inspection Item


Possible Causes

Remedies

Before beginning inspections and repairs, be sure the engine is fully warmed up



### 2. Gas leak sounds



Continued on next page


## Troubleshooting

Inspection Item	Possible Causes	Remedies
Continued from previous page		
OK ↓ Exhaust manifold	NG → Loose installation of manifold or glow plugs	Retighten
OK ↓ Head gasket	NG → Faulty	Replace

### 3. Continuous sounds

Fan belt	NG → Loose or damaged	Readjust belt tension, or replace
OK ↓ Cooling fan	NG → Loose fan installation	Tighten
OK ↓ Water pump bearing	NG → Wear or damage	Replace
OK ↓ Alternator	NG → Faulty alternator	Repair or replace appropriate parts
OK ↓ Valve clearance	NG → Improper valve clearance	Readjust

#### 4. Clanking sounds











**MEMO**




A series of horizontal dotted lines for writing.

**CHAPTER 12**  
**SPECIAL TOOLS**  
**CONTENTS**

<b>ITEM</b>	<b>PAGE</b>
<b>Special Tools List .....</b>	<b>220</b>

**SPECIAL TOOLS LIST**

Item No.	Illustration	Part Number	Part Name	Page
1		1-85235-007-0	Valve spring compressor	50
2		9-8523-1202-2	Valve guide remover	57
3	 <small>901LX053</small>	1-85231-016-0	Cylinder liner remover	67
4		1-85221-073-0	Cylinder liner installer	69
5		1-85221-072-0	Crankshaft gear installer	82
6		1-85220-052-0	Oil seal remover	83 84
7		1-85220-057-0	Oil seal installer	83 84
8	 <small>901HY00127</small>	5-85317-001-0	Compression gauge adapter	34

Item No.	Illustration	Part Number	Part Name	Page
9		1-85221-029-0	Piston ring replacer	53 93
10	 <p data-bbox="427 696 491 707">901HY00148</p>	1-85221-075-0	Drive gear installer	82
11		1-85210-051-0	Crank gear remover	82



**MEMO**

Dotted lines for writing


---


## CHAPTER 13

# REPAIR STANDARDS

### General Rules

1. These tables provide standards relating the repair of the following diesel engine;  
Model AA-6SD1T (turbocharged)
2. These Repair Standards are based on inspection items, together with dimensions, assembly standards, limit values, and repair procedures.
  - (1) Nominal dimensions are the standard production values.
  - (2) Assembly standards considered to be the values used as objectives during the assembly procedures which follow repairs; as a result, they may be somewhat at variance with the assembly dimensions of a new engine.
  - (3) Limit values refer to the measured values resulting from wear, etc., beyond which a part must not be used. If a measured value falls beyond the limit value, the part involved must be repaired or replaced.
  - (4) "Repair Procedures" indicates normal repair methods.
  - (5) Unless otherwise stated, the unit of numerical values in tables should be taken to refer to millimeters (mm).
3. Explanation of Terms Used in Tables
  - (1) The dimension of "wear" refers to the difference between the dimensions of a part which is not worn (or the "nominal dimension" of a part without wear) and the dimension of the part suffering from the most wear (the dimension of the worn part).
  - (2) Uneven wear means the difference between the maximum and minimum wear values.
4. When repairs are requested on the overall engine, first perform bench tests to determine what parts require repairs, then perform the minimum disassembly and repairs required to correct the problems. When repairs on a specific engine part are requested, repairs to be made in reference to the relevant items in accordance with the repair standards listed in this manual.

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments	
Time for engine disassembly and repair		Cylinder compression pressure MPa (kgf/cm <sup>2</sup> )	2.84 (29) or more		2.06 (21) or less	Disassemble and repair engine	Water temperature 70 – 85°C, engine speed 220 rpm (varies depending on altitude)	
		Fuel consumption ℓ/h	100%		140%			
		Lubricating oil consumption cc/h	100%		200%			
		Wear on liner bore Measured at A–A						New engine performance is assumed 100%
Engine Body	Cylinder Block		Dia. 120		Dia 120.3	Upper step wear must be repaired, or replaced with standard dimension liner	(Ref) Cylinder & liner interference 0.011 – 0.029	
		Liner projection		0.106 – 0.134			Some projection must be present	Difference in liner projection between neighboring cylinders not to exceed 0.02
		Cylinder block upper face warpage		0.05 or less	0.2 or more	Not repairable; must be replaced		
		Pressure test: 3 minutes kPa (kgf/cm <sup>2</sup> )		490 (5)		Leaks require repair or replacement		

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments	
Engine Body	Cylinder Head	Valve seat depression: B (both inlet and exhaust)  (Insert) (Cylinder head) (Valve) Lower surface of cylinder head 45° D14A1/00002		Inlet side 0.48	1.48 or more	Replace insert	Valve seat angle: $\alpha$ Inlet side 30° Exhaust side 45°	
				Exhaust side 1.60	2.60 or more			
			Contact width with valve seat: A		Inlet side 2.7 Exhaust side 2.4	3.5 or more 3.2 or more	Repair with valve seat cutter	After repair, be sure to lap contact surfaces
			Warpage and flatness of cylinder head lower face (mounting surface)		0.05 or less	0.2 or more	Cannot be repaired: must replace cylinder head	
			Warpage of manifold mounting surface		0.05 or less	0.4 or more	repair	
			Water-pressure test, 3 minutes kPa (kgf/cm <sup>2</sup> )		490 (5)		Leaks require repair or replacement	
			Cylinder head bolts tightening torque (angular tightening method) N·m (kgf·m)		M10 bolts 31 – 45 (3.2 – 4.6)		<ul style="list-style-type: none"> <li>Clean bolt mounting surfaces and apply molybdenum disulfide grease.</li> <li>Never tighten again after using angular tightening method.</li> <li>Reuse bolts max. 2 times</li> </ul>	Tighten M14 bolts to 98.0 N·m (10 kgf·m) then to 147 N·m (15 kgf·m). Next, use angular method to additionally tighten to 30°–60° rotation.


Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments		
Main Operating Parts	Pistons	Clearance with cylinder: grade position from upper face 98 mm		Clearance with major axis 0.131 – 0.175					
		Piston pin and piston pin hole clearance		0.004 – 0.017	0.05 or more	Replace piston or piston pin			
		Pin wear	Dia. 43		Dia. 42.98 or less	Replace piston pin			
	Cylinder Head	Piston Ring Gap	No. 1 compression ring		0.35 – 0.50	1.0 or more	Replace rings when performing engine disassembly and repair	Gauge inner standard diameter 120	
			No. 2, 3 compression ring		0.35 – 0.50	0.8 or more			
			Oil ring		0.25 – 0.45	14.7 or less (1.5)			
		Tension N (kgf)	No. 1 compression ring		24.1 – 31.8 (2.46 – 3.24)	9.8 (1.0) or below	Replace	Measure with ring compressed to standard ring gap.	
			No. 2 compression ring		15.4 – 21.3 (1.57 – 2.17)	11.8 (1.2) or below			
			No. 3 compression ring		17.7 – 24.5 (1.80 – 2.50)	37.3 (3.8) or below			
		Ring gap orientation	Oil ring	No. 1 compression ring		53.9 – 73.5 (5.5 – 7.5)	0.20 or more	Replace	Measure with expander attached
				No. 2 compression ring		0.105 – 0.14	0.20 or more		
				No. 3 compression ring		0.105 – 0.14	0.20 or more		
				Oil ring		0.085 – 0.120	0.15 or more		
						At 120° intervals			

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments	
Main Operating Parts	Crankshaft	Uneven wear on journal and pins	Dia. 90 Dia. 80	0.001	0.05 or more	Replace	Do not attempt to grind: always replace with new parts	
		Journal wear	Dia. 90		Dia. 89.909 or less	Replace		
		Pin wear	Dia. 80		Dia. 79.894 or less	Replace		
		Journal and pin finish precision (taper and ellipse)		Ellipse and taper 0.007				
		Journal and bearing spread				96 or less	Use those with projection and proper arc; take care with back side fit	Load 9807 [1000] N[Kgf] Projection 0.03 – 0.07 mm
		Clearance between journal and bearing		0.045 – 0.11		0.16 or more	Replace bearing	
		Journal bearing undersize					Undersize bearings cannot be used	
		Crankshaft end play		0.15 – 0.33		0.4 or more	Replace thrust bearings	Measure at crankshaft's No. 4 bearing thrust surface
		Crankshaft runout		0.08 or less		0.15 or more	Replace	
		Ring gear					Perform lapping on gears with burrs; in cases of severe damage, replace.	
		Crankshaft balance (g-cm)		36 or less			Check dynamic balance	(Ref. value) At ends of journal
		Lower crankcase bolts tightening torque (angular tightening method)  N·m (kgf-m)		M14 bolts 98 (10) ↓ 147 (15) ↓ 30 — 60° M10 bolts 38 (3.9)		0.15 or more	Apply molybdenum disulfide grease to threads and seating areas of bolts before tightening	Do not catch foreign matter in bolts
		Crankshaft rear oil seal wear					In case of oil leak, replace oil seal	Check for oil seal collapse (liberally apply oil when installing)




**Repair Standards**

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments
Main Operating Parts	Connecting Rods	Connecting rod bearing runout			85 or less	Use those with projection and proper arc; take care work back side fit	Load 9807 (1000 N (Kgf) Projection 0.03 – 0.07 mm
		Clearance between connecting rod bearing and crankpin		0.04 – 0.106	0.16 or more	Replace bearing or crankshaft	Take special care with crankpin precision
		Contact between connecting rod bearing and crankpin				Replace parts with poor contact or abrasions	
		Clearance between smallest bushing and piston pin		0.12 – 0.027	0.10 or more	Replace bushing or pin	Sufficient gap to allow smooth rotation when holding big end
		Connecting rod bearing undersize	Dia. 80				Crank must not be ground (no undersizes available)
		Connecting rod and crankpin end play		0.17 – 0.28	0.35 or more	Replace connecting rod	
		Center distance between big end and small end (mm)	223.5				Reference value
		Big end to small end hole twist (per 100 mm)		0.03 or less	0.1 or more	Repair or replace	
		Big end to small end hole parallelism (per 100 mm)		0.03 or less	0.1 or more	Repair or replace	
		Piston weight difference after assembly g		20 or less		Repair or replace	
		Bearing cap bolt tightening torque (angular tightening method) N·m (kgf·m)		39 (4.0) alternately (One side) (Other side) 60° ↗ ↘ 120° 60°		After tightening to 39 N·m (4.0 kgf·m), use angular tightening to tighten alternately first side 90°, other side 120°–150°, first side 30°–90°.	

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments
Main Operating Parts	Camshaft	Journal uneven wear				Replace camshaft	
		Clearance between journal and bearing		0.06 – 0.11	0.16 or more	Replace camshaft or bearing	
		Journal wear	Dia. 40	Dia. 39.915 – 39.940	Dia. 39.89 or less	Replace camshaft	
		Cam height: A – B	5.92		5.56 or less	Replace camshaft	Minor step wear on cams can be repaired
		Camshaft runout		0.05	0.10 or more	Replace camshaft	Measure with dial gauge at No. 3 or No. 4 journal, runout during one rotation.
		Camshaft play (front-back direction)		0.055 – 0.205	0.4 or more		






Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments		
Valve System	Valves	Inlet valve stem wear	Dia. 10		Dia. 9.92	Replace valve and valve guide together	Measure valve stem at three positions		
		Exhaust valve stem wear	Dia. 10		Dia. 9.90				
		Clearance between inlet valve stem and valve guide		0.040 – 0.077	0.15 or more	Replace valve and valve guide together			
		Clearance between exhaust valve stem and guide		0.065 – 0.102	0.20 or more				
		Interference between valve guide and cylinder head		0.024			Apply oil to valve guide and press in		
		Valve thickness		Inlet	2.50		2.00 or less	Replace valve and valve guide together	
				Exhaust	2.35		1.85 or less		
		Height of valve guide above cylinder head		22				Reference value	
		Valve stem oil seal lip		Dia. 9.5			Dia. 9.8 or more	Replace oil seal	Don't damage lip.
		Valve spring	Tension N (kgf) (When compressed to installed length)	Inlet	Inner [11.4]		Inner [10.2 or less]	Replace oil seal	
					Outer [29.8]		Outer [26.8 or less]		
			Exhaust	Inner [29.0]		Inner [26.1 or less]			
				Outer [51.0]		Outer [45.9 or less]			
			Free height mm	Inlet	Inner [62.5]		Inner [60.5 or less]		
					Outer [59.3]		Outer [57.3 or less]		
Exhaust	Inner [69.2]		Inner [67.2 or less]						
	Outer [80.7]		Outer [78.7 or less]						
Inclination mm					Inner 3.0 or more				
					Outer 3.5 or more				

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments
Valve System	Valves	Valve clearance (inlet & exhaust) (cold)		0.4		Adjust	
		Clearance between rocker arm shaft and bushing		0.01 – 0.05	0.2 or more	Replace bushing or shaft	
		Rocker arm shaft wear	Dia. 19		Dia. 18.85 or less	Replace	
Intake System	Air cleaner	Air cleaner element condition					Special order item from manufacturer

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments	
Lubricating System	Oil pressure	Lubricating oil pressure kPa (kg/cm <sup>2</sup> )						
		Clearance between pump body inner wall and gear teeth mm		0.10 – 0.196	0.15	Replace bushing, gear or body		
	Oil Pump and Relief valve	Pumping rate 2486 rpm, SAE #30, pumping pressure $7.8 \times 10^2(8)$ kPa (kgf/cm <sup>2</sup> ) / cm <sup>2</sup> , oil temp. 80°C		90.0				
		End gap between pump cover and gear		0.040 – 0.093	0.15	Replace gear or cover		
		Clearance between drive shaft and pump body		0.032 – 0.070	0.15			
		Clearance between drive shaft and bushing		0.045 – 0.078	0.15	Replace bushing		
		Diameter of drive shaft	Dia. 16		Dia 15.9 or less	Replace shaft		
	Oil filter	Initial operating pressure of relief valve kPa (kgf/cm <sup>2</sup> )	Oil gallery		539 (5.5)			Reference value
			Oil pump		1.08x10 <sup>3</sup> (11.0)			
		Clogging and damage to oil filter				Replace	Replace cartridge every 500 hours of operation	
		Initial operating pressure of main oil filter relief valve kPa (kgf/cm <sup>2</sup> )		196 (2.0)				

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments	
Cooling System	Water pump	Water pump ball bearing chatter (radial direction)		0.008 – 0.010	0.2	Replae	#6305 (2) #6205 (1)	
		Pumping rate ℓ/min ( pumping speed 2000 rpm, water temp 30°C Total head 8.6 m or more )		265				
		Clearance between pump impeller and pump body mm		0.5			Repair or replace if impeller and pump body are touching	
		Fan belt deflection mm Press with finger  033BE100007		About 7 – 9			Adjust	(Reference) 10 kg/each
		Initial thermostat operating temperature (at sea level)		74.5 – 78.5°C				Replace thermostat if operation is incorrect.
		Thermostat full-open temperature (at sea level)		90°C			Temperature at which thermostat lift reaches 13 mm or more.	
		Fan center and bearing shaft interference		0.07 – 0.11			Press-in load 600 kg or less	Maximum 2 disassemblies. From 3rd time, replace shaft assembly.
		Bearing shaft and impeller interference		0.020 – 0.060				
		Pulley and fan center clearance		0.14 or less				

**Repair Standards**

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments
Fuel System	Piping, etc.	Clogged, cracked, loose fuel pipes, injection pipes, nozzle holders; defective seals.				Repair or replace	
		Fuel filter element clogging or damage				Replace	Cartridge type
	Fuel feed pump	Pumping performance ( with hand primer pump, speed 60 – 100 times/minutes 1m head, pipe internal diameter x length (8mm x 2m) )		Pumped up within 25 strokes or less	120 times or more	Repair or replace	
		Pumping capacity (cc) Pump speed 1000 rpm. ( 15 seconds duration, Inlet head : 1m Outlet head : 0.3m )		530 or more	400 or less	Repair or replace	
	Injection pump	Air tightness 196 kPa (2.0 kgf/cm <sup>2</sup> )		Bubbles from pushrod less than rice-grain size, not to exceed 30 cc/min		Other leaks require or replacement	
		Delivery valve Delivery valve wear				Inspect for damage to valve's piston and seat; replace in case of severe vertical cracks on piston or impact scars on seat with loss of finish gloss. Immerse delivery valve in clean diesel fuel, then lightly press lower part of valve seat with finger and release; replace assembly if valve does not return to original state when finger is released.	

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments
Fuel system	Injection Nozzle	Technology Needle valve seat: 7.84MPa (80 kgf/cm <sup>2</sup> )				Repair or replace parts with leaks from seat area	
		Needle valve shaft seat: seconds Impress fuel pressure of 29.4 MPa (300 kgf/cm <sup>2</sup> ) (nozzle starting pressure) and measure time required for pressure to drop from 24.5 MPa (250 kgf/cm <sup>2</sup> ) to 19.6 MPa (200 kgf/cm <sup>2</sup> ).		5.0 or more		Replace	Fuel used: diesel fuel; clay (Redwood); 37 - 40 seconds 120°C
Electrical	Charge/Discharge Indication	Fuel spray and injection Impress fuel pressure of Adjust needs valve opening pressure to 1st stage: 17.7 MPa (180 kg/cm <sup>2</sup> /2570 psi) 2nd stage: 22.1 MPa (225 kg/cm <sup>2</sup> /3200 psi)	① Visually inspect, no relatively large drops scattered. ② No drops scattered to one side. ③ No unevenness of spray from jets.			Replace faulty parts	
		Warning lamp indication				If warning indicator lights when engine is operating at normal speeds, check and repair electrical system.	
	Wiring	Check for looseness, cuts or damaged insulation to wiring.				Repair	
	Alternator 24V, 50A	Performance Rated output current 27 V (5000 rpm)		50A			

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments		
Electrical	Starter 24V, 5.5 kW	Loose mount				Repair			
		Brush height		20	13 or less	Replace			
			Magnetic switch	Series coil resistance value ( $\Omega$ )	0.76 – 0.84 (20°C)				If coil resistance value is severely abnormal, replace switch.
		Shunt coil resistance value ( $\Omega$ )		2.42 – 2.62 (20°C)					
		Commutator	O.D.	Dia. 43	Dia. 42	Replace armature			
			Undercut depth	0.5 – 0.8	0.2	Repair			
		Performance	Unloaded characteristics (24V, 120A or less)		4100 rpm		Smooth pinion operation without noise		
		Preheater	Control register, glow plug				Replace if cut wiring or shorts are found		
		Battery	Battery terminals						Special order from original manufacturer; manufacturer's specs.
			Plates, separator plates, container, etc.						
	Electrolyte turbidity								

Major Category	Name of Part	Inspection Item	Nominal Dimension	Assembly Standard Value	Limit	Repair Procedure	Comments	
Electrical	Battery	Electrolyte specific gravity (at recharging, 20°C)					Special order from original manufacturer	
		Capacity (20 hours)						
		Electrode voltage						
		Electrolyte surface height						
Final Inspection		Engine run-in operation				30 minutes or more		
		Cylinder compression pressure MPa (kgf/cm <sup>2</sup> ) (water temp. 70 – 85°C, about 220 rpm)		2.84 (29)	2.6 (21) or less	Inspect	Warm engine	
		Difference in compression between cylinders kPa (kgf/cm <sup>2</sup> ) (water temp. 70 – 85°C, about 220 rpm)			196 (2 or more)	Inspect	Warm engine	
		Lubricating oil pressure kPa (kgf/cm <sup>2</sup> )		539 (5.5)	196 or less (2.0)	Adjust		
		Output check		85% or more				When new engine output is 100%
		Fuel consumption check		110% or less				



**MEMO**

Lined area for writing a memo, consisting of horizontal dotted lines.

Copyright reserved for this manual may not be reproduced or copied, in whole or in part, without the written consent of ISUZU MOTORS LIMITED.

---

**WORKSHOP MANUAL  
DIESEL ENGINE**

**MODEL AA-6SD1T**

**IDE-2392**

**Issued by**

**ISUZU MOTORS LIMITED**  
POWERTRAIN SERVICE & PARTS DEPT.  
6-26-1, Minami-oi, Shinagawa-ku, Tokyo, 140-8722, Japan  
TEL 03-5471-1111

---

First edition Jun., 2001

0106-01K

**ISUZU**