

SHOP MANUAL

KOMATSU

GD700-4 SERIES

| MACHINE MODEL | SERIAL No. |
|-----------------|---------------------|
| GD705R-4 | 16001 and up |
| GD705A-4 | 21001 and up |

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- GD705R-4, GD705A-4 mount the 6D125, S6D125 engine.
For details of the engine, see the 6D125 Series Engine Shop Manual.

CONTENTS

| | No. of page |
|-----------------------------------|-------------|
| 01 GENERAL | 01-1 |
| 10 ENGINE | |
| 11 STRUCTURE AND FUNCTION | 11-1 |
| 12 TESTING AND ADJUSTING | 12-1 |
| 13 DISASSEMBLY AND ASSEMBLY | 13-1 |
| 20 POWER TRAIN | |
| 21 STRUCTURE AND FUNCTION | 21-1 |
| 22 TESTING AND ADJUSTING | 22-1 |
| 23 DISASSEMBLY AND ASSEMBLY | 23-1 |
| 24 MAINTENANCE STANDARD | 24-1 |
| 40 STEERING SYSTEM | |
| 41 STRUCTURE AND FUNCTION | 41-1 |
| 42 TESTING AND ADJUSTING | 42-1 |
| 43 DISASSEMBLY AND ASSEMBLY | 43-1 |
| 44 MAINTENANCE STANDARD | 44-1 |
| 50 BRAKE SYSTEM | |
| 51 STRUCTURE AND FUNCTION | 51-1 |
| 52 TESTING AND ADJUSTING | 52-1 |
| 53 DISASSEMBLY AND ASSEMBLY | 53-1 |
| 54 MAINTENANCE STANDARD | 54-1 |
| 60 HYDRAULIC SYSTEM | |
| 61 STRUCTURE AND FUNCTION | 61-1 |
| 62 TESTING AND ADJUSTING | 62-1 |
| 63 DISASSEMBLY AND ASSEMBLY | 63-1 |
| 64 MAINTENANCE STANDARD | 64-1 |
| 70 WORK EQUIPMENT | |
| 71 STRUCTURE AND FUNCTION | 71-1 |
| 72 TESTING AND ADJUSTING | 72-1 |
| 73 DISASSEMBLY AND ASSEMBLY | 73-1 |
| 74 MAINTENANCE STANDARD | 74-1 |
| 80 ELECTRICAL SYSTEM | 81-1 |
| 90 OTHERS | |
| 92 INSPECTION TABLE | 92-1 |

LIST OF REVISED PAGES

LIST OF REVISED PAGES

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

| Mark | Indication | Action required |
|------|------------------------|-----------------|
| ○ | Page to be newly added | Add |
| ● | Page to be replaced | Replace |
| () | Page to be deleted | Discard |

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

| Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision |
|------|---------|------------------|------|-------|------------------|------|-------|------------------|------|-------|------------------|------|-------|------------------|
| ● | 00- 1 | ④ | | 01- 9 | ② | | 11- 8 | ② | | 13-20 | ② | | 13-49 | ② |
| | 00- 2 | ② | | 01-10 | ② | | 11- 9 | ② | | 13-22 | ② | | 13-50 | ② |
| ● | 00- 2-1 | ④ | | 01-11 | ② | | 12- 1 | ② | | 13-23 | ② | | 13-51 | ② |
| ● | 00- 2-2 | ④ | | 01-12 | ② | | 12- 2 | ② | | 13-24 | ② | | 13-52 | ② |
| ● | 00- 2-3 | ④ | | 01-13 | ② | | 12- 3 | ② | | 13-25 | ② | | 13-53 | ② |
| ● | 00- 2-4 | ④ | | 01-14 | ② | | 12- 4 | ② | | 13-26 | ② | | 13-54 | ② |
| ● | 00- 2-5 | ④ | | 01-15 | ② | | 12- 5 | ② | | 13-27 | ② | | 13-55 | ② |
| ● | 00- 3 | | | 01-16 | ② | | 12- 6 | ② | | 13-28 | ② | | 13-56 | ② |
| ● | 00- 4 | | | 01-17 | ② | | 12- 7 | ② | | 13-29 | ② | | 13-57 | ② |
| ● | 00- 5 | | | 01-18 | ② | | 12- 8 | ② | | 13-30 | ② | | 13-58 | ② |
| ● | 00- 6 | | | 01-19 | ② | | 13- 1 | ② | | 13-31 | ② | | 13-59 | ② |
| ● | 00- 7 | | | 01-20 | ② | | 13- 2 | ② | | 13-32 | ② | | 13-60 | ② |
| ● | 00- 8 | | | 01-21 | ② | | 13- 3 | ② | | 13-33 | ② | | 13-61 | ② |
| ● | 00- 9 | | | 01-22 | ② | | 13- 4 | ② | | 13-34 | ② | | 13-62 | ② |
| ● | 00-10 | | | 01-23 | ② | | 13- 6 | ② | | 13-35 | ② | | 13-63 | ② |
| ○ | 00-11 | | | 01-24 | ② | | 13- 7 | ② | | 13-36 | ② | | 13-64 | ② |
| ○ | 00-12 | | | 01-25 | ② | | 13- 8 | ② | | 13-37 | ② | | 13-65 | ② |
| ○ | 00-13 | | | 01-26 | ② | | 13- 9 | ② | | 13-38 | ② | | 13-66 | ② |
| ○ | 00-14 | | | 01-27 | ② | | 13-10 | ② | | 13-39 | ② | | 13-67 | ② |
| ○ | 00-15 | | | 01-28 | ② | | 13-11 | ② | | 13-40 | ② | | 13-68 | ② |
| ○ | 00-16 | | | 01-29 | ② | | 13-12 | ② | | 13-41 | ② | | 13-69 | ② |
| | 01- 1 | ② | | 11- 1 | ② | | 13-13 | ② | | 13-42 | ② | | 13-70 | ② |
| | 01- 3 | ② | | 11- 2 | ② | | 13-14 | ② | | 13-43 | ② | | 13-71 | ② |
| | 01- 4 | ② | | 11- 3 | ② | | 13-15 | ② | | 13-44 | ② | | 13-72 | ② |
| | 01- 5 | ② | | 11- 4 | ② | | 13-16 | ② | | 13-45 | ② | | 13-73 | ② |
| | 01- 6 | ② | | 11- 5 | ② | | 13-17 | ② | ● | 13-46 | ④ | | 13-74 | ② |
| | 01- 7 | ② | | 11- 6 | ② | | 13-18 | ② | | 13-47 | ② | | 13-75 | ② |
| | 01- 8 | ② | | 11- 7 | ② | | 13-19 | ② | | 13-48 | ② | | 13-76 | ② |

LIST OF REVISED PAGES

LIST OF REVISED PAGES

| Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision |
|------|-------|------------------|------|-------|------------------|------|-------|------------------|------|-------|------------------|------|--------|------------------|
| | 13-77 | ② | | 21-30 | ② | | 23- 5 | ② | | 23-46 | ② | | 23- 88 | ② |
| | 13-78 | ② | | 21-31 | ② | | 23- 6 | ② | | 23-47 | ② | | 23- 89 | ② |
| | 13-79 | ② | | 21-32 | ② | | 23- 7 | ② | | 23-48 | ② | | 23- 90 | ② |
| | 13-80 | ② | | 21-33 | ② | | 23- 8 | ② | | 23-49 | ② | | 23- 91 | ② |
| | 13-81 | ② | | 21-34 | ② | | 23- 9 | ② | | 23-50 | ② | | 23- 92 | ② |
| | 13-82 | ② | | 21-35 | ② | | 23-10 | ② | | 23-51 | ② | | 23- 93 | ② |
| | 13-83 | ② | | 21-36 | ② | | 23-11 | ② | | 23-52 | ② | | 23- 94 | ② |
| | 13-84 | ② | | 21-37 | ② | | 23-12 | ② | | 23-53 | ② | | 23- 95 | ② |
| | 13-85 | ② | | 21-38 | ② | | 23-13 | ② | | 23-54 | ② | | 23- 96 | ② |
| | 13-86 | ② | | 21-39 | ② | | 23-14 | ② | | 23-55 | ② | | 23- 97 | ② |
| | | | | 21-40 | ② | | 23-15 | ② | | 23-56 | ② | | 23- 98 | ② |
| | 21- 1 | ② | | 21-41 | ② | | 23-16 | ② | | 23-58 | ② | | 23- 99 | ② |
| | 21- 2 | ② | | 21-42 | ② | | 23-17 | ② | | 23-59 | ② | | 23-100 | ② |
| | 21- 3 | ② | | 21-43 | ② | | 23-18 | ② | | 23-60 | ② | | 23-101 | ② |
| | 21- 4 | ② | | 21-44 | ② | | 23-20 | ② | | 23-61 | ② | | 23-102 | ② |
| | 21- 5 | ② | | 21-46 | ② | | 23-21 | ② | | 23-62 | ② | | 23-103 | ② |
| | 21- 6 | ② | | 21-47 | ② | | 23-22 | ② | | 23-63 | ② | | 23-104 | ② |
| | 21- 7 | ② | | 21-48 | ② | | 23-23 | ② | | 23-64 | ② | | 23-106 | ② |
| | 21- 8 | ② | | 21-49 | ② | | 23-24 | ② | | 23-66 | ② | | 23-107 | ② |
| | 21- 9 | ② | | 21-50 | ② | | 23-25 | ② | | 23-67 | ② | | 23-108 | ② |
| | 21-10 | ② | | 21-51 | ② | | 23-26 | ② | | 23-68 | ② | | 23-109 | ② |
| | 21-11 | ② | | 21-52 | ② | | 23-27 | ② | | 23-69 | ② | | 23-110 | ② |
| | 21-12 | ② | | 21-53 | ② | | 23-28 | ② | | 23-70 | ② | | 23-111 | ② |
| | 21-13 | ② | | 21-54 | ② | | 23-29 | ② | | 23-71 | ② | | 23-112 | ② |
| | 21-14 | ② | | 21-55 | ② | | 23-30 | ② | | 23-72 | ② | | 23-113 | ② |
| | 21-15 | ② | | 21-56 | ② | | 23-31 | ② | | 23-73 | ② | | 23-114 | ② |
| | 21-16 | ② | | | | | 23-32 | ② | | 23-74 | ② | | 23-115 | ② |
| | 21-17 | ② | | 22- 1 | ② | | 23-33 | ② | | 23-75 | ② | | 23-116 | ② |
| | 21-18 | ② | | 22- 2 | ② | | 23-34 | ② | | 23-76 | ② | | 23-117 | ② |
| | 21-19 | ② | | 22- 3 | ② | | 23-35 | ② | | 23-77 | ② | | 23-118 | ② |
| | 21-20 | ② | | 22- 4 | ② | | 23-36 | ② | | 23-78 | ② | | 23-119 | ② |
| | 21-21 | ② | | 22- 5 | ② | | 23-37 | ② | | 23-79 | ② | | 23-120 | ② |
| | 21-22 | ② | | 22- 6 | ② | | 23-38 | ② | | 23-80 | ② | | 23-121 | ② |
| | 21-23 | ② | | 22- 7 | ② | | 23-39 | ② | | 23-81 | ② | | 23-122 | ② |
| | 21-24 | ② | | 22- 8 | ② | | 23-40 | ② | | 23-82 | ② | | 23-123 | ② |
| | 21-25 | ② | | | | | 23-41 | ② | | 23-83 | ② | | 23-124 | ② |
| | 21-26 | ② | | 23- 1 | ② | | 23-42 | ② | | 23-84 | ② | | 23-125 | ② |
| | 21-27 | ② | | 23- 2 | ② | | 23-43 | ② | | 23-85 | ② | | 23-126 | ② |
| | 21-28 | ② | | 23- 3 | ② | | 23-44 | ② | | 23-86 | ② | | 23-127 | ② |
| | 21-29 | ② | | 23- 4 | ② | | 23-45 | ② | | 23-87 | ② | | 23-128 | ② |

LIST OF REVISED PAGES

LIST OF REVISED PAGES

| Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision |
|------|--------|------------------|------|--------|------------------|------|-------|------------------|------|-------|------------------|------|-------|------------------|
| | 23-129 | 2 | | 23-170 | 2 | | 41- 7 | 2 | | 43- 4 | 2 | | 51-20 | 2 |
| | 23-130 | 2 | | 23-171 | 2 | | 41- 8 | 2 | | 43- 5 | 2 | | 51-21 | 2 |
| | 23-131 | 2 | | 23-172 | 2 | | 41- 9 | 2 | | 43- 6 | 2 | | 51-22 | 2 |
| | 23-132 | 2 | | 23-173 | 2 | | 41-10 | 2 | | 43- 7 | 2 | | 51-23 | 2 |
| | 23-133 | 2 | | 23-174 | 2 | | 41-11 | 2 | | 43- 8 | 2 | | 51-24 | 2 |
| | 23-134 | 2 | | 23-175 | 2 | | 41-12 | 2 | | 43- 9 | 2 | | 51-25 | 2 |
| | 23-135 | 2 | | | | | 41-14 | 2 | | 43-10 | 2 | | 51-26 | 2 |
| | 23-136 | 2 | | 24- 1 | 2 | | 41-15 | 2 | | 43-11 | 2 | | 51-27 | 2 |
| | 23-137 | 2 | | 24- 2 | 2 | | 41-16 | 2 | | 43-12 | 2 | | 51-28 | 2 |
| | 23-138 | 2 | | 24- 4 | 2 | | 41-17 | 2 | | 43-13 | 2 | | 51-29 | 2 |
| | 23-139 | 2 | | 24- 5 | 2 | | 41-18 | 2 | | 43-14 | 2 | | 51-30 | 2 |
| | 23-140 | 2 | | 24- 6 | 2 | | 41-20 | 2 | | 43-15 | 2 | | 51-31 | 2 |
| | 23-141 | 2 | | 24- 7 | 2 | | 41-21 | 2 | | | | | 51-32 | 2 |
| | 23-142 | 2 | | 24- 8 | 2 | | 41-22 | 2 | | 44- 1 | 2 | | 51-33 | 2 |
| | 23-143 | 2 | | 24- 9 | 2 | | 41-23 | 2 | | 44- 2 | 2 | | | |
| | 23-144 | 2 | | 24-10 | 2 | | 41-24 | 2 | | 44- 3 | 2 | | 52- 1 | 2 |
| | 23-145 | 2 | | 24-11 | 2 | | 41-25 | 2 | | 44- 4 | 2 | | 52- 2 | 2 |
| | 23-146 | 2 | | 24-12 | 2 | | 41-26 | 2 | | 44- 5 | 3 | | 52- 3 | 2 |
| | 23-147 | 2 | | 24-13 | 2 | | 41-27 | 2 | | 44- 6 | 2 | | 52- 4 | 2 |
| | 23-148 | 2 | | 24-14 | 2 | | 41-28 | 2 | | 44- 7 | 2 | | 52- 5 | 2 |
| | 23-149 | 2 | | 24-15 | 2 | | 41-29 | 2 | | | | | 52- 6 | 2 |
| | 23-150 | 2 | | 24-16 | 2 | | 41-30 | 2 | | | | | | |
| | 23-151 | 2 | | 24-17 | 2 | | 41-31 | 2 | | 51- 1 | 2 | | 53- 1 | 2 |
| | 23-152 | 2 | | 24-18 | 2 | | 41-32 | 2 | | 51- 2 | 2 | | 53- 2 | 2 |
| | 23-153 | 2 | | 24-19 | 2 | | 41-33 | 2 | | 51- 3 | 2 | | 53- 3 | 2 |
| | 23-154 | 2 | | 24-20 | 2 | | 41-34 | 2 | | 51- 4 | 2 | | 53- 4 | 2 |
| | 23-155 | 2 | | 24-21 | 2 | | 41-35 | 2 | | 51- 5 | 2 | | 53- 5 | 2 |
| | 23-156 | 2 | | 24-22 | 2 | | 41-36 | 2 | | 51- 6 | 2 | | 53- 6 | 2 |
| | 23-157 | 2 | | 24-23 | 2 | | 41-37 | 2 | | 51- 8 | 2 | | 53- 7 | 2 |
| | 23-158 | 2 | | 24-24 | 2 | | | | | 51- 9 | 2 | | 53- 8 | 2 |
| | 23-159 | 2 | | 24-25 | 2 | | 42- 1 | 2 | | 51-10 | 2 | | 53- 9 | 2 |
| | 23-160 | 2 | | 24-26 | 2 | | 42- 2 | 2 | | 51-11 | 2 | | 53-10 | 2 |
| | 23-161 | 2 | | 24-27 | 2 | | 42- 3 | 2 | | 51-12 | 2 | | | |
| | 23-162 | 2 | | | | | 42- 4 | 2 | | 51-13 | 2 | | 54- 1 | 2 |
| | 23-163 | 2 | | | | | 42- 5 | 2 | | 51-14 | 2 | | 54- 2 | 2 |
| | 23-164 | 2 | | 41- 1 | 2 | | 42- 6 | 2 | | 51-15 | 2 | | 54- 3 | 2 |
| | 23-165 | 2 | | 41- 3 | 2 | | | | | 51-16 | 2 | | 54- 4 | 2 |
| | 23-166 | 2 | | 41- 4 | 2 | | 43- 1 | 2 | | 51-17 | 2 | | 54- 5 | 2 |
| | 23-167 | 2 | | 41- 5 | 2 | | 43- 2 | 2 | | 51-18 | 2 | | | |
| | 23-168 | 2 | | 41- 6 | 2 | | 43- 3 | 2 | | 51-19 | 2 | | | |

LIST OF REVISED PAGES


LIST OF REVISED PAGES

| Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision | Mark | Page | Time of revision |
|------|-------|------------------|------|-------|------------------|------|-------|------------------|------|-------|------------------|------|-------|------------------|
| | 61- 1 | ② | | 61-41 | ② | | 61-81 | 2 | | 64- 7 | 2 | | 72- 3 | ② |
| | 61- 2 | ② | | 61-42 | ② | | | | | 64- 8 | 2 | | 72- 4 | ② |
| | 61- 3 | ② | | 61-43 | ② | | 62- 1 | 2 | | 64- 9 | 2 | | 72- 5 | ② |
| | 61- 4 | ② | | 61-44 | ② | | 62- 2 | 2 | | 64-10 | 2 | | 72- 6 | ② |
| | 61- 5 | ② | | 61-45 | ② | | | | | 64-11 | 2 | | | |
| | 61- 6 | ② | | 61-46 | ② | | 63- 1 | ② | ● | 64-12 | ④ | | 73- 1 | ② |
| | 61- 7 | ② | | 61-47 | ② | | 63- 2 | ② | ● | 64-13 | ④ | | 73- 2 | ② |
| | 61- 8 | ② | | 61-48 | ② | | 63- 3 | ② | | | | | 73- 3 | ② |
| | 61- 9 | ② | | 61-49 | ② | | 63- 4 | ② | | | | | 73- 4 | ② |
| | 61-10 | ② | | 61-50 | ② | | 63- 5 | ② | | 71- 1 | ② | | 73- 5 | ② |
| | 61-11 | ② | | 61-51 | ② | | 63- 6 | ② | | 71- 2 | ② | | 73- 6 | ② |
| | 61-12 | ② | | 61-52 | ② | | 63- 7 | ② | | 71- 3 | ② | | 73- 7 | ② |
| | 61-13 | ② | | 61-53 | ② | | 63- 8 | ② | | 71- 4 | ② | | 73- 8 | ② |
| | 61-14 | ② | | 61-54 | ② | | 63- 9 | ② | | 71- 5 | ② | | | |
| | 61-15 | ② | | 61-55 | ② | | 63-10 | ② | | 71- 6 | ② | | 74- 1 | ② |
| | 61-16 | ② | | 61-56 | ② | | 63-11 | ② | | 71- 7 | ② | | 74- 2 | ② |
| | 61-17 | ② | | 61-57 | ② | | 63-12 | ② | | 71- 8 | ② | | 74- 3 | ② |
| | 61-18 | ② | | 61-58 | ② | | 63-13 | ② | | 71- 9 | ② | | 74- 4 | ② |
| | 61-19 | ② | | 61-59 | ② | | 63-14 | ② | | 71-10 | ② | | 74- 5 | ② |
| ● | 61-20 | ④ | | 61-60 | ② | | 63-15 | ② | | 71-11 | ② | | 74- 6 | ② |
| ● | 61-21 | ④ | | 61-61 | ② | | 63-16 | ② | | 71-12 | ② | | 74- 7 | ② |
| ● | 61-22 | ④ | | 61-62 | ② | | 63-17 | ② | | 71-13 | ② | | 74- 8 | ② |
| ● | 61-23 | ④ | | 61-63 | ② | | 63-18 | ② | | 71-14 | ② | | 74- 9 | ② |
| ● | 61-24 | ④ | | 61-64 | ② | | 63-19 | ② | | 71-15 | ② | | 74-10 | ② |
| ● | 61-25 | ④ | | 61-65 | ② | | 63-20 | ② | | 71-16 | ② | | 74-11 | ② |
| | 61-26 | ② | | 61-66 | ② | | 63-21 | ② | | 71-17 | ② | | 74-12 | ② |
| | 61-27 | ② | | 61-67 | ② | | 63-22 | ② | | 71-18 | ② | | | |
| | 61-28 | ② | | 61-68 | ② | | 63-23 | ② | | 71-19 | ② | | | |
| | 61-29 | ② | | 61-69 | ② | | 63-24 | ② | | 71-20 | ③ | | 81- 1 | ② |
| | 61-30 | ② | | 61-70 | ② | | 63-25 | ② | | 71-21 | ③ | | 81- 2 | ② |
| | 61-31 | ② | | 61-71 | ② | | 63-26 | ② | | 71-22 | ③ | | 81- 3 | ② |
| | 61-32 | ② | | 61-72 | ② | | 63-27 | ② | | 71-23 | ③ | | 81- 4 | ② |
| | 61-33 | ② | | 61-73 | ② | | 63-28 | ② | | 71-24 | ② | | 81- 5 | ② |
| | 61-34 | ② | | 61-74 | ② | | | | | 71-25 | ② | | 81- 6 | ③ |
| | 61-35 | ② | | 61-75 | ② | | 64- 1 | ② | | 71-26 | ② | | 81- 7 | ③ |
| | 61-36 | ② | | 61-76 | ② | | 64- 2 | ③ | | 71-27 | ② | | 81- 8 | ② |
| | 61-37 | ② | | 61-77 | ② | | 64- 3 | ③ | | 71-28 | ② | | 81- 9 | ② |
| | 61-38 | ② | | 61-78 | ② | | 64- 4 | ③ | | | | | 81-10 | ② |
| | 61-39 | ② | | 61-79 | ② | | 64- 5 | ② | | 72- 1 | ② | | 81-11 | ② |
| | 61-40 | ② | | 61-80 | ② | | 64- 6 | ③ | | 72- 2 | ② | | 81-12 | ② |



IMPORTANT SAFETY NOTICE

Proper service and repair is extremely important for the safe operation of your machine. The service and repair techniques recommended by Komatsu and described in this manual are both effective and safe methods of operation. Some of these operations require the use of tools specially designed by Komatsu for the purpose.

To prevent injury to workers, the symbol  is used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.

SAFETY

GENERAL PRECAUTIONS

Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully BEFORE operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions given on the decals which are fixed to the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR signs on the controls in the operator's compartment.
5. Keep all tools in good condition and learn the correct way to use them.

6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.

PREPARATIONS FOR WORK

7. Before adding oil or making any repairs, park the machine on hard, level ground, and block the wheels or tracks to prevent the machine from moving.
8. Before starting work, lower blade, ripper, bucket or any other work equipment to the ground. If this is not possible, insert the safety pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.
9. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out.
Before disconnecting or removing components of the oil, water or air circuits, first remove the pressure completely from the circuit.
12. The water and oil in the circuits are hot when the engine is stopped, so be careful not to get burned.
Wait for the oil and water to cool before carrying out any work on the oil or water circuits.
13. Before starting work, remove the leads from the battery. Always remove the lead from the negative (–) terminal first.
14. When raising heavy components, use a hoist or crane.
Check that the wire rope, chains and hooks are free from damage.
Always use lifting equipment which has ample capacity.
Install the lifting equipment at the correct places. Use a hoist or crane and operate slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
15. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.
16. When removing components, be careful not to break or damage the wiring. Damaged wiring may cause electrical fires.
17. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips on to the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip, or can even start fires.
18. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.
19. Be sure to assemble all parts again in their original places.
Replace any damaged parts with new parts.
 - When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.
20. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also, check that connecting parts are correctly installed.
21. When assembling or installing parts, always use the specified tightening torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
22. When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
23. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurements.
24. Take care when removing or installing the tracks of track-type machines.
When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.

FOREWORD

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into chapters for each main group of components; these chapters are further divided into the following sections.

STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Troubleshooting charts correlating "Problems" to "Causes" are also included in this section.

DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

NOTICE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your KOMATSU distributor for the latest information.

HOW TO READ THE SHOP MANUAL

VOLUMES

Shop manuals are issued as a guide to carrying out repairs. They are divided as follows:

- Chassis volume:** Issued for every machine model
- Engine volume:** Issued for each engine series
- Electrical volume** : } Each issued as one volume to cover all models
- Attachments volume** : }

These various volumes are designed to avoid duplicating the same information. Therefore to deal with all repairs for any model, it is necessary that chassis, engine, electrical and attachment volumes are ready.


DISTRIBUTION AND UPDATING

Any additions, amendments or other changes will be sent to KOMATSU distributors. Get the most up-to-date information before you start any work.


FILING METHOD

- See the page number on the bottom of the page. File the pages in correct order.
- Following examples shows how to read the page number.

Example 1 (Chassis volume):



Example 2 (Engine volume):



- Additional pages:** Additional pages are indicated by a hyphen (-) and number after the page number. File as in the example.

Example:

| | | |
|--------|---------------------|----------|
| 10-4 | | 12-203 |
| 10-4-1 | } — Added pages — { | 12-203-1 |
| 10-4-2 | | 12-203-2 |
| 10-5 | | 12-204 |

REVISED EDITION MARK (①②③)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

REVISIONS


Revised pages are shown at the LIST OF REVISED PAGES on the between the title page and SAFETY page.


SYMBOLS

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

| Symbol | Item | Remarks |
|--------|-------------------|--|
| | Safety | Special safety precautions are necessary when performing the work. |
| | Caution | Special technical precautions or other precautions for preserving standards are necessary when performing the work. |
| | Weight | Weight of parts or systems. Caution necessary when selecting hoisting wire, or when working posture is important, etc. |
| | Tightening torque | Places that require special attention for the tightening torque during assembly. |
| | Coat | Places to be coated with adhesives and lubricants, etc. |
| | Oil, water | Places where oil, water or fuel must be added, and the capacity. |
| | Drain | Places where oil or water must be drained, and quantity to be drained. |

HOISTING INSTRUCTIONS



⚠ Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is indicated clearly with the symbol 

- If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:
 - Check for removal of all bolts fastening the part to the relative parts.
 - Check for existence of another part causing interference with the part to be removed.

2. Wire ropes


1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

| Wire ropes (Standard "Z" or "S" twist ropes without galvanizing) | |
|--|-----------------------|
| Rope diameter (mm) | Allowable load (tons) |
| 10 | 1.0 |
| 11.2 | 1.4 |
| 12.5 | 1.6 |
| 14 | 2.2 |
| 16 | 2.8 |
| 18 | 3.6 |
| 20 | 4.4 |
| 22.4 | 5.6 |
| 30 | 10.0 |
| 40 | 18.0 |
| 50 | 28.0 |
| 60 | 40.0 |

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.

2) Sling wire ropes from the middle portion of the hook.

Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result. Hooks have maximum strength at the middle portion.



FS0064


3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.

⚠ Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.

When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.





FS0065



STANDARD TIGHTENING TORQUE

1. STANDARD TIGHTENING TORQUE OF BOLTS AND NUTS

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in sections of "Disassembly and Assembly".

| Thread diameter of bolt (mm) | Width across flat (mm) |  |  |
|------------------------------|------------------------|---|---|
| | | kgm | Nm |
| 6 | 10 | 1.35 ± 0.15 | 13.2 ± 1.4 |
| 8 | 13 | 3.2 ± 0.3 | 31.4 ± 2.9 |
| 10 | 17 | 6.7 ± 0.7 | 65.7 ± 6.8 |
| 12 | 19 | 11.5 ± 1.0 | 112 ± 9.8 |
| 14 | 22 | 18.0 ± 2.0 | 177 ± 19 |
| 16 | 24 | 28.5 ± 3 | 279 ± 29 |
| 18 | 27 | 39 ± 4 | 383 ± 39 |
| 20 | 30 | 56 ± 6 | 549 ± 58 |
| 22 | 32 | 76 ± 8 | 745 ± 78 |
| 24 | 36 | 94.5 ± 10 | 927 ± 98 |
| 27 | 41 | 135 ± 15 | 1320 ± 140 |
| 30 | 46 | 175 ± 20 | 1720 ± 190 |
| 33 | 50 | 225 ± 25 | 2210 ± 240 |
| 36 | 55 | 280 ± 30 | 2750 ± 290 |
| 39 | 60 | 335 ± 35 | 3280 ± 340 |

This torque table does not apply to the bolts with which nylon packings or other non-ferrous metal washers are to be used, or which require tightening to otherwise specified torque.

★ Nm (newton meter): $1\text{Nm} \cong 0.1\text{kgm}$

2. TIGHTENING TORQUE OF SPLIT FLANGE BOLTS

Use these torques for split flange bolts.


| Thread diameter of bolt (mm) | Width across flats (mm) | Tightening torque | |
|------------------------------|-------------------------|-------------------|----------------|
| | | kgm | Nm |
| 10 | 14 | 6.7 ± 0.7 | 65.7 ± 6.8 |
| 12 | 17 | 11.5 ± 1 | 112 ± 9.8 |
| 16 | 22 | 28.5 ± 3 | 279 ± 29 |

STANDARD TIGHTENING TORQUE



3. TIGHTENING TORQUE FOR NUTS OF FLARED


Use these torques for nut part of flared.



FS0068

| Thread diameter of nut part (mm) | Width across flats of nut part (mm) | Tightening torque | |
|----------------------------------|-------------------------------------|-------------------|--------------|
| | | kgm | Nm |
| 14 | 19 | 2.5 ± 0.5 | 24.5 ± 4.9 |
| 18 | 24 | 5 ± 2 | 49 ± 19.6 |
| 22 | 27 | 8 ± 2 | 78.5 ± 19.6 |
| 24 | 32 | 14 ± 3 | 137.3 ± 29.4 |
| 30 | 36 | 18 ± 3 | 176.5 ± 29.4 |
| 33 | 41 | 20 ± 5 | 196.1 ± 49 |
| 36 | 46 | 25 ± 5 | 245.2 ± 49 |
| 42 | 55 | 30 ± 5 | 294.2 ± 49 |

COATING MATERIALS



The recommended coating materials prescribed in Komatsu Shop Manuals are listed below.

| Nomenclature | Komatsu code | Applications |
|--|--------------|---|
| Adhesives | LT-1A | Used to apply rubber pads, rubber gaskets, and cork plugs. |
| | LT-1B | Used to apply resin, rubber, metallic and non-metallic parts when a fast, strong seal is needed. |
| | LT-2* | Preventing bolts, nuts and plugs from loosening and leaking oil. |
| | LT-3 | Provides an airtight, electrically insulating seal. Used for aluminum surfaces. |
| | LT-4 | Used to coat plugs (plate shaped, bowl shaped) and holes, and mating portion of shaft. |
| Sealant gasket | LG-1 | Used with gaskets and packings to increase sealing effect. |
| | LG-3 | Heat-resistant gasket for precombustion chambers and exhaust piping. |
| | LG-4 | Used by itself on mounting surfaces on the final drive and transmission cases. (Thickness after tightening: 0.07 – 0.08 mm) |
| | LG-5 | Used by itself to seal grease fittings, tapered screw fittings and tapered screw fittings in hydraulic circuits of less than 50 mm in diameter. |
| | LG-6 | Silicon base type used in combination with LG-1 and LG-4. |
| | LG-7 | Has a shorter curing time than LG-6, and is easier to peel off. |
| Antifriction compound (Lubricant including molybdenum disulfide) | LM-P | Applied to bearings and taper shafts to facilitate press-fitting and to prevent sticking, burning or rusting. |
| Grease (Lithium grease) | G2-LI | Applied to bearings, sliding parts and oil seals for lubrication, rust prevention and facilitation of assembling work. |
| Vaseline | — | Used for protecting battery electrode terminals from corrosion. |

*LT-2 is also called LOCTITE in the shop manuals.



ELECTRIC WIRE CODE

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires. This wire code table will help you understand WIRING DIAGRAMS.

Example: 5WB indicates a cable having a nominal number 5 and white coating with black stripe.

CLASSIFICATION BY THICKNESS

| Nominal number | Copper wire | | | Cable O.D. (mm) | Current rating (A) | Applicable circuit |
|----------------|----------------|----------------------|----------------------------------|-----------------|--------------------|---------------------------------|
| | Number strands | Dia. of strands (mm) | Cross section (mm ²) | | | |
| 0.85 | 11 | 0.32 | 0.88 | 2.4 | 12 | Starting, lighting, signal etc. |
| 2 | 26 | 0.32 | 2.09 | 3.1 | 20 | Lighting, signal etc. |
| 5 | 65 | 0.32 | 5.23 | 4.6 | 37 | Charging and signal |
| 15 | 84 | 0.45 | 13.36 | 7.0 | 59 | Starting (Glow plug) |
| 40 | 85 | 0.80 | 42.73 | 11.4 | 135 | Starting |
| 60 | 127 | 0.80 | 63.84 | 13.6 | 178 | Starting |
| 100 | 217 | 0.80 | 109.1 | 17.6 | 230 | Starting |

CLASSIFICATION BY COLOR AND CODE

| Priority | Circuits Classification | | Charging | Ground | Starting | Lighting | Instrument | Signal | Other |
|----------|-------------------------|---------------|-------------|----------------|---------------|----------------|-----------------|----------------|--------------|
| | Code | Color | | | | | | | |
| 1 | Primary | Code | W | B | B | R | Y | G | L |
| | | Color | White | Black | Black | Red | Yellow | Green | Blue |
| 2 | Auxiliary | Code | WR | — | BW | RW | YR | GW | LW |
| | | Color | White & Red | — | Black & White | Red & White | Yellow & Red | Green & White | Blue & White |
| Code | | WB | — | BY | RB | YB | GR | LR | |
| Color | | White & Black | — | Black & Yellow | Red & Black | Yellow & Black | Green & Red | Blue & Red | |
| Code | | WL | — | BR | RY | YG | GY | LY | |
| Color | | White & Blue | — | Black & Red | Red & Yellow | Yellow & Green | Green & Yellow | Blue & Yellow | |
| Code | | WG | — | — | RG | YL | (GB) | (LB) | |
| Color | | White & Green | — | — | Red & Green | Yellow & Blue | (Green & Black) | (Blue & Black) | |
| Code | | — | — | — | RL | YW | (GL) | — | |
| Color | | — | — | — | Red & Blue | Yellow & White | (Green & Blue) | — | |

CONVERSION TABLE

CONVERSION TABLE

Method of using the Conversion Table

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

Example

- Method of using the Conversion Table to convert from millimeters to inches

1. Convert 55 mm into inches.

- (1) Locate the number 50 in the vertical column at the left side, take this as (A), then draw a horizontal line from (A).
- (2) Locate the number 5 in the row across the top, take this as (B), then draw a perpendicular line down from (B).
- (3) Take the point where the two lines cross as (C). This point (C) gives the value when converting from millimeters to inches. Therefore, 55 mm = 2.165 inches.

2. Convert 550 mm into inches.

- (1) The number 550 does not appear in the table, so divide by 10 (move the decimal point one place to the left) to convert it to 55 mm.
- (2) Carry out the same procedure as above to convert 55 mm to 2.165 inches.
- (3) The original value (550 mm) was divided by 10, so multiply 2.165 inches by 10 (move the decimal point one place to the right) to return to the original value. This gives 550 mm = 21.65 inches.

Millimeters to inches (B) 1 mm = 0.03937 in

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|--------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| 0 | | 0.039 | 0.079 | 0.118 | 0.157 | 0.197 | 0.236 | 0.276 | 0.315 | 0.354 |
| 10 | 0.394 | 0.433 | 0.472 | 0.512 | 0.551 | 0.591 | 0.630 | 0.669 | 0.709 | 0.748 |
| 20 | 0.787 | 0.827 | 0.866 | 0.906 | 0.945 | 0.984 | 1.024 | 1.063 | 1.102 | 1.142 |
| 30 | 1.181 | 1.220 | 1.260 | 1.299 | 1.339 | 1.378 | 1.417 | 1.457 | 1.496 | 1.536 |
| 40 | 1.575 | 1.614 | 1.654 | 1.693 | 1.732 | 1.772 | 1.811 | 1.850 | 1.890 | 1.929 |
| (A) 50 | 1.969 | 2.008 | 2.047 | 2.087 | 2.126 | 2.165 | 2.205 | 2.244 | 2.283 | 2.323 |
| 60 | 2.362 | 2.402 | 2.441 | 2.480 | 2.520 | 2.559 | 2.598 | 2.638 | 2.677 | 2.717 |
| 70 | 2.756 | 2.795 | 2.835 | 2.874 | 2.913 | 2.953 | 2.992 | 3.032 | 3.071 | 3.110 |
| 80 | 3.150 | 3.189 | 3.228 | 3.268 | 3.307 | 3.346 | 3.386 | 3.425 | 3.465 | 3.504 |
| 90 | 3.543 | 3.583 | 3.622 | 3.661 | 3.701 | 3.740 | 3.780 | 3.819 | 3.858 | 3.898 |

CONVERSION TABLE

Millimeters to Inches

1 mm = 0.03937 in

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| 0 | | 0.039 | 0.079 | 0.118 | 0.157 | 0.197 | 0.236 | 0.276 | 0.315 | 0.354 |
| 10 | 0.394 | 0.433 | 0.472 | 0.512 | 0.551 | 0.591 | 0.630 | 0.669 | 0.709 | 0.748 |
| 20 | 0.787 | 0.827 | 0.866 | 0.906 | 0.945 | 0.984 | 1.024 | 1.063 | 1.102 | 1.142 |
| 30 | 1.181 | 1.220 | 1.260 | 1.299 | 1.339 | 1.378 | 1.417 | 1.457 | 1.496 | 1.536 |
| 40 | 1.575 | 1.614 | 1.654 | 1.693 | 1.732 | 1.772 | 1.811 | 1.850 | 1.890 | 1.929 |
| 50 | 1.969 | 2.008 | 2.047 | 2.087 | 2.126 | 2.165 | 2.205 | 2.244 | 2.283 | 2.323 |
| 60 | 2.362 | 2.402 | 2.441 | 2.480 | 2.520 | 2.559 | 2.598 | 2.638 | 2.677 | 2.717 |
| 70 | 2.756 | 2.795 | 2.835 | 2.874 | 2.913 | 2.953 | 2.992 | 3.032 | 3.071 | 3.110 |
| 80 | 3.150 | 3.189 | 3.228 | 3.268 | 3.307 | 3.346 | 3.386 | 3.425 | 3.465 | 3.504 |
| 90 | 3.543 | 3.583 | 3.622 | 3.661 | 3.701 | 3.740 | 3.780 | 3.819 | 3.858 | 3.898 |

Kilogram to Pound

1 kg = 2.2046 lb

| Kilogram | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| | | 2.20 | 4.41 | 6.61 | 8.82 | 11.02 | 13.23 | 15.43 | 17.64 | 19.84 |
| 10 | 22.05 | 24.25 | 26.46 | 28.66 | 30.86 | 33.07 | 35.27 | 37.48 | 39.68 | 41.89 |
| 20 | 44.09 | 46.30 | 48.50 | 50.71 | 51.91 | 55.12 | 57.32 | 59.53 | 61.73 | 63.93 |
| 30 | 66.14 | 68.34 | 70.55 | 72.75 | 74.96 | 77.16 | 79.37 | 81.57 | 83.78 | 85.98 |
| 40 | 88.18 | 90.39 | 92.59 | 94.80 | 97.00 | 99.21 | 101.41 | 103.62 | 105.82 | 108.03 |
| 50 | 110.23 | 112.44 | 114.64 | 116.85 | 119.05 | 121.25 | 123.46 | 125.66 | 127.87 | 130.07 |
| 60 | 132.28 | 134.48 | 136.69 | 138.89 | 141.10 | 143.30 | 145.51 | 147.71 | 149.91 | 152.12 |
| 70 | 154.32 | 156.53 | 158.73 | 160.94 | 163.14 | 165.35 | 167.55 | 169.76 | 171.96 | 174.17 |
| 80 | 176.37 | 178.57 | 180.78 | 182.98 | 185.19 | 187.39 | 189.60 | 191.80 | 194.01 | 196.21 |
| 90 | 198.42 | 200.62 | 202.83 | 205.03 | 207.24 | 209.44 | 211.64 | 213.85 | 216.05 | 218.26 |

CONVERSION TABLE

Liter to U.S. Gallon

1 ℓ = 0.2642 U.S. Gal

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|----|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| | | 0.264 | 0.528 | 0.793 | 1.057 | 1.321 | 1.585 | 1.849 | 2.113 | 2.378 |
| 10 | 2.642 | 2.906 | 3.170 | 3.434 | 3.698 | 3.963 | 4.227 | 4.491 | 4.755 | 5.019 |
| 20 | 5.283 | 5.548 | 5.812 | 6.076 | 6.340 | 6.604 | 6.869 | 7.133 | 7.397 | 7.661 |
| 30 | 7.925 | 8.189 | 8.454 | 8.718 | 8.982 | 9.246 | 9.510 | 9.774 | 10.039 | 10.303 |
| 40 | 10.567 | 10.831 | 11.095 | 11.359 | 11.624 | 11.888 | 12.152 | 12.416 | 12.680 | 12.944 |
| 50 | 13.209 | 13.473 | 13.737 | 14.001 | 14.265 | 14.529 | 14.795 | 15.058 | 15.322 | 15.586 |
| 60 | 15.850 | 16.115 | 16.379 | 16.643 | 16.907 | 17.171 | 17.435 | 17.700 | 17.964 | 18.228 |
| 70 | 18.492 | 18.756 | 19.020 | 19.285 | 19.549 | 19.813 | 20.077 | 20.341 | 20.605 | 20.870 |
| 80 | 21.134 | 21.398 | 21.662 | 21.926 | 22.190 | 22.455 | 22.719 | 22.983 | 23.247 | 23.511 |
| 90 | 23.775 | 24.040 | 24.304 | 24.568 | 24.832 | 25.096 | 25.361 | 25.625 | 25.889 | 26.153 |

Liter to U.K. Gallon

1 ℓ = 0.21997 U.K. Gal

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|----|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| | | 0.220 | 0.440 | 0.660 | 0.880 | 1.100 | 1.320 | 1.540 | 1.760 | 1.980 |
| 10 | 2.200 | 2.420 | 2.640 | 2.860 | 3.080 | 3.300 | 3.520 | 3.740 | 3.950 | 4.179 |
| 20 | 4.399 | 4.619 | 4.839 | 5.059 | 5.279 | 5.499 | 5.719 | 5.939 | 6.159 | 6.379 |
| 30 | 6.599 | 6.819 | 7.039 | 7.259 | 7.479 | 7.699 | 7.919 | 8.139 | 8.359 | 8.579 |
| 40 | 8.799 | 9.019 | 9.239 | 9.459 | 9.679 | 9.899 | 10.119 | 10.339 | 10.559 | 10.778 |
| 50 | 10.998 | 11.281 | 11.438 | 11.658 | 11.878 | 12.098 | 12.318 | 12.528 | 12.758 | 12.978 |
| 60 | 13.198 | 13.418 | 13.638 | 13.858 | 14.078 | 14.298 | 14.518 | 14.738 | 14.958 | 15.178 |
| 70 | 15.398 | 15.618 | 15.838 | 16.058 | 16.278 | 16.498 | 16.718 | 16.938 | 17.158 | 17.378 |
| 80 | 17.598 | 17.818 | 18.037 | 18.257 | 18.477 | 18.697 | 18.917 | 19.137 | 19.357 | 19.577 |
| 90 | 19.797 | 20.017 | 20.237 | 20.457 | 20.677 | 20.897 | 21.117 | 21.337 | 21.557 | 21.777 |

CONVERSION TABLE

kgm to ft.lb

1 kg.m = 7.233 ft.lb

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|-----|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| | | 7.2 | 14.5 | 21.7 | 28.9 | 36.2 | 43.4 | 50.6 | 57.9 | 65.1 |
| 10 | 72.3 | 79.6 | 86.8 | 94.0 | 101.3 | 108.5 | 115.7 | 123.0 | 130.2 | 137.4 |
| 20 | 144.7 | 151.9 | 159.1 | 166.4 | 173.6 | 180.8 | 188.1 | 195.3 | 202.5 | 209.8 |
| 30 | 217.0 | 224.2 | 231.5 | 238.7 | 245.9 | 253.2 | 260.4 | 267.6 | 274.9 | 282.1 |
| 40 | 289.3 | 296.6 | 303.8 | 311.0 | 318.3 | 325.5 | 332.7 | 340.0 | 347.2 | 354.4 |
| 50 | 361.7 | 368.9 | 376.1 | 383.4 | 390.6 | 397.8 | 405.1 | 412.3 | 419.5 | 426.8 |
| 60 | 434.0 | 441.2 | 448.5 | 455.7 | 462.9 | 470.2 | 477.4 | 484.6 | 491.8 | 499.1 |
| 70 | 506.3 | 513.5 | 520.8 | 528.0 | 535.2 | 542.5 | 549.7 | 556.9 | 564.2 | 571.4 |
| 80 | 578.6 | 585.9 | 593.1 | 600.3 | 607.6 | 614.8 | 622.0 | 629.3 | 636.5 | 643.7 |
| 90 | 651.0 | 658.2 | 665.4 | 672.7 | 679.9 | 687.1 | 694.4 | 701.6 | 708.8 | 716.1 |
| 100 | 723.3 | 730.5 | 737.8 | 745.0 | 752.2 | 759.5 | 766.7 | 773.9 | 781.2 | 788.4 |
| 110 | 795.6 | 802.9 | 810.1 | 817.3 | 824.6 | 831.8 | 839.0 | 846.3 | 853.5 | 860.7 |
| 120 | 868.0 | 875.2 | 882.4 | 889.7 | 896.9 | 904.1 | 911.4 | 918.6 | 925.8 | 933.1 |
| 130 | 940.3 | 947.5 | 954.8 | 962.0 | 969.2 | 976.5 | 983.7 | 990.9 | 998.2 | 1005.4 |
| 140 | 1012.6 | 1019.9 | 1027.1 | 1034.3 | 1041.5 | 1048.8 | 1056.0 | 1063.2 | 1070.5 | 1077.7 |
| 150 | 1084.9 | 1092.2 | 1099.4 | 1106.6 | 1113.9 | 1121.1 | 1128.3 | 1135.6 | 1142.8 | 1150.0 |
| 160 | 1157.3 | 1164.5 | 1171.7 | 1179.0 | 1186.2 | 1193.4 | 1200.7 | 1207.9 | 1215.1 | 1222.4 |
| 170 | 1129.6 | 1236.8 | 1244.1 | 1251.3 | 1258.5 | 1265.8 | 1273.0 | 1280.1 | 1287.5 | 1294.7 |
| 180 | 1301.9 | 1309.2 | 1316.4 | 1323.6 | 1330.9 | 1338.1 | 1345.3 | 1352.6 | 1359.8 | 1367.0 |
| 190 | 1374.3 | 1381.5 | 1388.7 | 1396.0 | 1403.2 | 1410.4 | 1417.7 | 1424.9 | 1432.1 | 1439.4 |

CONVERSION TABLE

kg/cm² to lb/in²

1 kg/cm² = 14.2233 lb/in²

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| | | 14.2 | 28.4 | 42.7 | 56.9 | 71.1 | 85.3 | 99.6 | 113.8 | 128.0 |
| 10 | 142.2 | 156.5 | 170.7 | 184.9 | 199.1 | 213.4 | 227.6 | 241.8 | 256.0 | 270.2 |
| 20 | 284.5 | 298.7 | 312.9 | 327.1 | 341.4 | 355.6 | 369.8 | 384.0 | 398.3 | 412.5 |
| 30 | 426.7 | 440.9 | 455.1 | 469.4 | 483.6 | 497.8 | 512.0 | 526.3 | 540.5 | 554.7 |
| 40 | 568.9 | 583.2 | 597.4 | 611.6 | 625.8 | 640.1 | 654.3 | 668.5 | 682.7 | 696.9 |
| 50 | 711.2 | 725.4 | 739.6 | 753.8 | 768.1 | 782.3 | 796.5 | 810.7 | 825.0 | 839.2 |
| 60 | 853.4 | 867.6 | 881.8 | 896.1 | 910.3 | 924.5 | 938.7 | 953.0 | 967.2 | 981.4 |
| 70 | 995.6 | 1010 | 1024 | 1038 | 1053 | 1067 | 1081 | 1095 | 1109 | 1124 |
| 80 | 1138 | 1152 | 1166 | 1181 | 1195 | 1209 | 1223 | 1237 | 1252 | 1266 |
| 90 | 1280 | 1294 | 1309 | 1323 | 1337 | 1351 | 1365 | 1380 | 1394 | 1408 |
| 100 | 1422 | 1437 | 1451 | 1465 | 1479 | 1493 | 1508 | 1522 | 1536 | 1550 |
| 110 | 1565 | 1579 | 1593 | 1607 | 1621 | 1636 | 1650 | 1664 | 1678 | 1693 |
| 120 | 1707 | 1721 | 1735 | 1749 | 1764 | 1778 | 1792 | 1806 | 1821 | 1835 |
| 130 | 1849 | 1863 | 1877 | 1892 | 1906 | 1920 | 1934 | 1949 | 1963 | 1977 |
| 140 | 1991 | 2005 | 2020 | 2034 | 2048 | 2062 | 2077 | 2091 | 2105 | 2119 |
| 150 | 2134 | 2148 | 2162 | 2176 | 2190 | 2205 | 2219 | 2233 | 2247 | 2262 |
| 160 | 2276 | 2290 | 2304 | 2318 | 2333 | 2347 | 2361 | 2375 | 2389 | 2404 |
| 170 | 2418 | 2432 | 2446 | 2460 | 2475 | 2489 | 2503 | 2518 | 2532 | 2546 |
| 180 | 2560 | 2574 | 2589 | 2603 | 2617 | 2631 | 2646 | 2660 | 2674 | 2688 |
| 190 | 2702 | 2717 | 2731 | 2745 | 2759 | 2773 | 2788 | 2802 | 2816 | 2830 |
| 200 | 2845 | 2859 | 2873 | 2887 | 2901 | 2916 | 2930 | 2944 | 2958 | 2973 |
| 210 | 2987 | 3001 | 3015 | 3030 | 3044 | 3058 | 3072 | 3086 | 3101 | 3115 |
| 220 | 3129 | 3143 | 3158 | 3172 | 3186 | 3200 | 3214 | 3229 | 3243 | 3257 |
| 230 | 3271 | 3286 | 3300 | 3314 | 3328 | 3343 | 3357 | 3371 | 3385 | 3399 |
| 240 | 3414 | 3428 | 3442 | 3456 | 3470 | 3485 | 3499 | 3513 | 3527 | 3542 |

CONVERSION TABLE

Temperature

Fahrenheit-Centigrade Conversion. —A simple way to convert a Fahrenheit temperature reading into a Centigrade temperature reading or vice versa is to enter the accompanying table in the center or boldface column of figures.


These figures refer to the temperature in either Fahrenheit or Centigrade degrees.

If it is desired to convert from Fahrenheit to Centigrade degrees, consider the center column as a table of Fahrenheit temperatures and read the corresponding Centigrade temperature in the column at the left.

If it is desired to convert from Centigrade to Fahrenheit degrees, consider the center column as a table of Centigrade values, and read the corresponding Fahrenheit temperature on the right.

| °C | | °F | °C | | °F | °C | | °F | °C | | °F |
|-------|-----|-------|-------|----|-------|------|----|-------|------|-----|-------|
| -40.4 | -40 | -40.0 | -11.7 | 11 | 51.8 | 7.8 | 46 | 114.8 | 27.2 | 81 | 117.8 |
| -37.2 | -35 | -31.0 | -11.1 | 12 | 53.6 | 8.3 | 47 | 116.6 | 27.8 | 82 | 179.6 |
| -34.4 | -30 | -22.0 | -10.6 | 13 | 55.4 | 8.9 | 48 | 118.4 | 28.3 | 83 | 181.4 |
| -31.7 | -25 | -13.0 | -10.0 | 14 | 57.2 | 9.4 | 49 | 120.2 | 28.9 | 84 | 183.2 |
| -28.9 | -20 | -4.0 | -9.4 | 15 | 59.0 | 10.0 | 50 | 122.0 | 29.4 | 85 | 185.0 |
| -28.3 | -19 | -2.2 | -8.9 | 16 | 60.8 | 10.6 | 51 | 123.8 | 30.0 | 86 | 186.8 |
| -27.8 | -18 | -0.4 | -8.3 | 17 | 62.6 | 11.1 | 52 | 125.6 | 30.6 | 87 | 188.6 |
| -27.2 | -17 | 1.4 | -7.8 | 18 | 64.4 | 11.7 | 53 | 127.4 | 31.1 | 88 | 190.4 |
| -26.7 | -16 | 3.2 | -7.2 | 19 | 66.2 | 12.2 | 54 | 129.2 | 31.7 | 89 | 192.2 |
| -26.1 | -15 | 5.0 | -6.7 | 20 | 68.0 | 12.8 | 55 | 131.0 | 32.2 | 90 | 194.0 |
| -25.6 | -14 | 6.8 | -6.1 | 21 | 69.8 | 13.3 | 56 | 132.8 | 32.8 | 91 | 195.8 |
| -25.0 | -13 | 8.6 | -5.6 | 22 | 71.6 | 13.9 | 57 | 134.6 | 33.3 | 92 | 197.6 |
| -24.4 | -12 | 10.4 | -5.0 | 23 | 73.4 | 14.4 | 58 | 136.4 | 33.9 | 93 | 199.4 |
| -23.9 | -11 | 12.2 | -4.4 | 24 | 75.2 | 15.0 | 59 | 138.2 | 34.4 | 94 | 201.2 |
| -23.3 | -10 | 14.0 | -3.9 | 25 | 77.0 | 15.6 | 60 | 140.0 | 35.0 | 95 | 203.0 |
| -22.8 | -9 | 15.8 | -3.3 | 26 | 78.8 | 16.1 | 61 | 141.8 | 35.6 | 96 | 204.8 |
| -22.2 | -8 | 17.6 | -2.8 | 27 | 80.6 | 16.7 | 62 | 143.6 | 36.1 | 97 | 206.6 |
| -21.7 | -7 | 19.4 | -2.2 | 28 | 82.4 | 17.2 | 63 | 145.4 | 36.7 | 98 | 208.4 |
| -21.1 | -6 | 21.2 | -1.7 | 29 | 84.2 | 17.8 | 64 | 147.2 | 37.2 | 99 | 210.2 |
| -20.6 | -5 | 23.0 | -1.1 | 30 | 86.0 | 18.3 | 65 | 149.0 | 37.8 | 100 | 212.0 |
| -20.0 | -4 | 24.8 | -0.6 | 31 | 87.8 | 18.9 | 66 | 150.8 | 40.6 | 105 | 221.0 |
| -19.4 | -3 | 26.6 | 0 | 32 | 89.6 | 19.4 | 67 | 152.6 | 43.3 | 110 | 230.0 |
| -18.9 | -2 | 28.4 | 0.6 | 33 | 91.4 | 20.0 | 68 | 154.4 | 46.1 | 115 | 239.0 |
| -18.3 | -1 | 30.2 | 1.1 | 34 | 93.2 | 20.6 | 69 | 156.2 | 48.9 | 120 | 248.0 |
| -17.8 | 0 | 32.0 | 1.7 | 35 | 95.0 | 21.1 | 70 | 158.0 | 51.7 | 125 | 257.0 |
| -17.2 | 1 | 33.8 | 2.2 | 36 | 96.8 | 21.7 | 71 | 159.8 | 54.4 | 130 | 266.0 |
| -16.7 | 2 | 35.6 | 2.8 | 37 | 98.6 | 22.2 | 72 | 161.6 | 57.2 | 135 | 275.0 |
| -16.1 | 3 | 37.4 | 3.3 | 38 | 100.4 | 22.8 | 73 | 163.4 | 60.0 | 140 | 284.0 |
| -15.6 | 4 | 39.2 | 3.9 | 39 | 102.2 | 23.3 | 74 | 165.2 | 62.7 | 145 | 293.0 |
| -15.0 | 5 | 41.0 | 4.4 | 40 | 104.0 | 23.9 | 75 | 167.0 | 65.6 | 150 | 302.0 |
| -14.4 | 6 | 42.8 | 5.0 | 41 | 105.8 | 24.4 | 76 | 168.8 | 68.3 | 155 | 311.0 |
| -13.9 | 7 | 44.6 | 5.6 | 42 | 107.6 | 25.0 | 77 | 170.6 | 71.1 | 160 | 320.0 |
| -13.3 | 8 | 46.4 | 6.1 | 43 | 109.4 | 25.6 | 78 | 172.4 | 73.9 | 165 | 329.0 |
| -12.8 | 9 | 48.2 | 6.7 | 44 | 111.2 | 26.1 | 79 | 174.2 | 76.7 | 170 | 338.0 |
| -12.2 | 10 | 50.0 | 7.2 | 45 | 113.0 | 26.7 | 80 | 176.0 | 79.4 | 175 | 347.0 |


01 GENERAL



| | |
|---------------------------------------|-------|
| Motor grader numbering code | 01- 3 |
| General view | 01- 4 |
| Operator's compartment | 01- 5 |
| Specifications | 01-10 |
| Engine assembly | 01-14 |
| Weight table | 01-22 |
| Serial number locations | 01-24 |
| List of lubricant and water | 01-26 |
| Motor grader description | 01-27 |


MOTOR GRADER NUMBERING CODE

G D 7 0 5 A - 4




Example: **GD705R-4** Hydroshift drive, rigid type
GD705A-4 Hydroshift drive, articulated type

Basic mode A: Articulated




R: Rigid



F23K A036


GENERAL VIEW

GD705R-4



- 1. Blade lift cylinder
- 2. Drawbar side shift cylinder
- 3. Rear tire
- 4. Blade
- 5. Front tire



P23E04001





F23E04001

OPERATOR'S COMPARTMENT

GD705R-4




1. Work equipment control lever
2. Steering wheel
3. Horn button
4. Turn signal, dimmer switch (If equipped)
5. Safety lock (for work equipment control lever)
6. Steering post tilt pedal
7. Fuel control lever
8. Gear shift lever
9. Parking brake lever
10. Accelerator pedal
11. Brake pedal
12. Lifter lock pin pedal
13. Inching pedal
14. Safety lock lever (for gear shift lever)
15. Head lamp switch,
16. Engine oil pressure gauge
17. Water temperature gauge
18. Battery charging lamp
19. Parking brake pilot lamp acts also as brake oil level warning lamp (If equipped)
20. Speedometer
21. Fuel gauge
22. Heater signal
23. Panel lamp
24. Service meter
25. Dust indicator
26. Starting switch





GENERAL VIEW

GD705A-4





- 1. Blade lift cylinder
- 2. Drawbar side shift cylinder
- 3. Articulation cylinder
- 4. Rear tire
- 5. Blade
- 6. Front tire
- 7. Leaning cylinder





F2340400 I

OPERATOR'S COMPARTMENT

GD705A-4




1. Work equipment control lever
2. Steering wheel tilt lever
3. Steering wheel
4. Steering post tilt lever
5. Safety lock (for work equipment control lever)
6. Fuel control lever
7. Gear shift lever
8. Safty lock lever (for gear shift lever)
9. Parking brake lever
10. Accelerator pedal
11. Brake pedal
12. Inching pedal
13. DDV lever
14. Head lamp switch
15. Air pressure gauge
16. Engine oil pressure gauge
17. Water temperature gauge
18. High beam pilot lamp (If equipped)
19. Articulation lock pilot lamp (If equipped)
20. Parking brake pilot lamp
21. Differential lock pilot lamp
22. Battery charging lamp
23. Engine oil temperature warning lamp
24. Speedometer
25. Horn button
26. Turn signal, dimmer switch
27. Fuel gauge
28. Panel lamp
29. Lifter lock release switch
30. Differential control switch
31. Service meter
32. Dust indicator
33. Starting switch
34. Heater signal
35. Working lamp switch (If equipped)





GENERAL VIEW

GD705A-4 (Serial No. 31001 and up)







- 1. Drawbar side shift cylinder
- 2. Blade lift cylinder
- 3. Muffler
- 4. Rear tire
- 5. Articulation cylinder
- 6. Blade
- 7. Front tire



OPERATOR'S COMPARTMENT

GD705A-4 (Serial No. 31001 and up)



1. Work equipment control lever
2. Steering wheel tilt lever
3. Steering post tilt lever
4. Safety lock lever
(for gear shift lever)
5. Gear shift lever
6. Fuel control lever
7. Accelerator pedal
8. Brake pedal
9. Inching pedal
10. Parking brake lever
11. DDV lever
12. Service meter
13. Fuse box
14. Differential control switch
15. Lifter lock release switch
16. Air pressure gauge
17. Engine oil pressure gauge
18. Water temperature gauge
19. Parking brake pilot lamp
20. Differential lock pilot lamp
21. Battery charging lamp
22. Engine oil temperature warning lamp
23. Speedometer
24. Horn button
25. Turn signal, dimmer switch
26. Fuel gauge
27. Panel lamp
28. Working lamp switch
29. Head lamp switch
30. Starting switch
31. Heater signal
32. Dust indicator

SPECIFICATIONS

| Model | | GD705R-4 | | |
|-----------------|-----------------------|--------------|------------|------|
| Serial Numbers | | 16001 and up | | |
| Weight | Operating weight | (kg) | 17500 | |
| | On front axle (32.2%) | (kg) | 5640 | |
| | On rear axle (67.8%) | (kg) | 11860 | |
| Dimensions | Overall length | (mm) | 8770 | |
| | Overall width | (mm) | 2460 | |
| | Overall height | (mm) | 3260 | |
| | Wheel base | (mm) | 6150 | |
| | Rear wheel base | (mm) | 1615 | |
| | Tread (Front) | (mm) | 2030 | |
| | Tread (Rear) | (mm) | 2060 | |
| | Ground clearance | (mm) | 360 | |
| Performance | Travel speed | Forward | 1st (km/h) | 3.7 |
| | | 2nd (km/h) | 6.6 | |
| | | 3rd (km/h) | 11.1 | |
| | | 4th (km/h) | 15.3 | |
| | | 5th (km/h) | 27.7 | |
| | | 6th (km/h) | 46.0 | |
| | Reverse | 1st (km/h) | 4.4 | |
| | | 2nd (km/h) | 7.8 | |
| | | 3rd (km/h) | 13.1 | |
| | | 4th (km/h) | 18.2 | |
| | | 5th (km/h) | 32.6 | |
| | | 6th (km/h) | 53.9 | |
| | Maximum drawbar pull | | (kg) | 9490 |
| Turning radius | | (m) | 11.5 | |
| Over turn angle | | (°) | 35 | |

| | | | |
|--------------------------------------|--|--|--------------------------------------|
| Model | | GD705R-4 | |
| Serial Number | | 16001 and up | |
| Wheels | Tire (Front) | 14.00 – 24 – 12 PR (3.5 kg/cm ²) | |
| | Tire (Rear) | 14.00 – 24 – 12 PR (3.5 kg/cm ²) | |
| | Rim (Front) | 8.00 TG x 24 | |
| | Rim (Rear) | 8.00 TG x 24 | |
| Blade | Blade dimension (mm) (Length x Height x Thickness) | 4270 x 700 x 19 | |
| | Cutting edge dimension (mm) (Number – Length x Width x Thickness) | 2 x 2134 x 152 x 15.9 | |
| | Turning angle (°) | 360 | |
| | Cutting angle | | |
| | [Standard] (°) | 32 | |
| | [Maximum] (°) | 74 | |
| | [Minimum] (°) | 24 | |
| Engine model type | | Komatsu 6D125-1 Diesel Engine 4-cycle, water-cooled, overhead valve, direct injection type | |
| Cylinder number – bore x stroke (mm) | | 6 – 125 x 150 | |
| Piston displacement (cc) | | 11040 | |
| Firing order | | 1 – 5 – 3 – 6 – 2 – 4 | |
| Engine | Dimension | Overall length (mm) | 1563 |
| | | Overall width (mm) | 881 |
| | | Overall height (mm) | 1507 |
| | Performance | Flywheel horsepower (HP/rpm) | 182/1850 |
| | | Maximum torque (kgm/rpm) | 80/1100 |
| | | High idling (rpm) | 2100 ± 50 |
| | | Low idling (rpm) | 650 ⁺⁵⁰ ₋₀ |
| | | Fuel consumption ratio (g/HP.h) | 158 |
| | Dry weight (kg) | | 1300 |
| | Fuel oil | | Diesel fuel ASTM D975 No. 2 or No. 1 |
| | Fuel pump | | Bosch type PE-NB |
| Governor | | Bosch RSV centrifugal, all-speed type | |
| Alternator | | 24V, 13A | |
| Starting motor | | 24V, 7.5 kW | |
| Battery | | 12V, 150 Ah x 2 | |

(): Low Profile Rops Cab



| Model | | GD 705A-4 | |
|---------------------------|----------------------------|--------------|---------------|
| Serial Numbers | | 21001 and up | 31001 and up |
| Weight | Operating weight (kg) | 17620 | 18880 (18840) |
| | On front axle (27.7%) (kg) | 4885 | 5110 (5100) |
| | On rear axle (72.3%) (kg) | 12735 | 13770 (13740) |
| Dimensions | Overall length (mm) | 9270 | 9270 |
| | Overall width (mm) | 2800 | 2830 |
| | Overall height (mm) | 3365 | 3530 (3355) |
| | Wheel base (mm) | 6450 | 6450 |
| | Rear wheel base (mm) | 1730 | 1730 |
| | Tread (Front) (mm) | 2300 | 2300 |
| | Tread (Rear) (mm) | 2300 | 2300 |
| | Ground clearance (mm) | 410 | 410 |
| Performance | Travel speed | 1st (km/h) | 3.9 |
| | | 2nd (km/h) | 5.2 |
| | | 3rd (km/h) | 7.6 |
| | | 4th (km/h) | 11.0 |
| | | 5th (km/h) | 15.2 |
| | | 6th (km/h) | 20.5 |
| | | 7th (km/h) | 30.0 |
| | | 8th (km/h) | 43.0 |
| | Reverse | 1st (km/h) | 4.1 |
| | | 2nd (km/h) | 5.6 |
| | | 3rd (km/h) | 8.1 |
| | | 4th (km/h) | 11.7 |
| | | 5th (km/h) | 16.2 |
| | | 6th (km/h) | 21.8 |
| | | 7th (km/h) | 31.9 |
| | | 8th (km/h) | 45.9 |
| Maximum drawbar pull (kg) | | 10180 | 11010 (10990) |
| Turning radius (m) | | 7.5 | 7.5 |
| Over turn angle (°) | | 35 | 35 |

| Model | | GD705A-4 | |
|--------------------------------------|--|--|----------------|
| Serial Number | | 21001 and up | 31001 and up |
| Wheels | Tire (Front) | 16.00 – 24 – 12 PR (2.2 kg/cm ²) | |
| | Tire (Rear) | 16.00 – 24 – 12 PR (2.2 kg/cm ²) | |
| | Rim (Front) | 1000 VA x 24 SDC | |
| | Rim (Rear) | 1000 VA x 24 SDC | |
| Blade | Blade dimension (mm) (Length x Height x Thickness) | 4320 x 700 x 25 | |
| | Cutting edge dimension (mm) (Number – Length x Width x Thickness) | 2 – 2134 x 203 x 16 | |
| | Turning angle (°) | 360 | |
| | Cutting angle | | |
| | [Standard] (°) | 34 | |
| | [Maximum] (°) | 84 | |
| | [Minimum] (°) | 26 | |
| Engine model type | | Komatsu S6D 125-1 Diesel Engine 4-cycle, water-cooled, overhead valve, direct injection type with turbocharger | |
| Cylinder number – bore x stroke (mm) | | 6 – 125 x 150 | |
| Piston displacement (cc) | | 11040 | |
| Firing order | | 1 – 5 – 3 – 6 – 2 – 4 | |
| Dimension | Overall length (mm) | 1556 | |
| | Overall width (mm) | 877 | |
| | Overall height (mm) | 1703 | |
| Performance | Flywheel horsepower (HP/rpm) | 200/2000 | |
| | Maximum torque (kgm/rpm) | 92/1300 | |
| | High idling (rpm) | 2200 ± 50 | |
| | Low idling (rpm) | 650 ⁺⁵⁰ ₀ | |
| | Fuel consumption ratio (g/HP.h) | 152 | |
| Dry weight (kg) | | 1175 | |
| Fuel oil | | Diesel fuel ASTM D975 No. 2 or No. 1 | |
| Fuel pump | | Bosch PE-P type | |
| Governor | | Bosch RSV centrifugal, all-speed type | |
| Alternator | | 24V, 35A | 24V, 60A |
| Starting motor | | 24V, 7.5 kW | 24V, 11 kW |
| Battery | | 12V, 200Ah x 2 | 12V, 200Ah x 2 |

ENGINE ASSEMBLY


KOMATSU 6D125-1 (GD705R-4)

- Left side view




F23E04002

- Right side view




F23E04003

- Front side view



F23E04004


- Rear side view



F23E04005


KOMATSU S6D125-1 (GD705A-4)

- Left side view




F23404007-1

- Right side view




F23404006-1

- Front side view



F23404006-2

- Rear side view



F23404007-2

WEIGHT TABLE

This weight table is a guide for use when transporting or handling components.

(): GD705A-4 Serial No. 31001 and up Unit: kg

| Model | GD705R-4 | GD705A-4 |
|--|--------------|--------------|
| Serial Numbers | 16001 and up | 21001 and up |
| Engine assembly (dry) | 1300 | 1175 |
| Radiator assembly (dry) | 85 | 132 |
| Fuel tank assembly (dry) | 175 | 256 |
| Transmission (dry) | 805 | 950 |
| Final drive assembly | 940 | 1154 |
| Tandem drive assembly (each) | 900 x 2 | 1029 x 2 |
| Front axle assembly (except leaning cylinder) | 475 | 640 |
| Parking brake | 17 | 25 |
| Frame assembly | 3400 | 3160 |
| Front frame assembly | — | 1910 |
| Rear frame assembly | — | 1250 |
| Operator's compartment assembly (inc. control) | 250 | 260 (350) |
| ROPS canopy assembly | — | — (800) |
| Drawbar assembly | 1010 | 1735 |
| Blade assembly | 900 | 849 |
| Lifter assembly | | 334 |
| Circle rotation assembly | 95 | 176 |
| Wheel assembly | 160 x 6 | 235 x 6 |
| Power tilt cylinder assembly | — | 41 |
| Leaning cylinder assembly | 15 | 23 |
| Blade lift cylinder assembly | 55 | 63 |


Unit: kg

| Model | GD705R-4 | | GD705A-4 | |
|---|--------------|---|--------------|----|
| Serial Numbers | 16001 and up | | 21001 and up | |
| Drawbar shift cylinder assembly | 30 | | 43 | |
| Blade side shift cylinder assembly | 45 | | 72 | |
| Steering cylinder | 8 | | 11 | |
| Articulate cylinder | — | | 44 | |
| Ripper cylinder (dry) | — | | 105 | |
| Scarifier cylinder assembly (If equipped) | 30 | | — | |
| Scarifier assembly (If equipped) | 520 | | — | |
| Hydraulic tank (dry) | 60 | | 64 | |
| Hydraulic pump | SAR020 + 020 | 6 | SAR050 + 050 | 14 |
| | | | SAL050 | 6 |
| Steering pump | LAR016 | 3 | SAR032 | 5 |
| Transmission pump | SAL045 | 6 | SAL050 | 6 |
| Circle rotation motor | 10 | | 19 | |


SERIAL NUMBER LOCATIONS

GD705R-4


● Leaning cylinder No.




● Steering cylinder No.




● Circle rotation gear No.



● Circle rotation motor No.




● Blade lift cylinder No.





● Drawbar shift cylinder No.



● Blade side shift cylinder No.




● Tandem drive case No.




F23BB001A

● Transmission No.




GD705A-4


● Leaning cylinder No.




● Steering cylinder No.



● Circle rotation gear No.




● Blade lift cylinder No.




● Circle rotation motor No.




● Blade side shift cylinder No.




● Power tilt cylinder No.




● Chassis No.





● Drawbar shift cylinder No.




● Articulate cylinder No.




● Tandem case No.



F23404002



● Transmission No.



● Air reservoir No.

LIST OF LUBRICANT AND WATER


Unit: ℓ

| MODEL | GD705R-4 | GD705A-4 | Remark |
|---|--------------|--------------|---|
| SERIAL NUMBERS | 16001 and up | 21001 and up | |
| Engine cooling system | 55 | 55 | Water |
| Fuel tank | 300 | 400 | Diesel fuel ASTM D975 No. 2 or No. 1 |
| Engine oil pan | 30 | 30 | Engine oil class CD SAE30, SAE10W SAE10W-30, SAE15W-40 |
| Hydroshift transmission case | 40 | 48 | Engine oil class CD SAE30 or SAE10W |
| Tandem drive case (each) | 36 | 105 | |
| Hydraulic tank (incl. hydraulic circuit) | 68 | 140 | Engine oil class CD SAE10W, SAE10W-30, SAE15W-40 |
| Final drive case | 30 | 40 | Gear oil SAE90 |
| Circle rotation gear case | 4 | 12 | |
| Brake fluid tank | 0.8 | — | Brake fluid SAE J-1703f |
| Hydromaster | 0.06 | — | Vacuum cylinder oil |

MOTOR GRADER DESCRIPTION


FUNCTION

The major functions of a motor grader are to level road surfaces and dig ditches of fixed shape. In terms of function, a grader can be likened to a gigantic carpenter's plane.



Carpenter's plane

230F001



Motor grader


230F002

STRUCTURAL FEATURES

Since the major purpose of a motor grader is levelling of ground surfaces, mainly by use of a blade, vertical and lateral movement should be kept to a minimum during travel.

For this reason, motor graders have a long wheel base with the blade assembly (1) mounted in the center. Consequently, the engine, transmission and driving gear are located at the rear of the machine. The driver's seat is positioned behind the blade assembly and above the transmission and drive gear.

The scarifier assembly (2) (If equipped) can either be behind or in front of the front wheels. All grader travel and work operations are controlled by a single operator in the driver's seat.



P23AB030

Road Levelling


When performing road levelling operations, the grader itself has to travel over uneven surfaces. To minimize the vertical movement in the chassis and blade assembly caused by this unevenness, the grader incorporates special structural features.

1. Large wheel base


When automobiles travel along an uneven road, those with a larger wheel base experience less vibration than those with a smaller wheel base. By designing motor graders with a large wheel base, vertical movement is kept to a minimum.

2. Blade assembly mounted in center of grader

When a bulldozer with the blade located at the front runs over a rock, the blade is lifted to a relatively large degree. With graders whose blade is located in the center, the vertical movement of the blade is only 1/4 that of the bulldozer blade lift.




230F003




230F004

3. Seesaw motion in front wheel axle

If one of the front wheels runs over a rock or dips into a hole, the seesaw motion of the front wheel axle about the center pin ensures that the blade assembly remains horizontal.




One wheel dips into a hole



One wheel runs over a rock 230F006

4. Rear wheel tandem mechanism

Motor graders have four rear wheels (two on the left and two on the right) working in tandem. This permits the two pairs of rear wheels to move vertically in respect to each other, thereby ensuring that all four drive wheels remain in contact with the ground when moving over uneven surfaces. In addition to minimizing driving force, this also minimizes the effect on the blade assembly levelling precision. In small graders (such as GD22), where turning radius is important, there is only a single pair of rear wheels.




230F007

Improved forward drive

1. Leaning mechanism

This mechanism shifts the front wheels to the left or right by utilizing a conical rolling action. By putting the front wheels at an angle according to the load on the blade, lateral slipping of the front wheels is reduced during operation, thereby facilitating easier forward drive.

The leaning mechanism also reduces the turning circle.




230F008

2. Non-differential reduction gear


Graders are often put to work on very rough surfaces and construction sites. To prevent zig-zagging due to loss of traction when slipping in mud and when there is a sudden change in the load applied to the blade, a differential gear has not been included. Although this may result in a little extra strain on the machine when turning corners, it does make forward drive easier.

GD705A includes a lock-unlock differential gear as an option.

Lock-unlock differential gear



230F009



230F010

ENGINE



11 STRUCTURE AND FUNCTION



| | |
|----------------------------|------|
| Engine mounting | 11-2 |
| Radiator | 11-4 |
| Fuel tank and piping | 11-6 |
| Accelerator control | 11-8 |

ENGINE MOUNTING


GD705R-4



F23B03003

- 1. Dust indicator
- 2. Air cleaner
- 3. Muffler
- 4. Mounting bolt
- 5. Main frame

GD705A-4




F23404003

- 1. Bracket
- 2. Lock plate
- 3. Plate
- 4. Shim
- 5. Plate
- 6. Dust indicator

RADIATOR

GD705R-4




F23E04007

Radiator Core type: Model G6
 Total radiation area: 35.84 m²

- 1. Drain plug
- 2. Radiator core
- 3. Water filler cap
- 4. Inlet hose
- 5. Fan
- 6. Outlet hose

GD705A-4




F23E04008

Radiator Core type: Model G6
Total radiation area: 46.89 m²

- 1. Drain plug
- 2. Radiator core
- 3. Water filler cap
- 4. Inlet hose
- 5. Fan
- 6. Outlet hose

FUEL TANK AND PIPING

GD705R-4




F23E04009

Fuel tank capacity: 300 ℓ

1. Fuel tank
2. Fuel filler cap
3. Strainer
4. Fuel line valve
5. Drain cock

GD705A-4




F23E04010

Fuel tank capacity: 400 ℓ

- 1. Fuel tank
- 2. Fuel filler cap
- 3. Strainer
- 4. Fuel line valve
- 5. Drain cock

ACCELERATOR CONTROL

GD705R-4




F23E04011

OPERATION

When the accelerator pedal (3) is depressed it operates the engine governor through each linkage and sends the appropriate quantity of fuel to the injection pump. When the engine is at full rpm and the governor is contacting the stopper, if the accelerator pedal is depressed further, the governor or governor lever may be damaged. To prevent this a stopper bolt (4) is installed. The fuel control lever is to keep engine revolutions steady during operation.

1. Fuel control lever
2. Parking brake lever
3. Accelerator pedal
4. Stopper bolt
5. Accelerator return spring

GD705A-4




F23E04012

- 1. Fuel control lever
- 2. Parking brake lever
- 3. Accelerator pedal
- 4. Stopper bolt

ENGINE

12 TESTING AND ADJUSTING



| | |
|---|------|
| Testing and adjusting data | 12-2 |
| Testing and adjusting tool list | 12-3 |
| Testing and adjusting valve clearance | 12-4 |
| Measuring compression pressure | 12-5 |
| Measuring blow-by | 12-6 |
| Testing and adjusting fan belt tension | 12-6 |
| Testing and adjusting fuel injection timing | 12-7 |

TESTING AND ADJUSTING DATA

| Machine model | | | | GD705R-4 | | GD705A-4 | |
|---------------------------|---|---|-----------------------------|---------------------------------|----------------------|---------------------------------|----------------------|
| Engine model | | | | 6D125-1 | | S6D125-1 | |
| Classi- fica- tion | Item | Condition, etc. | Unit | Standard value | Permissible value | Standard value | Permissible value |
| Performance | Engine speed | High idling speed | rpm | 2100 ± 50 | — | 2200 ± 50 | — |
| | | Low idling speed | rpm | 650 ⁺⁵⁰ ₀ | — | 650 ⁺⁵⁰ ₀ | — |
| | Necessary starting speed | 0°C | rpm | Min. 100 | — | Min. 100 | — |
| | | -20°C (Using starting aid) | rpm | Min. 85 | — | Min. 85 | — |
| Intake and exhaust system | Intake resistance | All speed | mmH ₂ O | Max. 380 | 635 | Max. 180 | Max. 365 |
| | Intake pressure | All speed | mmHg | — | — | Max. 35 | Max. 45 |
| | Exhaust temperature | All speed (intake air temp.: 20°C) | °C | Max. 600 | 650 | Max. 600 | Max. 650 |
| | Exhaust gas color | Quick acceleration | Bolch scale | Max. 3.0 | 5.0 | Max. 4.0 | 5.5 |
| | | At high idling | | Max. 1.0 | 2.0 | Max. 1.0 | 2.0 |
| Valve clearance at 20°C | Intake valve | mm | 0.33 | — | 0.33 | 0.33 | |
| | Exhaust valve | mm | 0.71 | — | 0.71 | 0.71 | |
| Engine body | Compression pressure (SAE30) | Oil temperature: 40 – 60°C (Engine speed) | kg/cm ² (rpm) | 34 – 38 (200 – 250) | — | 32 – 36 (200 – 250) | — |
| | Blow-by pressure (SAE30) | At high idling (Water temperature operating range) | mmH ₂ O | Max. 50 | 100 | Max. 100 | 200 |
| Lubrication system | Oil pressure (SAE30, Oil temperature: Min. 80°C) | At high idling (Water temperature operating range) | kg/cm ² | 3.0 – 5.0 | Min. 1.8 | 3.5 – 5.5 | 2.0 |
| | | At low idling | kg/cm ² | Min. 1.3 | 0.8 | Min. 1.3 | 0.8 |
| | Oil temperature | All speed (Oil in oil pan) | °C | 90 – 115 | 120 | 95 – 115 | 120 |
| Oil consumption ratio | At continuous rated output (Ratio to fuel consumption) | % | Max. 0.5 | 1.0 | Max. 0.5 | 1.0 | |
| Fuel system | Fuel injection pressure | Nozzle tester | kg/cm ² | Min. 225 | 180 | 250 | 200 |
| | Fuel injection timing | B.T.D.C. | Degree | 22 ± 1 | — | 26 ± 1 | 26 ± 1 |
| Cooling system | Radiator pressure valve function | Opening pressure (Differential pressure) | kg/cm ² | 0.7 ± 0.1 | — | 0.7 ± 0.1 | 0.7 ± 0.1 |
| | Fan speed | At rated rpm | rpm | 1850 | 1757 | — | — |
| | | At high idling speed | | — | — | 1700 | 1615 |
| Fan belt tension | Deflect when pushed with a force of 6 kg | mm | 13 | 10 – 16 | 13 | 10 – 16 | |

TESTING AND ADJUSTING TOOL LIST

| No. | Testing and measuring item | Fault finding tool | Part No. | Remarks |
|-----|--|---------------------------------|------------------------|---|
| 1 | Engine speed | Multi-tachometer | 799-203-8000 | Digital reading, pressure sensing type 60 – 19,999 rpm |
| 2 | Battery S.G. | Battery coolant tester | 795-500-1000 | 1.100 – 1.300 |
| 3 | Freezing temperature of cooling water | | | –5 to –50°C |
| 4 | Water temperature, oil temperature, air intake temperature | Thermistor temperature gauge | 790-500-1300 | 0 – 200°C |
| 5 | Exhaust temperature | | | 0 – 1,000°C |
| 6 | Lubrication oil pressure | Engine pressure measuring kit | 799-203-2002 | 0 – 10 kg/cm ² |
| 7 | Fuel pressure | | | 0 – 20 kg/cm ² |
| 8 | Intake pressure, exhaust pressure | | | 0 – 1,500 mmHg |
| 9 | Blow-by pressure | | | 0 – 1,000 mmH ₂ O |
| 10 | Intake resistance | | | –1,000 – 0 mmH ₂ O |
| 11 | Compression pressure | Compression gauge | 795-502-1203 | 0 – 70 kg/cm ² |
| | | Adapter | 795-502-1360 | |
| 12 | Blow-by pressure | Blow-by checker | 799-201-1503 | 0 – 500 mmH ₂ O |
| 13 | Valve clearance | Feeler gauge | 795-125-1360 | Intake 0.33 mm, Exhaust 0.71 mm |
| 14 | Exhaust gas color | Handy smoke checker | 799-201-9000 | Dirtiness 0 – 70% with standard color (Dirtiness % x 1/10 = Bosch scale) |
| 15 | Water and fuel content in oil | Engine oil checker | 799-201-6000 | Provided with 0.1 and 0.2% water content standard samples |
| 16 | Fuel injection pressure Fuel injection nozzle spray condition | Nozzle tester | Commercially available | 0 – 300 kg/cm ² |
| 17 | Coolant quality | Water quality tester | 799-202-7001 | PH, nitrite ion concentration |
| 18 | Pressure valve function Leakage in cooling water system | Radiator cap tester | 799-202-9001 | 0 – 2 kg/cm ² |
| 19 | Radiator blockage (wing speed) | Anemometer (Air speed gauge) | 799-202-2001 | 0 – 40 m/s |
| 20 | Engine cranking | Cranking kit | 795-610-1000 | Engine with DC24V starting motor |
| 21 | Electrical circuits | Tester | Commercially available | Current, Voltage, Resistance |

TESTING AND ADJUSTING VALVE CLEARANCE

Special tool

| | Part number | Part name | Q'ty |
|---|--------------|--------------|------|
| A | 795-125-1360 | Feeler gauge | 1 |


★ Adjust clearance between rocker lever and top of crosshead to following value.

| Intake valve (at 20°C) | Exhaust valve (at 20°C) |
|------------------------|-------------------------|
| 0.33 mm | 0.71 mm |

- When adjusting the valve clearance for cylinders No. 3 to 6, remove air cleaner.
- Remove cylinder head cover.
- Rotate the crankshaft in the normal direction to align pointer (2) with the 1.6 TOP mark or crankshaft damper (1). When rotating, check the movement of the intake valves of No. 1 cylinder and No. 6 cylinder. Set with No. 1 cylinder at compression top dead center.
 - ★ When No. 1 cylinder is at compression top dead center, the intake valve of No. 6 cylinder opens.
- When No. 1 cylinder is at compression top dead center, adjust the valves marked ●. Then rotate the crankshaft one turn in the normal direction, set No. 6 cylinder to compression top dead center, and adjust the valves marked ○.

| Cylinder No. | 1 | 2 | 3 | 4 | 5 | 6 |
|---------------|---|---|---|---|---|---|
| Intake valve | ● | ● | ○ | ● | ○ | ○ |
| Exhaust valve | ● | ○ | ● | ○ | ● | ○ |

- To adjust, insert tool A between rocker lever (3) and crosshead (4) and turn adjustment screw (5) until clearance is a sliding fit.
- Tighten locknut (6) to hold adjustment screw in position.


 Locknut: 6.7 ± 0.7 kgm

★ After adjusting No. 1 cylinder at compression top dead center, it is also possible to turn the crankshaft 120° each time and adjust the valve clearance of each cylinder according to the firing order.




- Firing order: 1 – 5 – 3 – 6 – 2 – 4

★ After tightening the locknut, check the clearance again.

GD705R-4



GD705A-4



234F1141


MEASURING COMPRESSION PRESSURE

Special tools


| | Part number | Part name | Q'ty |
|---|--------------|-------------------|------|
| A | 795-502-1360 | Adapter | 1 |
| B | 795-502-1203 | Compression gauge | 1 |


★ Warm up the engine (oil temperature: 40 – 60°C) before measuring the compression pressure.



1. Adjust valve clearance.
2. Remove spill tube (1), then disconnect fuel injection tube (2) and remove nozzle holder assembly (3).
 - ★ When removing the nozzle holder assembly, use the mounting bolt of the spill pipe and lever the nozzle holder assembly out with a bar.
3. Install tool **A** in mount of nozzle holder assembly, and tighten to specified torque.

 **kgm** Mounting bolt: 2.2 ± 0.3 kgm


4. Connect tool **B** to adapter.
5. Place fuel control lever (4) in NO INJECTION position. Crank engine with starting motor and measure compression pressure.
 - ★ Measure the compression pressure at the point where the compression gauge indicator remains steady.
 - ★ If the adapter mount is coated with a small amount of oil, leakage is reduced.

 If the fuel control lever is not set to the NO INJECTION position, the engine will start.

 When measuring the compression pressure, be careful not to touch the exhaust manifold or muffler, or to get caught in rotating parts.




GD705R-4



P23E04010

GD705A-4



MEASURING BLOW-BY

Special tool

| | Part number | Part name | Q'ty |
|---|--------------|-----------------|------|
| A | 799-201-1503 | Blow-by checker | 1 |


1. Measuring blow-by

Connect tool A to breather hose.

- ★ Check that the oil filler and dipstick are properly sealed.


2. Precautions when measuring blow-by

- ★ Measure blow-by with the engine properly warmed up (oil temperature: 60°C) and running at rated output.
- When measuring in the field, a similar value will be obtained at stall speed.
- If it is impossible to run the engine at rated output or at stall speed, measure at high idling. The blow-by value obtained at high idling will be about 80% of the value at rated output.
- ★ Blow-by varies greatly according to the condition of the machine, so if the value obtained is considered abnormal, check for factors related to defective blow-by. These factors include excessive oil consumption, defective exhaust gas color, deterioration and early discoloration of oil.



TESTING AND ADJUSTING FAN BELT TENSION

- Check that the fan belt deflects by approx. 13 mm when pushed with a force of 6 kg. at a point midway between the alternator pulley and the crankshaft pulley.
- Adjusting fan belt tension
 - 1) Loosen adjustment bolt (1) and mounting bolt (2).
 - 2) Using a bar or pipe, raise alternator (3) and adjust tension of belt. Tighten adjustment bolt (1) and mounting bolt (2).
 - ★ Check the pulley groove and belt for wear. The belt must not be in contact with the bottom of the groove.
 - ★ Replace both belts if the belt is stretched so much that the tension cannot be adjusted, or if the belt is cut or cracked.




TESTING AND ADJUSTING FUEL INJECTION TIMING




When installing the fuel injection pump on the engine, test and adjust the fuel injection timing as follows.

- **Aligning match mark**
Use this method when the fuel injection pump is put back on the same engine without being repaired.
- **Delivery check method**
Use this method when replacing or installing a repaired fuel injection pump.
- ★ Set the No. 1 cylinder to top dead center when testing and adjusting.

1. Testing and adjusting by aligning match mark


- 1) Set the No. 1 cylinder to top dead center, then rotate the crankshaft $30^{\circ} - 40^{\circ}$ in the reverse direction. Next, rotate the crankshaft in the normal direction and align the fuel injection line on crankshaft damper (1) with pointer (2).
- 2) Check that line "a" on the injection pump and line "b" on the coupling are aligned.
 - ★ If the lines are not aligned, loosen nut (3). Move the coupling to align the lines, then tighten the nut.

 Nut: 6.2 ± 0.2 kgm




2. Testing and adjusting fuel injection timing by delivery check

- 1) Disconnect fuel injection tube (4) of No. 1 cylinder.
- 2) Remove delivery valve holder (5).



- 3) Remove spring (6) and delivery valve (7), then install delivery valve holder (5) again.
- 4) Place fuel control lever at FULL position, then operate priming pump and rotate crankshaft slowly in normal direction. Check point where fuel stops flowing from delivery valve holder.
- 5) Check that fuel injection timing line on crankshaft damper and pointer are aligned at point where fuel stops flowing.
 - ★ BEYOND injection timing line:
Timing RETARDED
 - ★ BEFORE injection timing line:
Timing ADVANCED




234P1119

3. If the test shows that the fuel injection timing is incorrect, adjust as follows.

- 1) Set the No. 1 cylinder to top dead center, then rotate the crankshaft 30° – 40° in the reverse direction.
- 2) Next, rotate the crankshaft in the normal direction and align the fuel injection line on the crankshaft damper with the pointer correctly.
- 3) Loosen nut (3) in oblong hole of mounting flange of fuel injection pump. Operate priming pump and rotate flange at pump end a little at a time. Stop at point where fuel stops flowing from delivery valve holder.
- 4) Tighten nut in oblong hole of mounting flange of fuel injection pump.
 - ★ After tightening the nut, check again that the fuel injection timing is correct.

ENGINE

13 DISASSEMBLY AND ASSEMBLY



| | |
|--|-------|
| ALTERNATOR ASSEMBLY | |
| Removal and installation | 13- 2 |
| STARTING MOTOR ASSEMBLY | |
| Removal and installation | 13- 4 |
| OIL COOLER ASSEMBLY | |
| Removal and installation | 13- 4 |
| HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY | |
| Removal and installation | 13- 6 |
| WATER PUMP ASSEMBLY | |
| Removal and installation | 13- 8 |
| FUEL INJECTION PUMP ASSEMBLY | |
| Removal and installation | 13-10 |
| AIR COMPRESSOR ASSEMBLY | |
| Removal and installation | 13-12 |
| TURBOCHARGER ASSEMBLY | |
| Removal and installation | 13-13 |
| NOZZLE HOLDER ASSEMBLY | |
| Removal and installation | 13-14 |
| CYLINDER HEAD ASSEMBLY | |
| Removal | 13-16 |
| Installation | 13-22 |
| RADIATOR ASSEMBLY | |
| Removal | 13-44 |
| Installation | 13-46 |
| FUEL TANK ASSEMBLY (incl. HYDRAULIC TANK) | |
| Removal | 13-52 |
| Installation | 13-54 |
| ENGINE ASSEMBLY (incl. TRANSMISSION) | |
| Removal | 13-60 |
| Installation | 13-67 |



REMOVAL OF ALTERNATOR ASSEMBLY

GD705R-4



Disconnect the lead from the negative (–) terminal of the battery.

1. Disconnect wire (1) of water temperature gauge and wire (2) of alternator.
2. Disconnect tubes (3), (4) and (5) of vacuum pump.
3. Remove adjustment bolt (6), then loosen mounting bolt (7).
4. Move alternator assembly (8) towards block, and remove belt (9).
5. Remove mounting bolt, then remove alternator assembly.



INSTALLATION OF ALTERNATOR ASSEMBLY

GD705R-4

1. Install alternator assembly (8), then temporarily tighten mounting bolt (7).
2. Install belt (9), then temporarily tighten adjustment bolt (6).
3. Adjust belt tension.
 - ★ For details, see TESTING AND ADJUSTING.
4. Tighten bolts (6) and (7) fully.
5. Fit gaskets and connect tubes (5), (4) and (3) of vacuum pump.
6. Connect wire (2) of alternator, and wire (1) of water temperature gauge.
7. Connect lead to negative (–) terminal of battery.



REMOVAL OF ALTERNATOR ASSEMBLY

GD705A-4



Disconnect the cable from the negative (–) terminal of the battery.


1. Disconnect L.H. engine side cover.
2. Disconnect wire (1) of water temperature gauge.
3. Disconnect wires (2), (3) and (4) of alternator.
4. Remove adjustment bolt (5), then loosen mounting bolt and nut (6).
5. Move alternator assembly inside, and remove fan belt (7) from pulley groove.
6. Remove mounting bolt and nut (6), then remove alternator assembly (8).



INSTALLATION OF ALTERNATOR ASSEMBLY

GD705A-4

1. Install alternator assembly (8), then temporarily tighten mounting bolt and nut (6).
2. Fit fan belt (7) on pulley.
3. Temporarily install mounting bolt (5) of adjustment plate. Raise alternator assembly to outside and adjust belt tension.
 - ★ For details, see TESTING AND ADJUSTING.
4. Tighten mounting bolt and nut (6), and adjustment bolt (5) fully.
5. Connect wires (4), (3) and (2) of alternator.
6. Connect wire (1) of water temperature gauge.
7. Install L.H. engine side cover.
8. Connect cable to negative (–) terminal of battery.




REMOVAL OF STARTING MOTOR ASSEMBLY




Disconnect the cable from the negative (–) terminal of the battery.

1. Remove L.H. engine side cover.
2. Disconnect wires (1) and (2).
3. Remove starting motor assembly (3).




INSTALLATION OF STARTING MOTOR ASSEMBLY

1. Fit gasket and install starting motor assembly (3).
2. Connect wires (2) and (1).
3. Install L.H. engine side cover.
4. Connect cable to negative (–) terminal of battery last.



REMOVAL OF OIL COOLER ASSEMBLY

1. Remove hydroshift transmission oil cooler assembly.
For details, see 13 REMOVAL OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY.
2. Disconnect ground connection (1).
3. Remove oil cooler assembly (2).





INSTALLATION OF OIL COOLER ASSEMBLY

1. Fit gasket and install oil cooler assembly (2).
2. Connect ground connection (1).
3. Install hydroshift transmission oil cooler assembly.
For details, see 13 INSTALLATION OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY.

REMOVAL OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY

GD705R-4


1. Loosen drain valve (1) and drain cooling water.
★ If the coolant contains antifreeze, dispose of it correctly.
2. Remove L.H. engine side cover.
3. Remove air bleed tube (2).
4. Remove water drain tube (3) of muffler.
5. Remove inlet and outlet tubes (4) and (5) of oil cooler.
6. Remove brackets (6) and (7).
7. Remove oil cooler assembly (8).



INSTALLATION OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY

GD705R-4

1. Fit gasket and install oil cooler assembly (8).
 2. Secure oil cooler assembly with brackets (7) and (6).
 3. Fit O-rings and install inlet and outlet tubes (5) and (4) of oil cooler.
 4. Install water drain tube (3) of muffler.
 5. Install air bleed tube (2).
 6. Install L.H. engine side cover.
 7. Tighten drain valve (1) and add water through water filler to the specified level.
- ★ Run the engine to circulate the water through the system.
Then check the water level again.





REMOVAL OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY

GD705A-4



Disconnect the cable from the negative (–) terminal of the battery.



1. Loosen drain valve (1) and drain cooling water.
 - ★ If the coolant contains antifreeze, dispose of it correctly.
2. Remove L.H. engine side cover.
3. Disconnect wire (2) of water temperature gauge and wire (3), (4) and (5) of alternator.
4. Remove air bleed tube (6).
5. Disconnect inlet and outlet tubes (7) and (8) of oil cooler.
6. Remove brackets (9) and (10).
7. Remove oil cooler assembly (11).



INSTALLATION OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY

GD705A-4



1. Fit gasket and install oil cooler assembly (11).
2. Secure oil cooler assembly with brackets (10) and (9).
3. Fit O-rings and connect inlet and outlet tubes (8) and (7) of oil cooler.
4. Install air bleed tube (6).
5. Connect wires (5), (4) and (3) of alternator and wire (2) of water temperature gauge.
6. Install L.H. engine side cover.
7. Connect cable to negative (–) terminal of battery.
8. Tighten drain valve (1) and add water through water filler to the specified level.
- ★ Run the engine to circulate the water through the system. Then check the water level again.



REMOVAL OF WATER PUMP ASSEMBLY

GD705R-4



1. Loosen drain valve (1) and drain cooling water.
★ If the coolant contains antifreeze, dispose of it correctly.
2. Remove L.H. engine side cover.
3. Disconnect tubes (2), (3) and (4) of vacuum pump.
4. Remove vacuum pump assembly (5).
5. Remove hydroshift transmission oil cooler assembly.
For details, see 13 REMOVAL OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY.
6. Disconnect radiator outlet hose (6).
7. Disconnect bypass tube (7) at hose.
8. Remove 3 mounting bolts (8), then remove water pump assembly (9).



INSTALLATION OF WATER PUMP ASSEMBLY

GD705R-4


1. Fit gasket and install water pump assembly (9), then tighten 3 mounting bolts (8).
 2. Connect bypass tube (7) at hose, then secure with hose clamp.
 3. Connect radiator outlet hose (6).
 4. Install hydroshift transmission oil cooler assembly.
For details, see 13 INSTALLATION OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY.
 5. Fit gasket and install vacuum pump assembly (5).
 6. Fit gaskets and connect tubes (4), (3) and (2) of vacuum pump.
 7. Install L.H. engine side cover.
 8. Tighten drain valve (1) and add water through water filler to the specified level.
- ★ Run the engine to circulate the water through the system.
Then check the water level again.



REMOVAL OF WATER PUMP ASSEMBLY

GD705A-4



1. Remove hydroshift transmission oil cooler assembly.
For details, see 13 REMOVAL OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY.
2. Disconnect hose (1).
3. Disconnect radiator outlet hose (2).
4. Disconnect bypass tube (3) at hose.
5. Remove 3 mounting bolts (4), then remove water pump assembly (5).



INSTALLATION OF WATER PUMP ASSEMBLY

GD705A-4



1. Fit gasket and install water pump assembly (5), then tighten 3 mounting bolts (4).
2. Connect bypass tube (3) at hose, then secure with hose clamp.
3. Connect radiator outlet hose (2).
4. Connect hose (1).
5. Install hydroshift transmission oil cooler assembly.
For details, see 13 INSTALLATION OF HYDROSHIFT TRANSMISSION OIL COOLER ASSEMBLY.



REMOVAL OF FUEL INJECTION PUMP ASSEMBLY


GD705R-4



- ★ Close the fuel supply lever to stop the supply of fuel.
- 1. Remove R.H. engine side cover.
- 2. Remove spring (1), then disconnect fuel control cable (2).
- 3. Disconnect 2 connector hoses (3) of fuel filter, and fuel return hose (4).
- 4. Remove fuel supply tube (5).
- 5. Remove lubrication tubes (6) and (7).
- 6. Disconnect fuel injection tube (8).
- 7. Remove 4 mounting bolts (9) of fuel injection pump.
- 8. Remove 2 mounting bolts (10) of drive shaft.
- 9. Remove fuel injection pump assembly (11).



INSTALLATION OF FUEL INJECTION PUMP ASSEMBLY

GD705R-4

- 1. Fit fuel injection pump assembly (11) on bracket, then set in mounting position.
- 2. Tighten 2 mounting bolts (10) of drive shaft.
- 3. Tighten 4 mounting bolts (9) of fuel injection pump.
 - ★ Tighten the mounting bolts uniformly in turn.
- 4. Connect fuel injection tube (8).
 -  Sleeve nut: 3.0 ± 1.0 kgm
- 5. Fit gaskets and install lubrication tubes (7) and (6).
- 6. Fit gasket and install fuel supply tube (5).
- 7. Fit gaskets and connect fuel return hose (4), and 2 connector hoses (3) of fuel filter.
- 8. Connect fuel control cable (2), secure with locknut, then install spring (1).
- 9. Install R.H. engine side cover.





REMOVAL OF FUEL INJECTION PUMP ASSEMBLY

GD705A-4


- ★ Close the fuel supply lever at the bottom of the fuel tank to stop the supply of fuel.



1. Remove R.H. engine side cover.
2. Remove spring (1), then disconnect fuel control cable (2).
3. Disconnect fuel hoses (3) and (4), and fuel return hose (5).
4. Remove fuel supply tube (6).
5. Disconnect fuel injection tube (7).
6. Remove lubrication tubes (8) and (9).
7. Remove 4 mounting bolts (10) of fuel injection pump.
8. Remove 2 mounting bolts (11) of drive shaft.
9. Remove fuel injection pump assembly (12).



INSTALLATION OF FUEL INJECTION PUMP ASSEMBLY

GD705A-4



1. Fit fuel injection pump assembly (12) on bracket, then set in mounting position.
2. Tighten 2 mounting bolts (11) of drive shaft.
3. Tighten 4 mounting bolts (10) of fuel injection pump.
 - ★ Tighten the mounting bolts uniformly in turn.
4. Fit gaskets and install lubrication tubes (9) and (8).
5. Connect fuel injection tube (7).
 -  Sleeve nut: 3.0 ± 1.0 kgm
6. Fit gaskets and install fuel supply tube (6).
7. Fit gaskets and connect fuel return hose (5), and fuel hoses (4) and (3).
8. Connect fuel control cable (2), secure with locknut, then install spring (1).
9. Install R.H. engine side cover.



REMOVAL OF AIR COMPRESSOR ASSEMBLY

GD705A-4


1. Loosen drain valve (1) and drain cooling water.
 - ★ If the coolant contains antifreeze, dispose of it correctly.
2. Remove fuel injection pump assembly.
For details, see 13 REMOVAL OF FUEL INJECTION PUMP ASSEMBLY.
3. Disconnect air hoses (2) and (3), and suction hose (4).
4. Remove lubrication tube (5) and cooling tubes (6) and (7).
5. Remove air compressor assembly (8).



INSTALLATION OF AIR COMPRESSOR ASSEMBLY

GD705A-4

1. Fit O-ring and install air compressor assembly (8).
 2. Fit gasket and install cooling tubes (7) and (6), and lubrication tube (5).
 3. Connect suction hose (4) and air hoses (3) and (2).
 4. Install fuel injection pump assembly.
For details, see 13 INSTALLATION OF FUEL INJECTION PUMP ASSEMBLY.
 5. Tighten drain valve (1) and add water through water filler to the specified level.
- ★ Run the engine to circulate the water through the system. Then check the water level again.





REMOVAL OF TURBOCHARGER ASSEMBLY

GD705A-4



Disconnect the cable from the negative (–) terminal of the battery.


1. Remove hood.
2. Remove muffler assembly (1).
3. Disconnect wire (2) of electric heater, then remove connector pipe (3).
4. Disconnect oil supply tube (4).
5. Disconnect drain tube (5).
6. Disconnect hose (6), then remove turbocharger assembly (7).



INSTALLATION OF TURBOCHARGER ASSEMBLY

GD705A-4

1. Fit gasket and install turbocharger assembly (7), then connect hose (6).
2. Fit gasket and connect drain tube (5).
3. Fit gasket and connect oil supply tube (4).
4. Fit gasket and install connector pipe (3), then connect wire (2) of electric heater.
5. Fit seal ring and install muffler assembly (1).
6. Install hood.
7. Connect cable to negative (–) terminal of battery.





REMOVAL OF NOZZLE HOLDER ASSEMBLY

GD705R-4



Disconnect the lead from the negative (–) terminal of the battery.


1. Remove L.H. and R.H. engine side covers.
2. Lift off hood.
3. Disconnect wire (1) of electric heater.
4. Disconnect dust indicator hose (2).
5. Remove air cleaner assembly (3) together with connector pipe (4).
6. Disconnect fuel injection tube (5).
7. Remove spill tube (6).
8. Using a bar, remove nozzle holder assembly (7).
 - ★ When removing the nozzle holder, clean around the nozzle holder and fit a blind plug to prevent dust or dirt from entering.






INSTALLATION OF NOZZLE HOLDER ASSEMBLY

GD705R-4

1. Fit O-ring and install nozzle holder assembly (7).
 - ★ Tighten the nozzle holder mounting bolts uniformly.

 Mounting bolt: 2.2 ± 0.3 kgm

2. Fit gasket and install spill tube (6).
3. Connect fuel injection tube (5).
 -  Sleeve nut: 3.0 ± 1.0 kgm
4. Install air cleaner assembly (3) together with connector pipe (4).
5. Connect dust indicator hose (2).
6. Connect wire (1) of electric heater.
7. Install hood.
8. Install L.H. and R.H. engine side covers.
9. Connect lead to negative (–) terminal of battery.





REMOVAL OF NOZZLE HOLDER ASSEMBLY

GD705A-4



Disconnect the cable from the negative (–) terminal of the battery.



1. Remove left and right engine side covers.
2. Lift off hood.
3. Remove air cleaner assembly (1).
4. Remove wire (2) of electric heater, then remove connector pipe (3).
5. Disconnect fuel injection tube (4).
6. Remove spill tube (5).
7. Using a bar, remove nozzle holder assembly (6).
 - ★ When removing the nozzle holder, clean around the nozzle holder and fit a blind plug to prevent dust or dirt from entering.
 - ★ Mark the nozzle holders with tags showing the cylinder no. and keep in a safe place. If there is no abnormality in the nozzle holder, install in the same position when assembling.




INSTALLATION OF NOZZLE HOLDER ASSEMBLY

GD705A-4



1. Fit O-ring and install nozzle holder assembly (6).
 - ★ Tighten the nozzle holder mounting bolts uniformly.

 Mounting bolt: 2.2 ± 0.3 kgm
2. Fit gasket and install spill tube (5).
3. Connect fuel injection tube (4).
 - ★  Sleeve nut: 3.0 ± 1.0 kgm
4. Install connector pipe (3), then connect wire (2) of electric heater.
5. Install air cleaner assembly (1).
6. Install hood.
7. Install left and right engine side covers.
8. Connect cable to negative (–) terminal of battery.



REMOVAL OF CYLINDER HEAD ASSEMBLY

GD705R-4



F23E04013




Disconnect the lead from the negative (–) terminal of the battery.

1. Draining cooling water

Loosen drain valve (1) and drain cooling water.

- ★ If the coolant contains antifreeze, dispose of it correctly.



2. Side covers, hood


- 1) Remove L.H. and R.H. engine side covers.
- 2) Lift off hood.

3. Wiring of water temperature gauge

Disconnect wire (2) of water temperature gauge.


4. Air bleed tube

Remove air bleed tube (3).




5. Oil filter assembly

Remove oil filter assembly (5) from intake manifold.




6. Fuel filter assembly

Remove fuel filter assembly (6) from intake manifold assembly.




7. Wiring of electrical heater

Disconnect wire (7) of electrical heater.

**8. Dust indicator hose**

Disconnect dust indicator hose (8).

**9. Radiator hoses**


Disconnect radiator inlet hose (9) and aeration hose (10).

10. Corrosion hoses


Disconnect 2 corrosion hoses (11) from water manifold.

11. Bracket

Remove bracket (12).


**12. Air cleaner, intake manifold assembly**

Remove intake manifold assembly (13) together with air cleaner and connector pipe assembly (14).




13. Muffler, exhaust manifold assembly


Remove exhaust manifold assembly (15) together with muffler assembly (16).

**14. Water manifold assembly**

Remove water manifold assembly (17).

**15. Nozzle holder assembly**


Remove nozzle holder assembly (18).
For details, see 13 REMOVAL OF NOZZLE HOLDER ASSEMBLY.

**16. Cylinder head cover**

Remove cylinder head cover (19).


17. Rocker lever

Remove mounting bolts (20), then remove rocker lever (21).




18. Rocker lever housing


Remove rocker lever housing (22).

**19. Push rod**


Remove push rod (23).

**20. Crosshead**

Remove crosshead (24).


**21. Cylinder head assembly**

Remove mounting bolts (25), then remove cylinder head assembly (26).



INSTALLATION OF CYLINDER HEAD ASSEMBLY


GD705R-4



F23E04014

Special tool


| | Part number | Part name | Q'ty |
|---|--------------|--------------|------|
| A | 795-125-1360 | Feeler gauge | 1 |



- ★ Remove all carbon and dirt from the contact surfaces of the cylinder block and cylinder head. Remove all burrs and damage, and clean out all dirt from inside the cylinder block.

1. Cylinder head assembly


- 1) Install cylinder head gasket.
- 2) Install cylinder head assembly (26).
- 3) Tighten mounting bolts (25).

 Coat the bolt thread and the under part of the bolt head with antifriction agent (LM-P) before tightening.


- ★ First, screw in the mounting bolts by hand at least 2 to 3 times, then tighten as follows. (Bolts ① to ⑥.)

- 1st step: 10 ± 1 kgm
- 2nd step: 14 ± 0.5 kgm
- 3rd step: Put a mark on the bolt and head, then turn the bolt $90^\circ \pm 15^\circ$

- ★ Tighten bolt ⑦ to 6.7 ± 0.7 kgm



Mark on the bolt and head.





2. Crosshead

Install crosshead (24).

6150F315

- ★ Adjust the crosshead as follows.
 - i) Loosen locknut, then loosen adjustment screw.
 - ii) Hold top of crosshead lightly with finger and tighten adjustment screw.
 - iii) When adjustment screw touches valve system, tighten a further 20° .
 - iv) Hold adjustment screw and tighten locknut.


 Locknut: 3.8 ± 0.35 kgm




3. Push rod


Install push rod (23).

- ★ Check that the push rod is fitted completely into the socket of the camshaft follower.

**4. Rocker lever housing**


Install rocker lever housing (22).


-  Mounting bolt: 6.7 ± 0.7 kgm

**5. Rocker lever**

Set rocker lever (21) in position, then tighten 12 mounting bolts (20).

- ★ Check that the ball of the adjustment screw is fitted properly into the socket of the push rod before tightening the mounting bolt.
- ★ Clean the oil hole before installing.

-  Mounting bolt: 6.7 ± 0.7 kgm

**6. Adjusting valve clearance**

Adjust valve clearance.

For details, see 12 ADJUSTING VALVE CLEARANCE.


7. Cylinder head cover

Fit gasket and install cylinder head cover (19).

8. Nozzle holder assembly


Install nozzle holder assembly (18).

For details, see 13 INSTALLATION OF NOZZLE HOLDER ASSEMBLY.




9. Water manifold assembly


Fit gasket and install water manifold assembly (17).

**10. Muffler, exhaust manifold assembly**

Fit gasket and install exhaust manifold assembly (15) together with muffler assembly (16).

**11. Air cleaner, intake manifold assembly**

Fit gasket and install intake manifold assembly (13) together with air cleaner and connector pipe assembly (14).

**12. Bracket**


Install bracket (12).

13. Corrosion hoses

Connect corrosion hoses (11) to water manifold.


14. Radiator hoses

Connect aeration hose (10) and radiator inlet hose (9).




15. Dust indicator hose


Connect dust indicator hose (8).

**16. Wiring of electrical heater**


Connect wire (7) of electrical heater.

**17. Fuel filter assembly**

Install fuel filter assembly (6).

**18. Oil filter assembly**

Install oil filter assembly (5).



19. Air bleed tube


Install air bleed tube (3).

20. Wiring of water temperature gauge

- 1) Connect wiring of water temperature gauge (2).
- 2) Connect lead to negative (-) terminal of battery.


21. Side covers, hood

- 1) Raise hood and install.
- 2) Install L.H. and R.H. engine side covers.

**22. Refilling with water**


Tighten drain valve and add water cooling water through water filler (27) to the specified level.


- ★ Run the engine to circulate the water through the system.
Then check the water level again.



REMOVAL OF CYLINDER HEAD ASSEMBLY

GD705A-4





234F1147



Disconnect the cable from the negative (–) terminal of the battery.


1. Draining water

Loosen drain valve (1) and drain cooling water.

★ If the coolant contains antifreeze, dispose of it correctly.


2. Side covers, hood

- 1) Remove left and right engine side covers.
- 2) Lift off hood.




3. Wiring, air bleed tube

- 1) Disconnect wire (2) of water temperature gauge.
- 2) Disconnect wires (3), (4) and (5) of alternator.
- 3) Remove air bleed tube (6).




4. Muffler

Lift off muffler assembly (7).



5. Dust indicator hose

Disconnect dust indicator hose (8).




6. Air cleaner


Remove air cleaner assembly (9).

7. Connector pipe


- 1) Disconnect wire (10) of electric heater.
- 2) Remove connector pipe (11).

**8. Turbocharger oil supply tube**


Remove oil supply tube (12).

**9. Compressor hose**

Disconnect compressor suction hose (13).


**10. Oil filter assembly**

Disconnect 2 oil hoses (14), remove oil filter assembly (15).



11. Fuel filter assembly

Remove fuel filter assembly (16).




12. Bracket

Remove bracket (17).


13. Corrosion hoses

Disconnect corrosion hoses (18) and (19) at water manifold end.



14. Turbocharger drain tube

Disconnect drain tube (20).




15. Fuel injection tube

Remove fuel injection tube (21).


16. Spill tube

Remove spill tube (22).




17. Intake manifold assembly


Remove intake manifold assembly (23) together with corrosion resistor assembly.

**18. Radiator hoses**


Disconnect radiator inlet hose (24) and aeration hose (25).

**19. Exhaust manifold assembly**

Remove exhaust manifold assembly (26) together with turbocharger assembly.

**20. Water manifold assembly**


Remove water manifold assembly (27).



21. Nozzle holder assembly

Remove nozzle holder assembly (28).


- ★ When removing the nozzle holder, clean around the nozzle holder and fit a blind plug to prevent dust or dirt from entering.
- ★ Mark the nozzle holders with tags showing the cylinder no. and keep in a safe place. If there is no abnormality in the nozzle holder, install in the same position when assembling.

**22. Cylinder head cover**


Remove cylinder head cover (29).

23. Rocker lever


Remove mounting bolts (30), then remove rocker lever (31).

**24. Rocker lever housing**

Remove rocker lever housing (32).


**25. Push rod**

Remove push rod (33).




26. Crosshead

Remove crosshead (34).


**27. Cylinder head assembly**


Remove mounting bolts (35), then remove cylinder head assembly (36).



INSTALLATION OF CYLINDER HEAD ASSEMBLY

GD705A-4





234F1148


Special tool

| | Part No. | Part Name | Q'ty |
|---|--------------|--------------|------|
| A | 795-125-1360 | Feeler gauge | 1 |


- ★ Remove all carbon and dirt from the contact surfaces of the cylinder block and cylinder head. Remove all burrs and damage, and clean out all dirt from inside the cylinder block.

1. Cylinder head assembly




- 1) Install cylinder head gasket.
- 2) Install cylinder head assembly (36).
- 3) Tighten mounting bolts (35).

 Coat the bolt thread and the under part of the bolt head with antifriction compound (LM-P) before tightening.

- ★ First, screw in the mounting bolts by hand 2 to 3 times, then tighten as follows. (Bolts ① to ⑥)

 **kgm** 1st step: 10 ± 1 kgm
 2nd step: 14 ± 0.5 kgm
 3rd step: Put a mark on the bolt and cylinder head, then turn the bolt $90^\circ \pm 15^\circ$

- ★ Tighten bolt ⑦ to 6.7 ± 0.7 kgm





6150F315

2. Crosshead

Install crosshead (34).

- ★ Adjust the crosshead as follows.
 - i) Loosen locknut, then loosen adjustment screw.
 - ii) Hold top of crosshead lightly with fingers and tighten adjustment screw.
 - iii) When adjustment screw touches valve stem, tighten a further 20° .
 - iv) Hold adjustment screw and tighten locknut.


 **kgm** Locknut: 3.8 ± 0.35 kgm



3. Push rod


Install push rod (33).

- ★ Check that the push rod is fitted completely into the socket of the camshaft follower.

**4. Rocker lever housing**

Install rocker lever housing (32).


- ⤵ kgm Mounting bolt: 6.7 ± 0.7 kgm

**5. Rocker lever**

Set rocker lever (31) in position, then tighten 12 mounting bolts (30).

- ★ Check that the ball of the adjustment screw is fitted properly into the socket of the push rod before tightening the mounting bolt.
- ★ Clean the oil holes of the bolts before installing.

- ⤵ kgm Mounting bolt: 6.7 ± 0.7 kgm

**6. Adjusting valve clearance**

Adjust valve clearance. (For details, see 12 ADJUSTING VALVE CLEARANCE.)

7. Cylinder head cover

Fit gasket and install cylinder head cover (29).


8. Nozzle holder assembly

- ★ Check that there is no dirt or dust inside the sleeve of the nozzle holder.

Fit O-ring, install nozzle holder (28) in cylinder head, then tighten mounting bolts.


- ★ Tighten the nozzle holder mounting bolts uniformly.

- ⤵ kgm Mounting bolt: 2.2 ± 0.3 kgm




9. Water manifold assembly

Fit gasket and install water manifold assembly (27).




10. Exhaust manifold assembly

Fit gasket and install exhaust manifold assembly (26) together with turbocharger assembly.




11. Radiator hoses

Connect aeration hose (25) and radiator inlet hose (24).



12. Intake manifold assembly

Fit gasket and install intake manifold assembly (23) together with corrosion resistor assembly.





13. Spill tube

Fit gasket and install spill tube (22).


14. Fuel injection tube

Install fuel injection tube (21).

 Sleeve nut: 3.0 ± 1.0 kgm

**15. Turbocharger drain tube**


Fit gasket and connect drain tube (20).

**16. Corrosion hoses**


Connect corrosion hoses (19) and (18).

17. Bracket

Install bracket (17).


**18. Fuel filter assembly**

Install fuel filter assembly (16).




19. Oil filter assembly

Install oil filter assembly (15), then connect 2 oil hoses (14).




20. Compressor hose

Connect compressor suction hose (13).



21. Turbocharger oil supply tube

Install oil supply tube (12).




22. Connector pipe

- 1) Fit gasket and install connector pipe (11).
- 2) Connect wire (10) of electric heater.


23. Air cleaner

Install air cleaner assembly (9).




24. Dust indicator hose


Connect dust indicator hose (8).

**25. Muffler**

Fit seal ring and install muffler assembly (7).

**26. Wiring, air bleed tube**

- 1) Install air bleed tube (6).
- 2) Connect wires (5), (4) and (3) of alternator.
- 3) Connect wire (2) of water temperature gauge.
- 4) Connect cable to negative (-) terminal of battery.


**27. Side covers, hood**

- 1) Raise hood and install.
- 2) Install left and right engine side covers.

28. Refilling with water

Tighten drain valve (1) and add water through water filler to the specified level.


- ★ Run the engine to circulate the water through the system. Then check the water level again.




REMOVAL OF RADIATOR ASSEMBLY

GD705R-4


1. Loosen drain valve (1) and drain cooling water.
★ If the coolant contains antifreeze, dispose of it correctly.
2. Remove L.H. and R.H. engine side covers.
3. Lift off hood.




4. Disconnect wiring (2) at connector.



5. Disconnect aeration hose (3) and radiator inlet hose (4).
6. Remove fan guard (5).




7. Disconnect radiator outlet hose (6).



8. Lift off radiator mask (7).




9. Disconnect radiator drain hose (8).



10. Lift off radiator assembly (9).


$\frac{3}{4}$ kg Radiator assembly: 85 kg




INSTALLATION OF RADIATOR ASSEMBLY

GD705R-4


1. Raise radiator assembly (9) and install.




2. Connect radiator drain hose (8).




3. Raise radiator mask (7) and install.



4. Connect radiator outlet hose (6).




5. Install fan guard (5).
6. Connect radiator inlet hose (4) and aeration hose (3).



7. Connect wiring (2).
8. Raise hood and install.
9. Install L.H. and R.H. engine side covers.




10. Tighten drain valve and add cooling water through water filler (10) to the specified level.
- ★ Run the engine to circulate the water through the system.
Then check the water level again.




REMOVAL OF RADIATOR ASSEMBLY

GD705A-4


1. Loosen drain valve (1) and drain cooling water.
★ If the coolant contains antifreeze, dispose of it correctly.
2. Remove L.H. and R.H. engine side covers.
3. Lift off hood.




4. Disconnect wiring (2) at connector.




5. Disconnect hose (3), aeration hose (4) and radiator inlet hose (5).
6. Remove 2 left and right steering pipes (6).
7. Remove fan guard (7).




8. Disconnect drain hose (8).



- 9. Disconnect radiator outlet hose (9).




- 10. Lift off radiator mask (10).



- 11. Lift off radiator assembly (11).




Radiator assembly: 132 kg




INSTALLATION OF RADIATOR ASSEMBLY

GD705A-4


1. Raise radiator assembly (11) and install.




2. Raise radiator mask (10) and install.




3. Connect radiator outlet hose (9).




4. Connect drain hose (8).




5. Install fan guard (7).
6. Install 2 left and right steering pipes (6).
7. Connect radiator inlet hose (5), aeration hose (4) and hose (3).



8. Connect wiring (2).
9. Install hood.
10. Install L.H. and R.H. engine side covers.



11. Tighten drain valve and add water through water filler (12) to the specified level.
- ★ Run the engine to circulate the water through the system. Then check the water level again.



REMOVAL OF FUEL TANK ASSEMBLY (incl. HYDRAULIC TANK)

GD705R-4



Disconnect the lead from the negative (–) terminal of the battery.



Loosen oil filler cap (1) to release pressure inside hydraulic tank.

1. Remove drain plug (2) and drain oil from hydraulic tank.



Hydraulic tank: Approx. 27ℓ

2. Remove cover (4).





3. Remove tubes (5) and (6).

4. Disconnect hose (7).


5. Remove L.H. and R.H. engine side covers.

6. Lift off hood.


7. Remove cover (9).




8. Disconnect transmission filter hoses (10) and (11) from transmission control valve.
9. Close fuel supply lever (12), then disconnect fuel hose (13).



10. Disconnect fuel return hose (14).
11. Disconnect hydromaster air supply hose (15) from air cleaner.




12. Disconnect inlet tube of steering pump at hose (16).
13. Remove wiring behind fuel tank, and move it towards engine.



14. Install eye bolts (Thread dia. = 12 mm, Pitch = 1.75 mm), remove mounting bolts of frame, then lift off fuel tank and frame assembly (17).




Fuel tank assembly (incl. hydraulic tank):
450 kg (with 300ℓ of fuel)




INSTALLATION OF FUEL TANK ASSEMBLY (incl. HYDRAULIC TANK)

GD705R-4


1. Install eye bolts (Thread dia. = 12 mm, Pitch = 1.75 mm), raise fuel tank and frame assembly (17) and install.
2. Install wiring behind fuel tank, and connect lead to negative (-) terminal of battery.



3. Connect inlet tube of steering pump at hose (16), and secure with clamp.




4. Connect hydromaster air supply hose (15) to air cleaner, and secure with clamp.




5. Connect fuel return hose (14).

6. Connect fuel hose (13) and open fuel supply lever (12).


7. Connect transmission filter hoses (11) and (10).




8. Install cover (9).
9. Raise hood and install.
10. Install L.H. and R.H. engine side covers.



11. Connect hose (7), and secure with clamp.
12. Fit O-rings and install tubes (6) and (5).



13. Install cover (4).




14. Tighten drain plug (2).
15. Add engine oil through oil filler (1) to the specified level.



Hydraulic tank: 27ℓ

- ★ Run the engine to circulate the oil through the system. Then check the oil level again.



REMOVAL OF FUEL TANK ASSEMBLY (incl. HYDRAULIC TANK)

GD705A-4



Disconnect the cable from the negative (-) terminal of the battery.





Loosen oil filler cap (1) to release pressure inside hydraulic tank.

1. Remove drain plug (2) and drain oil from hydraulic tank.




Hydraulic tank: 70ℓ


2. Remove left and right engine side covers.
3. Lift off hood.
4. Remove cover (3).
5. Disconnect hose (4).




6. Disconnect hoses (5), (6), (7) and (8).




7. Remove stay (9) and cover (10).



8. Disconnect 2 transmission filter hoses (11).
9. Close fuel supply valve (12), then disconnect fuel supply hose (13).
10. Loosen clamp, and disconnect hose (14).




11. Disconnect fuel return hose (15).
12. Remove wiring behind fuel tank, and move it towards engine.



13. Lift off fuel tank assembly (16).




Fuel tank assembly (incl. hydraulic tank):
320 kg (dry weight)




INSTALLATION OF FUEL TANK ASSEMBLY (incl. HYDRAULIC TANK)

GD705A-4


1. Raise fuel tank assembly (16) and install.
2. Install wiring behind fuel tank, and connect cable to negative (-) terminal of battery.




3. Connect fuel return hose (15).




4. Connect hose (14), and secure with clamp.
5. Connect fuel supply hose (13), then open fuel supply valve (12).
6. Connect 2 transmission filter hoses (11).




7. Install cover (10) and stay (9).



8. Connect hoses (8), (7), (6) and (5).




9. Connect hose (4).



10. Install cover (3).
11. Raise hood and install.
12. Install left and right engine side covers.
13. Tighten drain plug (2).
14. Add engine oil through oil filler (1) to the specified level.




Hydraulic tank: 70ℓ



- ★ Run the engine to circulate the oil through the system.
Then check the oil level again.

REMOVAL OF ENGINE ASSEMBLY

GD705R-4



F23E04015




Disconnect the lead from the negative (–) terminal of the battery.

1. Draining cooling water

Loosen drain valve (1) and drain cooling water.

- ★ If the coolant contains antifreeze, dispose of it correctly.



2. Draining hydraulic oil and transmission oil




Loosen oil filler cap (2) to release pressure inside hydraulic tank.

- 1) Remove drain plug (3) and drain oil from hydraulic tank.




Hydraulic tank: Approx. 27ℓ



- 2) Remove drain plug (4) and drain oil from transmission case.



Transmission case: Approx. 30ℓ




3. Side covers, hood

- 1) Remove L.H. and R.H. engine side covers.
- 2) Remove L.H. and R.H. covers under fuel tank.
- 3) Lift off hood.


232P229

4. Wiring


- 1) Disconnect wires (5) and (6) of starting motor.
- 2) Disconnect wire (7) of oil temperature sensor.




- 3) Disconnect wire (8) of water temperature gauge.
- 4) Disconnect wire (9) of alternator.




- 5) Disconnect wire (10) of oil pressure gauge.



- 6) Disconnect wire (11) of electric heater.




- 5. **Fuel control cable**
Remove spring (12), then disconnect fuel control cable (13).



6. Dust indicator hose

Disconnect dust indicator hose (14).

**7. Outlet hoses of hydraulic pump**

Disconnect outlet hoses (15) and (16) of hydraulic pump.

8. Fuel tank assembly


Remove fuel tank assembly.

For details, see 13 REMOVAL OF FUEL TANK ASSEMBLY.


9. Radiator assembly

Remove radiator assembly.


For details, see 13 REMOVAL OF RADIATOR ASSEMBLY.

**10. Outlet hose of steering pump**


Disconnect outlet hose (17) of steering pump.

**11. Parking brake cable, speedometer cable**

1) Disconnect parking brake cable (19).



- 2) Disconnect speedometer (20).




12. Transmission control rod

- Disconnect transmission control rod (21).




13. F-R cable, inching cable

- 1) Loosen locknut (22).
- 2) Remove coupling (23), then disconnect F-R cable (24) and inching cable (25).




14. Transmission oil filler

- Remove transmission oil filler tube (26).




15. Vacuum hose


Disconnect hose (27) between vacuum pump and vacuum tank.

**16. Universal joint assembly**


Remove universal joint assembly (28).

**17. Support**


Remove mounting bolts (29) of support.

**18. Engine assembly**

- 1) Remove 4 mounting bolts (30) and 2 mounting bolts (31).



- 2) Sling engine assembly, then remove bracket (32).




- 3) Move engine assembly (33) to rear, then lift off.




Engine assembly (incl. transmission):
1970 kg

- ★ If the hydroshift transmission assembly is to be removed from the engine assembly (which includes the transmission assembly), remove the connecting bolts of the flywheel housing, then remove the hydroshift transmission.



INSTALLATION OF ENGINE ASSEMBLY

GD705R-4






Special tool

| | Part number | Part name | Q'ty |
|---|--------------|----------------|------|
| A | 792-271-2000 | Centering tool | 1 |


1. Engine assembly




- 1) Raise engine assembly (33), install bracket (32), then set on frame.

 Mounting bolt of bracket:
Thread tightener (LT-2)




- 2) Tighten mounting bolts (31) and (30).
 - ★ Tighten the mounting bolts fully after centering the engine.
- 3) Measure face and radial runout of engine as follows. Install tool A, then set dial gauge ③ in position. Rotate tool A, and measure face and radial runout between engine and transmission.
 - ★ Radial runout, face runout
- 4) Tighten mounting bolts to specified tightening torque.

 Mounting bolt: 39 ± 4 kgm





2. Support

Tighten mounting bolts (29) of support.


**3. Universal joint assembly**

Install universal joint (28).


 kgm Mounting bolt: 10 – 12.5 kgm

**4. Vacuum hose**

Connect hose (27) between vacuum pump and vacuum tank.


**5. Transmission oil filler**

Fit O-ring and install transmission oil filler tube (26).




6. F-R cable, inching cable


- 1) Connect inching cable (25) and F-R cable (24) to spool. Fit O-ring to coupling (23), then tighten cover.
- 2) Secure cable with locknut (22).

**7. Transmission control rod**


- 1) Connect transmission control rod (21).

**8. Parking brake cable, speedometer cable**

- 1) Connect speedometer cable (20).



- 2) Connect parking brake cable (19) and secure with locknut.



9. Outlet hose of steering pump

Connect outlet hose (17) of steering pump.

10. Radiator assembly


Install radiator assembly.

for details, see 13 INSTALLATION OF RADIATOR ASSEMBLY.


11. Fuel tank assembly

Install fuel tank assembly.


For details, see 13 INSTALLATION OF FUEL TANK ASSEMBLY.

**12. Outlet hoses of hydraulic pump**


Connect hoses (16) and (15) of hydraulic pump.

**13. Dust indicator hose**

Connect dust indicator hose (14).


**14. Fuel control cable**

Connect fuel control cable (13), secure with locknut, then install spring (12).




15. Wiring


- 1) Connect wire (11) of electric heater.




- 2) Connect wire (10) of oil pressure gauge.



- 3) Connect wire (9) of alternator.
- 4) Connect wire (8) of water temperature gauge.



- 5) Connect wire (7) of oil temperature sensor.
- 6) Connect wires (6) and (5) of starting motor.
- 7) Connect lead to negative (-) terminal of battery.



16. Side covers, hood


- 1) Raise hood and install.
- 2) Install L.H. and R.H. covers under fuel tank.
- 3) Install L.H. and R.H. engine side covers.

17. Refilling with hydraulic oil and transmission oil

- 1) Tighten drain plug of transmission, and add engine oil through oil filler (34) to the specified level.




Transmission case: Approx. 30ℓ



- 2) Tighten drain plug (3) and add engine oil through oil filler (2) to the specified level.




Hydraulic tank: Approx. 27ℓ

**18. Refilling with water**


Tighten drain valve and add cooling water through water filler (35) to the specified level.

- ★ Run the engine to circulate the water through the system. Then check the water level again.
- ★ Run the engine to circulate the water and the oil through the system. Then check the water and the oil level again.



REMOVAL OF ENGINE ASSEMBLY (incl. TRANSMISSION)

GD705A-4



234F1150


- ★ When removing the hydroshift transmission assembly, remove it first together with the engine, then remove the transmission assembly.

1. Draining oil

Remove drain plug (1) and drain oil from transmission case.



Transmission case: 48ℓ



234P1188

2. Draining water

Loosen drain valve (2) and drain cooling water.


- ★ If the coolant contains antifreeze, dispose of it correctly.

3. Left and right engine side covers

Remove left and right engine side covers.

4. Hood

Lift off hood.




234P1189

5. Wiring



Disconnect the cable from the negative (–) terminal of the battery.

- 1) Disconnect wire (3) of starting motor.




234P1190

- 2) Disconnect wire (4) of water temperature gauge and wire (5) of alternator.




234P1191


- 3) Disconnect ground connection (6).




- 4) Disconnect wire (7) of electric heater.



6. **Outlet hose of steering pump**
Disconnect outlet hose (8) of steering pump.




7. **Compressor hoses**
Disconnect 2 compressor hoses (9).




8. Fuel control cable


Remove spring (10), then disconnect fuel control cable (11).

**9. Parking brake cable, speedometer cable**


- 1) Disconnect parking brake cable (12).
- 2) Disconnect speedometer cable (13).

**10. Transmission control rod**

Disconnect transmission control rod (14).


**11. F-R cable, inching cable**

- 1) Loosen locknut (15).
- 2) Remove coupling (16), then disconnect F-R cable (17) and inching cable (18).




12. Transmission oil filler

Remove transmission oil filler tube (19).

**13. Dust indicator hose**

Disconnect dust indicator hose (20).


**14. Air cleaner**

Remove air cleaner assembly (21).

15. Fuel tank assembly

Remove fuel tank assembly.

For details, see 13 REMOVAL OF FUEL TANK ASSEMBLY.


**16. Outlet hose of hydraulic pump**

Disconnect outlet hose (22) of hydraulic pump.

17. Radiator assembly


Remove radiator assembly.

For details, see 13 REMOVAL OF RADIATOR ASSEMBLY.




18. Drive shaft

Remove drive shaft (23).

**19. Support**

Remove mounting bolts (24) of support plate.



**20. Engine assembly**

- 1) Remove mounting bolts (25) and (26).
- 2) Lift off engine assembly (27).




Engine assembly (incl. transmission): 2130 kg

- ★ If the hydroshift transmission assembly is to be removed from the engine assembly (which includes the transmission assembly), remove the connecting bolts of the flywheel housing, then remove the hydroshift transmission.



INSTALLATION OF ENGINE ASSEMBLY (incl. TRANSMISSION)

GD705A-4




234F1152

Spedical tool




| | Part No. | Part Name | Q'ty |
|---|--------------|----------------|------|
| A | 792-271-2000 | Centering tool | 1 |

★ When installing the hydroshift transmission assembly on the machine, install the connecting bolts of the flywheel housing to install the hydroshift transmission assembly to the engine, then install on the machine together with the engine.




1. Engine assembly


- 1) Lift engine assembly (27) and mount it to the frame.
- 2) Tighten mounting bolts (26) and (25).
 - ★ Tightly fasten the mounting bolt after aligning the engine.
- 3) Measure face runout and radial runout as follows.
 - i) Install centering tool A on flange of output shaft.
 - ii) Set dial gauge ③ on tool A.
 - iii) Rotate flange and measure radial runout and face runout. If the value is not within the standard, adjust the mounting position of the engine.
 - ★ Radial runout: Max. See lower diagram
 - ★ Face runout: Max. See lower diagram
 - iv) When the value is not within the standard, adjust shim A and shim B.



F23EC006



- 4) Carry out centering and shim adjustment as follows.
 - i) Add shims to **P** and **Q** to adjust the three points **PL**, **PR** and **Q** so that the drive shaft of the final drive is parallel to the center line of crankshaft. When doing this, the standard shim thickness for **P** should be 2.4 mm with a minimum thickness of 0.6 mm.
 - ii) Decide the shim thickness so that the clearance at **RL** and **RR** is '0'. Then add 0.7 mm of shim and assemble.
 - iii) Remove 0.6 mm of shim from **PL** and **PR** and assemble.
 - iv) Add 1.4 mm of shim to **Q** and assemble.




234F1151

- 5) Tighten mounting bolt.

 Mounting bolt: 39.25 ± 4.25 kgm

2. Support


Install plate mounting bolt (24).




234P1205

3. Drive shaft

Install drive shaft (23).

 Drive shaft: 11.25 ± 1.25 kgm



234P1204

4. Radiator assembly

Install radiator assembly.

For details, see 13 INSTALLATION OF RADIATOR ASSEMBLY.


5. Outlet hose of hydraulic pump

Connect hose (22) of hydraulic pump.


6. Fuel tank assembly

Install fuel tank assembly.


For details, see 13 INSTALLATION OF FUEL TANK ASSEMBLY.

**7. Air cleaner**


Install air cleaner assembly (21).

**8. Dust indicator hose**

Connect dust indicator hose (20).


**9. Transmission oil filler**

Fit O-ring and install transmission oil filler tube (19).




10. F-R cable, inching cable


- 1) Connect inching cable (18) and F-R cable (17) to spool. Fit O-ring to coupling (16), then tighten cover.
- 2) Secure cable with locknut (15).

**11. Transmission control rod**


- Connect transmission control rod (14).
- ★ Bend cotter pin securely.

**12. Parking brake cable, speedometer cable**

- 1) Connect speedometer cable (13).
- 2) Connect parking brake cable (12) and secure with locknut.


**13. Fuel control cable**

- Connect fuel control cable (11), then install spring (10).




14. Compressor hoses


Connect 2 compressor hoses (9).

**15. Outlet hose of steering pump**


Connect outlet hose (8) of steering pump.

**16. Wiring**


1) Connect wire (7) of electric heater.



2) Connect ground connection (6).




- 3) Connect wire (5) of alternator and wire (4) of water temperature gauge.



- 4) Connect wire (3) of starting motor.
5) Connect cable to negative (–) terminal of battery.

17. Hood

Raise hood and install.




18. Left and right engine side covers

Install left and right engine side covers.

19. Refilling with water

Tighten drain valve and add water through water filler (28) to the specified level.



234P1209


20. Refilling with oil

- 1) Tighten drain plug.
- 2) Add engine oil through oil filler (29) to the specified level.



Transmission case: 48ℓ


- ★ Run the engine to circulate the water and oil through the system. Then check the water and oil levels again.



234P1210

POWER TRAIN


21 STRUCTURE AND FUNCTION



| | |
|---|-------|
| General | 21- 2 |
| Power train diagram | 21- 4 |
| Damper | 21- 6 |
| PTO | 21- 8 |
| Hydroshift transmission | 21-10 |
| Hydroshift transmission control valve | 21-21 |
| Hydroshift transmission control | |
| circuit diagram | 21-32 |
| Hydroshift transmission control | 21-33 |
| Hydroshift transmission piping | 21-36 |
| Lubrication relief valve | 21-38 |
| Transmission pump | 21-39 |
| Hydroshift transmission control linkage | 21-40 |
| Drive shaft | 21-44 |
| Final drive | 21-46 |
| Differential lock and unlock piping | 21-50 |
| Tandem drive | 21-54 |

GENERAL

GD705R-4



F23B008


The power from diesel engine (1) is transmitted to the HYDROSHIFT transmission (3) through the damper (2). In the HYDROSHIFT transmission, in response to the load and the forward-reverse rotation direction, the clutch is selected and the power is transmitted to the final drive (6) through the drive shaft (5).

Here, the power is separated into left and right perpendicular directions and transmitted to the tandem drive (7) through the rear axle.

The tandem drive transmits the power to the wheel by a chain and the machine travels.

1. Engine
2. Damper
3. HYDROSHIFT transmission
4. Parking brake
5. Drive shaft
6. Final drive
7. Tandem drive

GD705A-4



F23E005

The power from diesel engine (1) is transmitted to the HYDROSHIFT transmission (3) through the joint (2). In the HYDROSHIFT transmission in response to the load and the forward-reverse rotation direction, the clutch is selected and the power is transmitted to the final drive (6) through the drive shaft (5).


Here, the power is separated into left and right perpendicular directions and transmitted to the tandem drive (7) through the rear axle.

The tandem drive transmits the power to the wheel by a chain and the machine travels.

1. Engine
2. Joint
3. HYDROSHIFT transmission
4. Parking brake
5. Drive shaft
6. Final drive
7. Tandem drive

POWER TRAIN DIAGRAM


GD705R-4



F23E04017

- 1. Engine
- 2. Damper
- 3. HYDROSHIFT transmission
- 4. Parking brake
- 5. Drive shaft
- 6. Final drive
- 7. Tandem drive
- 8. Brake lining

GD705A-4




21F002-1

- 1. Engine
- 2. Joint
- 3. HYDROSHIFT transmission
- 4. Parking brake
- 5. Drive shaft
- 6. Final drive (with differential)
- 7. Tandem drive

DAMPER


GD705R-4



21F009

- 1. Rubber
- 2. Body
- 3. Body
- 4. Flange
- 5. Gear
- 6. Flange

GD705A-4




F23E006

- 1. Disc
- 2. Bolt
- 3. Washer
- 4. Flywheel housing
- 5. HYDROSHIFT transmission case


PTO

GD705A-4




F23404008


- 1. Joint bolt
- 2. Joint bolt



Section A - A



Section C - C



Section B - B

- 3. Gear (35 teeth)
- 4. Gear (57 teeth)
- 5. Flywheel (137 teeth)
- 6. Bolt
- 7. Gear
- 8. Housing
- 9. Gear (52 teeth)


- 7. Gear
- 8. Housing
- 9. Gear (52 teeth)
- 10. Gear

- 11. Snap ring
- 12. Bearing
- 13. Cover
- 14. Gear
- 15. Snap ring
- 16. Bearing

F23404009

HYDROSHIFT TRANSMISSION

GD705R-4



21F017A

Model GD705R-4 are equipped with planetary type transmission (F6, R6) and is a combination of planetary gear system and disc clutch.

For each revolution direction and rpm, three of 7 disc clutches of the planetary gear system are hydraulically locked by acutating the control valve.

The R clutch is for reverse travel and F clutch for forward travel. The correspondence between clutch combinations and speeds are as follows:


| Clutch | | Speed | Clutch | | Speed |
|--------|-----|-----------|--------|-----|-----------|
| L | 1st | 1st speed | H | 1st | 4th speed |
| | 2nd | 2nd speed | | 2nd | 5th speed |
| | 3rd | 3rd speed | | 3rd | 6th speed |

| | Reduction ratio | | | | Each speed ratio |
|----|-----------------|-------|------------|-----------------------|-------------------------|
| | R.F.3.2.1 | T/F | H.L | Total reduction ratio | |
| F1 | 3.000 | 0.688 | L 4,167 | 8.601 | 1.800 1.667 1.389 |
| F2 | 1.667 | | | 4.779 | |
| F3 | 1.000 | | | 2.867 | |
| F4 | 3.000 | | H 1,000 | 2.064 | 1.800 1.667 |
| F5 | 1.667 | | | 1.147 | |
| F6 | 1.000 | | | 0.688 | |
| R1 | -2.536 | 0.688 | L 4,167 | -7.290 | 1.800 1.667 1.389 |
| R2 | -1.409 | | | -4.039 | |
| R3 | -0.845 | | | -2.403 | |
| R4 | -2.536 | | H 1,000 | -1.745 | 1.800 1.667 |
| R5 | -1.409 | | | -0.969 | |
| R6 | -0.845 | | | -0.581 | |

- | | | |
|-----------------------------------|-------------------------------|------------------------------------|
| 1. Case | 24. 2nd piston | A. R. sun gear (28 teeth) |
| 2. Gauge | 25. 3rd, F, carrier | B. R. planetary pinion (21 teeth) |
| 3. R. planetary pinion shaft | 26. F. piston | C. R. ring gear (71 teeth) |
| 4. R. housing | 27. R. carrier | D. R. ring gear (71 teeth) |
| 5. F. 3rd, planetary pinion shaft | 28. Input shaft | E. F. sun gear (38 teeth) |
| 6. F, housing | 29. L. planetary pinion shaft | F. F. planetary pinion (17 teeth) |
| 7. 3rd piston | 30. Cage | G. F. ring gear (76 teeth) |
| 8. 2nd housing | 31. Spring | H. 3rd sun gear (38 teeth) |
| 9. Sleeve | 32. Housing | I. 3rd planetaly pinion (19 teeth) |
| 10. 2nd carrier | 33. Shaft | J. 3rd ring gear (76 teeth) |
| 11. 2nd planetary pinion shaft | 34. Cage | K. 2nd sun gear (38 teeth) |
| 12. 1st spring | 35. Cage | L. 2nd planetaly pinion (19 teeth) |
| 13. 1st piston | 36. Sleeve | M. 2nd ring gear (76 teeth) |
| 14. 1st housing | 37. Valve | N. 1st gear (75 teeth) |
| 15. Cage | 38. Sleeve | O. Gear (32 teeth) |
| 16. Cage | 39. Shaft | P. Gear (31 teeth) |
| 17. Transfer case | 40. H. drum | Q. Gear (30 teeth) |
| 18. Cage | 41. Cage | R. Gear (22 teeth) |
| 19. Shaft | 42. H. piston | S. H. gear |
| 20. Cage | 43. L. carrier | T. L. sun gear |
| 21. Cage | 44. L. piston | U. L planetary pinion |
| 22. 1st spring | 45. Coupling | V. L ring gear |
| 23. 1st housing | 46. Shaft | |

HYDROSHIFT TRANSMISSION

GD705A-4



F23E010

The GD705A has a planetary type transmission which combines a planetary gear mechanism and disc clutch for 8 forward speeds and 8 reverse speeds.

Out of the 8 sets of planetary gear type disc clutches, 3 clutches are fixed by oil pressure via the control valve to select one revolving direction and one revolving speed. The R clutch is for reverse travel and F clutch for forward travel. The correspondence between clutch combinations and speeds are as follows:

| Clutch | | Speed | Clutch | | Speed |
|--------|-----|-----------|--------|-----|-----------|
| L | 1st | 1st speed | H | 1st | 5th speed |
| | 2nd | 2nd speed | | 2nd | 6th speed |
| | 3rd | 3rd speed | | 3rd | 7th speed |
| | 4th | 4th speed | | 4th | 8th speed |

| Reduction ratio Speed stage | Reduction ratio | | | Each speed ratio |
|--------------------------------|-----------------|------------------|-----------------------|------------------|
| | RF4321 LH | T/F | Total reduction ratio | |
| F1 | 7.823 | 1.103 (32/29) | 8.637 | 1.349 |
| F2 | 5.798 | | 6.398 | 1.465 |
| F3 | 3.958 | | 4.367 | 1.435 |
| F4 | 2.758 | | 3.043 | 1.383 |
| F5 | 1.994 | | 2.200 | 1.349 |
| F6 | 1.478 | | 1.631 | 1.465 |
| F7 | 1.009 | | 1.113 | 1.435 |
| F8 | 0.703 | | 0.776 | |
| R1 | 7.341 | | 8.100 | 1.349 |
| R2 | 5.440 | | 6.003 | 1.465 |
| R3 | 3.714 | | 4.098 | 1.435 |
| R4 | 2.588 | | 2.856 | 1.383 |
| R5 | 1.871 | | 2.065 | 1.349 |
| R6 | 1.387 | | 1.530 | 1.465 |
| R7 | 0.947 | | 1.045 | 1.435 |
| R8 | 0.660 | | 0.728 | |

- | | |
|---|--|
| <ol style="list-style-type: none"> 1. F, R housing 2. F piston 3. 4th planetary pinion shaft 4. Sleeve 5. 4th piston 6. 4th, 3rd housing 7. 3rd piston 8. 3rd, 4th carrier 9. 2nd housing 10. 2nd piston 11. 2nd planetary piston shaft 12. 1st housing 13. 1st piston 14. 1st planetary pinion shaft 15. L housing 16. L piston 17. L planetary pinion shaft 18. H piston 19. Spring 20. Cage 21. Transfer case 22. Cage | <ol style="list-style-type: none"> 23. Shaft 24. Cage 25. Shaft 26. Cage 27. Output shaft 28. L carrier 29. 1st carrier 30. 2nd carrier 31. Shaft 32. 3rd planetary pinion shaft 33. F carrier 34. R carrier 35. Housing 36. Input shaft 37. Cage 38. R planetary pinion shaft 39. F planetary pinion shaft 40. Cover 41. R piston 42. Cage 43. Coupling 44. Shaft |
|---|--|

PLANETARY GEAR SYSTEM

Planetary gear system (structure)

The planetary gear mechanism consists of sun gear **A**, planetary pinion **B**, ring gear **C** and carrier **D**.

The planetary pinion is supported by the carrier and meshes with the sun gear and the ring gear.

When the ring gear is fixed,

The sun gear **A** revolutions are transmitted to the planetary pinions **B**.


The planetary pinions are meshed with the ring gear **C**. Since the ring gear is fixed, it cannot revolve as it is. Therefore, the planetary pinions revolve on their axes while revolving around the sun gear along the ring gear. At this time the torque of the sun gear becomes carrier **D** torque and is transmitted. The direction of rotation of the carrier is the same as that of the sun gear.

When the carrier is fixed,

The sun gear **A** revolutions are transmitted to the planetary pinions **B**.


Because carrier **D** is fixed, the planetary pinions meshed with the sun gear revolve on their own axes at their positions. The ring gear **C** which is meshed with planetary pinions revolves in the opposite direction to the sun gear, and the sun gear torque becomes the torque of the ring gear and is transmitted.

Combination such as → Sun gear → Planetary pinion → Ring gear or carrier, is the structure of R.F. 3rd, 2nd, L clutches. However, for R clutch, the sun gear becomes the power source and transmits power to the ring gear, and for F, L clutch, the sun gear is the power source and transmits power to the carrier, and for 3rd and 2nd clutches the carrier is the power source and transmits power to 3rd and 2nd sun gears.




21F018

- A. Sun gear
- B. Planetary pinion
- C. Ring gear
- D. Planetary carrier



21F019




21F020

DISC CLUTCH

In order to fix the ring gear a disc clutch made up of piston (26), plate (50), disc (51), pin (52), piston return spring (53), washer spring (54), etc., is installed. The internal teeth of the disc mesh with the external teeth of the ring gear.

The plate is fixed in the direction of rotation by the meshing of the notched protrusions of the outer diameter and pins (52) fixed into the housing (6).


The piston is also fixed in the direction of rotation in the same way.



21F023

Clutch "ENGAGED" (Fixed)

Hydraulic oil from the control valve passes through the port of the housing (6) and transmits pressure to the back of the piston (26). The piston presses disc (51) and plate (50) and the friction stops the disc rotation, resulting in fixing ring gear **G** which is meshing with the interior teeth of the disc.




21F024

Clutch "DISENGAGED" (Released)

When the hydraulic oil from the control valve is interrupted, the piston return spring (53) acts to return the piston (26) to its original position, the plate (50) and disc (51) friction is released and the ring gear **G** becomes neutral.

The washer spring (54) installed between the pin (52) and the plate acts to return the piston more quickly when the clutch is disengaged, improve plate and disc separation and prevent the disc drag rotation.



21F025

ROTARY CLUTCH


Clutch "ENGAGED" (Fixed)

Hydraulic oil from the control valve goes to the back of the piston (13) through the port of the cage (20).

The piston force-presses disc (55) and plate (56).

The clutch is engaged by meshing the internal teeth of the disc and the external teeth of the gear **N** and the external teeth of the plate and the internal teeth of the drum (2nd carrier, (10)).

The gear and drum become one unit and revolve.




21F026

Clutch "DISENGAGED" (Released)

When the hydraulic oil from the control valve is interrupted the piston is returned by the disc spring (12).


On the other hand, when the piston is returned to its original position, and the clutch is disengaged, the wave spring (57) between plates (56) separates plate and disc (55) completely, and prevents drag rotation.



21F027

FUNCTION (GD705R-4)

FORWARD 1st GEAR (F, 1st, L)



Power is transmitted from F sun gear E to F planetary pinion F.


Because F ring gear G is fixed, F planetary pinion revolves around F sun gear while revolving on its axis. F carrier (25) (one with 3rd carrier) to revolve it in the same direction as F sun gear.

Furthermore, because 1st clutch has been engaged 1st gear N, 2nd carrier (10) and 3rd ring gear J become one unit.

In this condition, F carrier (one with 3rd carrier) is revolving and 3rd sun gear H, 2nd sun gear K, 1st clutch, 2nd carrier and 3rd ring gear revolve as one unit, power is transmitted to revolve output shaft (19) in the same direction as F sun gear.

Furthermore, power is transmitted through gears O, P, Q, R, to HL transmission, and because L clutch is fixed, power is transmitted to the output shaft through L planetary pinion U and L carrier (43).

FORWARD 4th GEAR (F, 1st, H)




21F029

Transmission of power to the input shaft of H-L clutch is exactly the same as for Forward 1st gear, so see previous page.

Power from the input shaft of H-L clutches is transmitted so that the output shaft revolves in the same direction and at the same speed as the input shaft, because when H clutch is engaged, L carrier, L ring gear and H clutch become one unit.

REVERSE 1st GEAR (R, 1st, L)




43

21F030

Power is transmitted from R sun gear A to R planetary pinion B.
Because R ring gear C is fixed by R clutch, R carrier (20) is also fixed.
Because of this R planetary pinion revolves on its axis.
R ring gear D revolves in the opposite direction to R sun gear. At this time power is transmitted to revolve F carrier (25) in the opposite direction to the input shaft revolution because it is one with R ring gear.
Transmission of power after this is the same as with Forward 1st gear.

REVERSE 4th GEAR (R, 1st, H)



43


21F031

Power to the transfer input shaft is exactly the same as reverse 1st gear.

Furthermore, it is transmitted through the transfer to the H-L clutches. Power from the H-L clutches is transmitted to the output shaft to revolve it in the same direction and at the same speed as for forward 4th gear.


HYDROSHIFT TRANSMISSION CONTROL VALVE

GD705R-4




HYDROSHIFT TRANSMISSION CONTROL VALVE (1/2)


GD705A-4




1. Lubrication oil pressure measuring plug
2. Inching oil pressure measuring plug
3. Pilot oil pressure measuring plug
4. Main oil pressure measuring plug
5. Relief valve (Lubrication and cooler by-pass)
6. Shift valve lever (for F.R)
7. Shift valve lever (for Inching)
8. Speed select control lever





Section A-A



Section B-B




Detail P




Section D-D


234F1107




Section D-D




Section G-G




Section H-H




Section J-J



Section E-E



Section F-F



Section K-K

1. Sleeve
2. Sleeve
3. Valve
4. Sleeve
5. Valve body
6. Shift valve (1st)
7. Valve body
8. Shift valve (2nd)
9. Stopper
10. Yoke
11. Shift valve (F,R)
12. Shift valve (Inching)
13. Spring
14. Valve
15. Sleeve
16. Washer
17. Stopper
18. Sleeve
19. Sleeve
20. Spring
21. Shift valve (H,L)
22. Valve body
23. Sleeve
24. Shift valve (3rd)
25. Cover
26. Valve
27. Spring
28. Valve
29. Priority valve
30. Spring
31. Sleeve
32. Cover
33. Spring
34. Valve
35. Modulating valve
36. Valve body
37. Sleeve
38. Quick return valve
39. Modulating valve
40. Stopper
41. Plug
42. Spring
43. Valve body
44. Lubrication valve
45. Spring
46. Cooler bypass valve

F23E016

| Control position | N | 1st | 2nd | 3rd | 4th | 5th | 6th | 7th | 8th |
|------------------|---------|-------|-------|-------|-------|-------|-------|-------|-------|
| Shift valve | Cut off | L 1st | L 2nd | L 3rd | L 4th | H 1st | H 2nd | H 3rd | H 4th |

PRIORITY VALVE

FUNCTION

The priority valve keeps the hydraulic pressure (shift valve operation hydraulic pressure) of the pilot circuit constant at the specified pressure if the main circuit hydraulic pressure decreases, to ensure operation of the gear shift valve.


1. When neutral

The priority valve (1) is a relief valve with a set pressure of 14 kg/cm².


When there is no gear changing, the pilot circuit hydraulic pressure (shift valve hydraulic oil pressure) is the same as the main circuit hydraulic pressure: 25 kg/cm². The priority valve is in contact with the stopper.

2. During gear changing

When the main circuit oil pressure goes down below 14 kg/cm², the pilot circuit oil pressure is maintained at 14 kg/cm² by the priority valve and the shift valve can reliably function.




21F033



21F034

MODULATING VALVE AND QUICK RETURN VALVE

The modulating valve and the quick return valve smoothly raise the main oil pressure when gear changing. By operating the clutch, shock at driving gear changing is eliminated and the production of peak torque in the power line is prevented.




21F022A

1) Immediately after gear changing (X point)

Immediately after changing gears the main circuit (from the pump) oil flows into the piston of the operating clutch.


Due to the flow of oil at this time, a difference in pressure is produced in the A-chamber and the B-chamber of the quick return valve (3), and the quick return valve moves to the left. At this time, the C-chamber of the modulating valve load piston port is connected to the drain circuit. By the force of the spring (4) the modulating load piston (5), while draining the oil which has filled the C-chamber of the load piston port, returns to stroke end (right edge).



21F036

2) While raising pressure (Y point)


When the clutch piston fills with oil, the flow of oil almost completely stops. The pressure of the A-chamber and B-chamber of the quick return valve (3) is almost the same. Due to this, the pressure difference ($a > b$) on the surface and b surface of the quick return valve causes the quick return valve to return the right. The circuit to the drain port D-chamber of the modulating valve load piston closes. At the same time the oil passed through the orifice (e) of the quick return valve pushes the modulating valve load piston (5) to the left. Then, due to the movement of the load piston, the spring (4) contracts and the relief pressure of the modulating valve gradually rises.



21F037

3) At set pressure (25kg/cm²) (Z point)

When the modulating valve load piston touches the stopper, the increase in the oil pressure ceases. At this time the relief pressure is the set pressure (25kg/cm²) of the modulating valve.




FUNCTION (GD705A-4)

SPEED STAGE CHANGING VALVE


1) At neutral

The pilot pressure applies on the A-chamber of the cutoff valve and because the C-chamber connects with the drain circuit, the spool moves to the right due to the difference in pressure between the A-chamber and the C-chamber. The oil from the pump does not operate each clutch, but lubricates the transmission and PTO, and is drained into the transmission case.




2) At forward 1st speed

The B-chamber and D-chamber of the back pressure side of the shift valve (1st) (H.L) are each connected to the drain circuit and so a difference in pressure arises in the A-chamber and B-chamber, and the A-chamber and D-chamber. The 1st spool is pushed to the right and the H.L spool is pushed to the left and since the F.R spool is set in the F position, the oil from the pump is led to the 1st, L, F clutch.



3) Forward 8th speed

Since the E-chamber of the back pressure side of the shift valve (4th) is connected to the drain circuit, a pressure difference arises between A-chamber and E-chamber and the spool is pushed to the left. Since the F. R spool is set on the F position, the oil from the pump flows into the 4th, H, F clutch.




F23E019

4) At reverse 2nd speed

Because the back pressure side of the shift valve (2nd), (H.L) is connected to the drain circuit, a difference in pressure arises between the A-chamber and D-chamber, and the A-chamber and F-chamber. The H.L. spool is pushed to the left and the 2nd spool is pushed to the right. Since the F.R spool is set in the R position, the oil from the pump is led to the 2nd, L, R clutch.

At other forward 2nd speed to 7th speed and reverse 1st speed and 3rd speed to 8th speed occur according to combinations in the above items 2 to 4. The combinations are as follows:

- Forward 2nd speed: 2nd, L, F
- Forward 3rd speed: 3rd, L, F
- Forward 4th speed: 4th, L, F
- Forward 5th speed: 1st, H, F
- Forward 6th speed: 2nd, H, F
- Forward 7th speed: 3rd, H, F
- Forward 8th speed: 4th, H, F
- Reverse 1st speed: 1st, L, R
- Reverse 3rd speed: 2nd, L, R
- Reverse 4th speed: 4th, L, R
- Reverse 5th speed: 1st, H, R
- Reverse 6th speed: 2nd, H, R
- Reverse 7th speed: 3rd, H, R
- Reverse 8th speed: 4th, H, R



F23E020


INCHING VALVE

OPERATION

1. Inching valve [OPEN]

The oil from the pump passes through ports **A** and **B**, and then goes from the F-R spool to the F-R clutch.

The return spring of the inching pedal pushes valve spool (2) and collar (3), and moves valve (1) to the left. Oil passes through orifice **D** and enters chamber **C**. It acts to push valve (1) to the right, but because of the tension of the return spring, valve (1) does not move.




233F318

2. Inching valve [THROTTLED]

When the inching pedal is depressed slightly, valve spool (2) moves to the right, so piston (4) pushes valve (1) to the right to a position where it balances the tension of springs (5), (6) and (7).


In other words, the passage to port **B** is restricted, and orifice **E** is connected to the drain port, so the hydraulic pressure of the F-R clutch is reduced, and the clutch is partially disengaged.



233F319

3. Inching valve [CLOSED]


When the inching is depressed fully, valve spool (2) moves fully to the right, so the tension of springs (5) and (6) becomes weaker. As a result, the hydraulic pressure of the F-R clutch drops to 0.4 – 0.55 kg/cm², and the clutch is completely disengaged.



233F320

HYDROSHIFT TRANSMISSION CONTROL CIRCUIT DIAGRAM

GD705R-4




21F046

- | | |
|---|------------------------------|
| 1. Strainer | 9. F-R clutch valve |
| 2. HYDROSHIFT transmission pump (SAL 045) | 10. 1st clutch valve |
| 3. Oil filter | 11. 2nd clutch valve |
| 4. Priority valve | 12. 3rd clutch valve |
| 5. Modulating valve | 13. H.L clutch valve |
| 6. Quick return valve | 14. Speed selector valve |
| 7. Cut-off valve | 15. Oil cooler |
| 8. Inching valve | 16. Cooler by-pass valve |
| | 17. Lubrication relief valve |

HYDROSHIFT TRANSMISSION CONTROL


GD705R-4



21F045

HYDROSHIFT TRANSMISSION CONTROL CIRCUIT DIAGRAM


GD705A-4



F23E022A

HYDROSHIFT TRANSMISSION CONTROL


GD705A-4



F23E02 I A

HYDROSHIFT TRANSMISSION PIPING


GD705R-4



232F109

1. Hydroshift transmission control valve
2. Hydroshift transmission
3. Oil filter
4. Mission pump (SAL 045)
5. Engine
6. Oil cooler


GD705A-4



F23404010

1. Transfer
2. HYDROSHIFT transmission control valve
3. Engine
4. Transmission pump (SAL 050)
5. Oil filter

LUBRICATION RELIEF VALVE




21F048

- 1. Plug
- 2. Spring
- 3. Body
- 4. Poppet

TRANSMISSION PUMP

GD705R-4 (SAL045)
GD705A-4 (SAL050)





238F026


- 1. Drive gear
- 2. Bracket
- 3. Gear case
- 4. Cover
- 5. Driven gear
- 6. Bushing
- 7. Oil seal
- 8. Snap ring

HYDROSHIFT TRANSMISSION CONTROL LINKAGE


GD705R-4




Section A-A



Section B-B





Section C-C




Section D-D


F23E04018



Section E-E



View Y





View Z

- | | |
|--------------------------------|---------------------------------|
| 1. Inching pedal | 5. Lock lever (for shift lever) |
| 2. Wire (for F.R. control) | 6. Shift lever |
| 3. Wire (for inching) | 7. F.R. control side |
| 4. Stopper (for inching pedal) | 8. Inching control side |


F23E04019

HYDROSHIFT TRANSMISSION CONTROL LINKAGE


GD705A-4




Section A - A



Section B - B




Section C - C




Section D - D

F23404049




Section E - E Section F - F




View Y

(Serial No. 21001 and up)



View Y

(Serial No. 31001 and up)



View Z

F23404050

- | | |
|--------------------------------|---------------------------------|
| 1. Inching pedal | 5. Lock lever (for shift lever) |
| 2. Wire (for F.R control) | 6. Shift lever |
| 3. Wire (for inching) | 7. F.R control side |
| 4. Stopper (for inching pedal) | 8. Inching control side |

DRIVE SHAFT






DIAGRAM OF ADJUSTING RUN OUT



F23E026

FINAL DRIVE

GD705R-4



F23E04020


- | | | |
|----------------------------|---------------------------|--------------------|
| 1. Case | 9. Gear (17 teeth) | 17. Flange |
| 2. Gage | 10. Bevel gear (38 teeth) | 18. Housing |
| 3. Bevel pinion (13 teeth) | 11. Shaft | 19. Oil level plug |
| 4. Coupling | 12. Gear (17 teeth) | 20. Oil drain plug |
| 5. Nut | 13. Shim | 21. Support |
| 6. Shim | 14. Gear (44 teeth) | 22. Oil filler |
| 7. Sprocket (13 teeth) | 15. Shaft | 23. Breather |
| 8. Gear (44 teeth) | 16. Bearing | |

Power transmitted from the engine to the damper and to the transmission is transmitted at right angles by meshing of the bevel pinion (3) and bevel gears (10). Then it is reduced by gear (8), (9) and transmitted to the sprocket (7).


Also, the weight of the machine is transmitted by the final drive cases (1), (18) to the tandem cases. Because this weight is directly transmitted to the tandem case by flange (17), the shaft (15) transmits the torque only. (The shaft (15) is full floating.)

Adjustment of the preload of the bevel pinion is done with nut (5) and washer. Also, adjustment of the preload of bevel gear, backlash, adjusting tooth contact of pinion is done with shim (13).

This is a device that reduces power from the transmission and transmits it to the left and right tandem drive gears. When a motor grader is operated with the blade at a propulsion angle, or the machine on a slope, it receives on its front section a side reaction force that tends to turn it sideways, either to left or right. Because it is necessary to resist this and continue to advance straight ahead, it is generally structured without a differential installed.




232F111



21F053

FINAL DRIVE

GD705A-4



21F044-2

F23E027

- | | | |
|------------------------|-----------------------------|------------------------------|
| 1. Shaft | 10. Gear | 19. Case |
| 2. Bearing | 11. Bevel gear (38 teeth) | 20. Housing |
| 3. Sprocket (13 teeth) | 12. Nut | 21. Breather |
| 4. Joint | 13. Cage | 22. Filler tube |
| 5. Gear (42 teeth) | 14. Gear (17 teeth) | 23. Tube for oil level gauge |
| 6. Shaft | 15. Shim | 24. Shim |
| 7. Gear | 16. Nut | 25. Bolt |
| 8. Gear | 17. Coupling | 26. Support |
| 9. Lock plate | 18. Bevel pinion (13 teeth) | |

The final drive is a speed reduction gearing system which transmits drive power from the transmission to the right and left tandem drive gears.

When a motor grader is operated with its blade set to an angled position or with the machine body tilted, the reaction of the surface being graded will cause a lateral force to turn the front end of the machine right or left. To keep the machine traveling straight forward by resisting this turning force, ordinary motor graders are equipped with a differential.

However, since the GD705A-4 is an articulated machine, in which the rear wheels are likely to slip sideways when articulation is in effect, a differential is used to prevent early wear of the rear tires. The differential can be locked when necessary by remote control from the operator's seat.


The rotation of the engine is transmitted through the damper to the transmission along the machine center line. The rotation of the transmission output shaft is then transmitted through bevel gear (11), which is in mesh with transmission output shaft bevel pinion (18), to the bevel gear shaft which is at a right angle to the machine center line. The rotation of the bevel gear shaft is in turn transmitted to sprockets (3) after its speed of rotation is decreased by gear trains (5) – (7) and (5) – (14), respectively.

The full-floating shaft (1) transmits only driving torque.


The weight of the machine is directly delivered to the tandem case from final drive case (19) and housing (20) by bearing (2) and joint (4)

The bevel pinion preload can be adjusted with nut (16). Shim (15) and nut (12) are used to adjust the tooth contact between the bevel gear and pinion, the backlash and the bevel gear preload.

Shim (24) is used to correct the step between the right and left mounting surfaces to which support (26) is fitted when mounting the case on the main frame.




21F044-2





21F053

DIFFERENTIAL LOCK AND UNLOCK PIPING

GD705A-4



F23404013



Section A - A



Detail A




Detail B

F23404014



- 1. Lever (Differential control)
- 2. Air regulator valve
- 3. Air tube
- 4. Chamber
- 5. Air charge plug

DIFFERENTIAL LOCK AND UNLOCK

GD705A-4 (Serial No. 31001 and up)



F23E092



Section A-A



Detail A




Detail B

F23E093

1. Lever (Differential control)
2. Air regulator valve
3. Air tube
4. Chamber
5. Air charge plug

TANDEM DRIVE

GD705R-4



F23E04021


- ★ Above 0°C: Use engine oil CLASS-CD SAE30
 Below 10°C: Use engine oil CLASS-CD SAE10W

Reduction ratio: $\frac{23}{13} = 1.769$

Lubrication amount: 36 ℓ

- | | |
|---------------|--------------------|
| 1. Cover | 8. Bearing |
| 2. Breather | 9. Tandem case |
| 3. Chain | 10. Cover |
| 4. Hub shaft | 11. Oil level plug |
| 5. Sprocket | 12. Cover |
| 6. Cage | 13. Oil drain plug |
| 7. Brake drum | |

GD705A-4



21F046-1

- ★ Above 0°C: Use engine oil CLASS-CD SAE30
- Below 10°C: Use engine oil CLASS-CD SAE10W

Reduction ratio: $\frac{26}{13} = 2.0$

Lubrication amount: 105 ℓ


- | | |
|------------------------|-----------------------|
| 1. Cover | 10. Spring |
| 2. Breather | 11. Bearing |
| 3. Chain | 12. Gear (105 teeth) |
| 4. Hub shaft | 13. Plate (138 teeth) |
| 5. Bearing | 14. Disk |
| 6. Shim | 15. Tandem case |
| 7. Sprocket (26 teeth) | 16. Cover |
| 8. Cage | 17. Oil level gauge |
| 9. Piston | 18. Drain plug |

Power from the final drive is transmitted to the front and back rear wheels by chain.

The tandem cases can swing up and down 13° each. All four rear wheels are in contact with the ground even when the ground is rough restricting the up-and-down movement of the blade to a minimum.


The movement of the blade of a motor grader when its rear wheels ride over an obstacle is as follows:

1. When both left and right wheels ride over on object (height: H) at the same time, the center of the rear axle rise $H/2$ as right figure shows, and because the blade is situated about halfway between the front and rear axles, its movement further becomes $H/4$.



21F043


2. When only one left rear wheel rides over an object (height: H), the rise at the center of rear axle is $H/2$ at its left end as right figure shows and $H/4$ at the center line of machine and on the rear axle. The movement of the center part of the blade is half of that, which is $H/8$.



21F044

POWER TRAIN

22 TESTING AND ADJUSTING



| | |
|--|------|
| Table of judgement standard value | 22-2 |
| Inching pedal stroke and operating force | 22-3 |
| HYDROSHIFT transmission | 22-4 |
| Transmission control lever stroke and operating force | 22-8 |


TABLE OF JUDGEMENT STANDARD VALUE

| Item | | Test condition | Standard value | | |
|-----------------|--|---|--|--------------------------------|------------|
| | | | GD705R-4 | GD705A-4 | |
| Stroke | Fuel control lever | Amount of movement from center of lever knob from slow to full rotation | 215 ± 10 mm | 150 ± 10 mm | |
| | Accelerator pedal | Amount of movement in up-down direction | 97 ± 10 mm | 70 ± 10 mm | |
| | Inching pedal | Amount of movement in up-down direction | 67 ± 5 mm | 105 ± 10 mm | |
| | Parking brake lever | Ability to hold in stopped condition on 1/5 incline paved surface | Within range of 2 – 3 notches. | Within range of 2 – 3 notches. | |
| | Gear shift lever | N → 1 | Engine stopped, stroke of tip of lever | 54.5 ± 5 mm | 55 ± 10 mm |
| | | 1 → 2 | Engine stopped, stroke of tip of lever | 54.5 ± 5 mm | 50 ± 10 mm |
| | | 2 → 3 | Engine stopped, stroke of tip of lever | 54.5 ± 5 mm | 45 ± 10 mm |
| | | 3 → 4 | Engine stopped, stroke of tip of lever | 54.5 ± 5 mm | 45 ± 10 mm |
| | | 4 → 5 | Engine stopped, stroke of tip of lever | 54.5 ± 5 mm | 45 ± 10 mm |
| 5 → 6 | | Engine stopped, stroke of tip of lever | 54.5 ± 5 mm | 45 ± 10 mm | |
| 6 → 7 | | Engine stopped, stroke of tip of lever | — | 45 ± 10 mm | |
| 7 → 8 | Engine stopped, stroke of tip of lever | — | 45 ± 10 mm | | |
| Operating force | Fuel control lever | Maximum value at tip of lever until just before stroke end | 4 ± 1 kg | 9 ± 2 kg | |
| | Accelerator pedal (depression force) | Maximum value until just before stroke end | 7.8 ± 1 kg | 10 ± 2 kg | |
| | Inching pedal | Maximum value until just before stroke end | 12 ± 1 kg | 7 ± 2 kg | |
| | Brake pedal (depression force) | Measured with wheels completely locked | Max. 30 kg | Max. 30 kg | |
| | Parking brake lever | Ability to hold in stopped condition on 1/5 incline paved surface | Max. 20 kg | Max. 20 kg | |
| | Gear shift lever | Maximum value until just before stroke end | Max. 3.6 kg | Max. 5 kg | |
| Heat balance | Engine cooling water | • Oil and water levels are normal | Max. 100°C | Max. 100°C | |
| | Engine oil temperature | • Air temperature 40°C conversion | Max. 120°C | Max. 120°C | |
| | Transmission oil temperature | • Performed at a continuous traction (F-2) | Max. 120°C | Max. 120°C | |
| | Final drive oil temperature | • On a concrete road surface | Max. 120°C | Max. 120°C | |
| | Tandem case oil temperature | • Using thermistor | Max. 120°C | Max. 120°C | |
| | Hydraulic oil temperature | • Performed with thermostat open | Max. 120°C | Max. 120°C | |
| Others | Height of inching pedal (when not operating) | Height from the floor to the center of the stopper mounting bolt | 130 ± 2 mm | 120 ± 5 mm | |
| | Height of inching pedal (during operating) | | 63 ± 5 mm | 15 ± 1 mm | |
| | Inching pedal play | | 0 mm | 0 mm | |
| | Transmission operating | At engine full rotation, F-6, using both the parking brake and the wheel brake, the engine should stop within the ruled value when the inching pedal is released. | Within 3.0 sec. | Within 3.0 sec. | |

INCHING PEDAL STROKE AND OPERATING FORCE


INCHING PEDAL STROKE CHECK

Use convex rule ① to measure the length of the movement from up to down from beginning to the end of depressing inching pedal (1).



INCHING PEDAL OPERATING FORCE CHECK

Use push-pull scale ② to measure the maximum value in the stroke to just before the inching pedal stroke end.



HYDROSHIFT TRANSMISSION


GD705R-4

Special tool

| | Part No. | Part Name | Q'ty |
|---|--------------|------------------|------|
| A | 790-301-1103 | Hydraulic tester | 1 |


TRANSMISSION PILOT OIL PRESSURE CHECK

1. Remove side cover (1).
2. Remove measuring plug (2) and attach hydraulic gauge A (25 kg/cm²).
3. Start engine and measure pilot oil pressure of transmission.




TRANSMISSION OIL PRESSURE CHECK (MODULATING PRESSURE)

1. Remove side cover (1).
2. Remove measuring plug (3) and attach oil pressure gauge A (70 kg/cm²).
3. Start engine and measure oil pressure of transmission (modulating pressure).
 - ★ To confirm modulating set pressure only, it is necessary to start the engine.
 - ★ To confirm clutch pressure for each gear shift (except F and R) start engine and measure with the inching pedal depressed.




TRANSMISSION LUBRICATION PRESSURE CHECK

1. Remove measuring plug (4) and attach hydraulic gauge A (25 kg/cm²).
2. Start engine and measure lubricating oil pressure of transmission.



Unit: kg/cm²

| | Measurement check items | Standard value |
|----------|--------------------------|----------------|
| Plug (2) | Pilot oil pressure | 14.5 ± 0.5 |
| Plug (3) | Modulating pressure | 25.5 ± 1.5 |
| Plug (4) | Lubrication oil pressure | 2.5 ± 1.5 |




GD705A-4

Special tool

| | Part No. | Part Name | Q'ty |
|---|--------------|------------------|------|
| A | 790-301-1103 | Hydraulic tester | 1 |


TRANSMISSION PILOT OIL PRESSURE CHECK

1. Remove side cover (1).
2. Remove measuring plug (2) and attach hydraulic gauge A (25 kg/cm²).
3. Start engine and measure pilot oil pressure of transmission.



TRANSMISSION OIL PRESSURE CHECK (MODULATING PRESSURE)

1. Remove side cover (1).
2. Remove measuring plug (3) and attach oil pressure gauge A (70 kg/cm²).
3. Start engine and measure oil pressure of transmission (modulating pressure).
 - ★ To confirm modulating set pressure only, it is necessary to start the engine.
 - ★ To confirm clutch pressure for each gear shift (except F and R) start engine and measure with the inching pedal depressed.





TRANSMISSION LUBRICATION PRESSURE CHECK

1. Remove measuring plug (4) and attach hydraulic gauge A (25 kg/cm²).
2. Start engine and measure lubricating oil pressure of transmission.

Unit: kg/cm²

| | Measurement check items | Standard value |
|----------|--------------------------|----------------|
| Plug (2) | Pilot oil pressure | 14.5 ± 0.5 |
| Plug (3) | Main oil pressure | 25.5 ± 1.5 |
| Plug (4) | Lubrication oil pressure | 2.5 ± 1.5 |



HYDROSHIFT TRANSMISSION


GD705A-4 (Serial No. 31001 and up)

Special tool

| | Part No. | Part Name | Q'ty |
|---|--------------|------------------|------|
| A | 790-301-1103 | Hydraulic tester | 1 |


TRANSMISSION PILOT OIL PRESSURE CHECK

1. Remove measuring plug (2) and attach hydraulic gauge A (25 kg/cm²).
2. Start engine and measure pilot oil pressure of transmission.



TRANSMISSION OIL PRESSURE CHECK (MODULATING PRESSURE)

1. Remove measuring plug (3) and attach oil pressure gauge A (70 kg/cm²).
2. Start engine and measure oil pressure of transmission (modulating pressure).
 - ★ To confirm modulating set pressure only, it is necessary to start the engine.
 - ★ To confirm clutch pressure for each gear shift (except F and R) start engine and measure with the inching pedal depressed.



TRANSMISSION LUBRICATION PRESSURE CHECK

1. Remove measuring plug (1) and attach hydraulic gauge A (25 kg/cm²).
2. Start engine and measure lubricating oil pressure of transmission.


Unit: kg/cm²

| | Measurement check items | Standard value |
|----------|--------------------------|----------------|
| Plug (2) | Pilot oil pressure | 14.5 ± 0.5 |
| Plug (3) | Modulating pressure | 25.5 ± 1.5 |
| Plug (1) | Lubrication oil pressure | 2.5 ± 1.5 |

TRANSMISSION OIL PRESSURE ADJUSTMENT (MODULATING PRESSURE)


★ If oil pressure is outside standard value, adjust according to following procedure.

1. Remove transmission control valve assembly (4).



22P014

2. Remove cover (5) and remove valve (6).
3. Increase or decrease shims (7) and adjust tension of spring (8).
 - ★ Increase shims and oil pressure rises.
Decrease shims and oil pressure falls.
 - ★ Standard shim thickness: 1.0 mm
 - ★ Kind of shim: 0.5 mm
4. After adjustment, confirm that transmission oil pressure (modulating pressure) is within standard value, following procedure of TRANSMISSION OIL PRESSURE CHECK (MODULATING PRESSURE).




22P015

TRANSMISSION CONTROL LEVER STROKE AND OPERATING FORCE

STROKE CHECK AND ADJUSTMENT

Use convex rule ① to measure the stroke of the gear shift lever at the tip of each lever between each gear shift.


- ★ Measure with engine stopped.
- ★ The stroke of gear shift lever is determined by the working distance of the lever notch on the transmission side. However, the neutral position of the gear shift lever is determined by adjusting rod (2) and cable (3) without removing the gear shift lever guide.




P23404010

GD705R-4

GD705A-4



F23E04022




F23404050A

OPERATING FORCE CHECK AND ADJUSTMENT

Use push-pull scale ② to measure maximum value in the stroke to just before the stroke end of each gear at the gear shift lever (1) tip.


- ★ Measure with engine stopped.
- ★ The operating force of the gear shift lever is determined on transmission side. However, when the operating force is above standard value, check the movement of connecting rod. If it is normal, disassemble the transmission side and check the operating condition of the movement of the spool.



P23404011

POWER TRAIN

23 DISASSEMBLY AND ASSEMBLY




| | |
|-----------------------------------|--------|
| DAMPER | |
| Removal and installation | 23- 2 |
| HYDROSHIFT TRANSMISSION ASSEMBLY | |
| Disassembly | 23- 4 |
| Assembly | 23- 20 |
| CAGE AND REVERSE CARRIER ASSEMBLY | |
| Disassembly and assembly | 23- 99 |
| 1ST SPEED AND 2ND SPEED | |
| CARRIER ASSEMBLY | |
| Disassembly | 23-100 |
| Assembly | 23-101 |
| HIGH REVOLUTION CLUTCH ASSEMBLY | |
| Disassembly | 23-102 |
| Assembly | 23-103 |
| PLANETARY GEAR | |
| Disassembly and assembly | 23-104 |
| HYDROSHIFT TRANSMISSION CONTROL | |
| VALVE | |
| Removal | 23-106 |
| Installation | 23-107 |
| HYDROSHIFT TRANSMISSION PUMP | |
| ASSEMBLY | |
| Removal and installation | 23-108 |
| TANDEM AND FINAL DRIVE ASSEMBLY | |
| Removal | 23-110 |
| Installation | 23-111 |
| FINAL DRIVE ASSEMBLY | |
| Disassembly | 23-114 |
| Assembly | 23-119 |
| BEVEL GEAR ASSEMBLY | |
| Disassembly | 23-140 |
| Assembly | 23-141 |
| BEVEL PINION ASSEMBLY | |
| Removal | 23-148 |
| Installation | 23-150 |
| Disassembly | 23-152 |
| Assembly | 23-153 |
| TANDEM CASE AND SPROCKET | |
| Removal | 23-154 |
| Installation | 23-157 |
| SPROCKET ASSEMBLY | |
| Removal | 23-160 |
| Installation | 23-162 |

REMOVAL OF DAMPER

GD705R-4

1. Remove HYDROSHIFT transmission.
Refer to "REMOVAL OF HYDROSHIFT TRANSMISSION" section.
2. Temporarily sling damper (1).
3. Remove stopper (2). Sling up and remove damper (1).
Damper: Approx. 35 kg




INSTALLATION OF DAMPER

GD705R-4

1. Sling damper (1) into flywheel.
2. Install stopper (2).
★ Bend down lock plate firmly.
3. Install HYDROSHIFT transmission.
Refer to "INSTALLATION OF HYDROSHIFT TRANSMISSION" section.

DISASSEMBLY OF DAMPER**GD705R-4**


1. Remove flange (1).
2. Turn over damper and remove flange (2).
3. Pull out body (4) and rubber (5) from body (3).
4. Remove gear (6) from body (3).




23P043

ASSEMBLY OF DAMPER**GD705R-4**


1. Install gear (6) on body (3).
 - ★ Bend down lock plate firmly.
2. Install flange (1).
 - ★ Bend down lock plate firmly.
 - ★ Charge grease (G2-LI) to flange pilot as much as one fifth of its capacity.



23P044




23F008



23P045


3. Install body (4) and rubber (5) on body (3).
 - ☞ Rubber: Grease (G2-LI)
4. Install flange (2).
 - ★ Bend down lock plate firmly.




23P046


DISASSEMBLY OF HYDROSHIFT TRANSMISSION

GD705R-4






23F018




23FO19




Special tool

| | Part number | Part name | Q'ty |
|---|--------------|-------------|------|
| A | 799-301-1300 | Air checker | 1 |

1. Drum
Remove brake drum (1).




2. Flange
Remove center bolt, remove flange (2).



3. Parking brake

Remove parking brake assembly (3).




23P151

4. Transmission control valve piping

Remove transmission control valve tubes (4), (5) and (6).

★ Care should be taken not to let strainer to come out from the tube (4).



23P152

5. Transmission control rod


Disconnect transmission control rod (7) from lever and remove it together with bracket (8) as an assembly.

6. Tube

Remove tubes (9), (10) and (11).

7. Lubricating tube


Remove lubricating tube (12).



23P153

8. Transmission control valve


Remove transmission control valve (13) together with cooler bypass valve (14) as an assembly.



23P154

9. Cover

Screw in jack bolt and remove cover (15).


**10. Sleeve**

Screw in jack bolts (Thread dia. = 16 mm, Pitch = 2.0 mm) and remove sleeves (16), (17) and (18).


★ Since there are two kinds of sleeves, confirm their location before removal.

11. Yoke


Loosen lock nut and remove F-R yoke (19) and inching yoke (20) from spool.

**12. Sleeve**

Remove snap ring and move sleeve (21) to the right side to disconnect from control valve.


**13. Transmission control valve**

Remove four mounting bolts (Thread dia. = 10 mm) and lift transmission control valve (22) to remove.



14. Sleeve


Remove sleeves (21) and (24).



23P159

15. Transmission case


- 1) Set transmission in place with its transfer case faced down.
 - ★ Before setting in place, remove mounting bolts tightened from transfer case side.




23P160

- 2) Install eye bolts ① (Thread dia. = 10 mm, Pitch = 1.75 mm) and ② (Thread dia. = 12 mm, Pitch = 1.75 mm). Sling and remove transmission case (25).

★ Slowly sling transmission case horizontally.

 Transmission case: Approx. 130kg



23P161


16. Checking air

Using tool A, measure piston stroke at each speed stage (F, R, 3rd, 2nd and L) as well as check their function.

- ★ Air pressure: 5kg/cm² min.
- ★ Pistn stroke

(Unit: mm)

| Speed stage | F | R | 3rd | 2nd | L |
|-------------|-----|-----|-----|-----|-----|
| Stroke | 3.5 | 3.5 | 2.5 | 2.5 | 3.5 |




23P162

17. Cage and reverse travel carrier assembly

- 1) Remove tie bolt.
- 2) Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and remove cage and reverse travel carrier assembly (26).



Cage and reverse travel carrier assembly:
Approx. 35kg



23P163

18. Reverse travel ring gear


Remove ring gear (27).

19. Spring

Remove spring (28).


20. Spring, Disc, Plate

- 1) Remove spring (29).




- 2) Remove discs (30), plates (31) and spring (29) in order.

★ Disc: 3 pcs. Plate: 2 pcs.

**21. Reverse travel piston and housing assembly**

Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and remove reverse travel piston and housing assembly (32).




22. Reverse travel ring gear

Remove snap ring (33), remove ring gear (34).

23. Spring


Remove spring (35).



24. Spring, Disc, Plate

Remove spring (36), discs (37) and plates (38).


★ Disc: 3 pcs. Plate: 2 pcs.



25. Ring gear

Remove ring gear (39).

★ Confirm installing direction of ring gear before removal.




26. Forward travel and 3rd speed pistons and housing assembly

Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and remove forward travel and 3rd speed pistons and housings assembly (40).

★ Hold 3rd speed piston by the hand to prevent falling.



Forward and 3rd speed pistons and housings assembly: Approx. 35kg



27. Spring

Remove spring (41).


28. Spring, Disc, Plate

Remove spring (42), discs (43) and plate (44) in order.

★ Disc: 2 pcs. Plate: 1 pc.

29. Pin


Remove pin (45).

**30. Snap ring**

Remove snap ring (46).

31. Forward travel and 3rd speed carriers assembly


Using gear puller ④ ($\phi 219$) pull out forward and 3rd speed carriers assembly (47).

**32. Spacer**

Remove spacer (48).

33. 3rd speed sun gear


Remove 3rd speed sun gear (49).

**34. 3rd speed ring gear**

Remove snap ring (50), remove 3rd speed ring gear (51).

35. Spacer


Remove spacer (52).



36. 2nd speed piston and housing assembly

Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and remove 2nd speed piston and housing assembly (53).

★ Hold piston by the hand to prevent falling.


**37. Spring**

Remove spring (54).


38. Spring, Disc, Plate

Remove spring (55), discs (56) and plate (57).


★ Disc: 2 pcs. Plate: 1 pc.

**39. 2nd speed ring gear**

Remove 2nd speed ring gear (58).


**40. 1st speed housing**

Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and remove 1st speed housing (59).




41. 1st speed rotary clutch

Install sling plate (5) . Sling and remove 1st speed clutch (60).

 1st speed clutch: Approx. 85kg


- ★ Sling plate mounting bolt:
Thread dia. = 14 mm, Pitch = 2.0

**42. Cage**


Remove cage (61).

43. No. 1 gear

Remove No. 1 gear (62).

**44. Cage**


Remove cage (63).

**45. Worm**

Remove worm (64).


46. Spacer

Remove spacer (65).



47. Low piston housing

- 1) Remove tie bolt.
 - 2) Using push puller ⑥ pull out low piston housing (66) from shaft.
 - 3) Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and remove low piston housing.
- ★ Hold piston with the hand to prevent falling.




48. Spring

Remove spring (67).

49. Spring, Disc, Plate

Remove spring (68), discs (69) and plates (70) in order.

★ Disc: 3 pcs. Plate: 2 pcs.




50. Low ring gear

Remove low ring gear (71).


51. Pin

Remove pin (72).



52. Housing

Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and remove housing (73).




53. High speed rotary clutch


- 1) Remove four cage mounting bolts (74).
- 2) Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and remove high speed rotary clutch (75).



High speed rotary clutch: Approx. 75kg

**54. Cage**


- 1) Place transfer in place with its mounting face down.
 - 2) Screw in jack bolt and remove cage (76).
- ★ Keep shims identified their location.

**55. Cage**


- Screw in jack bolt and remove cage (77).
- ★ Keep shims identified their location.

56. Cage

- Screw in jack bolt and remove cage (78).
- ★ Keep shims identified their location.

**57. Cage**

- Screw in jack bolt and remove cage (79).
- ★ Keep shims identified their location.

**58. No. 2 gear**

Remove gear (80).

59. Bearing


Remove bearing (81) together with collar (82) as an assembly.

60. Shaft


Remove shaft (83).

61. No. 3 gear


Remove gear (84).

**62. Bearing**


- 1) Remove bearing (85) together with collar (86) as an assembly.



- 2) Remove bearing outer races (87) and (88) from transfer case.


**63. Valve**

Remove plate (89), remove valve (90), spring (91) and sleeve (92).





ASSEMBLY OF HYDROSHIFT TRANSMISSION

GD705R-4




Special tools


| | Part number | Part name | Q'ty |
|---|--------------|---------------|------|
| A | 799-301-1300 | Air checker | 1 |
| B | 792-371-1500 | Spline shaft | 1 |
| | 795-630-1830 | Adaptor | 1 |
| | 795-630-1810 | Torque wrench | 1 |



23F020




23F02 I



★ Apply engine oil to sliding portion of each part before installing.

1. Valve


- 1) Fix transfer case with its mounting face down.
- 2) Install sleeve (92), install spring (91), valve (90) and plate (89).




23P197

2. Cage


- 1) Using push tool ($\phi 130$) press-fit bearing outer races (87) and (88).



- 2) Using push tool ($\phi 130$) press-fit bearing outer race (93).
- 3) Using push tool ($\phi 90$) press-fit bearing (94) and install snap ring (95) to lock bearing.




- 4) Fix transfer case with its mounting face up.
- 5) Install cage (96).




3. No. 4 gear

- 1) Using press-fitting tool ⑦ ($\phi 75$) press-fit bearing (98) to gear (97).




- 2) Fix transfer case with its mounting face down.
- 3) Install No. 4 gear (99).
 - ★ Number of teeth: $Z = 22$
- 4) Fit O-ring and install sleeve (100).




4. Cage

- 1) Using press-fitting tool ($\phi 130$) press-fit bearing outer race (101).
- 2) Using press-fitting tool ($\phi 70$) press-fit collar (102) aligning mounting position and install ball (103).
 - ★ If mounting position is not aligned, ball cannot be installed.
- 3) Install snap ring (104) to press ball.




- 4) Insert shims (105) into mounting portion and install cage (76).
 - ★ Use removed shims, the same amount at upper and lower sides.

Ⓜ kgm Mounting bolt: 11 ± 1.5 kgm




5) Adjusting bearing preload

- ★ Transfer gears are No. 1, No. 2 and No. 4 from input side.
 - i) Fix transfer case with its mounting face directed forward.
 - ii) Install tool **B** to measure starting torque of No. 4 gear alone and confirm that it is within standard. Adjustment can be accomplished by increasing or decreasing shims.
 - ★ Starting torque: 1 to 10 kgcm
 - ★ Measure starting torque after racing gear 4 or 5 turns and use the minimum value.



5. Bearing


- 1) Fix transfer case with its mounting face down.
- 2) Press-fit bearing (85) into collar (86) and install it on transfer case.



6. No. 3 gear


Install No. 3 gear (84).

- ★ Number of teeth: $Z = 30$
- ★ Gear has proper installing direction and install it with its spot faced boss faced up.



7. Shaft

Install snap ring and install shaft (83).



8. Bearing


Press-fit bearing (81) to collar (82) and install it on shaft.

9. Cage

- 1) Using press-fitting tool ($\phi 130$) press-fit bearing outer race (106).
- 2) Fit O-ring and install cage (77) with shims (107) inserted into mounting portion.

- ★ Use removed shims as they are, the same amount at right and left sides.


Mounting bolt: $11 \pm 1.5\text{kgm}$



3) Adjusting bearing preload

- i) Fix transfer case with its mounting face directed frontward.
- ii) Install tool **B** and measure starting torque with No. 4 gear (total starting torque of No. 4 and No. 3 gears) and confirm that it is within standard. Adjustment can be accomplished by increasing or decreasing shims.


- ★ Starting torque: 2 to 17 kgcm
- ★ Measure starting torque after racing gear 4 or 5 turns and use the minimum value.
- ★ Adjust preload so that starting torque increases more than 1kgcm and less than 10kgcm as gear is added one each.



23P207

10. No. 2 gear

- 1) Using press-fitting tool ⑦ ($\phi 75$) press-fit bearings (109) to both ends of gear (108).
 - 2) Install gear (80).
- ★ Number of teeth: $Z = 31$





23P215

23P216

11. Cage

- 1) Using press-fitting tool ($\phi 130$) press-fit bearing outer race (110).
 - 2) Fit O-ring, inserted shims (111) to mounting portion, install cage (78).
- Use removed shims as they are, the same amount at right and left sides.

 Mounting bolt: $11 \pm 1.5\text{kgm}$




23P217

23P218

3) Adjusting bearing preload

Install tool **B** in the same manner described in 9-3) section, measure starting torque with No. 4 gear (total starting torque of No. 4, No. 3 and No. 2 gears) and confirm that it is within standard. Adjustment can be accomplished by increasing or decreasing shims.


- ★ Starting torque: 3 to 24 kgcm
- ★ Other instructions are subject to those described in 9-3) section.




23P207

12. No. 1 gear

- 1) Fix transfer case with its mounting face up.
 - 2) Using press-fitting tool ⑧ ($\phi 85$) press-fit bearings (113) to both ends of gear (112).
 - 3) Install No. 1 gear (62).
- ★ Number of teeth: $Z = 32$


**13. Cage**

- 1) Using press-fitting tool ($\phi 130$) press-fit bearing outer race (114).
- 2) Install cage (61).

**14. Cage**


- 1) Fix transfer case with its mounting face down.
- 2) Using press-fitting tool ($\phi 130$) press-fit bearing outer race (115).
- 3) Fit O-ring, insert shims (116) to mounting portion, install cage (79).

Ⓜ Mounting bolt: $17 \pm 1 \text{ kgm}$



- 4) Adjusting bearing preload
Install tool B in the same manner as described in 9-3) section, measure starting torque with No. 4 gear (total starting torque of No. 4, No. 3, No. 2 and No. 1 gears), confirm that it is within standard. Adjustment can be accomplished by increasing or decreasing shims.

- ★ Starting torque: 3.5 to 30.5 kgcm
 ★ Other instructions are subject to those described in 9-3) section.




15. High speed rotary clutch


- 1) Fix transfer case with its mounting face up.
- 2) Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and remove high speed rotary clutch (75).



High rotary clutch: Approx. 70kg

**16. Housing**


- Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and install housing (73).

**17. Pin**

- Install pin (72).

18. Low ring gear


- Install low ring gear (71).
 ★ Install ring gear with its recessed inner teeth side up.

**19. Spring, Disc, Plate**

- Install spring (68), discs (69) and plates (70).
 ★ Install discs aligning their notches in the same position.
 ★ Disc: 3 pcs. Plate: 2 pcs.


20. Spring

- Install spring (67).



21. Low piston housing


- 1) Using press-fitting tool ($\phi 140$) press-fit bearing (117).



23P230

- 2) Install seal rings (120) on piston (118) and housing (119) and install piston in housing.


★ Install seal ring with care to avoid twisting.



23P231

- 3) Fit O-ring, install eye bolts ③ (Thread dia. 14 mm, Pitch = 2.0 mm). Sling and install low piston housing (66).

★ Hold piston by the hand to prevent falling off.




23P232


- 4) Using push tool ⑨ ($\phi 80$) install low piston housing (66).

★ Install housing with care not to damage planetary carrier seal ring.

- 5) Tighten tie bolt.

 kgm Tie bolt: 17 ± 1 kgm

★ Confirm that spring (67) is firmly installed in housing and piston groove.




23P233

22. Spacer

Install seal ring (121) and install spacer (65).

23. Worm


Install worm (64).


**24. Cage**

1) Using push tool ($\phi 97$) install oil seal (122) and install speedometer shaft (123).

★ Charge grease (G2-L1) to oil seal lip groove to fill up 40 to 60%.

2) Fit O-rings (two) and install cage (63).


 Mounting bolt: $11 \pm 1.5\text{kgm}$

**25. Cage**

1) Fix transfer case with its mounting face directed to the other side.

2) Screw in jack bolt and remove cage (76).

★ Keep removed shims identified their location.


**26. Snap ring**

Install snap ring (124).

27. Seal ring

Install seal ring (125).


★ Install seal rings not aligning their slits.




28. Cage

Fit O-ring, insert shims in mounting portion and install cage (76).


- ★ Install cage with care not to damage seal ring.
- ★ Install removed shims as they are.


 Mounting bolt: $11 \pm 1.5\text{kgm}$



29. 1st speed rotary clutch

- 1) Fix transfer case with its mounting face up.
- 2) Install sling plates (5). Sling and install 1st speed rotary clutch (60).

 1st speed rotary clutch: Approx. 85kg





30. 2nd speed sun gear

Install 2nd speed sun gear (126).

31. Spacer


Install spacer (52).

 Inside surface of bushing: Grease (G2-L1)



32. 1st speed housing


Install eye bolts (3) (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and install 1st speed housing (59).



33. 2nd speed ring gear

Install 2nd speed ring gear (58).

- ★ Install ring gear with its recessed inner teeth side down.


**34. Pin**

Install pin (45).

35. Spring, Disc, Plate

Install spring (55), discs (56) and plate (57) in order.


- ★ Install discs aligning notches of inner teeth in the same position.
- ★ Disc: 2 pcs. Plate: 1 pc.

**36. Spring**

Install spring (54).

37. 2nd speed piston and housing assembly


- 1) Install seal ring and install piston in housing.
- 2) Install 2nd speed piston and housing assembly (53).
 - ★ Hold piston by the hand to prevent falling off.
 - ★ Confirm that spring (54) is firmly installed in housing and piston groove.

**38. 3rd speed sun gear**

Install 3rd speed sun gear (49).

39. Spacer


Install spacer (48).



40. 3rd speed ring gear


Install 3rd speed ring gear (51) and fix it with snap ring (50).

- ★ Confirm that ring gear is firmly installed on planetary carrier.



41. Forward travel and 3rd speed carriers assembly

- 1) Install seal ring (128) and planetary gear.
 - ★ Refer to "INSTALLATION OF PLANETARY GEAR" section.
- 2) Using push tool ⑨ (φ80) install forward travel and 3rd speed carriers assembly (47).




42. Snap ring

Install snap ring (46).

43. Spring, Disc, Plate

Install spring (42), discs (43) and plate (44) in order.

- ★ Install discs aligning their notches in the same position.
- ★ Disc: 2 pcs. Plate: 1 pc.




44. Spring

Install spring (41).

45. Forward travel and 3rd speed piston and housing assembly

- 1) Install seal ring and install piston in housing.
- 2) Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and install forward travel and 3rd speed pistons and housing assembly (40).
- ★ Hold pistons by the hand to prevent falling off and confirm that springs are installed firmly in housings and piston groove.


Forward and 3rd speed piston and housing assembly: Approx. 35kg



46. Ring gear


Install ring gear (39).

- ★ Install ring gear with recessed inner teeth up.

**47. Spring, Disc, Plate**

Install spring (36), discs (37) and plate (38) in order.

- ★ Install discs aligning notches of inner teeth in the same position.
- ★ Disc: 3 pcs. Plate: 2 pcs.


**48. Spring**

Install spring (35).


49. Reverse travel ring gear

Install reverse travel ring gear (34) and fix it with snap ring (33).

- ★ Confirm that ring gear is firmly installed on planetary carrier.

**50. Reverse travel piston and housing assembly**


- 1) Install seal ring and install piston on housing.
 - 2) Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and install reverse travel piston and housing assembly (32).
- ★ Confirm that spring (35) is firmly installed in housing and piston groove.



51. Reverse travel ring gear

Install reverse travel ring gear (27).


- ★ Install ring gear with its ring gear inner teeth up.



52. Spring, Disc, Plate

Install spring (29), discs (30) and plates (31) in order.

- ★ Install discs aligning notches of inner teeth in the same position.
- ★ Disc: 3 pcs. Plate: 2 pcs.




53. Spring

Install spring (28).


54. Cage and reverse travel carrier assembly

- 1) Install eye bolts ③ (Thread dia. = 14 mm, Pitch = 2.0 mm). Sling and install cage and reverse travel carrier assembly (26).

- 2) Tighten tie bolt.

 Tie bolt: 17 ± 1kgm

- ★ Confirm that spring (28) is firmly installed in housing and piston groove.




55. Checking air

Using tool A check function of piston at each speed stage (F, R, 3rd, 2nd and L). Measure piston stroke and confirm that it is within standard.

- ★ Air pressure: 5kg/cm² min.
- ★ Piston stroke




(Unit: mm)


| Speed stage | F | R | 3rd | 2nd | L |
|-------------|-----|-----|-----|-----|-----|
| Stroke | 3.5 | 3.5 | 2.5 | 2.5 | 3.5 |




56. Transmission case


Attach gasket to mounting face, install eye bolts ① (Thread dia. = 10 mm, Pitch = 1.5 mm) and ② (Thread dia. = 12 mm, Pitch = 1.75 mm). Sling and install transmission case (25).

-  Gasket: Gasket sealant (LG-1)
 Mounting bolt: $18 \pm 2\text{kgm}$
 Transmission case: Approx. 130kg

**57. Sleeve**


- 1) Raise up transmission and fix it with transmission control valve mounting face directed forward.
- 2) Fit O-rings to both ends and install sleeves (21) and (24).


 O-ring: Grease (G2-L1)

**58. Transmission control valve**


Attach O-ring to mounting surface, insert transmission control valve (22) into sleeve (24) and install.

- ★ When inserting transmission control valve into sleeve, be careful not to damage O-ring of sleeve.

 Mounting bolt: $3.5 \pm 0.5\text{kgm}$

**59. Sleeve**


Move sleeve (21) to the left side to connect to control valve, install snap ring to fix sleeve.



60. Yoke


Install F-R yoke (19) and inching yoke (20) setting distance "a" at the standard at the state where spool is pulled and tighten lock nut to fix them on spool.


★ Distance "a": 19mm



61. Sleeve


Fit O-rings to both ends and install sleeves (16), (17) and (18).


 O-ring: Grease (G2-LI)




62. Cover


1) Attach gasket, connect speed selector lever to spool yoke, install cover (15).


 Gasket: Gasket sealant (LG-1)


 Mounting bolt: $7 \pm 0.5\text{kgm}$

2) Remove cover (129) to confirm whether speed selector lever is firmly connected to spool and install cover with gasket attached.

 Gasket: Gasket sealant (LG-1)


 Mounting bolt: Gasket sealant (LG-1)


 Mounting bolt: $3.5 \pm 0.5\text{kgm}$



63. Transmission control valve


Fit O-ring to mounting portion and install transmission control valve (13) together with cooler bypass valve (14) as an assembly.

 Mounting bolt: $4.5 \pm 1\text{kgm}$



64. Lubricating tube

Attach gaskets to both ends and install lubricating tube (12).

 Joint bolt: 11.5 ± 2.5kgm


65. Piping

Fit O-rings to both ends and install tubes (9), (10) and (11).

66. Transmission control rod

Fit bracket (8) and connect the transmission control rod (7) on lever (control valve side).

★ Bend down cotter pin firmly.




23P153


67. Transmission control valve piping

1) Fit O-rings to both ends and install control valve tubes (4) and (5).

★ Install strainer in tube (4).

2) Fit O-ring and install control valve tube (6).


 Control valve common tightening bolt: 4.5 ± 1kgm



23P152

68. Parking brake

Install parking brake assembly (3).



 Mounting bolt: 18 ± 2kgm


★ Bend down lock plate firmly.

69. Flange

1) Install flange (2) on shaft.

2) Fit O-ring and install holder (130) and tighten center bolt.


 Center bolt: Thread tightener (LT-2)
 Center bolt: 23.5 ± 2.5kgm




23P151


70. Drum

Install brake drum (1).

 Mounting bolt: 18 ± 2kgm




23P149



23P253


**DISASSEMBLY OF CAGE AND REVERSE CARRIER ASSEMBLY
GD705R-4**



23F022

1. Forward sun gear

Remove snap ring (1) and remove forward sun gear (2).




2. Snap ring

Remove snap ring (3).


3. Reverse sun gear

Remove snap ring (4) and remove reverse sun gear (5).




4. Spacer


Remove spacer (6).

**5. Input shaft**


Using press-fitting tool ① pull out input shaft (7).

**6. Reverse carrier assembly**

- 1) Remove snap ring (8).
- 2) Using press-fitting tool ② ($\phi 108$) pull out reverse carrier (9).

**7. Seal ring**


Remove seal ring (10).




23P260

8. Bearing

- 1) Remove snap ring (11).
- 2) Using press-fitting tool ③ ($\phi 139$) pull out bearing (12).


**9. Bearing**

- 1) Remove snap ring (13).
- 2) Using press-fitting tool ④ ($\phi 79$) pull out bearing (14).

**10. Planetary gear**

Refer to "DISASSEMBLY OF PLANETARY GEAR" section.

**ASSEMBLY OF CAGE AND REVERSE CARRIER ASSEMBLY
GD705R-4**




23F023

★ Coat sliding portion of each part with engine oil before installing.


1. Bearing

- 1) Using press-fitting tool ⑤ (φ160) press-fit bearing (12).
- 2) Install snap ring (11).



2. Seal ring

Install seal ring (10).




23P260

3. Planetary gear

Refer to "ASSEMBLY OF PLANETARY GEAR" section.


4. Bearing

- 1) Using press-fitting tool ⑥ ($\phi 90$) press-fit bearing (14).
- 2) Install snap ring (13).




5. Cage assembly

- 1) Using press-fitting tool ⑦ press-fit cage assembly.
 - ★ Press-fit cage using care not to damage its seal ring.
- 2) Install snap ring (8).




6. Input shaft

Using press-fitting tool ⑧ press-fit input shaft (7).



7. Spacer

Install spacer (6).




8. Reverse sun gear


Install reverse sun gear (5) and install snap ring (4).

9. Snap ring


Install snap ring (3).

**10. Forward sun gear**

Install forward sun gear (2) and install snap ring (1).



**DISASSEMBLY OF 1ST SPEED ROTARY CLUTCH
GD705R-4**




23F024

Special tools

| | Part number | Part name | Q'ty |
|---|--------------|-----------|------|
| A | 792-371-1300 | Plate | 1 |
| | 790-201-2350 | Push tool | 1 |

1. Housing assembly


- 1) Remove plate (1).
- 2) Remove housing (2).



23P269

2. Snap ring


- Remove snap ring (3).



23P270

3. Shaft, Bearing

- Set shaft (4) and bearing (5) in press and pull out them.




23P271

4. Collar

- Pull out collar (6).


5. 2nd speed carrier assembly

- 1) Remove mounting bolts (7) leaving two bolts un-removed.



23P272

- 2) Fix carrier faced up.
- 3) Remove remaining bolts and remove 2nd carrier assembly (8).




23P273

6. Spring, Disc, Plate

Remove spring (9), discs (10) and plates (11) in order.


★ Disc: 3 pcs. Plate: 2 pcs.



23P274

7. 1st speed gear


Remove gear (12).



23P275

8. Spacer

Remove spacer (13).




23P276


9. Spring

Be careful since spring is applied tension.

- 1) Put match marks on piston (14) and cage (15).
- 2) Using tool A compress spring with press and remove snap ring (17).
- 3) Remove snap ring (18).

**10. Piston assembly**


Remove piston assembly (19).



23P279


11. Cage assembly

- 1) Remove bolts mounting cage (20).




23P280

- 2) Using press-fitting tool ① ($\phi 90$) pull out cage assembly (22) from cage (21).



12. Cage


Remove cage (23).



23P283

13. Seal ring


Remove seal ring (24).



23P284


14. Bearing

Remove snap rings (25) and (26) and pull out bearings (27) and (28).



23P285

**ASSEMBLY OF 1ST SPEED ROTARY CLUTCH
GD705R-4**



23F025


Special tools

| | Part number | Part name | Q'ty |
|---|--------------|-----------|------|
| A | 792-371-1300 | Plate | 1 |
| | 790-201-2350 | Push tool | 1 |


★ Coat sliding portion of each part with engine oil before installing.

1. Bearing


- 1) Using press-fitting tool ② ($\phi 130$) press-fit bearing (28).



- 2) Using press-fitting tool ③ ($\phi 75$) press-fit bearing (27).




- 3) Install snap rings (25) and (26).



2. Seal ring


Install seal rings (24).

- ★ Install rings not aligning their slits.



3. Cage assembly


Using press-fitting tool ④ ($\phi 115$) press-fit cage assembly (22) to cage (21).

**4. Cage**

Install cage (23) aligning its oil vent with that on cage (21).


★ Install cage using care not to damage seal ring.

Mounting bolt: Thread tightener (LT-2)
 Mounting bolt: $1.35 \pm 0.15\text{kgm}$


**5. Piston assembly**

1) Install seal rings (29) and (30) on piston.

★ Install seal rings using care to avoid twisting.




2) Install piston assembly (19) aligned with match mark put when disassembled.




6. Spring

- 1) Install spring (18).
- 2) Be sure to align match marks on piston and cage and install snap ring (17) compressing spring with press using tool A.
- ★ Secure snap ring firmly.




7. Spacer

Install spacer (13).




8. Shaft

Press-fit shaft (4).



9. 1st speed gear


Install gear (12).



10. Spring, Disc, Plate


Install spring (9), discs (10) and plates (11) in order.

- ★ Disc: 3 pcs. Plate: 2 pcs.
- ★ Align plate internal teeth with piston external teeth.






11. 2nd speed carrier assembly

1) Align mounting bolt holes and install 2nd speed carrier assembly (8).




2) Fix cage faced up and tighten mounting bolts (7).

-  Mounting bolt: Thread tightener (LT-2)
-  Mounting bolt: 11 ± 1.5kgm




12. Collar

- 1) Install seal rings (31) on collar.
 - ★ Install seal rings not aligning their slits.
- 2) Using press-fitting tool (5) (φ76) press-fit collar (6).
 - ★ Press-fit collar using care not to damage seal ring.




13. Bearing

Using press-fitting tool ⑤ ($\phi 76$) press-fit bearing (5).




14. Snap ring

Install snap ring (3).





15. Housing assembly


1) Install housing assembly (2).




2) Install plate (1).

 Mounting bolt: Thread tightener (LT-2)

 Mounting bolt: $6.5 \pm 1.0\text{kgm}$




**DISASSEMBLY OF HIGH SPEED ROTARY CLUTCH
GD705R-4**




Special tools

| | Part number | Part name | Q'ty |
|----------|--------------|-----------|------|
| A | 792-371-1400 | Sleeve | 1 |
| | 790-201-2660 | Push tool | 1 |
| | 790-201-2760 | Push tool | 1 |

1. **Seal ring**
Remove seal ring (1).




2. **Gear assembly**
 - 1) Remove snap ring (2).
 - 2) Remove gear assembly (3).




3. Cage assembly

Remove cage assembly (4).


**4. Drum**

Remove mounting bolts and remove drum (5).


**5. Spring, Disc, Plate**

Remove spring (6), discs (7) and plates (8) in order.

★ Disc: 3 pcs. Plate: 2 pcs.

**6. High gear**

Remove gear (9).




7. Spring



Be careful since spring is applied tension.

- 1) Put match marks on piston (10) and carrier (11).
- 2) Using tool **A** compress spring (12) with press and remove snap ring (13).
- 3) Remove cage (14) and remove spring (12).



8. Piston assembly


- 1) Remove pin (15) and remove piston assembly (10).

9. Cage

- 1) Remove snap ring (16).
- 2) Remove cage (17).

10. Shaft assembly

- 1) Remove shaft (18).
- 2) Remove bushing (19) and seal ring (20) from shaft assembly.







11. Seal ring

Remove seal ring (21).


12. Planetary gear

Remove planetary gear (22).

★ Refer to "DISASSEMBLY OF PLANETARY GEAR" section for removal of planetary gear..



**ASSEMBLY OF HIGH SPEED ROTARY CLUTCH
GD705R-4**



Special tools

| | Part number | Part name | Q'ty |
|---|--------------|-----------|------|
| A | 792-371-1400 | Sleeve | 1 |
| | 790-201-2660 | Push tool | 1 |
| | 790-201-2760 | Push tool | 1 |

★ Coat sliding portion of each part with engine oil before installing.


1. Planetary gear

Install planetary gear (22).

★ Refer to "ASSEMBLY OF PLANETARY GEAR" section for installing planetary gear.

2. Seal ring

Install seal ring (21).




23P317

3. Shaft assembly

1) Press-fit bushing (19) to shaft and install seal rings (20).

★ Install seal rings not aligning their slits.

2) Install shaft assembly (18) on carrier assembly.





23P316

23P315


4. Cage

- 1) Install seal ring (23) and install cage (17).

 Mounting bolt: Thread tightener (LT-2)


 Mounting bolt: $3 \pm 0.5\text{kgm}$

- 2) Install snap ring (16).




5. Piston assembly

- 1) Install seal ring (24) on piston.




- 2) Install piston assembly (10) aligning match marks put when disassembled and install pin (15).




6. Spring

- 1) Install spring (12) and cage (14).




- 2) Confirm that match marks on piston and carrier are aligned and install snap ring (13) by compressing spring with press, using tool **A**.

★ Secure snap ring firmly.



7 High gear


Install gear (9).



8. Spring, Disc, Plate


Install spring (6), discs (7) and plates (8) in order.


- ★ Disc: 3 pcs. Plate: 2 pcs.
- ★ Align plate internal teeth with piston external teeth.



9. Drum


- 1) Press-fit bearing outer race to drum.
- 2) Install drum (5) aligning mounting bolt holes.

 Mounting bolt: $11 \pm 1.5\text{kgm}$



DISASSEMBLY OF PLANETARY GEAR GD705R-4


1. Pull out shaft (2) from planetary carrier assembly (1) to remove ball (3), and remove thrust washer (4), gear (5) and thrust washer (6) in that order.
2. Pull out bearing (7) from gear (5).



ASSEMBLY OF PLANETARY GEAR GD705R-4


★ Coat sliding portion of each part with engine oil before installing.


1. Install bearing (7) on gear (5).
2. While inserting carrier into shaft (2), install thrust washer (6), gear (5) and thrust washer (4), and at last fix shaft with ball (3).
 - ★ If shaft comes out, calk slightly carrier ball groove.
3. After assembling, measuer side clearance of planetary gear (5) with feeler gauge ① and confirm that it is within standard.
 - ★ Side clearace: 0.35 – 0.8 mm




DISASSEMBLY OF HYDROSHIFT TRANSMISSION ASSEMBLY


GD705A-4







F23ECO10






F23EC011






F23EC012


- 1. **Drum**
Remove brake drum (1).




- 2. **Flange**
Remove center bolt and dismount flange (2).



- 3. **Parking brake assembly**
Remove parking brake assembly (3).



- 4. **Transmission control valve piping**
Remove transmission control valve tubes (4), (5).




5. Piping

Remove tube (6).

6. Lubrication tube


Remove lubrication tube (7).



P23EC109

7. Transmission control valve assembly


Remove transmission control valve assembly (8) together with cooler by-pass valve assembly (9).



P23EC110

8. Cover

Screw in jack bolt and remove cover (10).



P23EC111


9. Sleeve

Screw in jack bolt (Thread dia. = 10 mm, Pitch = 1.5 mm), (Thread dia. = 16 mm, Pitch = 2.0 mm) and remove sleeves (11), (12) and (13).

★ As there are two kinds of sleeves, check the mounting position at removal.

10. Yoke

Loosen lock nut, remove F · R yokes (14) and yoke (15) for inching from spool.




P23EC112

11. Sleeve

Remove snap rings, shift sleeves (16), (17) to right side and disconnect it from control valve.

12. Transmission control valve assembly


Remove four mounting bolts (Thread dia. = 10 mm), lift up control valve assembly (18) and dismount it.



P23EC113

13. Sleeve


Remove sleeves (16), (17).



P23EC114

14. Transmission case


- 1) Set transmission in place with its transfer case facing down.
 - ★ Before setting in place, remove mounting bolts from transfer case side.
- 2) Install eye bolt, lift transmission case (19) and dismount it.
 - ★ Slowly sling transmission case horizontally.



P23EC115

15. Sleeve


Remove sleeve (20).



P23EC116

16. Cage and reverse carrier assembly

- 1) Remove tie bolt.
- 2) Install eye bolts, sling cage and reverse carrier assembly (21) and remove it.



P23EC117

17. Reverse ring gear

Remove ring gear (22).


18. Spring

Remove spring (23).

19. Spring, Disc, Plate

Remove spring (24), disc (25) and plate (26) in order.


- ★ Disc: 4 pcs Plate: 3 pcs



P23EC118

20. Reverse ring gear

Remove snap ring (27) and remove ring gear (28).



P23EC119

21. Reverse piston and housing assembly

Install eye bolts, sling reverse piston and housing assembly (29) and remove them.

22. Forward piston

Remove forward piston (30).


23. Spring

Remove spring (31).

24. Spring, Disc, Plate


Remove spring (32), disc (33), plate (34) in order.

- ★ Disc: 4 pcs Plate: 3 pcs




P23EC120

- 25. **Forward ring gear**
Remove ring gear (35).




- 26. **Cage and forward carrier assembly**
Install eye bolt, sling cage and forward carrier assembly (36) and remove them.



- 27. **Spring**
Remove spring (37).


- 28. **Spring, Disc, Plate**
Remove spring (38), disc (39) and plate (40) in order.
★ Disc: 3 pcs, Plate: 2 pcs

- 29. **Pin**
Remove pin (41).




- 30. **4th ring gear**
Remove ring gear (42).

- 31. **Bearing**
Remove holder and remove bearing (43).



32. 3rd and 4th carrier assembly

Remove 3rd and 4th carrier assembly (44).




P23EC125

33. 3rd, 4th piston and housing assembly

Remove 3rd, 4th piston and housing assembly (45).

★ Hold 3rd speed piston by hand to prevent falling.



P23EC126

34. Spring

Remove spring (46).


35. Spring, Disc, Plate

Remove spring (47), disc (48), plate (49) in order.

★ Disc: 3 pcs, Plate: 2 pcs

36. 3rd and 4th sun gear

Remove 4th sun gear (50), spacer (51) and 3rd sun gear (52).



P23EC127


37. 3rd ring gear

Remove snap ring and remove ring gear (53).

38. 2nd piston and housing assembly

Remove 2nd piston and housing assembly (54).


★ Hold piston by hand to prevent falling.




P23EC128

39. **Spring**
Remove spring (55).


40. **Spring, Disc, Plate**
Remove spring (56), disc (57) and plate (58) in order.
★ Disc: 2 pcs, Plate: 1 pc



41. **1st, 2nd carrier assembly**
Install eye bolts, sling 1st and 2nd carrier assembly (59) then remove them.




42. **1st piston and housing assembly**
Remove 1st piston and housing assembly (60).
★ Hold piston by hand to prevent falling.



43. **1st ring gear**
Remove ring gear (61).

44. **Spring**
Remove spring (62).


45. **Spring, Disc, Plate**
Remove wave spring (63), disc (64) and plate (65) in order.
★ Wave spring: 3 pcs, Disc: 3 pcs, Plate: 2 pcs.



46. Cage assembly

Remove cage assembly (66).

- ★ Align pin and hole and confirm the position.



P23EC132

47. Spring

Remove spring (67).


48. Spring, Disc, Plate

Remove spring (68), disc (69) and plate (70) in order.

- ★ Disc: 5 pcs, Plate: 4 pcs

49. Pin

Remove pin (71).



P23EC133


50. Low ring gear

Remove ring gear (72).

51. Low piston and housing assembly

Remove low piston and housing assembly (73).


- ★ Align hole of housing and pin of transfer case and confirm the position.



P23EC134

52. Cage assembly

- 1) Face transfer case side up and insert block to prevent high revolution clutch assembly from falling.
- 2) Screw in jack bolt and remove cage assembly (74).




P23EC135

53. Bearing inner race

Remove snap ring (75) and remove bearing inner race (76).

54. Spacer


Remove spacer (77).



55. High revolution clutch assembly


Lift transfer case (78) and remove high revolution clutch (79).

★ Slowly sling transfer case horizontally.




56. Cage

Screw in jack bolt and remove cage (80) together with bearing outer race.



57. Bearing

Remove holder (81) and remove bearing inner race (93).



58. Cage

Remove cage (82).

59. Shaft

Remove shaft (83) together with bearing (84).

60. Cage

Screw in jack bolt and remove cage (85).

61. Cage

Screw in jack bolt and remove cage (86) together with bearing outer race.

62. Bearing

Remove bearing inner race (87).

63. Gear

Remove gear (88).

64. Shaft

Remove shaft (89) together with bearing inner race.

65. Gear

Shift gear (90) to hole of neighbor and pull it out.


66. Cage assembly

Screw in jack bolt and remove cage (91) together with bearing outer race.


67. Gear

Remove gear (92).


★ Confirm installation direction.




P23EC140




P23EC141



P23EC142




P23EC144




P23EC143


ASSEMBLY OF HYDROSHIFT TRANSMISSION ASSEMBLY


GD705A-4







F23ECO14





F23EC015





F23ECO16

★ Apply engine oil to sliding portion of each part before installation.


1. Gear

Install gear (92).

★ Confirm installation direction of gear.

2. Cage assembly

Insert bearing outer race to cage (91), fix snap ring and mount it to transfer case.



3. Gear

Insert gear (90) from center hole and shift it to the hole of out put shaft side.


4. Shaft

1) Press-fit bearing outer race to transfer case.

2) Press-fit bearing inner race to shaft (89).

3) Mount shaft.

★ Confirm installing direction of shaft.



5. Gear

Install gear (88).


6. Bearing

Using press-fitting tool, press-fit bearing (87).

7. Cage

1) Press-fit bearing outer race to cage (86).

2) Fit O-ring and install cage (86).




8. Cage

Fit O-ring and install cage (85).


9. Shaft


Press-fit bearing (84) to shaft (83) and install shaft (83).



10. Cage

- 1) Use push tool to install oil seal.
 - ★ Charge grease (G2-L1) to oil seal lip groove to fill it up to 40 to 60%.
 - ★ Coat fluid gasket to press-fit face of oil seal.
- 2) Fit O-ring to mounting face and install cage (82).


 Mounting bolt: 11.25 ± 1.25 kgm





P23EC140

11. Bearing

Using press-fit tool, press-fit bearing (93) and install holder (81).

 Mounting bolt: Thread tightener (LT-2)


 Mounting bolt: 18 ± 2 kgm



P23EC139

12. Cage


Press-fit bearing outer race to cage (80), fit O-ring to cage and install it.



P23EC138

13. High revolution clutch assembly

- 1) Put high revolution clutch assembly (79) on the block.
- 2) Lift transfer case (78) and put it on the high revolution clutch assembly.
 - ★ Slowly put horizontally on transfer case.




P23EC137

14. Spacer


Install spacer (77).


15. Bearing inner race

Press-fit bearing inner race (76) and fix it with snap ring (75).


**16. Cage assembly**

Fix O-ring and install cage assembly (74).

 kgm Mounting bolt: 17 ± 1 kgm


**17. Low piston and housing assembly**

- 1) Install ring (94) to piston and housing.
 - ★ Install ring without twisting.
- 2) Install low piston and housing assembly (73).
 - ★ Be careful about align position of pin.

**18. Low ring gear**

Install ring gear (72).

- ★ Confirm that ring gear is firmly installed on planetary carrier.



19. Pin

Install pin (71).


20. Spring, Disc, Plate

Spring (68), disc (69) and plate (70) in order.

★ Disc: 5 pcs, Plate: 4 pcs

21. Spring

Install spring (67).




P23EC133

22. Cage assembly

Install cage assembly (66).

★ Be careful align position of pin.

★ Confirm that spring (67) is firmly installed in piston and groove of plate.



P23EC147

23. 1st ring gear


Install ring gear (61).

★ Install ring gear with its recessed inner teeth side down.

24. Spring, Disc, Plate

Install spring (63), disc (64) and plate (65) in order.

★ Wave spring: 3 pcs, Disc: 3 pcs, Plate: 2 pcs



P23EC131

25. Spring

Install spring (62).


26. 1st piston and housing assembly

1) Install piston and ring to housing.

2) Install 1st piston and housing assembly (60).

★ Hold piston by hand to prevent falling.

★ Confirm that spring (62) is firmly installed in cage and groove of piston.




P23EC130

27. 1st and 2nd carrier assembly

Install eye bolt, lift carrier assembly (59) and install it.

- ★ Confirm that sun gear and ring gear are firmly installed to planetary carrier.



P23EC129


28. Spring, Disc, Plate

Install spring (56), disc (57) and plate (58) in order.

- ★ Disc: 2 pcs, Plate: 1 pc

29. Spring

Install spring (55).



F23EC013


30. 2nd piston and housing assembly

1) Install ring to piston and housing

- ★ Install ring without twisting.

2) Install 2nd piston and housing assembly (54).

- ★ Hold piston by hand to prevent falling.
- ★ Confirm that spring (55) is firmly installed in housing and groove of piston.



P23EC148

31. 3rd ring gear

Install ring gear (53) and fix it with snap ring.

32. 3rd speed and 4th speed sun gear

Install spacer (51), 3rd speed sun gear (52) and 4th speed sun gear (50).


33. Spring, Disc, Plate

Spring (47), disc (48) and plate (49) in order.

- ★ Disc: 3 pcs, Plate: 2 pcs.

34. Spring


Install spring (46).



P23EC127

35. 3rd speed and 4th speed piston and housing assembly

- 1) Install ring to piston and housing.
 - ★ Install ring without twisting.
- 2) Install piston and housing assembly (45).
 - ★ Hold 3rd speed piston by hand to prevent falling.
 - ★ Confirm that spring (46) is firmly installed in housing and groove of piston.




P23EC149

36. 3rd speed and 4th speed carrier assembly

Install seal ring (95) to carrier assembly (44).


- ★ Confirm that ring gear and planetary gear are firmly engaged.





P23EC150

37. Bearing

Press-fit bearing (43) and install holder.

 Mounting bolt: Thread tightener (LT-2)

 Mounting bolt: 6.75 ± 0.75 kgm



P23EC124

38. 4th speed ring gear

Install ring gear (42).

- ★ Confirm that ring gear is firmly installed on planetary carrier.

39. Pin

Install pin (41).


40. Spring, Disc, Plate

Install spring (38), disc (39) and plate (40) in order.

- ★ Disc: 3 pcs, Plate: 3pcs

41. Spring

Install spring (37).




P23EC123

42. Cage and forward carrier assembly


Install eye bolt, sling cage and forward carrier assembly (36) and install it.

- ★ Confirm that spring (37) is firmly installed in piston and groove of cage.

**43. Forward ring gear**

Install ring gear (35).

- ★ Confirm that ring gear is firmly installed on planetary carrier.

**44. Spring, Disc, Plate**

Install spring (32), disc (33) and plate (34) in order.

- ★ Disc: 4 pcs, Plate: 3 pcs


45. Spring

Install spring (31).

46. Forward piston

Install teflon ring and install piston (30).

- ★ Install teflon ring without twisting.
- ★ Confirm that spring (31) is firmly installed in cage and groove of piston.

**47. Reverse piston and housing assembly**


1) Install teflon ring to piston and housing.

- ★ Install ring without twisting.

2) Install eye bolt, lift reverse piston and housing assembly (29) and install it.

48. Reverse ring gear

Install ring gear (28) and fix it with snap ring (27).



49. Reverse ring gear

Install ring gear (22).


50. Spring, Disc, Plate

Install spring (24), disc (25) and plate (26) in order.

★ Disc: 4 pcs, Plate: 3 pcs

51. Spring

Install spring (23).




P23EC118


52. Cage and reverse carrier assembly

1) Install eye bolt, lift cage and reverse carrier assembly (21) and then install it.

2) Tighten tie bolt.

 Tie bolt: 17 ± 1 kgm


★ Confirm that spring is firmly installed in piston and groove of cage.



P23EC117

53. Sleeve


Fix O-ring and install sleeve (20).




P23EC116

54. Transmission case

Attach gasket to mounting face, install eye bolt, lift transmission case (19) and mount it.


 Gasket: Liquid gasket (LG-1)



P23EC115

55. Sleeve


Fix O-ring to each side end and install sleeves (16), (17).




P23EC114

56. Transmission control valve assembly

Fix O-ring and install transmission control valve assembly (18).

 Mounting bolt: 3.5 ± 0.5 kgm



P23EC113


57. Sleeve

Shift sleeves (16), (17) to left side and connect them to control valve. Fix control valve with snap ring.

58. Yoke

Pull out spool and set to specified length.
Install F · R yokes (14) and yoke (15) for inching, then tighten their lock nuts.


★ a length: 12 mm



F23EC017

59. Sleeve


Fix O-ring on each side end and install sleeves (11), (12), (13).



P23EC112


60. Cover


- 1) Attach gasket, connect speed selector lever to yoke of spool and install cover (10).


 Gasket: Liquid gasket (LG-1)

- 2) Remove cover (96) and confirm that speed selector lever is connected firmly then attach gasket and install cover.

 Gasket: Liquid gasket (LG-1)

 Mounting bolt: Liquid gasket (LG-1)

 Mounting bolt: 3.5 ± 0.5 kgm




P23EC152

61. Transmission control valve assembly

Fix O-ring to mounting face and install transmission control valve assembly (8) together with cooler by-pass valve assembly (9).


 Mounting bolt: 4.25 ± 1.25 kgm



P23EC110


62. Lubrication tube

Install tube (7).

 Joint bolt: 3.0 ± 0.5 kgm

63. Piping


Fix O-ring to each side and install tube (6).



P23EC109

64. Transmission control valve piping


Fix O-ring and install tube (4), (5).




P23EC108

65. Parking brake assembly

Install parking brake assembly (3).

 Mounting bolt: 28.25 ± 3.25 kgm


- ★ Bend cotter pin securely.





23P151

66. Flange

- 1) Install flange (2) to shaft.
- 2) Fix O-ring, install holder and tighten center bolt.

 Center bolt: Thread tightener (LT-2)


 Center bolt: 23.5 ± 2.5 kgm




23P150

67. Drum

Install brake drum (1).

 Mounting bolt: 18 ± 2 kgm




23P149

DISASSEMBLY OF CAGE AND REVERSE CARRIER ASSEMBLY

GD705A-4

1. **Forward sun gear**
 - 1) Remove snap ring (1) and remove sun gear (2).
 - 2) Remove snap ring (3).
2. **Reverse sun gear**
 - 1) Remove snap ring (4) and remove sun gear (5).
 - 2) Remove spacer (6).
3. **Shaft**
Remove shaft (7).
4. **Cage**
Remove cage (8).
5. **Cage assembly**
 - 1) Remove snap ring (9).
 - 2) Remove cage assembly (10).



F23EC018

ASSEMBLY OF CAGE AND REVERSE CARRIER ASSEMBLY

GD705A-4


- ★ Coat sliding portion of each part with engine oil before installing.
1. **Cage assembly**
 - 1) Install spacer (12) to reverse carrier assembly (11).
 - 2) Press-fit bearing (13) to cage assembly (10).
 - 3) Install seal ring (14), install cage assembly (10) and fix it with snap ring (9).
 2. **Cage**
Install seal ring (15) and install cage (8).
 3. **Shaft**
Install shaft (7).
 4. **Reverse sun gear**
 - 1) Install spacer (6).
 - 2) Install sun gear (5) and fix it with snap ring (4).
 - ★ Confirm that sun gear is firmly engaged in planetary gear.
 5. **Forward sun gear**
 - 1) Install snap ring (3).
 - 2) Install sun gear (2) and fix it with snap ring (1).

DISASSEMBLY 1ST SPEED AND 2ND SPEED CARRIER ASSEMBLY

GD705A-4

1. Low sun gear

- 1) Remove snap ring (1) and remove sun gear (2).
- 2) Remove spacer (3).



2. 2nd speed carrier assembly

- 1) Remove 2nd speed carrier assembly (4).
- 2) Remove mounting bolt and remove cage (5).


3. 2nd speed ring gear and 1st speed carrier assembly

- 1) Remove 2nd speed ring gear and 1st speed carrier assembly (6) from shaft.
- 2) Remove snap ring (7) and remove ring gear (8).


P23EC153

4. Shaft assembly


- 1) Remove snap ring (10) from shaft (9) and remove 1st speed sun gear (11).
- 2) Remove spacer (12).




P23EC154



F23EC019A



P23EC156



P23EC155

ASSEMBLY 1ST SPEED AND 2ND SPEED CARRIER ASSEMBLY

GD705A-4

★ Coat sliding portion of each part with engine oil before installing.

1. Shaft assembly


- 1) Install spacer (12) to shaft (9).
- 2) Install 1st speed sun gear (11) and fix it with snap ring (10).
- 3) Install seal ring (13) to spacer (12).

2. 2nd speed ring gear and 1st speed carrier assembly

- 1) Press-fit bearing (15) to 1st speed carrier assembly (14) and fix it with snap ring (16).
- 2) Install 2nd speed ring gear (8) and fix it with snap ring (7).
- 3) Install 2nd speed ring gear and 1st carrier assembly (6) on shaft.

3. 2nd speed carrier assembly

- 1) Press-fit bearing (17) to 2nd speed carrier assembly and fix it with snap ring (18).
- 2) Install cage (5).


 Mounting bolt: Thread tightener (LT-2)

- 3) Install seal rings (19), (20). Using press-fit tool ① install 2nd speed carrier assembly (4).


★ Confirm that ring gear is firmly installed on planetary carrier.

4. Low sun gear


- 1) Install spacer (3).
- 2) Install sun gear (2) and fix it with snap ring (1).




F23EC019




P23EC157




P23EC156



P23EC158



P23EC153



P23EC155

DISASSEMBLY OF HIGH ROTARY CLUTCH ASSEMBLY
GD705A-4

1. **Shaft assembly**

Remove mounting bolt and remove shaft assembly (1).

2. **Spring, Disc, Plate**

Remove wave spring (2), disc (3), plate (4) in order.

★ Spring: 4 pcs., Disc: 4 pcs., Plate: 3 pcs.

3. **Sun gear**

1) Remove snap ring (5).

2) Remove sun gear (6).

4. **Cage assembly**


1) Put punch mark on cage (7) and carrier (8).

2) Remove bearing (9) together with cage.


5. **Planetary gear**

Remove planetary gear (10).


★ For details, see 23 DISASSEMBLY OF PLANETARY GEAR.




P23EC159



P23EC160



P23EC161



P23EC162

ASSEMBLY OF HIGH ROTARY CLUTCH ASSEMBLY GD705A-4

- ★ Coat sliding portion of each part with engine oil before installing.


1. Planetary gear

Install planetary gear (10).

- ★ For detail, see ASSEMBLY OF PLANETARY GEAR.

2. Cage assembly

- 1) Press-fit bearing (9) to cage (7).
- 2) Align the punch mark stamped during disassembly and install cage assembly (8).

 Mounting bolt: Thread tightener (LT-2)

3. Sun gear

- 1) Install sun gear (6).
- 2) Turn carrier assembly over and fix it with snap ring (5).



4. Spring, Disc, Plate

Install wave spring (2), disc (3) and plate (4) in order.

- ★ Spring: 4 pcs., Disc: 4 pcs., Plate: 3 pcs.


5. Shaft assembly

Install shaft assembly (1).



DISASSEMBLY OF PLANETARY GEAR GD705A-4


1. Pull out shaft (2) from planetary carrier assembly (1) and remove ball (3). Then remove thrust washer (4), gear (5), thrust washer (6) in order.
2. Pull out bearing (7) from gear (5).



ASSEMBLY OF PLANETARY GEAR GD705A-4

★ Coat sliding portion of each part with engine oil before installing.

1. Install bearing (7) in gear (5).
2. Inserting shaft (2) into carrier and install thrust washer (6), gear (5), thrust washer (4) in order. Then fix shaft with ball (3).
 - ★ When shaft comes out, lightly caulk ball groove of carrier.
3. After assembly, measure side clearance of planetary gear (5) with feeler gauge ① and confirm measured internal clearance within standard.
 - ★ Side clearance: 0.3 to 0.8 kgm




REMOVAL OF HYDROSHIFT TRANSMISSION CONTROL VALVE

GD705R-4


- 1. **Operator's seat ass'y**
Sling and remove operator's seat assembly (1).




Operator's seat assembly: Approx. 32 kg



- 2. **Cover**
Remove cover (2).



- 3. **Control valve piping**
 - 1) Remove control valve tube (3).
 - ★ Care should be taken not to allow strainer to fall off, which is installed in tube.
 - 2) Remove control valve tube (4).




- 4. **Cooler piping**
Disconnect cooler bypass valve outlet tube (5) and cooler bypass valve inlet tube (6) from cooler bypass valve.

- 5. **Cooler bypass valve assembly**
Remove cooler bypass valve assembly (7).

- 6. **Control valve inlet tube**
Disconnect control valve inlet tube (8) from control valve assembly.

- 7. **Transmission control valve assembly**
Remove transmission control valve assembly (9).




INSTALLATION OF HYDROSHIFT TRANSMISSION CONTROL VALVE

GD705R-4


1. Transmission control valve assembly

Fit O-ring to mounting face and install transmission control valve assembly (9).

 Mounting bolt: 4.5 ± 1 kgm

2. Control valve inlet tube


Fit O-ring and connect control valve inlet tube (8) to control valve assembly.

 Bolt mounting control valve together:
 4.5 ± 1 kgm

★ Fit O-ring in groove closely.

3. Cooler bypass valve assembly

Fit O-ring to mounting face and install cooler bypass valve assembly (7).

 Mounting bolt: 10 mm 4.5 ± 1 kgm
 8 mm 2.5 ± 1 kgm

4. Cooler piping

Fit O-ring and connect cooler bypass valve outlet tube (5) and cooler bypass valve inlet tube (6) to cooler bypass valve assembly.

5. Control valve piping

- 1) Fit O-ring and install control valve tube (4).
- 2) Fit strainer and O-ring, and install control valve tube (3).


★ Fit O-ring in groove closely.

6. Cover


Install cover (2).

7. Operator's seat assembly


Sling and install operator's seat assembly (1).




P23E04056



P23E04055



P23E04054





P23E04053

REMOVAL OF HYDROSHIFT TRANSMISSION PUMP ASSEMBLY

GD705R-4

1. Remove cover (1).
2. Remove transmission pump outlet hose (2).
3. Loosen clamp (3), slide hose (4) and disconnect it.
4. Dismount transmission pump assembly (5) together with transmission pump inlet tube (6).
5. Remove transmission pump inlet tube from transmission pump assembly.



INSTALLATION OF HYDROSHIFT TRANSMISSION PUMP ASSEMBLY

GD705R-4

1. Fit O-ring, install transmission pump inlet tube on transmission pump assembly.
 2. Fit O-ring, mount transmission pump assembly (5) together with transmission pump inlet tube (6).
 3. Slide hose (4), connect transmission pump inlet tube, then tighten them with clamp (3).
 4. Connect transmission pump outlet hose (2).
 5. Install cover (1).
- ★ Run the engine to circulate engine oil through the system. Then check the oil level again.

REMOVAL OF HYDROSHIFT TRANSMISSION PUMP ASSEMBLY

GD705A-4





Lower the work equipment completely to the ground and stop the engine.

1. Remove fuel tank assembly (incl. hydraulic tank).
For details, see 13 REMOVAL OF FUEL TANK ASSEMBLY (incl. HYDRAULIC TANK).
2. Remove inlet and outlet tubes (1) and (2) of transmission pump from transmission pump.
3. Remove transmission pump assembly (3).



Transmission pump assembly: Approx. 6 kg



INSTALLATION OF HYDROSHIFT TRANSMISSION PUMP ASSEMBLY

GD705A-4

1. Fit O-ring and install transmission pump assembly (3).
2. Fit O-rings and install inlet and outlet tubes (1) and (2) of transmission pump to transmission pump.
3. Install fuel tank assembly.
For details, see 13 INSTALLATION OF FUEL TANK ASSEMBLY (incl. HYDRAULIC TANK).

REMOVAL OF TANDEM AND FINAL DRIVE ASSEMBLY






GD705R-4

1. Disconnect drive shaft (1) from final case side.
2. Remove filler tube (2).
3. Remove L.H. and R.H. brake oil joint (3).
4. Remove L.H. and R.H. cap (4).




Cap (each): Approx. 16 kg

5. Remove bolt, and remove support (5) from frame.
6. Dismount tandem and final drive assembly
 - 1) Hold final drive case lower part with jack and raise body with crane, then dismount it from frame.
 - 2) Turn wheel to pull tandem and final drive case assembly (6) out in the rear direction.
 - 3) After pulling out tandem and final drive assembly, support body with block.



P23E04066




P23E04065

INSTALLATION OF TANDEM AND FINAL DRIVE ASSEMBLY


GD705R-4

1. Mount tandem and final drive assembly
 - 1) Raise tandem and final drive assembly (6) with a crane, extend center of body, and set at rear of body. Then support final case lower part with a jack.
 - 2) Raise body with a crane and pull out the block. While turning the wheel set the tandem and final drive assembly to the lower part of the body.
 - 3) Lower the body slowly, and connect the tandem and final drive assembly while moving it.


2. Install support (5) on frame.
3. Install L.H. and R.H. cap (4).
4. Install L.H. and R.H. brake oil joint (3).
5. Install filler tube (2).
6. Connect drive shaft (1).
7. Adjusting brake
For detail, see CHECK AND ADJUSTING OF BRAKE SYSTEM.




P23E04066




P23E04065



P23E04064



P23E04061




P23E04062

REMOVAL OF TANDEM AND FINAL DRIVE ASSEMBLY

GD705A-4


1. Drive shaft

Remove drive shaft (1).





2. L.H. and R.H. brake piping joint

Remove L.H. and R.H. brake piping joints (2).




3. L.H. and R.H. cap, hanger

- 1) Disconnect differential lock chamber connect tube (3) and wiring (4).
 - 2) Remove bolt and hanger (5) from frame.
 - 3) Remove L.H. and R.H. cap (6).
- ★ Distinguish between L.H. and R.H. caps.



4. Tandem • Final drive assembly

- 1) Using hook (7) lift up the chassis.
- 2) Turning wheel, pull out tandem and final drive assembly (8) to rear.




INSTALLATION OF TANDEM AND FINAL DRIVE ASSEMBLY

GD705A-4


1. Tandem and final drive assembly


- 1) Using hook (7), raise the chassis. Turning the wheel, set tandem and final drive assembly (8) under the chassis.
- 2) Slowly lower the chassis and connect tandem and final drive assembly while moving them.




2. L.H. and R.H. cap, hanger

- 1) Install L.H. and R.H. caps (6).
 - ★ Be careful not to confuse L.H. and R.H. caps.
- 2) Install hanger (5) on frame.
- 3) Connect differential lock chamber connect tube (3) and wiring (4).


 Hanger mounting bolt: Thread tightener (LT-2)

 Hanger mounting bolt: 56 ± 6 kgm



3. L.H. and R.H. brake piping joint


Install L.H. and R.H. piping joints (2).



4. Drive shaft


Install drive shaft (1).

 Mounting bolt: 11.25 ± 1.25 kgm



DISASSEMBLY OF FINAL DRIVE ASSEMBLY

GD705R-4




F23BB010


Special tool

| | Part number | Part name | Q'ty |
|---|--------------|--------------|------|
| A | 792-571-1600 | Chain puller | 1 |

1. Tandem, final drive assembly


- 1) For details, see "REMOVAL OF TANDEM AND FINAL DRIVE ASSEMBLY".
- 2) Raise tandem, final assembly (1) with crane, and remove wheel (2).

 Tandem, final drive assembly: 3 ton




P23BB086


- 3) Set tandem, final drive assembly on block (1) and remove drain plug (3), then drain oil from tandem case.

 Tandem case (each side): Approx. 36ℓ

- 4) Remove drain plug and drain from final drive case.

 Final drive case: Approx. 24ℓ


- ★ Set blocks in three places under the L.H. and R.H. tandem case and final drive case.




P23E04067

2. Cover (tandem final)


Remove covers (4) (tandem side, F, R, 6 pcs.), cover (5) (final side 1 pc.).

**3. Chain**


1) Rotate the pinion to bring the connecting port of the chain into line with the inspection window.



2) Using tool A, tighten the chain, then remove lock pin (6) and pin (7).




3) Remove chain (8).



4. Tandem case assembly

- 1) Suspend tandem case assembly (9).



P23E04069

- 2) i) Remove mounting bolts (10) and dismount the tandem case assembly.




Tandem case assembly:
Approx. 920 kg (one side)

- ★ When dismounting the tandem case assembly, be careful to maintain it in a balanced condition in order to prevent the contact face of the O-ring on the case side from being damaged.

- ii) Dismount cover (11).

- ★ Keep shims on one side so they don't get mixed up.



P23E04070

P23E04071


5. Bevel pinion assembly

- 1) Dismount coupling (12).
- 2) Remove the mounting bolts, then dismount bevel pinion assembly (13).



Bevel pinion assembly: Approx. 50 kg


- ★ Check the number and positions of the shims which were removed.



P23E04072


6. Side case assembly

- 1) Remove shaft end holder (14).
- 2) Remove sprocket (15) and collar (16).




P23BB199

- 3) Remove snap ring (17).



P23BB200

- 4) Pull out shaft (18) together with bearing (19).



F23BB012


- 5) Remove mounting bolt and disconnect side case assembly (20) from center case.



Side case assembly: Approx. 240 kg



Be careful to prevent inside gear from falling out.




P23BB201

- 6) Remove mounting bolts, then fit eye bolts 3 (Thread dia. = 12 mm, Pitch = 1.75 mm) and dismount joint assembly (21).




Joint: 100 kg




23P164A

- 7) Remove bushings (22) and (23) from the joint assembly.




23P165A

- 8) i) Remove the mounting bolts and dismount cage (24).
- ii) In a similar manner, remove top and bottom plates (25) and washers (26).



23P166A


- 7. Center case assembly
Dismount bearing (27).



P23E04073

ASSEMBLY OF FINAL DRIVE ASSEMBLY

GD705R-4




238F227




Special tool


| | Part number | Part name | Q'ty |
|---|--------------|--------------|------|
| A | 792-571-1600 | Chain puller | 1 |


- Center case ass'y
Mount bearing (27).




- Side case ass'y
 - Fit cage (24) on the side case.
Fit washer (26), plate (25) and washer (26) in that order, and tighten the bolt.

-  Washers: Grease (G2-LI) (both sides)
-  Bolt: Liquid gasket (LG-1)
-  Bolt: 9 kgm




- 2) Fit bushings (22) and (23) on the joint.
- ★ Arrange the slit of the bushings as follows:
 Arrange the slit of bushing (22) so that it is at the bottom of the machine body.
 Arrange the slit of bushing (23) so that it is at the top of the machine body.
-  Bushing: Engine oil (both side)




23P165A

- 3) Fit eye bolts 3 (Thered dia. = 12 mm, Pitch = 1.75 mm) to joint assembly (21), then lift the joint assembly and mount it on the side case.




23P164A

- 4) Mount shaft (18) and the bearing (19) as single assembly.




F23BB012

- 5) Fit snap ring (17).




23P162A



- 6) Fit sprocket (15) and (16).




- 7) Mount shaft end holder (14).
 ★ Bend lock plates securely.




- 8) Fit gasket (31) and gear (32) to center case (30), then mount right side case assembly (20).

-  Gasket: Gasket sealant (LG-1)
 Mounting bolt: 23.5 kgm



3. Bevel gear shaft assembly

Suspend bevel gear shaft assembly (33) in the middle of center case (30), then mount it on right side bearing.




4. Bevel pinion ass'y

- 1) Mount gear (32) and engage it with the gear on the bevel gear shaft ass'y side.
- 2) Mount bevel pinion ass'y (13) and engage it with the bevel gear.

★ Backlash adjusting shims

- i) Insert adjusting shims of the same thickness as those which were removed during disassembly.
- ii) Standard shim thickness; 2.0mm
- iii) Types of shims:

| |
|-----------|
| t = 0.1mm |
| t = 0.3mm |
| t = 1.0mm |




5. Side case ass'y

Mount the left side case ass'y in similar manner to item 2.

6. Pre-pressure adjustment

Adjust the overall thickness of shims (34), then tighten cover (35) and measure the starting torque.

- ★ Adjust the shim thickness so that the starting torque at the bevel pinion increases by about 0.3 to 0.4
- ★ Standard shim thickness: 2.0mm
- Types of shims: t = 0.1 mm, 0.3 mm, 1.0 mm




7. Adjustment of backlash and tooth contact of bevel gear

- ★ Fit the shims which were removed during disassembly of the bevel pinion ass'y in their initial positions.
- ★ Perform pre-pressure adjustment, backlash adjustment and tooth contact adjust at the same time.
- ★ Measure the rotating torque of the bevel gear and shaft ass'y with the bevel gear and bevel pinion engaged.
- ★ When adjusting the bearing pre-pressure, tighten the adjusting shims while rotating the bevel gear. Adjust the rotating torque on the bevel gear to about 4.5 to 6kg.


1) Backlash measurement

Fix dial gauge to the case in such a way that its tip touches the tooth face of the bevel gear at right angles.

- ★ Fix the bevel pinion and measure the backlash of the bevel gear. (Perform measurements at minimum of 3 points.)
- ★ Backlash should be between 0.3 to 0.4mm.



233F228




3) Adjusting tooth contact


Coat the tooth face of the bevel pinion lightly with red lead (minimum). Rotate the bevel gear forward and backward and inspect the pattern left on the teeth.

- ★ Tooth contact should be checked with no load on the bevel pinion. The tooth contact pattern should be located 20 to 40% from the small end. It should be in the center of the tooth height. If the gears are adjusted to this pattern, the tooth contact will be correct when load is applied.

If the result of the inspection shows that the correct tooth contact is not being obtained, adjust again as follows.





- ★ Tooth contact
 - a Tooth contact width 30 to 50%
 - b Tooth contact center 20 to 40%



23F032

- i) If bevel pinion is too far from center line of bevel gear. Contact is at the small end of the convex tooth face of the bevel gear and at the big end of the concave tooth face.



- ★ Procedure for adjustment
Reduce the thickness of the shims at the mount of the bevel pinion assembly to move the pinion shaft in direction A, nearer to the bevel gear. Increase the thickness of shims at the right and left cage mounts to move the bevel gear in direction B by the same amount that the bevel pinion has moved in direction A. Check the tooth contact pattern and backlash.



23F058

- ii) If bevel pinion is too close to center line of bevel gear. Contact is at the small end of the concave tooth face of the bevel gear and the big end of the convex tooth face.

- ★ Procedure for adjustment
Increase the thickness of the shims at the mount of the bevel pinion assembly to move the pinion shaft in direction A, away from the bevel gear. Reduce the thickness of shims at the right and left cage mounts to move the bevel gear in direction B by the same amount that the bevel pinion has moved in direction A. Check the tooth contact pattern and backlash.







23F059

- ★ When adjusting the bevel gear to the right or left, do not change the preload of the bearing. Adjust by moving shims between the bevel gear and the bevel pinion. Always keep the same total thickness of shims.


8. Tandem case ass'y

- 1) Suspend tandem case ass'y (9) and mount it on the final drive case.
- 2) Tighten mounting bolts (10).

-  Mounting bolts: Thread tightener (LT-2)
-  Case: Gasket sealant (LG-1)
-  Mounting bolts: 23.5 kgm




P23E04069



P23E04074


9. Chain

- 1) Fit chain (8) on the sprocket while rotating the wheel hub.
 - ★ It is relatively easy to fit the chain from the driven side sprocket.
 - ★ Fit the chain towards the inside at the front of the machine body and towards the outside at the rear of the machine body.




238P062

- 2) Using tool A, connect the chain and align it with the pin.




P23BB090

- 3) Fit pin (7) and bend lock pin (6).
 - ★ Bend lock pin securely.




10. Cover (tandem and final)

Install covers (4) (six covers) front and rear at the tandem side and cover (5) (one cover) at the final side after fitting gaskets to them.

 Gasket and bolt: Gasket sealant (LG-1)

- ★ Install the tandem cover with the oil filler at the front of the machine body, and the cover with the breather at the rear inner side.




11. Tandem, final ass'y

- 1) Mount wheel (2), then raise the tandem, final ass'y (1) and remove the block.
- 2) Screw tandem case drain plug, then pour in engine oil from the oil filler to the specified level.



Tandem case (one side): 36ℓ




- 3) Screw final case drain plug (36), then pour in gear oil from the oil filler to the specified level.



Final case: 24ℓ

- ★ Start and run engine to let oil circulate in hydraulic system. Check oil level again.



DISASSEMBLY OF FINAL DRIVE ASSEMBLY

GD705A-4

Special tools

| | Part number | Part name | Q'ty |
|---|--------------|-----------------------|------|
| A | 792-571-1600 | Chain puller | 1 |
| B | 792-571-1400 | Wrench (for L.H. nut) | 1 |
| C | 792-571-1500 | Wrench (for R.H. nut) | 1 |

1. Tandem and final drive assembly

- 1) For detail see DISMOUNTING TANDEM DRIVE AND FINAL DRIVE ASS'Y.
- 2) Sling tandem and final drive assembly (1) and remove wheel (2).



Tandem and final drive assembly: 4.0 ton

- 3) Set tandem and final drive assembly on block ①, remove drain plug (3) and drain tandem case oil.





Tandem case (each): Approx. 105ℓ

- 4) Remove drain plug and drain final drive case oil.




Final drive case: Approx. 40ℓ

- ★ Set block with three places under the L.H. and R.H. tandem case and final drive.




2. Cover

Remove covers (4) (Front and rear: 6 pcs.)




3. Chain

- 1) Turn the pinion and align connection part of chain to check port position.




P23BB089

- 2) Using tool A squeeze the chain, remove lock pin (5) and pull out connection pin (6).



P23BB090


- 3) Remove chain (7).



P23BB091

4. Tandem case assembly

- 1) Sling tandem case assembly (8).




P23BB092

- 2) Remove mounting bolt (9) and dismount tandem case assembly.



Tandem case assembly: Approx. 1030 kg




P23BB093

5. Dismounting side case assembly

Remove mounting bolt and disconnect side case assembly (10) from center case.




Side case assembly: Approx. 240 kg



P23BB094


6. Disassembly side case assembly

- 1) Remove holder (11) of shaft end.




P23BB095

- 2) Remove sprocket (12), collar (13).




P23BB096

- 3) Remove snap ring (14)




- 4) Install eye bolt, sling shaft and joint assembly (15) and remove it.


kg Shaft and joint assembly: Approx. 150 kg



- 5) Remove bushing (16), (17) from joint assembly.



- 6) Remove plate (18), upper and lower washer (19) and cage (20).




7. Gear and shaft assembly

Remove gear and shaft assembly (21).


8. Gear

Remove gear (22).




9. Bearing

Remove bearings (23), (24).




10. Bevel pinion assembly

1) Screw in jack bolt and remove cover (25).




2) Install eye bolt and remove bevel pinion assembly (26).





11. Cover

Screw in jack bolt and remove differential lock chamber (28) together with cover (27).





12. Bevel gear assembly

- 1) Remove lock (29) of L.H. and R.H. adjusting nuts.
- 2) Using tool B, loosen L.H. nut (30).
- 3) Using tool C, loosen R.H. nut (31).
- 4) Remove L.H. and R.H. nuts (32) and cap (33).



- 5) Remove bevel gear assembly (34).

 kg Bevel gear assembly: Approx. 90 kg



ASSEMBLY OF FINAL DRIVE ASSEMBLY


GD705A-4

Special tools

| | Part number | Part name | Q'ty |
|---|--------------|-----------------------|------|
| A | 792-571-1600 | Chain puller | 1 |
| B | 792-571-1400 | Wrench (for L.H. nut) | 1 |
| C | 792-571-1500 | Wrench (for R.H. nut) | 1 |


1. Bevel gear assembly

- 1) Sling bevel gear assembly (34) and install case.
 - ★ When install, upper set dowel pin connection notch of cap.



P23EC172


- 2) i) Align dowel pin part and install cap (33).
 - ii) Temporarily tighten nut (32).
 - ★ When tightening adjusting nut, bevel gear assembly is reduced to move on both sides.
 - ★ When installing cap, case inner side and cap are reduced to as the same face.



P23EC173


2. Bevel pinion assembly

- 1) Fix O-ring, install bevel pinion assembly (26) and it is engaged in bevel gear.
 - ★ Backlash adjusting shims
 - i) Insert adjusting shims (35) of the same thickness as those which were removed during disassembly.
 - ii) Standard shim thickness: 2.0 mm
 - iii) Typs of shims
 - t = 0.1 mm t = 0.2 mm t = 0.5 mm



P23BB109


- 2) Attach gasket and install cover (25).
 Cover side: Liquid gasket (LG-1)
- 3) Install coupling (36).




3. Checking and adjusting

Adjust preload to taper roller bearing, backlash and tooth contact of bevel gear and bevel pinion by tightening R.H. nut (6) with tool A and L.H. nut (7) with tool B.


- ★ Adjust bevel pinion assembly for starting force of 7.5 to 10.5 kg as a single assembly.
- ★ Install bevel pinion assembly on case with the same shims as those before removal.
- ★ Perform adjustment of preload, backlash and tooth contact in parallel.
- ★ Measure starting torque of bevel gear assembly while bevel gear is in mesh with bevel pinion.
- ★ When adjusting preload to bearing, adjust it by tightening adjustment nut while adjusting play of L.H. and R.H. bearings by rotating bevel gear.



- ★ Tooth contact a Tooth contact width 30 to 50%
- b Tooth contact center 20 to 40%




- 1) Backlash measurement
 Fix dial gauge ② to the case in such a way that its tip touches the tooth face of the bevel gear at a right angle.
- ★ Fix the bevel pinion and measure the backlash of the bevel gear.
 (Measurements at least 3 points)



- Measuring with fuse wire
Put a fuse wire (approx. $\phi 1.5$ mm) between the teeth of the bevel gear and bevel pinion. Rotate the bevel gear and then measure the thickness of the wire with a micrometer ⑨ .
Put the fuse wire in the center of the bevel pinion contact pattern (about 30% from small end) and measure at least three points around the gears.
- ★ Adjust the backlash to the standard value by adjusting the shim thickness at the right and left cage mounts.


Standard value for backlash: 0.3 to 0.4 kgm



- 2) Adjusting preload of bevel gear shaft bearing
 - i) Measure starting torque of bevel pinion with torque wrench ④ . Adjust the starting torque to the standard value by adjusting the shim thickness at the right and left cage mounts.


Starting torque: 0.3 to 0.4 mm

- ii) After adjusting preload, check backlash between bevel pinion and bevel gear.



- 3) Adjusting tooth contact.
Refer to page 23-150.


4. Nut
Tighten L.H. and R.H. nuts (32), and align cotter pin hole.
★ Tighten nuts equally.
★ Bend cotter pin securely.




5. Lock
Install lock (29) on L.H. and R.H. adjusting nuts.
★ Bend cotter pin securely.

6. Cover
Attach gasket and install cover (27) together with differential lock chamber (28).

Cover: Liquid gasket (LG-1)




- ★ Confirm that shifting fork (37) is firmly installed in gear (38).



7. Bearing

Install bearings (23), (24).




8. Gear

Install gear (22).

9. Gear and shaft assembly


Install gear and shaft assembly (21).





10. Side case assembly


- 1) Install cage (20) on side case.
Install washer (19), plate (18), washer (19) in order and tighten bolt.

Washer (each side): Grease (G2-LI)

 Mounitng bolt: 18 ± 2 kgm





- 2) Install bushings (16), (17) in joint.
 ★ Slit position of bushing is as follows.
 Slit of bushing (16) faces lower side of chassis.
 Slit of bushing (17) faces upper side of chassis.
 Bushing (each side): Engine oil



P23BB099


- 3) Lift shaft and joint assembly (15) and install it to side case.

 Shaft and joint assembly: Approx. 150 kg




P23BB098

- 4) Install snap ring (14).




P23BB097

- 5) Install sprocket (12), collar (13).




P23BB096

- 6) Install holder (11) of shaft end.
- ★ Bend lock plate securely.



- 7) Attach gasket to center case and install side case assembly (10).


- Center case side: Liquid gasket (LG-1)
- Mounting bolt: 28.25 ± 3.25 kgm
- Side case assembly: Approx. 240 kg



11. Tandem case assembly



Fix O-ring to joint of final drive assembly, lift tandem case assembly (8) and mount it.

- Mounting bolt: Liquid gasket (LG-1)
- Mounting bolt: 39.25 ± 4.25 kgm
- Tandem case assembly: Approx. 1030 kg




12. Chain


- 1) Hang chain on the sprocket. While rotating the hub, install chain.
- ★ The chain is much easier to connect from the driven side sprocket.
- 2) Use tool A, pull the chain ends, and align pin inserting hole.
- 3) Insert pin (6) and bend lock pin (5).
- ★ Bend lock pin securely.




13. Cover

Attach gasket on covers (4) (Front and rear: 6 pcs).


-  Mounting bolt (tandem case side):
Liquid gasket (LG-1)


**14. Tandem and final drive assembly**

- 1) Lift tandem and final drive assembly (1) and install wheel (2).
- 2) Tighten tandem case drain plug and refill engine oil through filler port to the specified level.

 Tandem case (each): Approx. 105ℓ

- 3) Tighten final drive case drain plug and refill gear oil through filler port to the specified level.


 Final drive case: Approx. 40ℓ



DISASSEMBLY OF BEVEL GEAR AND SHAFT ASSEMBLY


GD705R-4

1. Loosen the bolts and remove holder (1) (both ends).




23P187

2. Using gear puller ①, pull out gear (2) and bearing (3) together (both ends).



23P188

3. Pull out bevel gear (4) from shaft (5).




23P189

ASSEMBLY OF BEVEL GEAR AND SHAFT ASSEMBLY


GD705R-4

1. Mount bevel gear (4) on shaft (5).




23P189

2. Mount gear (2), then drive in (press-fit) bearing (3) using press-fit tool (2) (both ends).




23P190

3. Fit holder (1) and tighten the bolts to the specified torque.

 Tightening torque: 9.0 kgm

- ★ Bend lock plate securely.



23P191

DISASSEMBLY OF BEVEL GEAR ASSEMBLY


GD705A-4

1. Gear

Remove holder (1) and remove gear (2).

2. Cage


Remove cage (3) together with nut (4).



P23EC178


3. Case and gear assembly

1) Remove mounting bolt and remove case and gear assembly (5).




P23EC179

2) Remove gear (6).




P23BB127

3) Remove thrust washer (7) and bushing (8).



P23BB128


- 4) Remove bearing (9).



P23BB129


4. Cross joint assembly

- 1) Remove cross joint assembly (10).



P23EC180

- 2) Remove washer (11), pinion (12), and bushing (13) from cross joint (10).




P23BB131

P23BB132

5. Gear


- Remove gear (14).



P23EC181

6. Thrust washer and bushing


Remove thrust washer (15) and bushing (16).

**7. Bevel gear**

Remove mounting bolt (17) and bevel gear (18).

8. Bearing

Remove bearing (19).



ASSEMBLY OF BEVEL GEAR ASSEMBLY

GD705A-4


1. Bearing

Install bearing (19).

2. Bevel gear

Install bevel gear (18) and tighten bolt (17).


★ Bend lock plate securely.



P23BB135

3. Thrust washer and bushing


Install bushing (16) and thrust washer (15).



P23EC182

4. Gear


Install gear (14).



P23EC181

5. Cross joint assembly


1) Install bushing (13) on pinion (12) and install pinion, washer (11) on cross joint (10) in order.



P23BB131

P23BB132


- 2) Install cross joint assembly (10).



P23EC180


6. Case and gear assembly

- 1) Install bearing (9).




P23BB129

- 2) Install bushing (8) and thrust washer (7).




P23BB128

- 3) Install gear (6).



P23BB127


- 4) Install case and gear assembly (5).
★ Bend lock plate securely.



P23EC179


7. **Cage**
Install nut (4) together with cage (3).

8. **Gear**
Install gear (2) and install holder (1).
★ Bend lock plate securely.



P23EC178

REMOVAL OF BEVEL PINION ASSEMBLY



F23B03035


1. Draining oil

Remove drain plug (1) and drain oil from final drive case.




Final drive case: Approx. 24ℓ GD705R-4
Approx. 40ℓ GD705A-4

GD705R-4



P23E04058

GD705A-4




P23404014

2. Drive shaft


Remove drive shaft (2).

GD705A-4



P23EC184


GD705R-4



P23E04059

3. Coupling

Remove coupling (3).


**4. Bevel pinion assembly**

Remove mounting bolt, and using two jack bolts 1. (Thread dia. = 12 mm, Pitch = 1.75 mm, Length = 200 mm) for GD705R-4, (Thread dia. = 14 mm, Pitch = 2.0 mm, Length = 200 mm) for GD705A-4, pull out bevel pinion assembly (4).




Bevel pinion assembly: 50 kg (GD705R-4)
60 kg (GD705A-4)

- ★ Separate the L.H. and R.H. removed shims, and count them for confirmation.




INSTALLATION OF BEVEL PINION ASSEMBLY




1. Bevel pinion assembly

- 1) Install two guide bolts ② (Thread dia. = 12 mm, Pitch = 1.75 mm, Length = 200 mm) for GD705R-4 (Thread dia. = 14 mm, Pitch = 2.0 mm, Length = 200 mm) for GD705A-4, in bolt holes at final drive side.
- 2) Install shims (5) for adjusting backlash.
 - ★ Install shims for adjusting of the same thickness as that before removal.
 - ★ Standard shim thickness: 2.0 mm
 - ★ Kinds of shims: t = 1.0 mm, 0.3 mm, 0.1 mm (for GD705R-4)
t = 0.5 mm, 0.2 mm, 0.1 mm (for GD705A-4)
- 3) Install bevel pinion assembly (4).



2. Coupling


Install coupling (3).



3. Checking and adjusting

- 1) Adjustment of backlash can be accomplished by increasing or decreasing shims (5).
 - ★ Backlash: 0.3 to 0.4 mm
- 2) Refer to "CHECKING AND ADJUSTING" section in "INSTALLATION OF FINAL DRIVE ASSEMBLY" section for adjusting tooth contact.
 - ★ If adjustment is carried out when bevel pinion is mounted on machine, raise up machine body, place block under case, remove hanger, oil filling port and cover, check and adjust by rotating wheel.

- ★ Tooth contact a Tooth contact width 30 to 50%
- b Tooth contact center 20 to 40%




23F032


4. Drive shaft

Install drive shaft (2).

GD705R-4



GD705A-4

**5. Adding oil**


Tighten drain plug and add engine oil to specified level through oil filler port (6).




Final drive case: Approx. 24ℓ (GD705R-4)
Approx. 40ℓ (GD705A-4)

- ★ Run the engine to move machine.
Then check the oil level.

GD705R-4




GD705A-4



DISASSEMBLY OF BEVEL PINION ASSEMBLY


1. Nut, Lock plate

Set bevel pinion assembly in vice and remove nut (1) and lock plate.




2. Cage assembly

- 1) Use press-fit tool ① (I.D. $\phi 200$ mm) and set pinion cage ass'y in press.
 - 2) Press pinion (2), pull it out from cage (3) to separate pinion and cage.
- ★ It is possible to remove bearing and pull out pinion at the same time.




3. Pinion side bearing

Use a bearing separator, pull out bearing (4).



4. Bearing outer race

Remove outer races (5) (upper and lower: 2 pcs).



ASSEMBLY OF BEVEL PINION ASSEMBLY

1. Bearing outer race


Using press-fit tool ②, press-fit outer races (5) (Upper and lower: 2 pcs) in cage (3).

2. Pinion side bearing

Use press-fit tool to press fit bearing (4).





3. Cage assembly

- 1) Put pinion assembly (2) on the press table and install cage assembly (3).
- 2) Use press-fit tool ③ and press-fit bearing (6).
 - ★ Press-fit the bearing while rotating the cage. Stop rotating the cage when a little heaviness is felt.




4. Starting torque adjustment

- 1) Set the pinion cage assembly in a vice and install nut (7).
- 2) Tighten nut (7), install tool ④ on coupling (8) and measure starting torque.
 - ★ Starting torque: 5.0 to 6.0 kgm
- 3) Loosen nut (7) and set starting torque at 0.5 to 0.8 kgm.
 - ★ Nut must not securely be completely loose.
- 4) Install lock plate (9), lock nut (1), measurement are shown in item 2 above.
 - ★ Tightening torque for lock nut: 40 ± 10 kgm
 - ★ Starting torque: 1.2 to 1.6 kgm
- 5) Bend lock plate securely.



REMOVAL OF TANDEM CASE AND SPROCKET

GD705R-4



23F05 I

Special tool

| | Part number | Part name | Q'ty |
|---|--------------|--------------|------|
| A | 792-571-1600 | Chain puller | 1 |

PREPARATORY WORK


- Loosen rear wheel mounting nuts before raising up body.

1. Draining oil

Remove drain plug (1) to drain oil from tandem case.




Tandem case (one side only): Approx. 36ℓ



238P058

2. Raising up body

Sling body and place block ① under frame to support body.




P23E04076

3. Wheel

Temporarily sling rear wheels (2), remove nuts (3) and remove front and rear wheels.




Wheel (one): Approx. 160 kg



P23E04077

4. Cover


Dismount front and rear covers (5) (two covers) and right, front and rear covers (4) (four covers).



P23E04078


5. Chain

1) Rotate the drum to bring the connecting part of the chain into line with the inspection window.




P23E04068

2) Set tool A and tighten the chain, then remove lock pin (6) and pin (7).




23PI54

3) Remove front and rear chains (8).




6. **Joint**
Remove brake piping joint (9).




7. **Tandem case assembly**
1) Temporarily suspend tandem case ass'y (10).

2) Remove mounting bolts (11) and dismount the tandem case ass'y.



 Tandem case ass'y: Approx. 920 kg

- ★ When dismounting the tandem case ass'y, be careful to maintain it in a balanced configuration in order to avoid damaging the contact face of the case O-ring.
- ★ When replacing the sprocket alone, it is possible to do this by dismounting the wheel tandem ass'y without removing the wheel.




8. **Holder**
Remove shaft end holder (12).

9. **Sprocket**
Remove sprocket (13).



INSTALLATION OF TANDEM CASE AND SPROCKET

GD705R-4




Special tool

| | Part number | Part name | Q'ty |
|---|--------------|--------------|------|
| A | 792-571-1600 | Chain puller | 1 |

1. Sprocket

Install sprocket (13) on shaft.

- ★ Install sprockets with their boss sides faced inside.




23P224

2. Holder

Install holder (12).

- ★ Bend down lock plate securely.



kgm Mounting bolt: 9 kgm




P23BB218

3. Tandem case ass'y

- 1) Fit O-ring to the joint.
- 2) Suspend tandem case ass'y (10) and mount it on the final side joint.
- 3) Tighten mounting bolts (11).


-  Bolts: Gasket sealant (LG-1)
-  Mounting bolt: 23.5 kgm



P23E04080

4. Joint


Mount brake piping joint (9).



P23E04079


5. Chain

- 1) Fit chain (8) to the sprocket while rotating the drum.
 - ★ It is relatively easy to fit the chain from the driven side sprocket.
 - ★ Fit the chain towards the inside at the front of the machine and towards the outside at the rear of the machine.




238P062

- 2) Using tool A, connect the chain and align it with the pin.




23P154


- 3) Fit pin (7) and bend lock pin (6).
 ★ Bend lock pin securely.




6. **Cover**
 Install covers (5) (two covers) front and rear and covers (4) (four covers) front, rear, left and right.



7. **Wheel**
 Suspend wheel (2), then mount the hub and tighten nuts (3).


 Nut: 50 ± 5 kgm


- ★ It is relatively easy to tighten the nuts after lowering the machine body.



8. **Lowering machine body**
 Lift the machine body and remove support.

9. **Refilling with oil**
 Tighten drain plug (1) and pour in engine oil from the oil filler to the specified level.

 Tandem case (one side): 36ℓ



REMOVAL OF SPROCKET ASSEMBLY

GD705A-4

Special tool



| | Part number | Part name | Q'ty |
|---|--------------|----------------|------|
| A | 790-102-1921 | Nut wrench kit | 1 |

1. **Wheel**
Remove wheel.
2. **Chain**
For detail, see 23 REMOVAL OF CHAIN.
3. **Brake tube**
1) Remove cover (1).
2) Remove tube (2).
4. **Tandem case assembly**
Lift tandem case assembly (3) and remove it.




Tandem case assembly: Approx. 1030 kg

5. **Tandem stopper**
Remove tandem stopper (4).




6. **Cage**
1) Using tool A, remove nut (5) and washer (6).
2) Screw in jack bolt (Thread dia. = 16 mm, Pitch = 2.0 mm) and remove cage (7).



- ★ Insert collar ① ($\phi 95$) and temporarily tighten nut (5) so that the sprocket does not slip out.

7. Shim

Remove shim assembly (8).



P23BB140


8. Wheel brake and sprocket assembly

- 1) Fix cage and shaft with guide bolt ② (Thread dia. = 10 mm, Pitch = 1.5 mm, Length = 5 mm).
- 2) Lift wheel brake and sprocket assembly (9) and remove it.



Wheel brake and sprocket assembly:

Approx. 300 kg



P23BB141




INSTALLATION OF SPROCKET ASSEMBLY


GD705A-4

Special tool

| | Part number | Part name | Q'ty |
|---|--------------|----------------|------|
| A | 790-102-1921 | Nut wrench kit | 1 |

1. Wheel brake and sprocket assembly

- 1) Fix O-ring to support of wheel brake assembly.
 O-ring: Grease (G2-L1)
- 2) Lift wheel brake and sprocket assembly (9) and install it on tandem case.
 Mounting bolt: Liquid gasket (LG-1)
 Mounting bolt: 23.5 ± 8 kgm
- 3) Remove guide bolt (2).




P23BB141

2. Shim



Install shim assembly (8).


3. Cage

- ★ Remove nut (5) and remove collar (1).
- 1) Press-fit bearing in cage (7).



P23BB140

- 2) Fix O-ring (2 points) and install cage assembly (7).
 O-ring: Grease (G2-L1)
- 3) Using tool A, install washer (6) and tighten nut (5).
 Nut: 30 ± 3 kgm




P23BB138

P23BB139

4. Tandem stopper

Install tandem stopper (4).

**5. Tandem case assembly**

Fix O-ring to final drive case side, lift tandem case assembly (3), and install it.

**6. Brake tube**

- 1) Install tube (2).
- 2) Install cover (1).

7. Chain

For detail, see 23 INSTALLATION OF CHAIN.

8. Wheel

Install wheel.

REMOVAL OF CHAIN


Special tool

| | Part number | Part name | Q'ty |
|---|--------------|--------------|------|
| A | 792-571-1600 | Chain puller | 1 |

1. Remove drain plug (1) and drain tandem case oil.




Tandem case (each): Approx. 36ℓ GD705R-4
 Approx. 105ℓ GD705A-4




238P058

2. Lift chassis (2) and place it on block ① (Height: approx. 400 mm) under tandem case (3).



238P065


3. Remove covers (5) (Front and Rear: 2 pcs) and covers (4) (L.H., R.H., Front, Rear = 4pcs).




238P061

4. Chain


- 1) Rotating wheel, align the chain connection part and check hole.



- 2) Using tool A, pull the chain end, remove lock pin (6), and pull out pin (7).



- 3) Remove front and rear chains (8).




INSTALLATION OF CHAIN

Special tool


| | Part number | Part name | Q'ty |
|---|--------------|--------------|------|
| A | 792-571-1600 | Chain puller | 1 |

1. Chain


- 1) Hang chain (8) on sprocket, and install it while rotating the wheel.
 - ★ The chain is much easier to connect from the driven sprocket side.
 - ★ Install the chain to the inside of the machine at the front and to the outside of the machine at the rear.



- 2) Using tool A, connect the ends of the chain and align with pin hole.




- 3) Insert connection pin (7) and install lock pin (6).



2. Tighten drain plug (1). Add engine oil through cover mounting hole.



Tandem case (each): Approx. 36ℓ GD705R-4
Approx. 105ℓ GD705A-4




238P058

3. Cover

Attach gasket and install covers (4), (5).


Bolt and case: Liquid gasket (LG-1)

★ Apply liquid gasket to the case side.



238P061

4. Lift the chassis (2) and pull out block (1) from tandem case (3).



238P065



REMOVAL OF WHEEL BRAKE AND SPROCKET ASSEMBLY

GD705R-4

1. Remove wheel. For details, see "REMOVAL OF TANDEM AND FINAL DRIVE".
2. Remove chain. For details, see "REMOVAL OF CHAIN".
3. Remove cover (1) and disconnect brake tube (2).
4. Raise wheel brake (3) and sprocket assembly with crane and remove bolt.
5. Screw in jack bolt and dismount wheel brake and sprocket assembly.



Wheel brake and sprocket assembly: 220 kg



INSTALLATION OF WHEEL BRAKE AND SPROCKET ASSEMBLY

GD705R-4

1. Fit O-ring, raise wheel brake and sprocket assembly (3) with a crane and mount the assembly on tandem case (4).



Mounting bolt: Liquid gasket (LG-1)




Mounting bolt: 23.5 ± 7.5 kgm

2. Connect brake tube (2) and install cover (1).
3. Install chain. For details, see "INSTALLATION OF CHAIN".
4. Install wheel. For details, see "INSTALLATION OF TANDEM CASE ASSEMBLY AND SPROCKET".
5. Adjust wheel brake. For details, see "TESTING AND ADJUSTING OF BRAKE".

DISASSEMBLY OF WHEEL BRAKE AND SPROCKET ASSEMBLY

GD705R-4



F23BB014

Special tool


| | Part number | Part name | Q'ty |
|---|--------------|------------|------|
| A | 790-102-1921 | Nut wrench | 1 |

1. Brake drum

Raise brake drum (1) with a crane and remove it.



Brake drum: Approx. 42 kg



2. Nut

- 1) Using tool A, remove nut (2).
- 2) Remove washer (3).

3. Spacer

Remove spacers (4).


4. Sprocket

Remove sprocket (5).


5. Spacer

Remove spacer (6).


Front side assembly




Rear side assembly


**6. Hub shaft**


Raise hub shaft (8) with a crane and remove it.

 Hub shaft assembly: 65 kg

**7. Brake shoe assembly**

Remove mounting bolt (9) and remove brake shoe assembly (10).

 Brake shoe assembly: 27 kg




8. Bearing

Pull out bearing (11).

9. Collar

Remove collar (12).

**10. Bearing**


Remove bearing (13).

11. Oil seal

Remove oil seal (15).

12. Bearing outer race


Remove bearing outer race (14).



F23BB015

ASSEMBLY OF WHEEL BRAKE AND SPROCKET ASSEMBLY

GD705R-4



F23B03015

Special tool

| | Part number | Part name | Q'ty |
|---|--------------|------------|------|
| A | 790-102-1921 | Nut wrench | 1 |

1. Bearing outer race



Press-fit outer race (14).


2. Oil seal

- 1) Add grease (G2-LI) to P of cage.
- 2) Using a push tool (dia. 180 mm), press-fit oil seal (15).


3. Brake shoe assembly

Mount brake shoe assembly (10), install mounting bolt (9).


-  Mounting bolt (8): 11.25 ± 1.25 kgm
-  Mounting bolt (9): 6.75 ± 0.75 kgm



F23BB015A




F23BB016




232F166A

4. Hub shaft assembly


- 1) Install collar (12).
- 2) Press-fit bearing (11).



- 3) Raise hub shaft assembly (8) with a crane and install it.

**5. Bearing**

- Press-fit bearing (13).



6. Spacer

Install spacer (6).

7. Sprocket

Install sprocket (5).


8. Spacer

Install spacers (4).


9. Nut

- 1) Install lock washer (3).
- 2) Tighten nut (2), using push-pull scale, measure starting torque.
 - ★ Starting torque: 2.25 ± 0.25 kgm
 - ★ Bend cotter pin securely.

Front side assembly





Rear side assembly




10. Brake drum

Raise brake drum (1) with a crane and install it.


 Mounting bolt: Thread tightener (LT-2)

 Mounting bolt: 0.01 – 0.5 kgm



POWER TRAIN



24 MAINTENANCE STANDARD



| | |
|---|-------|
| Damper | 24- 2 |
| Hydroshift transmission | 24- 4 |
| Hydroshift transmission control valve | 24-14 |
| Hydroshift transmission pump | 24-22 |
| Final drive | 24-24 |
| Tandem drive | 24-26 |

DAMPER

GD705R-4



Section A-A


24F012

Unit: mm

| No. | Check Item | Criteria | | Remedy |
|-----|---|---------------|--------------|----------------|
| | | Standard size | Repair limit | |
| 1 | Wear or damage of rubber | 44 | 40.5 | Replace rubber |
| | | | | |
| 2 | Backlash between input shaft and inner body | 0.071 – 0.177 | 0.5 | Replace |
| | | | | |
| 3 | Backlash between flywheel inner teeth and plate | 0.4 – 0.55 | 1.0 | |

HYDROSHIFT TRANSMISSION


GD705R-4



F23E04024

Unit: mm

| No. | Check Item | Criteria | | | Remedy | | |
|-----|--|--------------------|------------------|----------------|--------------|--------|---------|
| | | Standard clearance | Clearance limit | | | | |
| 1 | R Sun gear-to-R Planetary gear backlash | 0.11 – 0.29 | | | | | |
| | | 0.12 – 0.33 | — | | | | |
| 2 | F Sun gear-to-F Planetary gear backlash | 0.12 – 0.33 | — | | | | |
| 3 | 3rd Sun gear-to-3rd Planetary gear backlash | 0.12 – 0.33 | — | | | | |
| 4 | 2nd Sun gear-to-2nd Planetary gear backlash | 0.12 – 0.33 | — | | | | |
| 5 | Transfer input shaft gear-to-Transfer input side idler gear backlash | 0.19 – 0.45 | — | | | | |
| 6 | Transfer input side idler gear-to-Transfer output side idler gear backlash | 0.19 – 0.44 | — | | | | |
| 7 | Transfer output side idler gear-to-Transfer output shaft gear backlash | 0.19 – 0.44 | — | | | | |
| 8 | L Sun gear-to-L Planetary gear backlash | 0.11 – 0.29 | — | | | | |
| 9 | R Planetary gear-to-R Ring gear backlash | 0.13 – 0.42 | — | | | | |
| 10 | F Planetary gear-to-F Ring gear backlash | 0.13 – 0.42 | — | | | | |
| 11 | 3rd Planetary gear-to-3rd Ring gear backlash | 0.13 – 0.42 | — | | | | |
| 12 | 2nd Planetary gear-to-2nd Ring gear backlash | 0.13 – 0.42 | — | | | | |
| 13 | L Planetary gear-to-L Ring gear backlash | 0.13 – 0.42 | — | | | | |
| 14 | R Ring gear-to-R Carrier backlash | 0.18 – 0.54 | — | | | | |
| 15 | R Ring gear-to-F Carrier backlash | 0.18 – 0.54 | — | | | | |
| 16 | 3rd Ring gear-to-3rd Carrier backlash | 0.18 – 0.54 | — | | | | |
| 17 | R, F, 3rd, 2nd, L Ring gears-to-Clutch disc backlash | 0.34 – 0.84 | — | | | | |
| 18 | Clutch disc-to-1st, H Hub backlash | 0.19 – 0.55 | — | | | | |
| 19 | R, L Clutch springs | Standard size | | | Repair limit | | Replace |
| | | Free length x O.D. | Installed length | Installed load | Free length | Load | |
| | | 53 x 15.3 | 44 | 8.2 kg | 51.7 | 7.0 kg | |
| 20 | F Clutch spring | 53 x 15.3 | 47 | 8.2 kg | 51.7 | 7.0 kg | |
| 21 | 3rd Clutch spring | 39.6 x 15.3 | 33 | 8.4 kg | 38.6 | 7.1 kg | |
| 22 | 2nd Clutch spring | 39.6 x 15.3 | 35 | 5.9 kg | 38.9 | 5.0 kg | |




F23E04024

Unit: mm

| No. | Check Item | Criteria | | Remedy |
|-----|---|--------------------|-----------------|--------|
| 23 | Assembled thickness of disc and plate for R, F, 1st, L.H. | Standard size | Repair limit | |
| | | 25 | 23.5 | |
| 24 | Assembled thickness of disc and plate for 3rd, 2nd clutch | 15 | 14.1 | |
| 25 | Thickness of one plate | 5 | 4.7 | |
| 26 | Side clearance of planetary gear | Standard clearance | Clearance limit | |
| | | 0.35 – 0.80 | 1.5 | |
| 27 | Thickness of shim | Standard thickness | Repair limit | |
| | | 2.0 | — | |
| 28 | Bolt tightening torque | 17 ± 1.0 kgm | | |
| 29 | Bolt tightening torque | 6.5 ± 1.0 kgm | | |
| 30 | Cage mounting bolt tightening torque | 17 ± 1.0 kgm | | |
| 31 | Bolt tightening torque | 1.35 ± 0.15 kgm | | |
| 32 | Bolt tightening torque | 11.0 ± 1.5 kgm | | |
| 33 | Cover mounting bolt tightening torque | 11.0 ± 1.5 kgm | | |
| 34 | Bolt tightening torque | 3.0 ± 0.5 kgm | | |
| 35 | Housing mounting bolt tightening torque | 17 ± 1.0 kgm | | |
| 36 | Plug tightening torque | 0.8 kgm | | |
| 37 | Holder fixing bolt tightening torque | 23.5 ± 2.5 kgm | | |
| 38 | Cage mounting bolt tightening torque | 10.75 ± 1.75 kgm | | |
| 39 | Bolt tightening torque | 11.0 ± 1.5 kgm | | |
| 40 | Plug tightening torque | 0.8 kgm | | |
| 41 | Drain plug tightening torque | 15.5 ± 2.5 kgm | | |

HYDROSHIFT TRANSMISSION


GD705A-4



F23E094

Unit: mm


| No. | Check Item | Criteria | | Remedy |
|-----|--|--------------------|-----------------|---------|
| | | Standard clearance | Clearance limit | |
| 1 | No. 1 sun gear-to-No. 1 planetary gear backlash | 0.13 – 0.32 | — | Replace |
| | | 0.13 – 0.34 | — | |
| 2 | No.2 sun gear-to-No. 2 planetary gear backlash | 0.13 – 0.34 | — | |
| 3 | No. 3 sun gear-to-No. 3 planetary gear backlash | 0.13 – 0.32 | — | |
| 4 | No. 4 sun gear-to-No. 4 planetary gear backlash | 0.13 – 0.32 | — | |
| 5 | No. 5 sun gear-to-No. 5 planetary gear backlash | 0.13 – 0.32 | — | |
| 6 | No. 6 sun gear-to-No. 6 planetary gear backlash | 0.11 – 0.28 | — | |
| 7 | No. 7 sun gear-to-No. 7 planetary gear backlash | 0.13 – 0.32 | — | |
| 8 | Drive gear-to-idle gear backlash | 0.26 – 0.61 | — | |
| 9 | No. 1 planetary gear-to-No. 1 ring gear backlash | 0.14 – 0.43 | — | |
| 10 | No. 2 planetary gear-to-No. 2 ring gear backlash | 0.14 – 0.37 | — | |
| 11 | No. 3 planetary gear-to-No. 3 ring gear backlash | 0.14 – 0.43 | — | |
| 12 | No. 4 planetary gear-to-No. 4 ring gear backlash | 0.13 – 0.42 | — | |
| 13 | No. 5 planetary gear-to-No. 5 ring gear backlash | 0.14 – 0.43 | — | |
| 14 | No. 6 planetary gear-to-No. 6 ring gear backlash | 0.12 – 0.22 | — | |
| 15 | No. 7 planetary gear-to-No. 7 ring gear backlash | 0.14 – 0.43 | — | |
| 16 | Thickness of No. 1 clutch disc | 5 | 4.7 | |
| 17 | Thickness of No. 1 clutch plate | 5 | 4.7 | |
| 18 | Thickness of No. 1 clutch | 35 | 32.9 | |
| 19 | Thickness of No. 2 clutch disc | 5 | 4.7 | |
| 20 | Thickness of No. 2 clutch plate | 5 | 4.7 | |
| 21 | Thickness of No. 2 clutch | 35 | 32.9 | |
| 22 | Thickness of No. 3 clutch disc | 5 | 4.7 | |
| 23 | Thickness of No. 3 clutch plate | 5 | 4.7 | |
| 24 | Thickness of No. 3 clutch | 25 | 23.5 | |



F23E094

Unit: mm

| No. | Check Item | Criteria | | Remedy |
|-----|---|--------------------|-----------------|---------|
| | | Standard clearance | Clearance limit | |
| 25 | Thickness of No. 4 clutch disc | | | Replace |
| | | 5 | 4.7 | |
| 26 | Thickness of No. 4 clutch plate | 5 | 4.7 | |
| 27 | Thickness of No.4 clutch | 25 | 23.5 | |
| 28 | Thickness of No. 5 clutch disc | 5 | 4.7 | |
| 29 | Thickness of No. 5 clutch plate | 5 | 4.7 | |
| 30 | Thickness of No. 5 clutch | 15 | 14.1 | |
| 31 | Thickness of No. 6 clutch disc | 5 | 4.7 | |
| 32 | Thickness of No. 6 clutch plate | 5 | 4.7 | |
| 33 | Thickness of No. 6 clutch | 25 | 23.5 | |
| 34 | Thickness of No. 7 clutch disc | 5 | 4.7 | |
| 35 | Thickness of No. 7 clutch plate | 5 | 4.7 | |
| 36 | Thickness of No. 7 clutch | 45 | 42.3 | |
| 37 | Thickness of No. 8 clutch disc | 5 | 4.7 | |
| 38 | Thickness of No. 8 clutch plate | 5 | 4.7 | |
| 39 | Thickness of No. 8 clutch | 35 | 32.9 | |
| 40 | No. 1 clutch disc-to-No. 1 ring gear backlash | 0.29 – 0.67 | — | |
| 41 | No. 2 clutch disc-to-No. 2 ring gear backlash | 0.29 – 0.67 | — | |
| 42 | No. 3 clutch disc-to-No.3 ring gear backlash | 0.29 – 0.67 | — | |
| 43 | No. 4 clutch disc-to-No. 4 ring gear backlash | 0.29 – 0.67 | — | |
| 44 | No. 5 clutch disc-to-No. 5 ring gear backlash | 0.29 – 0.67 | — | |
| 45 | No. 6 clutch disc-to-No. 6 ring gear backlash | 0.19 – 0.54 | — | |
| 46 | No. 7 clutch disc-to-No. 7 ring gear backlash | 0.29 – 0.67 | — | |
| 47 | No. 8 clutch disc-to-No. 8 ring gear backlash | 0.29 – 0.54 | — | |



F23E094



Unit: mm

| No. | Check Item | Criteria | | | | | Remedy |
|-----|------------------------------------|----------------------|---------------------|-------------------|-----------------|-------------------|---------|
| 48 | No. 1 clutch spring | Standard size | | | Repair limit | | Replace |
| | | Free length x O.D | Installed length | Installed load | Free length | Installed load | |
| | | 53 x | 44 | 8.2 kg | 51.7 | 7.0 kg | |
| 49 | No. 2 clutch spring | 53 x | 47 | 5.5 kg | 51.9 | 4.5 kg | |
| 50 | No. 3 clutch spring | 39.6 x | 33 | 8.4 kg | 38.6 | 7.1 kg | |
| 51 | No. 4 clutch spring | 39.6 x | 33.5 | 7.8 kg | 38.6 | 6.5 kg | |
| 52 | No. 5 clutch spring | 39.6 x | 33 | 8.4 kg | 38.6 | 7.1 kg | |
| 53 | No. 6 clutch spring | 39.6 x | 34.5 | 6.5 kg | 38.6 | 5.2 kg | |
| 54 | No. 7 clutch spring | 66 x | 60 | 8.5 kg | 64.9 | 7.9 kg | |
| 55 | No. 8 clutch spring | 6.5 x | 5.5 | 143 kg | 6.2 | 100 kg | |
| 56 | Side clearance of planetary gear | Standard clearance | | | Clearance limit | | |
| | | 0.35 – 0.80 | | | 1.5 | | |
| 57 | Idler gear-to-driven gear backlash | 0.25 – 0.60 | | | — | | |

HYDROSHIFT TRANSMISSION CONTROL VALVE

GD705R-4

1. HYDROSHIFT transmission control valve




232F262

Unit: mm

| No. | Check Item | Criteria | | | | | Remedy |
|-----|---|---------------|------------------|-------------|--------------------|-----------------|---------|
| | | Standard size | Tolerance | | Standard clearance | Clearance limit | |
| | | | Shaft | Hole | | | |
| 1 | Clearance between shift valve spool (1st) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.08 | Replace |
| 2 | Clearance between shift valve spool (3rd) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.08 | |
| 3 | Clearance between shift valve spool (2nd) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.08 | |
| 4 | Clearance between cut off valve spool and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.08 | |
| 5 | Clearance between shift valve spool (H.L.) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.08 | |
| 6 | Clearance between valve spool (F.R.) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.08 | |
| 7 | Clearance between inching valve spool and sleeve | 17.2 | -0.035 -0.045 | +0.018 0 | 0.035 – 0.063 | 0.08 | |
| 8 | Clearance between inching valve and valve body | 25 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.08 | |
| 9 | Clearance between inching valve and valve | 10 | -0.020 -0.030 | +0.015 0 | 0.020 – 0.045 | 0.08 | |
| 10 | Clearance between speed selector spool and valve body | 14 | -0.035 -0.045 | +0.011 0 | 0.035 – 0.056 | 0.08 | |
| 11 | Clearance between priority valve and valve body | 25 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.08 | |
| 12 | Clearance between priority valve and valve spool | 15 | -0.02 -0.03 | +0.018 0 | 0.029 – 0.048 | 0.08 | |
| 13 | Clearance between modulating valve and valve body | 25 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.08 | |
| 14 | Clearance between modulating valve and valve spool | 15 | -0.02 -0.03 | +0.018 0 | 0.020 – 0.048 | 0.08 | |
| 15 | Clearance between modulating valve and valve body | 35 | -0.035 -0.045 | +0.016 0 | 0.035 – 0.061 | 0.08 | |
| 16 | Clearance between quick return valve and sleeve | 12 | -0.035 -0.045 | +0.011 0 | 0.035 – 0.056 | 0.08 | |
| 17 | Clearance between lubrication valve and valve body | 22 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.10 | |
| 18 | Clearance between cooler by-pass valve and valve body | 22 | -0.035 -0.045 | +0.013 0 | 0.035 – 0.058 | 0.10 | |

2. HYDROSHIFT transmission control valve spring



232F263


Unit: mm

| No. | Check item | Criteria | | | | | Remedy |
|-----|---------------------------------|-----------------------|---------------------|-------------------|----------------|---------|---------|
| | | Standard size | | | Repair limit | | |
| | | Free length x O.D. | Installed length | Installed load | Free length | Load | |
| 1 | Spool return spring | 36.75 x | 30 | 6.41 kg | | 6.09 kg | Replace |
| 2 | Inching valve spring | 26 x | 18 | 0.66 kg | | | |
| 3 | Inching valve spring (Large) | 50.2 x | 33 | 4.02 kg | | | |
| 4 | Inching valve spring (Small) | 39 x | 33 | 0.81 kg | | | |
| 5 | Inching valve spring | 16.1 x | 12.5 | 1.12 kg | | | |
| 6 | Priority valve spring | 35 x 9.5 | 21 | 1.33 kg | | 1.26 kg | |
| 7 | Priority valve spring | 115.5 x 16.9 | 100 | 23.5 kg | | 22.3 kg | |
| 8 | Modulating valve spring (Large) | 86.7 x 23.2 | 65 | 27.1 kg | | | |
| 9 | Modulating valve spring (Small) | 71.2 x 14.3 | 65 | 13.4 kg | | | |
| 10 | Lubrication valve spring | 39.4 x 15.6 | 37 | 6.20 kg | | 5.9 kg | |
| 11 | Cooler by-pass valve spring | 71.4 x 14.9 | 66 | 13.88 kg | | 13.2 kg | |

HYDROSHIFT TRANSMISSION CONTROL VALVE

GD705A-4

1. HYDROSHIFT transmission control valve




F23E04025

Unit: mm

| No. | Check Item | Criteria | | | | | Remedy |
|-----|---|---------------|------------------|-------------|--------------------|-----------------|---------|
| | | Standard size | Tolerance | | Standard clearance | Clearance limit | |
| | | | Shaft | Hole | | | |
| 1 | Clearance between shift valve spool (3rd) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.08 | Replace |
| 2 | Clearance between shift valve spool (1st) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.08 | |
| 3 | Clearance between shift valve spool (2nd) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.08 | |
| 4 | Clearance between shift valve spool (4th) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.08 | |
| 5 | Clearance between shift valve spool (H.L.) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.08 | |
| 6 | Clearance between valve spool (F.R.) and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.08 | |
| 7 | Clearance between inching valve spool and valve body | 10 | -0.020 -0.030 | +0.015 0 | 0.020-0.045 | | |
| 8 | Clearance between inching valve and valve body | 25 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | | |
| 9 | Clearance between inching sleeve and inching valve spool | 17.2 | -0.035 -0.045 | +0.018 0 | 0.035-0.063 | | |
| 10 | Clearance between speed selector spool and valve body | 14 | -0.035 -0.045 | +0.011 0 | 0.035-0.056 | 0.08 | |
| 11 | Clearance between priority valve and valve body | 25 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.08 | |
| 12 | Clearance between priority valve and valve spool | 15 | -0.02 -0.03 | +0.018 0 | 0.020-0.048 | 0.08 | |
| 13 | Clearance between modulating valve and valve body | 25 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.08 | |
| 14 | Clearance between modulating valve and valve spool | 15 | -0.02 -0.03 | +0.018 0 | 0.020-0.048 | 0.08 | |
| 15 | Clearance between valve and valve body | 35 | -0.035 -0.045 | +0.016 0 | 0.035-0.061 | 0.08 | |
| 16 | Clearance between quick return valve and sleeve | 12 | -0.035 -0.045 | +0.011 0 | 0.035-0.056 | 0.08 | |
| 17 | Clearance between lubrication valve and valve body | 22 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.10 | |
| 18 | Clearance between cooler by-pass valve and valve body | 22 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.10 | |
| 19 | Clearance between cut off valve and valve body | 19 | -0.035 -0.045 | +0.013 0 | 0.035-0.058 | 0.08 | |

2. HYDROSHIFT transmission control valve spring




F23E04026

Unit: mm

| No. | Check item | Criteria | | | | | Remedy |
|-----|---|-----------------------|---------------------|-------------------|----------------|---------|--------|
| 1 | Spool return spring | Standard size | | | Repair limit | | |
| | | Free length x O.D. | Installed length | Installed load | Free length | Load | |
| | | 36.75 x 19.3 | 30.3 | 6.12 kg | 36.1 | 5.51 kg | |
| 2 | Inching valve spring | 16.1 x | 12.5 | 1.12 kg | | | |
| 3 | Inching valve spring (Large) | 50.2 x | 33 | 4.02 kg | | | |
| 4 | Inching valve spring (Small) | 39 x | 33 | 0.81 kg | | | |
| 5 | Inching valve spring | 26 x | 18 | 0.66 kg | | | |
| 6 | Priority valve spring | 35 x 9.5 | 21 | 1.33 kg | 34.3 | 1.26 kg | |
| 7 | Priority valve spring | 115.5 x 16.9 | 100 | 23.50 kg | 114.7 | 22.3 kg | |
| 8 | Modulating valve spring (Large) | 86.7 x 23.2 | 65 | 27.03 kg | 85.6 | 25.7 kg | |
| 9 | Modulating valve spring (Small) | 71.2 x 14.3 | 65 | 13.39 kg | 70.9 | 12.7 kg | |
| 10 | Lubrication valve spring | 39.4 x 15.6 | 37 | 6.20 kg | 39.0 | 5.27 kg | |
| 11 | Cooler by-pass valve spring | 71.4 x 14.9 | 66 | 13.88 kg | 70.6 | 11.8 kg | |
| 12 | Cut off valve spring | 36.75 x | 30 | 6.41 kg | 36.1 | 5.79 kg | |
| A | Length between selector valve and yoke | 51.4 (for reference) | | | | | |
| B | Clearance between nut and selector valve body | 0.1 – 0.3 | | | | | |

HYDROSHIFT TRANSMISSION PUMP SAL045

GD705R-4




F23B061A

Unit: mm

| No. | Check Item | Criteria | | | | Remedy |
|-----|---|--------------------|-------------------|------------------|-------------------|--------|
| | | Standard clearance | | Clearance limit | | |
| 1 | Side clearance between gear case and side plate | 0.10 – 0.15 | | 0.19 | | |
| 2 | Bearing I.D. to gear shaft clearance | 0.060 – 0.125 | | 0.20 | | |
| 3 | SAL045 (EO10-CD 50 ± 5° C 210 kg/cm ²) | Standard value | | Repair limit | | |
| | | Pump speed (rpm) | Delivery (ℓ/min.) | Pump speed (rpm) | Delivery (ℓ/min.) | |
| | | 3000 | 121 | 3000 | 111 | |

SAL050

GD705A-4




24F004A

Unit: mm

| No. | Check Item | Criteria | | | | Remedy |
|-----|--|--------------------|-------------------|------------------|-------------------|--------|
| | | Standard clearance | | Clearance limit | | |
| 1 | Side clearance between gear case and side plate | 0.10 ~ 0.15 | | 0.19 | | |
| 2 | Clearance between bearing I.D. and gear shaft O.D. | 0.06 ~ 0.166 | | 0.20 | | |
| 3 | SAL050 SAE10W, Class CD at 50°C 210 kg/cm ² | Standard value | | Repair limit | | |
| | | Pump speed (rpm) | Delivery (ℓ/min.) | Pump speed (rpm) | Delivery (ℓ/min.) | |
| | | 3000 | 138 | 3000 | 128 | |

FINAL DRIVE

GD705R-4




232F143

Unit: mm

| No. | Check Item | Criteria | | Remedy |
|-----|--|---|--------------|--------|
| 1 | Preload of bevel pinion bearing | Starting torque: 1.2 – 1.6 kgm | | |
| 2 | Preload of side bearing | Starting torque: (Starting torque of bevel pinion bearing) + (0.3 – 0.4) kgm (Measured on pinion shaft) | | |
| 3 | Backlash between 2nd pinion and 2nd pinion | Tolerance | Repair limit | Adjust |
| | | 0.24 – 0.60 | 1.6 | |
| 4 | Backlash between bevel gear and bevel pinion | 0.3 – 0.4 | 1.4 | |

GD705A-4




234F107-1

Unit: mm

| No. | Check Item | Criteria | | Remedy |
|-----|--|--|--------------|--------|
| 1 | Preload of bevel pinion bearing | Starting torque: 1.2 – 1.6 kgm | | Adjust |
| 2 | Preload of side bearing | Starting torque: (Starting torque of bevel pinion bearing) + 0.3 – 0.4 kgm | | |
| 3 | Backlash between 2nd pinion and 2nd gear | Tolerance | Repair limit | |
| | | 0.24 – 0.60 | 1.6 | |
| 3 | Backlash between bevel pinion and bevel gear | 0.3 – 0.4 | 1.4 | |

TANDEM DRIVE

GD705R-4




F23E04029

Unit: mm

| No. | Check Item | Criteria | | Remedy |
|-----|-------------------------------|-------------------------------|--------------|---------|
| 1 | Hub bearing preload | Turning torque: 2.0 – 2.5 kgm | | Adjust |
| 2 | Extension of chain (10 links) | Standard size | Repair limit | Replace |
| | | 508.0 | 515.62 | |

GD705A-4



234F108-1

Unit: mm

| No. | Check Item | Criteria | | Remedy |
|-----|-------------------------------|--------------------------------|--------------|---------|
| 1 | Preload of hub bearing | Starting torque: 2.0 – 2.5 kgm | | Adjust |
| 2 | Extension of chain (10 links) | Standard size | Repair limit | Replace |
| | | 571.5 | 580 | |

STEERING SYSTEM


41 STRUCTURE AND FUNCTION



| | |
|--------------------|-------|
| Steering piping | 41- 2 |
| Steering wheel | 41- 5 |
| Steering valve | 41- 6 |
| Steering system | 41- 7 |
| Flow control valve | 41-14 |
| Steering pump | 41-18 |
| Steering cylinder | 41-20 |
| Front axle | 41-22 |
| Wheel | 41-28 |

STEERING PIPING

GD705R-4




F23E04030

The steering system on the GD705R is fully hydraulic. When steering wheel (3) is turned, an amount of oil in proportion to the angle of turning is sent from steering valve (2) (orbit roll type) to steering cylinder (1). This operates the steering.

- 1. Steering cylinder
- 2. Steering valve
- 3. Steering wheel
- 4. Steering pump (LAR016)
- 5. Flow control valve
- 6. Double relief valve

STEERING PIPING

GD705A-4




F23404015

The steering system on the GD705A is fully hydraulic. When steering wheel (3) is turned, an amount of oil in proportion to the angle of turning is sent from steering valve (2) (orbit roll type) to steering cylinder (1). This operates the steering.

- 1. Steering cylinder
- 2. Steering valve
- 3. Steering wheel
- 4. Steering pump (SAR032)
- 5. Flow control valve
- 6. Oil cooler
- 7. Double relief valve

STEERING WHEEL




F23AB043

The GD705-4 steering system features hydraulic control. A quantity of oil corresponding to the turn of the steering wheel (2) passes to the steering cylinder via a steering valve (Orbit roll type). The hydraulic oil is also used in the steering system.


- 1. Steering valve
- 2. Steering wheel

STEERING VALVE (Orbit roll type)



- 1. Rotor
- 2. Drive shaft
- 3. Center spring
- 4. Needle bearing
- 5. Upper cover
- 6. Center pin
- 7. Check valve ball
- 8. Sleeve
- 9. Spool
- 10. Stator
- 11. Lower cover

41F002



STEERING SYSTEM

STRUCTURE


The steering system is of the fully hydraulic type and hydraulic oil is sent to the steering cylinder by this steering valve, oil flow being varied with turning angle of the steering wheel. The valve has a built-in hand pump, which makes it possible to suck up oil directly from the tank so that necessary steering operation can be maintained in case of trouble of the oil pump or the engine. This valve is of the orbit roll type.

- The lower end of the steering wheel shaft is spline-fitted to the top of the spool, which is inserted in the sleeve. The spool and the sleeve are joined to each other with the center pin (which does not contact to the spool when the steering wheel is at neutral position) and the center spring.


- There is the drive shaft inside the spool. The upper end of the shaft is joined to the center pin and the lower end of it is spline-fitted to the hand pump rotor. The hand pump adjusts oil flow to the cylinder, depending on steering angle of the steering wheel, and also acts to supply oil to the cylinder in case of oil pump or engine trouble by utilizing turning force of the steering wheel to suck up oil directly from the tank.

- The valve body has four ports which connect to the oil pump, tank, steering cylinder head and steering cylinder bottom, respectively. The pump side port and the tank side port are connected to each other through the check valve, which permits the steering valve to suck up oil directly from the tank in case of oil pump or engine trouble.
- ★ For the function of center spring, refer to page 41-12.

Steering wheel shaft is connected here.




41P002



41P003


Center pin is inserted in this groove.




41P004

OPERATION

When steering wheel is not manipulated




41F003




41F004

When the steering wheel is not manipulated, the center spring keeps the spool and the sleeve are stopped in the position at which the center pin is located to the center of the slotted hole in the spool. Under this condition, the ports that connect the sleeve to the steering cylinder and the hand pump are insulated from the lengthwise slots in the spool. While, the small holes in the spool bottom are aligned with those in the sleeve bottom. (Total 24 holes are provided by arranging twin holes at 12 places equally spaced around the circumference of spool or sleeve.)

Oil from the pump enters the valve inlet port and flows through the small holes in the sleeve and spool to the inside of the spool. The oil, in turn, flows through the slotted hole in the spool and the spring mounting portion to the valve outlet port, and is returned to the tank.





41P005






41P006

When steering wheel is manipulated (Turning to the left)



- When the steering wheel is turned to the left, the rotation causes the spool spline-fitted to the steering wheel shaft to turn to the left. As the sleeve is joined to the spool with the center spring, the spring contracted by the spool causes a difference in turning angle between the spool and the sleeve depending on contraction of the spring. As the result, each port in the sleeve is connected to a lengthwise slit in the spool.
- Under this condition, the hand pump port in the sleeve and the steering cylinder port (on the left-steering side) in the sleeve are connected to each other through the lengthwise slits in the spool. Also, the steering cylinder port (on the right-steering side) in the sleeve is connected to the valve outlet port in the sleeve.
- Oil from the pump enters the hand pump through the valve inlet port and returns to the sleeve. The oil, in turn, flows from a lengthwise slit in the spool, through the steering cylinder port in the sleeve to the steering cylinder. While, oil from the steering cylinder is forced to flow through the port in the sleeve and a lengthwise slit in the spool and returns to the tank.
- Under such a condition as mentioned above, the hand pump is rotated by hydraulic oil from the pump and acts as an oil motor to lighten steering wheel manipulating force. When the steering wheel is stopped turning, difference in turning angle between the sleeve and the spool is removed by return force of the center spring. The same condition as mentioned before under "When steering wheel is not manipulated" is recovered. Refer to page 41-11 for details of mutual relation between the hand pump ports (7 ports) and the sleeve ports (12 ports) which will be connected to each other when the steering wheel is turned to either direction.

When steering is made with the oil pump malfunctioning (Turning to the right)



- When a motor grader is to be towed by another machine because of some trouble in the oil pump or the engine, keeping normal steering of the grader cannot be neglected to prevent accident. To satisfy this requirement, a built-in hand pump is provided on the bottom of the steering valve. When the steering system is normally supplied hydraulic oil from the pump, the hand pump is only to control flow of oil, its rotation being supported by pressure of oil. When oil from the pump is stopped, the center pin comes into contact with an end of the slitted hole in the spool and, then, turning force of the steering wheel is used for driving the hand pump.

- Like as before-mentioned, a difference occurs in turning angle between the spool and the sleeve and, therefore, each port in the sleeve is connected to a lengthwise slit in the spool. The hand pump is rotated with turning of the steering wheel. The rotation causes the hand pump to suck oil directly from the tank, through the check valve provided between the valve outlet port and the inlet port, and to deliver oil to the steering cylinder.
- The hand pump resemble trochoid pumps, but its ports are arranged on the root of teeth and each port acts as the inlet port and the outlet port alternatively. Oil suction and discharge operation of the hand pump is carried out by the combination of the seven ports in the hand pump and the 12 ports in the sleeve. (see page 41-11)

CONNECTION OF HAND PUMP PORTS TO SLEEVE PORTS




Fig. 1

41F010






Fig. 2

41F011

- The scheme of connection of hand pump ports (7 ports) to sleeve ports (12 ports) is illustrated above. When the steering wheel is turned to the right, ports 2, c, e, g, i and k are connected through the lengthwise slits in the spool to the pump. Similarly, ports b, d, f, h, j and l are connected to the steering cylinder.
- Under the condition shown in Fig. 1, hand pump ports 1, 2 and 3 are in oil delivery state. At that time, these ports are just connected to sleeve ports 1, b and d, respectively, and oil is sent to the cylinder from these ports. Furthermore, hand pump ports 5, 6 and 7 are in oil suction state and they are just connected to sleeve ports g, i and k ports, respectively. Oil from the steering oil pump is sucked up through these ports. When the steering wheel is turned 90° from the condition shown in Fig. 1, connection of hand pump ports to steering ports shown in Fig. 2 is obtained. Under this condition, hand pump ports 1, 2 and 3 just connected to sleeve ports i, k and a, respectively, are in oil suction state. While, hand pump ports 5, 6 and 7 just connected to sleeve ports d, f and h, respectively, are in oil delivery state.



41P007




41P008


- As described above, hand pump ports being in oil delivery state are connected to the respective sleeve ports which lead to the steering cylinder. While, hand pump ports being in oil suction state are connected to the respective sleeve ports which lead to the steering oil pump. When supply of oil from the steering oil pump is stopped because of some trouble in the engine or the pump, the hand pump is forced to suck up oil from the tank and deliver oil to the steering cylinder with manipulation of the steering wheel. Therefore, necessary steering operation can be maintained.
- The other function of the hand pump is to adjust delivery of oil by using the fact that all oil from the steering oil pump must always pass through the hand pump. As the internal gear of the hand pump advances one tooth for each 1/7 turn of the steering wheel, causing delivery of oil corresponding to the advance of the internal gear, quantity of delivery of oil is direct proportion to the steered angle of the steering wheel. This function of the hand pump is not lost even when the engine or steering oil pump is mal-functioning, so that normal oil delivery property can be maintained.

Comparison between trochoid pump and steering valve hand pump

- In the case of the trochoid pump, the inlet port and the outlet port are located separately from each other. When the pump shaft turns as shown in the figure below, the pump sucks oil from the inlet side and delivers it from the outlet side in the sequence of 2 to 6.





- In the case of the hand pump, the inlet/outlet ports are arranged at the root of teeth of internal gear. When the pump shaft runs, the port shown in the figure is connected to the steering oil pump at the steps 2 and 3 to suck up oil and is connected to the steering cylinder at the steps 5 and 6 to send oil to the cylinder. Each of seven ports performs the same oil suction and delivery operation, independently.




Function of center spring

- The X-shape center spring, which is formed by two sets of three leaf springs as shown in the photo below, is installed in the sleeve and spool. When the steering wheel is turned in either direction, the spool compresses the center spring. Because of the X-shape spring, some angular difference arises between the sleeve and the spool. This causes the connection of sleeve ports and spool ports to each other so that oil flows through the ports to the steering cylinder. When turning of the steering wheel is stopped, the hand pump stops turning. As oil flow to the cylinder is shut off, oil pressure rises until the main relief valve opens to relieve the oil. To prevent such unnecessary rise of oil pressure, the center spring returns to the original state so that no angular difference between the sleeve and the spool remains. Then, the same condition as mentioned before under "When steering wheel is not manipulated" in page 41-8 is recovered.



FLOW CONTROL VALVE


GD705R-4



F23E04031

- | | |
|-------------------|--------------|
| 1. Body | 6. Snap ring |
| 2. Relief spring | 7. Spring |
| 3. Relief plunger | 8. Plunger |
| 4. Connector | 9. O-ring |
| 5. Spring seat | 10. Plug |

GD705A-4




F23AB089

- | | |
|------------------|-------------------------|
| 1. Valve body | 7. Nut |
| 2. Relief spring | 8. Adjusting screw |
| 3. Poppet valve | 9. O-ring |
| 4. O-ring | 10. Plug |
| 5. Housing | 11. Flow control spring |
| 6. Plate | 12. Plunger |
| | 13. O-ring |
| | 14. Plug |

OPERATION (For example GD705A-4)

1. When pump delivery is lower than regulated flow


The flow of oil from the pump (IN side) passes through the orifice and goes to the steering valve (PF side). When this happens, the flow of oil through the orifice causes a difference in pressure on the two sides of the orifice. This difference in pressure acts on the plunger which compresses the spring. Because of the balance with the spring force, portion "A" of the plunger is not connected to the tank (EF side). As a result, all of the oil flows to the steering valve (PF side).



F23AB147

2. When pump delivery is high than regulated flow


When the flow of oil from the pump (IN side) exceeds the set regulated flow, the difference in pressure on the two sides of the orifice becomes larger. The plunger moves, portion "A" opens, and the remaining oil flows to the tank (EF side). In this condition, the steering valve (PF side) circuit functions. If the pressure rises, the plunger moves to make the area of the opening at portion "A" smaller. In this way, the system is kept in balance automatically so that the actuating pressure and set regulated flow can be maintained.



F23AB148

3. When circuit on tank side (EF side) is actuated

If oil flows to the tank (EF side) is actuates the tank circuit (EF side). When the pressure rises, the difference in pressure on the two sides of the orifice causes the plunger to move. This makes the opening at portion "B" smaller, and automatically prevents the excess oil from flowing to the steering valve (PF side).





F23AB149

4. When circuits on steering valve side (PF side) and tank side (EF side) are actuated simultaneously


If the actuating pressures of the circuits on both the steering valve side (PF side) and the tank side (EF side) are raised simultaneously, the openings at portions "A" and "B" of the plunger are automatically determined so that a constant regulated flow is maintained.

STEERING PUMP

GD705R-4 (LAR016)
GD705A-4 (SAR032)



Section A-A





Section B-B

F23E030

- 1. Snap ring
- 2. Oil seal
- 3. Bracket
- 4. Gear case
- 5. Carrier
- 6. Driven gear
- 7. Drive gear

STEERING CYLINDER


GD705R-4



F23E04032

1. Snap ring
2. Cylinder head
3. Dust seal
4. Back up ring
5. O-ring
6. Bushing
7. Rod packing
8. Piston rod
9. Cylinder
10. Piston
11. Piston ring
12. Wearing
13. Nut

GD705A-4






F23E03 I


- 1. Snap ring
- 2. Cylinder head
- 3. Dust seal
- 4. Ring
- 5. Backup ring
- 6. O-ring
- 7. Bushing
- 8. Rod packing
- 9. Piston rod
- 10. Cylinder
- 11. Piston
- 12. Piston ring
- 13. Wearing
- 14. Nut

FRONT AXLE

GD705R-4



Section A — A




Section B — B

Toe-in 6.5mm
 Camber 1.5°
 King pin tilting angle 8.5°

1. Knuckle arm
2. Leaning rod
3. Knuckle bracket
4. Hub
5. Knuckle
6. Hub bolt, Nut
7. King pin
8. Front axle

F23E04033

GD705A-4



F23E032

Toe-in 8.2 ± 1.0 mm
 Camber 1.5°
 King pin tilting angle: 0°

1. Tie rod
2. Pitman arm
3. Front axle
4. Leaning rod
5. Housing
6. Hub shaft
7. Hub nut
8. King pin
9. Bracket
10. Nut


FUNCTION OF FRONT AXLE

1. Steering

Refer section, "STEERING SYSTEM"

2. Lessening blade angling and up-and-down movement

The axle is fixed in the center with a center pin to the frame so that it can oscillate 13 degrees. This, like the tandem system, restricts the up-and-down movement of the blade to a minimum when one front wheel rides over an object or falls into a hole. When the front wheel rides over an object (height-H), the center point of the front axle rises H/2, as shown in drawing. Because of possible rocking of front axle blade movement rises only H/4 while holding its horizontal posture. Unless the whole oscillating range (left, right 13°) of the front axle is used, the blade moves up-and-down holding its horizontal posture.




41F017

3. Prevention of side slipping of front wheels (leaning system)

The front wheels can be tilted to left or right. This is called the leaning system, and is to prevent the front wheels from slipping sideways and to reduce the turning radius.


Operations with blade at propulsion angle are frequent among grader operations. In proportion to the propulsion angle a side slipping force acts on the blade to cause side slipping.



41F018

Also the distribution of weight on the front and rear wheels is about 3:7, and when the blade cuts into the ground, the load on the front wheels decreases and it is easier for the front wheels to slip sideward.

To counteract this side slipping, the front wheels are leaned to make them more resistant, and this changes the center of the load on the front axle and the center of gravity of the machine and prevents side slipping.




41F019

When the wheel is leaned the angle between the center line of the leaned tire and the perpendicular line is called the "Leaning angle".

Leaning angle is the distance $S = 2 \times \pi \times r$ covered by the tire as it advances, and the side with the greater load radius, in order to advance more than the side with the less load radius, advances in the direction of the leaning. Using this characteristic, the turning radius can be lessened when the leaning operation is carried out.

When backing, leaning should be reversed to the leaning for forward operation by turning a steering wheel in the same direction.

Leaning angle is 16.5° .




41F020

Also, when there is no differential mechanism, even though the front wheels are steered, the rear wheels tend to go straight ahead and this causes the front wheels to slip little by little. Leaning prevents this. Also, the front wheels steering angle is increased by leaning.

Explanation according to the drawing to the right: (In order to keep the explanation simple it will be done without steering.)

When the front wheels are leaned to one side, O_4 revolves 23° around O_3 and comes to O_4' , and at the same time O_2 also revolves around O_3 and comes to O_2' . The tie-rod revolves around O_1 , but since its length is fixed, a clearance " l " is made. However, since O_1 is fixed, the housing is pulled to the " l " and comes to the position " l " (O_2).

Since the front wheels are steered a little in the direction of leaning, the steering angle becomes a little bigger.



41F021


- O_1 : Center of pitman arm ball joint
- O_2 : Center of tie-rod end pin
- O_3 : Center of mounting pin of housing
- O_4 : Center of cylinder rod

FRONT WHEEL ALIGNMENT

In vehicles steered by the two front wheels, the wheels are fitted by a special method to ensure ease, stability, and accuracy in steering. This special fitting is called alignment, and has a very big influence on operation of the steering wheel.

1. Camber

The front wheels are fitted so that the top of the wheels is further away from the vehicle than the bottom of the wheels in contact with the ground. This slanting is called camber.




2. Toe-in

When seen from above, the distance **A** between the front of the front wheels is slightly less than the distance **B** between the rears.

This is called toe-in.

When vehicles travel with a camber angle, the force which tends to push the front wheels outwards increases the ground resistance of the wheels, resulting in less stable travel and greater tire wear. By fitting the wheels with a slight inward slant, however, this undesirable tendency can be eliminated. The difference between **A** and **B** of 3 to 7 mm is called the toe-in quantity.




3. King pin angle of inclination

The king pin is not exactly vertical to the ground but inclines slightly inwards. This angle is called the king pin angle of inclination.

Together with the camber, this inclination shortens the trail for easier steering wheel operation.

Since the front wheels turn during operation with the king pin center line as the center axis, the front wheels tend to be lifted up. This action, however, is also accompanied by a reaction which tends to return the wheels to the former position. When the grader turns a little and still is about to proceed straight ahead, releasing the steering wheel will generate the restoring force, and bring the steering wheel back to its former position. This angle is generally about 5° to 8°.




4. Caster (The caster angle in graders is 0°.)

Caster refers to the angle at which the king pin is fitted when the wheel is viewed from the side shown in the accompanying diagram. The angle is called the caster angle.


If the king pin is fitted at an angle, the point of contact between the wheel and the ground will be behind the point where the extrapolated king pin center line meets the ground. This means that during travel, there is a force constantly pulling the wheels backward, depending on the ground resistance added to the point where the wheels are in contact with the ground. This backward force tends to keep the wheels directed straight ahead (directional property).

This force also tends to return the steering wheel to the original position when the steering wheel is turned (restoring property).

In automobiles, the caster angle is generally 1° to 3°. In graders, however, the angle is 0°.



230F112



Three-wheel vehicle


Office chair

230F113

WHEEL

GD705R-4

FRONT WHEEL




F23E04034

| | |
|--------------|------------------------|
| Tire size | 14.00 – 24 – 12PR |
| Tire pattern | Traction |
| Rim size | 8.00TG x 24 |
| Air pressure | 3.5 kg/cm ² |

- 1. Side ring
- 2. Rim
- 3. Tube
- 4. Tire

REAR WHEEL



Oscillate angle $+13^{\circ} \sim -13^{\circ}$

F23E04035


| | |
|--------------|------------------------|
| Tire size | 14.00 - 24 - 12PR |
| Tire pattern | Traction |
| Rim size | 8.00TG x 24 |
| Air pressure | 3.5 kg/cm ² |

- 1. Side ring
- 2. Rim
- 3. Tube
- 4. Tire

WHEEL

GD705A-4

FRONT WHEEL




F23E033

| | |
|--------------|------------------------|
| Tire size | 16.00 – 24 – 12PR |
| Rim size | 10.00VA x 24SDC |
| Air pressure | 2.2 kg/cm ² |

- 1. Side ring
- 2. Rim
- 3. Tube
- 4. Tire

GD705A-4

REAR WHEEL




F23E034

| | |
|--------------|------------------------|
| Tire size | 16.00 – 24 – 12PR |
| Rim size | 10.00VA x 24SDC |
| Air pressure | 2.2 kg/cm ² |

- 1. Side ring
- 2. Rim
- 3. Tube
- 4. Tire

STRUCTURE



230F117

1. Tread
2. Breaker
3. Side wall
4. Bead wire
5. Carcass

There are many different types of tires used in construction machines, and these are used under a wide range of different conditions. Hence, unlike ordinary automobile tires, construction machinery tires vary greatly from type to type.

With the larger scale of construction operations today, the life and cost of the tires of wheeled construction machinery will naturally be related to construction profit factor.

As a result of research into these problems, a tire of large floatation with reduced internal pressure and smaller grounding pressure was developed. This tire is called the "off the road" tire.

The improved performance of construction vehicles also required better performance tires. The "wide base tire" was standardized in 1956.

Most construction vehicles operate in sandy, muddy, or rocky conditions and cannot, therefore, travel at high speeds. Internal pressure and load are thus determined by speed. On rocky surfaces and also in sandy and muddy conditions, speeds will naturally be slower, and on rocky ground, there is greater likelihood of suffering tire cuts and punctures. In sandy and muddy conditions, tires with reduced internal pressure for greater floatation are used to prevent the tires from sinking into the sand or mud.

In other words, it is important to select the right type of tire for the right job.

1. Tread

The tread is the outermost layer of a tire, its main purpose being to protect the internal parts of the tire as well as minimizing wear and abrasion. That part of the tread in contact with the ground is called the crown. This is the section which is made with different patterns and groove types to match the conditions where the tire is to be used.

2. Breaker

This section is located between the tread and the carcass. It absorbs shocks applied to the tire and prevents tread damage from penetrating any further.

3. Sidewall

In addition to protecting the carcass, the sidewall swells in and out continuously during travel.

4. Tire bead

Made of copper and steel wires, these beads secure the tire to the rim. The beads in tubeless tires are also very important in maintaining airtight conditions.

5. Tire body (carcass)

The tire body absorbs the load and shocks applied to the tire. It consists of layers of special cord material criss-crossed sufficiently to withstand the internal pressure. In other words, this section forms the tire skeleton.

6. Ply

Located inside the tire body, this section is formed by layers of a powerful nylon cord material.

TRACTION AND FLOATATION

Greater floatation is achieved by reducing grounding pressure.

- (1) Reduce the air pressure as much as possible.
- (2) Use tires which are as wide as possible.
- (3) When the load is constant, increase the grounding length and the width of the tire in contact with the ground.
- (4) Use wide base tires.
- (5) Reduce the machine load.

To increase traction

- (1) Increase the machine load.
- (2) Use tires with a tread which helps the tire bite into the ground.
- (3) Use large diameter tires, and prevent free rotation.
- (4) Take the ground conditions into consideration and select the most suitable ground for travel.

Tires for soft ground


- (1) Increase the air pressure (to reduce the ground contact area and reduce rotational resistance).
- (2) Use tires with a large external diameter (to prevent possible free rotation).
- (3) Lighten the load.

TIRE AND RIM NOMINAL DIMENSIONS

Tire Nominal Dimensions

Tire nominal dimensions include tire width in inches, tire inner diameter in inches, and tire strength in ply rating, the three figures being joined by hyphens.



Example



Rim Nominal Dimensions

Rim nominal dimensions include the width of the tire seat in inches plus a symbol denoting the shape of the edge, and the diameter of the tire seat (tire inner diameter) expressed in inches and joined by an X.

Example




230F118

TUBELESS TIRES

Tubeless tires are commonly used on large dump trucks and large scrapers.

Structurally, tubeless tires include a special layer of rubber on the inside to preserve airtight conditions. The bead section must be very tough, and therefore uses relatively expensive materials. However, due to the difficulty in repairing punctures where the carcass is penetrated, tubeless tires are seldom used on small sized loaders.

With large sized loaders and dump trucks, where the benefits of greater service efficiency have been acknowledged, there is increasing interest in the use of tubeless tires.



230F119

FEATURES

1. No sudden loss of air when the tire is punctured by nails, etc. (Integrated structure with inner liner).
2. Simple rim assembly operation. (No tube or flap).
3. Relatively longer lift due to better thermal radiation during travel.

NORMAL WIDTH TIRES AND WIDE BASE TIRES


Construction machines use either normal width tires or wide base tires.

OR (OFF THE ROAD) TIRE CLASSIFICATIONS

| Service | TRA* classification | Tread | Use |
|---------|---------------------|----------|--|
| Grader | G-1 | Rib | For front wheels of graders. |
| | G-2 | Traction | For rear wheels of graders used where traction is necessary. |
| | G-3 | Rock | For rear wheels of graders used where resistance against external necessary, rather than traction. |

*TRA stands for Tire and Rim Association

Tread Patterns



TIRE MOUNTING METHOD

Many graders use traction type tires with a tread pattern designed to prevent slipping and sand clogging.

Rear wheels


In order to prevent sand clogging in the tread grooves and to protect the tire surface from undue wear during operation, the pattern of the tread on the rear wheels is like a row of inverted V's when seen from behind.

Front wheels

Rib pattern tread is sometimes used on the front wheels in order to prevent lateral sliding during grading operations.

Where traction treads are used, the pattern is in the reverse direction from the rear wheel pattern. That is, the pattern appears like a row of inverted V's when seen from the front.

When the front wheels are pushed forward and roll over, a force is applied just as if the wheels were driven from the direction of the ground. And since this is opposite to the action on the rear wheels, sand clogging and tire wearing is avoided.



230F135

REFERENCE

GENERAL TIRE KNOWLEDGE

Tire punctures

A major disadvantage in rubber tires is the lack of resistance to heat, poor heat conductivity, and relative weakness when wet. A simple experiment where rubber is stabbed with a wet knife and dry knife will illustrate the difference in this respect.

How to prevent punctures

1. Clear the operating area of protrusions and broken rock.
2. Check that the tire air pressure is at the suitable level.
3. Do not travel at high speed during operations. (This applies particularly to large dump trucks and motor scrapers).
4. Use tires with a low ply rating.

Causes of tire wear

1. Poor ground management at work area.
2. Excessive tire slipping.
 - Poor driving skill.
 - Excessive load.
 - Small tire diameter.
3. Unsuitable tire tread selection.

TMPH (Ton-mile per hour)

TMPH is an expression of work performed per hour. Tire MPH refers to the MPH of the tire itself, while operating MPH refers to the MPH of the operation.

Tire MPH

Refers to the tire heat generation limit for different sizes, ply ratings and structures.

Operating MPH

Determined from the following equation based on speed and load.

Operating MPH calculation

$$\text{MPH} = (\text{Average tire load}) \times (\text{Average speed})$$

Average tire load

$$= \frac{1}{2} (\text{tire load when vehicle carries empty load} + \text{tire load when vehicle is loaded})$$

Average speed

$$= \frac{\text{round trip distance} \times \text{number of job cycles per day}}{\text{total hours of operation per day}}$$

Total hours of operation include the recess and dead time.

Note: The unit for round trip distance is miles
(1 km = 0.625 mile).

The calculated operating MPH is calculated and compared with the tire MPH

1. The operating MPH should be less than the tire MPH.
2. If the operating MPH is greater than the tire MPH, the problem should be remedied immediately.

Where the operating MPH is greater than the tire MPH, there is danger of tire damage due to heat generation. Either change to tires with a higher MPH, or adjust the operating conditions to reduce the operating MPH.

TMPH RATING AT AMBIENT TEMPERATURE °C (°F)

Where the ambient temperature in an operating environment is high or where a long haul or high-speed drive is required, the standard tires cannot sometimes be suitable because of its small MPH.

MPH should vary depending on the atmospheric temperature. Thus, under the above operating conditions, it is recommended that the optimum tires to determined after obtaining MPH by applying the previously stated formulas.

- NOTES:
1. The MPH Rating varies depending on the tire manufacturer.
 2. The MPH Rating is based on U.S. ton.
(not on metric ton)

OR (OFF THE ROAD) TIRE AIR PRESSURE

● **Tire Air Pressure**

Tires perform their roles once they have been inflated with air. These roles include support of the vehicle and load, and movement along the ground in response to drive and control forces. Tires also absorb the shock of impact with the ground and are instrumental in changing the direction of the vehicle. To fulfill these roles, tires must be inflated to the proper level.

Maintaining this proper air pressure is important to protect the tires from damage and ensure longer service life.

Proper air pressure is determined according to vehicle features, operating conditions, and other conditions. With air pressure at the prescribed level, the standard load specifications should not be exceeded.

● **Importance of Air Pressure**

When the vehicle is loaded with inflated tires stationary, the tire shape is changed in the vertical direction (vertical flexure) and the horizontal direction (horizontal flexure).

The relation between vertical flexure and load varies considerably at different air pressures.

In large dump trucks operating at dam sites, contact between pairs of wheels can sometimes be seen even when the truck does not appear to be overloaded. This would not occur, however, if the tires were at correct air pressure. That is, contact between wheels in this case is more likely to be due to insufficient air pressure than to overloading.

When the tire is pressed to the ground, the pressure distribution of the section on the ground also changes greatly at different air pressures. The shape of the section on the ground is usually elliptical, and the lower the air pressure (with greater change in tire shape), the longer the length on the ground becomes. That is, a drop in air pressure increases the grounding length and enlarges the movement of the ground surface section. A larger section on the ground leads to accelerated generation of heat and greater tire wear. This subsequently increases the fatigue in the tire carcass and deterioration of the cord material strength.


For these reasons, always check the following points during tire maintenance checks.

- a. Check air pressure and refill air at normal temperature (while still cold).
- b. Check new tires more frequently.
New tires tend to expand within a certain fixed period after fitting. The volume capacity also increases, resulting in a corresponding drop in air pressure.
- c. Use tire gauges correctly.




Correct air pressure

230F120



Under inflated

230F121



Over inflated

230F122

STEERING SYSTEM

42 TESTING AND ADJUSTING



| | |
|-----------------------------------|------|
| Table of judgement standard value | 42-2 |
| Steering wheel | 42-3 |
| Checking tire play | 42-4 |
| Checking toe-in | 42-5 |

TABLE OF JUDGEMENT STANDARD VALUE

(): GD705A-4 Serial No. 31001 and up


| | Item | Test Condition | Standard | |
|---------------------|--|---|------------------------|------------------------------------|
| | | | GD705R-4 | GD705A-4 |
| Stroke | Steering wheel turning angle | | 5.4 turns \pm 50° | 5.35 turns \pm 50° |
| | Leaning lever | Travel at the tip of the lever | 45 \pm 10 mm | 45 \pm 10 mm (40 \pm 10 mm) |
| | Articulation lever | Travel at the tip of the lever | — | 40 \pm 10 mm (45 \pm 10 mm) |
| Operating force | Steering wheel (turning direction) | When traveling at engine slow rotation, F-1 | Max. 5 kg | Max. 5 kg |
| | Leaning lever | Maximum value until just before stroke end | Max. 5 kg | Max. 5 kg |
| | Articulation lever | Maximum value until just before stroke end | Max. 5 kg | Max. 5 kg |
| Wheels | Tire vibration | Measure tire side surface of both front and rear wheels with dial gauge | Max. 7 mm | Max. 7 mm |
| | Tire air pressure | Front wheel | 3.5 kg/cm ² | 2.2 \pm 0.2 kg/cm ² |
| | | Rear wheel | 3.5 kg/cm ² | 2.2 \pm 0.2 kg/cm ² |
| | Camber | Level paved surface | 1.5° \pm 5% | 1.5° \pm 5% |
| | Toe in | Level paved surface | 6.5 \pm 1.5 mm | 8.5 \pm 1.5 mm |
| | Leaning angle | Level paved surface | 23 \pm 2° | 23.5 \pm 2° |
| | Wheel bearing band temperature | Measure at surface of wheel cap after traveling 10km | Max. 40°C | Max. 40°C |
| Steering wheel play | At engine slow rotation, and with the tires floating measured at the outside circumference of the steering wheel | 10 – 12 mm | 10 – 12 mm | |

STEERING WHEEL

CHECKING STEERING WHEEL PLAY

Standard play: 10 to 12 mm

When the play of the steering wheel is outside the standard value or vibrates abnormally or pulls, replace the steering valve assembly.




42F001

CHECKING STEERING WHEEL OPERATING FORCE

Using push-pull scale ①, measure the operating force of the steering wheel.

- ★ Measure operating force of the steering wheel with the engine idling and with the wheels on the ground.




P23EC229

CHECKING TIRE PLAY

FRONT WHEEL CHECK

1. Start the engine and raise the front wheels off the ground, using the blade or scarifier as a jack.
2. Use dial gauge ① to measure the tire play while rotating the tire (1) by hand.




REAR WHEEL CHECK

1. Start the engine and raise four rear wheels by operating the blade.
2. Insert block ② in place at rear side of chassis.
3. Use dial gauge ① to measure the tire play while rotating the tire (2) by hand.





Measure with engine stopped.



P23BB143

CHECKING AIR PRESSURE OF TIRE


Use tire gauge ① to measure the air pressure of front and rear wheels.




CHECKING TOE-IN

CHECKING TOE-IN


1. Put steering and leaning in central position and park the machine on a level surface.
 - ★ Park the machine after it has moved a few meter straight forward.
2. Use convex rule to measure the height from tire tread level to the center of the shaft.
3. Mark the center of the width of both left and right tires at the height attained in item 2.
4. Use convex rule to measure distance **A** between the marks on the left and right tires.
5. Advance the machine slowly and move the marks on the front of the tires to the back. Stop the machine when these marks are the same distance from the tire tread level to the center of the shaft.
6. Use the convex rule to measure distance **B** between the marks on the left and right tires.
7. Standard of toe-in: $B - A = 6.5 \pm 1.5 \text{ mm (GD705R-4)}$
 $B - A = 8.5 \pm 1.5 \text{ mm (GD705A-4)}$



K9075



KE2639




K9058


TOE-IN ADJUSTMENT

- ★ When toe-in is out-side standard value, adjust it according to following procedure.
Loosen mounting nuts (1), apply wrench to the notch section (2), turn left and right tie-rods, and adjust to within standard value.
- ★ Toe-in increases when tie-rod is turned in the direction of the arrow, and decreases when it is turned in the opposite direction.
- ★ Adjust length of left and right (C and D) tie-rods equally.
- ★ Adjust with the front axle horizontal without any leaning.


GD705R-4



GD705A-4




GD705R-4



232F207

GD705A-4



F23EC045

STEERING SYSTEM



43 DISASSEMBLY AND ASSEMBLY



| | |
|--------------------------------|-------|
| FRONT AXLE ASSEMBLY | |
| Removal | 43- 2 |
| Installation | 43- 6 |
| STEERING PUMP ASSEMBLY | |
| Removal and installation | 43-14 |
| STEERING CYLINDER ASSEMBLY | |
| Removal and installation | 43-15 |

REMOVAL OF FRONT AXLE ASSEMBLY

GD705R-4




43F001

1. Front wheel assembly

- 1) Loosen wheel nut (1) a little.
- 2) Raise front wheels using the blade as a jack and support the lower part of frame center firmly with a block (700 mm high).
- 3) Temporarily sling wheels (2) with nylon sling ①. Remove wheel nuts and remove wheel assembly.



Front wheel assembly: Approx. 160 kg



2. Cover

Remove cover (3).




3. Hub assembly


- 1) Remove nuts (4).
- 2) Temporarily sling hub assembly (5). Using gear puller (2), pull out hub assembly and lift it out.




Hub assembly: Approx. 50 kg

**4. Tie rod**


Remove nut (6) and disconnect tie rod (7).

**5. Leaning rod**

Remove nut (8) and disconnect leaning rod (9).

**6. Shaft**

Temporarily sling bracket and axle. Remove nut (10) and pull out shaft (11).




7. Axle assembly


Pull out shaft (11) and sling out axle assembly (12).




Bracket and axle assembly: Approx. 35 kg

**8. Arm**

- 1) Remove grease fitting plug (13).
- 2) Remove nut (14) and pull out arm (15).


**9. Knuckle arm**

Remove nut (16) and pull out knuckle arm (17) using press.

**10. King pin**


Pull out king pin (18).

- ★ Blind plug (19) can be removed together with king pin.





11. Axle

- 1) Remove axle (21), bearing (22) and spacer (23) from bracket (20).
- 2) Remove bearing (24) and spacer (25).



INSTALLATION OF FRONT AXLE ASSEMBLY


GD705R-4



43F002

1. Axle


- 1) Install spacer (25) and bearing (24).
- 2) Install axle (21), bearing (22) and spacer (23) on bracket (20).



43P014 43P013

2. King pin

- Drive king pin (18) and drive blind plug (19).
- ★ Drive king pin with its notch pointed in installation direction of knuckle arm.





43P012

3. Knuckle arm

Drive knuckle arm (17) and loosely install collar and nut (16).

★ Fully tighten nut after mounting front axle on machine.


 Knuckle arm: Grease (G2-L1)




4. Arm

1) Drive arm (15) and loosely install collar and nut (14).

★ Fully tighten nut after mounting front axle on machine.



 Fitting plug: Thread tightener (LT-2)

2) Tighten grease fitting (13).



5. Axle assembly

Sling axle assembly (12) in place and insert it with shaft (11).




6. Shaft


Fasten shaft (11) with nut (10).


 Nut: 60 ± 40 kgm

★ Bend down cotter pin firmly.


**7. Leaning rod**

Connect leaning rod (9) and tighten nuts (8).


 Front nut: 45 ± 25 kgm


 Rear nut: 32.5 ± 12.5 kgm

★ Bend down cotter pins firmly.


**8. Tie rod**

Connect tie rod (7) and tighten nuts (6).


 Front nut: 55 ± 25 kgm

 Rear nut: 14 ± 6 kgm


★ Bend down cotter pins firmly.

**9. Hub assembly**

1) Press-fit outer race (26) and oil seal (27) to hub assembly (5).





- 2) Temporarily sling hub assembly. Using press-fitting tool ②, drive in bearing (28).

 Hub assembly: Grease (G2-LI)

- 3) Tighten nut (4) and measure torque using push-pull scale ③.


★ Rotating force: 10 ± 2 kg

★ Bend down cotter pin firmly.




10. Cover


Attach two gaskets and install cover (3).



11. Front wheel assembly

- 1) Temporarily sling wheel (2) using a nylon sling ① and loosely tighten wheel nuts.
- 2) Raise front wheels using the blade as a jack, remove the block, and lower body to the ground.
- 3) Tighten wheel nuts (1).


 Wheel nut: 50 ± 5 kgm

 Wheel nut: Anti-friction compound
(GL-M)



REMOVAL OF FRONT AXLE ASSEMBLY

GD705A-4




F23EC022-1

1. Front wheel assembly

- 1) Loosen wheel nut (1) a little.
- 2) Raise front wheels using scarifier or blade as jack. Support the lower part of frame center firmly with a block (Height: 700 mm).
- 3) Temporarily lift wheels (2) with a nylon sling, remove wheel nuts (1) and remove wheel assembly.



Front wheel assembly: Approx. 235 kg



P23EC190

2. Cover


Remove cover (3).

3. Hub shaft assembly

- 1) Remove nuts (4), (5).
- 2) Temporarily lift hub shaft assembly (6), pull out hub shaft assembly, lift it, then remove it.




Hub shaft assembly: Approx. 55 kg



F23EC023

4. Tie rod


Remove nut (7) and disconnect tie rod (8).



F23EC024

5. Leaning rod

Remove bolt (9), pull out pin (10) and disconnect leaning rod (11).




F23EC025


6. Shaft

Temporarily lift axle, remove nut (12) and shaft (13).

7. Axle assembly

Pull out shaft (13), lift axle assembly (14) and remove it.

 Axle assembly: Approx. 375 kg




F23EC026

8. King pin

Remove king pin (15).


- ★ Blind plug (16) can be removed together with king pin (15).



F23EC027

INSTALLATION OF FRONT AXLE ASSEMBLY



GD705A-4




F23EC028-1

1. King pin

Drive king pin (15) and drive plug (16).


-  Plug: Thread tightener (LT-2)
-  King pin and bushing: Grease (G2-LI)




F23EC027

2. Axle assembly

Lift axle assembly (14) and insert shaft (13).

-  Shaft and bushing: Grease (G2-LI)



F23EC026


3. Shaft

Tighten shaft (13) with nut (12).

- ★ Bend cotter pin securely.


4. Leaning rod

Align the connecting pin hole of leaning rod end (11) and the bracket, and insert connecting pin (10). Then install lock bolt (9).

 Bushing: Grease (G2-LI)

5. Tie-rod


Connect tie-rod (8) and tighten nut (7).

 Nut: 26.5 ± 4.5 kgm

★ Bend cotter pin securely.

6. Hub shaft assembly

1) Temporarily lift hub shaft assembly (6) and install it in housing.

 Hub shaft assembly: Grease (G2-LI)

2) Tighten nuts (4), (5).

3) Adjust rotating torque

- Fasten nut (5) so that it starts to rotate at 30 to 35 kg, as measured by a spring balancer hooked to the hub bolt. Turn the shaft at least 3 times left and right.

- Loosen nut (5) so that it can start to rotate at 2 to 5 kg. Do not fully loosen the nut.


- Tighten the lock washer and second nut (4) at 30 to 50 kgm so that the rotating force is 15 to 20 kgm.

- Measure the rotating force again after rotating hub shaft (6) 3 times and after the bearing roller fits well. Then bend the lock washer.

★ Adjust the preload after the bearing temperature becomes normal.

7. Cover

Fix O-ring on plate and install together with cover (3).


 O-ring: Grease (G2-LI)


8. Front axle assembly

1) Temporarily lift wheel (2) with a nylon sling and temporarily tighten wheel nut (1).


2) Raise front wheels with scarifier or blade, remove block and lower body to the ground.

3) Tighten wheel nuts (1).


 Wheel nut: 50 ± 5 kgm




F23EC025



F23EC024



F23EC023



P23EC190

REMOVAL OF STEERING PUMP ASSEMBLY



Lower the work equipment completely to the ground and stop the engine. Operate the control lever several times to release the remaining hydraulic oil pressure in the hydraulic piping. Then loosen the oil filler cap (1) slowly to release the remaining oil pressure in the hydraulic tank.

1. Remove drain plug (2) and drain oil from hydraulic tank.



Hydraulic tank: Approx. 70ℓ

2. Remove R.H. side cover.
3. Disconnect steering pump inlet tube (3) and steering pump outlet hose (4) from steering pump.
4. Remove steering pump assembly (5).

INSTALLATION OF STEERING PUMP ASSEMBLY


1. Fix O-ring and install steering pump assembly (5).
2. Connect steering pump outlet hose (4) to pump.
3. Fix O-ring and install steering pump inlet tube (3) to pump.
4. Install R.H. side cover.
5. Tighten drain plug and refill engine oil through oil filler to specified level.




Hydraulic oil: Approx. 27ℓ (GD705R-4)
Approx. 70ℓ (GD705A-4)

- ★ Run the engine to circulate the oil through the system. Then check the oil level again.


GD705R-4




GD705A-4



GD705R-4




GD705A-4



REMOVAL OF STEERING CYLINDER ASSEMBLY

GD705R-4

1. Remove lock plate and remove pin (1) at head side.
2. Disconnect hoses (2) and (3).
3. Remove lock plate and remove pin (4) at bottom side.
4. Remove steering cylinder assembly (5).



P23E04084

INSTALLATION OF STEERING CYLINDER ASSEMBLY


GD705R-4

1. Install steering cylinder assembly (5).
2. Install pin (4) at bottom side and secure it with lock plate.
3. Connect hoses (3) and (2).
 - ★ Install hoses, taking care to prevent twisting and interference.
4. Install pin (1) at head side and secure it with lock plate.

REMOVAL OF STEERING CYLINDER ASSEMBLY

GD705A-4

1. Remove nut (1) at head end and remove connecting pin (2).
2. Disconnect hoses (3), (4).
3. Remove lock plate and remove connecting pin (5) at bottom end.
4. Dismount steering cylinder assembly (6).




F23EC029

INSTALLATION OF STEERING CYLINDER ASSEMBLY

GD705A-4

1. Mount steering cylinder assembly (6).
2. Insert connecting pin (5) at bottom end and fix it with lock plate.
3. Connect hoses (3), (4).
 - ★ Install hose without twisting and interference.
4. Insert pin (2) at head side and fix it with nut (1).



P23EC192

STEERING SYSTEM


44 MAINTENANCE STANDARD



| | |
|-----------------------------|------|
| Steering pump | 44-2 |
| Steering cylinder | 44-5 |
| Front axle | 44-6 |

STEERING PUMP

GD705R-4 (LAL016)




F23B066A

Unit: mm

| No. | Check Item | Criteria | | Remedy | |
|-----|---|--------------------|------------------|------------------|------------------|
| | | Standard clearance | Tolerance | | |
| 1 | Side clearance between gear case and side plate | 0.05 – 0.1 | 0.15 | | |
| 2 | Clearance between bearing I.D. and gear shaft | 0.06 – 0.119 | 0.20 | | |
| 3 | Case installed tightening torque | 6.6 ± 0.6 kgm | | | |
| 4 | LAL016 (EO10-CD 50 ± 5°C 175 kg/cm ²) | Standard value | | Repair limit | |
| | | Pump speed (rpm) | Delivery (ℓ/min) | Pump speed (rpm) | Delivery (ℓ/min) |
| | | 3500 | 53.0 | 3500 | 48.0 |

GD705A-4 (SAR032)




F23E095A

Unit: mm

| No. | Check Item | Criteria | | | | Remedy |
|-----|--|--------------------|-------------------|------------------|-------------------|--------|
| | | Standard clearance | | Clearance limit | | |
| 1 | Side clearance between gear case and side plate | 0.10 – 0.15 | | 0.19 | | |
| 2 | Clearance between bearing I.D. and gear shaft diameter | 0.06 – 0.166 | | 0.20 | | |
| 3 | SAR032 EO10-CD 50°C 175 kg/cm ² | Standard value | | Repair limit | | |
| | | Pump speed (rpm) | Delivery (ℓ/min.) | Pump speed (rpm) | Delivery (ℓ/min.) | |
| | | 3000 | 72 | 3000 | 67 | |

STEERING CYLINDER

GD705R-4




F23E04038

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-----|---|---------------------------------------|------------------|------------------|--------------------|--------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| | Shaft | | Hole | | | | |
| 1 | Clearance between piston rod and bushing | 35 | -0.080 -0.142 | +0.132 +0.006 | 0.086 – 0.274 | 0.6 | Replace |
| 2 | Clearance between piston rod end and support shaft | 35 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | 1 | |
| 3 | Clearance between cylinder bottom end bushing and support | 35 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | 1 | |
| 4 | Piston nut tightening torque | 25 ± 2.5 kgm (Width across flats: 36) | | | | | |
| 5 | Cylinder head tightening torque | 45 ± 4.5 kgm | | | | | |

GD705A-4






234F119-6A

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-------|--|---------------|------------------|------------------|--------------------|--------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between piston rod and bushing | 35 | -0.030 -0.142 | +0.132 +0.006 | 0.036 – 0.274 | 0.6 | Replace bushing |
| 2 | Clearance between piston rod support shaft and bushing | 50 | -0.050 -0.075 | +0.041 +0.025 | 0.075 – 0.116 | 0.6 | |
| 3 | Clearance between cylinder bottom yoke and bushing | 30 | +0.009 -0.004 | 0 -0.010 | -0.019 – 0.004 | 0.6 | |
| 4 | Piston nut tightening torque | 42 ± 4.2 kgm | | | | | |
| 5 | Cylinder head tightening torque | 40 ± 4 kgm | | | | | |

FRONT AXLE

GD705R-4




F23E04040

Unit: mm

| No. | Check item | Criteria | | | | Remedy | |
|-------|--|----------------------------------|------------------|------------------|--------------------|--------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between knuckle bracket lower shaft and bushing | 40 | -0.025 -0.064 | +0.161 +0.118 | 0.143 – 0.225 | 0.5 | Replace bushing |
| 2 | Clearance between collar (joint arm) and bushing (leaning rod) | 40 | -0.025 -0.064 | +0.161 +0.118 | 0.143 – 0.225 | 0.5 | |
| 3 | Clearance between leaning rod and collar (joint arm) | 30 | +0.013 -0.008 | +0.033 0 | 0.013 – 0.041 | 0.1 | |
| 4 | Hub bearing pre-load | Starting torque: 1.34 – 2.01 kgm | | | | Adjust | |
| 5 | Wheel nut tightening torque | 50 ± 5 kgm | | | | | |
| 6 | Front axle-to-bracket installed nut tightening torque | 60 ± 40 kgm | | | | | |
| 7 | Knuckle arm stopper nut tightening torque | 55 ± 25 kgm | | | | | |
| 8 | Tie rod joint nut tightening torque | 12.5 ± 7.5 kgm | | | | | |
| 9 | Leaning cylinder installed pin top nut tightening torque | 32.5 ± 12.5 kgm | | | | | |
| 10 | Leaning rod installed pin top nut tightening torque | 45 ± 25 kgm | | | | | |

GD705A-4




F23E096

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-------|---|---------------------------------|------------------|--------------------|--------------------|-----------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between leaning pin and leaning rod bushing | 50 | -0.025 -0.064 | +0.025 +0 | 0.025 – 0.089 | 1.0 | Replace bushing |
| 2 | Clearance between center pin and bushing | 60 | -0.085 -0.110 | -0.025 -0.050 | 0.035 – 0.085 | 1.0 | |
| 3 | Clearance between king pin and bushing | 50 | -0.025 -0.050 | +0.025 +0 | 0.025 – 0.075 | 0.4 | |
| 4 | Axial clearance between knucle and bracket (king pin) | Standard clearance | | Interference limit | | 1.0 | Replace |
| | | 0.143 – 0.331 | | | | | |
| 5 | Clearance between axle end pin and bushing | 45 | -0.085 -0.064 | -0.025 +0 | 0.025 – 0.089 | 0.4 | Replace bushing |
| 6 | Tie rod joint nut tightening torque | 22 – 31 kgm | | | | Adjusting | |
| 7 | Preload of hub bearing | Starting torque: 2.5 – 3.35 kgm | | | | | |
| 8 | Hub nut tightening torque | 50 ± 5 kgm | | | | | |

BRAKE SYSTEM





51 STRUCTURE AND FUNCTION




| | |
|---------------------------------|-------|
| Brake piping diagram | 51- 2 |
| Brake piping | 51- 3 |
| Hydromaster | 51- 4 |
| Wheel brake | 51- 6 |
| Brake air piping | 51- 8 |
| Disk brake | 51-10 |
| Brake valve | 51-14 |
| Relay valve | 51-18 |
| Air governor | 51-20 |
| Check valve | 51-22 |
| Air reservoir | 51-23 |
| Safety valve | 51-23 |
| Pressure switch | 51-24 |
| Automatic drain valve | 51-26 |
| Air driver | 51-28 |
| Air compressor | 51-30 |
| Parking brake | 51-31 |
| Parking brake control | 51-32 |

BRAKE PIPING DIAGRAM

GD705R-4

-  Vacuum piping
-  Hydraulic booster piping
-  Depressed part hydraulic piping
-  Air piping




41F017A



Since there is a hydromaster (vacuum booster device) installed in this braking system, it increases braking efficiency and lessens brake pedal depression force and greatly reduces operator fatigue.

If the hydromaster happens to be failed, it acts as an ordinary hydraulic brake due to an intricate mechanism.

BRAKE PIPING



- 1. Master cylinder
- 2. Air cleaner
- 3. Hydromaster
- 4. Vacuum tank
- 5. Wheel Brake



F23E04041

HYDROMASTER

GD705R-4


OPERATION OF WHEEL BRAKE

1. When not being operated

(when not depressing brake pedal)

When both power piston chambers **A** and **B** are vacuum, and the power piston is pushed to the left side by the return spring, the power cylinder is balanced.

At this time the hydraulic piston hits against the piston stopper washer and pushes the yoke to the right and since the ball check valve is open, brake oil from the master cylinder passes through the hole in the middle of the hydraulic piston to the wheel cylinder. Accordingly, **even though the hydromaster is not operating**, it operates as an ordinary oil brake.




41F018

2. When being operated (when depressing brake pedal)

When the brake pedal is depressed, hydraulic pressure is transmitted from the master cylinder to the hydraulic cylinder and the relay valve. Hydraulic pressure acting on the relief valve operates the relief valve piston on the right side and at the same time the diaphragm is pushed to adhere tightly to the vacuum valve. As hydraulic pressure from the master cylinder further increases, the air valve separates from its seat surface and air from the air cleaner flows into the **A** chamber on the power cylinder braking side. (At this time **B** chamber is a vacuum.) This results in a pressure difference between the two sides of the power pistons and it is pushed to the right. This is transmitted directly to the hydraulic piston by the push rod, and the hydraulic piston also operates. When the piston begins to move, the yoke that was in contact with the washer at the top of the piston, separates, and shuts the ball check valve and shuts off brake oil on the master cylinder side and wheel cylinder side, and prevents a back flow of high pressure oil that has arisen on the wheel cylinder side.

This high pressure oil passes through the safety cylinder and acts on the wheel brake cylinder and barks the machine. Also, because engine rpm are not steady, there are variations in the suction of the vacuum pump, so a vacuum tank has been installed between the hydromaster and the vacuum pump to prevent vacuum pressure from falling.

Even if vacuum pressure falls, it is arranged that a warning buzzer from the vacuum pump sounds in the operator's compartment to warn the operator.




41F019

3. When brake is released.

(When foot is removed from brake pedal and braking stops.)

When the brake pedal is released, hydraulic pressure in the relay piston section drops. Then the air valve adheres tightly to its seat and cuts off air flow from outside. Next, the diaphragm separates from the vacuum chamber and opens the passage of both chambers **A** and **B** in the power cylinder, and air from **A** chamber flows into **B** chamber. Furthermore, because of the suction of the engine vacuum pump inside the hydromaster once again becomes vacuum. The power piston returns, being pushed to the left by a return spring, and at the same time the hydraulic piston also returns to its original position before operation.


Also, atmospheric pressure, applying on the relay valve (vacuum valve, air valve) and the diaphragm during operation, can be felt normally through the brake pedal as a direct hydraulic pressure reaction. Therefore, the operator, being aware of the degree of brake engagement, can brake freely.




41F020

WHEEL BRAKE



GD705R-4




Section A—A



Section B—B




Section C—C



Section D—D


F23B060



- 1. Return spring
- 2. Anchor pin
- 3. Wheel cylinder
- 4. Shoe
- 5. Lining
- 6. Adjuster
- 7. Brake drum



BRAKE AIR PIPING

GD705A-4




F23E035

- 1. Disk brake housing
- 2. Brake valve
- 3. Stop lamp switch



View Z




- 4. Air governor
- 5. Safety valve
- 6. Relay valve
- 7. Air compressor
- 8. Automatic drain valve (If equipped)
- 9. Air reservoir
- 10. Check valve
- 11. Low pressure switch
- 12. Air drier (If equipped)
- 13. Purge tank

F23E036

DISC BRAKE SYSTEM


GD705A-4

DISC BRAKE PIPING



F23B084


DISC BRAKE PIPING CIRCUIT DIAGRAM



238F046A

- | | |
|----------------------------|-----------------------------------|
| 1. Air compressor | 8. Low pressure switch |
| 2. Air drier (If equipped) | 9. Pressure gauge |
| 3. Air governor | 10. Brake valve |
| 4. Air reservoir | 11. Stop lamp switch |
| 5. Safety valve | 12. Automatic drain (If equipped) |
| 6. Relay valve | 13. Disc brake |
| 7. Check valve | 14. Purge tank |

STRUCTURE OF DISC BRAKE



F23E037

Disc brakes are fitted on the four rear wheels and are actuated by air pressure.

The motive force from the final drive rotates hub shaft (1), gear (2) and disc (4) inside cage (7). This rotation is transmitted to the tires which are fixed to the hub.


Each brake consists of disc (4) which is meshed with plate (5) and gear (2) which are meshed with cage (7). The discs are cooled by the oil inside the tandem case.

- 1. Hub shaft
- 2. Gear
- 3. Support
- 4. Disc
- 5. Plate
- 6. Spring
- 7. Cage
- 8. Piston
- 9. Nut
- 10. Bolt

OPERATION

1. Brake applied


When the brake pedal is depressed, the air circuit is connected to chamber **A** of the disc brake. When the air pressure is greater than the pushing force of spring (6), piston (8) moves to the left, and pushes disc (4) and plate (5). Friction is generated between the disc (meshed with gear (2)) and the plate (meshed with cage (7)). This shows down the rotation of the disc and finally stops it. In other words, the brake is applied.



F23E038

2. Brake released



When the brake pedal is released, the air in chamber **A** is released. Spring (6) moves piston (8) back to the right, so the pushing force is reduced. This removes the friction between disc (4) and plate (5), and allows them to rotate freely. In other words, the brake is released.



F23E039

BRAKE VALVE

GD705A-4





238F051

- 1. Brake pedal
- 2. Plunger
- 3. Piston
- 4. Inlet valve
- 5. Piston
- 6. Inlet valve
- 7. Rubber spring

- A. From air reservoir
- B. From air reservoir
- C. To R.H. relay valve
- D. To L.H. relay valve

Operating capacity curve



238F131

OPERATION


1. Brake operating

Upper part

- When brake pedal (1) is depressed, the operating force pushes plunger (2) and rubber spring (7), and these transmit the operating force to piston (3).
- When piston (3) moves down, it closes exhaust outlet (9). At the same time, it pushes down inlet valve (4) and air flows from air reservoir A to right relay valve C.

Lower part


- When inlet valve (4) opens, air flows to chamber 'a' of piston (5).
- The air pressure pushes piston (5) down and this closes exhaust outlet (10). At the same time, it pushes down inlet valve (6) and air flows from air reservoir B to left relay valve D to actuate the brake.
- Only a small amount of air pressure is needed to move piston (5), so the movement of the lower valve occurs at almost the same time as the movement of the upper valve.



238F052

2. Brake operation when lower side breaks down


If there is any leakage of air at the lower side, the upper side operates normally but the lower side does not actuate the brake.



238F053

3. Brake operation when upper side breaks down

- If there is any leakage of air at the upper side, piston (5) is pushed down mechanically when the brake pedal is depressed. Because of this, the lower side operates normally but the upper side does not actuate the brake.



238F054


4. Balancing operation

Upper part

- If the air pressure in relay valve C and the space below piston (3) becomes high, piston (3) will push rubber spring (7) and move up to close inlet valve (4).
- When this happens, exhaust outlet (9) remains closed, so the air pressure in the relay valve is maintained. As a result, the brake remains applied.

Lower part

- When the air pressure at the top and bottom of piston (5) becomes the same, the piston moves down slightly under the force of the spring at the top of the piston and closes inlet valve (6). The exhaust valve is closed so the air pressure is maintained. As a result, the brake remains applied.
- The pressure in the space in the upper part balances with the operating force of the pedal, and the pressure in the space in the lower part balances with the air pressure in the space in the upper part.



238F055

- When piston (3) and (5) move their whole stroke inlet valves (4) and (6) are completely opened. As a result, the air pressure in the spaces in the upper part and lower part, and in the right and left relay valves is the same as the air pressure in the air reservoir.
- Therefore, until the piston moves its full stroke down, the braking effect is controlled by the amount the brake pedal is depressed.


5. Pedal released

Upper part

- If the pressure on the pedal is reduced, and the operating pressure is removed from the top of the piston, the piston moves up because of the air pressure at the bottom of the piston and the force of the piston return spring. As a result, the passage to exhaust port (9) is opened and the compressed air in the relay valve is released to the atmosphere.

Lower part


- If the pressure on the pedal is reduced, and the compressed air at the top of piston (5) is released, the air pressure at the bottom of piston (5) pushes piston (5) up. Exhaust port (10) is opened and the compressed air in the relay valve is released to the atmosphere.



238F056

RELAY VALVE

GD705A-4



238F057


- 1. Exhaust valve seat
- 2. Spring
- 3. Cover
- 4. Relay piston
- 5. O-ring
- 6. O-ring
- 7. Valve guide
- 8. Exhaust check
- 9. Exhaust cover
- 10. Inlet exhaust valve
- 11. Spring
- 12. Body

OPERATION

1. When brake pedal is depressed

Compressed air enters chamber **A** at the top of relay piston (4) and pushes the relay piston down. Because of this, exhaust valve seat (1) closes exhaust port **C** and pushes open valve (10).


When the valve opens, compressed air from the air reservoir passes through the valve and is supplied to the brake chamber.



238F058

2. When brake pedal is held in place


The air pressure in chamber **A** at the top of the piston becomes equal to the air pressure in chamber **B** at the bottom of the piston. Spring (2) operates to push up relay piston (4), and spring (11) closes valve (10). In addition, exhaust port **C** stays closed at this position, so the pressure in lower chamber **B** is kept the same. If the pedal is depressed further and the pressure is increased, compressed air will be supplied to the disc brake until the pressure become equal again.



238F059

3. When brake pedal is released


The compressed air in chamber **A** at the top of relay piston (4) is released through the brake valve. When the pressure in chamber **A** drops, relay piston (4) is pushed up by the air pressure in chamber **B**. Exhaust port **C** opens, so the air in chamber **B** is released.



238F060

AIR GOVERNOR

GD705A-4



1. Cover
2. Lock nut
3. Spring upper seat
4. Spring
5. Body
6. Spring guide
7. Spring lower seat
8. Spring lower seat
9. O-ring
10. Spring
11. Washer
12. Spring
13. Pressure regulator valve
14. Exhaust stem
15. Piston
16. Adjust screw
17. Snap ring

238F061


The air governor is installed to prevent the pressure from rising too high. The reservoir port is connected to the air reservoir; the unloader port is connected to the unloader valve of the air compressor. The governor maintains the pressure inside the air reservoir within the specified range. If the pressure exceeds the specified limit, it stops the air compressor working.

Specified pressure range: 6.9 – 8.8 kg/cm²

OPERATION


1. When pressure inside air reservoir is too low

- The pressure at reservoir port **A** is too low, so piston (15) is pushed down by spring (4), and unloader port **B** is connected to the exhaust port. There is pressure on the unloader valve, so the compressor is working.




2. When pressure inside air reservoir is too high

- If the pressure at reservoir port **A** is too low, piston (15) is pushed up.
- When the piston is pushed up, the exhaust port closes and valve (13) opens. Compressed air from reservoir port **A** flows to unloader port **B**. This actuates the unloader valve and makes the compressor run at idling.
- When the pressure inside the air reservoir drops, the piston is pushed down by spring (4).
- When the pressure drops below the lower limit, valve (13) closes and exhaust stem (14) opens. Air pressure at the unloader port passes through the exhaust stem and is released to the atmosphere. As a result, the compressor starts working again.



CHECK VALVE

GD705A-4



1. Body
2. Disc valve
3. Spring
4. Screw cap


238F064

The check valve acts to prevent air in the air reservoir from flowing back to the air compressor when the air compressor is stopped.

OPERATION

When air flows into the check valve from the left, valve (2) leaks its seat and the air flows freely to the various ports.


When air flows into the check valve from the right, valve (2) is pushed back into its seat by spring (3) and the air pressure. This shuts off the air flow.



238F065

AIR RESERVOIR

GD705A-4




The air reservoir acts to store the compressed air produced by the air compressor.

Maximum pressure: 9.5 kg/cm² (Capacity 19ℓ x 2)

SAFETY VALVE

GD705A-4



The safety valve is installed in the air reservoir and acts to maintain safety in the air circuit. When the pressure inside the air reservoir exceeds 9.5 ± 0.3 kg/cm², the safety valve releases compressed air to the atmosphere.

PRESSURE SWITCH


GD705A-4

The pressure switch detects any change in the air pressure. In accordance with these changes, it switches the electric circuit on or off.

PRESSURE SWITCH FOR AIR PRESSURE WARNING (LOW PRESSURE SWITCH)

The contacts of this switch close when the air pressure inside the main tank drops below 4.2 kg/cm^2 . A warning buzzer then sounds to warn the operator of loss of braking power.

If the warning buzzer sounds, the operator must stop the machine and wait until the air pressure rises again.




238F068

- | | |
|------------------|------------------|
| 1. Cover | 5. Gasket |
| 2. Contact plate | 6. Body |
| 3. Spring | 7. Piston cup |
| 4. Contact disc | 8. Contact plate |

OPERATION


Contacts in OFF position



238F069

1. When pressure in air circuit is above 4.2 kg/cm^2
The air pressure acting on piston (2) is higher than the force of the spring, so piston (2) is pushed up. The electrical contacts are open, so no electric current flows in warning buzzer circuit and the buzzer does not sound.

Contacts in ON position



238F070

2. When pressure in air circuit is below 4.2 kg/cm^2
The air pressure acting on piston (2) is lower than the force of the spring, so piston (2) is pushed down. The electrical contacts are closed, so electric current flows in warning buzzer circuit and the buzzer sounds.


PRESSURE SWITCH FOR STOP LAMP

This switch acts to light up the stop lamp when the brake pedal is depressed. When the air pressure rises above 0.5 kg/cm^2 , the contacts close and the stop lamp lights up.

This switch is at the outlet port of the brake valve. One switch each is installed in both the right and left brake circuits.

OPERATION

When the brake pedal is depressed, air pressure is connected to the lower side of diaphragm (4). When the air pressure rises above 0.5 kg/cm^2 , the diaphragm compresses spring (2) and pushes up plunger (3). This brings the points of the plunger and terminal into contact, and the stop lamp lights up.




238F07 I

1. Terminal
2. Spring
3. Plunger
4. Diaphragm
5. Body

AUTOMATIC DRAIN VALVE

GD705A-4 (If equipped)




- 1. Retainer
- 2. Filter
- 3. Body
- 4. Plug
- 5. Valve guide
- 6. Inlet-Exhaust valve
- 7. Cover

238F072

The automatic drain valve is installed at the bottom of the air reservoir. It acts to automatically drain any water which forms when the compressed air is cooled.


OPERATION

1. When there is no air pressure inside the air reservoir, inlet-exhaust valve (6) is closed.




238F073

- When air pressure enters the air reservoir, inlet-exhaust valve (6) opens even when the pressure is low. Air and water then enter chamber **A**. The inlet-exhaust valve stops open until the pressure inside the air reservoir reaches the maximum pressure (until the governor is cut off).




238F074

- When the pressure in the air reservoir and the pressure in chamber **A** are equal, the spring action of valve guide (5) closes inlet-exhaust valve (6).



238F075


- When the pressure in the air reservoir drops, and the pressure in chamber **A** is about 0.3 kg/cm^2 , inlet-exhaust valve (6) exhausts the air and water.



238F076

AIR DRIER

GD705A-4 (If equipped)



Section A-A

238F077


The function of the air drier is to remove the water vapor from the compressed air in the circuit. In this way it protects the components of the equipment and prevents problems with operation in cold areas.

1. Body
2. Spring
3. Check valve
4. Drier cylinder
5. Drying agent
6. Valve
7. Piston
8. Valve body
9. Valve cap
10. Oil filter
11. Purge tank

OPERATION

1. Dehumidifying

When the compressor is working, air from the compressor enters port **A** of the air drier. It is then cooled by the outside of drier cylinder (4), and water and oil collect in the bottom of body (1). The air then passes through oil filter (10) which is fitted with an oil mist separator. Here the fine drops of oil and particles of dust are removed before the air enters the drier cylinder. Any water still included in the air is removed by drying agent (5). When the air reaches the top of the drier cylinder, it is completely dry. This dry air then passes through check valve (3) and the purge tank and is sent to the main tank.




238F078

2. Restoring drying agent

When the air pressure inside the circuit reaches the set pressure, the command from the governor switches the compressor to unloading. The same command is also received by the control ports of the air drier. Valve (6) opens and the air inside drier cylinder (4) is released to the atmosphere. Following this sudden drop in pressure, the dried air in the purge tank passes through orifice 'a'. Because of the drop in pressure, the dry air expands and becomes super-dry air. As it flows back through the drier cylinder, it picks up water from drying agent (5) and carries it out to the atmosphere. This completely dries out the drying agent and prepares it for further use.


When the loading cycle starts again, the valve closes, and the cylinder returns to dehumidifying action.



238F079

AIR COMPRESSOR

GD705A-4




234F1112

Bore x Stroke: 85 x 59.9 mm

Piston displacement: 340 cc

- | | | |
|------------------|-------------------|--------------------|
| 1. Crankcase | 8. Piston | 15. Unloader valve |
| 2. O-ring | 9. Piston pin | 16. Shim |
| 3. Bearing cover | 10. Snap ring | 17. Gasket |
| 4. Oil seal | 11. Oil ring | 18. Connecting rod |
| 5. Crankshaft | 12. Second ring | 19. O-ring |
| 6. Bearing | 13. Top ring | 20. Bushing |
| 7. Cylinder | 14. Cylinder head | 21. Drive gear |

PARKING BRAKE




4 | F022

- 1. Arm
- 2. Support plate
- 3. Drum
- 4. Return spring
- 5. Adjuster

PARKING BRAKE CONTROL

GD705R-4




41F023

The parking brake is a mechanical type duo-servo built in expansion type that brakes the transmission output shaft.

When the parking brake lever (1) is pulled, a cam lever (3) is moved by a wire (2) and expands the brake shoe (4) which brakes the output shaft.

- 1. Parking brake lever
- 2. Parking brake control wire
- 3. Lever
- 4. Brake shoe

GD705A-4




F23E040

- 1. Parking brake lever
- 2. Parking brake control wire
- 3. Lever

BRAKE SYSTEM

52 TESTING AND ADJUSTING



| | |
|--|------|
| Checking brake pedal height | 52-2 |
| Checking brake pedal play | 52-2 |
| Checking brake pedal operating force | 52-2 |
| Checking brake pedal depression height | 52-3 |
| Checking parking brake lever stroke and operating force | 52-4 |
| Bleeding air inside brake piping | 52-5 |
| Checking wear of brake disc | 52-6 |

CHECKING BRAKE PEDAL HEIGHT


GD705R-4

Use a convex rule to measure the height from the floor to the center of the mounting bolt of the foot rest of the pedal (1).

BRAKE PEDAL HEIGHT ADJUSTMENT

Adjust pedal stopper bolt (2) to fix pedal height.

- ★ Standard value: 190 ± 5 mm



233F243

CHECKING BRAKE PEDAL PLAY

GD705R-4

Use a convex rule and measure in the direction of pedal operation.

- ★ Measure with engine stopped.

BRAKE PEDAL PLAY ADJUSTMENT

Adjust the yoke (4) of rod (3) until it is at standard value (10 ± 5 mm).


- ★ Bend the cotter pin securely.

CHECKING BRAKE PEDAL OPERATING FORCE

GD705R-4

Using push-pull scale ①, measure maximum value in the stroke to just before the stroke end of the brake pedal.

- ★ Measure with engine idling.



CHECKING BRAKE PEDAL DEPRESSION HEIGHT

GD705R-4

BRAKE PEDAL DEPRESSION HEIGHT CHECK

- ⚠ Confirm that gear lever is in neutral and that parking brake lever is pulled on.



Start the engine, depress the pedal (1) and use convex rule (1) to measure the stroke from the center of the mounting bolt of the foot rest to floor level.

- ★ Measure with engine idling.
- ★ If the stroke is outside standard value when the brake pedal is depressed, or if brake efficiency is low, see section, "WHEEL BRAKE ADJUSTMENT".


WHEEL BRAKE ADJUSTMENT

- ⚠ Adjust with engine stopped.

1. Insert driver through the adjusting hole in the underside of the back plate and turn adjusting gear until lining and drum contact tightly.
2. Next, return the adjusting gear 4 to 5 ratchets.
3. Remove the rubber blind cap and confirm that clearance is less than 0.4 mm on one side when a 0.6 mm feeler gauge (2) is inserted on the other side of the underside inspection opening.
4. After adjusting, depress brake pedal and confirm that pedal depression height is within standard value (96 ± 20 mm).
5. After adjusting, travel for about 500 m, check the temperature of the four brake drums, and confirm there is no dragging.
6. After adjusting, confirm that braking distance at speed of 35 km/h is within the standard value for stopping distance.




234F040



CHECKING PARKING BRAKE LEVER STROKE AND OPERATING FORCE

STROKE CHECK

Use convex rule ① to measure the travel of parking brake lever (1) tip from bottom to top.



P23EC230


GD705A-4 Serial No. 31001 and up

STROKE ADJUSTMENT



Adjust with engine stopped.


1. Insert driver through adjusting hole of parking brake drum, rotate adjusting gear in the direction of the arrow until lining and drum contact tightly, then return 8 ratchets.
2. After adjusting the lining and drum clearance, pull the parking brake lever and adjust the cable so that the notched section is in the 2 to 3 ratchet range.
3. After adjustment, it is possible to keep the machine stopped on a 1/5 paved gradient by pulling the parking lever.



P23404017


OPERATING FORCE CHECK

Use push pull scale ② to check the operating force by hanging it on the front end of the parking brake lever and lifting it up.



P23EC231

GD705A-4 Serial No. 31001 and up



P23404018

BLEEDING AIR INSIDE BRAKE PIPING



GD705R-4

- ★ Carry out air bleeding in pairs. One worker adds brake fluid to the brake tank by repeatedly depressing the brake pedal. The other bleeds air from the various parts of the brake.
- ★ Prepare extra brake fluid so that it will not run out during the work.




Bleed air with engine stopped.

1. Install vinyl tube to breather (7) and put the other end in a container half filled with brake fluid.
 2. Depress the brake pedal a number of times, and loosen the breather plug with the pedal depressed. Tighten it before hydraulic pressure in the cylinder gives out. Repeat this process until air bubbles disappear from the brake fluid.
- ★ Operate the brake pedal about 3 seconds per operation.




3. Bleed air from hydromaster plugs (8), (9) in that order according to the procedure in item 1 and 2.




CHECKING WEAR OF BRAKE DISC

GD705A-4

1. Remove plug (1) of checking hole and peep through from directing above the checking hole.




2. Depress brake pedal to push piston (2) against plate (3) and to compress disc (4).
3. Confirm that length **A** in the diagram at right is not **O**. In other words, confirm that a portion of the disc can be seen through the checking hole.



F23EC030

BRAKE SYSTEM


53 DISASSEMBLY AND ASSEMBLY




| | |
|--------------------------------|-------|
| HYDROMASTER | |
| Disassembly | 53- 2 |
| Assembly | 53- 4 |
| WHEEL BRAKE ASSEMBLY | |
| Disassembly | 53- 6 |
| Assembly | 53- 8 |
| BRAKE MASTER CYLINDER ASSEMBLY | |
| Removal | 53-10 |
| Installation | 53-10 |

DISASSEMBLY OF HYDROMASTER**GD705R-4**


1. Disconnect tube (1) and valve body (2).
 - i) Remove spring (3), gasket (4) and diaphragm (5).
 - ii) Remove snap ring (6), pipe (7), spring (8) and O-ring (9).
2. Tighten nut (10) and remove cylinder (11).



43P047




43P048



43P049


3. Remove fitting (12), snap ring (13), spacer (14) and piston (15).



43P050


43P051

- Loosen nut (16) and pull out end plate assembly (18) from cylinder (17).




43P052

- Push in end plate assembly (18), remove pin to remove piston assembly (19), and remove end plate assembly.




43P053

- Remove ring (20), washer (21), retainer (22), packing (23), washer (24), oil seal (25) and gasket (26).



232F257

- Remove plate (27), packing (28) and plate (29).





F23E04042

ASSEMBLY OF HYDROMASTER

GD705R-4


1. Install plate (29), packing (28) and plate (27).

 Sliding portion of packing: Airmaster paste




F23E04042

2. Install gasket (26), oil seal (25), washer (24), packing (23), retainer (22) and washer (21), and secure them with ring (20).



232F257


3. Push in end plate assembly (18) and install piston assembly (19) with pin.



43P053


4. Install end plate assembly on cylinder (17) and secure it with nut (16).

 Inside face of cylinder: Airmaster paste





43P052


5. Secure piston (15) and spacer (14) with snap ring (13) and install fitting (12).



6. Install cylinder (11) and secure it with nut (10).
★ Install cylinder with air bleeder plug up.
7. Install O-ring (9), spring (8) and pipe (7) and secure them with snap ring (6).
8. Install diaphragm (5), gasket (4) and spring (3).



9. Install valve body (2) and tube (1) and fasten them with hose clamp.




DISASSEMBLY OF WHEEL BRAKE ASSEMBLY

GD705A-4

1. Sprocket

- 1) Remove bearing nut (1) and remove collar ①.
- 2) Remove spacer (2) and remove sprocket (3).




2. Support

- 1) Remove four connection bolts (6) between cage (4) and support (5) from behind.
- 2) Raise support (5) with crane and remove it.




Support: Approx. 39 kg



3. Gear


Remove gear (7).



4. Disc, plate

Remove plate (8) and disc (9) in order.

- ★ Plate: 6 pcs.
- Disc: 5 pcs.



5. Spacer


Remove spacer (10).

6. Cage assembly

Raise cage assembly (4) with a crane and remove it.




Cage assembly: Approx. 79 kg



P23BB149-1

7. Bolt, spring

Remove bolt (13) and spring (14).




P23BB150

8. Piston

Remove piston (15) from cage.

- ★ Blowing in air through the air charge port makes it easier to remove the piston.
- ★ Be careful not to damage piston sliding face and O-ring.




P23BB151

ASSEMBLY OF WHEEL BRAKE ASSEMBLY

GD705A-4

1. Bearing outer race

Press-fit bearing outer race (16) into cage.




2. Piston


- 1) Confirm that O-ring sliding faces of cage are not damaged.

 Sliding face: Grease (G2-L1)

- 2) Fix O-ring (2 pcs) and force piston (15) in cage.


★ Be careful not to damage sliding face and O-ring.


 O-ring groove part: Grease (G2-L1)




3. Bolt, Spring

Install bolt (13), spring (14).

 Mounting bolt: Thread tightener (LT-2)


 Mounting bolt: 7.5 ± 0.5 kgm

- ★ After tightening bolt, blow in air through the air charge port of the brake piping, and move the piston 2-3 cycles.




4. Shaft

- 1) Fix O-ring and install spacer (17).

 O-ring groove part: Grease (G2-L1)

- 2) Press-fit bearing (18).




5. Cage assembly

1) Raise cage assembly (4) and install shaft in cage.



Cage assembly: Approx. 79 kg



P23BB149-1

6. Spacer

Install spacer (10).

7. Gear

Install gear (7).

8. Disc, Plate

Install plate (8), disc (9) in order.

★ Plate: 6 pcs, Disc: 5 pcs.


9. Support

Fix O-ring (2 pcs) in support (5), install it in cage (4) and tighten with four bolts (6).


10. Sprocket

1) Install spacer (2) (above and below sprocket) and sprocket (3).


2) Insert collar ① (φ95 mm) and temporarily tighten bearing nut (1).




P23BB148



P23BB147



P23BB145




P23BB146-1

REMOVAL OF BRAKE MASTER CYLINDER ASSEMBLY


GD705R-4



1. Remove cover (1).
2. Disconnect hose (2).
3. Disconnect tube (3).
4. Disconnect rod (4).
5. Remove master cylinder assembly (5).



INSTALLATION OF BRAKE MASTER CYLINDER ASSEMBLY


GD705R-4

1. Install master cylinder assembly (5).
 Mounting bolt: 6.75 ± 0.75 kgm
2. Connect rod (4).
3. Fit gasket and connect tube (3).
4. Connect hose (2) and fix it with a clamp.
5. Install cover (1).
6. Add brake fluid up to maximum level.
 ★ After adding brake fluid, bleed the air.
 Depress brake pedal several times to feed the brake fluid, and bleed air from the hydromaster.



BRAKE SYSTEM


54 MAINTENANCE STANDARD



| | |
|---------------------|------|
| Wheel brake | 54-2 |
| Disc brake | 54-3 |
| Parking brake | 54-4 |

WHEEL BRAKE

GD705R-4




F23B029

Unit: mm

| No. | Check Item | Criteria | | Remedy |
|-----|-------------------------------------|---|--------------|-----------------|
| | | Standard size | Repair limit | |
| 1 | Wear of lining | 12 | 6 | Replace drum |
| 2 | Wear of brake drum I.D. | 438.2 ^{+0.3} / ₀ | 442 | Replace drum |
| 3 | Drum I.D. | Clearance between rivet head and lining surface: max. 0.5 | | Replace lining |
| 4 | Out of roundness of brake drum I.D. | Repair limit: 0.2 | | Turn or replace |

DISC BRAKE

GD705A-4




F23E097

Unit: mm

| No. | Check Item | Criteria | | | | Remedy |
|-----|--|--------------------|------------------|----------------|--------------|----------------|
| | | Standard size | | Repair limit | | |
| 1 | Thickness of disc | Standard size | | Repair limit | | Replace |
| | | 3.8 ± 0.1 | | 3.3 ± 0.1 | | |
| 2 | Thickness of plate | 2.3 ± 0.1 | | | | |
| 3 | Total thickness between disc and plate | 32.8 ± 1.1 | | 30.3 ± 1.1 | | |
| 4 | Return spring | Standard size | | | Repair limit | |
| | | Free length x O.D. | Installed length | Installed load | Free length | Installed load |
| | | 71 x | 52 | 16.9 | | |

PARKING BRAKE

GD705R-4




44F003

Unit: mm

| No. | Check Item | Criteria | | | | | Remedy |
|-----|---|---|------------------|----------------|--------------|----------------|----------------|
| | | Standard size | | | Repair limit | | |
| 1 | Wear of brake drum I.D. | Standard size | | | Repair limit | | Replace drum |
| | | 254 | | | 257 | | |
| 2 | Wear of brake drum | | | | | | |
| 3 | Wear of lining | Clearance between rivet head and lining surface: Max. 0.5 | | | | | Replace lining |
| 4 | Brake shoe return spring | Standard size | | | Repair limit | | Replace spring |
| | | Free length x O.D. | Installed length | Installed load | Free length | Installed load | |
| | | 68 x | 75 | 18.5 kg | 87 | 41 kg | |
| 5 | Clearance between brake drum and lining | 0.23 | | | | | |
| 6 | Brake drum installed bolt tightening torque | 18 ± 2 kgm | | | | | |
| 7 | Arm installed nut tightening torque | 1.9 ± 0.4 kgm | | | | | |

GD705A-4



F23E098

Unit: mm

| No. | Check Item | Criteria | | Remedy |
|-----|-------------------------------|---|--------------|-----------------|
| | | Standard size | Repair limit | |
| 1 | Wear of brake drum I.D. | 304.8 $\begin{smallmatrix} +0.2 \\ 0 \end{smallmatrix}$ | 308 | Replace drum |
| 2 | Wear of lining | Clearance between lining face and rivet head face: Max. 0.5 | | Replace lining |
| 3 | Out of roundness of drum I.D. | Repair limit: 0.2 | | Turn or replace |

HYDRAULIC SYSTEM

61 STRUCTURE AND FUNCTION




| | |
|-------------------------------------|-------|
| Hydraulic control piping | 61- 2 |
| Hydraulic system diagram | 61-16 |
| Hydraulic circuit diagram | 61-18 |
| Hydraulic control valve | 61-28 |
| DDV (Dual Demand Valve) | 61-39 |
| Flow divider valve | 61-55 |
| Pilot check valve | 61-56 |
| Double relief valve | 61-61 |
| Hydraulic pump | 61-62 |
| Circle rotation motor | 61-71 |
| Hydraulic cylinder | 61-74 |

HYDRAULIC CONTROL PIPING

GD705R-4

HYDRAULIC TANK TO CONTROL VALVES




F23E04043

The hydraulic control, which operates the work equipment, consists of hydraulic tank (4), work equipment (3), and high pressure piping which is connected by piping from the control valve to each cylinder and motor.

1. L.H. hydraulic control valve (4-spool)
2. R.H. hydraulic control valve (3-spool)
3. Work equipment pump (LAR020 + 020)
4. Hydraulic tank

GD705R-4

BLADE LIFT AND LEANING




F23E04044

- 5. Pilot check valve (for drawbar shift)
- 6. Pilot check valve (for leaning)
- 7. Leaning cylinder
- 8. Pilot check valve (for blade lift L.H.)
- 9. Pilot check valve (for blade lift R.H.)
- 10. Blade lift cylinder
- 11. R.H hydraulic control valve (3-spool)
- 12. L.H. hydraulic control valve (4-spool)

GD705R-4


DRAWBAR SHIFT, CIRCLE REVERSE AND BLADE SIDE SHIFT



F23E04045

- 13. Circle rotation motor (orbit 2-125AD4-E)
- 14. Rotary joint
- 15. Blade side shift cylinder
- 16. Drawbar shift cylinder

SCARIFIER GD705R-4 (If equipped)




F23E04046

- 17. Scarifier cylinder
- 18. Pilot check valve (for scarifier)
- 19. 4-Spool control valve

HYDRAULIC CONTROL PIPING

GD705A-4

HYDRAULIC TANK TO CONTROL VALVES



F23404016


The hydraulic control operating the work equipment consists of the following components: hydraulic tank, gear pump, dual demand valve, flow divider valve and high-pressure piping connecting the hydraulic control valve to the cylinders and motors.

★ Use CLASS-CD SAE10W engine oil for all seasons.

1. Work equipment pump (SAR050)
2. Work equipment pump (SAR050 + SAR050)
3. Hydraulic oil tank
4. Hydraulic control valve (R.H.)
5. Hydraulic control valve (L.H.)
6. Circle control valve
7. Mode control valve
8. Flow divider valve
9. Dual demand valve

GD705A-4

BLADE LIFT AND LEANING




F23404017

- 10. Pilot check valve (for leaning)
- 11. Pilot check valve (for drawbar shift)
- 12. Leaning cylinder
- 13. Pilot check valve (for blade lift L.H.)
- 14. Pilot check valve (for blade lift R.H.)
- 15. Blade lift cylinder
- 16. Drawbar shift cylinder
- 17. Pilot check valve (for articulate)
- 18. Articulate cylinder

GD705A-4

BLADE SIDE SHIFT, CIRCLE ROTATION AND POWER TILT




F23404018

- 19. Circle rotation motor
- 20. Pilot check valve (for power tilt)
- 21. Rotary joint
- 22. Blade side shift cylinder
- 23. Power tilt cylinder

GD705A-4


RIPPER (If equipped)



F23404019A

- 24. Ripper control valve
- 25. Pilot check valve
- 26. Ripper cylinder

GD705A-4
SCARIFIER (If equipped)




F23404051





- 27. Scarifier cylinder
- 28. Pilot check valve (for scarifier)
- 29. 4-spool control valve

HYDRULIC CONTROL PIPING

GD705A-4 (Serial No. 31001 and up)
HYDRAULIC TANK TO CONTROL VALVES



View Z




Section A - A

F23404052

1. Work equipment pump (SAR050)
2. Work equipment pump (SAR050 + SAR050)
3. Hydraulic oil tank
4. Hydraulic control valve (R.H.)
5. Hydraulic control valve (L.H.)
6. Circle control valve
7. Mode control valve
8. Flow divider valve
9. Dual demand valve

GD705A-4 (Serial No. 31001 and up)
 BLADE LIFT AND LEANING




F23404053

- 10. Pilot check valve (for leaning)
- 11. Pilot check valve (for drawbar shift)
- 12. Leaning cylinder
- 13. Pilot check valve (for blade lift L.H.)
- 14. Pilot check valve (for blade lift R.H.)
- 15. Blade lift cylinder
- 16. Drawbar shift cylinder
- 17. Pilot check valve (for articulate)
- 18. Articulate cylinder

GD705A-4 (Serial No. 31001 and up)


BLADE SIDE SHIFT, CIRCLE ROTATION AND POWER TILT



F23404054

- 19. Circle rotation motor
- 20. Pilot check valve (for power tilt)
- 21. Rotary joint
- 22. Blade side shift cylinder
- 23. Power tilt cylinder

GD705A-4 (Serial No. 31001 and up)
RIPPER (If equipped)




F23404055

- 24. Ripper control valve
- 25. Pilot check valve
- 26. Ripper cylinder

GD705A-4 (Serial No. 31001 and up)

SCARIFIER (If equipped)





F23404056

- 27. Scarifier cylinder
- 28. Pilot check valve (for scarifier)
- 29. Hydraulic control valve (R.H.)
- 30. Hydraulic control valve (L.H.)

HYDRAULIC SYSTEM DIAGRAM

GD705R-4








F23E04047

HYDRAULIC CIRCUIT DIAGRAM

GD705R-4







F23E04048

HYDRAULIC SYSTEM DIAGRAM

GD705A-4 (Serial No. 21001 - 31000)








F23404059A

HYDRAULIC CIRCUIT DIAGRAM

GD705A-4 (Serial No. 21001 - 31000)







F23404058

HYDRAULIC SYSTEM DIAGRAM

GD705A-4 (Serial No. 31001 and up)







F23404057A

HYDRAULIC CIRCUIT DIAGRAM

GD705A-4 (Serial No. 31001 and up)







F23404060

HYDRAULIC CONTROL VALVE


GD705R-4

1. Left hand valve


Drawbar shift, Circle rotation, Scarifier (If equipped), and Blade lift (L.H.)



Section A - A



Section B - B




Section C - C

F23E04049

- 1. Spool
- 2. Main relief valve
- 3. Inlet section valve
- 4. Spool section valve

2. Right hand valve
Blade lift (R.H.) Leaning, and Blade side shift



F23E04050

- 1. Spool
- 2. Main relief valve
- 3. Inlet section valve
- 4. Spool section valve
- 5. Outlet section valve


HYDRAULIC CONTROL VALVE

GD705A-4

1. 3-SPOOL VALVE

Left hand valve

- Blade lift (L.H.), Drawbar shift and Articulate (Serial No. 21001 and up)
- Blade lift (L.H.), Blade side shift and Power tilt (Serial No. 31001 and up)



F23AB205

1. Check valve
2. Main relief valve
3. Spool
4. Body


2. 4-SPOOL VALVE

Right hand valve

- Blade lift (R.H.), Leaning, Power tilt and Blade side shift (Serial No. 21001 and up)
- Blade lift (R.H.), Leaning, Drawbar shift and Articulate (Serial No. 31001 and up)

Left hand valve (If equipped)

- Scarifier, Blade lift (L.H.), Drawbar shift and Articulate (Serial No. 21001 and up)





238F097-1

1. Check valve
2. Main relief valve
3. Spool
4. Body


3. 5-SPOOL VALVE

Right hand valve (If equipped)



- Blade lift (R.H.), Leaning, Drawbar shift, Articulate and Scarifier (Serial No. 31001 and up)






Section D - D



Section A - A



Section B - B






Section C - C



F23AB206

1. Check valve
2. Main relief valve
3. Spool
4. Body

4. CIRCLE ROTATION



Section A-A





Section B-B

4



F23E048

- 1. Spool
- 2. Body
- 3. Main relief valve
- 4. Check valve

5. MODE CONTROL



Section A-A




Section B-B

F23E049

- | | |
|---------------|-------------------|
| 1. Cover | 9. Detent ball |
| 2. Valve body | 10. Plug |
| 3. Spool | 11. Plug |
| 4. Spacer | 12. Detent ball |
| 5. Retainer | 13. Detent |
| 6. Spring | 14. Detent spring |
| 7. Plug | 15. Case |
| 8. Retainer | |

6. RIPPER (If equipped)



F23E050

- 1. Plug
- 2. Spool
- 3. Body
- 4. Check valve

GENERAL

The control valves control the hydraulic cylinders in the hydraulic equipment. In order to control the motion of the hydraulic cylinders, these control valves control the pressure, direction, and flow of the oil fed from the hydraulic pump.

For this purpose, the control valves consist of a main valve (direction changeover valve), a main relief valve, and a check valve, according to their functions.

Main valve (Direction changeover valve)

The main valve selects the oil circuit when a hydraulic cylinder is operated. It consists mainly of the valve body and spool. This valve selects the path of the oil flow by using the reciprocating motion of the spool in the valve body. It also controls the oil flow by gradually opening the spool.

Main relief valve (pressure regulating valve)

The main relief valve is mounted between the hydraulic pump and the main valve.

When the hydraulic pressure reaches a certain value, the relief valve automatically opens to limit the hydraulic pressure, so that the hydraulic pressure cannot rise further.

Check valve


The check valve is mounted at the inlet of the main valve. If the cylinder is lifted when the engine is stopped, or if the cylinder is loaded, this valve operates so that oil flows from the pump to the cylinder without allowing it to return from the cylinder to the pump or tank. In other words, oil flows in one direction only.

MAIN VALVE

OPERATION

1. When the spool is set to NEUTRAL

The oil from the pump flows into the operation valve from port P. Since ports A₁, A₂, A₃, A₄, B₁, B₂, B₃, and B₄ are connected to the actuator and are shut off by the spool, oil fed from port P returns to the hydraulic oil tank both from the R.H. valve and the carry-over port C, as well as from the L.H. valve and the tank port T via the confluent valve.





2. When the spool operates

The flow passage connected to the carry-over port C (or tank port) is shut off, while port A₁ and B₁ are open.

The hydraulic oil fed from port P opens check valve (4), and flows from port B₁ to the actuator.


The return oil from the actuator is fed into port A₁, and then it returns to the tank from port T.

In order to ensure fine controllability, ports A₁, P, and B₁ are designed to communicate with each other at the start of the spool stroke. If a high retention pressure acts on port A₁ or B₁, the oil at the port reverses and flows into the other port, so that the actuator functions normally only after moving slightly opposite to the intended direction. In order to prevent this phenomenon, a check valve (a) is mounted in each block.



PERFORMANCE

The performance of the operation lever is improved by cutting notches and grooves in the main valve spool.




230F152

Fine control

Minor changes in the oil flow rate can be achieved by altering the spool stroke opening surface area during main valve spool operations. This ability to effect minor changes in flow rate is called FINE CONTROL.

If a spool without appropriate notches is operated by fine control, a large quantity of oil will flow when the port is opened, resulting in sudden jerking movement when starting or stopping the work equipment. With proper notches in the spool, however, the flow rate can be controlled.




230F153

Flow force


When oil flows from the high pressure side to the low pressure side in the spool shown in the diagram at right, the gap between the valve body and the spool is restricted, resulting in increased flow at that section.

This increased oil flow rate results in a drop in pressure at that section, which means the pressure at AB is lower than at CD. This creates force F which acts in a direction to close the spool circuit.

This force is called the FLOW FORCE, and the action of this force effects the force required to operate the spool, making smooth operation more difficult, and even impeding automatic spool return after operation. To minimize the effects of this force, notches are formed as shown in the diagram at right, resulting in the oil flow passing out at a suitable angle.



230F154



230F155

Hydraulic lock


The main valve spool has a tendency to become stuck at higher hydraulic pressures, making it very difficult to operate the spool, or even making manual operation impossible. This is referred to as HYDRAULIC LOCK.

The following factor is considered to be the cause of hydraulic lock.

Although high pressure oil is cut off from other ports by contact between valve body and spool, oil is admitted through a very small gap between contact surfaces. Due to unevenness in the gap, or to the presence of grit, pressure differences are generated around the spool, resulting in the spool being pressed against the low pressure side (see diagram). The spool thus becomes stuck against the valve body.

To prevent hydraulic lock, grooves are cut around the outside of the spool, thereby enabling the oil in the gap between contact surfaces to flow around the spool through the grooves and thereby equalize the pressure on all sides and prevent the spool from sticking.

In addition to hydraulic lock, spool sticking can also be caused by grit biting into the spool (called dirt lock), or distortion in the valve body.




230F156

DDV (Dual Demand Valve)

GD705A-4

CIRCUIT DIAGRAM



1. Lever
2. Rod
3. Mode control valve


F23E052

The DDV (dual demand valve) consists of two demands valves.

The No. 1 demand valve, when in neutral, maintains the delivery from each pump at a constant level even if the engine speed is low. Because of this, even if the engine speed drops, the work equipment can be moved at the usual speed. For finishing operations, the selector valve can be set to the ON position to obtain a speed for the work equipment to match the machine speed.


The No. 2 demand valve sends a constant flow of oil to the circle control valve when the engine speed is midrange or above. Any unnecessary oil is unloaded. This prevents any increase in loss of power and in this way improves fuel consumption.

When starting in low temperatures, the selector valve can be set to the UNLOAD position. This improves the ease of starting by unloading the oil delivered by the pump without sending it through the work equipment valve.




F23E051A-1

MODE CONTROL VALVE



- 1. Lever
- 2. Rod
- 3. Mode control valve

F23E052



F23E102

This valve acts to switch the DDV to its various positions: NEUTRAL, ON, UNLOAD.


★ For details of the operation of the DDV (dual demand valve), see DDV (DUAL DEMAND VALVE).

- 1. Spool
- 2. Body
- 3. Screw
- 4. Cover

OPERATION


1. NEUTRAL

When the DDV lever is placed in the NEUTRAL position, the oil from DDV port Po enters chamber D, it then passes through chamber C and flows from chamber B to DDV port Pi.




2. ON

When the DDV lever is placed in the ON position, the oil from DDV port Pi enters chamber B. It then flows from chamber A through passage F to chamber E and is drained to the tank.




3. UNLOAD


When the DDV lever is placed in the UNLOAD position, the oil from DDV port Po enters chamber D, it then divides into two oil flows. One passes through chamber E, passage F, chamber A and chamber B and goes to DDV port Pi. The other is drained from chamber E to the tank.




DUAL DEMAND VALVE



- 1. Pipe
- 2. Cover
- 3. Spring
- 4. Spool
- 5. Body
- 6. Plug
- 7. Cover
- 8. Cover
- 9. Spring
- 10. Spool
- 11. Spring
- 12. Plug (Orifice 1)
- 13. Plug (Orifice 2)




Section A-A



Section B-B

F23E056




- 1. Pipe
- 2. Cover
- 3. Spring
- 4. Spool
- 5. Body
- 6. Plug
- 7. Cover
- 8. Cover
- 9. Spring
- 10. Spool
- 11. Spring

F23E057


OPERATION PRINCIPLES OF DDV26

The oil from the hydraulic tank is delivered to DDV26 from each pump (pumps 1, 2 and 3).

The DDV26 distributes the oil to the V₁ port (to L.H. and R.H. hydraulic control valve), V₂ port (to circle rotation control valve) and T port according to the engine speed.



F23E051A-1



F23E058A

PRECONDITIONS

The explanation given so far assumes the control flow rates of the first and second demand valves to be **QA** and **QB**, respectively. In actuality, however, speeds **N1** through **N6** vary because of the flow control limits (illustrated) of the first and second demand valves.

PRINCIPLE OF OPERATION WHEN USED WITH MODE SELECTOR VALVE

Position a

See explanation of DDV26 operation principle, items 1 through 10.


Position b

This position causes pump speed change in proportion to the engine speed.


Since the pump discharge varies in proportion to the travel speed as with the conventional grader, fine control at a low travel speed at the time of road surface finishing operation is possible. This position is advantageous in improving the finishing speed.

Position c

This position causes unloading of pump discharge **P1** through the mode selector valve. Since unloading of the oil from all pumps (**P1**, **P2** and **P3**) is carried out by bypassing operation valves, the load at the time of engine starting is small, resulting in improvement of startability.




F23E059




Distribution to each port is as follows:

1. When the engine speed is N_1 or below: (Fig. 1)
The total volume of the oil from pumps 1, 2 and 3 flows to the V_1 port.





Section A-A



Section B-B

Fig. 1

F23E106



2. When the engine speed is from N₁ up to N₂: (Fig. 2)
 The total volume of the oil from pumps 1 and 2 flows to the V₁ port. ΔQ (Q₁ + Q₂ + Q₃ - QA) out of the oil from pump 3 flows to the V₂ port.






Fig. 2



F23E060




F23E059

3. When the engine speed is N_2 : (Fig. 3)

The total volume of oil from pumps 1 and 2 flows to the V_1 port, and the total volume of oil discharged from pump 3 flows to the V_2 port.




Section A-A




Section B-B

Fig. 3

F23E061




F23E059




4. When the engine speed is between N₂ and N₃ (Fig. 4)

The total volume of the oil from pump 1 and a part (QA - Q₁) of the oil from pump 2 flow to the V₁ port. The total volume of oil from pump 3 and ΔQ (Q₁ + Q₂ - QA) out of the oil from pump 3 flows to the V₂ port.





Section A-A



Section B-B

Fig. 4

F23E062



5. When the engine speed is between N_3 and N_4 :
- Same as item 4 when the oil flowing to the V_1 port is used.
 - When the oil flowing to the V_1 port is not used and is led to the C_o port: (Fig. 5)
The total volume of the oil from pumps 1 and 2 and a part of the oil ($Q_B - Q_1 - Q_2$) from pump 3 flows to the V_2 port and $\Delta Q (Q_1 + Q_2 + Q_3 - Q_B)$ out of the oil from pump 3 flows to the T port (for unloading).








Fig. 5


F23E063



- 6. When the engine speed is N_4 :**
- Same as item 4 when the oil flowing to the V_1 port is used.
 - When the oil flowing to the V_1 port is not used and is led to the C_0 port: (Fig. 6)
The total volume of oil from pumps 1 and 2 flows to the V_2 port and the total volume of oil from pump 3 flows to the T port.




Section A-A




Section B-B

Fig. 6

F23E064




F23E059




7. When the engine speed is between N₄ and N₅:
- Same as item 4 when the oil flowing to the V₁ port is used.
 - When the oil flowing of the V₁ port is not used and is led to the C₀ port: (Fig. 7)

The total volume of oil from pump 1 and a part of oil (QB - Q₁) from pumps 2 flows to the V₂ port.

The total volume of the oil from pump 3 and a part (ΔQ = Q₁ + Q₂ - QB) of the oil from pump 2 flows to the T port.




Section A-A




Section B-B

Fig. 7

F23E065



F23E059




8. When the engine speed is between N₄ and N₅:

- a. When the oil flowing to the V₁ port is used: (Fig. 8)


The total volume of oil from pump 1 and a part (QA - Q₁) of the oil from pump 2 flows to the V₁ port.

A part ($\Delta Q = Q_1 + Q_2 - QA$) of the oil from pump 2 and a part ($QA + QB - Q_1 - Q_2$) of the oil from pump 3 flows to the V₂ port.

A part ($\Delta Q = Q_1 + Q_2 + Q_3 - QA - QB$) of the oil from pump 3 flows to the T port.
- b. Same as 7 (b) when the oil flowing to the V₁ port is not used and is led to the C₀ port.




Section A-A




Section B-B

Fig. 8


F23E066




F23E059



9. When the engine speed is N_6 or above:
- a. When the oil flowing to the V_1 port is used: (Fig. 9)
The total volume of the oil from pump 1 flows to the V_1 port. The total volume of the oil from pump 2 and a part ($\Delta Q = Q_2 + Q_3 - QB$) from pump 3 flows to the T port.




Section A-A




Section B-B

Fig. 9

F23E067




F23E059




- b. When the oil flowing to the V₁ port is not used and is led to the C₀ port: (Fig. 10)

The total volume of the oil from pump 1 flows to the V₁ port → C₀ port. The total volume of the oil from pump 3 and a part ($\Delta Q = Q_1 + Q_2 - QB$) of the oil from pump 2 flows to the T port. Therefore, the total volume of oil from pump 1 and a part ($QB - Q_1$) of the oil from pump 2 flows to the V₂ port.



Section A-A




Section B-B

Fig. 10

F23E068

FLOW DIVIDER VALVE


GD705A-4



- 1. O-ring
- 2. Plug
- 3. Snap ring
- 4. Sleeve
- 5. Piston
- 6. Housing

F23E069


The oil from the DDV enters chamber **A** and is divided according to a constant flow ratio. It then passes through throttles **B₁** and **B₂**, then through chambers **C₁** and **C₂**, and goes to the hydraulic control valve.



F23E107


PILOT CHECK VALVE

(For Blade lift R.H.)



234F1119

- 1. Pilot valve
- 2. Check valve
- 3. Sleeve




234F1120

OPERATION

Using blade lift cylinder (right) as an example, when trying to lower the blade, when the control valve is operated, pressure develops in the cylinder bottom side of the blade lift cylinder. The pressure passing through the throttle forces the pilot valve (1) downwards and opens the pilot check valve and returns air and oil at the head of the cylinder to the tank. Pressure to hold the blade acts in the blade lift cylinder head side and pushes the check valve (2).

At the instant the check valve opens, oil escapes suddenly from chamber C to chamber A and pressure at the cylinder bottom side falls.


At this time, if there was no throttle in the pilot valve, the pilot valve would be constantly opening and shuttering in response to the changes in pressure at the cylinder bottom side and the head side which would give rise to the phenomena of chattering. For this reason a throttle has been provided at E position, so that, even if pressure at the cylinder bottom side fails, it has a damper effect so that the check valve does not close immediately.



234F1121

PILOT CHECK VALVE

(For Leaning, Articulate, Drawbar)




F23B092

1. Pilot check valve
2. Body
3. Piston
4. Pilot check valve

OPERATION

When extending the cylinder, if the control valve is operated, the oil from the pump enters chamber **A**. It pushes the pilot check valve and the piston, and enters chamber **C**. This forms pressure at the bottom end. Because the pressure in chamber **C** rises and pushes the cylinder, the oil in chamber **D** passes through the pilot check valve and flows to chamber **B**. The cylinder then extends.





F23B093

PILOT CHECK VALVE (With Safety Valve)

(For Power tilt, Ripper (if equipped))

- 1. Valve
- 2. Body
- 3. Piston
- 4. Pilot check valve
- 5. Sleeve
- 6. Poppet



F23E04078

The check valve with safety valve prevents hydraulic drift of the cylinder. At the same time, it protects the cylinder from abnormal pressure inside the cylinder caused by external force.

OPERATION

When extending the blade, the oil from the pump passes through chamber A and flows to chamber C. The pressure at the bottom rises and pushes the cylinder. When the cylinder is pushed, the oil in chamber B₁ passes through the pilot valve and flows to chamber B. When the oil pressure is more than 250 kg/cm², the oil from chamber D pushes the poppet and flows back to chamber C.

When the ripper lever is moved to the LOWER position, the oil from the pump passes through chamber A₂ and pushes pilot check valve (4). It then passes through chamber B₂ and flows to the chamber at the bottom end

of the cylinder, and extends the cylinder to lower the ripper. The oil at the head end of the cylinder flows back through chamber A₁ and chamber B₁, and returns to the tank.


When the ripper lever is moved to the RAISE position, the oil from the pump passes from chamber A₁ through chamber B₁ and flows to the chamber at the head end of the cylinder. When this happens, the pressure in chambers A₁ and B₁ rises. As the pressure rises, piston (3) is pushed, and check valve (4) is pushed open. The oil at the bottom end of the cylinder flows through the restriction in check valve (4) and returns through chamber A₂ to the tank. The cylinder retracts and the ripper rises.

When the ripper is operated, if there is abnormal ripper pressure of over 250 kg/cm² generated in chamber B₁, relief valve poppet (6) is pushed open. The oil flows to chamber B₂ and raises the ripper to relieve the shock.

PILOT CHECK VALVE (With Safety Valve)

(For Blade lift L.H., Scarifier (If equipped))

It is installed on the left blade lift and the scarifier cylinders.



1. Pilot valve
2. Check valve
3. Sleeve
4. Adjusting screw
5. Lock nut
6. Sleeve
7. Poppet

61F023


A safety valve is installed on the check valve not only to prevent natural falling of the cylinder and vacuum developing at the cylinder bottom side, but also to preserve the cylinder against abnormal pressure from outside forces.

OPERATION


Using blade lift cylinder (left) as an example, when trying to lower the blade, when the control valve is operated, pressure develops in the cylinder bottom side of the blade lift cylinder. The pressure passing through the throttle forces the pilot valve (1) downwards and opens the pilot check valve and returns air and oil at the head of the cylinder to the tank. Pressure to hold the blade acts in the blade lift cylinder head side and pushes the check valve (2).

At the instant the check valve opens, oil escapes suddenly from chamber C to chamber A and pressure at the cylinder bottom side falls.

At this time, if there was no throttle in the pilot valve, the pilot valve would be constantly opening and shuttering in response to the changes in pressure at the cylinder bottom side and the head side which would give rise to the phenomena of chattering. For this reason a throttle has been provided at E position, so that, even if pressure at the cylinder bottom side fails, it has a damper effect so that the check valve does not close immediately.




61F024



61F025

A safety valve poppet (7) has been installed to preserve the cylinder when high hydraulic pressure arises in the cylinder head side of the cylinder because of interference from the work equipment or external force. When high hydraulic pressure (about 250 kg/cm^2) arises to C, oil flows through the drill hole in the spool (6) to open the safety valve poppet (7) to flow to the cylinder bottom side of the cylinder.




61F026

DOUBLE RELIEF VALVE

GD705A-4

(For Steering)




- 1. Relief valve
- 2. Body
- 3. Poppet (A)
- 4. Sleeve
- 5. Relief valve
- 6. Poppet (B)
- 7. Sleeve

F23B098

The check valve with safety valve protects the cylinder from abnormal pressure inside the cylinder caused by external force.

OPERATION


In the hydraulic circuit diagram above, oil from chamber **A₁** enters. When there is abnormal pressure of over 210 kg/cm², it pushes poppet (B) and flows to chamber **A₂**. In the same way, when there is abnormal pressure of over 210 kg/cm², oil from chamber **B₂** pushes poppet (A) and flows to chamber **B₁**.



F23B099

HYDRAULIC PUMP


FOR WORK EQUIPMENT (LAR020 + LAR020) GD705R-4
 (SAR050 + SAR050) GD705A-4



238F089

- | | |
|---------------|-----------------|
| 1. Drive gear | 8. Cover |
| 2. Bracket | 9. Driven gear |
| 3. Gear case | 10. Bushing |
| 4. Carrier | 11. Driven gear |
| 5. Bracket | 12. Bushing |
| 6. Gear case | 13. Oil seal |
| 7. Drive gear | 14. Snap ring |

FOR WORK EQUIPMENT (SAR050) GD705A-4



238F039

- 1. Drive gear
- 2. Bracket
- 3. Gear case
- 4. Cover
- 5. Driven gear
- 6. Bushing
- 7. Oil seal
- 8. Snap ring

GENERAL

The hydraulic pump receives mechanical energy from the engine and other external devices, and converts it into fluid energy.

It serves as a generating source for the energy needed by the hydraulic devices. The fluid energy is classified as either velocity energy, pressure energy, or positional energy.

The fluid energy utilized for hydraulic pressure is, in most cases, pressure energy.

The hydraulic pump transfers energy by utilizing the static pressure of fluid. The pump displacement is determined by the transfer quantity of oil transferred within its chamber.

The hydraulic pump can easily generate high pressure without any noticeable change of the piston displacement as the load fluctuates. Accordingly, the hydraulic pump is not designed to produce pressure, but instead is designed to provide a constant oil flow. Pump pressure is generated by the resistance (load) which acts to resist the oil flow. As a result, if there is no resistance, no pressure will be produced.

The hydraulic pumps are divided roughly into rotary pumps and reciprocating pumps, according to their structures, and they are further divided into the fixed delivery type and the variable delivery type, depending on their function.

The hydraulic pumps employed on the wheel loader, for example, include the external gear pump and the fixed delivery type vane pump, which belong to the fixed delivery type of rotary pumps.


The external gear pump employs involute spur gears. This category of pump can also be divided into the following types according to their structure.

- Side plate adjusting system
 - Fixed side plate type (FAL, FAR)
 - Moving side plate type (PAL, PAR, KAL, KAR, SAL, SAR)
 - Variable side plate type



- Bearing metal system
 - Anti-friction bearing metal type
 - Plain bearing metal type

Standard KOMATSU pumps are indicated as follows.

1. Single pump



2. Tandem pump



F23AB133

OPERATING PRINCIPLES


How oil flows

The diagrams at right outline the operating principles of a circumscribed gear pump with two gears intermeshed and rotating within the gear case. Oil entering via the inlet passes between the gear teeth and turns together with the gears, thereby being carried to the outlet. Because of the intermeshing of the gear teeth, only oil at the base of the gear teeth will be carried back to the inlet side.

Since the gears continually carry oil, oil on the discharge side is forced out from the discharge port. The discharge rate increases at faster gear rotational speeds.

If there is no resistance obstructing the flow of oil forced out from the discharge port, there will be no increase in oil pressure as the oil continues to move along the route. If, however, the end of the route is blocked by a hydraulic cylinder and the oil can proceed no further, the oil pressure will increase. If the hydraulic cylinder piston is then pushed out by the increased oil pressure, the pressure will rise no further.

As was described above, the gear pump itself generates the flow of oil, it does not generate pressure. The oil pressure is generated as a result of the load applied, or in other words, oil pressure depends on factors external to the pump.




F23AB136

Oil confinement

When the gears of a gear pump mesh and rotate, two pairs of gear teeth will mesh simultaneously at one stage, while only one pair will mesh at another (see accompanying diagrams). When two pairs of teeth mesh simultaneously, the oil in the gap between the meshed teeth is trapped and cut off from both inlet and outlet. This is referred to as "oil confinement".


As the gears rotate, the gap trapping the oil moves from the discharge side to the inlet side. During the period when the gap moves from the start of the confinement to the center, the volume of the gap gradually decreases, but while the gap is moving from the center to the end of the confinement, the volume increases again.

Since oil cannot contract, the pressure of the trapped oil increases if there is nowhere for the oil to go when the gap volume decreases. Since this results in the generation of considerable noise and vibration, escape grooves cut in the side plate enable the trapped oil to pass out towards the discharge side when the gap volume is decreasing (see diagram below). In addition, grooves are also cut to connect the inlet side with the gaps when the gap volume is increasing again, thereby replenishing the escaped oil to prevent a vacuum.




F23AB137

Fixed wall plate type gear pump



Movable side plate type gear pump




F23AB138

Internal oil leakage

If there are any gaps, oil will leak from positions of higher oil pressure to those of lower oil pressure. In gear pumps, a small gap is left between the gears and the case and side wall to prevent "seizure" and scraping. The oil leaking through this small gap serves to lubricate the pump. This condition is outlined in the diagram at right. Hence, there is a continuous leakage of oil from the high pressure discharge side to the inlet side inside the actual pump, and the discharge rate is reduced by that amount.

If this gap is enlarged by wear and tear, or if the oil viscosity drops due to increased oil temperature during operation, or if a low viscosity oil is used, there will be a subsequent increase in the oil leakage, resulting in a corresponding reduction in the discharge rate.




F23AB139

Forces applied to the gear

Due to the oil pressure of the surrounding oil, a force is applied to the center of the gear. This pressure is high on the discharge side due to the discharge pressure, and low on the inlet side due to suction pressure. In the intermediate positions, the pressure gradually falls from the discharge side to the inlet side. This is outlined in the diagram at right. In addition, there are also forces interacting on gear teeth in contact with each other. Due to the forces described above, the gears are pushed over on the inlet side, this thrust being supported by bearings. As a result of this tendency towards the inlet side, the gap between the tips of the gear teeth and the case on the inlet side becomes narrower, and depending on the type of pump (PAL, PAR, KAL, KAR), the gap may sometimes be closed altogether.

Consequently, if the discharge pressure is too high and excessive pressure is applied to the gear, the extra load on the bearings will shorten the bearing life, and the gear teeth will tend to bite into the case. It is therefore essential to avoid increasing the discharge pressure too high.



F23AB140

Movable side plate type gear pump

In movable plate type gear pumps, the bushing which serves as the side plate is fitted into the case and pressed against the side of the gears. This reduces oil leakage from the side of the gears. Since the bushing is pressed constantly against the side of the gears by oil pressure, wearing of the bushing over long periods of time does not increase the size of the gap, thereby keeping oil leakage at a constant level.

Furthermore, the bushing is pushed towards the gears from the cover side by oil pressure, but pushed away from the gears by the pressure of the oil between the gear teeth and of the oil leaking through the gap between bushing and gear.


However since the gear oil pressure is high on the discharge side and low on the input side, a force pushing the bushing from the cover side is also added, resulting in a greater push on the discharge side and a smaller push on the inlet side.

By partitioning the surface area of the bushing to which the cover side pressure is applied by means of back up rings fitted on the seal plate as shown in the diagram at right, the surface area on the discharge side will be greater than on the inlet side.


When the pump operates at higher rotational speeds, the pressure on the discharge side decreases, and the distribution of pressure around the gears changes as shown in the diagram.

Consequently, when the rotational speed is changed, the pressure distribution changes, creating a force which pushes against the bushing from the gear side.

Therefore, a pressure balance groove is cut in the bushing. The discharge pressure acts along this groove, thereby stabilizing the pressure distribution whenever the rotational speed is changed.




F23AB141



F23AB142

FEATURES

1. Performance and durability
 - i) Side plate (9) is made flush with minimal torque loss, and high resistance against wear and tear.
 - ii) Stable performance and durability are due to improvements in the hydrobalance mechanism.



F23AB143

2. Simplification of structure
 - In addition to reduction of mechanically processed parts such as brackets and covers, greater compatibility and standardization of parts has been achieved. The total number of component parts has been reduced.

Structural comparison with KA series pumps


| | KA Series | SA Series |
|-----------------------------------|------------------------------------|---------------------------------------|
| Bracket (mounting flange section) | No standard (exclusive to Komatsu) | SAE standard (international standard) |
| Gear case | Intake and discharge ports | No ports |
| Cover | No ports | Intake and discharge ports |
| Bushing or side plate | Movable bushing | Movable side plate |
| Plain bearing | Press fit bushing | Press fit to bracket and cover |
| Number of component parts | 60 | 32 |
| Weight | 7.6 | 6.3 |

F23AB144


3. Simplification of piping

- Selection of port shape – side port or rear port.

Rear port




Side port



F23AB145

CIRCLE ROTATION MOTOR




61F007

Orbit motor is used for circle rotation motor; the machine is mounted with this motor on drawbar. Star gear (6) turns with high hydraulic pressure, thereby rotating output shaft (1) which turns together with the star gear (6) and the main drive shaft (5). This output shaft is connected to circle rotation gear case. Since star gear (6) engages with disc valve drive shaft (8), disc valve (9) also turns, thus changing the position where the hydraulic oil to Geroler (7) enters.

- | | |
|-------------------------|---------------------------|
| 1. Output shaft | 7. Geroler housing |
| 2. Flange | 8. Disc valve drive shaft |
| 3. Oil seal | 9. Disc valve |
| 4. Taper roller bearing | 10. Check valve |
| 5. Main drive shaft | 11. Valve plate |
| 6. Star gear | 12. Pump housing |


HYDRAULIC PUMP TYPE

| | GD705R-4 | GD705A-4 |
|--------------------------------|------------------------|------------------------|
| Roller | 37.5 mm | 37.5 mm |
| Theoretical oil quantity | 123 cc/rev. | 246 cc/rev. |
| Rated speed | 562 rpm | 603 rpm |
| Instantaneous maximum torque | 34.2 kgm | 68.5 kgm |
| Instantaneous maximum pressure | 175 kg/cm ² | 175 kg/cm ² |
| Weight | 9.8 kg | 18.8 kg |




61F008A

Disc valve (9) is furnished with twelve oil holes; the oil of high pressure flows through six oil holes, and the other oil holes serve as a drain port. Disc valve (9) contacts the valve plate (11) with seven oil holes. These oil holes in the valve plate (11) are connected to the chamber made up of star gear (6) and Geroler (7). The oil of high pressure, which has entered to each travelling motor, goes into the chamber via the disc valve (9) and valve plate (11). When the oil of high pressure flows into the chamber, the star gear (6) starts running with the hydraulic pressure. When the star gear (6) rotates, disc valve (9) turns. Thus, the position where the high-pressure oil is delivered to the chamber, is shifted in regular sequence.




61F009

The star gear (6) rotates on its own axis and it also revolves round the center of Geroler. The rotation of star gear (6) is transmitted to the output shaft via the main drive shaft.




61F010

When star gear (6) makes $1/7$ of a rotation left-ward on its own axis, it makes $6/7$ of a revolution right-ward. Namely, when the star gear makes one revolution, it rotates $1/6$ of a rotation on its own axis. As a result, compared with general hydraulic motors (the difference from the orbit motor can be understood more easily when compared with the trochoid motor), this orbit motor makes available a torque 6 times as large as that possible with hydraulic motors. In addition, the rotating speed of the orbit motor can be reduced to as low as $1/6$ of the speed of hydraulic motors. Nevertheless, the orbit motor is designed to be of the compact type.





61F011



61F012

HYDRAULIC CYLINDER



BLADE LIFT CYLINDER GD705R-4



- 1. Cap
- 2. Cylinder head
- 3. Cylinder
- 4. Piston
- 5. Wear ring
- 6. Piston nut
- 7. Bushing
- 8. Piston ring
- 9. Piston rod
- 10. Rod packing
- 11. Bushing
- 12. Dust seal



F23E04051

GD705A-4



61F030


**BLADE SIDE SHIFT CYLINDER
GD705R-4**



F23E04052



- 1. Bushing
- 2. Cylinder head
- 3. Cylinder
- 4. Piston
- 5. Wear ring
- 6. Piston nut
- 7. Piston ring
- 8. Piston rod
- 9. Rod packing
- 10. Bushing
- 11. Dust seal
- 12. Bushing

GD705A-4



F23E070A



**DRAWBAR SHIFT CYLINDER
GD705R-4**



F23E04053

- 1. Cap
- 2. Cylinder head
- 3. Cylinder
- 4. Piston
- 5. Wear ring
- 6. Piston nut
- 7. Piston ring
- 8. Piston rod
- 9. Rod packing
- 10. Bushing
- 11. Dust seal



GD705A-4



61F029A

LEANING CYLINDER



GD705R-4



- 1. Cylinder head
- 2. Cylinder
- 3. Piston
- 4. Wear ring
- 5. Piston nut
- 6. Bushing (bottom side)
- 7. Piston ring
- 8. Piston rod
- 9. Rod packing
- 10. Bushing
- 11. Dust seal
- 12. Bushing (head side)


F23E04054

GD705A-4




F23E071A

ARTICULATE CYLINDER GD705A-4



F23404020

POWER TILT CYLINDER GD705A-4





F23404021

- 1. Cylinder head
- 2. Cylinder
- 3. Piston
- 4. Wearing
- 5. Piston nut
- 6. Bushing (Bottom side)
- 7. Piston ring
- 8. Piston rod
- 9. Rod packing
- 10. Bushing
- 11. Dust seal
- 12. Bushing (head side)

SCARIFIER CYLINDER (If equipped)



GD705R-4



- 1. Cylinder head
- 2. Cylinder
- 3. Piston
- 4. Wearing
- 5. Piston nut
- 6. Bushing (bottom side)
- 7. Piston ring
- 8. Piston rod
- 9. Rod packing
- 10. Bushing
- 11. Dust seal
- 12. Bushing (head side)



F23E04055

GD705A-4



F23404022A

RIPPER CYLINDER
GD705A-4



F23E075

- 1. Cylinder
- 2. Piston
- 3. Wearing
- 4. Piston nut
- 5. Piston ring
- 6. Rod packing
- 7. Bushing
- 8. Dust seal
- 9. Bushing (Head side)

OUTLINE

The hydraulic cylinder is a mechanism for converting fluid energy into mechanical energy for linear drive purposes. The cylinder has oil inlets and outlets at both the head end (piston rod end) and the bottom end, and by applying oil pressure to both ends, the oil is alternately forced in and out of the cylinder resulting in the piston and piston rod being moved back and forth.

Cylinders with this kind of action are referred to as double-acting cylinders and are used in motor grader.

STRUCTURE AND FUNCTION**Cylinder**


Cylinders are made of steel piping with a base welded to the bottom. The inside of the piping is finished by honing in order to prevent oil leakage and abrasion with the packing.

Cylinder head

The cylinder head of motor grader is secured to the cylinder by cutting a thread into the head and screwing it into the cylinder.

The cylinder head has a center hole through which the piston rod is passed. This hole is fitted with a bronze bushing to prevent the piston rod from rubbing directly against the cylinder head.

This section is also packed to prevent leakage of cylinder oil through the gap between the cylinder head and piston rod. In addition, a dust seal is employed to prevent grit adhering to the piston rod from being carried into the cylinder when the rod is pushed in.



HYDRAULIC SYSTEM

62 TESTING AND ADJUSTING



Checking hydraulic oil temperature 62-2

CHECKING HYDRAULIC OIL TEMPERATURE


Special tool

| | Part number | Part name | Q'ty |
|---|--------------|------------|------|
| A | 795-500-1300 | Thermistor | 1 |

1. Remove hydraulic oil tank cap (1) and remove strainer.



When removing cap, loosen the oil filler cap slowly to release the remaining oil pressure in the hydraulic tank.




2. Insert sensor into filling port and measure oil temperature with thermistor gauge A.



HYDRAULIC SYSTEM

63 DISASSEMBLY AND ASSEMBLY



| | |
|------------------------------------|-------|
| HYDRAULIC TANK | |
| Removal and installation | 63- 2 |
| HYDRAULIC PUMP ASSEMBLY | |
| Removal and installation | 63- 3 |
| HYDRAULIC CONTROL VALVE ASSEMBLY | |
| Removal | 63- 5 |
| Installation | 63- 6 |
| BLADE LIFT CYLINDER ASSEMBLY | |
| Removal and installation | 63- 9 |
| DRAWBAR SHIFT CYLINDER ASSEMBLY | |
| Removal and installation | 63-10 |
| BLADE SIDE SHIFT CYLINDER ASSEMBLY | |
| Removal | 63-11 |
| Installation | 63-12 |
| LEANING CYLINDER ASSEMBLY | |
| Removal and installation | 63-15 |
| ARTICULATE CYLINDER ASSEMBLY | |
| Removal and installation | 63-17 |
| POWER TILT CYLINDER ASSEMBLY | |
| Removal and installation | 63-18 |
| HYDRAULIC CYLINDER ASSEMBLY | |
| Disassembly | 63-19 |
| Assembly | 63-22 |

REMOVAL OF HYDRAULIC TANK

GD705A-4





Lower the work equipment completely to the ground and stop the engine. Operate the control lever several times to release the remaining hydraulic pressure in the hydraulic piping. Then loosen the oil filler cap (1) slowly to release the remaining oil pressure in the hydraulic tank.

1. Remove drain plug (2) and drain oil from hydraulic tank.



Hydraulic tank: 70ℓ

2. Remove cover (3).
3. Disconnect hose (4).
4. Disconnect hoses (5), (6) (7), (8).
5. Lift hydraulic tank and dismount it.




INSTALLATION OF HYDRAULIC TANK

GD705A-4

1. Lift hydraulic tank and mount it.
2. Connect hoses (8), (7), (6), (5).
3. Connect hose (4).
4. Install cover (3).
5. Tighten drain plug (2).
6. Add engine oil through hydraulic oil filler (1) to the specified level.



Hydraulic oil tank: 70ℓ



- ★ Run the engine to circulate the oil through the system. Then check the oil level again.

REMOVAL OF HYDRAULIC PUMP ASSEMBLY

GD705R-4



Lower work equipment completely to the ground.



Slowly loosen cap (1) to release the oil pressure from the hydraulic tank.

1. Remove drain plug (2) and drain engine oil from the hydraulic tank.





Hydraulic tank: Approx. 27ℓ

2. Remove cover (3).
3. Disconnect inlet tubes (4), (5).
4. Disconnect outlet hoses (6), (7).
5. Dismount hydraulic pump assembly (8).



Hydraulic pump assembly: Approx. 11 kg



INSTALLATION OF HYDRAULIC PUMP ASSEMBLY



GD705R-4

1. Fit O-ring and mount hydraulic pump (8).
2. Connect outlet hoses (6), (7).
3. Connect inlet tubes (4), (5).
4. Install cover (3).
5. Tighten drain plug (2) and add engine oil through filler port (1) to the specified level.



Hydraulic tank: Approx. 27ℓ

- ★ Run the engine to circulate engine oil through the system. Then check oil level again.



REMOVAL OF HYDRAULIC PUMP ASSEMBLY

GD705A-4



Lower the work equipment completely to the ground and stop the engine.

- ★ Remove fuel tank assembly (incl. hydraulic tank).
For details, see 13 REMOVAL OF HYDRAULIC PUMP ASSEMBLY (incl. HYDRAULIC TANK).

REMOVAL OF HYDRAULIC PUMP ASSEMBLY

1. Disconnect inlet tube (1), outlet tube (2) and outlet hose (3) from hydraulic pump assembly.
2. Remove hydraulic pump assembly (4).





Hydraulic pump assembly: Approx. 14 kg

REMOVAL OF CIRCLE ROTATION PUMP ASSEMBLY

1. Remove inlet tube (5) and outlet tube (6) from circle rotation pump.
2. Remove circle rotation pump assembly (7).



Rotation pump assembly: Approx. 6 kg



INSTALLATION OF HYDRAULIC PUMP ASSEMBLY


GD705A-4

INSTALLATION OF HYDRAULIC PUMP ASSEMBLY

1. Install hydraulic pump assembly (4).
 - ★ Fit O-ring at PTO case end.
2. Connect outlet hose (3), outlet tube (2) and inlet tube (1).

INSTALLATION OF CIRCLE ROTATION PUMP ASSEMBLY

1. Install circle rotation pump assembly (7).
 - ★ Fit O-ring at PTO case end.
 2. Install outlet tube (6) and inlet tube (5).
- ★ Install fuel tank assembly (incl. hydraulic tank).
For details, see 13 INSTALLATION OF FUEL TANK ASSEMBLY (incl. HYDRAULIC TANK).



REMOVAL OF HYDRAULIC CONTROL VALVE ASSEMBLY

GD705R-4



Lower work equipment completely to the ground.



Operate the control valve several times to release the oil pressure from the piping.





Slowly loosen the filler cap (1) to release the remaining oil pressure from the hydraulic tank.

1. Remove drain plug (2) and drain engine oil from the hydraulic tank.



Hydraulic tank: Approx. 27ℓ

2. Dismount L.H. control valve assembly
 - 1) Disconnect inlet tube (3), eight cylinder tubes (4), outlet tube (5), carry over tube (6).
 - 2) Remove joint pins (7) for control lever and dismount L.H. control valve assembly (8).
3. Dismount R.H. control valve assembly
 - 1) Disconnect carry over tube (9), six cylinder tubes (10), inlet tube (11), outlet tube (12).
 - 2) Remove joint pins (7) for control lever and dismount R.H. control valve assembly (13).



INSTALLATION OF HYDRAULIC CONTROL VALVE ASSEMBLY





GD705R-4

1. Mount L.H. control valve assembly
 - 1) Mount L.H. control valve assembly (8) and connect control lever with joint pins (7).
 - 2) Connect carry over tube (6), outlet tube (5), eight cylinder tubes (4), inlet tube (3).
 - ★ Bend cotter pin securely.
2. Mount R.H. control valve assembly
 - 1) Mount R.H. control valve assembly (13) and connect control lever with joint pins (7).
 - 2) Connect outlet tube (12), inlet tube (11), six cylinder tubes (10), carry over tube (9).
 - ★ Bend cotter pin securely.
3. Tighten drain plug (2), add engine oil through filler port (1) to the specified level.





Hydraulic tank: Approx. 27ℓ

- ★ Run the engine to circulate engine oil through the system. Then check oil level again.





REMOVAL OF HYDRAULIC CONTROL VALVE ASSEMBLY

GD705A-4

-  Lower work equipment completely to the ground.
-  Operate the control lever several times to release the remaining hydraulic oil pressure in system. Then loosen the oil filler cap (1) slowly to release the remaining oil pressure in the hydraulic tank.

1. Remove drain plug (2) and drain oil from hydraulic oil tank.


 Hydraulic oil tank: Approx. 70ℓ



P23EC077

REMOVAL OF L.H. HYDRAULIC CONTROL VALVE

1. Disconnect six cylinder hoses (3), inlet hose (4), outlet tube (6) and carry over port hose (5).
 2. Pull out three connecting pins (7) of control lever and dismount L.H. control valve assembly (8).
 3. Remove mounting bolt of control valve.
- ★ Disconnect cylinder hoses in the order shown in the diagram below.




P23EC196

REMOVAL OF R.H. HYDRAULIC CONTROL VALVE

1. Disconnect eight cylinder hoses (9), inlet hose (10), outlet tube (11), and carry over port hose (12).
 2. Pull out four connecting pins and dismount R.H. hydraulic control valve assembly (13).
 3. Remove mounting bolt of control valve.
- ★ Disconnect cylinder hoses in the order shown in the diagram below.




P23BB160



R.H. valve

L.H. valve

F23EC032A




P23EC234A

INSTALLATION OF HYDRAULIC CONTROL VALVE ASSEMBLY

GD705A-4

INSTALLATION OF L.H. HYDRAULIC CONTROL VALVE ASSEMBLY


1. Install hydraulic control valve assembly (8) and insert three connection pins (7) of hydraulic control lever.
2. Connect six cylinder hoses (3), inlet hose (4), outlet tube (6), and carry over port hose (5).
3. Tighten mounting bolt of control valve.
 - ★ Bend cotter pin securely.
- ★ Connect cylinder hoses in the order shown in the diagram below.




P23BB160

INSTALLATION OF R.H. HYDRAULIC CONTROL VALVE ASSEMBLY


1. Install hydraulic control valve assembly and install four connection pins of hydraulic control lever.
2. Connect eight cylinder hoses (9), inlet hose (10), outlet tube (11), and carry over port hose (12).
3. Tighten mounting bolt of control valve.
 - ★ Bend cotter pin securely.
- ★ Connect cylinder hoses in the order shown in the diagram below.



P23EC196



P23EC234A



R.H. valve

L.H. valve

F23EC033A


REFILLING WITH OIL

Tighten drain plug (2) and refill engine oil through oil filler port (1) to specified level.



Hydraulic tank: Approx. 70ℓ

- ★ Run the engine to circulate the oil through the system. Then check the oil level again.



P23EC077

REMOVAL OF BLADE LIFT CYLINDER ASSEMBLY



Lower work equipment completely to the ground.

1. Raise blade lift cylinder assembly (1) with a crane.
2. Remove cap (2), and disconnect it from drawbar (3).
3. Run the engine, operate control lever and fully retract piston rod.



To prevent piston rod from coming out, fix piston rod with wire.



Stop engine, operate the control lever several times to release the oil pressure from the system.

4. Disconnect hoses (4), (5) from cylinder.
5. Remove cap (6) and dismount blade cylinder assembly (1).




Blade cylinder assembly:


Approx. 55 kg (GD705R-4)

Approx. 63 kg (GD705A-4)


GD705R-4




GD705A-4



GD705R-4



GD705A-4



INSTALLATION OF BLADE LIFT CYLINDER ASSEMBLY

1. Raise blade lift cylinder assembly (1) with crane, install seal, and set in position with the yoke. Align dowel pin and install cap (6).
2. Install cap (6) and tighten with bolt.
3. Connect hoses (5), (4) to cylinder.
 - ★ Be sure to connect hoses to the correct end.
 - ★ Install hoses without twisting.
4. Run the engine, extend piston rod, and install dust seal. Then set in position with drawbar (3).
5. Fit shim, install cap (2) and tighten with bolt.
 - ★ Operate the control lever to circulate engine oil through in cylinder. Then add engine oil into hydraulic tank to be specified level.

REMOVAL OF DRAWBAR SHIFT CYLINDER ASSEMBLY



Lower work equipment completely to the ground.

1. Sling center of drawbar shift cylinder assembly (1) and raise it with a crane.
2. Remove cap (2) and disconnect it from bracket.
3. Start engine. Fully retract piston rod.



Stop the engine. Operate control lever several times the remaining pressure from the hydraulic piping.

4. Disconnect hoses (3), (4) from cylinder.
5. Remove cap (5) and dismount drawbar shift cylinder assembly (1).




Drawbar shift cylinder assembly: Approx. 35 kg
 Approx. 30 kg (GD705R-4)
 Approx. 35 kg (GD705A-4)


INSTALLATION OF DRAWBAR SHIFT CYLINDER ASSEMBLY

1. Sling center of drawbar shift cylinder assembly (1) and raise it with a crane.
 Install dust seal (6) and align the ass'y with drawbar (7).
2. Install shims (8) and install cap (5).
3. Connect hoses (3), (4) to cylinder.
 - ★ Be sure to connect the hoses to the correct end.
 - ★ Install hoses without twisting.
4. Start engine, extend piston rod and install dust seal. Align piston rod with the brocket.
5. Install shim and install cap (2).
- ★ Operate the control lever to circulate oil in the cylinder then add engine oil into the hydraulic tank to the specified level.



GD705R-4



GD705A-4



GD705R-4




REMOVAL OF BLADE SIDE SHIFT CYLINDER ASSEMBLY

GD705R-4




Start engine and operate lever to raise blade about 200 mm off the ground and support swing circle lower part with block.

1. Operate lever to fully extend piston rod (1) to push blade (2).
2. Remove bolt and remove plate (3).
3. Temporarily sling cylinder piston rod and disconnect bracket (4) from blade.
4. Start engine and operate lever to fully retract piston rod.
5. Sling blade (2) and push it out to the piston where cylinder can be removed.




P23E04097



P23E04098

6. Disconnect hoses (5) and (6) from cylinder.




P23E04099

7. Put jack (1) to blade side shift cylinder assembly (7), remove snap ring (8) and pull washer (9) and shaft (10), remove cylinder assembly.



Blade side shift cylinder: 45 kg




63P015


INSTALLATION OF BLADE SIDE SHIFT CYLINDER ASSEMBLY

GD705R-4


- Put blade side shift cylinder assembly (7) on jack ①. Align hole on cylinder with that on adjuster. Drive shaft (10) and install washer (9) and install snap ring (8).




- Connect hoses (6) and (5) to cylinder.
 - ★ Install hoses using care to avoid twisting.



- Sling blade (2) and fully extend piston rod to the installable position.
- Sling piston rod (1) and start engine to extend piston rod fully.
- Install bracket (4) to blade.



- Install plate (3).
- Raise blade to remove block.
 - ★ Operate control lever to circulate oil through the cylinder and add engine oil to hydraulic tank up to the specified level.




REMOVAL OF BLADE SIDE SHIFT CYLINDER ASSEMBLY

GD705A-4




Start engine, operate control lever to raise work equipment, (approx. 200 mm) then put blocks under the circle.




P23BB163

1. Operate control lever to fully extend piston rod (1), then push out blade (2).
2. Temporarily raise piston rod and disconnect bracket (3) from blade.
3. Remove bolt (4) and remove bracket.
4. Start engine. Operate control lever to fully retract piston rod.
5. Sling the center of blade (2) raise it with a crane, remove cylinder and push it out slightly to the side.



P23BB164

6. Disconnect hoses (5), (6) from cylinder.




P23BB165

7. Put blade side shift cylinder assembly (7) on jack ①, remove bolt (8) and washer (9) and remove cylinder assembly.



Blade side shift cylinder assembly:

Approx. 72 kg




P23BB166


INSTALLATION OF BLADE SIDE SHIFT CYLINDER ASSEMBLY

GD705A-4


1. Put blade side shift cylinder assembly (7) on jack ①, align adjuster hole with cylinder. Install washer (9) and bolt (8).




2. Connect hoses (5), (6) to cylinder.
 - ★ Install hoses without twisting.



3. Raise blade (2) with a crane, fully extend piston rod and push it in until it reaches a position where it can be connected.
4. Raise piston rod (1), start engine and fully extend piston rod (1).
5. Install bracket (3) in rod end and install bolt (4).
6. Connect bracket on blade.



7. Raise work equipment and pull out block.
 - ★ Operate control lever to circulate the oil in the cylinder, then add engine oil into the hydraulic tank to the specified level.



REMOVAL OF LEANING CYLINDER ASSEMBLY

GD705R-4

Special tool



| | Part number | Part name | Q'ty |
|---|--------------|----------------|------|
| A | 790-102-1820 | Nut wrench kit | 1 |

1. Remove retaining plate (2) of cylinder bottom end pin (1).
2. Run the engine, fully retract the piston rod.



Stop engine, operate the control lever to release the oil pressure from the system.


3. Disconnect hoses (3), (4) from cylinder.
4. Using tool A, remove nut (5) and washer (6). Then dismount leaning cylinder assembly (7).



INSTALLATION OF LEANING CYLINDER ASSEMBLY

GD705R-4

1. Connect leaning cylinder assembly (7) to shaft.
 2. Fit two washers (6). Use tool A to tighten nut (5).
 - ★ Bend cotter pin securely.
 3. Connect hoses (4), (3) to cylinder.
 - ★ Be sure to connect the hoses to the correct end.
 - ★ Install hoses without twisting.
 4. Run the engine, extend piston rod and align pin holes of cylinder bottom end and axle bracket (8), then install retaining plate (2) of bottom end pin (1).
- ★ Operate control lever to release the remaining oil pressure through the system. Add engine oil to hydraulic tank to the specified level.



REMOVAL OF LEANING CYLINDER ASSEMBLY


GD705A-4

1. Remove bolt (1) and spacer (2).
2. Start engine. Fully retract piston rod.



Stop the engine. Operate control lever several times to release the remaining pressure from the hydraulic piping.


3. Disconnect hoses (3), (4) from cylinder.
4. Remove bolt (5), retaining plate (6) and dismount leaning cylinder assembly (7).



INSTALLATION OF LEANING CYLINDER ASSEMBLY

GD705A-4

1. Connect leaning cylinder assembly (7) to shaft.
 2. Install retaining plate (6) and tighten it with bolt (5).
 3. Connect hoses (4), (3) on cylinder.
 - ★ Be sure to connect the hoses to the correct end.
 - ★ Install hoses without twisting.
 4. Start engine. Extend piston rod and align pin hole of cylinder bottom end and axle end bracket. Then install it with spacer (2) and bolt (1).
- ★ Operate control lever to circulate oil in the cylinder, then add engine oil into the hydraulic tank to the specified level.



REMOVAL OF ARTICULATE CYLINDER ASSEMBLY

GD705A-4

1. Remove retaining plate (1) at head, then remove pin (2).




If it is difficult to remove the pin because of residual pressure in the cylinder, loosen the sleeve nut of the hose to discharge the residual pressure.


2. Draw the cylinder toward the vehicle body, and disconnect cylinder bottom hose (3) and cylinder head hose (4) from the cylinder.
3. Temporarily hoist cylinder assembly (5).
4. Remove bottom retaining plate (6) and bottom pin (7).
5. Hoist cylinder assembly (5) and remove it.



Articulate cylinder assembly: Approx. 44 kg



P23404022




P23404023

INSTALLATION OF ARTICULATE CYLINDER ASSEMBLY

GD705A-4

1. Sling center of cylinder assembly (5) and raise it with a crane so that the bottom of the cylinder assembly is positioned on the mounting bracket.
2. Insert bottom pin (7), and fix it to retaining plate (6).
3. Connect cylinder head hose (4) and bottom hose (3) to the cylinder.
 - ★ Install hoses without twisting and interference.
4. Start the engine, extend the cylinder rod. Align the piston rod connecting pin holes with the holes in the bracket.
5. Insert connecting pin (2) at head end and fix it with retaining plate (1).
- ★ Operate the control lever to circulate oil in the cylinder then add engine oil into the hydraulic tank to the specified level.



P23404024

REMOVAL OF POWER TILT CYLINDER ASSEMBLY

GD705A-4

 Lower work equipment completely to the ground.

1. Place support under the blade.
2. Remove cover (1).
3. Remove retaining plate (2) at cylinder head end, then remove pin (3).




If it is difficult to remove the pin because of residual pressure in the cylinder, loosen the sleeve nut of the hose to discharge the residual pressure.


4. Disconnect hose at cylinder bottom end (4) and at cylinder head end (5) from cylinder.
5. Fit wire around center of cylinder (6) and raise it.
6. Remove cap (7).
7. Raise cylinder assembly (6) and remove it.



Power tilt cylinder: Approx. 41 kg



P23404025



P23404026

INSTALLATION OF POWER TILT CYLINDER ASSEMBLY

GD705A-4

1. Raise cylinder assembly (6) and set bottom in position on mounting bracket.
2. Install cap (7).
3. Connect cylinder hoses on head side (5) and bottom side (4) to the cylinder.
 - ★ Install hose without twisting.
4. Start engine. Extend cylinder. Align the piston rod connecting pin holes with the holes in the bracket.
5. Insert pin (3) and fix it with retaining plate (2).
6. Install cover (1).
- ★ Operate the control lever to circulate oil in the cylinder then add engine oil into the hydraulic tank to the specified level.


DISASSEMBLY OF HYDRAULIC CYLINDER ASSEMBLY

Special tools

| | Part number | Part name | Q'ty |
|---|--------------|-----------------------|------|
| A | 790-502-1000 | Cylinder repair stand | 1 |
| B | 796-731-1300 | Wrench | 1 |


1. Remove the cylinder head and piston rod assembly from the cylinder.

- 1) Set cylinder (1) down onto tool A.




- 2) Unlock cylinder head (2) and loosen the cylinder head with tool B.

- ★ Since cylinder head (2) is locked at one or two points on the circumference with caulking, it is necessary to use a chisel to unlock it.




- 3) Carefully draw out the cylinder head and piston rod assembly (3) from cylinder (4).

- ★ When hoisting the cylinder head and piston rod assembly with a wire rope, wrap waste rags around it to avoid damaging the rod.
- ★ Some hydraulic oil may spill out of the cylinder at the lower end. Therefore, place a drain oil pan under the cylinder head.
- ★ If piston rod (3) cannot be drawn out of cylinder (4) smoothly, turn it a little while pulling it.
- ★ Be particularly careful not to damage the piston ring (slipper seal) on the threaded part of the cylinder while removing it.




4) Remove the cylinder (4) from tool A.

2. Set the cylinder head and piston rod assembly onto tool A, and loosen the piston nut by using socket ① and power wrench ②.



3. Remove piston nut (5). Then remove piston assembly (6) and cylinder head (7) from rod (8).





DISASSEMBLY OF PISTON ASSEMBLY

★ If the piston rings (slipper seal (10), backup ring (13) and back ring (12)) are not damaged, do not disassemble them.

1. Remove wear ring (9) from piston (11).
2. Remove backup ring (13), slipper seal (10) and back ring (12), if they show signs of damage.



★ Once the backup ring, slipper seal and back ring have been removed, they can no longer be used. Always replace them with new ones.



F23404070

**DISASSEMBLY OF CYLINDER HEAD
ASSEMBLY**

- ★ Don't disassemble the dust seal and other seals if they are not damaged.
 - ★ Once seals are removed, they cannot be reused. They must always be replaced with new ones.
1. Remove snap ring (12) and detach dust seal (13) from cylinder head (16).
 2. Remove rod packing (14) from cylinder head (16) by using a screwdriver.
 - ★ Be careful not to damage any other parts while prying out the rod packing.
 3. Remove bushing (15) from the cylinder head.
 4. Remove O-ring (17) and back-up ring (18).



125P390


ASSEMBLY OF HYDRAULIC CYLINDER ASSEMBLY

Special tools

| | Part number | Part name | Q'ty |
|---|--------------|-----------------------|------|
| A | 790-502-1000 | Cylinder repair stand | 1 |
| B | 796-731-1300 | Wrench | 1 |
| C | 790-702-1000 | Expender | 1 |
| D | 796-720-1660 | Ring | 1 |


ASSEMBLY OF CYLINDER HEAD ASSEMBLY

- ★ Remove any sharp edge, etc., from the fitting grooves of the rod packings and dust seals in cylinder head (16) (parts marked with O in the figure at right) by using an oil stone, so that seals are not damaged when they are being inserted.




1. Apply a coat of grease (or hydraulic oil) around the inner walls of cylinder head (16) and fitting grooves of the rod packings (shaded section).


- ★ Observe steps 2 and 3 below if backup ring (19) is attached to the U-packing.



2. Fit backup ring (19) into groove (B) by pressing it to a smaller size than inner diameter D.




3. Press in rod packing (14) until it fits snugly into groove **B**.
Install the rod packing in the specified direction.
★ Be careful to install rod packing facing in the right direction.




230F246

4. Assemble the rod packing into groove **B** by slightly pressing in its opposite side with a jig, as shown in the illustration.
★ Use a copper, aluminum, or plastic jig which is free of any sharp edge, etc, which may contact the rod packing.
In order to prevent the rod packing from being damaged, we recommend that you assemble the rod packing by hand without using the jig.




230F245

5. Check the internal circumference of the lip for any defects, and for the condition of the fit in the groove, while pressing the internal circumference of rod packing (14) against the external circumference by hand.





230F247

6. Immerse back-up ring (18) in 30° to 50°C hot water for two or three minutes.
7. Take back-up ring (18) out of the hot water and fit it over the cylinder head by stretching it slightly.
★ When assembling the cylinder head assembly, make sure that back-up ring (18) has first cooled down and returned to its original size.



230F249

8. Insert O-ring (17) into cylinder head (16).





125P390


9. Press bushing (15) into cylinder head (16) by using a Push tool, and then fit snap ring (14).

★ Take particular case to deform the bushing when press fitting.

10. Press-fit dust seal (13) into cylinder head (16) by using a push tool (3), and then fit snap ring (12).





125P389



230F251


ASSEMBLY OF PISTON ASSEMBLY

- ★ Remove any sharp edge, etc., from the fitting grooves of the piston ring (parts marked with O in the figure) by using an oil stone so that the piston ring is not damaged as it is being inserted. Make sure that these parts are free of burrs, etc.




230F252

1. Apply a coat of grease (or hydraulic oil) to the upper **A** face of the taper surface of piston (11).



230F253


2. First insert the circumferential part of pack ring (12) into the groove, and then assemble it by pressing in its opposite side by hand along the taper surface.



230F254


3. Immerse slipper seal (10) into 60° to 100°C hot water for at least 5 minutes so that it can easily be fitted onto piston (11).

4. First insert the circumferential part of slipper seal (10) into the groove, and then assemble the slipper seal into the groove by pressing in its opposite side by hand along the taper surface.



★ The following procedure may be observed in place of steps 3 and 4.

- 1) Using tool C, expand piston ring (10).
 - ★ After setting the piston ring in tool C, rotate the handle 8 to 10 times to expand.
- 2) Remove piston ring (10) from tool C and assemble on piston (11).



5. After fitting slipper seal (10), tighten the outer circumference of slipper seal (10) to forcedly contract it.

★ If slipper seal (10) is inserted into the cylinder tube with its outer diameter stretched, it may be damaged by the threaded part (circular cylinder), or it may be caught between the cylinder tube and the threaded part. For this reason, it is necessary to contract it by force.

● **Tightening procedure**

Set slipper seal (10) so that width **b** is set to groove width **B** of the protective cover, by using tightening jig **E**, as shown. Continue tightening it for at least 1 minute.




● **References:**

For low pressure hoses, the JUBILEE clamp is recommended.


(See the following table)

| Cylinder diameter | JUBILEE clamp parts No. |
|-------------------|-------------------------|
| φ50 – φ60 | 3 |
| φ70 – φ80 | 4 |
| φ90 – φ100 | 5 |
| φ110 – φ120 | 6 |
| φ130 – φ150 | 7 |
| φ160 – φ180 | 7½ |
| φ200 – φ225 | 9½ |



| Parts name | Q'ty per set | Remarks |
|--------------------|--------------|-----------------------------|
| ① Clamp | 1 | See the above table |
| ② Protective cover | 1 | For fixed rubber material |
| ③ Protective cover | 1 | For sliding rubber material |



6. Assemble back-up ring (13) onto piston (11).



7. Assemble wear ring (9) onto piston (11).




125P394

230F259

HYDRAULIC SYSTEM

64 MAINTENANCE STANDARD




| | |
|-----------------------------------|-------|
| Hydraulic control valve | 64- 2 |
| Hydraulic pump | 64- 8 |
| Hydraulic cylinder | 64-10 |

HYDRAULIC CONTROL VALVE

GD705A-4

3-SPOOL




F23AB205-1

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-----|-------------------------------------|-----------------------|---------------------|-------------------|----------------|-------------------|-------------------|
| | | Standard size | | Repair limit | | | |
| | | Free length x O.D. | Installed length | Installed load | Free length | Installed load | |
| 1 | Spool return spring | 55.7 x 22.3 | 26.5 | 10 kg | — | 8 kg | Replace spring |
| 2 | Poppet spring | 29.6 x 9.5 | 26.5 | 12.6 kg | — | 10.1 kg | |
| 3 | Main valve spring | 23.3 x 7.2 | 19 | 2 kg | — | 1.6 kg | |
| 4 | Check valve spring | 18.0 x 12.5 | 7.5 | 0.2 kg | — | 0.16 kg | |
| 5 | Plug tightening torque | 1.5 ± 0.5 kgm | | | | Adjusting | |
| 6 | Plug tightening torque | 7 ± 1 kgm | | | | | |
| 7 | Plug tightening torque | 7 ± 1 kgm | | | | | |
| 8 | Body joint bolt tightening torque | 5.75 ± 0.75 kgm | | | | | |
| 9 | Bolt tightening torque | 2.75 ± 0.75 kgm | | | | | |
| 10 | Main relief valve tightening torque | 5.5 ± 0.5 kgm | | | | | |
| 11 | Plug tightening torque | 7 ± 1 kgm | | | | | |

GD705A-4
4-SPOOL




F23B068-1

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-----|-------------------------------------|-----------------------|---------------------|-------------------|----------------|-------------------|-------------------|
| | | Standard size | | Repair limit | | | |
| 1 | Spool return spring | Free length x O.D. | Installed length | Installed load | Free length | Installed load | Replace spring |
| | | 55.7 x 22.3 | 26.5 | 10 kg | — | 8 kg | |
| 2 | Poppet spring | 29.6 x 9.5 | 26.5 | 12.6 kg | — | 10.1 kg | |
| 3 | Main valve spring | 23.3 x 7.2 | 19 | 2 kg | — | 1.6 kg | |
| 4 | Check valve spring | 18.0 x 12.5 | 7.5 | 0.2 kg | — | 0.16 kg | Adjusting |
| 5 | Plug tightening torque | 1.5 ± 0.5 kgm | | | | | |
| 6 | Plug tightening torque | 7 ± 1 kgm | | | | | |
| 7 | Plug tightening torque | 7 ± 1 kgm | | | | | |
| 8 | Body joint bolt tightening torque | 5.75 ± 0.75 kgm | | | | | |
| 9 | Bolt tightening torque | 2.75 ± 0.75 kgm | | | | | |
| 10 | Main relief valve tightening torque | 5.5 ± 0.5 kgm | | | | | |
| 11 | Plug tightening torque | 7 ± 1 kgm | | | | | |


GD705A-4
5-SPOOL



Unit: mm

| No. | Check Item | Criteria | | | | Remedy |
|-----|-------------------------------------|--------------------|------------------|----------------|-------------|----------------|
| | | Standard size | | Repair limit | | |
| 1 | Spool return spring | Free length x O.D. | Installed length | Installed load | Free length | Replace spring |
| | | 55.7 x 22.3 | 26.5 | 10 kg | — | |
| | | — | — | — | 8 kg | |
| 2 | Poppet spring | 29.6 x 9.5 | 26.9 | 12.6 kg | — | Replace spring |
| 3 | Main valve spring | 23.3 x 19.2 | 19 | 2 kg | — | |
| 4 | Check valve spring | 18.0 x 1.25 | 7.5 | 0.2 kg | — | |
| 5 | Plug tightening torque | 1.5 ± 0.5 kgm | | | | Adjusting |
| 6 | Plug tightening torque | 7 ± 1 kgm | | | | |
| 7 | Plug tightening torque | 7 ± 1 kgm | | | | |
| 8 | Body joint bolt tightening torque | 5.75 ± 0.75 kgm | | | | |
| 9 | Bolt tightening torque | 2.75 ± 0.75 kgm | | | | |
| 10 | Main relief valve tightening torque | 5.5 ± 0.5 kgm | | | | |
| 11 | Plug tightening torque | 7 ± 1 kgm | | | | |

GD705A-4
CIRCLE ROTATION




F23E101

Unit: mm

| No. | Check Item | Criteria | | | | | Remedy |
|-----|--|-----------------------|---------------------|-------------------|--------------|-------------------|-----------|
| | | Standard size | | | Repair limit | | |
| 1 | Main relief valve spring | Free length x O.D. | Installed length | Installed load | Free length | Installed load | Replace |
| | | 41.1 x 11.8 | 34 | 22 kg | 39.7 | 17.6 kg | |
| 2 | Tightening torque of plug | 7.0 ± 1 kgm | | | | | Adjusting |
| 3 | Tightening torque of check valve plug | 10.75 ± 1.75 kgm | | | | | |
| 4 | Tightening torque of main relief valve | 8.5 ± 1.5 kgm | | | | | |
| 5 | Tightening torque of body joint bolt | 6 ± 1 kgm | | | | | |
| 6 | Tightening torque of body joint bolt | 9 ± 1 kgm | | | | | |

GD705A-4
MODE CONTROL




F23E103

Unit: mm

| No. | Check Item | Criteria | | | | | Remedy |
|-----|--|--------------------|------------------|----------------|--------------|----------------|-----------|
| 1 | Clearance between spool and valve body | Standard size | | | | | |
| | | 14 | | | | | |
| 2 | Spool return spring | Standard size | | | Repair limit | | Replace |
| | | Free length x O.D. | Installed length | Installed load | Free length | Installed load | |
| | | 53.3 x 23.3 | 10 kg | 33.5 | — | 8 kg | |
| 3 | Detent spring | 30.7 x 7.7 | 5 kg | 23 | — | 4 kg | |
| 4 | Tightening torque of detent plug | 1.5 ± 0.5 kgm | | | | | Adjusting |
| 5 | Tightening torque of plug | 0.75 ± 0.25 kgm | | | | | |

GD705A-4
RIPPER (If equipped)




F23E104A

Unit: mm

| No. | Check Item | Criteria | Remedy |
|-----|---------------------------------------|------------------|-----------|
| 1 | Tightening torque of check valve plug | 10.75 ± 1.75 kgm | Adjusting |
| 2 | Tightening torque of plug | 7.0 ± 1 kgm | |
| 3 | Tightening torque of plug | 8.5 ± 1.5 kgm | |
| 4 | Tightening torque of body joint bolt | 6 ± 1 kgm | |
| 5 | Tightening torque of body joint bolt | 9 ± 1 kgm | |

HYDRAULIC PUMP

FOR WORK EQUIPMENT (LAR020 + LAR020) GD705R-4
(SAR050 + SAR050) GD705A-4




F23B03020

Unit: mm

| No. | Check Item | Criteria | | | | Remedy |
|-----|--|--|-------------------|------------------|-------------------|--------|
| | | Standard clearance | | Repair limit | | |
| 1 | Gear case to gear clearance | 0.1 – 0.15 | | 0.19 | | |
| 2 | Bushing I.D. to gear shaft clearance | 0.06 – 0.119 | | 0.20 | | |
| 3 | SAE10, Class CD at 50 ± 5°C | Standard value | | Repair limit | | |
| | | Pump speed (rpm) | Delivery (ℓ/min.) | Pump speed (rpm) | Delivery (ℓ/min.) | |
| | | 175 kg/cm ² LAR020 + LAR020 | 3500 | 67 | 3500 | |
| | 210 kg/cm ² SAR050 + SAR050 | 3000 | 138 | 3000 | 120 | |

FOR WORK EQUIPMENT (SAR050) GD705A-4




24F004

Unit: mm

| No. | Check Item | Criteria | | | | Remedy |
|-----|--|--------------------|-------------------|------------------|-------------------|--------|
| | | Standard clearance | | Clearance limit | | |
| 1 | Clearance between gear case and gear | 0.10 - 0.15 | | 0.19 | | |
| 2 | Clearance between bearing I.D. and gear shaft O.D. | 0.06 - 0.166 | | 0.20 | | |
| 3 | SAR050 (E010-CD 50°C 210 kg/cm ²) | Standard size | | Repair limit | | |
| | | Pump speed (rpm) | Delivery (ℓ/min.) | Pump speed (rpm) | Delivery (ℓ/min.) | |
| | | 3000 | 138 | 3000 | 120 | |

HYDRAULIC CYLINDER

GD705R-4



F23E04058

Unit: mm


| No. | Check Item | Criteria | | | | | Remedy |
|-----|--|-------------------------|-----------|------------------|--------------------|------------------|---------|
| | | Standard size | Tolerance | | Standard clearance | Clearance limit | |
| | Shaft | | Hole | | | | |
| 1 | Clearance between piston rod and bushing | Blade lift | 55 | -0.100 -0.174 | +0.163 +0.006 | 0.106 – 0.337 | Replace |
| | | Blade side shift | 50 | -0.080 -0.142 | +0.164 +0.007 | 0.087 – 0.306 | |
| | | Drawbar side shift | 50 | -0.100 -0.174 | +0.163 +0.006 | 0.106 – 0.337 | |
| | | Leaning | 50 | -0.080 -0.142 | +0.164 +0.007 | 0.087 – 0.306 | |
| | | Scarifier (If equipped) | 55 | -0.100 -0.174 | +0.163 +0.006 | 0.106 – 0.337 | |

Unit: mm

| No. | Check Item | Criteria | | | | | Remedy | |
|-----|---|-------------------------|---------------------------------------|------------------|--------------------|------------------|---------|-----------|
| | | Standard size | Tolerance | | Standard clearance | Clearance limit | | |
| | | | Shaft | Hole | | | | |
| 2 | Clearance between cylinder head support shaft and bushing | Blade lift | 90 | -0.05 -0.15 | ± 0 | 0.05 – 0.150 | Replace | |
| | | Blade side shift | 45 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | | |
| | | Drawbar side shift | 80 | -0.05 -0.15 | ± 0 | 0.050 – 0.150 | | |
| | | Leaning | 45 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | | |
| | | Scarifier (if equipped) | 50 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | | |
| 3 | Clearance between cylinder bottom shaft and bushing | Blade lift | 70 | -0.100 -0.174 | +0.074 0 | 0.100 – 0.248 | Replace | |
| | | Blade side shift | 45 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | | |
| | | Drawbar side shift | 80 | -0.05 -0.15 | ± 0 | 0.050 – 0.150 | | |
| | | Leaning | 45 | -0.025 -0.064 | +0.142 +0.080 | 0.106 – 0.206 | | |
| | | Scarifier (if equipped) | 50 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | | |
| 4 | Tightening torque for piston nut | Blade lift | 80 ± 8 kgm (Width across flats: 46) | | | | | Retighten |
| | | Blade side shift | 63 ± 6.3 kgm (Width across flats: 41) | | | | | |
| | | Drawbar side shift | 63 ± 6.3 kgm (Width across flats: 41) | | | | | |
| | | Leaning | 63 ± 6.3 kgm (Width across flats: 41) | | | | | |
| | | Scarifier (if equipped) | 80 ± 8 kgm (Width across flats: 46) | | | | | |
| 5 | Tightening torque for cylinder head | Blade lift | 69 ± 6.9 kgm | | | | | Retighten |
| | | Blade side shift | 60 ± 6 kgm | | | | | |
| | | Drawbar side shift | 60 ± 6 kgm | | | | | |
| | | Leaning | 60 ± 6 kgm | | | | | |
| | | Scarifier (if equipped) | 69 ± 6.9 kgm | | | | | |

HYDRAULIC CYLINDER

GD705A-4



F23E04059

Unit: mm

| No. | Check Item | Criteria | | | | | Remedy |
|-----|---|-------------------------|-----------|----------------------------------|--------------------|----------------------------------|---------|
| | | Standard size | Tolerance | | Standard clearance | Clearance limit | |
| | | | Shaft | Hole | | | |
| 1 | Clearance between piston rod and bushing | Blade lift | 55 | -0.100 -0.174 | +0.163 +0.006 | 0.106 – 0.337 | Replace |
| | | Blade side shift | 55 | -0.100 -0.174 | +0.163 +0.006 | 0.106 – 0.337 | |
| | | Drawbar shift | 55 | -0.100 -0.174 | +0.163 +0.006 | 0.106 – 0.337 | |
| | | Leaning | 45 | -0.030 -0.019 | +0.007 +0.152 | 0.026 – 0.182 | |
| | | Articulate | 55 | -0.100 -0.174 | +0.163 +0.006 | 0.106 – 0.337 | |
| | | Power tilt | 50 | -0.030 -0.142 | +0.164 +0.007 | 0.037 – 0.306 | |
| | | Ripper (If equipped) | 70 | -0.100 -0.174 | +0.271 +0.075 | 0.175 – 0.445 | |
| | | Scarifier (If equipped) | 55 | -0.100 -0.174 | +0.163 +0.006 | 0.106 – 0.337 | |
| 2 | Clearance between piston rod support shift (ball joint) and bushing (rod end) | Blade lift | 90 | - | - | - | Replace |
| | | Blade side shift | 50 | -0.05 (-0.025) -0.15 (-0.064) | +0.142 +0.080 | 0.130 – 0.292 (0.105 – 0.250) | |
| | | Drawbar shift | 90 | - | - | - | |
| | | Leaning | 50 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | |
| | | Articulate | 60 | -0.030 -0.076 | +0.174 +0.100 | 0.130 – 0.350 | |
| | | Power tilt | 60 | 0 -0.019 | 0 -0.015 | 0 – 0.004 | |
| | | Ripper (If equipped) | 75 | +0.035 0 | +0.174 +0.100 | 0.065 – 0.174 | |
| | | Scarifier (If equipped) | 50 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | |

(): For Serial No. 21086 and up

Unit: mm

| No. | Check Item | Criteria | | | | | Remedy | |
|-----|---|-------------------------|-----------------------------|----------------------|----------------------|--------------------|-----------|-------|
| | | Standard size | Tolerance | | Standard clearance | Clearance limit | | |
| | | | Shaft | Hole | | | | |
| 3 | Clearance between cylinder bottom yoke (Support, support shaft, support ball joint) and bushing (rod end) | Blade lift | 70 | -0.100 -0.174 | +0.271 +0.095 | 0.195 – 0.445 | Replace | |
| | | Blade side shift | 70 | -0.100 -0.174 | +0.271 +0.095 | 0.195 – 0.445 | | |
| | | (Blade side shift) | (50) | (+0.025) (+0.064) | (+0.142) (+0.080) | (0.105 – 0.206) | | (1.0) |
| | | Drawbar shift | 90 | – | – | – | | – |
| | | Leaning | 50 | -0.025 -0.064 | +0.163 +0.006 | 0.031 – 0.227 | | 1.0 |
| | | Articulate | 60 | -0.030 -0.076 | +0.174 +0.100 | 0.130 – 0.350 | | 1.0 |
| | | Power tilt | 75 | -0.100 -0.174 | +0.074 0 | 0.100 – 0.248 | | 1.0 |
| | | Ripper (If equipped) | 90 | +0.035 0 | +0.207 +0.120 | 0.085 – 0.207 | | 1.0 |
| | | Scarifier (If equipped) | 50 | -0.025 -0.064 | +0.142 +0.080 | 0.105 – 0.206 | | 1.0 |
| 4 | Tightening torque for piston nut | Blade lift | 145 ± 14.5 kgm (80 ± 8 kgm) | | | | Retighten | |
| | | Blade side shift | 145 ± 14.5 kgm (80 ± 8 kgm) | | | | | |
| | | Drawbar shift | 145 ± 14.5 kgm (80 ± 8 kgm) | | | | | |
| | | Leaning | 110 ± 11.0 kgm (80 ± 8 kgm) | | | | | |
| | | Articulate | 145 ± 14.5 kgm | | | | | |
| | | Power tilt | 145 ± 14.5 kgm | | | | | |
| | | Ripper (If equipped) | 405 ± 40.5 kgm | | | | | |
| | | Scarifier (If equipped) | 145 ± 14.5 kgm | | | | | |
| 5 | Tightening torque for cylinder head | Blade lift | 69 ± 6.9 kgm | | | | Retighten | |
| | | Blade side shift | 69 ± 6.9 kgm | | | | | |
| | | Drawbar shift | 69 ± 6.9 kgm | | | | | |
| | | Leaning | 69 ± 6.9 kgm | | | | | |
| | | Articulate | 95 ± 9.5 kgm | | | | | |
| | | Power tilt | 80 ± 8.5 kgm | | | | | |
| | | Ripper (If equipped) | 94.5 ± 10.5 kgm | | | | | |
| | | Scarifier (If equipped) | 69 ± 6.9 kgm | | | | | |

{ } : For Serial No. 21086 and up

WORK EQUIPMENT


71 STRUCTURE AND FUNCTION



| | |
|-------------------------------------|-------|
| Drawbar | 71- 2 |
| Blade and circle | 71- 4 |
| Circle rotation gear | 71- 6 |
| Lifter | 71- 8 |
| Lifter bracket control | 71-10 |
| Rear mount ripper | 71-13 |
| Scarifier | 71-14 |
| Main frame | 71-16 |
| Hydraulic control linkage | 71-18 |
| Blade accumulator system | 71-24 |

DRAWBAR

GD705R-4




F23E04060

The drawbar is an important device to support the circle and blade. When there is ball joint (2) wear, a shim (1) is used to adjust the clearance of the joint so that there will not be a large gap. The guides (8), (5) are in contact with the circle during revolutions at (a), (b), and (c).

Adjustment of the clearance of contacting parts is done by shims (9), (6) and adjustment bolt (7).

- 1. Shim
- 2. Ball joint
- 3. Nut
- 4. Drawbar
- 5. Guide
- 6. Shim
- 7. Bolt
- 8. Guide
- 9. Shim
- 10. Bolt
- 11. Bolt

GD705A-4




F23404023

- 1. Shim
- 2. Ball joint
- 3. Nut
- 4. Drawbar
- 5. Guide
- 6. Shim
- 7. Bolt
- 8. Guide
- 9. Shim
- 10. Bolt
- 11. Bolt

BLADE AND CIRCLE

GD705R-4



F23E04061

End bits (5) installed on the blade are designed so that they can be used twice. This is done by reversing them and installing them at the other end of the blade.


The cutting angle of the blade can be adjusted freely by sliding adjuster (7) using the lever in the operator's compartment.

Guide (10) acts as a bushing for the sliding parts when the blade is shifted to the side. If the clearance from the sliding parts is too large to allow precise finishing, replace the guide.

The amount of side shift of the blade can be adjusted by sliding bracket (1) to positions "b" or "c".

- 1. Bracket
- 2. Support
- 3. Blade shift cylinder
- 4. Blade
- 5. End bit
- 6. Power tilt cylinder
- 7. Adjuster
- 8. Cutting edge
- 9. Yoke
- 10. Guide
- 11. Nut
- 12. Bolt

GD705A-4






F23404024

- 1. Bracket
- 2. Support
- 3. Blade shift cylinder
- 4. Blade
- 5. End bit
- 6. Power tilt cylinder
- 7. Adjuster
- 8. Cutting edge
- 9. Yoke
- 10. Guide
- 11. Nut
- 12. Bolt

CIRCLE ROTATION GEAR

GD705R-4



View Z


F23B047A-1

The circle rotation gear is driven by an oil motor through coupling (3).

The joint (9) and circle pinion gear (7) are connected by a shear pin (10). If an abnormal torque is transmitted from the blade, the shear pin (10) is cut through at (a) and prevents breakage of the blade system.

- 1. Worm wheel
- 2. Worm gear
- 3. Coupling
- 4. Drain plug
- 5. Oil filler and oil level plug
- 6. Case
- 7. Gear (circle pinion gear)
- 8. Shaft
- 9. Joint
- 10. Shear pin
- 11. Plate
- 12. Bolt

GD705A-4



F23E086

★ Use CLASS-CD SAE90 gear oil for all seasons.




The circle rotation gear is driven by an oil motor through coupling (3).

The joint (11) and circle pinion gear (6) are connected by a shear pin (10). If an abnormal torque is transmitted from the blade, the shear pin (10) is cut through at (a) and prevents breakage of the blade system.


- 1. Drain plug
- 2. Worm gear
- 3. Coupling
- 4. Case
- 5. Worm wheel
- 6. Gear (circle pinion gear)
- 7. Shaft
- 8. Plate
- 9. Bolt
- 10. Shear pin
- 11. Joint
- 12. Pin
- 13. Lock plate
- 14. Oil filler plug

LIFTER


GD705R-4




Section B—B



Section D—D



Section A—A



Section C—C



F23E04063

There is a cylinder installed in the lifter for moving the blade device. Brackets (1) and (4) are installed by the guide which is welded to the main frame. They can be revolved by revolving the guide by extracting a pin (8) controlled from the operator's seat. There are three insertion holes altogether for the pin (8) stopping revolution. Holes (a) and (c) are used for the blade to make a bank cut to left or right.


This (b) gets used much more than other holes and a bushing (7) is used in it to make the clearance between the pin and the hole at a minimum. (This clearance amplifies the up and down movement of the blade.) Also, the clearance between the bracket and the guide welded to the frame can be adjusted with shims (2). Pin (6) combined with bolt (3) tightening force prevents bracket up and down slippage.

1. Bracket (Upper)
2. Shim
3. Bolt
4. Bracket (Lower)
5. Yoke
6. Pin
7. Bushing
8. Pin


GD705A-4




Section A - A



Section B - B



Section C - C




Section D - D

F23404025

- 1. Bracket (Upper)
- 2. Shim
- 3. Bolt
- 4. Bracket (Lower)
- 5. Yoke
- 6. Pin
- 7. Bushing
- 8. Pin

LIFTER BRACKET CONTROL

GD705R-4




232F141

The lifter bracket is secured to the main frame lifter bracket guide by pin (1). For bank-cutting operations, depress pedal (3), remove the pin, and turn the lifter bracket.

- 1. Pin
- 2. Cable
- 3. Pedal

GD705A-4



F23404027

Detail A


F23404026

The lifter bracket is fixed by pin (2). When setting in the bank cutting position, operate control lever (1). This uses compressed air to push piston (3). The pin can be removed and the bracket can then be rotated.

1. Lever (for bank control pin)
2. Pin
3. Piston
4. Spring
5. Air tube

LIFTER BRACKET CONTROL

GD705A-4 (Serial No. 31001 and up)





F23404027

The lifter bracket is fixed by pin (2). When setting in the bank cutting position, operate control lever (1). This uses compressed air to push piston (3). The pin can be removed and the bracket can then be rotated.


1. Lever (for bank control pin)
2. Pin
3. Piston
4. Spring
5. Air tube

REAR MOUNT RIPPER (If equipped)


GD705A-4




Section A-A




Section B-B



Section C-C



Section D-D



Section E-E


F23E087

Ripper lifting height and digging height can be adjusted with hydraulic cylinder (1). Since the point tips cut into the ground under the load of the ripper's heavy weight, the ripper easily performs heavy-duty digging work which cannot be done by the scarifier. Two kinds of points are selectively used: A short point for heavy-duty work and a long point for ordinary work.

1. Ripper cylinder
2. Pin
3. Bracket
4. Shank pin
5. Shank
6. Point

SCARIFIER (If equipped)

GD705R-4




The lifting height and digging depth of the scarifier can be changed by moving the connecting holes (a) and (b) of the rod (5) and pipe (6).

Also, the digging angle, lifting height and digging depth of the scarifier teeth (8) can be changed by moving bolt (9) into holes (e), (f) or (g) on the scarifier body. When in (g) position especially, the blade can be revolved 360°, when the scarifier teeth are extracted and the scarifier raised up.

Oilless bushing for bushing (10) is used.

- 1. Scarifier cylinder
- 2. Arm
- 3. Scarifier lift arm
- 4. Pin
- 5. Rod
- 6. Pipe
- 7. Scarifier body
- 8. Scarifier teeth
- 9. Bolt
- 10. Bushing
- 11. Wedge
- 12. Pin

GD705A-4



F23404064


The lifting height and digging depth of the scarifier can be changed by moving the connecting holes (a), (b) and (c) of the rod (5) and pipe (6).

Also, the digging angle, lifting height and digging depth of the scarifier teeth (8) can be changed by moving bolt (9) into holes (e), (f) or (g) on the scarifier body. When in (g) position especially, the blade can be revolved 360°, when the scarifier teeth are extracted and the scarifier raised up.

1. Scarifier cylinder
2. Arm
3. Scarifier lift arm
4. Pin
5. Rod
6. Pipe
7. Scarifier body
8. Scarifier teeth
9. Bolt
10. Wedge
11. Pin

MAIN FRAME


GD705R-4



F23E04065

- 1. Main frame
- 2. Cap

GD705A-4



F23E088


The frame can be articulated 26° both to right and left of the center by the articulate cylinder. (The articulation stopper is on the side of the frame.) Articulation is useful for reducing turning radius, for offset work, for getting out of mud and for the various corner operations.

Also, because the front frame is one unit the visibility of the work equipment is good.

- 1. Main frame
- 2. Cap

HYDRAULIC CONTROL LINKAGE


GD705R-4




F23E04066

When the steering post and tilt pedal (2) are pressed, it is possible to extract lock pin (1) and adjust the post for either a standing or sitting position.


1. Lock pin
2. Steering post tilt pedal
3. Blade lift R.H. lever
4. Leaning lever
5. Blade side shift lever
6. Drawbar shift lever
7. Circle reverse lever
8. Scarifier (If equipped)
9. Blade lift L.H. lever




Section A-A




View Y




View Z




Section E-E



Section B-B





Section C-C



Section D-D

F23E04067

GD705A-4 (Serial No. 21027 and up)




F23C01001


- Steering wheel and instrument panel tilting mechanism:
Rotate tilt lever (12) to loosen the lock, move to a suitable position, then tighten the lever.
The tilting angle can be adjusted steplessly 10°.
- Console box tilting mechanism:
Depress pedal to remove the dowel pin, and the console box can be adjusted in five stages.
- Control lever tilting mechanism:
Push down tilt lever (11) to remove the dowel pin, and the control lever can be adjusted in six stages.

In this way, the steering wheel and control levers can be set to the optimum position for the operator.


1. Blade lift R.H. lever
2. Leaning lever
3. Blade shift lever
4. Power tilt lever
5. OP lever
6. Articulate lever
7. Scarifier or Ripper lever (if equipped)
8. Drawbar shift lever
9. Circle rotation lever
10. Blade lift L.H. lever
11. Tilt lever
12. Tilt lever




Detail R




Detail Q



Detail O



Section A-A



Section B-B



Section C-C



Section D-D



Section E-E




Section F-F




Section G-G




Section H-H




Section H-H




Section J-J




Section K-K




Section L-L




Section M-M




Section N-N



Section O-O




Section P-P



View Z


F23C01002

GD705A-4 (Serial No. 31040 and up)




F23C01003


1. Blade lift R.H. lever
2. Scarifier lever (if equipped)
3. Leaning lever
4. Articulate lever
5. Drawbar shift lever
6. Circle rotation lever
7. Power tilt lever
8. Blade shift lever
9. Ripper lever (if equipped)
10. Blade lift L.H. lever
11. Tilt lever
12. Tilt lever




Section A-A



Section B-B





Section C-C




Section D-D



Section E-E




Section F-F




Section G-G




Section H-H




Section J-J




Section K-K




Section L-L




Section M-M





Section N-N




Section O-O



Detail R



View Y





Detail Q

F23C01004


BLADE ACCUMULATOR SYSTEM (If equipped)

GD705A-4

NAMES OF COMPONENT PARTS



View Z




Detail solenoid valve

F23E078


- | | | |
|----------------------|----------------|-------------|
| 1. Bolt | 6. Bolt | 11. Tube |
| 2. Bolt | 7. Accumulator | 12. Bracket |
| 3. Pilot check valve | 8. Clip | 13. Nipple |
| 4. Solenoid valve | 9. Valve | 14. Tube |
| 5. Cover | 10. Nipple | 15. Bracket |

ACCUMULATOR HYDRAULIC CIRCUIT DIAGRAM





F23E079

ACCUMULATOR WIRING DIAGRAM




23BF005



F23E081

STRUCTURE AND FUNCTION




23BF008

FUNCTION

When oil pressure is applied from the blade cylinder, the pressurized oil flows to the accumulator through the solenoid valve, pushing valve (6). This in turn pushes valve (4), allowing the oil to flow into shell (2) from the blade cylinder. Thereby, bladder (3) is compressed. Consequently, the shock imposed on the blade cylinder is reduced by the compressible amount of the bladder. When the oil pressure in the cylinder drops, the bladder expands by the gas pressure in bladder (3), allowing the

oil in the shell to drain out until the oil pressure in the shell balances that from the blade cylinder side. At this time, valve (5) on the underside of the accumulator closes throttling the return oil. This prevents the oil in shell (2) from flowing out abruptly and prevents the bladder from striking against the inside of the shell. The flow of oil in the accumulator hydraulic circuit is repeated smoothly to reduce the shock imposed on the blade.

INSTALLATION PROCEDURE



View Z

Detail solenoid valve


F23E078

INSTALLATION PROCEDURE

1. Install valve (9) and elbow on accumulator body (7).
2. Hold the accumulator body with clip (8) and temporarily attach the accumulator body to the frame with bolts (6) and washers.
3. Temporarily attach solenoid valve bracket (12) to the frame bracket (15) with bolts (2) and washers.
4. Connect nipple (13), which has nipples for tubes (14) and (11) on the underside of solenoid valve bracket, to nipple in advance, and tighten them together.
5. Since the system set up according to this procedure must be provided on each side of the frame, follow the above procedure again to form the same system on the other side of the frame.
6. After connecting the piping, tighten the temporarily attached portions positively.
7. Secure solenoid valve (4) to the solenoid valve bracket (12).
8. Provide the electrical wiring, referring to the accumulator wiring diagram on page 61-64.

WORK EQUIPMENT

72 TESTING AND ADJUSTING



| | |
|--|------|
| Inspection table | 72-2 |
| Work equipment control lever stroke and operating force | 72-3 |
| Hydraulic drift of blade | 72-3 |
| Measuring blade sinking amount | 72-3 |
| Checking hydraulic oil pressure | 72-4 |
| Adjusting oil pressure | 72-5 |
| Charging blade accumulator with gas | 72-6 |

INSPECTION TABLE

(): GD705A-4 Serial No. 31001 and up


| Item | | Test Condition | Standard | | | | | |
|--|---|--|---|-----------|----------------------------|--|----------------|----------------|
| | | | GD705R-4 | GD705A-4 | | | | |
| Stroke | Work equipment control lever | Blade lift left, right | Engine stopped, stroke at the tip of the lever | 40 ± 5 mm | 40 ± 10 mm | | | |
| | | Blade side shift | Engine stopped, stroke at the tip of the lever | 40 ± 5 mm | 40 ± 10 mm | | | |
| | | Drawbar shift | Engine stopped, stroke at the tip of the lever | 40 ± 5 mm | 40 ± 10 mm | | | |
| | | Circle rotation | Engine stopped, stroke at the tip of the lever | 42 ± 5 mm | 45 ± 10 mm (40 ± 10 mm) | | | |
| | | Power tilt | Engine stopped, stroke at the tip of the lever | — | 45 ± 10 mm | | | |
| Operating force | Work equipment control lever | | Maximum value until just before stroke end | Max. 5 kg | Max. 5 kg | | | |
| | Performance | 1. Blade | Oil temperature: 40 ± 5°C When engine at rated rotation, the speed of lifting or lowering the blade with the lower edge of the blade 50 – 150 mm above the ground. | | | | | |
| | | 1-1. Blade lifting speed (rising) | | | | 237 ± 9.5 mm/s | 210 ± 8.4 mm/s | |
| | | 1-2. Blade lifting speed (lowering) | | | | 144 ± 5.8 mm/s | 140 ± 5.6 mm/s | |
| | | 1-3. Speed of cross-feed by circle movement - left | | | | When engine at rated rotation and the height of the lower edge of the blade 100 mm, speed of left and right side shifting by a level circle movement of 200 mm under standard position. | 215 ± 8.6 mm/s | 120 ± 4.8 mm/s |
| | | | | | | | 124 ± 5.0 mm/s | 180 ± 7.2 mm/s |
| | | 1-4. Speed of cross-feed by circle movement - right | | | | | | |
| | | 1-5. Speed of side shift in rotation to circle - left | | | | When engine at rated rotation and the height of the lower edge of the blade 100 mm, speed of the left and right side shifting in rotation to a circle of a level distance of 200 mm under standard position. | 130 ± 5.2 mm/s | 140 ± 5.6 mm/s |
| | | 1-6. Speed of side shift in rotation to circle - right | | | | | 210 ± 8.4 mm/s | 220 ± 8.8 mm/s |
| | | 1-7. Turning speed by circle rotation | | | | Angle speed with engine at rated rotation speed | 11 ± 0.66°/s | 14.5 ± 0.87°/s |
| 1-8. Hydraulic drift of blade (hanging down) | Amount of lowering of cylinder when the blade is suspended symmetrically perpendicular to the machine | Max. 10 mm/10 min. | Max. 10 mm/10 min. | | | | | |
| 1-9. Hydraulic drift of machine (support by blade) | Amount of cylinder sinking when the lower edge of the blade is in contact with the ground and the front wheels floating | Max. 20 mm/10 min. | Max. 20 mm/10 min. | | | | | |

WORK EQUIPMENT CONTROL LEVER STROKE AND OPERATING FORCE

WORK EQUIPMENT CONTROL LEVER STROKE CHECK AND ADJUSTMENT

Use a convex rule ① and measure the operating length from the center of the knob of lever (1).

- ★ Measure with engine stopped.
- ★ The stroke of work equipment control lever is determined by the spool stroke of the control valve, but the neutral position of each lever is adjusted by each rod.




P23EC235

CHECK AND ADJUSTMENT OF EACH WORK EQUIPMENT CONTROL LEVER OPERATING FORCE

Use push-pull scale ② to measure maximum value from the tip of lever (1) to just before the stroke end.


- ★ Measure with engine stopped.
- ★ The operating force of the work equipment control lever is determined by the spring load of the spool on the control valve side. When the operating force is outside standard value, check the movement of the connecting rod. If it is normal disassemble the control valve and check the movement of the spool.



P23EC236

HYDRAULIC DRIFT OF BLADE

1. Start engine and after the pressure test, bring hydraulic oil temperature to the $40 \pm 5^{\circ}\text{C}$ range.
2. Raise the blade 300 mm from the ground and at right angles to the machine and equidistant to right and left.
3. Stop the engine and leave for 10 minutes.
Use a convex rule ① to measure the amount the cylinder piston rod has dropped.



P23404027

MEASURING BLADE SINKING AMOUNT

1. Start engine after the pressure test, bring hydraulic oil temperature to the $40 \pm 5^{\circ}\text{C}$ range.
2. Lower blade until its bottom edge touches the ground, push the cylinder and float the front wheels about 300 mm off the ground.
3. Stop the engine and leave for 10 minutes.
Use a convex rule ① to measure at the cylinder the amount of sinking.

CHECKING HYDRAULIC OIL PRESSURE

Special tool


| | Part number | Part name | Q'ty |
|---|--------------|------------------|------|
| A | 790-301-1103 | Hydraulic tester | 1 |




After stopping the engine, loosen slowly the cap of the hydraulic tank to release the remaining oil pressure from the hydraulic tank.

1. Remove measuring plugs (1), (2) and install oil pressure gauge **A** (for 350 kg/cm²).
 - ★ In order to prevent oil spurting out when the plug is removed, remove after operating the control lever.
2. Start engine and when the hydraulic oil temperature enters 35 to 45°C range, operate the lever of the circuit to be measured and measure the relief pressure.


GD705R-4




GD705A-4




GD705A-4



GD705A-4




GD705R-4



ADJUSTING OIL PRESSURE

GD705R-4


- ★ If hydraulic pressure is not the standard value (175 kg/cm²), adjust as follows.
 - ★ Remove the cap nut (2), loosen the lock nut (3), and confirm that a few threads of the adjustment screw (4) are screwed into the pilot section. Using a screwdriver, set the adjustment screw (4) as follows.
1. Run the pump at a low speed of about 1/4 of its maximum rpm. However, the pump must be kept at a reasonable speed when the relief set pressure is applied to the pump.
 2. Move one plunger of the control valve through its full stroke and read the pressure from the pressure gauge.
 3. Turn the adjustment screw (4) **CLOCKWISE** until the required set pressure is attained.
 4. While pressing the adjustment screw, tighten the lock nut (3). Install the cap nut (2) and tighten it.
 5. The pressure set in the above manner can be obtained when the pump is checked on the machine with the engine running at full speed.



F23E04075

GD705A-4

- ★ When hydraulic pressure is outside standard value (175 kg/cm²), adjust according to the following procedure.
1. Loosen nut (3), turn adjusting screw (4) and adjust the pressure of the internal spring (5).
 - ★ When turned to the right, hydraulic pressure rises.
 - When turned to the left, hydraulic pressure falls.
 2. After adjustment follow the procedure of the item on checking work equipment hydraulic pressure to confirm that hydraulic pressure is within standard value.




F23BB025

CHARGING BLADE ACCUMULATOR WITH GAS

Special tool

| | Part number | Part name | Q'ty |
|---|--------------|-------------------|------|
| A | 792-610-1700 | Charging assembly | 1 |



234F1144


! Always use nitrogen when charging the accumulator with gas.

1. Remove plug (1) from the accumulator, then install charging assembly A.
Size of joint for connecting accumulator: TV8
2. When installing the charging valve, tighten valve (2) fully and open valve (3) fully.
3. After installing charging valve assembly A, tighten valve (3) gradually and the charging pressure of the gas in the accumulator will be shown on pressure gauge (4).

! Charging pressure: $20 \begin{smallmatrix} +1 \\ 0 \end{smallmatrix} \text{ kg/cm}^2$


If pressure gauge (4) does not reach 20 kg/cm^2 , loosen valve (2) gradually, and charge with gas from the cylinder until pressure gauge (4) reaches 20 kg/cm^2 .

If the pressure gauge registers above 20 kg/cm^2 , remove hose (5). Then gradually loosen valve (2) to release gas from the accumulator into the atmosphere and adjust to 20 kg/cm^2 .



234F1145


Accumulator joint



234F1146

WORK EQUIPMENT

73 DISASSEMBLY AND ASSEMBLY



BLADE ASSEMBLY

Removal and installation 73-2

CIRCLE ROTATION GEAR AND HYDRAULIC

OIL MOTOR ASSEMBLY

Removal and installation 73-3

Disassembly 73-4

Assembly 73-6

REMOVAL OF BLADE ASSEMBLY



Start engine, operate the control lever to raise the work equipment (approx. 200 mm).

Set a block (approx. 780 mm) under the circle to support it securely.

1. Operate the control lever and extend blade side shift cylinder piston rod (1) to pull out blade (2).
2. Remove cover (3).
3. Sling center of blade side shift cylinder, disconnect bracket (4) from blade, and fully retract piston rod.
- ★ Support piston rod of blade cylinder with block (2) to prevent it from being damaged.
4. Raise blade (2) with a crane, slide the sling position of the wire to the center of the blade, and dismount it.



Blade assembly: Approx. 900 kg (GD705R-4)
Approx. 850 kg (GD705A-4)


INSTALLATION OF BLADE ASSEMBLY

1. Raise center of blade (2) and set position it to blade support part.
2. While sliding the wire, operate the control lever to extend the cylinder piston rod, and push it in until it reaches a position where it can be connected.




Blade guide rail (upper, lower): Grease (G2-LI)


3. Raise blade side shift cylinder with a crane, start engine and operate the control lever to extend piston rod (1).
4. Install bracket (4) on blade (2).
5. Raise blade and pull out block.



P23EC209



P23BB180



P23BB181

REMOVAL OF CIRCLE ROTATION GEAR AND HYDRAULIC OIL MOTOR ASSEMBLY

1. Disconnect tube (1), (2).
2. Remove holder (3) and shim (4).
3. Remove shear pin (5) and remove joint (6).
4. Remove mounting bolt (7) and tap dowel pin (8) out from below.
5. Using eye bolt ① (Thread dia. = 10 mm, Pitch = 1.5 mm), raise circle rotation gear • hydraulic oil motor assembly (9) and remove it.



Hold the circle rotation gear • hydraulic oil motor assembly by hand.








Circle rotation gear • hydraulic oil motor assembly: Approx. 100 kg (GD705R-4)
Approx. 176 kg (GD705A-4)


6. Remove spacer (11).

INSTALLATION CIRCLE ROTATION GEAR AND HYDRAULIC OIL MOTOR ASSEMBLY

1. Install spacer (11) on circle rotating gear • hydraulic oil motor assembly (9).
2. Screw in eye bolt ① to circle rotation gear • hydraulic oil motor assembly (9), raise it with a crane, align it to gear (10) and slowly mount ass'y.
3. Tighten mounting bolt (7) and tap in dowel pin (8).
4. Install joint (6) and fix it to shear pin (5).
5. Install holder (3).
 - ★ Adjust length A with shims dimension:
 - 1.0 mm (GD705R-4)
 - 0.1 to 0.5 mm (GD705A-4)
 - ★ Bend lock plate securely.
6. Connect tubes (2), (1).



DISASSEMBLY OF CIRCLE ROTATION GEAR AND HYDRAULIC OIL MOTOR ASSEMBLY



1. Draining oil


Remove plug (1) and drain oil



Circle rotation gear: Approx. 4ℓ

2. Circle rotation gear · hydraulic oil motor ass'y


Remove bolt (2), and dismount hydraulic oil motor assembly (4) from circle rotation gear assembly (3).



233P170

3. Coupling

Remove coupling (5).



73P013

4. **Bolt, washer**
Remove bolt (6) and washer (7) from shaft of hydraulic oil motor ass'y.


5. **Plate (GD705A-4 only)**
Remove plate (8).

6. **Cover**
Remove cover (9).


7. **Housing**
Remove shim (12) and housing (11) from case (10).

8. **Worm gear • Bearing ass'y**
1) Remove worm gear • bearing ass'y (13).
2) Remove bearing (15) from shaft (14).

9. **Worm wheel shaft ass'y**
1) Remove worm wheel shaft assembly (16).
2) Remove lock plate and remove gear (18) from shaft (17).




73P014




P23BB184

73P016




233P172


73P018



233P173




233P174



73P019


ASSEMBLY OF CIRCLE ROTATION GEAR AND HYDRAULIC OIL MOTOR ASSEMBLY



F23EC037


1. Worm gear • bearing assembly

- 1) Using press-fit tool ($\phi 50$), press fit bearing (15) on shaft (14).




73P019

- 2) Insert worm gear • bearing ass'y (13) into case.




73P018



233P172

2. Housing


- 1) Attach shim (12) to housing (11) and install it in case.
 - ★ Fix O-ring in housing.
 - ★ Adjust rotating torque with shim.
 - ★ Rotating torque: 0.35 to 0.8 mm
- 2) Check the number of shims, loosen bolt of housing side, and pull out housing from case a little.
 - ★ Remove worm gear • bearing ass'y from outer race of bearing.




73P026

3. Worm wheel shaft assembly


- 1) Using push tool kit ① ($\phi 65$), press fit bushing (19) to case (10).
- 2) Using push tool kit ①, press fit bushing (20). Again using push tool kit ② ($\phi 62$), press fit oil seal (21).
 - ★ Oil seal lip: Grease (G2-L1)
- 3) Install gear (18) to shaft (17) and fix it with a lock plate.
 - ★ Bend lock plate securely.
- 4) Install worm wheel shaft assembly (16).
 - ★ Mesh teeth of the worm gear and worm wheel, tighten bolt on the housing side.
 - ★ Insert washers (22), (23) securely above and below the worm wheel shaft.




73P022




73P023




73P024




233P176



F23EC038



233P174




233P173

4. Plate (GD705A-4 only)

Install plate (8) on hydraulic oil motor assembly (4).

- ★ Fix O-ring to plate.
 - ★ From the plate side, attach a gasket ($t = 0.8$ mm), shim ($t = 0.5$ mm), and gasket ($t = 0.3$ mm) in order between plate and hydraulic oil motor.
- Coat liquid gasket (LG-1) so that the gasket ($t = 0.8$ mm) will contact only the face of the plate.



73P014


5. Washer · bolt

Install washer (7) and bolt (6) to hydraulic oil motor assembly.

6. Coupling

Install coupling (5) to shaft.


- ★ Insert spring pin in coupling hole.



73P013

7. Circle rotation gear · hydraulic motor assembly

Fix circle rotation gear assembly (3) and hydraulic oil motor assembly (4) with bolt (2).



233P170

8. Oil supply

Tighten drain plug (1) and refill engine oil to specified level.




Circle rotation gear case: Approx. 4ℓ

9. Cover

Fix O-ring and install cover (9).


- ★ Coat liquid gasket (LT-2) bolts of case tap protrusion part at worm gear side.



P23BB184

WORK EQUIPMENT


74 MAINTENANCE STANDARD



| | |
|--------------------------------|-------|
| Blade and circle | 74- 2 |
| Drawbar | 74- 3 |
| Blade lifter bracket | 74- 6 |
| Circle rotation gear | 74- 8 |
| Scarifier | 74-10 |
| Rear mount ripper | 74-12 |

BLADE AND CIRCLE

GD705R-4




F23E04068

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-----|---|---|------------------|-------------|--------------------|---------|---------------------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| | Shaft | | Hole | | | | |
| 1 | Clearance between blade shift cylinder shaft and adjuster | 45 | -0.025 -0.064 | +0.039 0 | 0.025 - 0.103 | 0.5 | Replace shaft or adjuster |
| 2 | Wear of cutting edge | From moldboard to edge: Max. 10 | | | | Replace | |
| 3 | Wear of side edge | Repair limit: Side surface: 22 From moldboard to edge: Max. 10 | | | | Replace | |
| 4 | Wear of blade rail | Repair limit: Height: 75 Thickness: 22 | | | | Replace | |
| 5 | Wear of blade rail guide | Repair limit: 10 | | | | | |

GD705A-4




F23404029

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-------|--|---|------------------|-------------|--------------------|---------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between blade shift cylinder support yoke and adjuster | 80 | -0.030 -0.076 | +0.030 0 | 0.030-0.106 | 0.5 | Replace |
| 2 | Wear of cutting edge | Max. 10 mm (from blade base) | | | | Replace | |
| 3 | Wear of side edge | Clearance limit: Side face 25 Max. 10 mm (from blade base) | | | | | |
| 4 | Wear of blade rail | Repair limit: Height 105 Thickness 22 | | | | | |
| 5 | Wear of blade rail guide | Repair limit: 10 | | | | | |

DRAWBAR

GD705R-4




F23E04069

Unit: mm

| No. | Check Item | Criteria | | | | Remedy |
|-------|--------------------------------------|--------------------|------------------|-----------------|--------------------|--------|
| | | Standard size | Tolerance | | Standard clearance | |
| Shaft | Hole | | | | | |
| 1 | Wear of drawbar ball joint end | 120 | -0.120 -0.297 | +0.180 0 | 0.12 - 0.477 | - |
| 2 | Clearance between circle and drawbar | Standard clearance | | Clearance limit | | |
| | | 1.5 | | 1.0 - 2.0 | | |

GD705A-4






F23404028

Unit: mm


| No. | Check Item | Criteria | | | | Remedy |
|-----|--------------------------------------|--------------------|----------------|-----------------|--------------------|--------|
| | | Standard size | Tolerance | | Standard clearance | |
| | Shaft | | Hole | | | |
| 1 | Wear of drawbar ball joint end | 150 | -0.05 -0.15 | +0.1 0 | 0.05 – 0.25 | – |
| 2 | Clearance between circle and drawbar | Standard clearance | | Clearance limit | | |
| | | 1.5 | | 1.0 – 2.0 | | |

BLADE LIFTER BRACKET


GD705R-4




Section A-A



Section B-B



Section C-C





Section D-D

F23E04070


Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-------|---|------------------------------|------------------|------------------|--------------------|---------------------------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between yoke and bushing | 85 | -0.036 -0.090 | +0.207 +0.120 | 0.156 – 0.297 | 0.6 | Replace bushing |
| 2 | Clearance between blade cylinder (bottom side) yoke and bushing | 70 | -0.100 -0.174 | +0.074 0 | 0.100 – 0.248 | 0.5 | |
| 3 | Wear of lifter bracket | Standard shim thickness: 2.0 | | | | Adjust or replace bracket | |


GD705A-4




Section A – A



Section B – B



Section C – C



Section D – D



F23404030

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-------|--|-------------------------------|------------------|------------------|--------------------|---------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between yoke and bushing | 85 | -0.036 -0.090 | +0.071 +0.001 | 0.037 – 0.161 | 0.6 | Replace |
| 2 | Clearance between blade side shift cylinder bottom side yoke and bushing | 70 | -0.100 -0.174 | +0.074 0 | 0.100 – 0.248 | 1.0 | |
| 3 | Wear of lifter | Standard thickness of shim: 2 | | | | Replace | |
| 4 | Axial clearance of yoke | Standard clearance | | Clearance limit | | Replace | |
| | | 0.3 – 0.8 | | 1.7 | | | |

CIRCLE ROTATION GEAR

GD705R-4




View Z

F23B047A-1

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-------|--|--------------------|------------------|------------------|--------------------|--------------------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between worm wheel shaft and bushing | 65 | -0.030 -0.060 | +0.057 +0.010 | 0.040 – 0.117 | 0.5 | Replace bushing |
| 2 | Backlash between worm and worm wheel | Standard clearance | | Clearance limit | | Replace worm wheel | |
| | | 0.3 – 0.4 | | 2.0 | | | |
| 3 | Wearing of pinion pin | Standard size | | Repair limit | | Replace | |
| | | 25 | | 20 | | | |

GD705A-4




F23E110

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-------|---|--|------------------|------------------|--------------------|---------|--------------|
| | | Standard size | Tolerance | | Standard clearance | | Repair limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between worm gear shaft and bushing | 65 | -0.030 -0.060 | +0.057 +0.010 | 0.040-0.117 | 0.3 | Replace |
| 2 | Clearance between worm gear shaft and bushing | 65 | +0.035 +0.005 | +0.226 +0.069 | 0.035-0.221 | 0.3 | |
| 3 | Backlash between worm and worm wheel | Standard clearance | | Clearance limit | | Replace | |
| | | 0.3 - 0.5 | | 2.0 | | | |
| 4 | Clearance between pinion and wear plate | 0.1 - 0.5 | | 0.6 | | Adjust | |
| 5 | Wear of pinion gear | Standard size | | Repair limit | | Replace | |
| | | 25 | | 20 | | | |
| 6 | Preload of worm shaft bearing | Starting torque 0.5 - 1.0 kgm (when worm wheel is not meshed) | | | | Adjust | |
| 7 | Tightening torque of filler plug | 9.5 - 12.5 kgm | | | | | |
| 8 | Tightening torque of drain plug | 9.5 - 12.5 kgm | | | | | |

SCARIFIER (If equipped)

GD705R-4




F23E04072

Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-------|-------------------------------------|---------------|------------------|--------------|--------------------|---------------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between shaft and bushing | 90 | -0.036 -0.090 | +0.035 0 | 0.036 - 0.125 | 0.7 | Replace bushing |
| 2 | Wear of tooth | Standard size | | Repair limit | | Replace tooth | |
| | | 450 | | 330 | | | |

GD705A-4




F23404065

Unit: mm

| No. | Check Item | Criteria | | | | | Remedy |
|-------|-------------------------------------|------------------|------------------|------------------|--------------------|-----------------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | Clearance limit | |
| Shaft | Hole | | | | | | |
| 1 | Clearance between shaft and bushing | 110 | -0.036 -0.090 | +0.207 +0.120 | 0.156 – 0.297 | 0.7 | Replace bushing |
| 2 | Wear of ball joint | 70 | -0.05 -0.15 | +0.1 0 | 0.05 – 0.25 | 0.5 | Adjust shim |
| 3 | Wear of tooth | Standard size | | Standard | Repair limit | Replace tooth | |
| | | Standard | | 450 | 330 | | |
| | | With point tooth | | 450 | 410 | | |

REAR MOUNT RIPPER (If equipped)


GD705A-4



F23E111A
Unit: mm

| No. | Check Item | Criteria | | | | Remedy | |
|-------|-----------------------------------|---------------|------------------|------------------|--------------------|---------|-----------------|
| | | Standard size | Tolerance | | Standard clearance | | Clearance limit |
| Shaft | Hole | | | | | | |
| 1 | Clearance between pin and bushing | 60 | -0.025 -0.055 | +0.046 0 | 0.025-0.101 | 0.5 | Replace |
| 2 | Clearance between pin and bushing | 60 | -0.025 -0.055 | +0.046 0 | 0.025-0.101 | 0.5 | Replace |
| 3 | Clearance between pin and bushing | 75 | -0.030 -0.076 | +0.089 +0.035 | 0.065-0.165 | 0.5 | Replace |
| 4 | Wear of point | Standard size | | Repair limit | | Replace | |
| | | 290 | | 150 | | | |

81 ELECTRIC SYSTEM



| | |
|--|-------|
| Battery handling | 81- 2 |
| Electric wire code | 81- 3 |
| Electrical wiring diagram | 81- 4 |
| Electrical circuit diagram | 81- 8 |
| Electrical circuit diagram for cab | 81-14 |
| Wiring diagram for cab | 81-15 |

BATTERY HANDLING

- Coat vaseline or grease on the battery terminals after connecting cords to the terminal posts. Do not allow vaseline or grease to adhere to the contact surfaces between the terminal posts and cords. Poor contact due to vaseline or grease will make it difficult for the engine to start.
- ★ When a battery removed from the machine is to be reinstalled, wipe the terminals with a clean cloth to thoroughly remove vaseline or grease.
- Fix the battery securely to the machine body. If loosely fitted to the machine, the battery will dance during running of the machine on rough ground, thus causing damage to the electrodes and early deterioration of the battery. On the other hand, excessive tension to the battery mounting bolts may cause breakage of the electrolyte container. "No Fire"
- When connecting a charger to the battery, connect the charger positive lead to the battery positive terminal and the charger negative lead to the battery negative terminal.
- During battery charging, the cathode issues hydrogen gas and the anode issues oxygen gas, both of which are scattered in the air through a small hole in the electrolyte filler plug for each cell. The mixture of the two gases is explosive and should be kept far away from fire.
- ★ Do not attempt under any circumstances to light a match or a lighter to check the electrolyte level in a battery in a dark place.
- "No Sparking"
 - The battery may spark if a tool is carelessly placed on the battery over two terminals. If a spark occurs, an instantaneous large current flow will cause damage to the electrodes. Causing a battery to spark intentionally to check the degrees of battery charge, which may sometimes be performed by uniformed persons, should be absolutely avoided.
- When the battery is not used for a long time, remove the battery from the machine and store it indoors. Check the specific gravity of the battery from time to time during storage and, if necessary, recharge it. A battery in storage loses its charge due to its self-discharge property and, therefore, must be recharged monthly in summer or every two months in winter.
- Specific gravity of the electrolyte
 - Battery charging rate can be determined by measuring the specific gravity of the electrolyte.
- When connecting a booster battery, be certain to connect the negative battery terminals together and the positive battery terminals together.



F23AB077

ELECTRIC WIRE CODE

In the wiring diagrams, various colors and symbols are employed to indicate thickness of wires.

Example: 05WB indicates a cable having a nominal number 05 and white coating with black stripe.

Classification by thickness


| Nominal number | Copper wire | | | Cable O.D. (mm) | Current rating (A) | Circuits applied |
|----------------|-------------------|---------------------|----------------------------------|-----------------|--------------------|---|
| | Number of strands | Dia. of strand (mm) | Cross section (mm ²) | | | |
| 01 | 11 | 0.32 | 0.88 | 2.4 | 12 | Starting, lighting, signal and instrument |
| 02 | 26 | 0.32 | 2.09 | 3.1 | 20 | Lighting, signal and instrument |
| 05 | 65 | 0.32 | 5.23 | 4.6 | 37 | Charging and signal |
| 15 | 84 | 0.45 | 13.36 | 7.0 | 59 | Starting (Glow plug) |
| 40 | 85 | 0.80 | 42.73 | 11.4 | 135 | Starting |
| 60 | 127 | 0.80 | 63.84 | 13.6 | 178 | Starting |
| 100 | 217 | 0.80 | 109.1 | 17.6 | 230 | Starting |


Classification by color and code

| Priority | Circuits Classification | Starting circuit | Charging circuit | Lighting circuit | Signal circuit | Instrument circuit | Other | |
|----------|-------------------------|------------------|------------------|------------------|----------------|--------------------|----------------|---------------|
| | | 1 | Primary | Code B | W | R | G | Y |
| | | Color | Black | White | Red | Green | Yellow | Blue |
| 2 | Auxiliary | Code | BW | WR | RW | GW | YR | LW |
| | | Color | Black & White | White & Red | Red & White | Green & White | Yellow & Red | Blue & White |
| 3 | | Code | BY | WB | RB | GR | YB | LR |
| | | Color | Black & Yellow | White & Black | Red & Black | Green & Red | Yellow & Black | Blue and Red |
| 4 | | Code | BR | WL | RY | GY | YG | LY |
| | | Color | Black & Red | White & Blue | Red & Yellow | Green & Yellow | Yellow & Green | Blue & Yellow |
| 5 | | Code | — | WY | RG | GB | YL | LB |
| | | Color | — | White & Yellow | Red & Green | Green & Black | Yellow & Blue | Blue & Black |
| 6 | | Code | — | WG | RL | GL | YW | |
| | | Cblor | — | White & Green | Red & Blue | Green & Blue | Yellow & White | |

ELECTRICAL WIRING DIAGRAM

GD705R-4





1. Water temperature gauge
2. Battery charging lamp
3. Parking brake pilot lamp
4. Speedometer
5. Turn signal, Dimmer switch (If equipped)
6. Fuel gauge
7. Engine oil pressure gauge
8. Head lamp switch
9. Buzzer
10. Horn relay
11. Safety switch
12. Starting switch
13. Heater signal
14. Working lamp switch (If equipped)
15. Yellow rotating lamp switch (If equipped)
16. Panel lamp
17. Service meter
18. Fuse box
19. Back-up lamp switch (If equipped)
20. Turn signal relay (If equipped)
21. Horn
22. Turn signal
23. Combination lamp (Front) (If equipped)
24. Working lamp (If equipped)
25. Parking brake switch
26. Buzzer switch
27. Heater relay
28. Fuel gauge unit
29. Battery relay
30. Oil pressure gauge unit
31. License plate lamp (If equipped)
32. Water temperature gauge
33. Back-up lamp (If equipped)
34. Combination lamp (Rear) (If equipped)
35. Vacuum switch
36. Back-up buzzer (If equipped)
37. Starting motor
38. Battery
39. Speedometer take out part
40. Stop lamp switch
41. Dust indicator


F23E04073

ELECTRICAL WIRING DIAGRAM


GD705A-4

Serial No. 21027 and up


Serial No. 31040 and up




View Z



View Y






F23404032-1

1. Parking lamp (If equipped)
2. Front combination lamp (If equipped)
3. Head lamp
4. Fog lamp (If equipped)
5. Working lamp (If equipped)
6. Air horn
7. Parking brake switch
8. Buzzer switch
9. Electrical air intake heater (Ribbon heater)

10. Fuel gauge unit
12. Oil pressure gauge unit
13. Battery
14. Back-up buzzer
15. Water temperature gauge
16. License plate lamp (If equipped)
17. Automatic drain heater (If equipped)
18. Rear combination lamp (If equipped)
19. Back-up lamp (If equipped)
20. Air pressure gauge unit
21. Low pressure switch
22. Heater relay
23. Battery relay
24. Starting motor
25. Oil temperature sensor
26. Differential lock indicator switch
27. Speedometer take out part
28. Air horn valve
29. Articulate switch
30. Stop lamp switch
33. Head lamp switch
34. Air pressure gauge
35. Engine oil pressure gauge
36. Water temperature gauge
37. High beam pilot lamp (If equipped)
38. Articulation lock pilot lamp (If equipped)
39. Differential lock pilot lamp
40. Parking brake pilot lamp
41. Battery charging lamp
42. Speedometer
43. Engine oil temperature warning lamp
44. Turn signal, dimmer switch
45. Fuel gauge
46. Safety switch
47. Back-up lamp switch
48. Turn signal relay
49. Heater signal
50. Working lamp switch (If equipped)
51. Panel lamp
52. Service meter
53. Hazard warning lamp switch (If equipped)
54. Car heater switch (If equipped)
55. Cigarette lighter (If equipped)
56. Fuse box
57. Starting switch
58. Horn relay
59. Hazard turn signal relay



GD705A-4

Parking lamp (24V)
(If equipped)

Combination lamp (24V)
(If equipped)

Clearance (12W),
Turn signal (26W)

Head lamp (80W, 180W)

Fog lamp (If equipped)

Working lamp
(If equipped)
(60W)

Solenoid valve
(R.H.)

Solenoid valve
(L.H.)

Air horn

Accumulator lamp (If equipped)

High beam lamp (If equipped)

Articulate lamp

Defroster lamp

Battery charge lamp

Parking lamp

Oil temperature lamp

Fuel gauge

Air pressure gauge

Oil pressure gauge

Water temperature gauge

Speedometer

For cabin







Horn switch

Dimmer/Turn signal switch

D

E

Articulate switch



Fog lamp (If equipped)

Head lamp (80W, 180W)

Combination lamp
(If equipped)

Clearance (12W),
Turn signal (26W)

Working lamp
(If equipped)
(60W)

Parking lamp (24V)
(If equipped)

Fluid level switch

Parking brake switch

Hazard parking switch

Accumulator switch (If equipped)

Heater signal

Working lamp switch
(If equipped)

Caution lamp switch
(If equipped)

Fuse ass'y

Starting switch

Hazard turn signal unit

Fuse box


Panel lamp

Service meter

Buzzer

Turn signal unit

Horn relay



Fuse box

| | | |
|---|--------------|----------------|
| | Brake lamp | Buzzer |
| L | Head lamp | |
| T | Caution lamp | |
| R | Hazard lamp | |
| | Back-up lamp | Caution lamp |
| I | Articulate | Oil temp. lamp |
| | Horn | |
| U | Accumulator | Head lamp |

Starting switch connection table

| Terminal Key position | B | BR | R ₁ | R ₂ | C | A.c.c. |
|-----------------------|---|----|----------------|----------------|---|--------|
| HEAT | ○ | ○ | ○ | | | ○ |
| OFF | ○ | | | | | ○ |
| ON | ○ | ○ | | | | ○ |
| START | ○ | ○ | ○ | | | ○ |

Dimmer switch connection table


| Connection | From lamp sw. | To head lamp (main) | To head lamp (dim.) |
|----------------|---------------|---------------------|---------------------|
| M | ○ | ○ | |
| D | ○ | | ○ |
| Color Terminal | RY | RW | RB |
| | 1 | 2 | 3 |


Turn signal switch connection table

| Connect. position | From washer unit | To R.H. signal lamp | To L.H. signal lamp |
|-------------------|------------------|---------------------|---------------------|
| R | ○ | ○ | |
| N | ○ | | ○ |
| L | ○ | | ○ |
| Color Terminal | G | GB | GR |
| | 6 | 4 | 5 |

F23404033



GD705A-4 (Serial No. 31001 and up)





Fuse box

| | | |
|---|--------------|----------------|
| L | Brake lamp | Buzzer |
| T | Head lamp | |
| R | Caution lamp | |
| | Hazard lamp | |
| | Back-up lamp | Caution lamp |
| I | Articulate | Oil temp. lamp |
| | Horn | |
| U | Accumulator | Head lamp |



Starting switch connection table

| Key position | B | BR | R1 | R2 | C | Acc |
|--------------|---|----|----|----|---|-----|
| HEAT | ○ | ○ | ○ | ○ | ○ | ○ |
| OFF | ○ | ○ | ○ | ○ | ○ | ○ |
| ON | ○ | ○ | ○ | ○ | ○ | ○ |
| START | ○ | ○ | ○ | ○ | ○ | ○ |



Dimmer switch connection table

| Terminal | From lamp switch | To head lamp (main) | To head lamp (dim.) |
|----------|------------------|---------------------|---------------------|
| M | ○ | ○ | ○ |
| D | ○ | ○ | ○ |
| Color | RY | RW | RB |
| Terminal | 4 | 5 | 6 |

Turn signal switch connection table

| Turn signal level | From flasher unit | To RH signal lamp | To LH signal lamp |
|-------------------|-------------------|-------------------|-------------------|
| R | ○ | ○ | ○ |
| N | ○ | ○ | ○ |
| L | ○ | ○ | ○ |
| Color | G | GB | GR |
| Terminal | 1 | 3 | 2 |

ELECTRICAL CIRCUIT DIAGRAM FOR CAB



Front wiper switch connecting table


| Terminal Key position | BW | Ground (Frame) | LW | LR | LB | B |
|-----------------------|----|----------------|----|----|----|---|
| OFF | ○ | ○ | ○ | ○ | | |
| 1 | ○ | ○ | ○ | ○ | ○ | |
| 2 | ○ | ○ | | ○ | | |

Rear wiper switch connecting table

| Terminal Key position | LW | LR | LB | B |
|-----------------------|----|----|----|---|
| OFF | ○ | ○ | | |
| 1 | ○ | ○ | ○ | |
| 2 | | ○ | ○ | ○ |

F23404067

WIRING DIAGRAM FOR CAB



F23404068

- | | | | |
|-----------------------------|--------------------------------------|-------------------------|---------------------------------|
| 1. Ground connection | 6. Room lamp | 11. Antenna | 17. Yellow rotating lamp switch |
| 2. Working lamp | 7. Ground connection (for room lamp) | 12. From defroster fan | 18. Rear wiper switch |
| 3. Front wiper motor | 8. From rear warning lamp | 13. Radio | 19. Front wiper switch |
| 4. Heated windshield switch | 9. Rear wiper motor | 14. Wind washer | 20. Cigarette lighter |
| 5. From front warning lamp | 10. Speaker | 15. Working lamp switch | |
| | | 16. Car heater switch | |