

# SHOP MANUAL

## **KOMATSU**

### **PC160-6k**

### **PC180LC, 180NLC-6k**

MACHINE MODEL

**PC160-6k**

**PC180LC, 180NLC-6k**

SERIAL NUMBER

**K30001 and up**

**K30001 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice
- PC160-6k mount the SA4D102E engine;  
PC180LC-6k, PC180NLC-6k mount the SA4D102E engine.  
For details of the engine, see the 102 Service Engine Shop Manual.







---

# **01 GENERAL**

---

Specification drawings .....	01- 2
Specifications .....	01- 4
Weight table .....	01- 8
Fuel, coolant and lubricants .....	01-12




## SPECIFICATIONS

Machine model			PC180LC-6K	PC160-6K	
Serial Number			and up	and up	
Bucket capacity (SAE) (m <sup>3</sup> )			0.67	0.58	
Operating weight (kg)			17900 (with 2.25 m ARM)	16300 (with 2.25 m ARM)	
Performance	Working range	Max. digging depth	(mm)	5610	5645
		Max. digging depth of cut for 8 level	(mm)	5375	5415
		Max. digging reach	(mm)	8675	8675
		Max. reach at ground level	(mm)	8510	8515
		Max. digging height	(mm)	8840	8800
		Max. dumping height	(mm)	6230	6190
	Max. digging force (using power max. function)		(kN(kg))	115 (11700)	115 (11700)
	Swing speed		(rpm)	12	12
	Swing max. slope angle		(deg.)	20	20
	Travel speed		(km/h)	Lo: 2.7 Mi: 4 Hi: 5,5	Lo: 2.7 Mi: 4 Hi: 5.5
	Gradeability		(deg.)	35	35
	Ground pressure [standard triple grouser shoe width]		(MPa(kg/cm <sup>2</sup> ))	0.041 (0.42) [600 mm]	0.051 (0.52) [500 mm]
	Dimensions	Overall length (for transport)		(mm)	8560
Overall width		(mm)	2780	2490	
Overall width of track		(mm)	2780	2490	
Overall height (for transport)		(mm)	2960	2945	
Overall height to top of cab		(mm)	2930	2890	
Ground clearance of counterweight		(mm)	1030	990	
Min. ground clearance		(mm)	440	440	
Tail swing radius		(mm)	2435	2435	
Min. swing radius of work equipment		(mm)	3060	3060	
Height of work equipment at min. swing radius		(mm)	7140	7100	
Length of track on ground		(mm)	3260	2880	
Track gauge		(mm)	2180	1990	
Height of machine cab		(mm)	2010	1970	

Machine model		PC180LC-6K	PC160-6k	
Serial Number		and up	and up	
Engine	Model	KOMATSU SA4D102E		
	Type	4-cycle, water-cooled, in-line, vertical, direct injection, with turbocharger		
	No. of cylinders - bore x stroke (mm)	4 - 102X120		
	Piston displacement (cc)	3920		
	Performance	Flywheel horsepower (kW(PS)/rpm)	78 (106)	
		Max torque (Nm(kgm)/rmp)	422 (43)/1400	
		Max. speed at no load (rpm)	2450	
		Min. speed at no load (rpm)	950	
		Min. fuel consumption (g/kW.h(g/PS.h))	210 (155)	
	Starting motor	24V 4.5 KW		
	Alternator	24V 55A		
	Battery	12V 95 AhX2		
	Radiator core type	CWX-4		
	Undercarriage	Carrier roller	2 on each side	1 on each side
Track roller		7 on each side	6 on each side	
Track shoe		Assembly-type triple grouser	Assembly-type triple grouser	
Hydraulic system	Hydraulic pump	Type X No.	Variable displacement piston type X gear type X 1	
		Delivery (/min.)	Piston type: 276 X 1, gear type: 34	
		Set pressure (MPa(kg/cm <sup>2</sup> ))	Piston type 34.81(355) 31.87(325) gear type: 32.36 (33)	
	Control valve	Type X No.	6-spool + 1-spool type X 1	
		Control method	Hydraulic	
	Hydraulic motor	Travel motor	Piston type (with brake valve,)X2	
		Swing motor	Piston type (with safety valve,): X1	
	Hydraulic cylinder	Double-acting piston		
Hydraulic tank	Box-shaped, sealed			
Hydraulic filter	Tank return side			
Hydraulic cooler	Air cooled			


	1.85m ARM	2.25m ARM	2.62m ARM	2.90m ARM
A	8620 mm	8560 mm	8560 mm	8570 mm
B	3125 mm	2960 mm	2965 mm	3055 mm
C	6040 mm	5135 mm	4750 mm	4555 mm

PC180 LC-6k






PC180LC-6k

		1.85m ARM	2.25m ARM	2.62m ARM	2.90m ARM
A	Max digging height	8775 mm	8840 mm	8900 mm	9055 mm
B	Max dumping height	6130 mm	6230 mm	6320 mm	6470 mm
C	Max digging depth	5200 mm	5610 mm	5960 mm	6250 mm
D	Max digging depth of cut for 8' level	4950 mm	5375 mm	5740 mm	6050 mm
E	Max digging reach	8355 mm	8675 mm	8960 mm	9230 mm
F	Max digging reach at ground	8180 mm	8510 mm	8800 mm	9075 mm
G	Min swing radius	3360 mm	3060 mm	3000 mm	3010 mm
H	Work equipment height of min swin radius	7210 mm	7140 mm	7120 mm	7140 mm




	1.85m ARM	2.25m ARM	2.62m ARM	2.90m ARM
A	8625 mm	8565 mm	8565 mm	8570 mm
B	3115 mm	2945 mm	2960 mm	3060 mm
C	5865 mm	4970 mm	4585 mm	4395 mm



PC160-6K

PC160-6k

		1.85m ARM	2.25m ARM	2.62m ARM	2.90m ARM
A	Max digging height	8735 mm	8800 mm	8865 mm	9015 mm
B	Max dumping height	6090 mm	6190 mm	6280 mm	6430 mm
C	Max digging depth	5240 mm	5645 mm	6000 mm	6290 mm
D	Max digging depth of cut for 8' level	4990 mm	5415 mm	5780 mm	6090 mm
E	Max digging reach	8355 mm	8675 mm	8960 mm	9230 mm
F	Max digging reach at ground	8190 mm	8515 mm	8805 mm	9080 mm
G	Min swing radius	3360 mm	3060 mm	3000 mm	3010 mm
H	Work equipment height of min swin radius	7170 mm	7100 mm	7080 mm	7100 mm





## WEIGHT TABLE

GENERAL

Units:kg		Units:kg	
Machine model	PC180LC-6	Machine model	PC180LC-6
Serial Number		Serial Number	
Engine assembly	600	Track shoe assembly (shoes +link+pin)	
Engine	445	600mm triple grouser shoe	2620
Damper	15	700mm triple grouser shoe	2870
Hydraulic pump	100	800mm triple grouser shoe	3120
Radiator, oil cooler assembly	115	Boom assembly	1030
Hydraulic tank, filter assembly (excl. hydraulic oil)	125	Arm assembly	
Fuel tank (excl. fuel)	100	1850 mm arm	400
Revolving frame	1410	2250 mm arm	450
Operator's cab	290	2620 mm arm	520
Operator's seat	30	2900 mm arm	600
Counterweight	2950	Bucket assembly (SAE 0.67 m <sup>3</sup> )	580
Swing machinery (excl. oil)	115	Boom cylinder assembly + Boom cylinder bottom pin	135 x 2 + 7 x 2
Control valve (7 spools)	70	Arm cylinder assembly	200
Swing motor	30	Bucket cylinder assembly	130
Travel motor	95 X 2	Link assembly	160
Center swivel joint	45	Boom pin (boom foot pin, boom cylinder top pin, arm cylinder bottom pin, boom top pin)	30 +21 + 9 + 19
Under carriage assembly (excl. track shoes assembly)	4600	Arm pin ( arm cylinder top pin, bucket cylinder bottom pin, arm top pin, arm - link joint pin)	10 + 7 + 16 + 15
Track frame	2460	Link pin (bucket cylinder top pin, link - bucket joint pin)	15 + 16
Swing circle	235		
Idler assembly	140 x 2		
Idler cushion	135 x 2		
Carrier roller	20 x 2		
Track roller	40 x 14		
Final drive (excl. travel motor)	195 x 2		

**WEIGHT TABLE**

Units:kg

Machine model	PC160-6k
Serial Number	
Engine assembly	600
Engine	445
Damper	15
Hydraulic pump	100
Radiator, oil cooler assembly	115
Hydraulic tank, filter assembly (excl. hydraulic oil)	125
Fuel tank (excl. fuel)	100
Revolving frame	1410
Operator's cab	290
Operator's seat	30
Counterweight	2950
Swing machinery (excl. oil)	115
Control valve (7 spools)	70
Swing motor	30
Travel motor	95 x 2
Center swivel joint	45
Under carriage assembly (excl. track shoes assembly)	4150
Track frame	2100
Swing circle	235
Idler assembly	140 x 2
Idler cushion	135 x 2
Carrier roller	20 x 2
Track roller	40 x 14
Final drive (excl. travel motor)	195 x 2

Units:kg

Machine model	PC160-6k
Serial Number	
Track shoe assembly (shoes +link+pin)	
500mm triple grouser shoe	2160
600mm triple grouser shoe	2390
700mm triple grouser shoe	2620
Boom assembly	1030
Arm assembly	
1850 mm arm	400
2250 mm arm	450
2620 mm arm	520
2900 mm arm	600
Bucket assembly (SAE 0.67 m <sup>3</sup> )	580
Boom cylinder assembly + Boom cylinder bottom pin	135 x 2 + 7 x2
Arm cylinder assembly	200
Bucket cylinder assembly	130
Link assembly	160
Boom pin (boom foot pin, boom cylinder top pin, arm cylinder bottom pin, boom top pin)	30 + 21 + 9 + 19
Arm pin ( arm cylinder top pin, bucket cylinder bottom pin, arm top pin, arm - link joint pin)	10 + 7 + 16 + 15
Link pin (bucket cylinder top pin, link - bucket joint pin)	15 + 16

# FUEL, COOLANT AND LUBRICANTS

RESERVOIR	KIND OF FLUID	AMBIENT TEMPERATURE								CAPACITY (✓)		
		-22 -30	-4 -20	14 -10	32 0	50 10	68 20	86 30	104°F 40°C	Specified	Refill	
Engine oil pan	Engine oil	SAE 30								16	16	
		SAE 10W										
		SAE 10W-30										
		SAE 15W-40										
Swing machinery case										4	4	
Final drive case (each side)										4	4	
Idler (1 each)			SAE 30								0.16	0.16
Track roller (1 each)										0.10	0.10	
Carrier roller (1 each)										0.16	0.16	
Hydraulic system			SAE 10W								190	135
			SAE 10W-30									
			SAE 15W-40									
	Hydraulic oil	H046-HM (★)										
Fuel tank	Diesel fuel	ASTM DG75 No. 2								250	-	
		ASTM D975A No. 1										
Cooling system	Coolant	Add antifreeze								20	-	

**NOTE:**

- (1) When fuel sulphur content is less than 0.5%, change oil in the oil pan every periodic maintenance hours described in this manual.  
Change oil according to the following table if fuel sulphur content is above 0.5%.

Fuel sulphur content	Change interval of oil in engine oil pan
0.5 to 1.0%	1/2 of regular interval
Above 1.0%	1/4 of regular interval

- 2) When starting the engine in an atmospheric temperature of lower than 0°C, be sure to use engine oil of SAE10W, SAE10W-30 and SAE15W-40, even though an atmospheric temperature goes up to 10°C more or less in the day time.
- 3) Use API classification CD as engine oil and if API classification CC, reduce the engine oil change interval to half.
- 4) There is no problem if single grade oil is mixed with multigrade oil (SAE10W-30), 15W matches the temperature in the table on the left.
- 5) We recommend Komatsu genuine oil which has been specifically formulated and approved for use in engine and hydraulic work equipment applications.
- ★ For the HO46-HM, use the oil recommended by Komatsu.

ASTM: American Society of Testing and Material  
SAE: Society of Automotive Engineers  
API: American Petroleum Institute

Specified capacity: Total amount of oil including oil for components and oil in piping.

Refill capacity: Amount of oil needed to refill system during normal inspection and maintenance.







---

# 10 STRUCTURE AND FUNCTION



---

Engine related parts .....	10-	2
Radiator . oil cooler . aftercooler .....	10-	3
Power train .....	10-	4
Final drive .....	10-	5
Swing circle .....	10-	6
Swing machinery .....	10-	8
Track frame . recoil spring .....	10-	9
Track shoe .....	10-	11
Hydraulic piping drawing .....	10-	12
Hydraulic curcuit diagram .....	10-	13
Hydraulic tank .....	10-	14
Hydraulic pump .....	10-	22
Control valve .....	10-	28
CLSS .....	10-	29
Swing motor .....	10-	67
Center swivel joint .....	10-	68
Travel motor .....	10-	76
Valve control .....	10-	77
Work equipment . swing PPC valve .....	10-	81
Travel PPC valve .....	10-	85
Service PPC valve .....	10-	88
Safety lock vavle .....	10-	89
PPC accumulator .....	10-	89
PPC shuttle . travel junction valve .....	10-	96
EPC . solenoid valve .....	10-	101
Hydraulic cylinder .....	10-	103
Additional filter for breaker .....	10-	104
Overload warning device .....	10-	108
Hose burst protection valve .....	10-	111
Work equipment .....	10-	112
Electrical control system .....	10-	114
Electrical wiring diagram .....	10-	117
Engine control system .....	10-	123
Electronic control system .....	10-	147
Machine monitor system .....	10-	154


ENGINE RELATED PARTS




D-D




5



A-A



B-B



C-C



H-H



1. Drive plate
2. Torsion spring
3. Stopper pin
4. Friction plate
5. Damper assembly
6. Air cleaner
7. Intake connector
8. Muffler
9. Rear engine mount
10. Front engine mount

OUTLINE

- The damper assembly is a dry type.





RADIATOR • OIL COOLER



- 1. Reservoir tank
- 2. Oil cooler
- 3. Radiator
- 4. Fan
- 5. Radiator inlet hose
- 6. Radiator outlet hose
- 7. Radiator cap
- 8. Net
- 9. Shroud

**SPECIFICATIONS**  
 Radiator: CWX-4  
 Oil cooler: SF-3


POWER TRAIN



- 1. Idler
- 2. Center swivel joint
- 3. Control valve
- 4. Final drive
- 5. Travel motor
- 6. Hydraulic pump

- 7. Engine
- 8. Travel speed solenoid valve
- 9. Swing brake solenoid valve
- 10. Swing motor
- 11. Swing machinery
- 12. Swing circle


FINAL DRIVE




1. Level plug
2. Drain plug
3. No. 1 sun gear (No. of teeth: 24)
4. No. 2 sun gear (no. of teeth: 28)
5. No. 3 sun gear (No of teeth: 20)
6. No. 1 planetary carrier
7. No. 2 planetary carrier
8. No. 3 planetary carrier
9. No. 1 planetary gear (No. of teeth: 26)
10. No. 1 ring gear (No. of teeth: 78)
11. No. 2 planetary gear (No. of teeth: 20)
12. No. 3 planetary gear (No. of teeth: 23)
13. No. 2 ring gear (No. of teeth: 68)
14. Cover
15. Floating seal
16. Parking brake piston
17. Parking brake spring
18. Parking brake disc
19. Parking brake plate

Reduction ratio:

$$- \left( \frac{24 + 78}{24} \right) \times \left( \frac{28 + 68}{28} \right) \times \left( \frac{20 + 68}{20} \right) + 1 = 63.114$$



## SWING CIRCLE




1. Swing circle inner race (No. of teeth: 94)
  2. Ball
  3. Swing circle outer race
- a. Inner race soft zone **S** position  
 b. Outer race soft zone **S** position

## SPECIFICATIONS


Reduction ratio:  $\frac{94}{12} = 7.833$

Amount of grease: 8/ (G2-LI)

SWING MACHINERY



1. Swing pinion (No. of teeth: 12)
2. Cover
3. Case
4. No. 2 of planetary carrier
5. No. 2 sun gear (No. of teeth: 24)
6. No. 2 ring gear (No. of teeth: 78)
7. Case
8. No. 1 ring gear (No. of teeth: 78)
9. No. 1 sun gear (No. of teeth: 18)
10. Retainer
11. Oil level gauge
12. Cover
13. No. 1 planetary gear (No. of teeth: 29)
14. No. 1 planetary carrier
15. Coupling
16. No. 2 planetary gear (No. of teeth: 26)
17. Drain plug
18. Breather
19. Parking brake piston
20. Parking brake spring
21. Parking brake disc
22. Parking brake plate.
23. Gauge rod.



SPECIFICATIONS

Reduction ratio:  $\frac{24 + 78}{24} \times \frac{18 + 78}{18} = 22.667$


**SWING HOLDING BRAKE**

**OPERATION**

**1) When swing brake solenoid valve is deactivated**

When the swing brake solenoid valve is deactivated, the pressurized oil from the control pump is shut off and port **B** is connected to the tank circuit.

Because of this, brake piston (2) is pushed down in the direction of the arrow by brake spring (1), so disc (3) and plate (4) are pushed together and the brake is applied.




**2) When swing brake solenoid valve is excited**

When the swing solenoid valve is excited, the valve is switched, and the pressurized oil from the control pump enters port **B** and flows to brake chamber "a".


The pressurized oil entering chamber "a" overcomes the force of brake spring (1), and brake piston (2) is pushed up in the direction of the arrow. Because of this, disc (3) and plate (4) separate, and the brake is released.

- 1. Brake spring
- 2. Brake piston
- 3. Disc
- 4. Plate



# TRACK FRAME • RECOIL SPRING

★ The diagram shows the PC180LC-6K



205CA06015

- The dimensions and number of track rollers may differ according to the model, but the basic structure is the same.

1. Idler
2. Track frame
3. Carrier roller
4. Final drive
5. Track roller
6. Track shoe
7. Center guard
8. Recoil spring
9. Front guard

• No. of rollers (each side)

Model	No. of track rollers	No. of carrier rollers
PC180LC-6K	7	2
PC160-6K	6	1

## TRACK SHOE

### STANDARD SHOE

Item	Model	PC180LC-6K	PC160-6K
	Shoe width (triple shoe)		600 mm
Link pitch		190 mm	190 mm
No. of rollers (each side)		45	41

### SELECTION OF TRACK SHOE

- Select the most suitable track shoe from the following table.

Model	PC180LC-6K		PC160-6K	
	Specification	Category	Specification	Category
Standard	600mm triple	A	500 mm triple	A
Option	700 mm triple	B	600 mm triple	B
Option	800 mm triple	C	700 mm triple	C
Option	-	-	-	-
Option	-	-	-	-
Option	-	-	-	-
Option	-	-	-	-



Category	Use	Precautions when using
A	Rocky ground, normal river soil	<ul style="list-style-type: none"> <li>Travel in Lo speed when traveling on rough ground with obstacles such as large boulders and fallen trees.</li> </ul>
B	Normal soil, soft land	<ul style="list-style-type: none"> <li>Cannot be used on rough ground where there are large obstacles such as boulders and fallen trees.</li> <li>Travel in Hi speed only on flat ground, and when it is impossible to avoid traveling obstacles, lower the travel speed to approx. half of Lo speed.</li> </ul>
C	Extremely soft ground (swampy ground)	<ul style="list-style-type: none"> <li>Use only for ground where "A" and "B" sink and are impossible to use.</li> <li>Cannot be used on rough ground where there are large obstacles such as boulders and fallen trees.</li> <li>Travel in Hi speed only on flat ground, and when it is impossible to avoid traveling over obstacles, lower the travel speed to approx. half of Lo speed.</li> </ul>


- ★ Categories "B" and "C" are wide shoes, so there are restrictions on their use. Therefore, before using, check the restrictions and consider carefully the conditions of use before recommending a suitable shoe width.  
If necessary, given the customer guidance in their use.


- ★ When selecting the shoe width, select the narrowest shoe possible within the range that will give no problem with flotation and ground pressure.  
If a wider shoe than necessary is used, there will be a large load on the shoe, and this may lead to bending of the shoe, cracking of the links, breakage of the pins, losing of the shoe bolts, or other problems.

# HYDRAULIC CIRCUIT DIAGRAM


PC180LC-6k

PC160-6k





## HYDRAULIC TANK



1. Hydraulic tank
2. Bypass valve
3. Oil filter cap
4. Sight gauge
5. Suction strainer
6. Filter element
7. Bypass strainer

**SPECIFICATIONS**

Tank capacity:

Amount of oil inside tank:


Pressure valve

Relief cracking pressure:  $0.038 \pm 0.015$  MPa  
( $0.39 \pm 0.15$  kg/cm<sup>2</sup>)

Suction cracking pressure:  $0 - 0.0045$  MPa  
( $0 - 0.046$  kg/cm<sup>2</sup>)

Bypass valve set pressure:  $0.103 \pm 0.02$  MPa  
( $1.05 \pm 0.2$  kg/cm<sup>2</sup>)

HYDRAULIC PUMP



- a. Pump drain port **PD**
- b. Pump delivery port **PA**
- c. Control pump suction port **PGS**
- d. Control pump delivery port **PGA**
- e. Pump LS pressure port **PLS**
- f. LS control EPC pressure port **PSIG**
- g. Main pump suction port **PS**
- h. Control pump drain port **PGD**


- 1. Main pump
- 2. Control relief valve
- 3. TVC•LS valve
- 4. Control pump

**OPERATION**

**1. Operation of pump**

- 1) cylinder block (7) rotates together with shaft (1), and shoe (5) slides on flat surface **A**.


When this happens, rocker cam (4) moves along cylindrical surface **B**, so angle  $\alpha$  between center line **X** of rocker cam (4) and the axial direction of cylinder block (7) changes. (Angle  $\alpha$  is called the swash plate angle.)




- 2) Center line **X** of rocker cam (4) maintains swash plate angle  $\alpha$  in relation to the axial direction of cylinder block (7), and flat surface **A** moves as a cam in relation to shoe (5).

In this way, piston (6) slides on the inside of cylinder block (7), so a difference between volume **E** and **F** is created inside cylinder block (7). The suction and discharge is carried out by this difference **F - E**.

In other words, when cylinder block (7) rotates and the volume of chamber **E** becomes smaller, the oil is discharged during that stroke. On the other hand, the volume of chamber **F** becomes larger, and as the volume becomes bigger, the oil is sucked in.



- 3) If center line **X** of rocker cam (4) is in line with the axial direction of cylinder block (7) (swash plate angle = 0), the difference between volumes **E'** and **F'** inside cylinder block (7) becomes 0, so the pump does not carry out any suction or discharge of oil. (In actual fact, the swash plate angle never becomes 0.)













2. TVC. LS valve



**LS VALVE**

- 1. Locknut
- 2. Plug
- 3. Spring
- 4. Spool
- 5. Sleeve
- 6. Piston
- 7. Sleeve
- 8. Spring


**TVC VALVE**

- 9. Solenoid
- 10. Piston
- 11. Spring
- 12. Spring
- 13. Piston
- 14. Lever
- 15. Valve body

**FUNCTION**


**1. LS VALVE**

- The **LS** valve detects the load and controls the discharge amount. This valve controls main pump discharge amount **Q** according to differential pressure  $\Delta PLS (=PP - PLS)$  (the difference between main pump pressure **PP** and control valve outlet port pressure **PLS**) (called the **LS** differential pressure).
- Main pump pressure **PP**, pressure **PLS** (called the **LS** pressure) coming from the control valve output, and pressure **PSIG** (called the **LS** selection pressure) from the proportional solenoid valve enter this valve. The relationship between discharge amount **Q** and differential pressure  $\Delta PLS$ , (the difference between main pump pressure **PP** and **LS** pressure **PLS**) ( $=PP - PLS$ ) changes as shown in the diagram on the right according to **LS** selector pressure **PSIG**.
- When **PSIG** changes between 0 and 2.94 MPa (0 and 30 kg/cm<sup>2</sup>), the spool load changes according to this, and the selector point for the pump discharge amount changes at the rated central value between 0.64 and 2.45 MPa (6.5 and 25 kg/cm<sup>2</sup>).



**2. TVC VALVE**







- When the pump discharge pressure **PP** (selfpressure) is high, the TVC valve controls the pump so that no more oil than the constant flow (in accordance with the discharge pressure) flows even if the stroke of the control valve becomes larger. In this way it carries out equal horsepower control so that the horsepower absorbed by the pump does not exceed the engine horsepower.
- In other words, if the load during the operation becomes larger and the pump discharge pressure rises, it reduces the discharge amount from the pump; and if the pump discharge pressure drops, it increases the discharge amount from the pump. The relationship between the average of the front and rear pump discharge pressures  $(PP1 + PP2)/2$  and pump discharge amount **Q** is shown on the right, with the current given to the TVC valve solenoid shown as a parameter. However, in the heavy-duty operation mode, there are cases where it is given the function of sensing the actual speed of the engine, and if the speed drops because of an increase in the load, it reduces the pump discharge amount to allow the speed to recover. In other words, when the load increases and the engine drops below the set value, the command



to the TVC valve solenoid from the controller increases according to the drop in the engine speed to reduce the pump swash plate angle.

# CONTROL VALVE

## 7-SPOOL VALVE (+ 1 SERVICE VALVE)



1. 7-spool valve
2. Cover 1 (main relief valve, LS bypass valve)
3. Cover 2 (Unload valve)
4. Arm counterbalance valve
5. No. 1 service valve




- a. Port **PP** (from main pump)
- b. Port **A1** (to swing motor)
- c. port **B1** (to swing motor)
- d. Port **A2** (to L.H. travel motor)
- e. Port **B2** (to L. H. travel motor)
- f. Port **A3** (to R.H. travel motor)
- g. Port **B3** (to R.H. travel motor)
- h. Port **A4** (to boom cylinder bottom)
- i. Port **B4** (to boom cylinder head)
- j. Port **A5** (to arm cylinder head)
- k. Port **B5** (to arm cylinder bottom)
- l. Port **A6** (to bucket cylinder head)
- m. Port **B6** (to bucket cylinder bottom)
- n. Port **A7** (to attachment)
- o. Port **B7** (to attachment)
- p. Port **TB** (to tank)
- q. Port **AE2** (to travel junction valve)
- r. Port **BE2** (to travel junction valve)
- s. Port **AE3** (to travel junction valve)
- t. Port **BE3** (to travel junction valve)
- u. Port **TE** (to oil cooler)
- v. Port **TSW** (to swing motor)

#### OUTLINE


- This control valve consists of the 6-spool valve (an integrated composition) and 1 service valve. Arm counterbalance valve is installed to this.
- Each valve forms one unit with the connection bolt, and the passages are internally connected, so the structure is compact and is very easy to service.
- This control valve consists of one spool for one item of the work equipment, so it has a simple structure.

- aa. Port **PLS1** (to rear pump control)
- bb. Port **TS** (to tank)
- cc. Port **PX1** (from solenoid valve)
- dd. Port **PX2** (from solnoid valve)
- ee. Port **SA** (pressure sensor mount port)
- gg. Port **BP** (from solenoid valve)
- hh. Pump pressure checking port
- ii. LS pressure checking port
- pa. Port **P1** (from swing PPC/EPC valve)
- pb. Port **P2** (from swing PPC/EPC valve)
- pc. Port **P3** (from L.H. travel PPC valve)
- pd. Port **P4** (from L.H. travel PPC valve)
- pe. Port **P5** (from R.H. travel PPC valve)
- pf. Port **P6** (from R.H. travel PPC valve)
- pg. Port **P7** (from boom PPC/EPC valve)
- ph. Port **P8** (from boom PPC/EPC valve)
- pi. Port **P9** (from arm PPC/EPC valve)
- pj. Port **P10** (from arm PPC/EPC valve)
- pk. Port **P11** (from bucket PPC/EPC valve)
- pl. Port **P12** (from bucket PPC/EPC valve)
- pm. Port **P13** (from service PPC valve)
- pn. Port **P14** (from service PPC valve)

MAIN STRUCTURE









- |                        |                        |
|------------------------|------------------------|
| 1. Spool (swing)       | 7. Spool (service 1)   |
| 2. Spool (L.H. travel) | 8. Spool return spring |
| 3. Spool (R.H travel)  | 9. Unload valve        |
| 4. Spool (boom)        | 10. Main relief valve  |
| 5. Spool (arm)         | 11. LS bypass valve    |
| 6. Spool (bucket)      |                        |



**D - D**


- 1. LS shuttle valve
- 2. LS select valve



- 1. Pressure compensation valve
- 2. Safety-suction valve
- 5. Suction valve



**SAFETY-SUCTION VALVE FOR SERVICE VALVE**




- 1. Suction valve
- 2. Main valve
- 3. Piston
- 4. Piston spring
- 5. Poppet
- 6. Poppet spring
- 7. Suction valve spring
- 8. Sleeve
- 9. Adjustment screw
- 10. Locknut

205F06038

Part No.	Set Pressure	Use
709-70-74600	24.5 MPa (250 kg/cm <sup>2</sup> ) at 5/min	For crusher (Okada)

## CLSS

### OUTLINE OF CLSS



#### Features

- CLSS stands for **C**losed center **L**oad **S**ensing **S**ystem, and has the following features.
  - 1) Fine control not influenced by load
  - 2) Control enabling digging even with fine control
  - 3) Ease of compound operation ensured by flow divider function using area of opening of spool during compound operations
 Energy saving using variable pump control


#### Structure

- The CLSS consists of a main pump (2 pumps), control valve, and actuators for the work equipment.
- The main pump body consists of the pump itself, the TVC valve and LS valve.

**BASIC PRINCIPLE**


**1) Control of pump swash plate angle**

- The pump swash plate angle (pump discharge amount) is controlled so that LS differential pressure  $\Delta PLS$  is constant. LS differential pressure  $\Delta PLS$ , which is the differential pressure between pump discharge pressure **PP** and LS pressure **PLS** (actuator load pressure) at the outlet port of the control valve (LS differential pressure  $\Delta PLS = \text{Pump discharge pressure } PP - \text{LS pressure } PLS$ )
- If LS differential pressure  $\Delta PLS$  becomes lower than the set differential pressure of the LS valve, the pump swash plate angle becomes greater, and if it becomes higher, the pump swash plate angle becomes smaller.




## 2) Pressure compensation control

- A valve (pressure compensation valve) is installed to the outlet port side of the control valve to balance the load.  
When there is compound operation of the actuators, this valve acts to make pressure difference  $\Delta P$  constant for the upstream flow (inlet port) and downstream flow (outlet port) of the spool of each valve. In this way, the flow of oil from the pump is divided in proportion to area of opening **S1** and **S2** of each valve.



### OPERATION FOR EACH FUNCTION OF CLSS

Hydraulic circuit diagram for system




1. Unload valve  
(LS pressure + 3.92 MPa (40 kg/cm<sup>2</sup>))
2. Safety-suction valve  
(35.77 MPa (365 kg/cm<sup>2</sup>) - Arm, Bucket)  
(33.32 MPa (340 kg/cm<sup>2</sup>) - Boom)
3. Pressure compensation valve
4. LS shuttle valve
5. Arm counterbalance valve
6. Suction valve
7. LS bypass valve  
(7.84MPa (80 kg/cm<sup>2</sup>),  
when pressure rises:  
36.26MPa (370 kg/cm<sup>2</sup>))  
(cracking pressure)
8. Main relief valve  
(normal: 31.85MPa (325 kg/cm<sup>2</sup>),  
when pressure rises:  
34.79MPa (355 kg/cm<sup>2</sup>))
9. Lift check valve
10. Bypass check valve
11. LS select valve

## 1) Unload valve

## Function

- When the control valve is at neutral, pump discharge amount  $Q$  discharged by the minimum swash plate angle is released to the tank circuit.  
When this happens, pump discharge pressure  $P_p$  is set at 3.92 MPa (40 kg/cm<sup>2</sup>) by spring (3) inside the valve. (LS pressure  $P_{Ls}$ : 0MPa (0 kg/cm<sup>2</sup>))



202F06063

## Operation

## When control valve is at neutral


- Pump discharge pressure  $P_p$  is acting on the left end of spool (4), and LS pressure  $P_{Ls}$  is acting on the right end.
- When the control valve is at neutral, LS pressure  $P_{Ls}$  is 0, so only pump discharge pressure  $P_p$  has any effect, and  $P_p$  is set only by the load of spring (3).
- As pump discharge pressure  $P_p$  rises and reaches the load of spring (3) (3.92 MPa (40kg/cm<sup>2</sup>)), spool (4) is moved to the right in the direction of the arrow. Pump discharge pressure  $P_p$  then passes through the drill hole in sleeve (2) and is connected to tank circuit T.
- in this way, pump discharge pressure  $P_p$  is set to 3.92 MPa (40kg/cm<sup>2</sup>)

- Unload valve
- Sleeve
- Spring
- Spool

 $P_p$ : Pump circuit (pressure) $P_{Ls}$ : LS circuit (pressure)

T: Tank circuit (pressure)

2. During fine control of the control valve, when the demand flow for the actuator is within the amount discharged by the minimum swash plate angle of the pump, pump discharge pressure  $P_p$  is set to LS pressure  $P_{Ls} + 3.92\text{MPa}$  ( $40\text{ kg/cm}^2$ ).  
When the differential pressure between pump discharge pressure  $P_p$  and LS pressure  $P_{Ls}$  reaches the load of spring (3)  $3.92\text{MPa}$  ( $40\text{ kg/cm}^2$ ), the unload valve opens, so LS differential pressure  $\Delta P_{Ls}$  becomes  $3.92\text{ MPa}$  ( $40\text{ kg/cm}^2$ ).



202F06064

## Operation

### Fine control of control valve


- When fine control is carried out on the control valve, LS pressure  $P_{Ls}$  is generated and acts on the right end of spool (4).  
When this happens, the area of the opening of the control valve spool is small, so there is a big difference between LS pressure  $P_{Ls}$  and pump discharge pressure  $P_p$ .
- When the differential pressure between pump discharge pressure  $P_p$  and LS pressure  $P_{Ls}$  reaches the load of spring (3)  $3.92\text{ MPa}$  ( $40\text{ kg/cm}^2$ ), spool (4) moves to the right in the direction of the arrow, and pump circuit  $P_p$  and tank circuit  $T$  are connected.
- In other words, pump discharge pressure  $P_p$  is set to a pressure equal to the spring force  $3.92\text{ MPa}$  ( $40\text{ kg/cm}^2$ ) + LS pressure  $P_{Ls}$ , and LS differential pressure  $P_{Ls}$  becomes  $3.92\text{ MPa}$  ( $40\text{ kg/cm}^2$ ).

1. Unload valve
2. Sleeve
3. Spring
4. Spool

$P_p$ : Pump circuit (pressure)  
 $P_{Ls}$ : LS circuit (pressure)  
 $T$ : Tank circuit (pressure)



3. When the control valve is being operated and the demand flow for the actuator becomes greater than the pump discharge from the minimum swash plate angle, the flow of the oil out to tank circuit **T** is cut off, and all of pump discharge **Q** flows to the actuator circuit.



202F06065

**Operation**

**Control valve operated**


- When the control valve is operated to a bigger stroke, Ls pressure **PLs** is generated and acts on the right end of spool (4). When this happens, the area of the opening of the control valve spool is large, so the difference between LS pressure **PLs** and pump discharge pressure **Pp** is small.
- For this reason, the differential pressure between pump discharge pressure **Pp** and LS pressure **PLs** does not reach the load of spring (3) (3.92 MPa (40 kg/cm<sup>2</sup>)), so spool (4) is pushed to the left by spring (3).
- As a result, pump circuit **Pp** and tank circuit **T** are shut off, and all the pump discharge amount **Q** flows to the actuator circuit.

1. Unload valve
2. Sleeve
3. Spring
4. Spool

**Pp:** Pump circuit (pressure)  
**PLs:** Ls circuit (pressure)  
**T:** Tank circuit (pressure)

### 3. Introduction of LS pressure

- ★ The diagram shows the condition for arm IN.



SLP00210

1. Main pump
2. Main spool
3. Pressure compensation valve
4. Valve
5. Ball valve
6. LS circuit
7. LS shuttle valve

#### Function

- The upstream pressure (= spool meter-in downstream pressure) of pressure compensation valve (3) is introduced and goes to shuttle valve (7) as the **LS** pressure. When this happens, it is connected to port **B** of the actuator through valve (4), and LS pressure = actuator load pressure. Introduction hole **a** inside the spool has a small diameter, so it also acts as a throttle.


#### Operation

- When spool (2) is operated, the pump pressure passes through introduction hole **a**, enters port **a**, and is taken to the LS circuit. When the pump pressure rises and reaches the load pressure of port **B**, ball valve (5) opens.

### 3) LS bypass plug

#### Outline

1. This releases the residual pressure of LS pressure  $P_{Ls}$ .
2. This makes the speed of the rise in pressure of LS pressure  $P_{Ls}$  more gentle.  
In addition, with this discarded throttled flow, it creates a pressure loss in the throttled amount of the spool or shuttle valve, and increases the stability by lowering the effective LS differential pressure.



202F06067

#### Operation

- The pressurized oil for LS circuit  $P_{Ls}$  passes from clearance filter **a** (formed by the clearance between LS bypass plug (1) and the valve body) through orifice **b** and flows to the tank circuit.

1. LS bypass plug


$P_{Ls}$ : LS circuit (pressure)

T: Tank circuit (pressure)

## 4) LS bypass valve

## Function

- When the travel and another actuator are operated at the same time, the LS throttle amount that is discarded is increased and the drop in the travel speed is kept small by relaxing the pressure compensation precision in the travel circuit.
- During normal operations, the pilot pressure (3.23 MPa (33 kg/cm<sup>2</sup>)) acts on pilot circuit **Px2** from the LS bypass solenoid valve, but when the travel + another are operated at the same time, the pilot pressure does not have any effect.



F20206001


## Operation

## Normal operation

- LS pressure **PLs** passes through clearance filter **a** and two-stage throttle **b**, and acts on poppet (3).
- Poppet (3) is being pushed to the right in the direction of the arrow by the load of spring (2).
- In addition, during normal operation, the pressure from the LS bypass solenoid valve acts on pilot circuit **Px2**, and pushes piston (4) to the right in the direction of the arrow.
- In other words, poppet (3) is pushed to the right in the direction of the arrow by the load of spring (2) (which is set by piston (4)), so it normally does not open, and LS circuit **PLs** and tank circuit **T** are not interconnected.

1. LS bypass valve
2. Spring
3. Poppet
4. Piston
5. LS bypass solenoid valve

**PLs:** LS pressure**Px2:** LS bypass pilot pressure**T:** Tank pressure




202F06069

**When travel and another actuator are operated together**

- With the operation described above, the pilot pressure from the LS bypass solenoid valve does not act on pilot circuit  $P_{x2}$ .
- For this reason, poppet (3) is pushed to the right in the direction of the arrow by the load of spring (2) (piston (4) is not acting on spring (2)).
- In this condition, if LS pressure  $P_{LS}$  rises and reaches the load of spring (2) (7.84 MPa (approx. 80 kg/cm<sup>2</sup>)), poppet (3) opens, LS circuit  $P_{LS}$  and tank circuit  $T$  are interconnected, and LS pressure  $P_{LS}$  flows out.

- 1. LS bypass valve
  - 2. Spring
  - 3. Poppet
  - 4. Piston
  - 5. LS bypass solenoid valve
- $P_{LS}$ : LS pressure  
 $P_{x2}$ : LS bypass pilot pressure  
 T: Tank pressure

5. Pressure compensation valve



SLP00212

- |                  |                     |
|------------------|---------------------|
| 1. Main pump     | 4. Piston           |
| 2. Valve         | 5. Spring           |
| 3. Shuttle valve | 6. LS shuttle valve |

**Fuction**

1) **During independent operation and at maximum load pressure (during compound operations, when load pressure is higher than other work equipment)**

- The pressure compensation valve acts as a load check valve.

**Operations**

- If the pump pressure (LS pressure) is lower than the load pressure at port **C**, shuttle valve (3) inside pressure compensation valve piston (4) moves to interconnect spring chamber **E** and port **C**. From this condition, the force of spring (5) acts to move piston (4) and valve (2) in the direction of closing.


**Reference: Intergrated pressure compensation valve**

- When high peak pressure is generated in the actuator circuit or when peak pressure is generated repeatedly over a continuous period (such as when using a breaker), valve (2) may hit vavle chamber seat **s** and generate a high stress. To prevent this, an integrated pressure compensation valve combining valve (2) and


piston (4) is used. On this machine, this is employed for the bucket valve (at the cylinder bottom) and service valve.

With the integrated compensation valve, as a basic rule, port **C** and spring chamber **E** are not interconnected, so even if a high peak pressure is generated at port **C**, valve(7) does not hit the valve chamber.

(However, the system is designed so that port **C** and spring chamber **E** are interconnected just before the bucket valve is seated.)



SAP00387



SLP00213


**2) When receiving compensation (during compound operations, when load pressure is lower than other work equipment)**

- The pressure compensation valve is closed by the LS pressure of port **D**, and the spool meter-in downstream pressure of port **B** becomes the same as the maximum pressure of the other work equipment. The spool meter-in upstream pressure of port **A** is the pump pressure, so spool meter-in differential pressure (upstream pressure (pressure of port **A**) - downstream pressure (pressure of port **B**)) becomes the same for all spools that are being operated. In this way, the pump flow is divided in proportion to the area of the meter-in opening.

**Operation**

- Spring chamber **E** is interconnected with port **D**. Piston (4) and valve (2) are actuated by the LS circuit pressure from the other work equipment at port **F** in the direction of closing (to the right). In other words, the valve upstream pressure of port **B** (= spool meter-in downstream pressure) is controlled by the **LS** pressure.

## 6. Shuttle valve inside pressure compensation valve



SLP00214


1. Main pump
2. Valve
3. Shuttle valve inside pressure compensation valve
4. Piston

**Function**

**When holding pressure at port A > LS pressure in spring chamber B.**

- Shuttle valve (3) is pushed to the right by the pressure of port A, and the circuit between ports A and C is shut off. In this condition, the holding pressure at port A is taken to spring chamber B, and pushes piston (4) to the left to prevent piston (4) and valve (2) from separating.






SLP00215

**<For travel>**


- No holding pressure is generated at port **A** in the travel circuit, so a pressure compensation valve without a shuttle valve is used.




SBP00216

**Reference: When there is no shuttle valve**

- If there is no shuttle valve, piston (4) and valve (2) will separate. In this condition, if another actuator is opened, the piston acts as an accumulator, so there is a time lag.



SAP00217



SLP00218

**<Area ratio of pressure compensation valve>**

The condition of the flow division changes according to the ratio of the areas of portion **A1** and portion **A2** of the pressure compensation valve.

Area ratio =  $A2/A1$


- When area ratio = 1: Spool meter- in downstream pressure = Max. load pressure, and oil flow is divided in proportion to area of opening of spool.
- When ratio is more than 1: Spool meter-in downstream pressure > Max. load pressure, and a smaller oil flow is divided than the proportion between the areas of opening of the spool.
- When ratio is less than 1: Spool meter-in downstream pressure < Max. load pressure, and a larger oil flow is divided than the proportion between the areas of opening of the spool.

**Area ratio for each part of work equipment**

	Port A		Port B	
	Area ratio	Throttle diameter (mm)	Area ratio	Throttle diameter (mm)
Bucket	1.0 (CURL)	-	1.0 (DUMP)	-
L.H./ R.H. travel	1.01	0.6 No Shuttle valve	1.01	0.6 NO SHUTTLE VALVE
Boom	0.96 (RAISE)	-	1.0 (LOWER)	-
Swing	0.98	0.6	0.98	0.6
Arm	0.96 (OUT)	-	1.0 (IN)	-
Service (for 2 -spool valve)				
Service (for 1 -spool valve)	Vaiable	-	Variable	-

★ Integrated pressure compensation valve

## 7. Boom regeneration circuit



SLP00220


1. Main pump
2. Main spool
- 3A. Pressure compensation valve
- 3B. Pressure compensation valve
- 4A. Suction valve (with safety)
- 4B. Suction valve
5. Check valve
6. LS shuttle valve
7. Drain circuit
8. Regeneration circuit

**Function****1) Cylinder head pressure < cylinder bottom pressure (free fall, etc.)**

- A return flow circuit is provided from the cylinder bottom to the cylinder head so that when the boom is lowered, the return flow can be used to increase the flow of oil from the pump to the cylinder bottom.

**Operation**

- When the cylinder head pressure < cylinder bottom pressure, part of the pressurized oil from the cylinder bottom passes through the notch in spool (2), goes through port B, and enters drain circuit (7). The rest of the oil goes from port C, enters regeneration circuit (8), opens check valve (5), and passes through ports C and D to flow back to the cylinder head.




S LP00221

**2) Cylinder head pressure > Cylinder bottom pressure (digging operations, etc.)**

- Check valve (5) in regeneration circuit (8) acts to shut off the flow from the cylinder head to the cylinder bottom.

8. Arm regeneration circuit



205F06060

- 1. Main pump
- 2. Main spool
- 3A. Pressure compensation valve
- 3B. Pressure compensation valve
- 4A. Safety valve
- 4B. Safety valve
- 5. Arm counterbalance valve
- 6. Piston
- 7. Spool
- 8. Check valve
- 9. LS shuttle valve
- 10. Drain circuit
- 11. Regeneration circuit


**Function**

**1) Cylinder head pressure > cylinder bottom pressure**

- A return flow circuit is provided from the cylinder head to the cylinder bottom so that when the arm is moved in, the flow of oil to the cylinder becomes the pump discharge amount + the return flow, and this increases the cylinder speed.

**Operation**

- When the cylinder head pressure > cylinder bottom pressure, the pressurized oil from the cylinder head passes through the notch in spool (2), enters port C and opens check valve (8), then passes through ports D and E to flow back to the cylinder bottom.



205F06061

## 2) When load is large

- During arm IN operations, if the load increases and the cylinder bottom pressure exceeds 16.6 MPa (170 kg/cm<sup>2</sup>), counterbalance valve (5) is actuated to increase the meter-out opening at the cylinder head. This reduces the pressure loss between the cylinder head and the hydraulic tank, and ensures the digging force.


## 3) Cylinder bottom pressure > Cylinder head pressure

- When the cylinder bottom pressure > cylinder head pressure, check valve (8) is closed by the cylinder bottom pressure and prevents any oil flowing back from the cylinder bottom to the head end.

## Operation

- The cylinder bottom pressure enters port F and pushes piston (6) to the left. Spool (7) moves fully to the left and interconnects port C of regeneration circuit (11) and tank drain circuit (10). As a result, the pressure loss in the drain circuit is reduced.

## 9. Arm counterbalance valve



205F06062

1. Piston
2. Spool
3. Spring
4. Check valve
5. Regeneration circuit
6. Tank drain circuit


**Operation**

- During arm IN operations, if the actuating pressure at the arm cylinder bottom rises, the pressure at port **A** also rises. When the force received by piston (1) from the pressure at port **A** becomes greater than the force of spring (3), piston (1) moves to the left.
- Spool (2) is pushed by piston (1) and also moves to the left, so ports **B** and **C** are interconnected. When this happens, the pressurized oil from the cylinder head passes through ports **B** and **C**, and flows directly to drain circuit (6). (The pressure loss is removed when draining.)
- When this happens, check valve (4) is closed by the pressure at port **A**, so it shuts off regeneration circuit (5), and prevents the oil from flowing back from the cylinder bottom to the head end.

## 10) LS select valve

**Function**

- When the swing + boom RAISE, or swing + travel are operated together, this valve prevents the high pressure which is generated when driving the swing, and prevents swing LS pressure **a** from flowing into LS circuit **PLs**.



202F06081


**Operation****Normal operation**

- Normally, when the swing is operated alone, or when it is operated together with any other movement except boom RAISE or the travel, the pilot pressure does not act on pilot port **Bp**.
- In this condition, swing LS pressure pushes valve (2) open, and flows to LS circuit **PLs**.

1. LS select valve
2. Valve
3. Spring
4. Piston

- a:** Swing LS circuit (pressure)  
**PLs:** LS circuit (pressure)  
**Bp:** PPC pilot circuit (pressure)  
**T:** Tank circuit (pressure)





202F06082

**Swing + boom RAISE, or swing + travel operated together**


- When the swing + boom RAISE, or swing + travel are operated, the pilot pressure from the PPC shuttle valve flows into pilot port **Bp**.
- When pilot pressure **Bp** becomes stronger than spring (3), piston (4) is pushed to the right in the direction of the arrow, valve (2) closes, and swing LS pressure **a** does not flow into LS circuit **PLs**.
- The size of pilot pressure **Bp** is determined by the amount the control lever is operated.

- 1. LS select valve
- 2. Valve
- 3. Spring
- 4. Piston
- a**: Swing LS circuit (pressure)
- PLs**: LS circuit (pressure)
- Bp**: PPC pilot circuit (pressure)
- T**: Tank circuit (pressure)

11) Cut-off function

Function

- This function uses the TVC valve, pump controller, and pump pressure sensor, and if pump discharge pressure  $P_p$  exceeds the set pressure, it makes pump discharge amount  $Q$  the minimum.




Operation

- If the pump pressure sensor detects that the pump discharge pressure  $P_p$  has gone above the set pressure, it sends this information to the pump controller.
- When the pump controller receives this signal, it increases the signal current to TVC valve (1), and makes the pump discharge amount (swash plate angle)  $Q$  the minimum.

- TVC valve
- Solenoid

	Swing lock switch		
	On (Brake on)	Off (Brake off)	
			Power max or speed down + knob s/w on
HO	B	B	B
GO	B	A	B
FO	B	A	A
BO	B	A	A
LO	B	B	B
Travel	B	B	B

6B. Variable type pressure compensation valve (for service valve)



1. Valve
2. Spring
3. Sleeve
4. Poppet
5. Spring
6. Screw
7. Locknut
8. Plastic cap

**Function**

- It is possible to adjust the division of the oil flow to the service valve when the service valve (for attachment) is operated together with the main control valve (boom RAISE, etc.).  
(Variabel in proportion to surface area)
- The pump pressure leaving the service valve spool acts on the left end of valve (1), and at the same time passes through throttle **a** and enters chamber **g**.  
The maximum LS pressure passes through throttle **d** and enters chamber **e**. At the sametime, the cylinder port pressue passes through passage **c** and throttle **f**, and goes to chamber **h**.  
In addition, the force of spring (2) acts on valve (1), and the force of spring (5) acts on poppet (4). The force of spring (5) can be adjusted with screw (6).

Operation

Simultaneous operation with work equipment under heavy load (boom RAISE, etc.)

1. The pump pressure and LS pressure are determined by the pressure of the other work equipment, but the cylinder port pressure becomes the actuating pressure of the attachment. When the difference between the pump pressure and the cylinder pressure is less than the force of spring (5), the balance of the force acting on valve (1) is as follows.


$$P \times A_1 = P \times A_2 + LS (A_2 - A_1) + F$$

A1: Cross-sectional area of diameter D1


A2: Cross-sectional area of diameter D2

F: Force of spring

2. If the difference between pump pressure P and the cylinder pressure becomes greater than the force of spring (5), poppet (4) is pushed to the right and the passage opens, so the pump passage is connected to the cylinder port through throttle a, chamber g, and passages b and c, and the oil flows to the cylinder port. When this happens, a differential pressure is formed between the upstream and downstream sides of throttle a, and the pressure in chamber g goes down, so the force pushing valve (1) to the left is reduced. In other words, the area ratio becomes smaller, so valve (1) moves to the right and increases the flow from the pump to the cylinder.






SDPO1132



SDPO1133


SWING MOTOR




- a. Port **L**. (to control valve TSW port)
- b. Port **MB** (from control valve)
- c. Port **MA** (from control valve)
- d. Port **T** (to tank)

SPECIFICATIONS

Type	F12-060-MF-CV-C-509
Theoretical delivery	59.8 cc/rev
Safety valve set pressure	31.36 MPa (320 kg/cm <sup>2</sup> )
Rated speed	2250 rpm







- 1. Barrel housing
- 2. Valve plate
- 3. Cylinder barrel
- 4. Piston with piston rings
- 5. Timing gear
- 6. Roller bearings
- 7. Bearing housing
- 8. Shaft seal
- 9. Output/input shaft
- 10. Needle bearings
- 11. Safety valve with check valve
- 12. Check valve
- 13. Check valve spring



# CENTER SWIVEL JOINT

## 4-PORT SWIVEL




- 1. Cover
- 2. Body
- 3. Slipper seal
- 4. O-ring
- 5. Shaft


- A1. From control valve port **B2**
- A2. To R.H. travel motor port **PB**
- B1. From control valve port **B5**
- B2. To L.H. travel motor port **PA**
- C1. From control valve port **A2**
- C2. To R.H. travel motor port **PA**
- D1. From control valve port **A5**
- D2. To L.H. travel motor port **PB**
- E1. From travel speed solenoid valve
- E2. To L.H. and R.H. travel motors port **P**
- T1. To tank
- T2. From L.H. and R.H. travel motors port **T**

205F06076

TRAVEL MOTOR




- a. Port **PB** (from control valve)
- b. Port **PA** (from control valve)
- c. Port **T** (to tank)
- d. Port **X** (from travel speed solenoid valve)
- e. Port **Bri** (to parking brake release port of final drive)



SPECIFICATIONS

Type	A6VE80	
Theoretical delivery	Min.	50 cc/rev
	Max.	80 cc/rev
Cracking pressure of safety valve	37.73 MPa (385 kg/cm <sup>2</sup> ) / at 5//min	
Rated speed	Min. capacity	2650 rpm
	Max. capacity	1650 rpm
Brake releasing pressure	1.27 MPa (13 kg/cm <sup>2</sup> )	






- |                 |                          |                             |
|-----------------|--------------------------|-----------------------------|
| 1. Output       | 9. Regulator valve       | 21. Safety valve            |
| 2. Motor case   | 10. Spring               | 22. Shuttle valve           |
| 3. Ball         | 15. Regulator piston     | 23. Pressure reducing valve |
| 4. Servo piston | 16. Spring               | 24. Retainer plate          |
| 5. Piston       | 17. Check valve spring   | 25. Stopper                 |
| 6. Cylinder     | 18. Check valve          | 26. Lock nut                |
| 7. Valve plate  | 19. Counterbalance valve |                             |
| 8. End cover    | 20. Spool return spring  |                             |


OPERATION OF MOTOR

1) Motor swash plate angle (capacity) at maximum



- The solenoid valve is deactivated, so the pilot pressure oil from the control pump does not flow to port X. For this reason, regulator piston (15) is pushed to the bottom in the direction of the arrow by spring (10).
- Because of this, it pushes shuttle valve (22), and the main pressure oil from the control valve goes to regulator valve (9).
- (Piston direction), the pressurized oil at regulator valve (9) passes through orifice "a" and goes to chamber "b"
- As a result, servo piston (4) moves in the maximum swash plate angle direction, the motor capacity becomes maximum.
- At the same time the oil in chamber "d" passes through passage in (15) and goes to drain port.

2) Motor swash plate angle (capacity) at minimum



- When the solenoid valve is excited, the pilot pressure oil from the control pump flows to port **X**, and pushes regulator piston (15) to the up in the direction of the arrow.
- Because of this, the main pressure oil from the control valve passes through passage in regulator valve (9), and goes to chamber "d".
- As a result, servo piston (4) moves in the minimum swash plate angle direction, the motor capacity becomes minimum.
- At the same time the oil in chamber "b" passes through passage in piston (15) and goes to drain port.




**OPERATION OF PARKING BRAKE**

**1) When starting to travel**


When the travel lever is operated, the pressurized oil from the pump passes through shuttle valve (22) and goes to pressure reducing valve (23). The oil pressure is reduced by this valve and flows into chamber **A**. This circuit pressure is kept Max 23 bar by pressure reducing valve (23).

It overcomes the force of spring (11), and pushes piston (12) to the left in the direction of the arrow.

When this happens, the force pushing plate (13) and disc (14) together is lost, so plate (13) and disc (14) separate and the brake is released



OPERATION OF PARKING BRAKE



2) When stopping travel

When the travel lever is placed in neutral, Travel Control valve returns to the neutral position.


The pressurized oil in chamber A of brake piston (12) is drained to the case from the orifice (27) and brake piston (12) is pushed in the direction of the arrow by spring (11).

As a result, plate (13) and disc (14) are pushed together, and the brake is applied.

A time delay is provided by having the pressurized oil pass through orifice (27) when the brake piston returns, and this ensures that the brake still effective after the machine stops.


**OPERATION OF BRAKE VALVE**

- The brake valve consist of a check valve, counterbalance valve, and safety valve in a circuit as shown in the diagram on the right. (Fig.1)
- The function and operation of each component is as given below.




**1) Counterbalance valve, check valve  
Function**

- When traveling downhill, the weight of the machine makes it try to travel faster than the speed of the motor.  
As a result, if the machine travels with the engine at low speed, the motor will rotate without load and the machine will run away, which is extremely dangerous.  
To prevent this, these valves act ot make the machine travel according to the engine speed (pump discharge amount).



**Operation when pressure oil is supplied**

- When the travel lever is operated, the pressurized oil from the control valve is supplied to port **PA**. It pushes open check valve (18A) and flows from motor inlet port **MA** to motor outlet port **MB**.  
However, the motor outlet port is closed by check valve (18B) and spool (19), so the pressure at the supply side rises. (Fitg.2)
- The pressurized oil at the supply side flows from orifice **E1** in spool (19) and shuttle orifice **E2** in the piston to chamber **S1**. When the pressure in chamber **S1** goes above the spool switching pressure, spool (19) is pushed to the right in the direction of the arrow.  
As a result, port **MB** and **PB** are connected, the outlet port side of the motor is opened, and the motor starts to rotate. (Fig. 3)




### Operation of brake when traveling downhill

- If the machine tries to run away when traveling downhill, the motor will turn under no load, so the pressure at the motor inlet port will drop, and the pressure in chamber S1 through offices E1 and E2 will also drop.

When the pressure in chamber S1 drops below the spool switching pressure, spool (19) is returned to the left in the direction of the arrow (20), and outlet port MB is throttled. (Fig.4)

As a result, the pressure at the outlet port side rises, resistance is generated to the rotation of the motor, and this prevents the machine from running away.

In other words, the spool moves to a position where the pressure at outlet port MB balances the pressure at the inlet port and the force generated by the weight of the machine. It throttles the outlet port circuit and controls the travel speed according to the amount of oil discharged from the pump. (Fig. 4)




## 2) Safety valve

### Function

- When travel is topped (or when traveling downhill), the circuits at the inlet and outlet ports of the motor are closed by the counterbalance valve, but the motor is rotated by inertia, so the pressure at the outlet port of the motor will become abnormally high and damage the motor or piping. The safety valve acts to release this abnormal pressure and send it to the inlet port side of the motor to prevent damage to the equipment.

VALVE CONTROL



- 1. Travel PPC valve
- 2. Service PPC valve
- 3. Service pedal
- 4. L.H. travel lever
- 5. R.H. travel lever
- 6. R.H. PPC valve
- 7. R.H. work equipment lever
- 8. LS control EPC valve

- 9. Hydraulic pump
- 10. Control valve
- 11. PPC shuttle valve
- 12. Accumulator
- 13. Solenoid valve block
- 14. L.H. work equipment lever
- 15. Safety lock valve
- 16. L.H. PPC valve
- 17. Safety lock lever


**Lever positions**

- ① Neutral
- ② Boom RAISE
- ③ Boom LOWER
- ④ Bucket DUMP
- ⑤ Bucket CURLL
- ⑥ Neutral
- ⑦ Arm In
- ⑧ Arm OUT

- ⑨ Swing RIGHT
- ⑩ Swing LEFT
- ⑪ Neutral
- ⑫ Travel REVERSE
- ⑬ Travel FORWARDS
- ⑭ LOCK
- ⑮ FREE








WORK EQUIPMENT • SWING PPC VALVE



20UF02032

- a. Port **P** (from control pump)
- b. Port **T** (to tank)
- c. Port **P2** (L.H. : Arm IN/ R.H.: Boom RAISE)
- d. Port **P4** (L.H.: Swing LEFT/ R.H.: Bucket DUMP)
- e. Port **P1** (L.H.: Arm OUT/ R.H.: Boom LOWER)
- f. Port **P3** (L.H.: Swing RIGHT/ R.H.: Bucket CURL)



20UF02033


- 1. Spool
- 2. Metering spring
- 3. Centering spring
- 4. Piston
- 5. Disc
- 6. Nut (for connecting lever)

- 7. Joint
- 8. Plate
- 9. Retainer
- 10. Body
- 11. Filter

**OPERATION**

**1) At neutral**

Ports **A** and **B** of the control valve and ports **P1** and **P2** of the PPC valve are connected to drain chamber **D** through fine control hole "f" in spool (1). (Fig.1)



20TF01044

**2) During fine control (neutral fine control)**

When piston (4) starts to be pushed by disc (5), retainer (9) is pushed; spool (1) is also pushed by metering spring (2), and moves down.

When this happens, fine control hole "f" is shut off from drain chamber **D**, and at almost the same time, it is connected to pump pressure chamber **Pp**, so pilot pressure oil from the control pump passes through fine control hole "f" and goes from port **P1** to port **A**.


When the pressure at port **P1** becomes higher, spool (1) is pushed back and fine control hole "f" is shut off from pump pressure chamber **Pp**.

At almost the same time, it is connected to drain chamber **D** to release the pressure at port **P1**.

When this happens, spool (1) moves up or down so that the force of metering spring (2) is balanced with the pressure at port **P1**. The relationship in the position of spool (1) and body (10) (fine control hole "f" is at a point midway between drain hole **D** and pump pressure chamber **Pp**) does not change until retainer (9) contacts spool (1).

Therefore, metering spring (2) is compressed proportionally to the amount of movement of the control lever, so the pressure at port **P1** also rises in proportion to the travel of the control lever.

In this way, the control valve spool moves to a position where the pressure in chamber **A** (the same as the pressure at port **P1**) and the force of the control valve spool return spring are balanced. (Fig.2)



20TF01045


**3) During fine control  
(when control lever is returned)**

When disc (5) starts to be returned, spool (1) is pushed up by the force of centering spring (3) and the pressure at port **P1**.

When this happens, fine control hole "f" is connected to drain chamber **D** and the pressure oil at port **P1** is released.

If the pressure at port **P1** drops too far, spool (1) is pushed down by metering spring (2), and fine control hole "f" is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **Pp**, and the pump pressure is supplied until the pressure at port **P1** recovers to a pressure that corresponds to the lever position. When the spool of the control valve returns, oil in drain chamber **D** flows in from fine control hole "f" in the valve on the side that is not working.

The oil passes through port **P2** and enters chamber **B** to fill the chamber with oil. (Fig. 3)




20TF01046

**4) At full stroke**

When disc (5) pushes down piston (4), and retainer (9) pushes down spool (1), fine control hole "f" is shut off from drain chamber **D**, and is connected with pump pressure chamber **Pp**.


Therefore, the pilot pressure oil from the control pump passes through fine control hole "f" and flows to chamber **A** from port **P1**, and pushes the control valve spool.

The oil returning from chamber **B** passes from port **P2** through fine control hole "f" and flows to drain chamber **D**. (Fig. 4)




20TF01047

TRAVEL PPC VALVE




205F06 | 02


- a. Port **P** (from control pump)
- b. Port **T** (to tank)
- c. Port **P1** (L.H. travel REVERSE)
- d. Port **P3** (R.H. travel REVERSE)
- e. Port **P2** (L.H. travel FORWARD)
- f. Port **P4** (R.H. travel FORWARD)




A-A



B-B



C-C



D-D

- 1. Piston
- 2. Plate
- 3. Collar
- 4. Body


- 5. Valve
- 6. Metering spring
- 7. Centering spring
- 8. Bolt

205F06103

**OPERATION**

**1. At neutral**

Ports **A** and **B** of the control valve and ports **P1** and **P2** of the PPC valve are connected to drain chamber **D** through fine control hole "f" in spool (1). (Fig. 1)



22TF01094

**2. Fine control (neutral → fine control)**

When piston (4) starts to be pushed by disc (5), retainer (9) is pushed. Spool (1) is also pushed by metering spring (2) and moves down.

When this happens, fine control hole "f" is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **Pp**, and the pilot pressure of the control pump is sent from port **A** through fine control hole "f" to port **P1**.


When the pressure at port **P1** rises, spool (1) is pushed back. Fine control hole "f" is shut off from pump pressure chamber **Pp**. At almost the same time, it is connected to drain chamber **D**, so the pressure at port **P1** escapes.

As a result, spool (1) moves up and down until the force of metering spool (2) is balanced with the pressure of port **P1**.

The relationship of the positions of spool (1) and body (10) (fine control hole "f" is in the middle between drain hole **D** and pump pressure chamber **Pp**) does not change until retainer (9) contacts spool (1).

Therefore, metering spring (2) is compressed in proportion to the travel of the control lever, so the pressure at port **P1** also rises in proportion to the travel of the control lever.

In this way, the spool of the control valve moves to a position where the pressure of chamber **A** (same as pressure at port **P1**) and the force of the return spring of the control valve spool are balanced. (Fig. 2)



22TF01095

**3. Fine control (control lever returned)**


When disc (5) starts to be returned, spool (1) is pushed up by the force of centering spring (3) and the pressure at port **P1**.

Because of this, fine control hole "f" is connected to drain chamber **D**, and the pressurized oil at port **P1** is released.

If the pressure at port **P1** drops too much, spool (1) is pushed up by metering spring (2), so fine control hole "f" is shut off from drain chamber **D**.

At almost the same time, it is connected to pump pressure chamber **Pp**, so the pressure at port **P1** supplies the pump pressure until the pressure recovers to a pressure equivalent to the position of the lever.


When the control valve returns, oil in drain chamber **D** flows in from fine control hole "f" of the valve on the side that is not moving. It passes through port **P2** and goes to chamber **B** to charge the oil. (Fig. 3)



22TF01096

**4) At full stroke**


Disc (5) pushes down piston (4), and retainer (9) pushes down spool (1). Fine control hole "f" is shut off from drain chamber **D**, and is connected to pump pressure chamber **Pp**. Therefore, the pilot pressure oil from the control pump passes through fine control hole "f" and flows to chamber **A** from port **P1** to push the control valve spool. The return oil from chamber **B** passes from port **P2** through fine control hole "f" and flows to drain chamber **D**. (Fig. 4)




22TF01097



SERVICE PPC VALVE




- 1. Pin
  - 2. Cam
  - 3. Ball
  - 4. Piston
  - 5. Cover
  - 6. Sleeve
  - 7. Centering spring
  - 8. Metering spring
  - 9. Spool
  - 10. Body
- a. Port T (to tank)
  - b. Port P (from control pump)
  - c. Port A (to service valve P1)
  - d. Port B (to service valve P2)



**OPERATION**


**At neutral**

- The pressurized oil from the control pump enters from port **P** and is blocked by spool (9).
- Port **A** and **B** of the control valve and port "a" and "b" of the PPC valve are connected to drain port **T** through fine control hole **X** of spool (9).




**When operated**


- When cam (2) is moved, metering spring (8) is pushed by ball (3), piston (4), and sleeve (6), and spool (9) is also pushed down by this.
- As a result, fine control hole **X** is shut off from the drain circuit. At almost the same time, fine control portion **Y** is connected with port "a", and the pressurized oil from port **P** flows from port "a" to port **A** of the control valve.




- When the pressure at port "a" becomes higher, spool (9) is pushed back by the force acting on the end of the spool. When fine control portion Y closes, fine control hole X is connected to the drain circuit at almost the same time.
- As a result, spool (9) moves up and down to balance the force at port "a" and the force at metering spring (8).
- Therefore, metering spring (8) is compressed in proportion to the amount the control lever is moved. The spring force becomes larger, so the pressure at port "a" also increases in proportion to the amount the control lever is operated.
- In this way, the control valve spool moves to a position where the pressure of port A (the same as the pressure at port "a") is balanced with the force of the return spring of the control valve spool.



### SAFETY LOCK VALVE




- 1. Lever
- 2. Body
- 3. Seat
- 4. Ball
- 5. End cap



F205C5018


### PPC ACCUMULATOR



- 1. Gas plug
- 2. Shell
- 3. Poppet
- 4. Holder
- 5. Bladder
- 6. Oil port

**SPECIFICATIONS**  
Gas capacity: 400 cc

# PPC SHUTTLE • TRAVEL JUNCTION VALVE




1. PPC shuttle valve
2. Travel junction valve

**OUTLINE**

- The PPC shuttle valve and travel junction valve form a combined structure.


PPC SHUTTLE VALVE



**FUNCTION**

This sends the PPC valve output pressure or EPC valve output pressure to the control valve and travel junction valve. It is provided with a mount port for the pressure switch for detecting the pilot pressure.

- a. Port **P11** (to control valve [swing])
- b. Port **P21** [to control valve (swing)]
- c. Port **P31** [to control valve (bucket)]
- c. Port **P41** [to control valve (bucket)]
- e. Port **P51** [to control valve (boom)]
- f. Port **P61** [to control valve (arm)]
- g. Port **PLS** (to LS select valve)
- h. Port **P71** [to control valve (arm)]
- i. Port **P81** [to control valve (boom)]
- j. Port **PA1** [to control valve (R.H. travel)]
- k. Port **PB1** [to control valve (L.H. travel)]
- l. Port **PC1** [to control valve (L.H. travel)]
- m. Port **P91** [to control valve (R.H. travel)]
- n. Port **P12** (from swing PPC valve)
- o. Port **P22** (from swing PPC valve)
- p. Port **P32** (from bucket PPC valve)
- q. Port **P42** (from bucket PPC valve)
- r. Port **P52** (from boom PPC valve)
- s. Port **P62** (from arm PPC/EPC valve)
- t. Port **P72** (from arm PPC/EPC valve)
- u. Port **P82** (from boom PPC/EPC valve)
- v. Port **PA2** (from R.H. travel PPC valve)
- w. Port **PB2** (from L.H. travel PPC valve)
- x. Port **PC2** (from L.H. travel PPC valve)
- y. Port **P92** (from R.H. travel PPC valve)
- z1. Port **PR** (to travel junction valve)
- z2. Port **PF** (to travel junction valve)
- aa. Port **A1** (mount port for swing oil pressure switch)
- ba. Port **A8** (mount port for bucket DUMP oil pressure switch)
- bb. Port **A2** (mount port for bucket CURL oil pressure switch)
- ca. Port **A4** (mount port for arm OUT oil pressure switch)
- cb. Port **A3** (mount port for arm IN oil pressure switch)
- da. Port **A5** (mount port form boom RAISE oil pressure switch)
- db. Port **A7** (mount port for boom LOWER oil pressure switch)
- ee. Port **A6** (mount port for travel oil pressure switch)




KW130P6033

**PPC shuttle valve**

1. Ball
2. Plug
3. Blind plug
4. Valve body




TRAVEL JUNCTION VALVE



- 1. Body
- 2. Plug
- 3. Spring
- 4. Spool

- a. Port **T1** (from R.H. travel control valve)
- b. Port **T2** (from L.H. travel control valve)
- c. Port **T3** (from R.H. travel control valve)
- d. Port **T4** (from L.H. travel control valve)
- e. Port **PF** (from PPC shuttle valve)
- f. Port **PR** (from PPC shuttle valve)
- g. Port **PS** (to control valve (arm))

**STRAIGHT-TRAVEL SYSTEM**



**FUNCTION**


- A travel junction valve is installed between the travel valve and travel motor to compensate for any difference in the oil flow to the left and right travel circuits when traveling in a straight line.
- Because of this, the flow of oil to the left and right travel motors when traveling in a straight line is almost the same, so there is no travel deviation.
- The travel junction valve interconnects the travel circuit when the straight-travel is operated independently or when the straight travel + another actuator are operated simultaneously.
- When steering, if the difference in the movement of the travel levers is more than approx. 10 mm, the travel junction valve is switched, and the left and right travel circuits are shut off.

**OPERATION**

- A: PPC output pressure (R.H. travel REVERSE or L.H. travel FORWARD)
- B: PPC output pressure (R.H. travel FORWARD or L.H. travel REVERSE)

**When traveling in a straight line in forward or reverse**


- When traveling forward (or in reverse), there is no difference in the pilot pressure from the PPC shuttle valve (the output pressure of each PPC valve), so the spool is balanced in the middle. In this condition, the R.H. FORWARD and L.H. FORWARD, and R.H. REVERSE and L.H. REVERSE are interconnected through the spool.



205F06109

**When steering in forward or reverse**


- When the steering is operated in forward (or reverse), if the difference in the pilot pressure from the PPC shuttle valve becomes greater than the switching pressure (spring force), the spool moves to the right or left and the L.H. and R.H. forward and L.H. and R.H. reverse passages are separated. Because of this, a difference in pressure is created in the L.H. and R.H. circuits, and the steering can be operated.



205F06110

# EPC • SOLENOID VALVE


## LS SELECT, 2-STAGE RELIEF, TRAVEL SPEED, SWING BRAKE SOLENOID VALVE



202F06123

- a. Port **A5** (to pump LS valve)
- b. Port **T2** (to LS select valve)
- c. Port **T1** (from PPC valve)
- d. Port **T0** (to tank)
- e. Port **A1** (to L.H. and R.H. travel motor)
- f. Port **A2** (to swing motor)
- g. Port **A3** (to main relief valve)
- h. Port **A4** (to LS bypass valve)
- i. Port **P1** (to PPC valve)
- j. Port **P0** (from control pump)

- 1. LS control EPC valve
- 2. LS bypass solenoid valve
- 3. 2-stage relief solenoid valve
- 4. Swing brake solenoid valve
- 5. Travel speed solenoid valve
- 6. Valve block




205F06112

**OPERATION**

**When solenoid is deactivated**


- The signal current does not flow from the controller, so coil (3) is deactivated. For this reason, spool (5) is pushed to the right in the direction of the arrow by spring (6). As a result, the circuit between ports P and A closes and the pressurized oil from the control pump does not flow to the actuator. At the same time, the pressurized oil from the actuator flows from port A to port T, and is then drained to the tank.



205F06113


**When solenoid is excited**

- When the signal current flows from the controller to coil (3), coil (3) is excited. For this reason, spool (5) is pushed to the left in the direction of the arrow. As a result, the pressurized oil from the control pump flows from port P through the inside of spool (5) to port A, and then flows to the actuator. At the same time, port T is closed, and this stops the oil from flowing to the tank.



205F06114

LS CONTROL EPC VALVE



205F06115


- 1. Body
- 2. Spool
- 3. Spring
- 4. Push pin

- 5. Coil
- 6. Plunger
- 7. Connector

- a. Port C (to LS valve)
- b. Port T (to tank)
- c. Port P (from control pump)

**FUNTION**


- The EPC valve consists of the proportional solenoid portion and the hydraulic valve portion.
- When it receives signal current "i" from the valve controller, it generated the EPC output pressure in proportion to the size of the signal, and outputs it to the control valve.



**OPERATION**


1. When signal current is 0 (coil deactivated)
  - There is no signal current flowing from the controller to coil (5), coil (5) is deactivated.
  - For this reason, spool (2) is pushed to the right in the direction of the arrow by spring (3).
  - As a result, port **P** closes and the pressurized oil from the control pump does not flow to the LS valve.

At the same time, the pressurized oil from the LS valve passes from port **C** through port **T** and is drained to the tank.




**2. When signal current is very small (coil excited)**

- When a very small signal current flows to coil (5) is excited, and a propulsion force is generated, which pushes plunger (6) to the left in the direction of the arrow.
- Push pin (4) pushes spool (2) to the left in the direction of the arrow, and pressurized oil flows from port **P** to port **C**.
- When the pressure at port **C** rises and the load of spring (3) + the force acting on surface "a" of spool (2) becomes greater than the propulsion force of plunger (6), spool (2) is pushed to the right in the direction of the arrow. The circuit between port **P** and port **C** is shut off, and at the same time, port **C** and port **T** are connected.
- As a result, spool (2) is moved to the left or right until the propulsion force of plunger (6) is balanced with the load of spring (3) + pressure of port **C**.
- Therefore, the circuit pressure between the EPC valve and the LS valve is controlled in proportion to the size of the signal current.



**3. When signal current is maximum (coil excited)**

- When the signal current flows to coil (5), coil (5) is excited.
- When this happens, the signal current is at its maximum, so the propulsion force of plunger (6) is also at its maximum.
- For this reason, spool (1) is pushed to the left in the direction of the arrow by push pin (4).
- As a result, the maximum flow or pressurized oil from port **P** flows at its maximum to port **C**, and the circuit pressure between the EPC valve and LS valve becomes the maximum.
- At the same time, port **T** closes and stops the oil from flowing to the tank.






# HYDRAULIC CYLINDER

## SPECIFICATIONS

Unit: mm

Item	Boom		Arm		Bucket	
	PC180LC-6K	PC160-6K	PC180LC-6K	PC160-6K	PC180-6K	PC160-6K
Outside diameter of piston rod	75	75	85	85	75	70
Inside diameter of cylinder tube	110	110	120	120	110	105
Stroke	1170	1170	1352	1352	1013	1013
Max. stroke	2805	2805	3285	3285	2560	2560
Min. stroke	1635	1635 </td <td>1933</td> <td>1933</td> <td>1547</td> <td>1547</td>	1933	1933	1547	1547


## BOOM CYLINDER



FK203P5016

- |                     |                 |                         |
|---------------------|-----------------|-------------------------|
| 1. Rod side bushing | 6. Wear ring    | 11. Piston              |
| 2. Piston rod       | 7. Cylinder     | 12. Set screws          |
| 3. Cylinder head    | 8. Casting ring | 13. Bottom side bushing |
| 4. Rod packing      | 9. Wear ring    |                         |
| 5. Buffer ring      | 10. Piston ring |                         |


### ARM CYLINDER



FK203P5018

- |                     |                              |                                 |
|---------------------|------------------------------|---------------------------------|
| 1. Rod side bushing | 7. Cylinder                  | 13. Set screw                   |
| 2. Piston rod       | 8. Head side cushion plunger | 14. Bottom side cushion plunger |
| 3. Cylinder head    | 9. Casting ring              | 15. Bottom side bushing         |
| 4. Rod packing      | 10. Wear ring                |                                 |
| 5. Buffer ring      | 11. Piston ring              |                                 |
| 6. Wear ring        | 12. Piston                   |                                 |

### BUCKET CYLINDER





FK203P5021

- |                     |                 |                         |
|---------------------|-----------------|-------------------------|
| 1. Rod side bushing | 6. Wear ring    | 11. Piston              |
| 2. Piston rod       | 7. Cylinder     | 12. Set screw           |
| 3. Cylinder head    | 8. Casting ring | 13. Bottom side bushing |
| 4. Rod packing      | 9. Wear ring    |                         |
| 5. Buffer ring      | 10. Piston ring |                         |

## ADDITIONAL FILTER FOR BREAKING

★ For machine equipped with breaker



205F06096


1. Head cover
2. Element
3. Case
4. Drain plug
5. Valve
6. Spring
7. Spring set plug

### SPECIFICATIONS

Rated pressure : 6.86 MPa (70 kg/cm<sup>2</sup>)  
 Flow : 107 l/min  
 Relief valve cracking pressure : 0.34 ± 0.049 MPa  
 (3.5 ± 0.5 kg/cm<sup>2</sup>)  
 Filter mesh size : 6 μm  
 Filtering area : 3160 cm<sup>2</sup>

## OVERLOAD WARNING DEVICE

### 1. OUTLINE




### FUNCTION

- This device is installed to warn the operator when the machine is close to tipping over when it lifts an excessive weight while being used as a crane.

### STRUCTURE

- When an excessive weight is lifted, the oil pressure goes up at the bottom side of the boom cylinders. When this happens, the pressure switch senses the rising pressure, turns the pressure switch on, and lights the monitor lamp to warn the operator. When the monitor lamp lights, immediately lower the weight to the ground or bring the arm closer in to the operator to prevent the machine from tipping over.

Control panel



## 2. OPERATION

- Hose (2) directs the oil pressure from the bottom side of the boom cylinders to pressure switch (3).

### a. When the boom is in the lowest position

- When boom (5) is in the lowest position, lever (4) takes position **A** in Fig. 1 and the pressure to activate its switch (closed and open) becomes  $60 \text{ kg/cm}^2$ .

### b. When the boom is in the highest position

- When the boom is in the highest position, lever (4) takes position **B** in Fig. 1 and the pressure to activate the switch becomes  $360 \text{ kg/cm}^2$ .

### c. When the boom is in an arbitrary position

- When the boom is in a position anywhere between the lowest and the highest points, the operating pressure of switch (3) will be somewhere between  $360 \text{ kg/cm}^2$ , based on the boom position.

For instance, when the boom is in a certain position between the lowest and the highest points, lever (4) takes a position which corresponds to that boom position.

If lever (4) is in the position to make the operating pressure of the pressure switch  $150 \text{ kg/cm}^2$  (which is the same pressure as the bottom side of the boom cylinder), the pressure switch will turn on when excessive weight is lifted by the boom and the oil pressure of the bottom of the boom cylinders exceeds  $150 \text{ kg/cm}^2$ .



When the machine is performing any kind of operation other than lifting loads, fasten the pressure switch lever (4) with the bolt (6) to prolong the life at the pressure switch.




FIG.1

3. ADJUSTING PRESSURE OF THE OIL PRESSURE SWITCH

- **Screw D: Pressure range adjustment screw**


To make an adjustment so that the oil pressure switch acts normally when checking the operation of the overload warning device.


Turning to the left makes the pressure range wider.

- **Screw E: Zero point adjustment screw**



Turning to the right one complete turn raises the pressure by 57 kg/cm<sup>2</sup>.

Each complete turn to the left lowers the pressure by 57 kg/cm<sup>2</sup>.


 When an adjustment is required, contact your Komatsu distributor and have him make the adjustment.



1. Body
2. Boudon tube
3. Eccentric disc
4. Microswitch
5. Lever and roller
6. Adjustment screw (E)
7. Adjustment screw (D)




Screw E



Screw D

## HOSE BURST PROTECTION VALVE (BOOM)


**FUNCTION**

- This valve prevents sudden uncontrolled lowering of the boom, when lifting, due to the burst of a hose in the boom cylinder line. In such a condition this valve will hold the load until operator lowers the boom in a controlled way using the normal wrist control.



**When hose burst occurs****(Operation to lower safety)**


- The sudden loss of pressure at port **V** will cause check valve (4) to re-seat and so the valve is locked.
- The boom can be lowered in a controlled way by operating the wrist control in the normal way.



**OPERATION**


**BOOM RAISE**

- During boom raising the pilot signal from wrist control operates control valve spool to direct high pressure oil to port **V** of hose burst valve.
- This pressure lifts check valve (4) from seat & high pressure oil flows in the bottom of the cylinder raising the boom.




**BOOM LOWER**

- During boom lowering the pilot signal reverses the front through the control valve spool. High pressure oil flows to the head side of the cylinder. Oil in the bottom side of the cylinder flows through the port **Cy** of the valve but cannot flow past the check valve. the pilot signal also opens the spool (2) of the hose burst valve and allows oil to flow back to tank.




# WORK EQUIPMENT



- 1. Arm
- 2. Bucket cylinder
- 3. Arm cylinder
- 4. Boom
- 5. Boom cylinder
- 6. Bucket



## ENGINE CONTROL SYSTEM



202F06148

## FUNCTION


1. Starting motor
2. Fuel control dial
3. Pump end engine throttle controller
4. Governor motor
5. Loose spring
6. Battery relay
7. Battery
8. Fuel injection pump

- The engine can be started and stopped simply by using the starting switch.
- A dial type engine control is used to control the engine speed. The engine throttle controller receives the control signal from the fuel control dial, sends a drive signal to the governor motor, and controls the angle of the governor lever in the fuel injection pump.
- At the same time, the engine throttle controller also receives signals from other controllers to control the engine speed.

### 1. OPERATION OF SYSTEM


#### Starting engine

- When the starting switch is turned to the START position, the starting signal flows to the starting motor, and the starting motor turns to start the engine. When this happens, the engine throttle controller checks the signal from the fuel control dial and sets the engine speed to the speed set by the fuel control dial.




#### Engine speed control

- The fuel control dial sends a signal to the engine throttle controller according to the position of the dial. The engine throttle controller calculates the angle of the governor motor according to this signal, and sends a signal to drive the governor motor so that it is at that angle. When this happens, the operating angle of the governor motor is detected by the potentiometer, and feedback is sent to the engine throttle controller, so that it can observe the operation of the governor motor.




#### Stopping engine

- When the starting switch is placed at the OFF position, the shut off valve is closed so the supply of fuel to the engine is shut off and the engine stops.






2. COMPONENTS OF SYSTEM


1) FUEL CONTROL DIAL



1. Knob
2. Dial
3. Spring
4. Ball
5. Potentiometer
6. Connector




Composition of circuit



205F05113

**FUNCTION**

- The fuel control dial is installed at the bottom of the monitor panel. A potentiometer is installed under the knob, and when the knob is turned, it rotates the potentiometer shaft. When the shaft rotates, the resistance of the variable resistor inside the potentiometer changes, and the desired throttle signal is sent to the engine throttle controller. The shaded area in the graph on the right is the abnormality detection area and the engine speed is set at low idling.




Characteristics of throttle voltage

205F05114

2) GOVERNOR MOTOR

1. Potentiometer
2. Cover
3. Shaft
4. Dust seal
5. Bearing
6. Motor
7. Gear
8. Connector



202F06149

**FUNCTION**

- The motor is rotated and the governor lever of the fuel injection pump is controlled by the drive signal from the engine throttle controller.
  - A stepping motor is used for the motor which provides the motive power.
  - In addition, a potentiometer for giving feedback is installed to allow observation of the operation of the motor.
- The rotation of the motor is transmitted to the potentiometer through a gear.

**OPERATION**

Motor stationary



- Both A phase and B phase of the motor are continuous, and a holding torque is generated in de motor.

Motor rotating

- A pulse current is applied to the A phase and B phase from the engine throttle controller to give synchronous rotation with the pulse.



Governor, pump controller



SAP00327

Input and output signals

CN-1

Pin. No.	Name of signal	Input/output
1	Battery relay drive output	Output
2	Pump merge/divider solenoid /NC	Output
3	Swing holding brake solenoid	Output
4	NC	
5	NC	
6	GND	Input
7	Power source (+24V)	Input
8	NC	
9	Travel selector solenoid	Output
10	2-stage relief solenoid	Output
11	NC	
12	GND	Input
13	Power source (+24V)	Input

CN-2

Pin. No.	Name of signal	Input/output
1	Solenoid power source (+24V)	Input
2	Governor motor phase A (+)	Output
3	Governor motor phase A (-)	Output
4	Governor motor phase B (+)	Output
5	Governor motor phase B (-)	Output
6	NC	
7	LS-EPC solenoid (+)	Output
8	TVC solenoid 1 (+)	Output
9	NC	
10	NC	
11	PGND	Input
12	Solenoid power source (+24V)	Input
13	NC	
14	NC	
15	NC	
16	NC	
17	LS-EPC solenoid (-)	Output
18	TVC solenoid 1 (-)	Output
19	NC	
20	NC	
21	PGND	Input


CN-3

Pin. No.	Name of signal	Input/output
1	Engine water temperature sensor	Input
2	Fuel level sensor	Input
3	Pump F pressure input	Input
4	Throttle potentiometer input	Input
5	NC	
6	Pressure sensor power source (+24V)	Output
7	Potentiometer power source (+5V)	Output
8	Starting switch (ACC)	Input
9	Knob switch	Input
10	NC	
11	NC	
12	Battery charge (alternator terminal R)	Input
13	NC	
14	Feedback potentiometer input	Input
15	NC	
16	Pressure sensor GND	Input
17	Potentiometer GND	Input
18	Starting switch (terminal C)	Input
19	Automatic greasing controller abnormality	Input
20	NC	
21	NC	
22	Boom RAISE pressure switch	Input
23	Arm IN pressure switch	Input
24	S-NET(+)	Input, output
25	Model selection 1	Input
26	Model selection 3	Input
27	Model selection 5	Input
28	Swing prolix switch	Input
29	Overload sensor	Input
30	Boom LOWER pressure switch	Input
31	Arm OUT pressure switch	Input
32	S-NET(+)	Input, output
33	Model selection 2	Input
34	Model selection 4	Input
35	Kerosene mode selection	Input
36	Swing lock switch	Input

CN-5

Pin. No.	Name of signal	Input/output
1	Engine speed sensor GND	Input
2	Engine speed sensor	Input
3	S-NET (-)	Input/output
4	GND	Input
5	Swing pressure switch	Input
6	Service valve pressure switch	Input
7	Engine oil pressure sensor H	Input
8	Radiator water level sensor	Input
9	NC	
10	NC	
11	Bucket CURL pressure switch	Input
12	Bucket DUMP pressure switch	Input
13	Travel pressure switch	Input
14	NC	
15	Engine oil pressure sensor L	Input
16	Engine oil level sensor	Input
17	Air cleaner clogging sensor	Input


1. Pump & Engine Mutual control system



FUNCTION


- There are five modes available for selection with the working mode switch on the monitor panel. These modes are the heavy-duty operation (H/O) mode, general operation (G/O) mode, finishing operation (F/O) mode, lifting operation (L/O mode), and the breaker operation (B/O) mode. It is possible to select the most suitable engine torque and pump absorption torque to match the nature of the work.
- The pump controller detects the actual engine speed and the speed set by the engine governor through the fuel control dial matches the pump absorption torque set for each mode, and carries out control so that the pump absorbs all of the torque at each output point of the engine.

• Engine torque curve




202F06154

• Engine horsepower curve



202F06155




• Pump output curve



1) **Control method in each mode Heavy-duty operation (H/O) mode**

- Matching point in heavy-duty operation mode:  
Rated output point
- When the load on the pump rises and the pressure rises, the engine speed goes down. When this happens, the pump discharge amount is reduced, and the engine speed is controlled so that it becomes the rated speed. Just the cut-off at relief is canceled and the oil flow at relief is increased.
- If the reverse happens and the pressure goes down, the system is controlled so that the pump discharge amount is increased until the engine speed reaches the rated speed. By repeating this control, the engine can always be used at near the rated output point.




Model	PC180,PC150-6K
Heavy-duty operation (H/O)	81 kW (107 Hp) 2,100 rpm



**General operation (G/O), finishing operation (F/O) mode**

- Matching point in general operation and finishing operation modes: 75% partial output point.
- When the load on the pump rises and the pressure rises, the engine speed goes down. When this happens, mutual control of the engine and pump is used to control the system so that the pump absorption torque follows the equal horsepower curve of the engine, and the engine speed is lowered while keeping the torque constant.
- In this way, the engine is used in a range which provides good fuel efficiency.


Model	PC180,PC160-6K
General operation (G/O), Finishing operation (F/O)	60 kW (81 Hp) 1,910 rpm




**Lifting operation (L/O) mode**

- Matching point in lifting operation mode: 65 % partial output point
- When the lifting operation mode is selected, the engine speed is automatically lowered to the partial position.  
The cut-off function is canceled and also the relief pressure is increased.
- In this condition, control is carried out in the same way as for the general operation and finishing operation modes to match the load on the pump.
- In this way, the fuel consumption is reduced and the fine control ability is improved.


Model	PC180,PC160-6K
Lifting operation (L/O)	53 kW (70HP) 1,780 rpm



202F06163



202F06164




202F06165


**Breaker operation (B/O) mode**

- Matching point in breaker operation mode: 75% partial output point
- The pump absorption torque in the breaker operation mode is the same as for the general operation and finishing operation modes, and is controlled to become an even lower speed.
- As a result, the pump absorption torque needed to ensure the breaker drive is ensured, and the engine is used in a range that provides a much better fuel consumption ration than for the general operation mode or finishing mode.


Model	PC180,PC160-6K
Breaker operation (B/O)	60 kW (81 HP) 1,910 rpm



202F06166






202F06167



202F06168

Power max. mode




- Matching point in power max. mode:  
Rated output point

Model	PC180, PC160K
Mode	
Power max.	81 kW (107 HP) 2100 rpm


- When the pump load increases, the engine speed drops. When this happens, the pump discharge is reduced to prevent the engine speed from going down and to ensure that the engine is used at near the rated output point. The cut-off at relief is canceled and the oil flow at relief is increased. And also the relief pressure is increased.

2) **Pump control function when traveling**

- If the travel is operated in any working mode other than the heavy-duty operation (H/O) mode, the working mode and engine speed are kept as they are, and the pump absorption torque is increased to the maximum horsepower at that speed.




202F06169




202F06170

3) **Control function when TVC prolix switch is ON.**

- Even if any abnormality should occur in the controller or sensor, the TVC prolix switch can be turned ON to provide an absorption torque more or less equivalent to the general operation (G/O) mode, thereby allowing the machine to maintain its functions.
- In this case, it is designed to allow a constant current to flow from the battery to the TVC valve, so oil pressure sensing is carried out only by the TVC valve.




202F06171



202F06172

## 2. Pump and valve control function




## FUNCTION

- The following functions are available to provide the optimum matching under various working conditions: a cut-off function which reduces the relief loss; a function which cancels the cut-off function and prevents the speed from dropping; a 2-stage relief function which increases the digging power; and a fine control mode function which improves the ease of fine control.



1) LS control function


- The switching point (LS set differential pressure) for the pump discharge amount inside the LS valve is changed by changing the output pressure from the LS control EPC valve to the LS valve according to the engine speed and operating condition of the actuator.
- Because of this, the timing for starting the discharge amount from the pump can be optimized, to give excellent ease of compound operation and fine control.
- ★ For details of the operation, see HYDRAULIC PUMP.



202F06174

2) Cut-off function


- If the load becomes larger during operation, and the pump discharge pressure rises to close to the relief pressure, the pump pressure sensor detects this, and the controller sends a signal to the TVC valve to reduce the relief loss.
- ★ For details of the operation, see CLSS.



202F06175

3) Cut-off cancel function

- The cut-off cancel function acts to stop the operation of the cut-off function in order to ensure the pump flow when close to the relief pressure, thereby preventing any drop in speed.
- The relief pressure when the cut-off is operated is 31.85MPa (325 kg/cm<sup>2</sup>), and when the cut-off cancel function is operated, the relief pressure becomes approx. 32.83 MPa (335 kg/cm<sup>2</sup>).
- Actuation conditions for cut-off cancel function



202F06176

	Working mode switch				Swing lock	Switch	Knob switch	
	H/O	G/O, F/O, B/O	L/O	Travel ON			ON	OFF
Cut-off function	Canceled	Actuated	Canceled	Canceled	Canceled	Actuated	Canceled	Actuated
2-stage relief function	-	-	Actuated	Actuated	Actuated	-	Actuated at H/O, G/O	-

- ★ Quick warming up for hydraulic oil when swing lock switch is ON:  
When the swing lock switch is turned ON, the cut-off function is canceled, and the 2-stage relief function is actuated.  
If the work equipment is relieved in this condition, the temperature of the hydraulic oil can be raised more quickly to reduce the warming up time.

4) **2-stage relief function**

- The relief pressure for normal operations is 31.85MPa (325 kg/cm<sup>2</sup>), but when the 2-stage relief function is actuated, the relief pressure rises to approx. 34.79MPa (355 kg/cm<sup>2</sup>).  
Because of this, the hydraulic pressure is increased by one stage.
- When the 2-stage relief function is actuated, the cut-off cancel function is also actuated automatically.
- Actuating conditions for 2-stage relief function

Conditions	Relief pressure
<ul style="list-style-type: none"> <li>• When traveling</li> <li>• When swing lock switch is ON</li> <li>• In lifting operation (L/O) mode</li> <li>• When power max. function or swift slow-down function are actuated</li> </ul>	<p>31.85 MPa (325kg/cm<sup>2</sup>)</p> <p style="text-align: center;">↓</p> <p>34.79 MPa (355kg/cm<sup>2</sup>)</p>

5) **Fine control mode function**

- When the finishing operation (F/O) mode is selected from the working mode, the pump LS valve is controlled, and the pump discharge amount is reduced to improve the ease of fine control and the precision when finishing.


- Relationship between working mode and pump discharge amount (for independent operation) (%)

Mode	Boom		Arm		Bucket	Swing
	RAISE	LOWER	IN	OUT		
Heavy-duty operation (H/O)	100	50	100	100	50	50
General operation (G/O)						
Finishing operation (F/O)	80	40	60	80	40	40
Lifting operation mode (L/O)	100	50	100	100	50	50
Breaker operation (B/O)	100	50	100	100	50	50

6) **LS bypass function**

- When the travel is operated at the same time as the work equipment or swing, the pressure compensation function in the CLSS circuit is weakened to reduce the drop in the travel speed to the minimum.
  - With this mechanism, the pressure is controlled so that the LS pressure in the CLSS circuit is made lower than the actual pressure when the travel is operated together with the work equipment or swing. In this way the pressure compensation function is weakened.
- ★ For details of the operation, see CLSS.

## 3. Power max. function, swift slow-down function



## FUNCTION

- This function provides an increase in the digging power for a certain time or switches the working mode to the lifting operation (L/O) and reduced the speed. It is operated using the L.H. knob switch to momentarily match the operating conditions.
- ★ The power max. function and swift slow-down function are operated with the same switch. Only one of these functions can be selected at any time; they cannot both be operated together.

**1) Power max. function**

- During digging operations, when that extra bit of digging power is needed (for example, when digging up boulders), the L.H knob switch can be pressed to raise the hydraulic pressure by approx. 10% and increase the digging force.
- If the L.H. knob switch is pressed ON when the working mode is at H/O or G/O, each function is automatically set as follows.



Working mode	Cut-off function	2-stage relief function	Actuating time
Heavy-duty operation (H/O)	Canceled	Actuated (31.85 34.79 MPa) (325 355 kg/cm <sup>2</sup> )	Automatically canceled after 8.5 sec


**2) Swift slow-down function**

- During normal operations, if it is desired to carry out lifting operations or finishing operations for a moment, the working mode can be switched to lifting operation (L/O) mode by operating the L.H. knob switch.
- If the L.H. knob switch is pressed ON when the working mode is at H/O or G/O, each function is automatically set as follows.



Working mode	Actuating time
Lifting operation (L/O)	While switch is kept pressed

4. AUTO-DECELERATION FUNCTION



**FUNCTION**

- If all the control levers are at neutral when waiting for work or waiting for a dump truck, the engine speed is automatically reduced to a midrange speed to reduce fuel consumption and noise.
- If any lever is operated, the engine speed returns immediately to the set speed.


## OPERATION

## Control levers at neutral


- If the engine is running at above the deceleration actuation speed (approx. 1400 rpm), and all the control levers are returned to neutral, the engine speed drops immediately to approx. 100 rpm below the set speed to the No. 1 deceleration position.
- If another 4 seconds passes, the engine speed is reduced to the No. 2 deceleration position (approx. 1400 rpm), and is kept at that speed until a lever is operated.

## When control lever is operated

- If any control lever is operated when the engine speed is at No. 2 deceleration, the engine speed will immediately rise to the speed set by the fuel control dial.



## 5. AUTOMATIC WARMING-UP AND ENGINE OVERHEAT PREVENTION FUNCTION




## FUNCTION

- If the coolant temperature is low, this automatically raises the engine speed to warm up the engine after it is started. (Automatic warming-up function)  
In addition, if the coolant temperature rises too high during operations, it reduces the load of the pump to prevent overheating. (Engine overheat prevention function)

1) **Engine automatic warming-up function**

- After the engine is started, if the engine coolant temperature is low, the engine speed is automatically raised to warm up the engine.





2) Engine overheat prevention function

- This function protects the engine by lowering the pump load and engine speed to prevent overheating when the engine coolant temperature has risen too far.
- This system is actuated in two stages. The first stage is when the coolant temperature is between 102°C and 105°C, and the second stage is when the coolant temperature is 105°C and above.

Normal operation  
(coolant temperature below 102°C)

Actuation condition	
Normal operation	Coolant temperature: Below 102°C
	(Coolant temperature gauge: Green range)



1st stage (Coolant temperature between 102°C and 105°C)

Actuation condition	
1st stage	Coolant temperature: Between 102°C and 105 c
	(Coolant temperature gauge: Red range)

Actuation, remedy	
Working mode	PC180/PC160K
Heavy-duty General Finishing Breaker	Mode kept as it is output reduced
Lifting	Lifting operation kept as it is

Cancel condition	
2nd stage	Coolant temperature: Below 102°C
	When the above condition is met, the system returns to the condition before the overheat prevention function was actuated (automatic reset).

2nd stage (coolant temperature 105°C and above)


Actuation condition	
2nd stage	Coolant temperature: 105°C and above
	(Coolant temperature gauge: Red range)

Actuation, remedy	
Working mode	In any mode
Engine speed	Low idling
Monitor caution lamp	Lights up
Caution buzzer	Sounds

Cancel condition	
2nd stage	Coolant temperature: Below 102°C
	Fuel control dial: Return temporarily to low idling position
When the above conditions are met, the system returns to the condition before the overheat prevention function was actuated (manual reset).	

6. SWING CONTROL FUNCTION

7. Swing control system



**Function**

- The system is provided with a swing lock and swing holding brake function.

1) **Swing lock, swing holding brake function**

- The swing lock (manual) can be locked at any desired position, and the swing holding brake (automatic) is interconnected with the swing, so it prevents any hydraulic drift after the swing is stopped.

- Swing lock switch and wing lock, holding brake

Lock switch	Lock lamp	Function	Operation
OFF	OFF	Swing holding brake	When swing lever is placed at neutral, swing brake is applied after approx. 4 sec; when swing lever is operated, brake is canceled and swing can be operated freely.
ON	ON	Swing lock	Swing lock is actuated and swing is held in position. Even when swing lever is operated, swing lock is not canceled and swing does not move.


❖ Operation of swing lock prolix switch

- If any abnormality should occur in the controller, and the swing holding brake is not actuated normally and the swing cannot be operated, the swing lock prolix switch can be operated to cancel the swing lock and allow the swing to be operated.
- ★ Even when the swing lock prolix switch is turned ON, the swing lock switch stays ON and the swing brake is not canceled.
- ★ When the swing brake is canceled, the swing has only a hydraulic brake operated by the safety valve, so if the swing is stopped on a slope, there may be hydraulic drift.

Swing lock prolix switch	ON (when controller is abnormal)		OFF (when controller is normal)	
Swing lock switch	ON	OFF	ON	OFF
Swing brake	Swing lock applied	Swing lock canceled	Swing lock applied	Swing holding brake applied


2) **Hydraulic oil quick warm-up function when swing lock switch is ON**

- ★ For details, see PUMP AND VALVE CONTROL FUNCTION.



202F06182

8. Travel control system



Function

- When traveling, the pump control is carried out, and the travel speed can be selected manually or automatically to give a travel performance that suits the nature of the work or the jobsite.

**1) Pump control function when traveling**

- If the travel is operated in any working mode other than the heavy-duty operation (H/O) mode, this increases the pump absorption torque while keeping the working mode and engine speed as they are.
- ★ For details, see PUMP & ENGINE MUTUAL CONTROL FUNCTION.

**2) LS bypass function during simultaneous operation of travel + work equipment or swing**


- When the travel is operated simultaneously with the work equipment or swing, the pressure compensation function of the CLSS circuit is weakened and the drop in the travel speed is kept to the minimum.
- ★ For details, see PUMP AND VALVE CONTROL FUNCTION.

Travel speed switch	Lo (Low speed)	Mi (Midrange speed)	Hi (High speed)
Pump flow (%)	80	80	100
Motor volume	Max.	Min.	Min.
Travel speed (km/h)	2.7	4.0	5.5

**3) Travel speed selection function**


- i) Manual selection using travel speed switch  
If the travel speed switch is set to Lo, Mi, or Hi, the pump controller controls the pump flow and motor volume at each speed range as follows to switch the travel speed.
- ii) Automatic selection according to engine speed  
If the engine speed is reduced to below 1400 rpm by the fuel control dial:
  - If the machine is traveling in Lo, it will not shift even if Mi or Hi are selected.
  - If the machine is traveling in Mi, it will not shift even if Hi is selected.
  - If the machine is traveling in Hi, it will automatically shift to Mi.

- iii) Automatic selection according to pump discharge pressure  
If the machine is traveling with the travel speed switch at Hi, and the load increases, such as when traveling up a steep hill, if the travel pressure continues at 27.44 MPa (280 kg/cm<sup>2</sup>) for more than 0.5 sec, the motor volume is automatically switched and the travel speed changes to Mi. (The travel speed switch stays at Hi.)  
The machine continues to travel in Mi, and when the load reduced, such as when the machine travels again on flat ground or goes downhill, and the travel performance stays at 16.66 MPa (170 kg/cm<sup>2</sup>) or less for more than 0.5 sec, the motor volume is automatically switched and the travel speed returns to Hi.



8. COMPONENTS OF SYSTEM

1) ENGINE SPEED SENSOR




202F06185

- 1. Wire
- 2. Magnet
- 3. Terminal
- 4. Housing
- 5. Connector

FUNCTION

- The engine speed sensor is installed to the ring gear portion of the engine flywheel. It counts electrically the number of gear teeth that pass in front of the sensor, and sends the results to the pump controller.
- This detection is carried out by a magnet, and an electric current is generated every time the gear tooth passes in front of the magnet.

2) PPC OIL PRESSURE SWITCH



202F06186

- 1. Plug
- 2. Switch
- 3. Connector

SPECIFICATIONS

Composition of points: N.O. points

Actuation (ON) pressure:

$0.49 \pm 0.1 \text{ MPa} (5.0 \pm 1.0 \text{ kg/cm}^2)$

Reset (OFF) pressure:



$0.29 \pm 0.05 \text{ MPa} (3.0 \pm 0.5 \text{ kg/cm}^2)$

FUNCTION

- There are 8 switches installed to the PPC shuttle valve. The operating condition of each actuator is detected from the PPC pressure, and this is sent to the pump controller.

3) PUMP PRESSURE SENSOR

- 1. PLug
- 2. Sensor
- 3. Connector



Composition of circuit

202F06187

FUNCTION


- This sensor is installed to the inlet port circuit of the control valve. It converts the pump discharge pressure to a voltage and sends this to the controller.

OPERATION


- When the pressurized oil entering from the pressure introduction portion pressurizes the diaphragm deflects and changes shape.
- A gauge layer is installed to the face opposite the diaphragm, and the resistance of the gauge layer converts the deflection of the diaphragm into an output voltage and sends it to the amp (voltage amplifier).
- The voltage is further amplified by the amplifier and is sent to the pump controller.
- Relationship between P (kg/cm<sup>2</sup>) and output voltage (V)

$$V = 0.008 \times P + 1.0$$

★ 1 kg/cm<sup>2</sup> = 0.098 MPa




202F06188



202F06163

## 5) TVC PROLIX RESISTOR



202F06216

1. Resistor
2. Connector

**SPECIFICATION**Resistance: 30  $\Omega$ **FUNCTION**

- This resistor acts to allow a suitable current to flow to the TVC solenoid when the TVC prolix switch is ON.
- No current flows when the TVC prolix switch is OFF.

6) **FUEL CONTROL DIAL, GOVERNOR MOTOR, ENGINE THROTTLE CONTROLLER**

★ See ENGINE CONTROL SYSTEM.

7) **MONITOR PANEL**

★ See MONITORING SYSTEM.

8) **TVC VALVE**


★ See HYDRAULIC DUMP.

9) **LS CONTROL EPC VALVE  
LS BYPASS SOLENOID VALVE  
TRAVEL SPEED SOLENOID VALVE  
SWING BRAKE SOLENOID VALVE  
2-STAGE RELIEF SOLENOID VALVE**

★ See EPC • SOLENOID VALVE.




# MACHINE MONITOR SYSTEM



## Function

- The machine monitor system uses the sensors installed to all parts of the machine to observe the condition of the machine. It processes this information swiftly, and displays it on a panel to inform the operator of the condition of the machine.  
The content of the information displayed on the machine can broadly be divided as follows.
  1. Monitor portion  
This gives an alarm if any abnormality occurs in the machine.
  2. Gauge portion  
This always displays the condition of the machine (coolant temperature, fuel level).
- The monitor panel also has various built-in mode selector switches, and functions as the control panel for the machine control system.

1. Monitor panel



Outline

- The monitor panel consists of the switches for the monitor display functions, mode selector, and electrical components. It has a built-in CPU (Central Processing unit), and processes, displays, and outputs the information. The monitor display panel uses a liquid crystal display (LCD). The mode switches are flat sheet switches. Input and output signals

Input and output signals


CN-P01

Pin No.	Name of signal
1	N/W signal
2	N/W GND
3	ND
4	NC
5	Swing lock
6	Buzzer stop
7	Buzzer output
8	Lamp
9	Key ON signal
10	Terminal BR
11	N/W signal
12	N/W GND
13	NC
14	NC
15	NC
16	NC
17	NC
18	Preheating
19	Start signal
20	NC

CN-P02













Pin No.	Name of signal
1	GND
2	NC
3	NC
4	NC
5	NC
6	NC
7	NC
8	+VB
9	GND
10	NC
11	NC
12	NC
13	NC
14	NC
15	NC
16	+VB

DISPLAY MONITOR




1. Clock (displays error code when error occurs)
2. Service meter
3. Coolant temperature gauge
4. Fuel gauge
5. Engine oil level caution lamp
6. Preheating pilot lamp
7. Swing holding brake pilot lamp
8. Charge level caution lamp
9. Air cleaner clogging caution lamp
10. Overload caution lamp
11. Coolant level caution lamp
12. Engine oil pressure caution lamp
13. Fuel level caution lamp
14. Coolant temperature caution lamp

Content of display

Symbol	Display item	Display range	When engine is stopped	When engine is running
 SAP00519	Coolant level	Below low level	Flashes when abnormal	Flashes and buzzer sounds when abnormal
 SAP00520	Engine oil pressure	Below 1,500 rpm: below 0.05 MPa (0.5 kg/cm <sup>2</sup> ) Above 1,500 rpm: below 0.15 MPa (1.5 kg/cm <sup>2</sup> )	Lights up when normal (goes out when engine starts)	Flashes and buzzer sounds when abnormal
 SAP00521	Air cleaner clogging	When clogged	OFF	Flashes when abnormal
 SAP00522	Charge level	When charging is defective	Lights up when normal (goes out when engine starts)	Flashes when abnormal
 SAP00523	Engine oil level	Below low level	Flashes when abnormal	OFF
 SDP00688	Over load	Above high level	OFF	Flashes when abnormal
 SDP00582	Parking	When swing is locked	Lights up when swing lock switch is ON, flashes when swing lock prolix switch is ON	
 SAP00526	Preheating	During preheating	Lights up for 30 seconds when starting switch is at HEAT, then flashes for 10 seconds to indicate that preheating is completed	
 SAP00703	Coolant temperature	Flashes when above 102°C, flashes and buzzer sounds when above 105°C		 SAP00529
 SAP00704	Fuel level	Flashes when below low level		 SAP00530

MODE SELECTION SWITCHES

1. Working mode switch
2. Auto deceleration switch
3. Travel speed switch
4. Power max./Swift slow-down switch



- The switch portion consists of five mode selection switches, and the condition of the machine changes each time that any switch is pressed. The LED above the switch lights up to display the present condition of the machine.

Switch actuation table

Switch	Item	Action
 SDP00692	WORKING MODE	H/O ↔ G/O ↔ F/O ↔ L/O ↔ B/O
 SDP00693	KNOB BUTTON	↔ (POWER UP) (SPEED DOWN)
 n/min	AUTO DECEL	ON ↔ OFF
 SDP00696	TRAVEL SPEED	Hi ↔ Mi ↔ Lo


**2. Sensors**

- The signals from the sensor are input directly to the monitor panel.  
The contact type sensors are always connected at one end to the chassis GND.

Name of sensor	Type of sensor	When normal	When abnormal
Coolant level	Contact type	ON (closed)	OFF (open)
Engine oil level	Contact type	ON (closed)	OFF (open)
Engine oil pressure	Contact type	OFF (open)	ON (closed)
Coolant temperature	Resistance type	-	-
Fuel level	Resistance type	-	-
Air cleaner clogging	Contact type	OFF (closed)	ON (open)


**Coolant level sensor**

- Sub-tank
- Float
- Sensor
- Connector




SAP00375

Engine oil level sensor




- 1. Connector
- 2. Bracket
- 3. Float
- 4. Switch




SBP00376

Engine oil pressure sensor (both Lo and Hi)




- 1. Plug
- 2. Contact ring
- 3. Contact
- 4. Diaphragm
- 5. Spring
- 6. Terminal




SBP00378

Coolant temperature sensor




- 1. Connector
- 2. Plug
- 3. Thermistor




SBP00379

FUEL LEVEL SENSOR



Air cleaner clogging sensor













---

## 20 TESTING AND ADJUSTING

---

Table of judgement standard valve.....	20- 2	Testing and adjusting pressure .....	20- 39
Standard value table for electrical parts .....	20- 12	Testing EPC valve, solenoid valve output pressure .....	20- 41
Checking and adjusting belt tension for air conditioner compressor .....	20- 20	Measuring PPC valve output pressure and testing PPC shuttle valve .....	20- 43
Adjusting engine speed sensor .....	20- 21	Adjusting work equipment • swing PPC valve .....	20- 45
Testing and adjusting governor motor lever strong .....	20- 22	Testing travel deviation .....	20- 46
Testing clearance of swing circle bearing .....	20- 24	Testing locations causing hydraulic drift of work equipment .....	20- 47
Testing and adjusting track shoe tension .....	20- 25	Measuring oil leakage .....	20- 49
Testing and adjusting hydraulic pressure in work equipment, swing, travel circuit .....	20- 26	Releasing remaining pressure in hydraulic circuit .....	20- 51
Testing and adjusting TVC valve output pressure (servo piston input pressure) .....	20- 34	TROUBLESHOOTING .....	20- 55
Testing and adjusting LS valve output pressure (servo piston input pressure) and LS differential .....	20- 36		

-  When carrying out testing, adjusting, or troubleshooting, park the machine on level ground and use the safety pins and blocks to prevent the machine from moving.
-  When carrying out work together with other workers, always use signals and do not let unauthorized people near the machine.
-  When checking the water level, always wait for the water to cool down. If the radiator cap is removed when the water is still hot, the water will spurt out and cause burns.
-  Be careful not to get caught in the fan, fan belt, or other rotating parts.


## TABLE OF JUDGEMENT STANDARD VALUE

- FOR ENGINE





Machine model			PC180 LC-6K / PC160-6K	
Engine			SA4DI02E	
Item	Measurement conditions	Unit	Standard value	Permissible value
Engine speed	High idling	rpm	2450 $\pm$ 60	2450 $\pm$ 60
	Low idling	rpm	950 $\pm$ 50	950 $\pm$ 50
	Rated speed	rpm	2100	2100 $\pm$ 100





• **FOR CHASSIS**




★ The standard values and permissible values in this table are all values for H/O (heavy-duty operation) mode.

Machine model				PC180LC-6K/PC160-6K						
Category	Item		Measurement conditions	Unit	Standard value			Permissible value		
Engine speed	At 2-pump relief	Normal	<ul style="list-style-type: none"> <li>• Swing lock off</li> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• Coolant temperature: Within operating range</li> <li>• 2-pump relief:</li> </ul>	rpm	2,100 ± 100			-		
		At travel lever operate	<ul style="list-style-type: none"> <li>• Arm relief</li> <li>• Arm relief</li> <li>• Travel lever operated in small movements</li> <li>• Engine at high idling</li> </ul>		2,100 ± 100			2,100 ± 100		
	Speed when autodeceleration is operated		<ul style="list-style-type: none"> <li>• Fuel control dial at MAX.</li> <li>• Control lever at neutral</li> </ul>		1,400 ± 120			1,400 ± 120		
Spool stroke	Boom control valve	 <p style="text-align: center;">202F2302</p>	mm	l	a	b	l	a	b	
	Arm control valve			-	8 ± 0.5	8 ± 0.5	-	8 ± 0.5	8 ± 0.5	
	Bucket control valve									
	Swing control valve									
	Travel control valve									
Travel of control levers	Boom control lever	<ul style="list-style-type: none"> <li>• Center of lever knob</li> <li>• Read max. value to end of travel</li> <li>• Engine stopped</li> <li>• Excluding neutral play</li> </ul>	mm	76 ± 8			Max. 84 Min. 68			
	Arm control lever			76 ± 8			Max. 84 Min. 68			
	Bucket control lever			76 ± 8			Max. 84 Min. 68			
	Swing control lever			76 ± 8			Max. 84 Min. 68			
	Travel control lever			115 ± 11			Max. 126 Min. 104			
	Play of control lever			Max. 10			Max. 15			
Operating force of control levers	Boom control lever	<ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Oil temperature: 45 - 55°C</li> <li>• Fit push-pull scale to center of control lever knob to end of travel</li> <li>• Measure max. value to end of travel</li> </ul>	N (kg)	117. ± 3.9 (1.8 ± 0.4)			Max. 24.5 (Max. 2.5)			
	Arm control lever			17.7 ± 3.9 (1.8 ± 0.4)			Max. 24.5 (Max. 2.5)			
	Bucket control lever			14.7 ± 3.9 (1.5 ± 0.4)			Max. 21.6 (Max. 2.2)			
	Swing control lever			14.7 ± 3.9 (1.5 ± 0.4)			Max. 2.6 Max. 2.2)			
	Travel control lever			Lever	24.5 ± 5.9 (2.5 ± 0.6)			Max. 39.2 (Max. 4.0)		
				Pedal	74.5 ± 18.6 (7.6 ± 1.9)			Max. 107.8 (Max. 11)		






Machine model				PC180LC-6k/PC160-6k				
Category	Item	Measurement conditions		Unit	Standard value for new machine		Service limit value	
Hydraulic pressure	Boom	<ul style="list-style-type: none"> <li>Hydraulic oil temperature: 45 - 55 C</li> <li>Relief pressure with engine at high idling (Relieve only circuit to be measured)</li> <li>In G/O mode</li> <li>Swing lock off</li> <li>Knob switch off</li> <li>Figures in [ ] are when power max. function is used (reference)</li> <li>Pump outlet port pressure</li> <li>★ 1: For travel, measure oil pressure for relief on one side</li> </ul>		Mpa (kg/cm <sup>2</sup> )	31.85 ± 0.98 (325 ± 10)		Max. 33.81 (Max.345)	Min. 30.38 (Min. 310)
	Arm				[ 34.79 <sup>+1.47</sup> <sub>-0.98</sub> ] (355 <sup>+15</sup> )		Max. 37.24 (Max. 380)	Min.33.81 (Min. 345)
	Bucket				31.87 <sup>+1.47</sup> <sub>-0.98</sub> (325 <sup>+15</sup> )		Max. 33.83 (Max. 345)	Min. 30.40 (Min. 310)
	Swing				34.79 <sup>+1.47</sup> <sub>-0.98</sub> (355 <sup>+15</sup> )		Max. 37.24 (Max. 380)	Min. 33.81 (Min. 345)
	Travel				2.94 <sup>+0.59</sup> <sub>0</sub> (30 <sup>+6</sup> )		Max. 3.53 (Max. 36)	Min. 2.94 (Min. 30)
	Control pump						3.9 ± 1.0 (40 ± 10)	3.9 ± 1.0 (40 ± 10)
	LS differential pressure				<ul style="list-style-type: none"> <li>Hydraulic oil temperature: 45 - 55°C</li> <li>Engine at high idling</li> <li>In H/O mode</li> </ul>		Lever at neutral	2.5 ± 0.1 (25 ± 1)
		Travel speed HI, rotating under no load						
	TVC valve output pressure (servo piston input pressure)	<ul style="list-style-type: none"> <li>Engine at high idling</li> <li>Hydraulic oil temperature: 45 - 55°C</li> <li>In H/O mode</li> </ul>		Control lever no load				
				1-pump relief	Normal operation			
	When power max. function is used							



Machine model				PC180LC-6k/PC160-6k	
Category	Item	Measurement conditions	Unit	Standard value	Permissible value
Swing	Swing brake angle	Work equipment posture Max. reach  Empty 205F06701 <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature : 45 - 55°C</li> <li>• Stop after swinging one turn and measure distance that swing circle moves</li> </ul>	Deg.	Max. 100	Max. 120
	Time taken to start swing	Work equipment posture Max. reach  Empty 205F06701 <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55 C</li> <li>• In H/O mode</li> <li>• Time taken to swing 90° and 180° from starting position</li> </ul>	90°	3.1 ± 0.3	Max. 4.0
			180°	4.9 ± 0.5	Max. 6.0
	Time taken to swing	Work equipment posture Max. reach  Empty 205F06701 <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• In H/O mode.</li> <li>• Swing one turn, and measure time taken to swing next 5 turns</li> </ul>	Sec	25.0 ± 1.5	Max 30
	Hydraulic drift of swing	 205F06702 <ul style="list-style-type: none"> <li>• Engine stopped</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• Set machine on 15° slope, and set upper structure at 90° to the side.</li> <li>• Make match marks on swing circle outer race and track frame.</li> <li>• Measure distance that match marks move apart after 5 minutes.</li> </ul>	mm	0	0
Leakage from swing motor	<ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• Swing lock switch ON</li> <li>• Relieve swing circuit.</li> </ul>	ℓ/min	Max. 5	Max. 10	

Machine model				PC180LC-6k/PC160-6k				
Category	Item	Measurement conditions		Unit	Standard value		Permissible value	
					PC180	PC160	PC180	PC160
Travel	Travel speed (1)	 <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• In H/O mode</li> <li>• Raise track on one side at a time, rotate one turn, then measure time taken for next 5 turns with no load.</li> </ul>	Lo	Sec	59 ± 6	53 ± 6	53 - 70	47 - 64
			Mi		36.5 ± 4	34 ± 4	32.5 - 44.5	30 - 42
			Hi		29.5 ± 3	27 ± 3	24.5 - 36	24 - 33.5
	Travel speed (2)	 <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• In H/O mode</li> <li>• Run up for at least 10 m, and measure time taken to travel next 20 m on flat ground.</li> </ul>	Lo	Sec	26.7 ± 3.0		23.7 - 32.7	
			Mi		18 ± 2.0		16 - 22.0	
			Hi		13.3 ± 1.0		12.3 - 15.3	
	Travel deviation	 <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• Run up for at least 10 m, and measure deviation when traveling next 20 m on flat ground.</li> <li>★ Use a hard horizontal surface.</li> </ul>  <ul style="list-style-type: none"> <li>★ Measure dimension</li> </ul>		mm	Max. 200		300	

Machine model				PC180LC-6K/PC160-6K		
Category	Item	Measurement conditions	Unit	Standard value	Permissible value	
Travel	Hydraulic drift of travel	 <p>205F06705</p> <ul style="list-style-type: none"> <li>• Engine stopped</li> <li>• Hydraulic oil temperature: 45 - 55 °C</li> <li>• Stop machine on 12° slope with sprocket facing straight up the slope.</li> <li>• Measure the distance the machine moves in 5 minutes.</li> </ul>	mm	0	0	
	Leakage of travel motor	 <p>Lock pin 205F06706</p> <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• Lock shoes and relieve travel circuit.</li> </ul>	μ/mm	13.6	27.2	
Work equipment	Hydraulic drift work equipment	Total work equipment (hydraulic drift at tip of bucket teeth)	<p>Posture for measurement</p>  <p>205F06707</p>	mm	Max. 400	Max.600
		Boom cylinder (amount of retraction of cylinder)	<ul style="list-style-type: none"> <li>• Place in above posture and measure extension or retraction of each cylinder downward movement at tip of bucket teeth.</li> <li>• Bucket: Rated load</li> <li>• Horizontal, flat ground</li> <li>• Levers at neutral</li> <li>• Engine stopped</li> </ul>		Max. 14	Max. 21
		Arm cylinder (amount of extension of cylinder)	<ul style="list-style-type: none"> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• Start measuring immediately after setting.</li> <li>• Measure hydraulic drift every 5 minutes, and judge from results for 15 minutes.</li> </ul>		Max. 110	Max. 165
		Bucket cylinder (amount of retraction of cylinder)			Max. 28	Max. 42




Applicable model				PC180LC-6K/PC160-6K				
Category	Item	Measurement	Unit	Standard value	Permissible value			
Work equipment	Work equipment speed	Boom Bucket teeth in contact with ground  205F06708	RAISE	sec	3.7 ± 0.4	Max 4.5		
		Cylinder fully extended <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• In H/O mode</li> </ul>	LOWER		2.8 ± 0.3	Max 3.2		
		Arm Cylinder fully retracted  205F06709	IN		3.7 ± 0.4	Max 4.6		
		Fully extended <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• In H/O mode</li> </ul>	OUT		3.0 ± 0.3	Max. 3.6		
		Bucket Cylinder fully retracted  205F06710	CURL		3.6 ± 0.4	Max 4.3		
		Fully extended <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• In H/O mode</li> </ul>	DUMP		2.2 ± 0.3	Max. 2.8		
		Boom  205F06711			Max. 2.0	Max. 3		
		Arm  205F06712			Max. 1.0	Max. 2.8		
		Time lag						

Machine model				PC180LC-6k/PC160-6k		
Category	Item	Measurement conditions	Unit	Standard value	Permissible value	
Work equipment	Time lag	 <p>205F06713</p> <ul style="list-style-type: none"> <li>• Stop bucket suddenly and measure time taken for bucket to stop at bottom and then start again</li> <li>• Engine at low idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> </ul>	Sec	Max. 2.0	Max. 3.0	
	Internal leakage	Cylinders	<ul style="list-style-type: none"> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• Engine at high idling</li> <li>• Relieve circuit to be measured</li> </ul>	cc/min	Max 3.5	15
		Center swivel joint			10	50
Performance in compound operation	Travel deviation when work equipment + travel are operated	<ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55 C</li> </ul> <p>★ Use a hard horizontal surface.</p>  <p>205F2402</p> <p>* Measure dimension</p>	mm	Max. 200	Max. 220	
Performance of hydraulic pump	Hydraulic pump delivery	Control pump	<ul style="list-style-type: none"> <li>• Oil temperature: 45 - 55 C</li> <li>• Measure with engine at rated speed</li> <li>• At relief valve set pressure 3.14 MPa (32 kg/cm<sup>2</sup>)</li> </ul>	l/min	Min. 29	Min. 26
		Piston pump	See next page		See next page	

Category

PC180LC-6K/PC160-6K (H/O WORK. TRAVEL)

Performance of hydraulic pump




- Pump speed: At 2,200 rpm, TVC current 330 mA

Check point	Test pump discharge pressure (MPa (kg/cm²))	Standard value for discharge amount Q (L/min)	Judgement standard lower limit Q (L/min)
As desired	P	See graph	See graph

- ★ As far as possible, bring pump discharge pressures P as close as possible to the average pressure when measuring.  
The error is large near the point where the graph curves, so avoid measuring at this point.
- ★ When measuring with the pump mounted on the machine, if it is impossible to set the engine speed to the specified speed with the fuel control dial, take the pump discharge amount and the engine speed at the point of measurement, and use them as a base for calculating the pump discharge amount at the specified speed.

**Flow control characteristics of TVC valve (STD)**

★ The values in this table are used as reference values when carrying out troubleshooting.

Category	Item	Measurement conditions	Unit		
Performance in compound operations	Time taken for swing for boom RAISE + starting swing	 <p style="text-align: right;">205F06714</p> <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Hydraulic oil temperature: 45 - 55°C</li> <li>• In H/O mode</li> <li>• Load the bucket with the rated load and measure the time taken from the position of starting the swing to the point of passing the 90° position.</li> </ul>	Sec		

# STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgement table	Measurement conditions										
Control system	Fuel control dial	E06 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table border="1"> <tr> <td>Between (1) - (2)</td> <td>0.25 - 7 kΩ</td> </tr> <tr> <td>Between (2) - (3)</td> <td>0.25 - 7 kΩ</td> </tr> <tr> <td>Between (1) - (3)</td> <td>4 - 6 kΩ</td> </tr> </table>	Between (1) - (2)	0.25 - 7 kΩ	Between (2) - (3)	0.25 - 7 kΩ	Between (1) - (3)	4 - 6 kΩ	1) Turn starting switch OFF. 2) Disconnect connector.				
	Between (1) - (2)	0.25 - 7 kΩ													
	Between (2) - (3)	0.25 - 7 kΩ													
	Between (1) - (3)	4 - 6 kΩ													
	Governor motor	Potentiometer	E04 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table border="1"> <tr> <td>Between (1) - (2)</td> <td>0.25 - 7 kΩ</td> </tr> <tr> <td>Between (2) - (3)</td> <td>0.25 - 7 kΩ</td> </tr> <tr> <td>Between (1) - (3)</td> <td>4 - 6 kΩ</td> </tr> </table>	Between (1) - (2)	0.25 - 7 kΩ	Between (2) - (3)	0.25 - 7 kΩ	Between (1) - (3)	4 - 6 kΩ	1) Turn starting switch OFF. 2) Disconnect connector.			
		Between (1) - (2)	0.25 - 7 kΩ												
		Between (2) - (3)	0.25 - 7 kΩ												
	Between (1) - (3)	4 - 6 kΩ													
	Motor	E05 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between (1) - (2)</td> <td>2.5 - 7.5 Ω</td> </tr> <tr> <td>Between (3) - (4)</td> <td>2.5 - 7.5 Ω</td> </tr> <tr> <td>Between (1) - (3)</td> <td>No continuity</td> </tr> <tr> <td>Between (1) - chassis</td> <td>No continuity</td> </tr> <tr> <td>Between (3) - chassis</td> <td>No continuity</td> </tr> </table>	Between (1) - (2)	2.5 - 7.5 Ω	Between (3) - (4)	2.5 - 7.5 Ω	Between (1) - (3)	No continuity	Between (1) - chassis	No continuity	Between (3) - chassis	No continuity	1) Turn starting switch OFF. 2) Disconnect connector.
	Between (1) - (2)	2.5 - 7.5 Ω													
Between (3) - (4)	2.5 - 7.5 Ω														
Between (1) - (3)	No continuity														
Between (1) - chassis	No continuity														
Between (3) - chassis	No continuity														
Engine speed sensor	E07	Measure resistance	If the condition is within the range shown in the table below, it is normal <table border="1"> <tr> <td>Between(male) (1) - (2)</td> <td>500 - 1,000 Ω</td> </tr> <tr> <td>Between(male) (2) - chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between(male) (1) - (2)	500 - 1,000 Ω	Between(male) (2) - chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector.							
		Between(male) (1) - (2)	500 - 1,000 Ω												
		Between(male) (2) - chassis	Min. 1 MΩ												
Measure voltage	Measure with AC range <table border="1"> <tr> <td>Between (1) - (2)</td> <td>0.5 - 3.0 V</td> </tr> </table>	Between (1) - (2)	0.5 - 3.0 V	1) Start engine. 2) Insert T-adaptor.											
Between (1) - (2)	0.5 - 3.0 V														
Adjust	1) Screw in rotation sensor until it contacts ring gear, then turn back $1 \pm 1/6$ turns. 2) It must work normally when adjusted as above.														
PPC oil pressure switch	Travel S01 boom RAISE S02 arm OUT S03 boom LOWER S04 arm IN S05 bucket CURL S06 bucket DUMP S07 swing S08	Measure resistance	If the condition is as shown in the table below, it is normal When boom, arm, and bucket levers are operated <table border="1"> <tr> <td rowspan="2">Between (male) (1) - (2)</td> <td>All levers at neutral</td> <td>Min 1 MΩ</td> </tr> <tr> <td>Levers operated</td> <td>Max. 1 Ω</td> </tr> <tr> <td colspan="2">Between (male) (1), (2) - chassis</td> <td>Min. 1MΩ</td> </tr> </table>	Between (male) (1) - (2)	All levers at neutral	Min 1 MΩ	Levers operated	Max. 1 Ω	Between (male) (1), (2) - chassis		Min. 1MΩ	1) Start engine (or with engine stopped and accumulator charged) 2) Disconnect connectors S01 - S08			
Between (male) (1) - (2)	All levers at neutral	Min 1 MΩ													
	Levers operated	Max. 1 Ω													
Between (male) (1), (2) - chassis		Min. 1MΩ													
Fuel shut-off valve	E09 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table border="1"> <tr> <td>Between (A) - (C)</td> <td>46.5 - 56.9 kΩ</td> </tr> <tr> <td>Between (B) - (C)</td> <td>0.87 - 1.07 kΩ</td> </tr> </table>	Between (A) - (C)	46.5 - 56.9 kΩ	Between (B) - (C)	0.87 - 1.07 kΩ	1) Turn starting switch OFF 2) Disconnect connector							
Between (A) - (C)	46.5 - 56.9 kΩ														
Between (B) - (C)	0.87 - 1.07 kΩ														







System	Name of component	Connector No.	Inspection method	Judgement table	Measurement conditions					
Control system	Pump pressure sensor	C08 (male) (front)	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (2) - (1)</td> <td>18 - 28 V</td> </tr> <tr> <td rowspan="2">Between (3) - (1)</td> <td>All levers at neutral At arm IN relief</td> <td>0.5 - 1.5 V 3.1 - 4.5 V</td> </tr> </table>	Between (2) - (1)	18 - 28 V	Between (3) - (1)	All levers at neutral At arm IN relief	0.5 - 1.5 V 3.1 - 4.5 V	<ol style="list-style-type: none"> <li>1) Start engine.</li> <li>2) Turn fuel control dial to MAX position</li> <li>3) Insert T - adapter</li> </ol>
	Between (2) - (1)	18 - 28 V								
	Between (3) - (1)	All levers at neutral At arm IN relief	0.5 - 1.5 V 3.1 - 4.5 V							
		Swing lock switch	X05 (female)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (1) - (2) Between (3) - (4)</td> <td>When switch is OFF</td> <td>Min. 1 MΩ</td> </tr> <tr> <td>When switch is ON</td> <td>Max. 1 Ω</td> </tr> </table>	Between (1) - (2) Between (3) - (4)	When switch is OFF	Min. 1 MΩ	When switch is ON	Max. 1 Ω
	Between (1) - (2) Between (3) - (4)	When switch is OFF	Min. 1 MΩ							
		When switch is ON	Max. 1 Ω							
	TVC solenoid valve	C13 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) - (2)</td> <td>10 - 22 Ω</td> </tr> <tr> <td>Between (1), (2) - chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) - (2)	10 - 22 Ω	Between (1), (2) - chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn TVC prolix switch OFF.</li> <li>2) Turn starting switch OFF.</li> <li>3) Disconnect connector C13</li> </ol>	
Between (1) - (2)	10 - 22 Ω									
Between (1), (2) - chassis	Min. 1 MΩ									
Swing holding brake solenoid valve	V06 (male)	Measure resistance	<p>If the condition is within the range shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) - (2)</td> <td>20 -60 Ω</td> </tr> <tr> <td>Between (1), (2) - chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) - (2)	20 -60 Ω	Between (1), (2) - chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connector V06</li> </ol>		
Between (1) - (2)	20 -60 Ω									
Between (1), (2) - chassis	Min. 1 MΩ									
Travel speed solenoid valve	V04 (male)	Measure resistance	<p>If the condition is within the range shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) - (2)</td> <td>20 -60 Ω</td> </tr> <tr> <td>Between (1), (2) - chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) - (2)	20 -60 Ω	Between (1), (2) - chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connector V04</li> </ol>		
Between (1) - (2)	20 -60 Ω									
Between (1), (2) - chassis	Min. 1 MΩ									
LS bypass solenoid valve	V05 (male)	Measure resistance	<p>If the condition is within the range shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) - (2)</td> <td>20 -60 Ω</td> </tr> <tr> <td>Between (1), (2) - chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) - (2)	20 -60 Ω	Between (1), (2) - chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connector V05.</li> </ol>		
Between (1) - (2)	20 -60 Ω									
Between (1), (2) - chassis	Min. 1 MΩ									
2 step relief solenoid valve	V25 (male)	Measure resistance	<p>If the condition is within the range shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) - (2)</td> <td>20 -60 Ω</td> </tr> <tr> <td>Between (1), (2) - chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) - (2)	20 -60 Ω	Between (1), (2) - chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connector V25</li> </ol>		
Between (1) - (2)	20 -60 Ω									
Between (1), (2) - chassis	Min. 1 MΩ									









System	Name of component	Connector No.	Inspection method	Judgement table	Measurement conditions					
Control system	Governor, pump controller	LS-EPC solenoid	C10 (male)	Measure resistance <table border="1"> <tr> <td>Between (1) - (2)</td> <td>7 - 14 Ω</td> </tr> <tr> <td>Between (1), (2) - chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) - (2)	7 - 14 Ω	Between (1), (2) - chassis	Min. 1 MΩ	<p>If the condition is within the range shown in the table below, it is normal</p>	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connector C10.</li> </ol>
		Between (1) - (2)	7 - 14 Ω							
		Between (1), (2) - chassis	Min. 1 MΩ							
		Power source voltage	C01 C02	Measure voltage <table border="1"> <tr> <td>Between C01 (7), (13) - (6), (12)</td> <td>20 - 30 V</td> </tr> <tr> <td>Between C02 (11), (21) - (12)</td> <td>20 - 30 V</td> </tr> </table>	Between C01 (7), (13) - (6), (12)	20 - 30 V	Between C02 (11), (21) - (12)	20 - 30 V	<p>If the condition is within the range shown in the table below, it is normal</p>	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T - adapter</li> </ol>
		Between C01 (7), (13) - (6), (12)	20 - 30 V							
		Between C02 (11), (21) - (12)	20 - 30 V							
		Fuel control dial	C03	Measure voltage <table border="1"> <tr> <td>Between (7) - (17) (power source)</td> <td>4.75 - 5.25 V</td> </tr> <tr> <td>Between (4) - (17) (low idling)</td> <td>4.0 - 4.75 V</td> </tr> <tr> <td>Between (4) - (17) (high idling)</td> <td>0.25 - 1.0 V</td> </tr> </table>	Between (7) - (17) (power source)	4.75 - 5.25 V	Between (4) - (17) (low idling)	4.0 - 4.75 V	Between (4) - (17) (high idling)	0.25 - 1.0 V
Between (7) - (17) (power source)	4.75 - 5.25 V									
Between (4) - (17) (low idling)	4.0 - 4.75 V									
Between (4) - (17) (high idling)	0.25 - 1.0 V									
Governor potentiometer	C03	Measure voltage <table border="1"> <tr> <td>Between (14) - (17) (low idling)</td> <td>2.9 - 3.3 V</td> </tr> <tr> <td>Between (14) - (17) (high idling)</td> <td>0.5 - 0.9 V</td> </tr> <tr> <td>Between (7) - (17) (power source)</td> <td>4.75 - 5.25 V</td> </tr> </table>	Between (14) - (17) (low idling)	2.9 - 3.3 V	Between (14) - (17) (high idling)	0.5 - 0.9 V	Between (7) - (17) (power source)	4.75 - 5.25 V	<p>If the condition is as shown in the table below, it is normal</p>	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T - adapter</li> </ol>
Between (14) - (17) (low idling)	2.9 - 3.3 V									
Between (14) - (17) (high idling)	0.5 - 0.9 V									
Between (7) - (17) (power source)	4.75 - 5.25 V									
Coolant temperature sensor	P07 (male)	Measure resistance <table border="1"> <tr> <td>Normal temperature (25°C)</td> <td>Approx. 37 - 50 kΩ</td> </tr> <tr> <td>100°C</td> <td>Approx. 3.5 - 4.0 kΩ</td> </tr> </table>	Normal temperature (25°C)	Approx. 37 - 50 kΩ	100°C	Approx. 3.5 - 4.0 kΩ	<p>If the condition is as shown in the table below, it is normal</p>	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connector P07</li> <li>3) Insert T - adapter into connector at sensor end.</li> </ol>		
Normal temperature (25°C)	Approx. 37 - 50 kΩ									
100°C	Approx. 3.5 - 4.0 kΩ									
Governor motor	C02	Measure voltage <table border="1"> <tr> <td>Between (2) - (3)</td> <td>1.8 - 4.6 V</td> </tr> <tr> <td>Between (4) - (5)</td> <td>1.8 - 4.6 V</td> </tr> </table>	Between (2) - (3)	1.8 - 4.6 V	Between (4) - (5)	1.8 - 4.6 V	<p>If the condition is as shown in the table below, it is normal</p>	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T - adapter.</li> </ol>		
Between (2) - (3)	1.8 - 4.6 V									
Between (4) - (5)	1.8 - 4.6 V									
Battery relay	C01	Measure voltage <table border="1"> <tr> <td>Between (1) - (6)</td> <td>20 - 30 V</td> </tr> </table> <p>★This is only for 2.5 sec after the starting switch is operated ON → OFF; at other times it must be 0 V.</p>	Between (1) - (6)	20 - 30 V	<p>If the condition is within the range shown in the table below, it is normal</p>	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T - adapter.</li> </ol>				
Between (1) - (6)	20 - 30 V									

System	Name of component	Connector No.	Inspection method	Judgement table	Measurement conditions					
Control system	Governor, pump controller	C01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>When either swing or work equipment control lever is operated (solenoid ON, swing holding brake canceled)</td> <td rowspan="2">Between (3) - (6), (12)</td> <td>0 - 3 V</td> </tr> <tr> <td>Approx. 5 sec after swing lever and work equipment control levers are placed at neutral (solenoid OFF, swing holding brake applied)</td> <td>20 - 30 V</td> </tr> </table>	When either swing or work equipment control lever is operated (solenoid ON, swing holding brake canceled)	Between (3) - (6), (12)	0 - 3 V	Approx. 5 sec after swing lever and work equipment control levers are placed at neutral (solenoid OFF, swing holding brake applied)	20 - 30 V	<ol style="list-style-type: none"> <li>1) Start engine.</li> <li>2) Turn swing lock switch OFF.</li> <li>3) Turn swing lock prolix switch OFF.</li> <li>4) Insert T - adapter.</li> </ol> <p>★ The lever can be operated slightly (without moving the equipment).</p>
				When either swing or work equipment control lever is operated (solenoid ON, swing holding brake canceled)	Between (3) - (6), (12)		0 - 3 V			
				Approx. 5 sec after swing lever and work equipment control levers are placed at neutral (solenoid OFF, swing holding brake applied)		20 - 30 V				
				C01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>With travel speed switch at Hi or Mi (solenoid ON, travel motor swash plate angel MIN)</td> <td rowspan="2">Between (9) - (6), (12)</td> <td>0 - 3 V</td> </tr> <tr> <td>When travel speed switch is at lo (solenoid OFF travel motor swash plate angle MAX)</td> <td>20 - 30 V</td> </tr> </table>	With travel speed switch at Hi or Mi (solenoid ON, travel motor swash plate angel MIN)	Between (9) - (6), (12)	0 - 3 V	When travel speed switch is at lo (solenoid OFF travel motor swash plate angle MAX)
With travel speed switch at Hi or Mi (solenoid ON, travel motor swash plate angel MIN)	Between (9) - (6), (12)	0 - 3 V								
When travel speed switch is at lo (solenoid OFF travel motor swash plate angle MAX)		20 - 30 V								
C01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>When swing lock switch is OFF, and swing + travel levers are operated simultaneously (solenoid ON, LS not divided)</td> <td rowspan="2">Between (2) - (6), (12)</td> <td>0 - 3 V</td> </tr> <tr> <td>When sing lock switch is ON (solenoid OFF, LS not divided)</td> <td>20 - 30 V</td> </tr> </table>	When swing lock switch is OFF, and swing + travel levers are operated simultaneously (solenoid ON, LS not divided)			Between (2) - (6), (12)	0 - 3 V	When sing lock switch is ON (solenoid OFF, LS not divided)	20 - 30 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Isert T - adapter.</li> </ol> <p>★ The lever can be operated slightly (without moving the equipment).</p>
		When swing lock switch is OFF, and swing + travel levers are operated simultaneously (solenoid ON, LS not divided)	Between (2) - (6), (12)	0 - 3 V						
		When sing lock switch is ON (solenoid OFF, LS not divided)		20 - 30 V						
		C01	Measure voltage	<p>If the condition is as shown in the table below, it is normal.</p> <table border="1"> <tr> <td>When travel is operated independently (solenoid ON)</td> <td rowspan="2">Between (10) - (6), (12)</td> <td>0 - 3 V</td> </tr> <tr> <td>When levers and pedals are at neutral (solenoid OFF)</td> <td>20 - 30 V</td> </tr> </table>	When travel is operated independently (solenoid ON)	Between (10) - (6), (12)	0 - 3 V	When levers and pedals are at neutral (solenoid OFF)	20 - 30 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T - adapter.</li> </ol> <p>★ The lever can be operated slightly (without moving the equipment).</p>
When travel is operated independently (solenoid ON)	Between (10) - (6), (12)			0 - 3 V						
When levers and pedals are at neutral (solenoid OFF)				20 - 30 V						



System	Name of component	Connector No.	Inspection method	Judgement table	Measurement conditions													
Control system	Governor, pump controller	TVC solenoid valve (default value)	C02	Measure current If the condition is as shown in the table below, it is normal • G/O mode ( Hi-idle, swing lock off lever neutral) <table border="1"><tr><td>Between front (8) - (18)</td><td>410 ± 40 mA</td></tr></table>	Between front (8) - (18)	410 ± 40 mA	1) Turn starting switch ON. 2) Turn fuel control dial to MAX position 3) Turn prolix switch OFF.											
		Between front (8) - (18)	410 ± 40 mA															
		LS-EPC solenoid valve (default value)	C02	Measure current If the condition is as shown in the table below, it is normal • G/O mode <table border="1"><tr><td>Between (7) - (17)</td><td>800 ± 80 mA</td></tr></table>	Between (7) - (17)	800 ± 80 mA	1) Turn starting switch ON. 2) Turn fuel control dial to MAX position 3) All levers at neutral.											
		Between (7) - (17)	800 ± 80 mA															
		L.H. knob switch	C03	Measure voltage If the condition is as shown in the table below, it is normal <table border="1"><tr><td>When switch is ON</td><td rowspan="2">Between (9) - GND</td><td>20 - 28 V</td></tr><tr><td>When switch is OFF</td><td>0 - 1 V</td></tr></table>	When switch is ON	Between (9) - GND	20 - 28 V	When switch is OFF	0 - 1 V	1) Turn starting switch ON. 2) Insert T - adapter.								
		When switch is ON	Between (9) - GND	20 - 28 V														
		When switch is OFF		0 - 1 V														
S-NET	C17	Measure voltage If the condition is as shown in the table below, it is normal <table border="1"><tr><td>Between (4), (12) - GND</td><td>4 - 8 V</td></tr></table>	Between (4), (12) - GND	4 - 8 V	1) Turn starting switch ON. 2) Insert T - adapter													
Between (4), (12) - GND	4 - 8 V																	
Kerosene mode	C17	Measure voltage If the condition is as shown in the table below, it is normal <table border="1"><tr><td>Standard mode</td><td rowspan="2">Between (15) - GND</td><td>20 - 28 V</td></tr><tr><td>Kerosene mode</td><td>0 - 2 V</td></tr></table>	Standard mode	Between (15) - GND	20 - 28 V	Kerosene mode	0 - 2 V	1) Turn starting switch ON. 2) Insert T - adapter										
Standard mode	Between (15) - GND	20 - 28 V																
Kerosene mode		0 - 2 V																
No. 2 throttle signal	Monitoring code 16	Engine speed If the condition is as shown in the table below, it is normal High idling (rpm) <table border="1"><tr><td>H/O</td><td>Approx. 2450</td></tr><tr><td>G/O</td><td>Approx. 2030</td></tr><tr><td>F/O</td><td>Approx. 2030</td></tr><tr><td>L/O</td><td>Approx. 1890</td></tr><tr><td>Power max. (H/O) (G/O)</td><td>Approx. 2450</td></tr><tr><td>Swift slow-down (H/O) (G/O)</td><td>Approx. 1890</td></tr></table>	H/O	Approx. 2450	G/O	Approx. 2030	F/O	Approx. 2030	L/O	Approx. 1890	Power max. (H/O) (G/O)	Approx. 2450	Swift slow-down (H/O) (G/O)	Approx. 1890	1) Start engine. 2) Set monitoring code to 10 or 16 (command value). 3) Operate working mode switch and L.H. knob switch.			
H/O	Approx. 2450																	
G/O	Approx. 2030																	
F/O	Approx. 2030																	
L/O	Approx. 1890																	
Power max. (H/O) (G/O)	Approx. 2450																	
Swift slow-down (H/O) (G/O)	Approx. 1890																	
Model selection	C17 - C02	Continuity If the condition is as shown in the table below, it is normal <table border="1"><tr><td>Between selection 1</td><td>C17 (5) - C02 (11)</td><td>No continuity</td></tr><tr><td>Between selection 2</td><td>C17 (13) - C02 (11)</td><td>Continuity</td></tr><tr><td>Between selection 3</td><td>C17 (6) - C02 (11)</td><td>No continuity</td></tr><tr><td>Between selection 4</td><td>C17 (14) - C02 (11)</td><td>No continuity</td></tr><tr><td>Between selection 5</td><td>C17 (7) - C02 (11)</td><td>No continuity</td></tr></table>	Between selection 1	C17 (5) - C02 (11)	No continuity	Between selection 2	C17 (13) - C02 (11)	Continuity	Between selection 3	C17 (6) - C02 (11)	No continuity	Between selection 4	C17 (14) - C02 (11)	No continuity	Between selection 5	C17 (7) - C02 (11)	No continuity	1) Turn starting switch OFF. 2) Disconnect connector. 3) Connect T - adapter to wiring harness end.
Between selection 1	C17 (5) - C02 (11)	No continuity																
Between selection 2	C17 (13) - C02 (11)	Continuity																
Between selection 3	C17 (6) - C02 (11)	No continuity																
Between selection 4	C17 (14) - C02 (11)	No continuity																
Between selection 5	C17 (7) - C02 (11)	No continuity																

System	Name of component	Connector No.	Inspection method	Judgement table	Measurement conditions					
Monitor	Air cleaner clogging sensor	P11 (male) P12 (male)	Continuity	If the condition is as shown in the table below, it is normal <table border="1" style="margin-top: 10px;"> <tr> <td>Air cleaner normal</td> <td rowspan="2">Between P11 - P12</td> <td>Continuity</td> </tr> <tr> <td>Air cleaner clogged</td> <td>No continuity</td> </tr> </table>	Air cleaner normal	Between P11 - P12	Continuity	Air cleaner clogged	No continuity	1) Start engine. 2) Disconnect P11, P12.
	Air cleaner normal	Between P11 - P12	Continuity							
	Air cleaner clogged		No continuity							
	Engine speed sensor	E07	Measure resistance	If the condition is within the range shown in the table below, it is <table border="1" style="margin-top: 10px;"> <tr> <td>Between (1) - (2)</td> <td>500 - 1000 Ω</td> </tr> <tr> <td>Between (2) - chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) - (2)	500 - 1000 Ω	Between (2) - chassis	Min. 1 MΩ	1) Turn starting switch OFF. 3) Disconnect connector.	
			Between (1) - (2)	500 - 1000 Ω						
			Between (2) - chassis	Min. 1 MΩ						
Measure voltage	Measure with AC range <table border="1" style="margin-top: 10px;"> <tr> <td>Between (1) - (2)</td> <td>0.5 - 3.0 V</td> </tr> </table>	Between (1) - (2)	0.5 - 3.0 V	1) Start engine. 2) Insert T - adapter.						
Between (1) - (2)	0.5 - 3.0 V									
Adjust	1) Screw in rotation sensor until it contacts ring gear, then turn back $1 \pm 1/6$ turns 2) It must work normally when adjusted as above.									
Coolant level sensor	P08 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1" style="margin-top: 10px;"> <tr> <td>Above LOW level in sub-tank</td> <td>Max. 1Ω</td> </tr> <tr> <td>Below LOW level in sub-tank</td> <td>Min. 1MΩ</td> </tr> </table>	Above LOW level in sub-tank	Max. 1Ω	Below LOW level in sub-tank	Min. 1MΩ	1) Turn starting switch OFF. 2) Disconnect connector P08. 3) Insert T - adapter into connector at sensor end.		
Above LOW level in sub-tank	Max. 1Ω									
Below LOW level in sub-tank	Min. 1MΩ									
Engine oil level sensor	P05 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1" style="margin-top: 10px;"> <tr> <td>                       BLP00002                      Raise float                 </td> <td>Max. 1Ω</td> </tr> <tr> <td>                       BLP00003                      Lower float                 </td> <td>Min. 1MΩ</td> </tr> </table>	 BLP00002 Raise float	Max. 1Ω	 BLP00003 Lower float	Min. 1MΩ	1) Turn starting switch OFF. 2) Disconnect connector P05 3) Drain oil, then remove sensor.		
 BLP00002 Raise float	Max. 1Ω									
 BLP00003 Lower float	Min. 1MΩ									
Coolant temperature sensor	P07 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1" style="margin-top: 10px;"> <tr> <td>Normal temperature (25°C)</td> <td>Approx. 70 - 78 kΩ</td> </tr> <tr> <td>100°C</td> <td>Approx. 3 kΩ</td> </tr> </table>	Normal temperature (25°C)	Approx. 70 - 78 kΩ	100°C	Approx. 3 kΩ	1) Turn starting switch OFF. 2) Disconnect connector P07. 3) Put test in contact between sensor terminals and check resistance		
Normal temperature (25°C)	Approx. 70 - 78 kΩ									
100°C	Approx. 3 kΩ									


System	Name of component	Connector No.	Inspection method	Judgement table	Measurement conditions					
Monitor	Engine oil pressure sensor	P10	Measure resistance	<p>If the condition is as shown in the table below, it is normal.</p> <p>Low pressure sensor</p> <table border="1"> <tr> <td>Pressure rising</td> <td>Opens at <math>0.110 \pm 0.014</math> MPa (Non continuity) (<math>1.12 \pm 0.14</math> kg/cm<sup>2</sup>)</td> </tr> <tr> <td>Pressure dropping</td> <td>Closes at <math>0.08 \pm 0.014</math> MPa (Continuity) (<math>0.85 \pm 0.14</math> kg/cm<sup>2</sup>)</td> </tr> </table> <p>Sensor connector</p> 	Pressure rising	Opens at $0.110 \pm 0.014$ MPa (Non continuity) ( $1.12 \pm 0.14$ kg/cm <sup>2</sup> )	Pressure dropping	Closes at $0.08 \pm 0.014$ MPa (Continuity) ( $0.85 \pm 0.14$ kg/cm <sup>2</sup> )	<ol style="list-style-type: none"> <li>1) Install oil pressure measuring gauge.</li> <li>2) Remove wiring harness terminal.</li> <li>3) Start engine.</li> <li>4) Put tester in contact between sensor terminals A &amp; C.</li> </ol>	
	Pressure rising	Opens at $0.110 \pm 0.014$ MPa (Non continuity) ( $1.12 \pm 0.14$ kg/cm <sup>2</sup> )								
	Pressure dropping	Closes at $0.08 \pm 0.014$ MPa (Continuity) ( $0.85 \pm 0.14$ kg/cm <sup>2</sup> )								
Fuel level sensor	P06 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td> BLP00004</td> <td>Raise float to stopper</td> <td>Approx. 12 Ω or below</td> </tr> <tr> <td> BLP00005</td> <td>Lower float to stopper</td> <td>Approx. 85 - 110 Ω</td> </tr> </table>	 BLP00004	Raise float to stopper	Approx. 12 Ω or below	 BLP00005	Lower float to stopper	Approx. 85 - 110 Ω	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connector P06.</li> <li>3) Drain fuel, then remove sensor.</li> <li>4) Insert T - adapter into sensor.</li> </ol> <p>★ Connect the T - adapter to the connector and sensor flange.</p>
 BLP00004	Raise float to stopper	Approx. 12 Ω or below								
 BLP00005	Lower float to stopper	Approx. 85 - 110 Ω								
Air cleaner clogging sensor	P11 P12	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Air cleaner normal</td> <td>Continuity</td> </tr> <tr> <td>Air cleaner clogged</td> <td>No continuity</td> </tr> </table>  <p>BLP00006</p>	Air cleaner normal	Continuity	Air cleaner clogged	No continuity	<ol style="list-style-type: none"> <li>1) Start engine.</li> <li>2) Disconnect P11, P12.</li> <li>3) Put tester in contact with connector at sensor end to measure.</li> </ol>		
Air cleaner normal	Continuity									
Air cleaner clogged	No continuity									

Name of component	Connector No.	Inspection method	Judgement table	Measurement conditions																																											
Alternator	Between alternator terminal R and chassis	Measure voltage	When engine is running (1/2 throttle or above) below, the sensor is defective. → 27.5 - 29.5 V ★ If the battery is old, or after starting in cold areas, the voltage may not rise for some time.	1) Start engine																																											
Gauges	<table border="1"> <thead> <tr> <th colspan="2"></th> <th>Position of gauge display</th> <th>Display level resistance kΩ (Monitor panel input resistance)</th> </tr> <tr> <th colspan="2"></th> <th>Starting switch ON</th> <th>Starting switch OFF</th> </tr> </thead> <tbody> <tr> <td rowspan="16">Measure resistance between coolant temperature gauge C03 (female) (1) - C03 (female) (16)</td> <td rowspan="8">Right side ↑</td> <td>ALL OFF (15)</td> <td>Min. - Max. - 0.646</td> </tr> <tr><td>14</td><td>0.575 - 3.420</td></tr> <tr><td>13</td><td>3.156 - 3.708</td></tr> <tr><td>12</td><td>3.422 - 3.804</td></tr> <tr><td>11</td><td>3.512 - 3.900</td></tr> <tr><td>10</td><td>3.600 - 4.125</td></tr> <tr><td>9</td><td>3.807 - 4.349</td></tr> <tr><td>8</td><td>4.015 - 5.122</td></tr> <tr> <td rowspan="8">Display position ↓ Left side</td> <td>7</td><td>4.728 - 5.899</td></tr> <tr><td>6</td><td>5.445 - 6.818</td></tr> <tr><td>5</td><td>6.294 - 7.910</td></tr> <tr><td>4</td><td>7.302 - 9.210</td></tr> <tr><td>3</td><td>8.502 - 10.774</td></tr> <tr><td>2</td><td>9.946 - 36.535</td></tr> <tr><td>1</td><td>33.725 -</td></tr> <tr><td>ALL OFF (0)</td><td></td></tr> </tbody> </table> <p>★ Levels 13 and 14 flash</p>					Position of gauge display	Display level resistance kΩ (Monitor panel input resistance)			Starting switch ON	Starting switch OFF	Measure resistance between coolant temperature gauge C03 (female) (1) - C03 (female) (16)	Right side ↑	ALL OFF (15)	Min. - Max. - 0.646	14	0.575 - 3.420	13	3.156 - 3.708	12	3.422 - 3.804	11	3.512 - 3.900	10	3.600 - 4.125	9	3.807 - 4.349	8	4.015 - 5.122	Display position ↓ Left side	7	4.728 - 5.899	6	5.445 - 6.818	5	6.294 - 7.910	4	7.302 - 9.210	3	8.502 - 10.774	2	9.946 - 36.535	1	33.725 -	ALL OFF (0)		1) Insert a dummy resistance with the starting switch OFF, or measure the resistance of the sensor. 2) Check the display with the starting switch ON.
			Position of gauge display	Display level resistance kΩ (Monitor panel input resistance)																																											
		Starting switch ON	Starting switch OFF																																												
Measure resistance between coolant temperature gauge C03 (female) (1) - C03 (female) (16)	Right side ↑	ALL OFF (15)	Min. - Max. - 0.646																																												
		14	0.575 - 3.420																																												
		13	3.156 - 3.708																																												
		12	3.422 - 3.804																																												
		11	3.512 - 3.900																																												
		10	3.600 - 4.125																																												
		9	3.807 - 4.349																																												
		8	4.015 - 5.122																																												
	Display position ↓ Left side	7	4.728 - 5.899																																												
		6	5.445 - 6.818																																												
		5	6.294 - 7.910																																												
		4	7.302 - 9.210																																												
		3	8.502 - 10.774																																												
		2	9.946 - 36.535																																												
		1	33.725 -																																												
		ALL OFF (0)																																													
<table border="1"> <thead> <tr> <th colspan="2"></th> <th>Position of gauge display</th> <th>Display level resistance kΩ (Monitor panel input resistance)</th> </tr> <tr> <th colspan="2"></th> <th>Starting switch ON</th> <th>Starting switch OFF</th> </tr> </thead> <tbody> <tr> <td rowspan="16">Measure resistance between fuel level gauge C03 (female) (2) - chassis</td> <td rowspan="8">Right side ↑</td> <td>14</td> <td>Min. - Max. - 13.82</td> </tr> <tr><td>13</td><td>11.71 - 17.43</td></tr> <tr><td>12</td><td>15.18 - 21.25</td></tr> <tr><td>11</td><td>18.90 - 25.05</td></tr> <tr><td>10</td><td>22.59 - 28.45</td></tr> <tr><td>9</td><td>25.82 - 31.85</td></tr> <tr><td>8</td><td>29.18 - 35.22</td></tr> <tr><td>7</td><td>32.45 - 39.91</td></tr> <tr> <td rowspan="8">Display position ↓ Left side</td> <td>6</td><td>37.00 - 44.60</td></tr> <tr><td>5</td><td>41.77 - 48.72</td></tr> <tr><td>4</td><td>45.52 - 55.14</td></tr> <tr><td>3</td><td>50.42 - 64.35</td></tr> <tr><td>2</td><td>60.61 - 77.07</td></tr> <tr><td>1</td><td>72.98 - 69.15</td></tr> <tr><td>ALL OFF (0)</td><td>638.00 - 69.15</td></tr> <tr><td>ALL OFF (0)</td><td></td></tr> </tbody> </table> <p>★ Level 1 flashes.</p>					Position of gauge display	Display level resistance kΩ (Monitor panel input resistance)			Starting switch ON	Starting switch OFF	Measure resistance between fuel level gauge C03 (female) (2) - chassis	Right side ↑	14	Min. - Max. - 13.82	13	11.71 - 17.43	12	15.18 - 21.25	11	18.90 - 25.05	10	22.59 - 28.45	9	25.82 - 31.85	8	29.18 - 35.22	7	32.45 - 39.91	Display position ↓ Left side	6	37.00 - 44.60	5	41.77 - 48.72	4	45.52 - 55.14	3	50.42 - 64.35	2	60.61 - 77.07	1	72.98 - 69.15	ALL OFF (0)	638.00 - 69.15	ALL OFF (0)		1) Insert a dummy resistance with the starting OFF, or measure the resistance of the sensor. 2) Check the display with the starting switch ON.	
		Position of gauge display	Display level resistance kΩ (Monitor panel input resistance)																																												
		Starting switch ON	Starting switch OFF																																												
Measure resistance between fuel level gauge C03 (female) (2) - chassis	Right side ↑	14	Min. - Max. - 13.82																																												
		13	11.71 - 17.43																																												
		12	15.18 - 21.25																																												
		11	18.90 - 25.05																																												
		10	22.59 - 28.45																																												
		9	25.82 - 31.85																																												
		8	29.18 - 35.22																																												
		7	32.45 - 39.91																																												
	Display position ↓ Left side	6	37.00 - 44.60																																												
		5	41.77 - 48.72																																												
		4	45.52 - 55.14																																												
		3	50.42 - 64.35																																												
		2	60.61 - 77.07																																												
		1	72.98 - 69.15																																												
		ALL OFF (0)	638.00 - 69.15																																												
		ALL OFF (0)																																													

## CHECKING AND ADJUSTING BELT TENSION FOR AIR CONDITONER COMPRESSOR


### CHECKING

1. Remove belt guard ①.
2. Press compressor drive belt midway between fan pulley and compressor pulley. The belt should normally deflect by about 15-18 mm (0.60-0.70 inch) when pressed with the finger (with a force of approx. 6kg (13 lb.)





### ADJUSTING

1. Loosen two nuts and bolts ②.
2. Carefully lever compressor housing as shown to tighten belt to tightness criteria. Tighten lower bolt to hold in position.
3. Tighten upper bolt.
4. Check each pulley for damage, wear of the V-groove and wear of the V-belt. In particular, be sure to check the V-belt is not touching the bottom of the V-groove.
5. Replace belt if it has streched, leaving no allowance for adjustment, or if there is a cut or crack on belt.
6. Refit belt guard.
7. When the new belt is set, readjust it after operating for one hour.



## ADJUSTING ENGINE SPEED SENSOR


1. Screw in until the tip of sensor (1) contact gear (2).
  2. When gear (2) contact sensor (1), turn back one turn.
  3. Tighten locknut (3).
- ★ Be particularly careful when securing the sensor wiring to ensure that no excessive force is brought to bear on the wiring.
  - ★ Be careful not to let the tip of the sensor be scratched or to let any iron particles stick to the sensor tip.



## TESTING AND ADJUSTING GOVERNOR MOTOR LEVER STROKE


### TESTING

- ★ Use the governor motor adjustment mode.
- 1. In the time mode display, keep the time switch + travel speed R.H. switch + working mode R.H. switch pressed for 2.5 seconds.
- 2. In this condition, check the governor lever and spring rod.
- 3. After checking, repeat the procedure in Step 1) to finish the governor motor adjustment mode.



### ADJUSTING

1. Turn the starting switch OFF, then remove then nut and disconnect joint (1) from governor lever (4).
2. Repeat the procedure in Step 1 above to set to the governor motor adjustment mode.
3. Set governor lever (4) to a position where it contacts the full speed stopper of the injection pump, then adjust the length of spring assembly (5) and rod (3), and connect joint (1) with the nut.
4. From the above position, turn joint (1) back 4 turns, and secure in position with locknut (6).



### ★ Caution

When the spring assembly is removed and the starting switch is at the OFF position, if the governor motor lever is moved suddenly, the governor motor will generate electricity, and this may cause a failure in the engine throttle controller.

5. Confirm engine speeds are within tolerance according to:

No load engine speeds

Condition	Fuel dial	PC180/PC160
Low idle	Min.	950 ± 50
Auto decel	Max	1.400 ± 70
L.O.	Max.	1890 ± 100
G.O, F.O.	Max.	2030 ± 100
H.O.	Max.	2450 ± 70
Travel*	Max.	


- ★ To check travel condition, ensure H.O working mode is selected then move travel lever so that auto decel is cancel but machine does not move.




## TESTING CLEARANCE OF SWING CIRCLE BEARING

### Method of testing clearance of swing circle bearing when mounted on machine

1. Fix a magnet-type dial gauge to the outer circle (or inner circle) of the swing circle, and put the tip of the probe in contact with the inner circle (or outer circle). Set the dial gauge at the front or rear.




2. Extend the work equipment to the maximum reach, and set the tip of the bucket to the same height as the bottom of the revolving frame. When this is done, the upper structure will tilt forward, so the front will go down and the rear will rise.



3. Set the dial gauge to the zero point.

4. Set the arm more or less at right angles to the ground surface, then lower the boom until the front of the machine comes off the ground. When this is done, the upper structure will tilt back, so the front will rise and the rear will go down.



5. Read the value on the dial gauge at this point. The value on the dial gauge is the clearance of the swing circle bearing.


**!** When carrying out the measurement, do not put your hand or feet under the undercarriage.

6. Return tot the condition in Step 2, and check that the dial gauge has returned to the zero point. If it has not returned to the zero point, repeat Steps 2 to 5.

## TESTING AND ADJUSTING TRACK SHOE TENSION


### TESTING

1. Raise the track frame using the arm and boom, and measure the clearance between the bottom of the track frame and the top of the track shoe.
  - Clearance:  $303 \pm 20$  mm
  - Measurement position  
PC/180LC: 4th track roller from the sprocket.



### ADJUSTING

- ★ If the shoe tension is not within the standard value, adjust as follows.
1. When the tension is too high:
    - Loosen plug (1) gradually, and release the grease.
    - ⚠ There is danger that the plug may fly out under the high internal pressure of the grease, so never loosen plug (1) more than 1 turn.
    - ★ If the grease does not come out easily, move the machine backwards or forwards slowly.
  2. If track is too loose:
    - Pump in grease through grease fitting (2).
    - ★ If the grease cannot be pumped in easily, move the machine backwards and forwards slowly.



## TESTING AND ADJUSTING HYDRAULIC PRESSURE IN WORK EQUIPMENT, SWING, TRAVEL CIRCUIT

### MEASURING

★ Hydraulic oil temperature when measuring: 45 - 55°C

⚠ Lower the work equipment to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then put the safety lock lever in the LOCK position.

- Remove pressure pick-up plug (1) (Thread dia.= 10, Pitch= 1.25mm) from the circuit to be measured, then install oil pressure gauge C1 (58.8 MPa (600kg/cm<sup>2</sup>)).

- **Measuring unload pressure**




1. Measure the oil pressure in H/O mode with the engine at high idling and the control levers at neutral.

- **Measuring pump relief pressure**

1. Oil pressure when main pressure is at low pressure (31.9 kg/cm<sup>2</sup>)

- 1) Measure the pressure when each actuator except the travel is relieved in G/O mode with the engine at high idling.



★ Note that the set pressure of the safety valve for the swing motor is lower than the main relief pressure, so the value measured will be the relief pressure of the safety valve.  
If the swing lock switch is turned ON, the pressure will rise, so always keep the lock switch OFF when measuring.



2. When main relief pressure is raised (34.8 MPa (355 kg/cm<sup>2</sup>))
  - 1) When travel is operated
 

Measure the oil pressure when the travel is relieved on each side separately in H/O mode with the engine at high idling.

    - ★ To relieve the travel circuit, put block ① under the track shoe grouser, or put block ② between the sprocket and frame to lock the track.
  - 2) When power max. function is actuated when measuring the oil pressure in G/O or H/O mode with the engine at high idling and the power max. function actuated, relieve one of the boom, arm, or bucket circuits, and measure the oil pressure.




TESTING AND ADJUSTING


ADJUSTING

1. Main relief valve




- Adjusting high set pressure end
  - 1) Loosen locknut (5).
    - ★ Check that elbow (6) can move.
  - 2) Loosen locknut (3), then turn holder (4) to adjust.
    - ★ Turn the holder to adjust as follows.
      - To INCREASE pressure, turn CLOCKWISE.
      - To DECREASE pressure, turn COUNTERCLOCKWISE.
- ★ Amount of adjustment for one turn of adjustment screw: 12.6 MPa (128 kg/cm<sup>2</sup>)

 **kgm** Locknut: 58.8 ± 4.9 Nm (6 ± 0.5 kgm)

- ★ When the high pressure end is adjusted, the low pressure end also changes, so adjust the low pressure end also.
- Adjusting low set pressure end
  - 1) Loosen locknut (5).
    - ★ Check that elbow (6) can move.
  - 2) Loosen locknut (7), then turn holder (8) to adjust.
    - ★ Turn the holder to adjust as follows.
      - To INCREASE pressure, turn CLOCKWISE.
      - To DECREASE pressure turn COUNTERCLOCKWISE.
- ★ Amount of adjustment for one turn of adjustment screw: 12.6 MPa (128 kg/cm<sup>2</sup>)

 **kgm** Locknut: 44.1 ± 4.9 Nm (4.5 ± 0.5 kgm)

- ★ Normally, there is a pressure of approx. 1.27 MPa (13 kg/cm<sup>2</sup>) or less applied to port Pr, but at the high pressure setting the pressure is approx. 2.94 MPa (30kg/cm<sup>2</sup>).











## TESTING AND ADJUSTING



### 2. Measuring LS differential pressure

- 1) Measuring with a differential pressure gauge
  - i) Remove oil pressure measurement plug (1) (Thread dia.= 10mm, Pitch=1.25mm), and install differential pressure gauge C4.
  - ii) Set to the conditions in Table 2 and measure the LS differential pressure.

Working	Fuel control dial	Operation	Differential pressure (MPa(kg/cm <sup>2</sup> ))
H/O mode	MAX	Levers at neutral	3.9 ± 1.0 (40 ± 10)
H/O mode	MAX	Travel speed: Hi Travel circuit under no load (lever half operated)	2.5 ± 0.1 (25 ± 1)

### 2) Measuring with oil pressure gauge

- ★ The maximum differential pressure is 3.9 ± 1.0 MPa (40 ± 10 kg/cm<sup>2</sup>), so measure with the same gauge.
- i) Remove oil pressure measurement plug (1) (thread dia.= 10mm, pitch=1.25mm), and install the plug inside hydraulic tester C1.
- ii) Install oil pressure gauge C1 (58.8 MPa (600 kg/cm<sup>2</sup>)) to the measurement plug for the pump discharge pressure.
  - \* Use a gauge with a scale in units of 0.98 MPa (10 kg/cm<sup>2</sup>).
  - If no 58.8 MPa (600 kg/cm<sup>2</sup>) pressure gauge is available, a 39.2 MPa (400 kg/cm<sup>2</sup>) pressure gauge can be used.
- iii) Set to the conditions in Table 2 and measure the pump discharge pressure.
  - ★ Stand directly in front of the indicator and be sure to read it correctly.
- iv) Remove oil pressure gauge C1, then install to the LS pressure measurement plug.
- v) Set to the conditions in Table 2 and measure the LS pressure.
  - ★ Stand directly in front of the indicator and be sure to read it correctly. (pump discharge pressure) - (LS pressure) = Differential pressure



### ADJUSTING

#### 1. Adjusting LS valve

When the differential pressure is measured under the conditions above, and the results show that the differential pressure is not within the standard value, adjust as follows.


- 1) Loosen locknut (4) and turn screw (5) to adjust the differential pressure.
  - ★ Turn the screw to adjust the differential pressure as follows.
    - To INCREASE pressure, turn CLOCKWISE
    - To DECREASE pressure, turn COUNTERCLOCKWISE
- 2) After adjusting, tighten locknut (4).



kgm Locknut:

$29.4 \pm 4.9 \text{ Nm}$  ( $3.0 \pm 0.5 \text{ kgm}$ )

Note: Always measure the differential pressure while adjusting.



202F06355

## TESTING AND ADJUSTING TVC VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE)





### MEASURING

- ★ Hydraulic oil temperature when measuring: 45 - 55°C
  - Measure the oil pressure when the circuit is relieved in the pressure rise mode.
1. Remove pressure measurement plugs (1) and (2) and install oil pressure gauge C1.
    - ★ Install a 39.2 MPa (400 kg/cm<sup>2</sup>) gauge to the servo end, and a 58.8 MPa (600 kg/cm<sup>2</sup>) gauge to the pump outlet port end.
  2. Set the swing lock switch ON.
  3. Set the working mode to H/O mode.
  4. Run the engine at high idling, push the L.H. knob switch ON, and measure the oil pressure when the arm IN circuit is relieved.
- \* Check that the servo piston input pressure is APPROX 1/3 of the pump discharge pressure.

### [Reference]

If there is any abnormality in the LS valve or servo piston, the servo piston input pressure will be almost the same or 0 of the pump discharge pressure.

- ★ (2) Thread dia. = 10mm, Pitch=1.25mm
- (1) Thread dia= 12 mm Pitch =1.5 mm




**ADJUSTING**

- ★ If the load becomes larger, the engine speed will drop. Or if the engine speed remains normal, the work equipment speed will drop. In such cases, if the pump discharge pressure and LS differential pressure are normal, adjust the TVC valve as follows.
- 1. Loosen locknut (3), and if the speed is slow, turn screw (4) to the left; if the engine speed drops, turn the screw to the right.
  - ★ If the screw is turned clockwise the pump absorption torque will be increased, and if it is turned anticlockwise pump absorption torque will be reduced.
- 2. After completing the adjustment, tighten the locknut.

 **kgm** Locknut: Nm (kgm)

- ★ Before the screw is adjusted please mark there to make clear the original position of the screw.



# TESTING AND ADJUSTING LS VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE) AND LS DIFFERENTIAL PRESSURE

★ Hydraulic oil temperature when measuring: 45 - 55°C

## MEASURING

1. Measuring LS valve output pressure (servo piston input pressure)
  - 1) Remove pressure measurement plugs (1) and (2) and install oil pressure gauge C1.
    - ★ Install a 39.2 MPa (400 kg/cm<sup>2</sup>) gauge to the servo end, and a 58.8 MPa (600 kg/cm<sup>2</sup>) gauge to the pump outlet port end.
- Oil pressure when travel is rotating under no load (wheels OFF the ground).
  - i) Set the working mode to H/O mode, and turn the travel speed switch to Hi.
  - ii) Use the work equipment and/or undercarriage attachment to raise the wheels OFF the ground.
  - iii) Measure the oil pressure with the engine at high idling and the travel pedal operated to the end of its stroke to rotate the wheels under no load. Run the engine at high idling, operate the travel pedal to the end of its stroke, and measure the oil pressure when the working mode and travel speed are switched as shown in Table 1.






Table 1

Working mode	Travel pedal	Pump pressure MPa (kg/cm <sup>2</sup> )	Servo inlet port pressure (MPa(kg/cm <sup>2</sup> ))	Remarks
H/O mode	Neutral	3.9 ± 1.0 (4.0 ± 1.0)	3.9 ± 1.0 (40 ± 10)	About same pressure
H/O mode	Full	6.8 ± 2.0 (90 ± 20)		About of pressure

- ★ (2) Thread dia= 10mm
- (1) Thread dia= 12mm



202F06340



202F06341




2. Measuring LS differential pressure
  - 1) Measuring with a differential pressure gauge
    - i) Remove oil pressure measurement plug (1) (Thread dia.=12mm, Pitch=1.5 mm), and install differential pressure gauge **C4**.
    - ii) Set to the conditions in Table 2 and measure the LS differential pressure.

Table 2

Working mode	Fuel control dial	Operation	Differential pressure (MPa (kg/cm <sup>2</sup> ))
H/O mode	MAX	Pedal at neutral	3.9 ± 1.0 (40 ± 10)
H/O mode	MAX	Travel speed: Hi Travel circuit under no load (pedal fully operated)	2.5 ± 0.1 (25 ± 1)

Note: When all control levers are at neutral, the LS differential pressure is the same as the unload pressure

- 2) Measuring with oil pressure gauge
  - ★ The maximum differential pressure is 3.9MPa (40kg/cm<sup>2</sup>), so measure with the same gauge.
  - i) Remove oil pressure measurement plug (1) (thread dia.=12mm, pitch=1.5mm), and install the plug inside hydraulic tester **C1**.
  - ii) Install oil pressure gauge **C1** (58.8 MPa (600 kg/cm<sup>2</sup>)) to the measurement plug for the pump discharge pressure.
    - ★ Use a gauge with a scale in units of 0.98 MPa (10 kg/cm<sup>2</sup>).
    - If no 58.8 MPa (600 kg/cm<sup>2</sup>) pressure gauge is available, a 39.2 MPa (400 kg/cm<sup>2</sup>) pressure gauge can be used.
  - iii) Set to the conditions in Table 2 and measure the pump discharge pressure.
    - ★ Stand directly in front of the indicator and be sure to read it correctly.
  - iv) Remove oil pressure gauge **C1**, then install to the LS pressure measurement plug.
  - v) Set to the conditions in Table 2 and measure the LS pressure.
    - ★ Stand directly in front of the indicator and be sure to read it correctly. (Pump discharge pressure) - (LS pressure)= differential pressure





**ADJUSTING**

1. Adjusting LS valve

When the differential pressure is measured under the conditions above, and the results show that the differential pressure is not within the standard value, adjust as follows.

- 1) Loosen locknut (4) and turn screw (5) to adjust the differential pressure.
  - ★ Turn the screw to adjust the differential pressure as follows.
    - To INCREASE pressure, turn CLOCKWISE
    - To DECREASE pressure, turn COUNTERCLOCKWISE
- 2) After adjusting, tighten locknut (4).





 **kgm** Locknut:  
 $29.4 \pm 4.9 \text{ Nm}$  ( $3.0 \pm 0.5 \text{ kgm}$ )

Note: Always measure the differential pressure while adjusting.

# CONTROL PUMP CIRCUIT OIL PRESSURE


## MEASURING

- ★ Hydraulic oil temperature when measuring: 45 - 55°C
- 1. Remove pressure pick-up plug (1) (Thread dia.= 10mm, Pitch=1.25mm), and install oil pressure gauge C1 (5.88 MPa (60 kg/cm<sup>2</sup>).
- 2. Start the engine and measure with the engine at high idling.
  - ★ When testing for internal leakage of the equipment in the control circuit, use the parts given below to shut off the circuit for the following sections when measuring the relief pressure.



No.	Section of hydraulic circuit shut off	Component that can be checked
1	Control pump outlet port	Control pump
2	Solenoid valve inlet port	Solenoid valve
3	Travel PPC valve inlet port	Travel PPC valve
4	R.H. PPC valve inlet port	R.H. PPC valve
5	L.H. PPC valve inlet port	L.H. PPC valve

- ★ Items No. 2 and below can be checked if the equipment in the previous number is normal.
- ★ Use the following parts to shut off the circuit.
  - For elbow
    - Sleeve nut: 07221-20210, 07221-20315  
07221-20422
    - Plug: 07222-00210 07222-00315  
07222-00414
  - For hose
    - Plug: 07376-50210, 07376-50315  
07376-50422



202F06358-1K




**ADJUSTING**

1. Loosen locknut (2) and turn adjustment screw (3) to adjust.
  - ★ Turn the adjustment screw as follows.
    - To INCREASE pressure, turn CLOCKWISE
    - To DECREASE pressure, turn COUNTER-CLOCKWISE
  - ★ Amount of adjustment for one turn of adjustment screw: MPa (kg/cm<sup>2</sup>)

 **kgm** Locknut: Nm (± kgm)

- ★ After completion of adjustment, repeat the procedure in MEASURING to check the set pressure again.



## TESTING EPC VALVE, SOLENOID VALVE OUTPUT PRESSURE

### MEASURING

★ Hydraulic oil temperature when measuring: 45 - 55°C



1. Measuring output pressure of LS control EPC solenoid valve

- 1) Disconnect output hose (1) of the LS control EPC valve, then use adapter **C3** in the oil pressure gauge kit to install oil pressure gauge **C1** (5.9 MPa (60 kg/cm<sup>2</sup>)).
- 2) Measure the output pressure under the conditions in Table 1.

Table 1

Operation	Engine speed (rpm)	Output t pressure MPa (kg/cm <sup>2</sup> )	[Reference] Current (A)
All control levers at neutral	Min. 1100	2.5 (26)	800±80
Travel lever operated, travel speed Hi	Max. 1900	0.2 ± 0.2 (2±2)	0

★ Monitoring code 10 or 40 for engine speed  
Monitoring code 15 for LS control EPC current



2. Measuring output pressure of ON/OFF solenoid valve
  - 1) Disconnect outlet hose (2) of the solenoid valve, then use adapter **C3** in the oil pressure gauge kit to install oil pressure gauge **C1** (5.9 MPa (60 kg/cm<sup>2</sup>)).
  - 2) Measure the output pressure under the conditions in Table 2.





Table 2

Name of solenoid		Measurement conditions	Operating condition	Condition of solenoid	Oil pressure (MPa (kg/cm <sup>2</sup> ))	Remarks
1	Swing brake	Swing or work equipment lever operated	Brake canceled	ON	2.94±0.49 (30±5)	
		All levers except travel at neutral (5 sec after returning to neutral)	Brake actuated	OFF	0	
2	Travel speed	Travel speed switch at Hi Engine speed 1500 rpm or above Travel lever operated	Travel speed Hi	ON	2.94 ±0.49 (30±5)	Motor swash plate angle at minimum
		Travel speed selected switch at to or engine speed 1500 rpm or below	Travel speed Lo	OFF	0	Motor swash plate angle at maximum
3	2-stage relief	Swing lock switch ON + work equipment lever operated	pressure rise	ON	2.94 ±0.49 (30±5)	
		All levers at neutral	Normal pressure	OFF	0	
4	LS select	Compound operation of travel + work equipment or swing	LS circuit pressure bypassed	ON	0	
		Any operation except above	Ls circuit pressure not bypassed	OFF	2.94±0.49 (30±5)	

- ★ Operation of solenoid valve  
 ON: Continuous (oil pressure generated)  
 OFF: Not continuous (oil pressure: 0)  
 However, for LS bypass only:  
 ON: continuous (oil pressure: 0)  
 OFF: Not continuous (oil pressure: 30)



## MEASURING PPC VALVE OUTPUT PRESSURE AND TESTING PPC SHUTTLE VALVE

★ Hydraulic oil temperature when measuring: 45 - 55°C

### 1. Measuring PPC valve output pressure

- 1) Disconnect the hose of the circuit to be measured (see next page).
- 2) Install adapter **C3** between the hose and elbow.
- 3) Install oil pressure gauge **C1** (5.9 MPa (60 kg/cm<sup>2</sup>)) to adapter **C3**.
- 4) Run the engine at high idling, operate the control lever of the circuit to be measured, and measure the oil pressure.




### 2. Checking PPC shuttle valve

If the output pressure at the control valve end is low, check for leakage of oil from the PPC shuttle valve as follows.

- 1) Disconnect the hose between the PPC valve and the shuttle block at the block end.
- 2) Install an adapter for measuring the oil pressure to the tip of the hose, then install blind plugs to the tip and shuttle block end.
- 3) Operate the control lever and measure the output pressure.
  - ★ If the output pressure becomes normal, there is leakage from the PPC shuttle valve; if there is no change, the PPC valve is defective.

### 3. Checking defective operation of PPC shuttle valve


- 1) Remove the oil pressure switch, fit adapter **C5**, then install oil pressure gauge **C1** (5.9 MPa (60 kg/cm<sup>2</sup>)).
- 2) Operate the applicable lever.
  - ★ If no oil pressure is generated or if oil pressure is generated when another lever is operated, the operation of the PPC shuttle valve is defective.



**MEASURING PPC VALVE OUTPUT PRESSURE AND TESTING  
PPC SHUTTLE VALVE**


**TESTING AND ADJUSTING**

**Pressure switch location diagram**  
Shuttle block seen from rear of machine



202F06367

• **Circuit diagram**



F20206017

- |   |   |
|---|---|
| 1. Swing PPC shuttle valve  | 4. Travel PPC shuttle valve                                       |
| 2. PPC shuttle valve for LS select                                | 5. PPC shuttle valve for R.H. travel FORWARD, L.H. travel REVERSE |
| 3. PPC shuttle valve for L.H. travel FORWARD, R.H. travel REVERSE |   |

## ADJUSTING WORK EQUIPMENT, SWING PPC VALVE

★ If there is excessive play in the work equipment or swing lever, adjust as follows.

⚠ Lower the work equipment to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then set the safety lock lever to the LOCK position.


1. Remove the PPC valve.
2. Remove boot (1).
3. Loosen locknut (2), then screw in disc (3) until it contacts the 4 heads of piston (4).
- \* When doing this, do not move the piston.
4. Secure disc (3) in position, then tighten locknut (2) to the specified torque.

 **kgm** Locknut:

**112.7 ± 14.7 Nm (115.5±1.5 kgm)**

5. Install boot (1).



★ With the above adjustment, the clearance between disc (3) and piston (4) becomes 0.



BLP00154

## TESTING TRAVEL DEVIATION

- ★ When traveling on level ground.
- 1. set the machine in the travel posture.
  - ★ For the travel posture, extend the bucket and arm cylinder rods fully, and hold the boom angle at 45°.
- 2. Travel for 10 m, then measure the deviation when traveling for the next 20m.
  - ★ Set to H/O mode and measure with the engine at full throttle.
  - ★ Install the hydraulic pressure gauge and measure the pump discharge pressure at the same time.



## TESTING LOCATIONS CAUSING HYDRAULIC DRIFT OF WORK EQUIPMENT

★ If there is any hydraulic drift in the work equipment (cylinders), check as follows to determine if the cause is in the cylinder packing or in the control valve.



### 1. Checking for defective cylinder packing

- 1) Checking boom and bucket cylinders
  - i) Set in the same posture as when measuring hydraulic drift, and stop the engine.
  - ii) Operate the boom control lever to RAISE or the bucket control lever to CURL.
    - If the lowering speed increases, the packing is defective.
    - If there is no change, the boom lock valve (boom) or the control valve (bucket) is defective.
- 2) Checking arm cylinder
  - i) Operate the arm cylinder to move the arm in fully, then stop the engine.
  - ii) Operate the control lever to arm IN.
    - If the lowering speed increases, the packing is defective.
    - If there is no change, the control valve is defective.

★ If the pressure in the accumulator has dropped, run the engine for approx. 10 seconds to charge the accumulator again before operating.

**[Reference]** If the cause of the hydraulic drift is in the packing, and the above operation is carried out, the downward movement becomes faster for the following reasons.

- 1) If the work equipment is set to the above posture (holding pressure applied to the bottom end), the oil at the bottom end leaks to the head end. However, the volume at the head end is smaller than the volume at the bottom end by the volume of the rod, so the internal pressure at the head end increases because of the oil flowing in from the bottom end.
- 2) When the internal pressure at the head end increases, the pressure at the bottom end also rises in proportion to this. The balance is maintained at a certain pressure (this differs according to the amount of leakage) by repeating this procedure.
- 3) When the pressure is balanced, the downward movement becomes slower. If the lever is then operated according to the procedure given above, the circuit at the head end is opened to the drain circuit (the bottom end is closed by the check valve), so the oil at the head end flows to the drain circuit and the downward movement becomes faster.





**2. Checking PPC valve**





If the hydraulic drift differs when the safety lock lever is in the LOCK or FREE position, (engine running), the PPC valve is defective.



# MEASURING OIL LEAKAGE

★ Oil temperature when measuring: 45 - 55°C

## 1. Work equipment cylinder


- ★ If the hydraulic drift of the work equipment is outside the standard value, measure the leakage inside the cylinder as follows, and judge if the cause of the hydraulic drift is in the cylinder or in the control valve.
    - If the leakage is within the standard value, the problem is in the control valve.
    - If the leakage is greater than the standard value, the problem is in the cylinder.
- 1) Fully extend the rod of the cylinder to be measured, then stop the engine.
  - 2) Disconnect piping (1) at the head end, then block the piping at the chassis end with a blind plug.
    - ⚠ Be careful not to disconnect the piping at the bottom end.
  - 3) Start the engine and apply the relief pressure to the bottom end of the cylinder with the engine at full throttle.
    - ★ Boom cylinder: RAISE
    - Arm cylinder: IN
    - Bucket cylinder: CURL
  - 4) Continue this condition for 30 seconds, then measure the oil leakage for the next one minute.





**2. Swing motor**

- 1) Disconnect drain hose from the swing motor, then install a blind plug at the tank end.
- 2) Turn the swing lock switch ON.
- 3) Start the engine and operate the swing relief with the engine at full throttle.
- 4) continue this condition for 30 seconds, then measure the oil leakage for the next one minute.
  - ★ After measuring, swing 180° and measure again.






**3. Travel motor**

- 1) Disconnect drain hose (1) from the travel motor, then fit a blind plug at the hose end.
- 2) Fit block ① under the track shoe grouser, or fit block ② between the sprocket and frame to lock the track.
- 3) Start the engine and operate the travel relief with the engine at full throttle.

**⚠** When measuring the oil leakage from the travel motor, mistaken operation of the control lever may lead to a serious accident, so always use signals and check when carrying out this operation.

- 4) Continue this condition for 30 seconds, then measure the oil leakage for the next one minute.
  - ★ When measuring, move the motor slightly (to change the position between the valve plate and cylinder, and piston and cylinder), and measure several times.



## RELEASING REMAINING PRESSURE IN HYDRAULIC CIRCUIT

- ★ If the piping between the hydraulic cylinder and the control valve is to be disconnected, release the remaining pressure from the circuit as follows. The travel circuit is an open circuit, so there is no remaining pressure. It is enough to remove the oil filler cap.
1. Loosen the oil filler cap slowly to release the pressure inside the tank.
  2. Operate the control levers.
    - ★ When the levers are operated 2 - 3 times, the pressure stored in the accumulator is removed.
  3. Start the engine, run at low idling for approx. 5 minutes, then stop the engine and operate the control levers.
    - ★ Repeat the above operation 2 - 3 times to release all the remaining pressure.







# TROUBLESHOOTING

Points to remember when troubleshooting .....	20- 56
Sequence of events in troubleshooting .....	20- 57
Precautions when carrying out maintenance .....	20- 58
Checks before troubleshooting .....	20- 65
Connector types and mounting locations .....	20- 66
Connection table for connector pin numbers .....	20- 71
Explanation of control mechanism of electrical system .....	20- 84
Display method and special functions of monitor panel .....	20- 85
Method of using judgement table .....	20- 93
Method of using troubleshooting charts .....	20- 95
Details of troubleshooting and troubleshooting procedure .....	20- 97
Service code table .....	20- 102
Troubleshooting of communication abnormality system (N mode) .....	20- 103
Troubleshooting of governor, pump controller [governor control system] (E mode) .....	20- 106
Troubleshooting of engine (S mode) .....	20- 137
Troubleshooting of governor, pump controller system [pump control system] (C mode) .....	20- 160
Troubleshooting of governor, pump controller [input signal system] (Fmode) .....	20- 195
Troubleshooting of hydraulic, mechanical system (H mode) .....	20- 209
Troubleshooting of monitor panel system (M mode) .....	20- 243



## POINTS TO REMEMBER WHEN TROUBLESHOOTING

- ⚠ Stop the machine in a level place, and check that the safety pin, blocks, and parking brake are securely fitted.
- ⚠ When carrying out the operation with two or more workers, keep strictly to the agreed signal, and do not allow any unauthorized person to come near.
- ⚠ If the radiator cap is removed when the engine is hot, hot water may spurt out and cause burns, so wait for the engine to cool down before starting troubleshooting.
- ⚠ Be extremely careful not to touch any hot parts or to get caught in any rotating parts.
- ⚠ When disconnecting wiring, always disconnect the negative (-) terminal of the battery first.
- ⚠ When removing the plug or cap from a location which is under pressure from oil, water, or air, always release the internal pressure first. When installing measuring equipment, be sure to connect it properly.


The aim of troubleshooting is to pinpoint the basic cause of the failure, to carry out repairs swiftly, and to prevent reoccurrence of the failure.

When carrying out troubleshooting, an important point is of course to understand the structure and function. However, a short cut to effective troubleshooting is to ask the operator various questions to form some idea of possible causes of the failure that would produce the reported symptoms.

1. When carrying out troubleshooting, do not hurry to disassemble the components. If components are disassembled immediately any failure occurs:
  - Parts that have no connection with the failure or other unnecessary parts will be disassembled.
  - It will become impossible to find the cause of the failure.

It will also cause a waste of manhours, parts, or oil or grease, and at the same time, will also lose the confidence of the user or operator. For this reason, when carrying out troubleshooting, it is necessary to carry out thorough prior investigation and to carry out troubleshooting in accordance with the fixed procedure.
2. Points to ask user or operator
  - 1) Have any other problems occurred apart from the problem that has been reported?
  - 2) Was there anything strange about the machine before the failure occurred?
  - 3) Did the failure occur suddenly, or were there problems with the machine condition before this?
  - 4) Under what conditions did the failure occur?
  - 5) Had any repairs been carried out before the failure?  
When were these repairs carried out?
  - 6) Has the same kind of failure occurred before?
3. Check before troubleshooting
  - 1) Check the oil level
  - 2) Check for any external leakage of oil from the piping or hydraulic equipment.
  - 3) Check the travel of the control levers.
  - 4) Check the stroke of the control valve spool.
  - 5) Other maintenance items can be checked externally, so check any item that is considered to be necessary.
4. Confirming failure
  - Confirm the extent of the failure yourself, and judge whether to handle it as a real failure or as a problem with the method of operation, etc.
  - ★ When operating the machine to reenact the troubleshooting symptoms, do not carry out any investigation or measurement that may make the problem worse.
5. Troubleshooting
  - Use the results of the investigation and inspection in items 2-4 to narrow down the causes of failure, then use the troubleshooting flowchart to locate the position of the failure exactly.
  - ★ The basic procedure for troubleshooting is as follows.
    - 1) Start from the simple points.
    - 2) Start from the most likely points.
    - 3) Investigate other related parts or information.
6. Measures to remove root cause of failure
  - Even if the failure is repaired, if the root cause of the failure is not repaired, the same failure will occur again. To prevent this, always investigate why the problem occurred. Then, remove the root cause.

# SEQUENCE OF EVENTS IN TROUBLESHOOTING



## PRECAUTIONS WHEN CARRYING OUT MAINTENANCE

To maintain the performance of the machine over a long period, and to prevent failures or other troubles before they occur, correct operation, maintenance and inspection, troubleshooting, and repairs must be carried out. This section deals particularly with correct repair procedures for mechatronics and is aimed at improving the quality of repairs. For this purpose, it gives sections on "Handling electric equipment" and "Handling hydraulic equipment" (particularly hydraulic oil).



### 1. PRECAUTIONS WHEN HANDLING ELECTRIC EQUIPMENT

#### 1) Handling wiring harnesses and connectors


Wiring harnesses consist of wiring connecting one component to another component, connectors used for connecting and disconnecting one wire from another wire, and protector or tubes used for protecting the wiring. Compared with other electrical components fitted in boxes or cases, wiring harnesses are more likely to be affected by the direct effects of rain, water, heat, or vibration. Furthermore, during inspection and repair operations they are frequently removed and installed again, so they are likely to suffer deformation or damage. For this reason, it is necessary to be extremely careful when handling wiring harnesses.

#### Main failures occurring in wiring harness

- (1) Defective contact of connectors (defective contact between male and female) Problems with defective contact are likely not properly inserted into the female connector, or because one or both of the connectors is deformed or the position is not correctly aligned, or because there is corrosion or oxidization of the contact surfaces.




- (2) Defective compression or soldering of connectors  
The pins of the male and female connectors are in contact at the compressed terminal or soldered portion, but there is excessive force on the wiring, and the plating peels to cause improper connection or breakage.




- (3) Disconnections in wiring  
If the wiring is held and the connectors are pulled apart, or components are lifted with a crane with the wiring still connected, or a heavy object hits the wiring, the compression of the connector may be lost, or the soldering may be damaged, or the wiring may be broken.

- (4) High pressure water entering connector  
The connector is designed to make it difficult for water to enter (drip-proof structure), but if high pressure water is sprayed directly on the connector, water may enter the connector depending on the direction of the water jet.




The connector is designed to prevent water from entering, but at the same time, if the water does enter, it is difficult for it to be drained. Therefore, if water should get into the connector, the pins will be short-circuited by the water, so if any water gets in, immediately dry the connector or take other appropriate action before passing electricity through it.

- (5) Oil or dirt stuck to connector  
If oil or grease are stuck to the connector and an oil film is formed on the mating surface between the male and female pins, the oil will not let the electricity pass, so there will be defective contact. If there is oil or grease or dirt stuck to the connector, wipe it off with a dry cloth or blow dry with air, and spray it with a contact restorer.




- ★ When wiping the mating portion of the connector, be careful not to use excessive force or deform the pins.
- ★ If there is water or oil in the air, it will increase the contamination of the points, so clean with air from which all the water and oil has been removed.



## 2) Removing, installing, and drying connectors and wiring harness

### Disconnecting connectors


- (1) Hold the connectors when disconnecting. When disconnecting the connectors, hold the connectors and not the wires. For connectors held by a screw, loosen the screw fully, then hold the male and female connectors in each hand and pull apart. For connectors which have a lock stopper, press down the stopper with your thumb and pull the connectors apart.




- (2) Action to take after removing connectors  
After removing any connector, cover it with a vinyl bag to prevent any dust, dirt, oil, or water from getting in the connector portion.

### Connecting connectors

- (1) Check the connector visually.
- Check that there is no oil, dirt or water stuck to the connector pins (mating portion).
  - Check that there is no deformation, defective contact, corrosion, or damage to the connector pins.
  - Check that there is no damage or breakage to the outside of the connector.
- ★ If there is any oil, water, or dirt stuck to the connector, wipe it off with a dry cloth. If any water has got inside the connector, warm the inside of the wiring with a dryer, but be careful not to make it too hot as this will cause short circuits.
  - ★ If there is any damage or breakage, replace the connector.



- (2) Fix the connector securely.  
Align the position of the connector correctly, then insert it securely.  
For connectors with lock stopper  
Push in the connector until the stopper clicks into position.






- (3) Correct any protrusion of the boot and any misalignment of the wiring harness  
For connectors fitted with boots, correct any protrusion of the boot. In addition, if the wiring harness is misaligned, or the clamp is out of position, adjust it to its correct position.
- ★ When blowing with dry air, there is danger that the oil in the air may cause improper contact, so clean with air from which all the water and oil has been removed.


#### Drying wiring harness

If there is any oil or dirt on the wiring harness, wipe it off with a dry cloth. Avoid washing it in water or using steam. If the connector must be washed in water, do not use high pressure water or steam directly on the wiring harness. If water gets directly on the connector, do as follows.

- (1) Disconnect the connector and wipe off the water with a dry cloth.
- ★ If the connector is blown dry with air, there is the risk that oil in the air may cause defective contact, so avoid blowing with air.
- (2) Dry the inside of the connector with a dryer.  
If water gets inside the connector, use a dryer to dry the connector.
- ★ Hot air from the dryer can be used, but be careful not to make the connector or related parts too hot, as this will cause deformation or damage to the connector.






- (3) Carry out a continuity test on the connector. After drying, leave the wiring harness disconnected and carry out a continuity test to check for any short circuits between pins caused by water.
  - ★ After completely drying the connector, blow it with contact restorer and reassemble.



**3) Handling control box**

- (1) The control box contains a microcomputer and electronic control circuits. These control all of the electronic circuits on the machine, so be extremely careful when handling the control box.
- (2) Do not open the cover of the control box unless necessary.
- (3) Do not place objects on top of the control box.
- (4) Cover the control connectors with tape or a vinyl bag.
- (5) During rainy weather, do not leave the control box in a place where it is exposed to rain.
- (6) Do not place the control box on oil, water, or soil, or in any hot place, even for a short time. (Place it on a suitable dry stand)
- (7) Precautions when carrying out arc welding  
When carrying out arc welding on the body, disconnect all wiring harness connectors connected to the control box. Fit an arc welding ground close to the welding point.



## 2. POINTS TO REMEMBER WHEN HANDLING HYDRAULIC EQUIPMENT

With the increase in pressure and precision of hydraulic equipment, the most common cause of failure is dirt (foreign material) in the hydraulic circuit. When adding hydraulic oil, or when disassembling or assembling hydraulic equipment, it is necessary to be particularly careful.

### 1) Be careful of the operating environment.

Avoid adding hydraulic oil, replacing filters, or repairing the machine in rain or high winds, or places where there is a lot of dust.

### 2) Disassembly and maintenance work in the field

If disassembly or maintenance work is carried out on hydraulic equipment in the field, there is danger of dust entering the equipment. It is also difficult to confirm the performance after repairs, so it is desirable to use unit exchange. Disassembly and maintenance of hydraulic equipment should be carried out in a specially prepared dustproof workshop, and the performance should be confirmed with special test equipment.




### 3) Sealing openings

After any piping or equipment is removed, the openings should be sealed with caps, tapes, or vinyl bags to prevent any dirt or dust from entering. If the opening is left open or is blocked with a rag, there is danger of dirt entering or of the surrounding area being made dirty by leaking oil so never do this.

Do not simply drain oil out on to the ground, collect it and ask the customer to dispose of it, or take it back with you for disposal.

### 4) Do not let any dirt or dust get in during refilling operations.

Be careful not to let any dirt or dust get in when refilling with hydraulic oil. Always keep the oil filler and the area around it clean, and also use clean pumps and oil containers. If an oil cleaning device is used, it is possible to filter out the dirt that has collected during storage, so this is an even more effective method.






**5) Change hydraulic oil when the temperature is high.**

When hydraulic oil or other oil is warm, it flows easily. In addition, the sludge can also be drained out easily from the circuit together with the oil, so it is best to change the oil when it is still warm. When changing the oil, as much as possible of the old hydraulic oil must be drained out. (Do not drain the oil from the hydraulic tank; also drain the oil from the filter and from the drain plug in the circuit.) If any old oil is left, the contaminants and sludge in it will mix with the new oil and will shorten the life of the hydraulic oil.

**6) Flushing operations**

After disassembling and assembling the equipment, or changing the oil, use flushing oil to remove the contaminants, sludge, and old oil from the hydraulic circuit.


Normally, flushing is carried out twice: primary flushing is carried out with flushing oil, and secondary flushing is carried out with the specified hydraulic oil.



**7) Cleaning operations**

After repairing the hydraulic equipment (pump, control valve, etc.) or when running the machine, carry out oil cleaning to remove the sludge or contaminants in the hydraulic oil circuit.

The oil cleaning equipment is used to remove the ultrafine (about 3  $\mu$ ) particles that the filter built into the hydraulic equipment cannot remove, so it is an extremely effective device.



## CHECKS BEFORE TROUBLESHOOTING

	Item	Judgement standard	Action
Lubricating oil, cooling water	1. Check fuel level	-	Add fuel
	2. Check for dirt or water in fuel	-	Clean, drain
	3. Check hydraulic oil lever	-	Add oil
	4. Check hydraulic oil strainer	-	Clean, drain
	5. Check swing machinery oil level	-	Add oil
	6. Check engine oil level (Level of oil in oil pan)	-	Add oil
	7. Check cooling water level	-	Add water
	8. Check condition of dust indicator	-	Clean or replace
	9. Check hydraulic oil filter		Replace
Electrical equipments	1. Check for loose or corroded battery terminals	-	Tighten or replace
	2. Check for loose or corroded alternator terminals	-	Tighten or replace
	3. Check for loose or corroded straight motor terminals	-	Tighten or replace
Hydraulic, mechanical equipments	1. Check for abnormal noise or smell		Repaire
	2. Check for oil leakage	-	Repaire
	3. Bleed air from system	-	Bleed air
Electrical components	1. Check battery voltage (engine stopped)	20 - 30 V	Replace
	2. Check level of battery electrolyte	-	Add or replace
	3. Check for discolored, burnt, or bare wiring	-	Replace
	4. Check for missing wiring clamps, hanging wires	-	Repair
	5. Check for getting wet onto wiring (check carefully getting wet at connectors and terminals)	-	Disconnect connector and dry connection
	6. Check for broken or corroded fuses	-	Replace
	7. Check alternator voltage (engine running at over half throttle)	27.5 - 29.6 V	Replace
	8. Noise when battery relay is operated (switch starting switch from ON to OFF)	-	Replace

## CONNECTOR TYPES AND MOUNTING LOCATIONS

Connector No.	Type	No. of pins	Electrical component	Address
A01	KES1	2	Window washer circuit	
A03	KES1	2	LS select solenoid circuit	
A04	KES1	2	2-stages relief solenoid circuit	
A05	KES1	2	Swing brake solenoid circuit	
A06	KES1	2		
A07	KES1	2	Travel speed solenoid circuit	
A08	KES1	2	Heater circuit	
A09	KES1	2	Lower wiper circuit	
A11	KES1	2	Alarm buzzer circuit	
A13	KES1	2	Starter relay circuit	
A14	KES1	2	Battery relay drive circuit	
A16	KES1	2	Fuel shut off circuit	
A17	KES1	2	Starter circuit	
C01	MIC	13	Governor, pump controller	
C02	MIC	21	Governor, pump controller	
C03	040	20	Governor, pump controller	
C17	040	16	Governor, pump controller	
C05	S	10	TVC prolix switch	
C06	M	2	TVC prolix resistor	
C07	X	3		
C08	X	3	Front pump pressure sensor	
C09	S	8	Model selection connector	
C10	X	2	LS control EPC solenoid valve	
C13	X	2	Front pump TVC valve	
C16	MIC	17	Governor, pump controller	
E04	X	3	Governor potentiometer	
E05	X	4	Governor motor	
E06	M	3	Fuel control dial	
E07	X	2	Engine speed sensor	
E08	SWP	14	Intermediate connector	
E09		3	Fuel shut off valve	
F01	X	2	Travel alarm	

Connector No.	Type	No. of pins	Electrical component	Address
E11	RING	1	Heater relay	
H07	S	12	Intermediate connector	
H08	M	6	Intermediate connector	
H12	S	16	Intermediate connector	
H13	S	16	Intermediate connector	
H14	M	6	Intermediate connector	
H15	L	2	Intermediate connector	
E15	-	1	Safety relay	
K01	-	1	Aircon controller	
K02	-	1	Aircon pressure switch	
K03	-	1	Aircon pressure switch	
M02	X	2	Safety relay	
M06	M	4	Heater switch	
M08	KES1	2	Right front light	
M09	KES1	2	Working lamp (boom)	
M10	M	1	Intermediate connector	
M11	L	2	Fusible link	
M12	M	4	Heater	
M13	AMP	8	Speaker	
M14	L	2	Fusible link	
M16	-	1	Horn (high sound)	
M17	-	1	Horn (low sound)	
M18	M	4	Wiper, washer switch	
M20	-	-	Cigarette lighter	
M23	M	2	Horn switch, R.H. knob switch	
M26	AMP	11	Air conditioner	
M28	KES0	2	Window washer motor	
M34	Simple connector	1	Electromagnetic clutch for air conditioner compressor	
M35	X	4	Condenser for air conditioner	
M38	M	3	Light switch	
M21			Intermediate connector (Radio circuit)	

Connector No.	Type	No. of pins	Electrical component	Address
M40	KES1	2	Right working light	
M41	KES1	2	Left working light	
M42	KES1	2	Rear working light	
M43	X	2	Intermediate connector	
M45	M	3	Network bus	
M49	-	1	Refuel pump	
M58	KES1	2	Rear light	
M51	KES1	2	Left front lamp	
M52	X	2	Overload alarm switch	
M53		2	Heated seat	
M55	M	2	Beacon switch	
M56	M	2	Heated seat switch	
M57	-	1	Intermediate connector	
M61	-	1	Engine room lamp	
P01	040	20	Monitor panel	
P02	040	16	Monitor panel	
P03	M	2	Buzzer cancel switch	
P04	M	2	Alarm buzzer	
P05	X	1	Engine oil level sensor	
P06	X	1	Fuel level sensor	
P07	-	2	Coolant temperature sensor	
P08	X	2	Coolant level sensor	
P10		3	Engine oil pressure switch	
P11	-	1	Air cleaner, clogging sensor	
P12	-	1	Air cleaner clogging sensor	
R04	Shina-gawa	5	Light relay	
R05	Shina-gawa	5	Light relay	
R10	Shina-gawa	5	Light relay	
R11	Shina-gawa	5	Lower wiper relay	
S01	X	2	Travel oil pressure switch	
M71		1	Intermediate connector	

Connector No.	Type	No. of pins	Electrical component	Address
S02	X	2	Boom RAISE oil pressure switch	
S03	X	2	Arm OUT oil pressure switch	
S04	X	2	Boom LOWER oil pressure switch	
S05	X	2	Arm IN oil pressure switch	
S06	X	2	Bucket CURL oil pressure switch	
S07	X	2	Bucket DUMP oil pressure switch	
S08	X	2	Swing oil pressure switch	
S09	X	2	Att. pedal pressure switch	
S10		2	Att. pedal pressure switch	
S11		2	Att. pedal pressure switch	
V05	X	2	LS	
V06	X	2	Swing brake solenoid valve	
V25	X	2	2-stage relief solenoid valve	
V04	X	2	Travel speed solenoid valve	
W04	M	6	Wiper motor	
W08	070	18	Wiper motor controller	
W10	M	4	Rear limit switch	
W15	KESO	4	Lower wiper	
W16	M	2	Lower wiper switch	
X01	MIC	21	Intermediate connector	
X05	M	4	Swing lock switch	
X07	MIC	17	Intermediate connector	
E14		1	GRID HEATER	
E13		2	STARTER	
E12		3	ALTERNATOR	
E10		1	SHUT-OFF VALVE CIRCUIT GRD.	
E02		1	ADDITIONAL LAMP CIRCUIT GRD	
E03		1	ADDITIONAL LAMP CIRCUIT GRD	
E01		1	ADDITIONAL LAMP CIRCUIT GRD	

CONNECTOR TYPES AND MOUNTING LOCATIONS















Con- nector No.	Type	No. of pins	Electrical component	Add- ress
W03			Intermediate connector (rear limit switch)	
G26	X	3	(Clamshell rot/braeeker solenoid valve)	
G163		1	Window washer motor	
G30	M	4	Intermediate connector (knob switch)	
SW01			Swing redundancy switch	
SW03			Battery relay	
SW02			Starter switch	
M36	M	1	KEROSENE MODE SWITCH	
T02			GRD (Revo frame)	
T04			GRD (safety relay)	
T03			GRD (Revo frame)	
T05			GRD (Floor frame)	















# CONNECTION TABLE FOR CONNECTOR PIN NUMBERS







★ The terms male and female refer to the pins, while the terms male housing and female housing refer to the mating portion of the housing.

No. of pins	X type connector	
	Male (female housing)	Female (male housing)
1	 <p>205F05309</p>	 <p>205F05310</p>
2	  <p>205F05311</p>	  <p>205F05312</p>
3	  <p>205F05313</p>	  <p>205F05314</p>
4	  <p>205F05315</p>	  <p>205F05316</p>













No. of pins	M type connector	
	Male (female housing)	Female (male housing)
1	 <p>205F05317</p>	 <p>205F05318</p>
2	 <p>205F05319</p>	 <p>205F05320</p>
3	 <p>205F05321</p>	 <p>205F05322</p>
4	 <p>205F05323</p>	 <p>205F05324</p>

No. of pins	M type connector	
	Male (female housing)	Female (male housing)
6	 <p style="text-align: center;">205F05325</p>	 <p style="text-align: center;">205F05326</p>





No. of pins	S type connector	
	Male (female housing)	Female (male housing)
8	 <p>205F05327</p>	 <p>205F05328</p>
10	 <p>205F05329</p>	 <p>205F05330</p>
16	 <p>205F05333</p>	 <p>205F05334</p>

No. of pins	AMP040 type connector	
	Male (female housing)	Female (male housing)
16	<p>205F05335</p>	<p>205F05336</p>
20	<p>205F05337</p>	<p>205F05338</p>



No. of pins	AMP070 type connector	
	Male (female housing)	Female (male housing)
14	  <p>205F06364</p>	  <p>205F06365</p>
18	  <p>205F06366</p>	  <p>205F06367</p>



No. of pins	AMP250 type connector	
	Male (female housing)	Female (male housing)
3	 <p>205F06368</p>	 <p>205F06369</p>


No. of pins	SWP type connector	
	Male (female housing)	Female (male housing)
14	<p>F56103087</p>	<p>F56103088</p>



No. of pins	MIC connector	
	Male (female housing)	Female (male housing)
17	 <p style="text-align: right;">142F414</p>	 <p style="text-align: right;">142F415</p>
21	 <p style="text-align: right;">142F416</p>	 <p style="text-align: right;">142F417</p>







No. of pins	Relay connector	
	Male (female housing)	Female (male housing)
5		







No. of pins	Simple connector	
	Male (male housing)	Female (female housing)
1	 <p style="text-align: center;">195F05128</p>	 <p style="text-align: center;">195F05129</p>

No. of pins	Ring connector
1	

No. of pins	L type connector	
	Male (female housing)	Female (male housing)
2	 <p>20TF01149</p>	 <p>20TF01150</p>

No. of pins	PA type connector	
	Male (female housing)	Female (male housing)
9	 <p>205F06370</p>	 <p>205F06371</p>


No. of pins	Automobile connector (KESO)	
	Male (female housing)	Female (male housing)
2	 <p style="text-align: center;">205F06372</p>	 <p style="text-align: center;">205F06373</p>

No. of pins	Automobile conector (KES1)	
	Female (male housing)	Male (female housing)
2	 <p>423F349</p>	 <p>423F350</p>
3	 <p>423F351</p>	 <p>423F352</p>
4	 <p>423F353</p>	 <p>423F354</p>

# EXPLANATION OF CONTROL MECHANISM FOR ELECTRICAL SYSTEM

## 1. Explanation of machine control functions

The control mechanism for the electrical system consists of the monitor panel and governor and pump controller. The monitor panel and the governor and pump controller input the signals that are necessary, and together with the signals selected by the monitor panel, the governor and pump controller outputs or inputs the necessary signals and control the pump absorption torque and engine output.



## DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

### 1. Display on machine monitor

When the starting switch is turned on, all the monitor and gauge lamps light up for approx. 3 seconds, and the buzzer sounds for approx. 1 second. During this time, the monitor itself carries out self diagnosis, and after it has finished, it returns to the normal display.

### 2. Recording of service codes and user code display function

- 1) All the abnormality data for the governor and pump controller is sent to the monitor panel.

When the monitor panel receives this data, it records the abnormality data, and at the same time, depending on the nature of the abnormality, it displays the user code on the time display panel to advise the operator of the action to take.

However, in cases of abnormalities which are not urgent and do not require the user code to be displayed, only the content of the abnormality is recorded, and no display is given.

- 2) Types of user code and system

E02 (TVC system)

E03 (Swing holding brake system)


E05 (Governor motor system)

- ★ For details of the service codes included in the user code, see the action taken by the controller when an abnormality occurs, the symptoms on the machine or the judgement table.


- 3) Displaying user code

If it becomes necessary to display the user code, the time displayed panel is automatically switched to advise the operator to take the necessary action.

- Actual display (Example: Disconnection in the cancel solenoid system for the swing holding brake)




- 4) Display of trouble data  
The monitor panel records both service codes which are included in the user code, and service codes which are not included. This data can be displayed on the time display as follows.
- ★ For details of the service codes that are not included in the user code, see ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE or the JUDGEMENT TABLE




i) Method of displaying trouble data

Operation	Display
<p>1. To set to the trouble data display mode, Keep the TIME switch + L.H. travel speed switch pressed for 2.5 seconds. Note: It is possible to call it up at the following times.</p> <ol style="list-style-type: none"> <li>1) In the normal mode</li> <li>2) In the user code display mode</li> <li>3) In the machine data monitoring mode</li> <li>4) In the time adjustment mode</li> </ol> <p>2. To go to the next service code display, press the time switch + R.H. working mode switch.</p> <p>3. To go back to the previous service code display, press the time switch + L.H. working mode switch.</p>	<p>1. On the time display and service meter display, the service code and number of hours (service meter hours) that have elapsed since the occurrence of the abnormality are displayed.</p> <ul style="list-style-type: none"> <li>• Example of display : When E212 has occurred 12 hours before (service meter)</li> </ul> <p>1) Display of service code    2) Display of elapsed time</p> <p>3) If any abnormality exists at this time, the E mark is displayed.</p> <p>If there is an abnormality, or the controller is carrying out self diagnosis, the output is shut off, and E is displayed.</p> <p style="text-align: right;">BKP00079 BKP00080</p>

Operation	Display
<p>4. To finish with the trouble data display mode, keep the TIME switch + L.H. travel speed switch pressed for 2.5 seconds.</p> <p>5. To erase the memory, keep the time switch pressed, turn the starting switch from OFF to ON, and keep the time switch pressed for 5 seconds.</p>	<p>4) If there is no abnormality code in memory</p>  <p style="text-align: right;">BKP00081</p>


**3. Machine data monitoring function**

The input signals from the sensors and the output signals to drive the solenoid are displayed on the time display and service meter display.




TAP00176

1) Method of displaying monitoring code

Operation	Display
<p>1. To set the machine data monitoring mode, do as follows. Keep the time switch + knob button function switch pressed for 2.5 seconds. Note: This is possible at the following times.</p> <ol style="list-style-type: none"> <li>1) During the normal code</li> <li>2) During the user code display</li> <li>3) During the time adjustment mode</li> <li>4) During the trouble data display mode</li> </ol>	<p>1. On the time display and service meter display, the monitoring code and data are displayed.</p> <ul style="list-style-type: none"> <li>• Example of display</li> <li>1) When engine speed is monitoring (monitoring code 10)</li> </ul>  <p style="text-align: center;">(example of 1950 rpm)</p> <p style="text-align: right;">BKP00083</p>



Operation	Display
2. To go to the next monitoring code display, press the time switch + R.H. working mode switch. 3. To go back to the previous monitoring code display, press the time switch + L.H. working mode switch. 4. To finish with the machine data monitoring code mode, keep the time switch + knob button function switch pressed for 2.5 seconds.	2) When displaying bit pattern <ul style="list-style-type: none"> <li>For monitoring codes 08, 20 - 24, 36, 37, 47 - 49, 4A, display the bit pattern.</li> <li>Example of monitoring code 20</li> </ul>  <ul style="list-style-type: none"> <li>The code No. is displayed in the monitoring code portion, and the display lights up to display bit patterns (1) - (6).</li> </ul>

2) Table of machine data monitoring codes

★ For details of the B in the Unit column, see the bit pattern chart in the next section.


No.	Item	Unit	Name of component
01	Monitor model code	-	Monitor panel
02	Governor, pump controller model code	-	Governor, pump controller
03	Governor, pump controller model code	-	Governor, pump controller
08	S-NET component condition display	B	Governor, pump controller
10	Engine speed	10rpm	Governor, pump controller
11	Pump discharge pressure input	MPa (kg/cm <sup>2</sup> )	Governor, pump controller
13	TVC current output	10mA	Governor, pump controller
15	LS-EPC current output	10mA	Governor, pump controller
16	No. 2 throttle command	10mA	Governor, pump controller
20	Governor, pump controller PPC oil pressure switch input signal (1)	B	Governor, pump controller
21	Governor, pump controller PPC oil pressure switch input signal (2)	B	Governor, pump controller
22	Governor, pump controller PPC oil pressure switch input signal (3)	B	Governor, pump controller
23	Governor, pump controller solenoid actuation	B	Governor, pump controller
24	Input condition of sensor for governor, pump controller monitor warning 1	B	Governor, pump controller
30	Fuel control dial input value	10mV	Governor, pump controller
31	Potentiometer voltage	10mV	Governor, pump controller
32	VBB voltage (battery voltage)	100mV	
25	Input condition of sensor for governor, pump controller monitor warning 2	B	Governor, pump controller

★ For details of the B in the Unit column, see the bit pattern chart in the next section

No.	Item	Unit	Name of component
33	Governor motor A phase current	10mV	Governor, pump controller
34	Governor motor B phase current	10mV	Governor, pump controller
35	Battery relay output voltage	100MV	Governor, pump controller
36	Governor governor input condition	B	Governor, pump cotnroller
37	Governor governor output condition	B	Governor, pump controller
40	Engine speed	10rpm	Governor, pump controller
41	Coolant temperature sensor voltage	10mV	Governor, pump controller
42	Fuel sensor input voltage	10mV	Governor, pump controller
43	Battery charge input voltage	100mV	Governor, pump controller
47	Monitor panel output condition 1	B	Governor, pump controller
48	Monitor panel input condition 1	B	Governor, pump controller
49	Monitor panel input condition 2	B	Governor, pump controller
4A	Monitor panel input condition 3	B	Governor, pump controller
4C	Monitor panel output condition 2	B	Governor, pump controller

3) Bit pattern chart

As shown in the diagram below, the time display has bit numbers light up to show that the signal is being transmitted. (For details, see METHOD OF DISPLAYING MONITORING CODE.)



BKP00085

Code	Content	Bit	Details (condition when lighted up)
08	Connection of S-NET components	(1) (2) (3) (4) (5) (6)	Governor, pump controller connected (ID=2) Governor, pump controller connected (ID=3)
20	Input condition of governor, pump controller PPC switches	(1) (2) (3) (4) (5) (6)	Swing switch ON Travel switch ON Boom LOWER switch ON Boom RAISE switch ON Arm IN switch ON Arm OUT switch ON
21	Input condition of governor, pump controller PPC switches and other switches	(1) (2) (3) (4) (5) (6)	Bucket CURL switch ON Bucket DUMP switch ON Swing lock switch ON Service switch ON Model selection 5 Swing prolix switch ON
22	Input condition of governor, pump controller model selection and other switches Drive condition of governor,	(1) (2) (3) (4) (5) (6)	Model selection 1 GND connected Model selection 2 GND connected Model selection 3 GNC connected Model selection 4 GND connected Kerosene mode input GND connected Knob switch ON
25	Input condition 2 of sensor for governor, pump controller monitor warning	(1) (2) (3) (4) (5) (6)	Overload sensor Open

Code	Content	Bit	Details (condition when lighted up)
23	Pump controller ON/OFF solenoid valves	(1) (2) (3) (4) (5) (6)	LS bypass solenoid Swing holding brake ON 2 stage relief solenoid ON Travel speed selector solenoid ON
24	Input condition 1 of sensor for governor, pump controller monitor warning	(1) (2) (3) (4) (5) (6)	Above engine oil pressure sensor Lo set pressure Above engine oil pressure sensor Hi set pressure Radiator water level sensor abnormal Engine oil level sensor abnormal Hydraulic oil level sensor abnormal Air cleaner clogging sensor abnormal
36	Input condition of governor, pump controller	(1) (2) (3) (4) (5) (6)	Starting switch ON
37	Output condition of governor, pump controller	(1) (2) (3) (4) (5) (6)	Battery relay: Actuated
47	Monitor panel output condition 1	(1) (2) (3) (4) (5) (6)	Alarm buzzer: when operated machine
49	Monitor panel input condition 2	(1) (2) (3) (4) (5) (6)	KEY ON SW            OFF Terminal BR        Voltage Hi LIGHT SW            OFF Preheating switch   OFF START C              Sometimes turns ON
48	Monitor panel input condition 1	(1) (2) (3) (4) (5) (6)	Wiper (ON)            OFF Wiper (INT)          OFF Wiper (WASHER)    OFF Window LIMIT SW    OPEN LIMIT SW (W)        OPEN LIMIT SW (B)        OPEN

Code	Content	Bit	Details (condition when lighted up)
4A	Monitor panel INPUT condition 3	(1)	Time switch OFF
		(2)	PPC oil pressure selector switch OFF
		(3)	Overload selector switch OFF
		(4)	STD/DLX selection STD
		(5)	Swing lock switch OFF
		(6)	Buzzer cancel switch OFF
4C	Monitor panel output conditon 2	(1)	
		(2)	Wiper motor normal rotation relay output At abnormal current
		(3)	Wiper motor reverse rotating relay output At abnormal current
		(4)	Window washer motor drive output At abnormal current
		(5)	
		(6)	

**4. Governor motor adjustment mode**

This is used when adjusting the linkage between the governor motor and the injection pump. (For details of the procedure, see TESTING AND ADJUSTING.)

Operation	Display
1. To set the governor motor adjustment mode, press the time switch + R.H. travel speed switch + R.H. working mode switch.	<p>1.</p> <p style="text-align: right;">BKP00086</p>
2. To return to the time display mode use the same procedure as in Step 1.	2. Buzzer sounds once a second

**5. Time adjustment mode**

To adjust the time, do as follows.

Operation	Display
1. To set the time adjustment mode, keep the time switch depressed for 2.5 seconds.	<p>1. The time mark portion flashes</p> <p style="text-align: right;">BKP00087</p>
2. Use the L.H. working mode switch to advance the hour.	
3. Use the R.H. working mode switch to advance the minute.	
4. To return to the time display mode use the same procedure as in Step 1.	

★ The example shows the situation when setting to 12:34.

# METHOD OF USING JUDGEMENT TABLE

This judgement table is a tool to determine if the problem with the machine is caused by an abnormality in the electrical system or by an abnormality in the hydraulic or mechanical system. The symptoms are then used to decide which troubleshooting table (E-00, S-00, C-00, F-00, H-00, M-00) matches the symptoms. The judgement table is designed so that it is easy to determine from the user code and service code which troubleshooting table to go to.

★ The abnormality display (warning) given by the monitor panel leads directly to troubleshooting of the machine monitor (M-00). (See troubleshooting of the machine monitor system)

## 1. When using judgement table for governor, pump controller (governor control system) and engine related parts

- If a service code is displayed on the monitor panel, go to the troubleshooting code at the bottom of the judgement table (E-00).  
(A ● Mark is put at the places where the failure mode and service code match.)
- If a problem has appeared but no service code is displayed on the monitor panel, go to the point where the failure mode matches the troubleshooting code on the right of the judgement table (E- or S-).

<Example> Failure mode "Engine does not start".

Procedure: Check if the service code is being displayed on the monitor panel.

Failure mode	User code				Service code			
	605	308	317	318	306	315	316	
1 Engine does not start easily								
2 Engine does not start								
3 Engine speed stays at low idling, and does not follow accelerator, or engine pickup is poor	●	●	●	●				
4 Engine stops during operation								
5 Engine rotation is irregular								
When idling speed is irregular								
When there is hunting	●	●	●	●				
6 Lack of output (engine high idling speed is too low)								
7 Auto-deceleration does not work								
8 Engine does not stop	●	●	●	●				
9 Warming-up operation is defective								
10 Exhaust gas is black								
11 Oil consumption is excessive, or exhaust gas is blue								
12 Oil becomes dirty prematurely								
13 Fuel consumption is excessive, or exhaust gas is blue								
14 Oil is mixed in coolant								
15 Engine oil pressure caution lamp lights up								
16 Oil level rises								
17 Coolant temperature rises too high (overheating)								
18 Abnormal noise is generated								
19 There is excessive vibration								
20 Engine speed does not change even when working mode is switched								
Troubleshooting code when service code is displayed	E-1	E-2	E-3	E-4	E-5	E-6	E-7	
Troubleshooting code when there is abnormality in monitoring or machine monitor check								

● : This shows applicable item for service code  
★ : This shows item that needs only checking with monitoring

Checking monitoring check items		Machine monitor check item	Troubleshooting code if no service code display is given
Monitoring code		Does starting motor turn?	
Battery relay drive signal	35		S-1
No. 2 throttle command value	16		S-2
Fuel control dial command value	30		S-3
Governor motor potentiometer	31		S-4
Governor motor A phase current	33		E-9A), S-5
Governor motor B phase current	34		E-9A), S-5
Coolant temperature voltage	41		E-10, S-6
100% or above			E-3, E-4
105% or above			E-11
Is the range displayed?			E-3, E-4
Does starting motor turn?			S-7
			S-8
			S-9
			S-10
			S-11
			S-12
			S-13
			S-14
			S-15
			S-16
			E-3, E-4

○ : This shows item to check with monitoring or machine monitor

### [Judgement]

- 1) If a service code is being displayed on the monitor panel...go to troubleshooting [E3:00] for the governor, pump controller (governor control system).
- 2) If no service code is displayed on the monitor panel, and the engine does not start:

- Check that starting motor rotates
  - Starting motor rotates ..... Go to troubleshooting S-2 of mechanical system
  - Starting motor does not rotate ..... Go to troubleshooting E-8 of electrical system

2. When using judgement table for governor, pump controller (governor control system) and hydraulic related parts
  - If a service code is displayed on the monitor panel, go to the troubleshooting code at the bottom of the judgement table (C-○○).  
(A ● mark is put at the places where the failure mode and service code match.)
  - If a problem has appeared but no service code is displayed on the monitor panel, go to the point where the failure mode matches the input signal, and check the display for the input signal (the display at the place with a ○ mark)
    - If it is displayed normally, go to the troubleshooting code on the right of the judgement table (H-○○).
    - If the input signal is not displayed on the monitor panel, go to the troubleshooting code at the bottom of the judgement table (F-○○).

<Example> Failure mode "Upper structure does not swing".

Failure mode	Governor, pump controller (E2-XX system)	
	User code	Self-diagnostic display
	Service code	
All work equipment travel, swing	Speeds of all work equipment, swing, travel are slow or lack power	20
	There is excessive drop in engine speed, or engine stalls	21
	No work equipment, travel, swing move	22
	Abnormal noise generated (around pump)	23
	Auto-deceleration does not work	24
	Fine control ability is poor or response is poor	25
	Boom is slow or lacks power	26
	Arm is slow or lacks power	27
	Bucket is slow or lacks power	28
	Boom does not move	29
Work equipment	Arm does not move	30
	Bucket does not move	31
	Excessive hydraulic drift	32
	Excessive time lag (engine at low idling)	33
	Other equipment moves when single circuit is relieved	34
	In LJO, FTO modes, work equipment speed is faster than specified speed	35
	Lack of power when pressure rises	36
	In compound operations, work equipment with larger load is slow	37
	In swing + boom (RAISE), boom is slow	38
	In work equipment (boom raise) + travel travel speed drops excessively	39
Compound operations	In swing + travel, travel speed drops excessively	40
	Travel deviation	41
	Deviation is excessive during normal travel	42
	Deviation is excessive when starting	43
	Travel speed is slow	44
	Steering does not turn or lacks power	45
	Travel speed does not switch or is faster than specified speed	46
	Does not move (one side only)	47
	Does not swing	48
	Both left and right	49
Travel system	One direction only	50
	Swing acceleration is poor or swing speed is slow	51
	Both left and right	52
	One direction only	53
	Excessive overrun when stopping swing	54
	Both left and right	55
	One direction only	56
	Excessive shock when stopping swing (one direction only)	57
	Excessive abnormal noise when stopping swing	58
	Excessive hydraulic drift	59
When holding brake is released	60	
When holding brake is applied	61	
Swing speed is faster than specified swing speed	62	
Troubleshooting code when service code is displayed	63	
Troubleshooting code when there is abnormality in monitoring check	64	

Check items in monitoring mode															
Self-diagnostic display															
Pressure switch															
Adjuster if selected															
Non turning code															
20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	H+1
															H+2
															H+3
															H+4
															H+5
															H+6
															H+7
															H+8
															H+9
															H+10
															H+11
															H+12
															H+13
															H+14
															H+15 C-21
															H+16
															H+17
															H+18
															H+19
															H+20
															H+21
															H+22
															H+23
															H+24
															H+25
															H+26
															H+27
															H+28
															H+29
															H+30
															H+31

Procedure: check if the service code is being displayed on the monitor panel.

[Judgement]

- 1) If a service code is being displayed on the monitor panel...go to troubleshooting [E2: ] for the governor, pump controller (pump controller system).
- 2) If no service code is displayed on the monitor panel, and the upper structure does not swing:

- Check governor, pump controller input signal (Check in monitoring mode)

There is a signal ..... Go to troubleshooting H-25 of mechanical system

There is no signal ..... Go to troubleshooting F-○○ of governor, pump controller input signal system (F mode for applicable system)

## METHOD OF USING TROUBLESHOOTING CHARTS

### 1. Category of troubleshooting code number

Troubleshooting Code No.	Component	Service code
N-○○	Troubleshooting of communication abnormality system	E218 group
E-○○	Troubleshooting of electrical system for governor, pump controller (governor control system)	E3-○○ group
S-○○	Troubleshooting of engine related parts	-
C-○○	Troubleshooting of electrical system for governor, pump controller (pump control system)	E2-○○ group
F-○○	Troubleshooting of governor, pump controller (input signal system)	-
H-○○	Troubleshooting of hydraulic, mechanical system	-
M-○○	Troubleshooting of machine monitor	E1-○○ group

### 2. Method of using troubleshooting table for each troubleshooting mode

#### 1) Troubleshooting code number and problem

The title of the troubleshooting chart gives the troubleshooting code, service code, and failure mode (problem with the machine). (See Example (1))

#### 2) Distinguishing conditions

Even with the same failure mode (problem), the method of troubleshooting may differ according to the model, component, or problem. In such cases, the failure mode (problem) is further divided into sections marked with small letters (for example, a), so go to the appropriate section to carry out troubleshooting. (See Example (2)) If the troubleshooting table is not divided into sections, start troubleshooting from the first check item in the failure mode.

#### 3) Method of following troubleshooting chart

- Check or measure the item inside 

YES
NO

 and according to the answer follow either the YES line or the NO line to go to the next 

--

. (Note: The number written at the top right corner of the 

--

 is an index number; it does not indicate the order to follow.)
- Following the Yes or NO lines according to the results of the check or measurement will lead finally to the Cause column. Check the cause and take the action given in the Remedy column on the right. (See Example (3))
- Below the 

--

 there are the methods for inspection or measurement, and the judgement values. If the judgement values below the 

--

 are correct or the answer to the question inside the 

--

 is YES, follow the YES line; if the judgement value is not correct, or the answer to the question is NO, follow the NO line.
- Below the 

--

 is given the preparatory work needed for inspection and measurement, and the judgement values. If this preparatory work is neglected, or the method of operation or handling is mistaken, there is danger that it may cause mistaken judgement, or the equipment may be damaged. Therefore, before starting inspection or measurement, always read the instructions carefully, and start the work in order from Item 1).

#### 4) General precautions

When carrying out troubleshooting for the failure mode (problem), precautions that apply to all items are given at the top of the page and marked with ★ (See Example (4)).

The precautions marked ★ are not given in the 

--

, but must always be followed when carrying out the check inside the 

--

.

#### 5) Troubleshooting tools

When carrying out the troubleshooting, prepare the necessary troubleshooting tools. for details, see TOOLS FOR TESTING, ADJUSTING, AND TROUBLESHOOTING.





6) Installation position, pin number

A diagram or chart is given for the connector type, installation position, and connector pin number connection. When carrying out troubleshooting, see this chart for details of the connector pin number and location for inspection and measurement of the wiring connector number appearing in the troubleshooting flow chart for each failure mode (problem).


<Example>

(1) M-9 When starting switch is turned ON (engine stopped), check item for previous troubleshooting flashes

- (4) ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Check that the coolant is at the specifies level before carrying out troubleshooting

- (2) a)  (coolant level) flashes  
SAP00519 Divided into sections a) and b)
- b)  (engine oil level) flashes  
SAP00523

(3)



Table

Short connector	Continuity
Connected	Yes
Disconnected	No


# DETAILS OF TROUBLESHOOTING AND TROUBLESHOOTING PROCEDURE

If any abnormality should occur, it is necessary to go to the correct troubleshooting chart in accordance with the judgement table for that type of failure (governor, pump controller (governor control system) and governor, pump controller (pump control system)). For details of the troubleshooting and troubleshooting procedure, refer to this flow chart.

When carrying out troubleshooting, ask the operator as much as possible about the condition of the machine, and check the following items before starting.

- (1) Condition of controller connection (check with monitoring codes 02 - 03 )
- (2) Blown fuses
- (3) Battery voltage (monitoring mode 32)
- (4) Electricity generation (charge input) voltage (monitoring code 43)

The procedure for carrying out check items No. 3 and 4 in the flow chart below is given on the following pages.



★ For details, see governor, pump controller (governor control system) (pump control system) in the JUDGEMENT TABLE.

If there is no abnormality display in the communications system transmitted in S-NET, it can be taken that the output signal from the monitor panel has been transmitted. However, even if there is no abnormality display, if the operation is defective, use the following procedure when checking directly. If any abnormality occurs in the S-NET system, the system is automatically switched to the following default mode, so be careful when carrying out troubleshooting.

Default Mode when communications cannot be carried out for the monitor and governor, pump controller

Set mode	Pump Control	Governor control
1 Working mode	G/O mode	H/O mode
2 Throttle signal	FULL	FULL
3 Auto-deceleration	ON (deceleration mode)	ON (deceleration mode)
4 Coolant temperature signal	OFF	-
5 Priority mode	OFF	-
6 Power max. mode	ON (power max. possible)	-
7 Travel speed	Lo	-
8 Automatic warming up	-	ON (automatic warming-up mode)

### 1. Procedure for checking monitor panel output signal

- ★ For details of operating the monitoring mode, see MONITOR PANEL DISPLAY AND SPECIAL FUNCTIONS.
- 1. Connection condition of components
  - 1) Set to the monitoring mode and display monitoring code 08.
  - 2) The time display (bits) will light up to display the components that are connected.
    - ★ Governor, pump controller (pump control system) (1) and governor, pump controller (governor control system) (2) will light up.
- 2. Checking working mode signal (check No. 2 throttle signal monitoring code 16) at the same time
  - 1) Set to the monitoring mode and display monitoring code 10.
  - 2) Switch the working mode as shown in Table 1 and check that the engine speed changes.

Table 1

Working mode	High idling speed (rpm) [The figures in ( ) are the rated speed]
H/O	Approx. 2450 (2100)
G/O	Approx. 2030 (1910* 1)
L/O	Approx. 1890 (1780)

\* 1 Swing Lock ON

3. Checking travel speed selection signal
  - 1) Set to the monitoring mode and display monitoring code 23.
  - 2) Change the speed selector switch to Hi or Mi and run the engine at 1500 rpm or above.  
Check that bit (6) lights up when traveling at Hi or Mi (front or rear pump oil pressure: 21.6 - 32.3 MPa (220 - 330 kg/cm<sup>2</sup>))
2. **Checking input signal of governor, pump controller**
  - ★ Check the input signals for each controller as follows.
  - Pump control system
  1. Checking input signal
    - 1) Check hydraulic switch
      - i) Set to the monitoring mode, and display monitoring code 20 and 21.
      - ii) Operate each work equipment lever, and check how the bit pattern lights up.
        - ★ For details of the bit pattern chart, see MONITOR PANEL DISPLAY AND SPECIAL FUNCTIONS.
    - 2) Check speed sensor (check engine speed)
      - i) Set to the monitoring mode, and display monitoring code 10.
      - ii) Use the fuel control dial to change the speed, and measure the speed when this is done.
    - 3) Check pump discharge pressure sensor
      - i) Set to the monitoring mode, and display monitoring codes 11.

- 4) Check kerosene mode input signal
    - i) Set to the monitoring mode, and display monitoring code 22.
    - ii) Connect the CN-M36 connector and check that bit (5) lights up.
  - 5) Check knob switch input signal.
    - i) Set to the monitoring mode, and display monitoring code 22.
    - ii) Turn the knob switch ON and check that bit (6) lights up.
2. Check output signals
- i) Check LS-EPC solenoid output current
  - ii) Run the engine at high idling with all the levers at neutral and in the G/O or H/O mode, and measure the current.
    - ★ All levers at neutral:  $900 \pm 80$  mA
    - Engine at high idling, any lever operated (other than travel): 0 A
- 2) No. 2 throttle signal
    - i) Set to the monitoring mode, and display monitoring code 16.
    - ii) Use the procedure in Item 2 for checking the monitor panel output signal, and measure the engine speed.
  - 3) Checking ON  $\longleftrightarrow$  OFF solenoid condition
    - i) Set to the monitoring mode, and display monitoring code 23.
    - ii) Refer to Table 3 and check that the applicabel bit light up.

Table 3 Types of solenoid and conditions for actuation

Name of solenoid	Actuation condition	Bit that lights up
LS bypass	Swing lock switch OFF, swing + travel lever operated simultaneously	(1)
Swing holding brake	Swing or work equipment lever operated	(3)
2-stage relief ON release	Travel operated independently	(5)
Travel speed selector	Travel speed selector switch Hi or Mi	(6)

★ Operate the lever slightly not enough to move the machine.

- 4) Check TVC solenoid output current
  - i) Set to the monitoring mode, and display monitoring codes 13
  - ii) With the starting switch kept at the ON position (G/O mode), measure the current when the fuel control dial is turned to the MAX position.
    - Current with starting switch ON (G/O mode) and fuel control dial at MAX  $410 \pm 80$  (mA)

- **Governor control system**

1. Check input signal
  - 1) Check fuel control dial input voltage
    - i) Set to the monitoring mode, and display monitoring code 30.
    - ii) Measure the voltage when the fuel control dial is turned from low idling to high idling.
      - ★ Voltage: 0.25 - 4.75 V
  - 2) Check governor potentiometer voltage
    - i) Set to the monitoring mode, and display monitoring code 31.
    - ii) Measure the potentiometer voltage when the fuel control dial is turned from low idling to high idling.
      - ★ Voltage: 0.5 - 3.3 V
2. Check output signal
  - 1) Check governor motor drive current
    - i) Set to the monitoring mode, and display monitoring codes 33 and 34.
      - ★ Code 33 is the A phase (engine speed acceleration direction) and code 34 is the B phase (engine speed deceleration direction)
    - ii) Measure the governor motor drive current when the fuel control dial is turned in the acceleration direction and deceleration direction.
      - ★ Current:  $700 \pm 70$  (mA)
  - 2) Measure battery relay drive output voltage
    - i) Set to the monitoring mode, and display monitoring code 35.
    - ii) Measure the battery relay drive output voltage when the starting switch is turned from ON to OFF.
      - or
    - iii) Set to the monitoring mode, and display monitoring code 37.
    - iv) Check that bit (1) lights up when the starting switch is turned from ON to OFF.

SERVICE CODE TABLE

Service code	Abnormal system	User code
E101	Abnormality in error history data	
E102	Abnormality in time data	
E103	Short circuit in buzzer output, contact with 24 V wiring harness for buzzer drive	
E104	Air cleaner clogging detected	
E106	Abnormality in engine oil pressure sensor (Hi) detected	
E108	Water temperature over 105°C	
E201	Short circuit in LS bypass solenoid system	
E203	Short circuit in swing holding brake solenoid system	E03
E206	Short circuit in 2-stage relief solenoid system	
E206	Short circuit in travel speed solenoid system	
E211	Disconnection in LS bypass solenoid system	
E213	Disconnection in swing holding brake solenoid system	
E215	Disconnection in 2-stage relief solenoid system	E03
E216	Disconnection in travel speed solenoid system	
E217	Error in model selection input	
E218	Network response overtime error	
E222	Short circuit in LS-EPC solenoid system	
E223	Disconnect in LS-EPC solenoid system	
E224	Abnormality in pump pressure sensor system	
E226	Abnormality in pressure sensor system power source	
E227	Abnormality in engine speed sensor	
E232	Short circuit in pump TVC solenoid system	E02
E233	Disconnection in pump TVC solenoid system	E02
E306	Abnormality in feedback potentiometer system	
E308	Abnormality in fuel control dial input value	E05
E315	Short circuit in battery relay output system	
E316	Step-out in governor motor	
E317	Disconnection in governor motor system	E05
E318	Short circuit in governor motor system	E05

Service code	Abnormal system	User code
E112	Short circuit in relay drive R	
E113	Short circuit in relay drive L	
E114	Short circuit in window washer drive	

# **TROUBLESHOOTING OF COMMUNICATION ABNORMALITY SYSTEM (N MODE)**

N-1 [E218] Communication abnormality ..... 20-104



**N-1 [E218] Communication abnormality**

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ If the starting switch was turned off after the abnormality occurred, turn the starting switch on and check that the service code displays E. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




Table 1

Monitoring code		Display
01	Monitor panel model code	150
02	Governor, pump controller model code	150
03	Governor, pump controller model code	150

- When each controller is connected to the network, "-" is displayed. If the correct alphanumeric are not displayed (another model is displayed), each controller shows model selection abnormal.

Table 2


Monitoring code		Display
08	Network connection condition	

BKP00093

- Light up when connected
  - (1) Governor, pump controller
  - (2) Governor, pump controller

- Note: Checks can be carried out with code 08 only when there is a disconnection. The display does not change when there is a short circuit. Therefore, checks when there is a short circuit should be carried out basically using Table 1

## N-1 Related electric circuit diagram



BKP00092

# TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER (GOVERNOR CONTROL SYSTEM) (E MODE)

Points to remember when carrying out troubleshooting of governor, pump controller system .....	20-107
Action taken by controller and condition of machine when abnormality occurs .....	20-108
Judgement table for governor, pump controller (governor control system) and engine related parts .....	20-112
Electrical circuit diagram of governor, pump controller (governor control system) .....	20-114
E- 1 Abnormality in governor, pump controller power source (controller LED is OFF) .....	20-116
E- 2 [E308] Abnormality in fuel control dial input value is displayed .....	20-117
E- 3 [E317] Abnormality (disconnection) in governor motor drive system is displayed .....	20-118
E- 4 [E318] Abnormality (short circuit) in governor motor drive system is displayed .....	20-119
E- 5 [E306] abnormality in feedback potentiometer system is displayed .....	20-120
E- 6 [E315] Abnormality (short circuit) in battery relay output system is displayed .....	20-121
E- 7 [E316] Abnormality (step-out) in motor is displayed .....	20-122
E-8 Engine does not start .....	20-124
E-9 Engine speed is irregular .....	20-126
a) Idling speed is irregular .....	20-126
b) There is hunting .....	20-128
E- 10 Lack of output (engine high idling speed is too low) .....	20-130
E-11 Engine does not stop .....	20-132
E-12 Defective operation of battery relay system (engine does not stop) .....	20-134

## POINTS TO REMEMBER WHEN CARRYING OUT TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER SYSTEM


### 1. Points to remember when there is abnormality which is not displayed by user code

The engine is controlled by the governor and pump controller.

The problems that may occur with this system include the following.

1. Idling speed is too high (too low)
2. High idling speed is too low
3. Auto-deceleration speed is too high (too low)
4. Engine speed for automatic warming-up operation is too high (too low)
5. There is hunting
6. Engine does not stop

If any abnormality occurs, and the abnormality is displayed on the time display portion of the monitor panel, use the troubleshooting table to determine the appropriate troubleshooting flow chart form E-1 to E-12. However, if there is any abnormality in the machine and no abnormality display is given, it is necessary to determine whether the problem is in the mechanical system or in the electrical system. If the linkage between the governor motor and the injection pump is not properly adjusted, problems 1 to 6 listed above may occur. Therefore, if there is no abnormality display, but one of problems 1 to 6 above has occurred, carry out troubleshooting as follows.



Disconnect the linkage as explained above, or check the adjustment and go to the troubleshooting flow chart for the mechanical system or electrical system.

For details of the procedure for adjusting the linkage, see TESTING AND ADJUSTING.

### 2. Points to remember if abnormality returns to normal by itself

In the following two cases, there is a high probability that the same problem will occur again, so it is desirable to follow up this problem carefully.

- 1) If any abnormality returns to normal by itself, or
- 2) If the connector is disconnected and the T-adaptor is inserted, or if the T-adaptor is removed and the connector is returned to its original position when carrying out troubleshooting of the failure, and the service code is no longer displayed, or if the monitor display returns to normal.
- 3) After completing troubleshooting, always erase the service code from memory.

### 3. User code memory retention function

When displaying the abnormality code in memory and carrying out troubleshooting, note down the content of the display, then erase the display. After trying to re-enact the problem, carry out troubleshooting according to the failure code that is displayed.

(There are cases where mistaken operation or abnormalities that occur when the connector is disconnected are recorded by the memory retention function. Erasing the data in this way saves any wasted work.)

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY  
OCCURS AND PROBLEMS ON MACHINE

User code	Service code	Abnormal system	Nature of abnormality
E05	E308	Abnormality in fuel control dial input valve	<ol style="list-style-type: none"> <li>1. Short circuit in wiring harness between C03 (7) - (14), (7) - (17), (14) - (17)</li> <li>2. Short circuit in wiring harness between E04 (1) - (2), (1) - (3), (2) - (3)</li> <li>3. Short circuit in wiring harness between E06 (1) - (2), (1) - (3), (2) - (3)</li> <li>4. Short circuit in wiring harness between C03 (7) - (4), (4) - (17)</li> <li>5. Disconnection in wiring harness between C03 (7) - X07 (6) - E06 (1)</li> <li>6. Disconnection in wiring harness between C03 (4) - X07 (5) - E06 (2)</li> <li>7. Disconnection in wiring harness between C03 (17) - X07 (4) - E06 (3)</li> <li>8. Defective fuel control dial</li> <li>9. Defective contact of C03, X07, E06 connectors</li> </ol>
	E317	Abnormality (disconnection) in motor drive system	<ol style="list-style-type: none"> <li>1. Disconnection inside governor motor</li> <li>2. Disconnection in wiring harness between C02 (2) - E05 (1)</li> <li>3. Disconnection in wiring harness between C02 (4) - E05 (3)</li> <li>4. Disconnection in wiring harness between C02 (3) - E05 (2)</li> <li>5. Disconnection in wiring harness between C02 (5) - E05 (4)</li> <li>6. Defective contact of E05 connector</li> </ol>
	E318	Abnormality (short circuit) in motor drive system	<ol style="list-style-type: none"> <li>1. Short circuit inside governor motor</li> <li>2. Wiring harness between C02 (2) - E05 (1) and between C02 (4) - E05 (3) short circuiting with wiring harness between C02 (3) - E05 (2)</li> <li>3. Wiring harness between C02 (4) - E05 (3) and between C02 (2) - E05 (1) short circuiting with wiring harness between C02 (5) - E05 (4)</li> <li>4. Wiring harness in Items 2 and 3 short circuiting with ground</li> </ol>

Condition when normal (voltage, current, resistance)			Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality																		
<table border="1"> <thead> <tr> <th>C03 (female)</th> <th>E06 (male)</th> <th>Resistance value</th> </tr> </thead> <tbody> <tr> <td>(7) - (4)</td> <td>(1) - (2)</td> <td>0.25 - 7kΩ</td> </tr> <tr> <td>(4) - (17)</td> <td>(2) - (3)</td> <td>0.25 - 7kΩ</td> </tr> <tr> <td>(7) - (17)</td> <td>-</td> <td>2 - 3kΩ</td> </tr> <tr> <td>-</td> <td>(1) - (3)</td> <td>4 - 6kΩ</td> </tr> <tr> <td>Between each pin and chassis</td> <td>-</td> <td>Min. 1 MΩ</td> </tr> </tbody> </table>	C03 (female)	E06 (male)	Resistance value	(7) - (4)	(1) - (2)	0.25 - 7kΩ	(4) - (17)	(2) - (3)	0.25 - 7kΩ	(7) - (17)	-	2 - 3kΩ	-	(1) - (3)	4 - 6kΩ	Between each pin and chassis	-	Min. 1 MΩ			Maintains engine speed at position of fuel control dial immediately before abnormality occurred	<ol style="list-style-type: none"> <li>Does not become partial speed when set at MAX position</li> <li>Does not reach high idling when set at partial speed</li> <li>There are cases of hunting</li> <li>Lacks output (max. speed of engine is too low)</li> </ol>
C03 (female)	E06 (male)	Resistance value																				
(7) - (4)	(1) - (2)	0.25 - 7kΩ																				
(4) - (17)	(2) - (3)	0.25 - 7kΩ																				
(7) - (17)	-	2 - 3kΩ																				
-	(1) - (3)	4 - 6kΩ																				
Between each pin and chassis	-	Min. 1 MΩ																				
<table border="1"> <thead> <tr> <th>E05 (male)</th> <th>C02 (female)</th> <th>Resistance value</th> </tr> </thead> <tbody> <tr> <td>(1) - (2)</td> <td>(2) - (3)</td> <td>0.25 - 7kΩ</td> </tr> <tr> <td>(3) - (4)</td> <td>(4) - (5)</td> <td>0.25 - 7kΩ</td> </tr> <tr> <td>(1) - (3)</td> <td>(2) - (4)</td> <td>Min. 1 MΩ</td> </tr> <tr> <td>(1) - 94)</td> <td>(2) - (5)</td> <td>Min. 1 MΩ</td> </tr> <tr> <td>Between pins (1), (2), (3), (4) and chassis</td> <td>Between pins (2), (3), (4), and (5) and chassis</td> <td>Min. 1 MΩ</td> </tr> </tbody> </table> <p>Motor drive current: Hold: 0.7 A Start: 0.84 A</p>	E05 (male)	C02 (female)	Resistance value	(1) - (2)	(2) - (3)	0.25 - 7kΩ	(3) - (4)	(4) - (5)	0.25 - 7kΩ	(1) - (3)	(2) - (4)	Min. 1 MΩ	(1) - 94)	(2) - (5)	Min. 1 MΩ	Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ			Takes no particular action	<ol style="list-style-type: none"> <li>When there is a disconnection in both the A phase and B phase at the same time, the problem is the same as for a short circuit in the governor motor system</li> <li>When there is a disconnection in only one of A phase or B phase                             <ol style="list-style-type: none"> <li>Engine does not stop</li> <li>Stops moving at position immediately before failure, so engine speed cannot be controlled</li> <li>There are cases of hunting</li> </ol> </li> </ol>
E05 (male)	C02 (female)	Resistance value																				
(1) - (2)	(2) - (3)	0.25 - 7kΩ																				
(3) - (4)	(4) - (5)	0.25 - 7kΩ																				
(1) - (3)	(2) - (4)	Min. 1 MΩ																				
(1) - 94)	(2) - (5)	Min. 1 MΩ																				
Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ																				
<table border="1"> <thead> <tr> <th>E05 (male)</th> <th>C02 (female)</th> <th>Resistance value</th> </tr> </thead> <tbody> <tr> <td>(1) - (2)</td> <td>(2) - (3)</td> <td>0.25 - 7kΩ</td> </tr> <tr> <td>(3) - (4)</td> <td>(4) - (5)</td> <td>0.25 - 7kΩ</td> </tr> <tr> <td>(1) - (3)</td> <td>(2) - (4)</td> <td>Min. 1 MΩ</td> </tr> <tr> <td>(1) - (4)</td> <td>(2) - (5)</td> <td>Min. 1 MΩ</td> </tr> <tr> <td>Between pins (1), (2), (3), (4) and chassis</td> <td>Between pins (2), (3), (4), and (5) and chassis</td> <td>Min. 1 MΩ</td> </tr> </tbody> </table> <p>Motor drive current: Hold: 0.7 A Start: 0.84 A</p>	E05 (male)	C02 (female)	Resistance value	(1) - (2)	(2) - (3)	0.25 - 7kΩ	(3) - (4)	(4) - (5)	0.25 - 7kΩ	(1) - (3)	(2) - (4)	Min. 1 MΩ	(1) - (4)	(2) - (5)	Min. 1 MΩ	Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ			Sets motor drive current to 0	<ol style="list-style-type: none"> <li>If during operation                             <ol style="list-style-type: none"> <li>Set to low idling</li> <li>Engine does not stop</li> <li>There are cases of hunting</li> </ol> </li> <li>When stopped                             <ol style="list-style-type: none"> <li>Engine starts, but stays at low idling</li> <li>Engine does not stop after starting</li> <li>There are cases of hunting</li> </ol> </li> </ol>
E05 (male)	C02 (female)	Resistance value																				
(1) - (2)	(2) - (3)	0.25 - 7kΩ																				
(3) - (4)	(4) - (5)	0.25 - 7kΩ																				
(1) - (3)	(2) - (4)	Min. 1 MΩ																				
(1) - (4)	(2) - (5)	Min. 1 MΩ																				
Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ																				

**ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY  
OCCURS AND PROBLEMS ON MACHINE**

**TROUBLESHOOTING**

User code	Service code	Abnormal system	Nature of abnormality
-	E306	Abnormality in feedback potentiometer system	<ol style="list-style-type: none"> <li>1. Short circuit in wiring harness between C03 (7) - (14), (7) - (17), (14) - (17)</li> <li>2. Short circuit in wiring harness between E04 (1) - (2), (1) - (3), (2) - (3)</li> <li>3. Short circuit in wiring harness between E06 (1) - (2), (10) - (3), (2) - (3)</li> <li>4. Short circuit in wiring harness between C03 (7) - (4), (4) - (17)</li> <li>5. Disconnection in wiring harness between C03 (7) - E04 (1)</li> <li>6. Disconnection in wiring harness between C03 (14) - E04 (2)</li> <li>7. Disconnection in wiring harness between C03 (17) - E04 (3)</li> <li>8. Defective governor motor potentiometer</li> <li>9. Defective contact of C03, E04 connectors</li> </ol>
-	E315	Abnormality (short circuit) in battery relay output system	<p>If excess current flows between C03 (1) and battery relay</p> <p>★ This occurs only when turning starting switch to OFF and stopping engine</p>
-	E316	Abnormality (step-out) in motor	<ol style="list-style-type: none"> <li>1. Defective adjustment of rod or scuffing of loose spring</li> <li>2. Abnormality in governor motor</li> <li>3. Abnormality in governor, pump controller</li> </ol>

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality																		
<table border="1" data-bbox="220 506 681 808"> <thead> <tr> <th>C03 (female)</th> <th>E04 (male)</th> <th>Resistance value</th> </tr> </thead> <tbody> <tr> <td>(7) - (14)</td> <td>(1) - (2)</td> <td>0.25 - 7kΩ</td> </tr> <tr> <td>(7) - (17)</td> <td>(2) - (3)</td> <td>0.25 - 7kΩ</td> </tr> <tr> <td>(14) - (17)</td> <td>-</td> <td>2 - 3kΩ</td> </tr> <tr> <td>-</td> <td>(1) - (3)</td> <td>4 - 6kΩ</td> </tr> <tr> <td>Between each pin and chassis</td> <td>-</td> <td>Min. 1 MΩ</td> </tr> </tbody> </table>	C03 (female)	E04 (male)	Resistance value	(7) - (14)	(1) - (2)	0.25 - 7kΩ	(7) - (17)	(2) - (3)	0.25 - 7kΩ	(14) - (17)	-	2 - 3kΩ	-	(1) - (3)	4 - 6kΩ	Between each pin and chassis	-	Min. 1 MΩ	<p>Calculates position of motor and carries out control from value of voltage immediately before abnormality occurred</p>	<p>1. Precision of engine speed control may be reduced. For example:</p> <ol style="list-style-type: none"> <li>1) Engine does not rise to high idling speed (a little too low)</li> <li>2) Engine does not go down to low idling speed (a little too high)</li> <li>3) Defective engine speed for autodeceleration or automatic warming-up</li> <li>4) Engine may not stop                         <ul style="list-style-type: none"> <li>★ The governor motor moves in the direction to stop the engine, but the motor may not move completely to the position to stop the engine.</li> </ul> </li> <li>5) There are cases of hunting</li> </ol>
C03 (female)	E04 (male)	Resistance value																		
(7) - (14)	(1) - (2)	0.25 - 7kΩ																		
(7) - (17)	(2) - (3)	0.25 - 7kΩ																		
(14) - (17)	-	2 - 3kΩ																		
-	(1) - (3)	4 - 6kΩ																		
Between each pin and chassis	-	Min. 1 MΩ																		
<p>Between C03 (1) and chassis: 20 - 30 V ★ Holds with the motor in the stop position for 2 - 2.5 sec, returns to the low idling position, the turns then battery relay OFF.</p>	<p>Sets battery relay drive current to 0</p>	<p>Engine does not stop</p>																		
<ol style="list-style-type: none"> <li>1. Linkage adjustment correct</li> <li>2. Must move lightly when connector is removed</li> <li>3. Normal</li> </ol>	<ol style="list-style-type: none"> <li>1. Displays when returning from high idling to low idling ★ Starts again (repeats step-out)</li> <li>2. In some cases it may not display when returning from partial speed to low idling</li> </ol>	<p>Engine speed cannot be controlled (particularly at high idling), so there is hunting</p>																		



# JUDGEMENT TABLE FOR GOVERNOR, PUMP GOVERNOR (GOVERNOR CONTROL SYSTEM) AND ENGINE RELATED PARTS

Failure mode		Governor, pump controller, engine related parts (E3: system)						
		Self-diagnostic display						
		Abnormality in governor, pump controller, power source system						
		Abnormality in fuel control dial input value	Abnormality (disconnection) in motor drive system	Abnormality (short circuit) in motor drive system	Abnormality in feedback potentiometer system	Abnormality (short circuit) in battery relay output	Abnormality (step-out) in motor	
User code		E05						
Service code		308	317	318	306	315	316	
1	Engine does not start easily							
2	Engine does not start							
3	Engine speed stays at low idling, and does not follow accelerator; or engine pickup is poor	●	●	●	●	●		
4	Engine stops during operation							
5	Engine rotation is irregular							
	When idling speed is irregular							
	When there is hunting		●	●	●	●		●
6	Lack of output (engine high idling speed is too low)		●			●		
7	Auto-deceleration does not work							
8	Engine does not stop	●		●	●	●	●	●
9	Warming-up operation is defective							
10	Exhaust gas is black							
11	Oil consumption is excessive, or exhaust gas is blue							
12	Oil becomes dirty prematurely							
13	Fuel consumption is excessive, or exhaust gas is blue							
14	Oil is mixed in coolant							
15	Engine oil pressure caution lamp lights up							
16	Oil level rises							
17	Coolant temperature rises too high (overheating)							
18	Abnormal noise is generated							
19	There is excessive vibration							
20	Engine speed does not change even when working mode is switched							
Troubleshooting code when service code is displayed		E-1	E-2	E-3	E-4	E-5	E-6	E-7
Troubleshooting code when there is abnormality in monitoring or machine monitor check		-	-	-	-	-	-	-

- : This shows applicable item for service code
- ★ : This shows item that needs only checking with monitoring


Checking monitoring, check items										Machine monitor check item	
Battery relay drive signal											
No. 2 throttle command value											
Fuel control dial command value											
Governor motor potentiometer											
Governor motor A phase current											
Governor motor B phase current											
Coolant temperature voltage											
102°C or above											
105°C or above											
Does starting motor turn?											
Monitoring code											
35	16	30	31	33	34	41		108			
										S-1	
										○	S-2
		*	*	*	*			○			S-3
											S-4
											E-9A), S-5
			*								E-9A), S-5
	*	*					○				E-10, S-6
											E-3. E-4
○			*	*							E-11
							○	○			E-3. E-4
											S-7
											S-8
											S-9
											S-10
											S-11
											S-12
											S-13
							○	○			S-14
											S-15
											S-16
	*										E-3. E-4
-	-	-	-	-	-	-	-	-	-		
E-12	-	-	-	-	-	M-14	M-13	M-13	E-8		

Troubleshooting code if no service code display is given

○: This shows item to check with monitoring or machine monitor


# ELECTRICAL CIRCUIT DIAGRAM FOR E MODE 1/2

ELECTRICAL CIRCUIT DIAGRAM FOR EMODE 1/2



ELE1MODEE (SHOP).PARE

# ELECTRICAL CIRCUIT DIAGRAM FOR E MODE 2/2




ELECTRICAL CIRCUIT DIAGRAM FOR E MODE 2/2

# E-1 Abnormality in governor, pump controller power source (controller LED is OFF)

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ Check that fuse 1 is not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ When the starting motor rotates correctly. (If the starting motor also does not rotate, go to E-8.)

		Cause	Remedy		
<p>1</p> <p>Is voltage between C01 (7) (13) and C02 (11) (21) normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• 20 - 30 V</li> </ul>	YES	Defective governor, pump controller	Replace		
	NO	<p>2</p> <p>Is voltage between fuse 1 and chassis normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• 20 - 30 V</li> </ul>	YES	Defective contact, or disconnection in wiring harness between fuse 1 and C01 (female) (7) (13)	Repair or replace
	NO		Defective contact, or disconnection in wiring harness between fuse 1-H15 (2)-M14 (2) (1)-battery relay M	Repair or replace	

E-1 Related electric circuit diagram



BKP00096

## E-2 [E308] Abnormality in fuel control dial input value is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


	Cause	Remedy
<p>Is resistance between E06 (male) (1)-(2), (2)-(3) as show in Table 1?</p> <p>1 YES</p> <p>• Turn starting switch OFF.</p> <p>• Disconnect E06</p>	<p>Is resistance between each pin of C03 (female) (4) (7) (17), or between each pin and chassis as shown in Table 1?</p> <p>2 YES</p> <p>• Turn starting switch OFF.</p> <p>• Disconnect C03.</p>	<p>Defective governor, pump controller</p> <p>Replace</p>
	<p>Defective wiring harness in system with defective resistance</p>	<p>Replace</p>
	<p>Defective fuel control dial</p>	<p>Replace</p>

- ★ If E306 also occurs at the same time, check the wiring harness below.
  - Wiring harness between C03 (female) (7) - E04 (female) (1) short circuiting with ground, or contact with other wiring harness

Table 1

C03 (female)	E04 (male)	Resistance value
(7) - (4)	(1) - (2)	0.25 - 7kΩ
(4) - (17)	(2) - (3)	0.25 - 7kΩ
(7) - (17)	-	2 - 3kΩ
-	(1) - (3)	4 - 6kΩ
Between each pin and chassis	-	Min. 1 MΩ

### E-2 Related electric circuit diagram



BKP00097

## E-3 [E317] Abnormality (disconnection) in motor drive system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ During operation, if there is
  - 1) a simultaneous disconnection in A phase and B phase:
    - 1) the engine will run at low idling
    - 2) the engine will not stop
  - 2) a disconnection in either A phase or B phase, the engine speed will remain the same as before the abnormality occurred
- ★ If the problem occurs when the engine is stopped,
  - 1) the engine can be started, but it stays in low idling, or 2) it will not stop after it is started.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connected any disconnected connectors before going on the next step.

Cause	Remedy
Defective governor, pump controller	Replace
Defective wiring harness in system with defective resistance	Replace
Defective governor motor	Replace





Table 1

E05 (male)	C02 (female)	Resistance value
(1) - (2)	(2) - (3)	2.5 - 7.5 kΩ
(3) - (4)	(4) - (5)	2.5 - 7.5 kΩ

### E-3 Related electric circuit diagram



BKP00098

## E-4 [E318] Abnormality (short circuit) in moter drive system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ If the abnormality occurs during operation, because of the force of the spring,
  - 1) the engine will run at low idling
  - 2) the engine will not stop
- ★ If the problem occurs when the engine is stopped,
  - 1) the engine can be started, but it stays in low idling, or 2) it will not stop after it is started.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connertors before going on the next step.





Table 1

E05 (male)	C02 (female)	Resistance value
91) - (2)	(2) - (3)	2.5 - 7.5 kΩ
(3) - (4)	(4) - (5)	2.5 - 7.5 kΩ
(1) - (3)	(2) - (4)	Min. 1 MΩ
(1) - (4)	(2) - (5)	Min. 1 MΩ
Between chassis and pins (1) (2) (3) (4)	Between chassis and pins (2) (3) (4) (5)	Min. 1 MΩ

### E-4 Related electric circuit diagram



BKP00098



## E-5 [E306] Abnormality in feedback potentiometer system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


	Cause	Remedy
<p style="text-align: center;">2 YES</p> <p>Is resistance between each pin of C03 (female) (4) (7) (14), or between each pin and chassis as shown in Table 1?</p> <p>• Turn starting switch OFF. • Disconnecting C03.</p>	Defective governor, pump controller	Replace
<p style="text-align: center;">1 YES</p> <p>Is resistance between E06 (male) (1)-(2), (2)-(3) as shown in Table 1?</p> <p>• Turn starting switch OFF. • Disconnecting E04.</p>	Defective wiring harness in system with defective resistance	Replace
<p style="text-align: center;">NO</p>	Defective governor motor	Replace

- ★ If E308 also occurs at the same time, check the wiring harness below.
  - Wiring harness between C03 (female) (7) - x07 (6) - E06 (female) (1) short circuiting with ground, or contact with other wiring harness

Table 1

C03 (female)	E04 (male)	Resistance value
(7) - (4)	(1) - (2)	0.25 - 7kΩ
(14) - (17)	(2) - (3)	0.25 - 7kΩ
(7) - (17)	-	2 - 3kΩ
-	(1) - (3)	4 - 6kΩ
Between each pin and chassis	-	Min. 1 MΩ

### E-5 Related electric circuit diagram




BKP00097

## E-6 [E315] Abnormality (short circuit) in battery relay output system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ This only occurs when the engine is stopped and the starting switch is turned OFF.


	Cause	Remedy
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <p>1</p> <p>Is resistance between C01 (female) (1) and chassis normal?</p> <ul style="list-style-type: none"> <li>• Between C01 (female) (1) and chassis: Approx. 110Ω</li> <li>• Turn starting switch OFF.</li> <li>• Disconnect C01.</li> </ul> </div> <div style="flex: 1; border-left: 1px solid black; padding-left: 5px;"> <p>2 YES</p> <p>Is resistance between C01 (female) (1) and battery relay terminal BR, and between wiring harness and chassis normal?</p> <ul style="list-style-type: none"> <li>• Between C01 (female) (1) and battery relay BR: Max 1Ω</li> <li>• Between wiring harness and chassis: Min. 1 MΩ</li> <li>• Turn starting switch OFF.</li> <li>• Disconnect C01 and battery relay BR.</li> </ul> </div> </div>	Defective governor, pump controller	Replace
	Defective battery relay	Replace
	1) Contact between other wiring harness and wiring harness between C01 (female) (1)-battery relay BR. 2) When light is connected	Replace

### E-6 Related electric circuit diagram



## E-7 [E316] Abnormality (step-out) in motor is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ If any other service code [E306] - [E318] has occurred at the same time, start troubleshooting from the code except code [E316].
- ★ Check that the fuse is normal.
- ★ Read the precautions given in TESTING AND ADJUSTING, "Adjusting travel of governor motor lever" before carrying out the troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.






# E-8 Engine does not start

- ★ When starting motor does not rotate.
- ★ Check that fuse No. 14 is not blown before starting troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



E-8 Related electric circuit diagram



	Cause	Remedy
	Defective starting motor	Replace
	Defective contact of wiring harness between battery (+)-battery relay B-battery relay M-starting motor terminal B (including battery relay)	Replace
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>7</p> <p>Is voltage between safety relay terminal S and chassis normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch to START</li> <li>• Approx 24V</li> </ul> </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">YES</div> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;"> <p>8</p> <p>Is there continuity between battery relay M and safety relay B, between</p> </div> <div style="margin-left: 10px;">YES</div> </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">NO</div> <div style="margin-left: 10px;">NO</div> </div>	Defective safety relay  Defective contact, or disconnection in wiring harness between battery relay terminal M and safety relay terminal B, between safety relay terminal C and starting motor terminal C  Defective contact, or disconnection in wiring harness between starting switch terminal C-X07(10)-M02(1)-safety relay terminal S	Replace  Replace  Replace
	Defective starting switch (between terminals B and C)	Replace
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>11</p> <p>Is resistance of wiring harness between starting switch BR and battery relay BR normal?</p> <ul style="list-style-type: none"> <li>• Between starting switch BR and battery relay BR: Max. 1Ω</li> <li>• Between wiring harness and chassis: Min. 1 MΩ</li> <li>• Disconnect both starting switch and battery relay ends.</li> </ul> </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">YES</div> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;"> <p>12</p> <p>Is there continuity between chassis ground and battery relay terminal E?</p> </div> <div style="margin-left: 10px;">YES</div> </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">NO</div> <div style="margin-left: 10px;">NO</div> </div>	Defective battery relay  Defective contact or wiring harness between battery relay terminal E and revolving frame ground connection terminal  Defective contact, or disconnection in wiring harness between starting switch terminal BR-D13-battery relay terminal BR	Replace  Replace  Replace
	Defective starting switch (between B and BR)	Replace
	Defective contact, or disconnection in wiring harness between battery terminal (+)-M11-H05 (6)-X07 (1)-starting switch terminal B (including fusible link)	Replace
	Defective shut-off valve	Replace
	Defective contact, or disconnection in wiring harness between starting motor terminal C and shut-off valve E09 (B)	Replace
	Defective contact, or disconnection in wiring harness between starting switch terminal ACC-X07(11)-E08 (12, 13) -shut-off valve E09 (A).	Replace
	Lack of battery capacity	Replace

### E-9 Engine speed is irregular

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

#### a) Idling speed is irregular





Table 1

Controller model code	
03	150

- ★ The diagram shows monitoring code 03.

	Cause	Remedy
_____	See N mode	
_____	Defective adjustment of linkage	Adjust
_____	Defective injection pump	See S mode
_____	Defective governor motor	Replace
_____	Defective contact of wiring harness between starting switch ACC-X07 (17)-C03 (femal) (8), or defective starting switch	Repair or replace
_____	See E-5	-
_____	See E-2	-
_____	See C-14	-

E-9 Related electric circuit diagram





b) There is hunting





Table 1

Controller model code	
03	150

★ The diagram shows monitoring code 03.

	Cause	Remedy
	See N mode	
	Defective adjustment of linkage	Adjust
	Defective injection pump	See S mode
	Defective governor motor	Replace
	Defective contact of wiring harness between starting switch ACC-X07 (17)-C03 (femal) (8), or defective starting switch	Repair or replace
	See E-5	-
	See E-2	-
	See C-14	-

E-9 Related electric circuit diagram



### E-10 Lack of output (engine high idling speed is too low)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Controller model code	
03	150

- ★ The diagram shows monitoring code 03.

	Cause	Remedy
	See N mode	
	Defective injection pump	See S mode
<p>Starting motor signal 7 YES</p> <p>Is voltage between C03 (8) and chassis normal and stable?</p> <p>• During operation? 20 - 30V</p> <p>NO</p>	<p>Defective governor motor</p> <p>Defective contact of wiring harness between starting switch ACC - X07 (17) - C03 (female) (8), or defective starting switch</p>	<p>Replace</p> <p>Repair or replace</p>
	See E-5	
	See E-2	
	Defective adjustment of governor motor linkage	
	See S mode	Adjust
	See C-14	

E-10 Related electric circuit diagram



### E-11 Engine does not stop

**⚠** Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Read the precautions given in TESTING AND ADJUSTING, "Adjusting travel of governor motor lever" before carrying out the troubleshooting.





Table 1

Controller model code
<div style="font-family: monospace; font-size: 2em; font-weight: bold;">03 150</div>

★ The diagram shows monitoring code 03.


Table 2



Note 1: When the starting switch is ON, the controller end is OFF, but a voltage of approx. 20 - 30V is always flowing from starting switch BR, so if the voltage is measured at C01 (1), there is a voltage of 20 -30V

	Cause	Remedy
<p>7 YES</p> <p>When shut-off valve connector E09 is disconnected, does Engine stop?</p>	<p>Defective wiring harness between starting switch Terminal ACC-X07 (11) -E08 (12, 13) -shut-off valve connector E09 (A)</p>	<p>Replace</p>
<p>NO</p>	<p>Defective shut-off valve</p>	<p>See S mode</p>
	<p>Defective adjustment of linkage</p>	<p>Adjust</p>
	<p>Defective governor motor</p>	<p>Replace</p>
	<p>See E-5</p>	<p></p>
	<p>Defective governor, pump controller</p>	<p>Replace</p>
	<p>Contact with 24V wiring harness of wiring harness between starting switch ACC-X07 (17)- C03 (female) (8), or defective starting switch</p>	<p>Replace</p>
	<p>See C-14</p>	<p></p>

E-11 Related electric circuit diagram



### E-12 Defective operation of battery relay system (engine does not stop)

- ★ This only occurs when the engine is stopped and the starting switch is turned OFF.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1



Note 1: When the starting switch is ON, the controller end is OFF, but a voltage of approx. 20 - 30V is always from starting switch BR, so if the voltage is measured at C01 (1), there is a voltage of 20 - 30V.







# TROUBLESHOOTING OF ENGINE SYSTEM (S MODE)

Method of using troubleshooting charts .....	20-138
S- 1 Starting performance is poor (starting always takes time) .....	20-142
S- 2 Engine does not start .....	20-143
(1) Engine does not turn .....	20-143
(2) Engine turns but no exhaust smoke comes out (fuel is not being injected) .....	20-144
(3) Exhaust smoke comes out, but engine does not start (fuel is being injected) .....	20-145
S- 3 Engine does not pick up smoothly .....	20-146
S- 4 Engine stops during operations .....	20-147
S- 5 Engine does not rotate smoothly (hunting) .....	20-148
S- 6 Engine lacks output (no power) .....	20-149
S- 7 Exhaust smoke is black .....	20-150
S- 8 Oil consumption is excessive, or exhaust gas is blue .....	20-151
S- 9 Oil becomes contaminated quickly .....	20-152
S-10 Fuel consumption is excessive .....	20-153
S-11 Oil is in cooling water .....	20-154
S-12 Oil pressure caution lamp lights up (drop in oil pressure) .....	20-155
S-13 Oil level rises (water, fuel in oil) .....	20-156
S-14 Water temperature becomes too high (overheating) .....	20-157
S-15 Abnormal noise is made .....	20-158
S-16 Vibration is excessive .....	20-159

# METHOD OF USING TROUBLESHOOTING CHARTS

This troubleshooting chart is divided into three sections: **questions, check items, and troubleshooting.** The questions and check items are used to pinpoint high probability causes that can be located from the failure symptoms or simple inspection without using troubleshooting tools.

Next, troubleshooting tools or direct inspection are used to check the high probability causes to make final confirmation.

**[Questions]**

Sections **A** + **B** in the chart on the right corresponds to the items where answers can be obtained from the user. The items in **B** are items that can be obtained from the user, depending on the user's level.


**[Check items]**

The serviceman carries out simple inspection to narrow down the causes. The items under **C** in the chart on the right correspond to this.

The serviceman narrows down the causes from information **A** that he has obtained from the user and the results of **C** that he has obtained from his own inspection.

**[Troubleshooting]**

Troubleshooting is carried out in the order of probability, starting with the causes that have been marked as having the highest probability from information gained from **[Questions]** and **[Check items]**.



The basic method of using the troubleshooting chart is as follows.

Items listed for [questions] and [check items] that have a relationship with the Cause items are marked with ○, and of these, causes that have a high probability are marked with ⊙.

check each of the [Questions] and [Check items] in turn, and marked the ○ or ⊙ in the chart for items where the problem appeared. The vertical column (Causes) that has the highest number of points is the most probable cause, so start troubleshooting for that item to make final confirmation of the cause.

- ✱ 1. For [Confirm recent repair history] in the [Questions] section, ask the user, and mark the Cause column with △ to use as reference for locating the cause of the failure. However, do not use this when making calculations to narrow down the causes.
- ✱ 2. Use the △ in the Cause column as reference for [degree of use (Operated for long period)] in the [Questions] section as reference.  
As a rule, do not use it when calculating the points for locating the cause, but it can be included if necessary to determine the order for troubleshooting.

		Causes					
		Seized turbocharger, interference	Clogged air cleaner element	Worn piston ring, cylinder	Clogged, seized injection nozzle	Improper injection timing	Defective injection pump (excessive injection)
*1	Confirm recent repair history						
*2	Degree of use						
	Operated for long period	△	△	△			

• **Example of troubleshooting when exhaust gas is black**

Let us assume that [clogged air cleaner] is taken to be the cause of black exhaust gas. Three symptoms have causal relationship with this problem: [Exhaust gas slowly became black], [Power slowly became weaker], and [dust indicator is red].


If we look from these three symptoms to find the causes, we find that there is a relationship with five causes. Let us explain here the method of using this causal relationship to pinpoint the most probable cause.

**S-7 Exhaust gas is black (incomplete combustion)**

General causes why exhaust gas is black

- Insufficient intake of air
- Improper condition of fuel injection
- Excessive injection of fuel

		Causes									
		Seized turbocharger, interference	Worn piston ring, cylinder	Clogged, seized injection nozzle	Improper injection timing	Improper injection pump (excessive injection)	Crushed, clogged muffler	Leakage of air between turbocharger and head	Defective contact of valve, valve seat	Defective injection pump (rack, plunger seized)	
Questions	Confirm recent repair history										
	Degree of use	Operated for long period	△	△						△	
	Color of exhaust gas	Suddenly became black	○								○
		Blue under light load			○						
	Engine oil must be added more frequently			○							
	Power was lost	Suddenly	○		○		○			○	
	Non-specified fuel has been used			○						○	
	Noise of interference is heard from around turbocharger		○								
	Check items	Blow-by gas is excessive		○							
		Engine pickup is poor and combustion is irregular		○	○		○	○	○		○
When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low				○						○	
Match marks on fuel injection pump are out of alignment					○						
Seal on injection pump has come off						○					
Clanging sound is heard from around cylinder head							○				
Exhaust noise is abnormal			○		○			○			
Muffler is crushed							○				
Leakage of air between turbocharger and head, loose clamp								○			
Troubleshooting		When turbocharger is rotated by hand, it is found to be heavy	●								
	When air cleaner is inspected directly, it is found to be clogged		●						●		
	When compression pressure is measured, it is found to be low										
	Speed of some cylinders does not change when operating on reduced cylinders			●							
	When check is made using delivery method, injection timing is found to be incorrect				●						
	Injection pump test shows that injection amount is incorrect					●					
	When valve clearance is checked directly it is found to be outside standard value						●				
	When muffler is removed, exhaust gas color returns to normal							●			
When control rack is pushed, it is found to be heavy or does not return									●		
Remedy		Replace	Replace	Replace	Adjust	Adjust	Adjust	Replace	Repair	Replace	Replace



# S-1 Starting performance is poor (starting always takes time)

★ Check that the monitor panel does not display any abnormality in the governor control system.  
 General causes why exhaust smoke comes out but engine takes time to start

- Defective electrical system
  - Insufficient supply of fuel
  - Insufficient intake of air
  - improper selection of fuel
- (At ambient temperature of 10°C or below, use ASTM D975 No. 1)

★ Battery charging rate

Ambient temperature	Charging rate				
	100%	90%	80%	75%	70%
20°C	1.28	1.26	1.24	1.23	1.22
0°C	1.29	1.27	1.25	1.24	1.23
-10°C	1.30	1.28	1.26	1.25	1.24

- The specific gravity should exceed the value for the charging rate of 70% in the above table.
- In cold areas the specific gravity must exceed the value for the charging rate of 75% in the above table.

Legend

- : Possible causes (judging from Questions and check items)
- : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause

**Causes**

Worn piston ring, cylinder  
 Defective contact of valve, valve seat  
 Clogged air cleaner element  
 Clogged fuel filter, strainer  
 Clogged feed pump strainer  
 Starting aid  
 Defective regulator  
 Defective alternator  
 Defective or deteriorated battery  
 Defective injection nozzle  
 Defective injection timing  
 Leakage, clogging, pump (rack, plunger stuck)  
 Clogged air breather hole in fuel tank cap

Questions	Confirm recent repair history		Causes												
	Operated for long period	Gradually became worse	Starts when warm	Starts when warm	Starts when warm	Starts when warm	Starts when warm	Starts when warm	Starts when warm	Starts when warm	Starts when warm	Starts when warm	Starts when warm	Starts when warm	Starts when warm
Check items	Indicator lamp does not light up														
	Engine oil must be added more frequently														
	Replacement of filters has not been carried out according to Operation Manual														
	Air cleaner clogging caution lamp flashes														
	Non-specified fuel is being used														
	Battery charge lamp is ON														
	Starting motor cranks engine slowly														
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low														
	Engine does not pick up smoothly, and combustion is irregular														
	Blow-by gas is excessive														
	Match marks on fuel injection pump are out of alignment														
	Troubleshooting	Mud is stuck to fuel tank cap													
When engine is cranked with starting motor, 1) Little fuel comes out even when injection pump sleeve nut is loosened															
2) Little fuel comes out even when fuel filter air bleed plug is loosened															
Leakage from fuel piping															
There is hunting from engine (rotation is irregular)															
When compression pressure is measured, it is found to be low															
When air cleaner element is inspected directly, it is found to be clogged															
When fuel filter, strainer are inspected directly, they are found to be clogged															
When feed pump strainer is inspected directly, it is found to be clogged															
Heater mount does not become warm															
Is voltage 26 - 30V between alternator terminal R and terminal E with engine at low idling?															
Either specific gravity of electrolyte or voltage of battery is low															
Speed does not change when operation of certain cylinders is stopped															
When check is made using delivery method, injection timing is found to be incorrect															
When control rack is pushed, it is found to be heavy or does not return (when blind cover at rear of pump is removed, it can be seen that plunger control sleeve does not move)															
When fuel cap is inspected directly, it is found to be clogged															
Remedy	Replace	Correct	Clean	Clean	Clean	Replace	Replace	Replace	Replace	Adjust	Replace	Correct	Clean		

\* It is not permitted to replace only the regulator.

## S-2 Engine does not start

### (1) Engine does not turn

General causes why engine does not turn

- Internal parts of engine seized
  - ★ If internal parts of the engine are seized, carry out troubleshooting for "Engine stops during operations".
- Defective electrical system

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙: Most probable causes (judging from Questions and Check items)
- △: Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

		Causes							
		Defective wiring of starting circuit	Defective or deteriorated battery	Defective starting motor	Broken ring gear	Defective safety relay or safety switch	Defective battery relay	Defective battery terminal connection	
Questions	Confirm recent repair history								
	Degree of use of machine	Operated for long period	△		△				
	Condition of horn when starting switch is turned ON	Horn sounds	⊙					○	○
		Horn does not sound or volume is low	⊙						
	When starting switch is turned to START, pinion moves out, but	Makes grating noise		⊙	⊙				
		Soon disengages again				⊙			
		Makes rattling noise and does not turn	⊙						
	Check items	When starting switch is turned to START, pinion does not move out							
		When starting switch is turned to ON, there is no clicking sound						○	
		Battery terminal is loose						⊙	
When battery is checked, battery electrolyte is found to be low		⊙							
Troubleshooting	Specific gravity of electrolyte, voltage of battery is low	●							
	For the following conditions 1) - 5), turn the starting switch OFF, connect the cord, and carry out troubleshooting at ON								
	1) When terminal B and terminal C of starting switch are connected, engine starts							●	
	2) When terminal B and terminal C of starting motor are connected, engine starts		●						
	3) When terminal B and terminal C of safety relay are connected, engine starts				●				
	4) When terminal of safety switch and terminal B of starting motor are connected, engine starts				●				
5) There is no 24V between battery relay terminal M and terminal E						●			
When ring gear is inspected directly, tooth surface is found to be chipped				●					
Remedy		—	Replace	Replace	Replace	Replace	Replace	Replace	



(2) Engine turns but no exhaust smoke comes out (fuel is not being injected)

★ check that the monitor panel does not display any abnormality in the governor control system.

General causes why engine turns but no exhaust smoke comes out

- Supply of fuel impossible
- Supply of fuel is extremely small
- Improper selection of fuel (particularly in winter)

★ Standard for use of fuel

Type of fuel	Ambient temperature							
	-22	-4	14	32	50	68	86	104°F
	-30	-20	-10	0	10	20	30	40°C
Diesel fuel	ASTM D975 No.2							
	ASTM D975 No.1							

Causes							
Broken injection pump drive shaft, key							
Defective injection pump rack, plunger seized)							
Seized, broken feed pump piston							
Clogged fuel filter, strainer							
Clogged feed pump strainer							
Clogged, leaking fuel piping							
Clogged air-breather hole in fuel tank cap							
Improper fuel used							

Legend

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

	Questions	Check items	Troubleshooting	Causes								
				Broken injection pump drive shaft, key	Defective injection pump rack, plunger seized)	Seized, broken feed pump piston	Clogged fuel filter, strainer	Clogged feed pump strainer	Clogged, leaking fuel piping	Clogged air-breather hole in fuel tank cap	Improper fuel used	
	Confirm recent repair history											
	Degree of use of machine	Operated for long period						△	△		△	
	Exhaust smoke suddenly stops coming out (when starting again)			⊙	⊙	⊙						
	Replacement of filters has not been carried out according to Operation Manual						⊙	⊙				
	There is leakage from fuel piping								⊙			
	Mud is stuck to fuel tank cap									⊙		
	When fuel filter is drained, fuel does not come out										⊙	
	When engine is cranked with starting motor,											
	1) Injection pump coupling does not turn			⊙								
	2) No fuel comes out even when fuel filter air bleed plug is loosened			⊙			○	○			○	
	3) No fuel spurts out even when injection pipe sleeve nut is loosened			⊙	⊙	⊙						
	Rust and water are found when fuel tank is drained						○	○				
	Inspect injection pump directly			●								
	When control rack is pushed, it is found to be heavy, or does not return				●							
	Inspect feed pump directly					●						
	When fuel filter, strainer are inspected directly, they are found to be clogged						●					●
	When feed pump strainer is inspected directly, it is found to be clogged							●				
	When fuel cap is inspected directly, it is found to be clogged									●		
	Remedy			Replace	Replace	Replace	Clean	Clean	Correct	Correct	Replace	

**(3) Exhaust smoke comes out but engine does not start  
(Fuel is being injected)**

- ★ General causes why exhaust smoke comes out but engine does not start
- Lack of rotating force due to defective electrical system
- Insufficient supply of fuel
- Insufficient intake of air
- Improper selection of fuel and oil

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Causes										
Defective, broken valve system (valve, rocker lever, etc.)										
Defective injection pump (rack, rocker lever, etc.)										
Worn piston ring, cylinder liner										
Clogged fuel filter, strainer										
Clogged feed pump strainer										
Electrical air cleaner element										
Defective intake air heater										
Leakage or deteriorated battery										
Clogged, clogging, air in fuel system										
Clogged injection nozzle, defective spray										
Improper air breather hole in fuel tank cap										

	Questions	Check items	Causes																		
			1	2	3	4	5	6	7	8	9	10	11								
	Confirm recent repair history																				
	Degree of use of machine	Operated for long period																			△
	Suddenly failed to start		⊙	⊙																	
	When engine is cranked, abnormal noise is heard from around head		⊙																		
	Engine oil must be added more frequently				⊙																
	Non-specified fuel is being used			○																	○
	Replacement of filters has not been carried out according to Operation Manual					○	○	○													
	Rust and water are found when fuel tank is drained								○												
	Air cleaner clogging caution lamp flashes					○	○														
	Preheating indicator lamp does not light up									○											
	Starting motor cranks engine slowly										○										
	Mud is stuck to fuel tank cap																				○
	When fuel lever is placed at FULL position, it does not contact stopper			○																	
	When engine is cranked with starting motor, 1) Little fuel comes out even when injection pump sleeve nut is loosened			○																	
	2) No fuel comes out even when fuel filter air bleed plug is loosened					○	○														○
	There is leakage from fuel piping																○				
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low																			○	
	When fuel filter is drained, no fuel comes out																				○
Troubleshooting	Remove head cover and check directly		●																		
	When control rack is pushed, it is found to be heavy, or does not return			●																	
	When compression pressure is measured, it is found to be low				●																
	When fuel filter, strainer are inspected directly, they are found to be clogged					●															●
	When feed pump strainer is inspected directly, it is found to be clogged						●														
	When air cleaner element is inspected directly, it is found to be clogged							●													
	Heater mount does not become warm								●												
	Either specific gravity of electrolyte or voltage of battery is low									●											
	When feed pump is operated, operation is too light or too heavy										●										
	When injection nozzle is tested as individual part, spray condition is found to be poor											●									
	When fuel cap is inspected directly, it is found to be clogged																				●
Remedy			Replace	Replace	Replace	Clean	Clean	Clean	Replace	Replace	Correct	Clean	Clean	Replace							

### S-3 Engine does not pick up smoothly (follow-up is poor)

★ Check that the monitor panel does not display any abnormality in the governor control system.

General causes why engine does not pick up smoothly

- Insufficient intake of air
- Insufficient supply of fuel
- Improper condition of fuel injection
- Improper fuel used

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Causes									
Clogged air cleaner element	Clogged fuel filter, strainer	Clogged feed pump strainer	Clogged injection pump strainer	Seized injection nozzle, defective spray	Worn piston ring, cylinder liner	Seized turbocharger, interference	Improper valve clearance	Clogged air breather hole in fuel tank cap	Defective contact of valve and valve seat

Questions	Confirm recent repair history																			
	Degree of use of machine	Operated for long period	△	△	△				△											△
	Replacement of filters has not been carried out according to Operation Manual		⊙	⊙	⊙															
	Non-specified fuel is being used			⊙	⊙	⊙	⊙													
	Engine oil must be added more frequently								⊙											
	Rust and water are found when fuel tank is drained		⊙																	
	Air cleaner clogging caution lamp flashes			⊙	⊙															
	Noise of interference is heard from around turbocharger									⊙										
	Engine pick-up suddenly became poor					○				⊙			○		○					
	Color of exhaust gas	Blue under light load								⊙										
	Black	⊙			⊙				⊙										○	
Check items	Clanging sound is heard from around cylinder head											⊙								
	Mud is stuck to fuel tank cap												⊙							
	There is leakage from fuel piping																		⊙	
	High idling speed under no load is normal, but speed suddenly drops when load is applied				⊙	⊙							○							
	There is hunting from engine (rotation is irregular)			○	⊙	○							○							
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low					⊙	○													
	20. Blow-by gas is excessive											⊙								

Troubleshooting	When air cleaner element is inspected directly, it is found to be clogged		●																		
	When fuel filter, strainer are inspected directly, they are found to be clogged			●																	
	When feed pump strainer is inspected directly, it is found to be clogged				●																
	Speed does not change when operation of certain cylinders is stopped					●															
	When control rack is pushed, it is found to be heavy, or does not return						●														
	When compression pressure is measured, it is found to be low									●											●
	When turbocharger is rotated by hand, it is found to be heavy										●										
	When valve clearance is checked directly, it is found to be outside standard value											●									
	When fuel cap is inspected directly, it is found to be clogged												●								
	When feed pump is operated, operation is too light or too heavy																			●	
Remedy		Clean	Clean	Clean	Correct	Replace	Replace	Replace	Adjust	Clean	Correct	Replace									

## S-4 Engine stops during operations

★ Check that the monitor panel fuel level display shows that there is still fuel remaining.

General causes why engine stops during operations

- Seized parts inside engine
- Insufficient supply of fuel
- Overheating
- ★ If there is overheating and the engine stops, carry out troubleshooting for overheating.
- Failure in main piston pump
- ★ If the engine stops because of a failure in the main piston pump, carry out troubleshooting for the hydraulic system (H MODE).

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

		Causes												
		Broken, seized piston, connecting rod	Broken, seized crankshaft bearing	Broken valve system (valve, rocker lever, etc.)	Broken, seized gear train	Clogged fuel pump drive shaft, key	Clogged fuel filter, strainer	Broken, seized feed pump strainer	Clogged, leaking feed pump piston	Clogged air breather hole in fuel tank cap	Defective injection pump (rack, plunger stuck)	Failure in main pump		
Questions	Confirm recent repair history													
	Degree of use of machine	Operated for long period												
	Condition when engine stopped	Abnormal noise was heard and engine stopped suddenly	⊙	⊙	⊙	⊙	⊙			○			○	⊙
		Engine stopped slowly	⊙	○										
		There was hunting and engine stopped						○	○					
		Engine overheated and stopped						○	○			○		
	Replacement of filters has not been carried out according to Operation Manual						⊙	⊙						
	Non-specified fuel is being used						○	○	○				○	
	When feed pump is operated, operation is too light or too heavy						○	○	⊙	○				
	Mud is stuck to fuel tank cap										⊙			
	Try to turn by hand using barring tool	Does not turn at all	⊙	⊙										
		Turns in opposite direction			⊙									
		Moves amount of backlash			⊙									
	Rust and water are found when fuel tank is drained						⊙	⊙						
Metal particles are found when oil is drained	⊙	⊙				○	○							
Troubleshooting	When oil pan is removed and inspection is made directly, it is found to be abnormal	●	●											
	When head cover is removed and inspection is made directly, it is found to be abnormal			●										
	When gear train is inspected, it does not turn			●										
	When fuel filter, strainer are inspected directly, they are found to be clogged						●							
	When feed pump strainer is inspected directly, it is found to be clogged							●						
	Inspect feed pump directly								●					
	When control rack is pushed, it is found to be heavy, or does not return												●	
Remedy	Replace	Replace	Replace	Replace	Replace	Clean	Clean	Replace	Correct	Clean	Replace			

See troubleshooting of hydraulic, mechanical system (H mode)

## S-5 Engine does not rotate smoothly (hunting)

★ Check that the monitor panel does not display any abnormality in the governor control system.

General causes why engine does not rotate smoothly

- Air in fuel system
- Defective governor mechanism
- Defective electric governor mechanism
- ★ If hunting does not occur when the rod between the governor motor and the injection pump is disconnected, troubleshoot by using the electrical system troubleshooting (E mode).

Causes	
Defective operation of governor	
Defective adjustment of governor	
Defective operation of control rack	
Low idling speed is too low	
Clogged feed pump strainer	
Clogged fuel filter, strainer	
Clogged air in circuit between fuel tank and feed pump	
Clogged air in circuit between feed pump and nozzle	
Clogged air breather hole in fuel tank cap	

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Questions	Confirm recent repair history												
	Degree of use of machine	Operated for long period						△	△				
	Condition of hunting	Occurs at a certain speed range		⊙	⊙	⊙	○						
		Occurs at low idling		○			⊙	○	○	○	○		
		Occurs even when speed is raised		○	○	○							○
	Replacement of filters has not been carried out according to Operation Manual							⊙	⊙				
	Rust, water are found when fuel tank is drained							○	○				
	Leakage from fuel piping									⊙	⊙		
	Check items	When feed pump is operated,											
		1) No response, light, return is quick								○	○		
2) No response, light, return is normal									○				
Engine speed sometimes rises too far			⊙	⊙									
Engine is sometimes difficult to stop			⊙		⊙								
Seal on injection pump has come off				⊙		⊙							
Troubleshooting	When governor lever is moved it is found to be stiff		●		●								
	When injection pump is tested, governor is found to be improperly adjusted			●									
	When control rack is pushed, it is found to be heavy, or does not return				●								
	When fuel cap is inspected directly, it is found to be clogged						●					●	
	When feed pump strainer is inspected directly, it is found to be clogged							●					
	When fuel filter, strainer are inspected directly, they are found to be clogged								●				
Remedy		Adjust	Adjust	Adjust	Adjust	Clean	Clean	Correct	Correct	Clean			

## S-6 Engine lacks output (no power)

★ Check that the monitor panel does not display any abnormality in the governor control system.

Measure the engine speed and judge if the cause is in the engine or in the chassis.

General causes why engine lacks output

- Insufficient intake of air
  - Insufficient supply of fuel
  - Improper condition of fuel injection
  - Improper fuel used (if non-specified fuel is used, output drops)
  - Lack of output due to overheating
- ★ If there is overheating and insufficient output, carry out troubleshooting for overheating.

		Causes											
		Clogged air cleaner element	Seized turbocharger, interference	Worn piston ring, cylinder liner	Clogged fuel filter, strainer	Clogged feed pump strainer	Seized injection nozzle	Improper pump plunger	Defective valve clearance	Bent fuel control linkage	Defective adjustment	Clogged, leaking fuel piping	Overheating
Questions	Confirm recent repair history												
	Degree of use of machine	Operated for long period	△	△	△	△				△			
	Power was lost	Suddenly	○	●									○
		Gradually	○		○	○	○			○			
	Engine oil must be added more frequently		○										
	Replacement of filters has not been carried out according to Operation Manual	○		○	○								
	Non-specified fuel is being used			○	○	○	○						
	Air cleaner clogging caution lamp flashes	○											
	Color of exhaust gas	Black	○	○									
		Blue under light load			○								
	Noise of interference is heard from around turbocharger	○											
	Blow-by gas is excessive	○		○									
	Engine pickup is poor and combustion is irregular	○				○				○	○		
	High idling speed under no load is normal, but speed suddenly drops when load is applied				○	○					○		
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low					○	○					○	○
	There is hunting from engine (rotation is irregular)				○	○					○	○	
	Clanging sound is heard from around cylinder head							○					
	High idling speed of engine is low							○		○			
Leakage from fuel piping										○			
Water temperature gauge is in red range												○	
Troubleshooting	When air cleaner element is inspected directly, it is found to be clogged	●											
	When turbocharger is rotated by hand, it is found to be heavy	●											
	When compression pressure is measured, it is found to be low		●						●				
	When fuel filter, strainer are inspected directly, they are found to be clogged			●									
	When feed pump strainer is inspected directly, it is found to be clogged				●								
	Speed does not change when operation of certain cylinders is stopped					●							
	When control rack is pushed, it is found to be heavy, or does not return						●						
	When valve clearance is checked directly, it is found to be outside standard value							●					
	When lever is placed at FULL position, it does not contact stopper								●				
	When feed pump is operated, operation is too light or too heavy									●			
	When fuel cap is inspected directly, it is found to be clogged										●		
Remedy	Clean	Replace	Replace	Clean	Clean	Correct	Replace	Adjust	Replace	Adjust	Correct	Clean	

# S-7 Exhaust smoke is black (incomplete combustion)

General causes why exhaust smoke is black

- Insufficient intake of air
- Improper condition of fuel injection
- Excessive injection of fuel

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Causes	
Seized turbocharger, interference	
Clogged air cleaner element	
Worn piston ring, cylinder liner	
Clogged injection nozzle, defective liner	
Improper injection timing, defective spray	
Defective injection timing	
Improper injection pump (excessive injection)	
Crushed, clogged muffler	
Leakage of air between turbocharger and head	
Defective contact of valve and valve seat	
Defective injection pump (rack, plunger seized)	

Questions		Seized turbocharger, interference	Clogged air cleaner element	Worn piston ring, cylinder liner	Clogged injection nozzle, defective liner	Improper injection timing, defective spray	Defective injection timing	Improper injection pump (excessive injection)	Crushed, clogged muffler	Leakage of air between turbocharger and head	Defective contact of valve and valve seat	Defective injection pump (rack, plunger seized)
Confirm recent repair history												
Degree of use of machine	Operated for long period		△	△	△						△	
Color of exhaust gas	Suddenly became black	⊙										○
	Gradually became black	⊙	⊙							○		
	Blue under light load			⊙								
Engine oil must be added more frequently				⊙								
Power was lost	Suddenly	⊙			○				○			○
	Gradually		○	○						○	○	
Non-specified fuel is being used					○							○
Noise of interference is heard from around turbocharger		⊙										
Air cleaner clogging caution lamp flashes			⊙									
Blow-by gas is excessive				⊙								
Engine pickup is poor and combustion is irregular		○			⊙			○	○	○		○
When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low					○							○
Match marks on fuel injection pump are out of alignment						⊙						
Seal on injection pump has come off							⊙					
Clanging sound is heard from around cylinder head								⊙				
Exhaust noise is abnormal		○			○				⊙			
Muffler is crushed									⊙			
Leakage of air between turbocharger and head, loose clamp										⊙		

Troubleshooting		Seized turbocharger, interference	Clogged air cleaner element	Worn piston ring, cylinder liner	Clogged injection nozzle, defective liner	Improper injection timing, defective spray	Defective injection timing	Improper injection pump (excessive injection)	Crushed, clogged muffler	Leakage of air between turbocharger and head	Defective contact of valve and valve seat	Defective injection pump (rack, plunger seized)
When turbocharger is rotated by hand, it is found to be heavy		●										
When air cleaner is inspected directly, it is found to be clogged			●									
When compression pressure is measured, it is found to be low				●							●	
Speed does not change when operation of certain cylinders is stopped					●							
When check is made using delivery method, injection timing is found to be incorrect						●						
Injection pump test shows that injection amount is incorrect							●					
When valve clearance is checked directly it is found to be outside standard value								●				
When muffler is removed, exhaust color returns to normal									●			
When control rack is pushed, it is found to be heavy, or does not return												●

Remedy	Seized turbocharger, interference	Clogged air cleaner element	Worn piston ring, cylinder liner	Clogged injection nozzle, defective liner	Improper injection timing, defective spray	Defective injection timing	Improper injection pump (excessive injection)	Crushed, clogged muffler	Leakage of air between turbocharger and head	Defective contact of valve and valve seat	Defective injection pump (rack, plunger seized)
Replace											
Clean											
Replace											
Replace											
Adjust											
Adjust											
Adjust											
Replace											
Correct											
Replace											
Replace											

# S-8 Oil consumption is excessive (or exhaust smoke is blue)

★ Do not run the engine at idling for more than 20 minutes continuously. (Both low and high idling)

General causes why oil consumption is excessive

- Abnormal combustion of oil
- External leakage of oil
- Wear of lubrication system

		Causes													
		Broken piston ring	Worn piston ring, cylinder liner	Clogged breather or breather hose	Leakage from oil filter or oil cooler	Leakage from oil piping	Leakage from oil drain plug	Broken oil pan or cylinder head	Worn oil cooler	Worn seal at turbine end	Worn seal at blower end	Turbocharger	Dust sucked in from intake system	Worn valve (stem, guide), broken seal	
Questions	Confirm recent repair history														
	Degree of use of machine														
	Operated for long period		△							△	△			△	
	Oil consumption suddenly increased	◎							○						
	Engine oil must be added more frequently		◎						○						
	Engine oil becomes contaminated quickly	○	◎	○											
	Exhaust smoke is blue under light load	◎	◎												
	Amount of blow-by gas	Excessive	◎	◎							○				○
		None			◎										
	Check items	Area around engine is dirty with oil			◎	◎	◎	◎							
There is oil in engine cooling water								◎							
When exhaust pipe is removed, inside is found to be dirty with oil									◎					○	
When turbocharger air supply pipe is removed, inside is found to be dirty with oil										◎					
Oil level in PTO chamber rises												◎			
Clamps for intake system are loose													◎		
Check items		When compression pressure is measured, it is found to be low	●	●											
		When breather element is inspected, it is found to be clogged with dirty oil			●										
	There is external leakage of oil from engine				●	●	●	●							
	Pressure-tightness test of oil cooler shows there is leakage								●						
	Excessive play of turbocharger shaft									●	●				
	Inspect rear seal directly											●			
	When intake manifold is removed, dust is found inside												●		
	When intake manifold is removed, inside is found to be dirty with oil													●	
	Remedy	Replace	Replace	Clean	Correct	Correct	Correct	Correct	Replace	Replace	Replace	Correct	Correct	Correct	



## S-9 Oil becomes contaminated quickly

General causes why oil becomes contaminated quickly

- Intake of exhaust gas due to internal wear
- Clogging of lubrication passage
- Improper fuel
- Improper oil used
- Operation under excessive load

		Causes								
		Worn piston ring, cylinder liner	Clogged breather, breather hose	Clogged oil filter	Worn valve, valve guide	Clogged oil cooler	Clogged turbocharger drain pipe	Defective seal at turbocharger turbine end	Exhaust safety valve	Exhaust smoke is black
Questions	Confirm recent repair history									
	Degree of use of machine	Operated for long period	△		△		△			
	Engine oil must be added more frequently		⊙							
	Non-specified oil is being used			○						
Check items	Color of exhaust gas	Blue under light load	⊙							
		Black								⊙
	Amount of blow-by gas	Excessive	⊙		○		○	○		
		None		⊙						
		When oil filter is inspected, metal particles are found	○		⊙	○				
	When exhaust pipe is removed, inside is found to be dirty with oil				⊙					
	Engine oil temperature rises quickly				⊙					
Troubleshooting	When compression pressure is measured, it is found to be low	●			●					
	When breather element is inspected directly, hose is broken or is found to be clogged with dirty oil		●							
	When oil filter is inspected directly, it is found to be clogged			●						
	When oil cooler is inspected directly, it is found to be clogged					●				
	Turbocharger drain tube is clogged						●			
	Excessive play of turbocharger shaft							●		
	When safety valve is directly inspected, spring is found to be catching or broken								●	
	Remedy	Replace	Clean	Replace	Replace	Clean	Clean	Replace	Replace	—

Carry out troubleshooting for "Exhaust smoke is black".

# S-10 Fuel consumption is excessive

General causes why fuel consumption is excessive

- Leakage of fuel
- Improper condition of fuel injection
- Excessive injection of fuel

		Causes								
		Defective injection pump (excessive injection)	Defective nozzle holder spray	Defective injection pump plunger	External leakage from fuel piping	Leakage of fuel inside head cover	Defective oil seal inside feed pump	Defective adjustment of fuel pump (piston)	Defective adjustment of fuel control linkage	
Questions	Confirm recent repair history									
	Degree of use of machine	Operated for long period								
	Condition of fuel consumption	More than for other machines of same model	⊙		○					
		Gradually increased		○	○					
		Suddenly increased				○	○			
	Exhaust smoke color	Black	⊙	○	○					○
		White					○			
	Seal on injection pump has come off	⊙								
	There is irregular combustion		⊙							
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low		⊙	○						
	Match mark on injection pump is misaligned				⊙					
	There is external leakage of fuel from engine					⊙				
Engine oil level rises and smells of diesel fuel		○				○	○			
Engine low idling speed is high		○							⊙	
Troubleshooting	Injection pump measurement shows that injection amount is excessive	●								
	Speed does not change when operation of certain cylinders is stopped		●							
	When control rack is pushed, it is found to be heavy, or does not return			●						
	When check is made using delivery method, injection timing is found to be incorrect				●					
	Remove head cover and inspect directly					●				
	Remove feed pump and inspect directly						●			
	When engine speed is measured, low idling speed is found to be high								●	
Remedy		Adjust	Replace	Replace	Adjust	Correct	Correct	Correct	Adjust	

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

# S-11 Oil is in cooling water, or water spurts back, or water level goes down

General causes why oil is in cooling water

- Internal leakage in lubrication system
- Internal leakage in cooling system

Causes					

Legend

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Questions	Confirm recent repair history						
	Degree of use of machine	Operated for long period	△			△	
	Oil level	Suddenly increased	○	○			
		Gradually increased				○	○
Check items	Hard water is being used as cooling water		○			○	
	Engine oil level has risen, oil is cloudy white		⊙			○	○
	Excessive air bubbles inside radiator, spurts back			⊙	⊙		
Troubleshooting	Pressure-tightness test of oil cooler shows there is leakage		●				
	Pressure-tightness test of cylinder head shows there is leakage			●			
	Remove cylinder head and inspect directly				●		
	Remove oil pan and inspect directly					●	●
	Remedy		Replace	Replace	Replace	Replace	Replace

## S-12 Oil pressure caution lamp lights up (drop in oil pressure)

★ Check that the monitor panel engine oil level lamp is not lighted up.

★ When the oil pressure sensor is normal (see M mode).

General causes why oil pressure lamp lights up

- Leakage, clogging, wear of lubricating system
- Defective oil pressure control
- Improper oil used (improper viscosity)
- Deterioration of oil due to overheating

★ Standards for engine oil selection

Type of fuel	Ambient temperature							
	-22	-4	14	32	50	68	86	104°F
	-30	-20	-10	0	10	20	30	40°C
Diesel fuel					SAE 30			
	SAE 10W							
	SAE 10W-30							
	SAE 15W-40							

Causes
Clogged oil filter
Worn bearing, journal
Clogged strainer, inside oil pan
Clogged, broken inside oil pan
Broken suction pipe inside oil pan
Defective oil pump
Defective regulator valve
Leaking main relief valve
Defective oil pressure sensor
Water, fuel in oil

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙: Most probable causes (judging from Questions and Check items)
- △: Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

	Questions	Check items																			
			1	2	3	4	5	6	7	8	9	10									
	Confirm recent repair history																				
	Degree of use of machine	Operated for long period	△	△						△											
	Replacement of filters has not been carried out according to Operation Manual		⊙																		
	Non-specified oil is being used		○	○																	
	Condition when oil pressure lamp lights up	Lights up at low idling		⊙							○										
		Lights up at low, high idling			⊙	⊙	⊙	⊙	○	○											
		Sometimes lights up							⊙	⊙		○									
	There is clogging, leakage from hydraulic piping (external)																		⊙		
	Metal particles are found when oil is drained			⊙																	
	Metal particles are stuck to oil filter element			⊙				○													
	Oil is cloudy white or smells of diesel oil																			⊙	
Troubleshooting	When oil filter is inspected directly, it is found to be clogged		●	●																	
	Remove oil pan and inspect directly				●	●	●														
	Oil pump rotation is heavy, there is play									●											
	There is catching of relief valve or regulator valve, spring or valve guide is broken											●	●								
	When oil pressure is measured, it is found to be within standard value																				●
	Remedy		Clean	Clean	Clean	Clean	Correct	Replace	Adjust	Adjust	Correct	Replace									

Carry out troubleshooting for "Oil level rises".

# S-13 Oil level rises (water, fuel in oil)

★ If there is oil in the cooling water, carry out troubleshooting for "Oil is in cooling water".

General causes why oil level rises

- Water in oil
- Fuel in oil (diluted, and smells of diesel fuel)
- Entry of oil from other component

Causes	
Broken oil cooler core, O-ring	
Defective nozzle holder sleeve	
Broken cylinder head, head gasket (precombustion chamber)	
Clogged water pump breather hole, defective seal	
Worn, damaged rear seal surface	
Defective main pump seal	
Leakage of fuel inside head cover	
Defective part inside injection pump	
Defective thermostat seal (flange type)	
Damaged liner O-ring, holes made by pitting	
Cracks inside cylinder block	

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Questions														
	Degree of use of machine	Operated for long period												
Confirm recent repair history														
When engine is first started, drops of water come from muffler			⊙											
Exhaust smoke is white			⊙					○		○	○			
There is oil in radiator cooling water			⊙	○	○						○	○		
Leave radiator cap open. When engine is run at idling, an abnormal number of bubbles appear, or water spurts back				○							○			
Water pump breather hole is clogged with mud					⊙									
When water pump breather hole is cleaned, water comes out					⊙									
Oil level goes down in damper chamber						⊙								
Oil level goes down in hydraulic tank								○						
Engine oil smells of diesel fuel									○	○	○			
Fuel must be added more frequently									○	○	○			
Troubleshooting	Pressure-tightness test of oil cooler shows there is leakage		●											
	Pressure-tightness test of cylinder head shows there is leakage			●										
	When compression pressure is measured, it is found to be low				●									
	Remove water pump and inspect directly					●								
	Remove rear seal and inspect directly						●							
	When main pump is removed, seal is found to be damaged							●						
	Remove head cover and inspect directly								●					
	Remove injection pump and inspect directly									●				
	Defective contact of thermostat seal valve										●			
	Remove oil pan and check directly											●	●	
Remedy			Replace	Replace	Replace	Replace	Correct	Replace	Correct	Replace	Replace	Replace	Replace	

## S-14 Water temperature becomes too high (overheating)

- ★ Check that the monitor panel coolant level caution lamp is not lightend up.
- ★ When the monitor panel water temperature gauge is normal, go to troubleshooting of machine monitor system (M mode).

General causes why water temperature becomes too high

- Lack of cooling air (deformation, damage of fan)
- Drop in heat dissipation efficiency
- Defective cooling circulation system
- ★ Carry out troubleshooting for chassis.

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

		Causes									
		Broken water pump	Clogged, crushed radiator fins	Clogged radiator core	Defective thermostat (does not open)	Fan belt slipping, worn fan pulley	Clogged, broken oil cooler	Defective radiator pressure valve	Broken head, head gasket	Damaged liner O-ring, holes made by pitting	External leakage from cooling water piping

Questions	Confirm recent repair history											
	Degree of use of machine	Operated for long period		△	△							△
Condition of overheating	Suddenly overheated		⊙			○						
	Always tends to overheat		⊙	⊙	○	○						
Water temperature gauge	Rises quickly			⊙								
	Does not go down				○							
Check items	Fan belt whines under sudden load					○						
	Cloudy white oil is floating on cooling water						○					
	Cooling water flows out from overflow hose							○				
	Excessive air bubbles inside radiator, water spurts back								○			
	Engine oil level has risen, oil is cloudy white						○			○		
	There is play when fan pulley is rotated		⊙									
	Radiator shroud, inside of underguard are clogged with dirt or mud		⊙									
	When light bulb is held behind radiator, no light passes through		⊙									
	Water is leaking because of cracks in hose or loose clamps											○
	When belt tension is inspected, it is found to be loose						○					

Troubleshooting	Temperature difference between top and bottom radiator tanks is excessive		●									
	Temperature difference between top and bottom radiator tanks is slight			●								
	When water filler port is inspected, core is found to be clogged				●							
	When function test is carried out on thermostat, it does not open even at cracking temperature					●						
	When water temperature is measured, it is found to be normal						●					
	When oil cooler is inspected directly, it is found to be clogged							●				
	When measurement is made with radiator cap tester, set pressure is found to be low								●			
	When compression pressure is measured, it is found to be low									●		
	Remove oil pan and inspect directly										●	
	Remedy		Replace	Correct	Correct	Replace	Replace	Correct	Replace	Replace	Replace	Replace

# S-15 Abnormal noise is made

★ Judge if the noise is an internal noise or an external noise.

General causes why abnormal noise is made

- Abnormality due to defective parts
- Abnormal combustion
- Air sucked in from intake system

**Legend**

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Causes	
Excessive wear of piston ring, cylinder liner	
Seized turbocharger, interference	
Missing, seized bushing	
Clogged, seized injection nozzle	
Defective injection pump (rack, plunger seized)	
Deformed fan, fan belt interference	
Defective adjustment of valve clearance	
Broken dynamic valve system	
Improper gear train backlash	
Leakage of air between turbocharger and head	
Defect inside muffler (dividing board out of position)	

Questions																				
Confirm recent repair history																				
Degree of use of machine	Operated for long period	△																		
Condition of abnormal noise	Gradually occurred	○																		
	Suddenly occurred		○	○																
Non-specified fuel is being used						○	○													
Engine oil must be added more frequently		⊙																		
Color of exhaust gas	Blue under light load	⊙																		
	Black		⊙																	○
Metal particles are found in oil filter		⊙			⊙															
Blow-by gas is excessive		⊙																		
Noise of interference is heard from around turbocharger			⊙																	
Engine pickup is poor and combustion is abnormal						⊙														
When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low						⊙	○													
Seal on injection pump has come off											⊙									
Abnormal noise is loud when accelerating engine						○	○	○	○											
Clanging sound is heard from around cylinder head													⊙	⊙						
Leakage of air between turbocharger and head, loose clamp																				⊙
Vibrating noise is heard from around muffler																				⊙

Troubleshooting																				
When compression pressure is measured, it is found to be low		●																		
When turbocharger is rotated by hand, it is found to be heavy			●																	
Remove gear cover and inspect directly						●													●	
Speed does not change when operation of certain cylinders is stopped							●													
When control rack is pushed, it is found to be heavy, or does not return											●									
Injection pump test shows that injection amount is incorrect																				●
Fan is deformed, belt is loose																				●
When valve clearance is checked, it is found to be outside standard value																				●
Remove cylinder head cover and inspect directly																				●
When muffler is removed, abnormal noise disappears																				●

Remedy																				
Replace																				
Replace																				
Replace																				
Replace																				
Correct																				
Replace																				
Correct																				
Replace																				
Correct																				
Replace																				
Replace																				
Replace																				

## S-16 Vibration is excessive

★ If there is abnormal noise together with the vibration, carry out troubleshooting for "Abnormal noise is made".

General causes why vibration is excessive

- Defective parts (abnormal wear, breakage)
- Improper alignment
- \* Abnormal combustion

		Causes							
		Worn connecting rod, main bearing	Worn balancer, cam bushing	Loose engine mounting bolts	Broken part inside output shaft, broken cushion	Improper gear train backlash	Defective dynamic valve system	Defective injection pump (valve, rocker lever, etc.)	
Questions	Confirm recent repair history								
	Degree of use of machine	Operated for long period	△	△	△				
	Condition of vibration	Suddenly increased				○		○	
		Gradually increased	○	○	○				
	Non-specified oil is being used		○	○					
	Metal particles are found in oil filter		◎	◎					
	Metal particles are found when oil is drained		◎	◎					
	Oil pressure is low at low idling		○	○					
	Check items	Vibration occurs at mid-range speed			○	○			
		Vibration follows engine speed			○	○	○		
Exhaust smoke is black							◎	○	
Seal on injection pump has come off								◎	
Troubleshooting	Remove oil pan and inspect directly	●							
	Remove side cover and inspect directly		●						
	Inspect directly for loose engine mounting bolts, broken cushion			●					
	Inspect inside of output shaft (damper) directly				●				
	Remove front cover and inspect directly					●			
	Remove head cover and inspect directly						●		
	Injection pump test shows that injection amount is incorrect							●	
Remedy		Replace	Replace	Replace	Replace	Correct	Replace	Adjust	



# TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER (PUMP CONTROL SYSTEM) (C MODE)

Points to remember when carrying out troubleshooting of pump controller system .....	20-161
Action taken by controller and condition of machine when abnormality occurs .....	20-162
Judgement table for governor, pump controller and hydraulic related parts .....	20-168
Electrical circuit diagram of C mode systems .....	20-170
C- 1 Abnormality in controller power source (controller LED is OFF .....	20-172
C- 2 [E232] Short circuit in pump TVC solenoid system is displayed .....	20-173
C- 3 [E233] Disconnection pump TVC solenoid system is displayed .....	20-175
C- 6 [E201] Short circuit in LS bypass solenoid system is displayed .....	20-177
C- 7 [E211] Disconnection in LS bypass solenoid system is displayed .....	20-178
C- 8 [E203] Short circuit in swing holding brake solenoid system is displayed .....	20-179
C- 9 [e213] Disconnection in swing holding brake solenoid system is displayed .....	20-181
C- 10 [E205] Short circuit in 2-stage relief solenoid system is displayed .....	20-183
C- 11 [E215] Disconnection in 2-stage relief solenoid system is displayed .....	20-184
C- 12 [E206] Short circuit in travel speed solenoid system is displayed .....	20-185
C- 13 [E216] Disconnection in travel speed solenoid system is displayed .....	20-186
C- 14 [E217] Model selection input error is displayed .....	20-187
C- 15 [E222] Short circuit in LS-EPc solenoid system is displayed .....	20-189
C- 16 [E223] Disconnection in LS-EPc solenoid system is displayed .....	20-190
C- 17 [E224] Abnormality in pump pressure sensor system is displayed .....	20-191
C- 19 [E226] Abnormality in pressure sensor power source is displayed .....	20-192
C- 20 [E227] Abnormality in engine speed sensor system is displayed .....	20-193

## POINTS TO REMEMBER WHEN TROUBLESHOOTING PUMP CONTROLLER SYSTEM

### 1. Points to remember if abnormality returns to normal by itself

In the following two cases, there is a high probability that the same problem will occur again, so it is desirable to follow up this problem carefully.

- 1) If any abnormality returns to normal by itself, or
- 2) If the connector is disconnected and the T-adapter is inserted, or if the T-adapter is removed and the connector is returned to its original position when carrying out troubleshooting of the failure, and the service code is no longer displayed, or if the monitor display returns to normal.
- 3) After completing troubleshooting, always erase the user code from memory.

### 2. User code memory retention function

When displaying the abnormality code in memory and carrying out troubleshooting, note down the content of the display, then erase the display. After trying to re-enact the problem, carry out troubleshooting according to the failure code that is displayed.

(There are cases where mistaken operation or abnormalities that occur when the connector is disconnected are recorded by the memory retention function. erasing the data in this way saves any wasted work.)

## ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

User code	Service code	Abnormal system	Nature of abnormality
E02	E232	Short circuit in pump TVC solenoid system	<ol style="list-style-type: none"> <li>1. Short circuit with ground, short circuit inside pump TVC solenoid</li> <li>2. Short circuit with power source, short circuit with ground in wiring harness between controller C02 (8) and TVC solenoid C13 (1) ((+) side)</li> <li>3. Short circuit with power source in wiring harness between controller C02 (18) and TVC solenoid C13 (2) ((-) side)</li> <li>4. Defective governor, pump controller</li> </ol>
	E233	Disconnection in pump TVC solenoid system	<ol style="list-style-type: none"> <li>1. Disconnection, defective contact inside pump TVC solenoid</li> <li>2. Disconnection, defective contact in wiring harness between controller C02 (8) and TVC solenoid C13 (1) ((+) side)</li> <li>3. Disconnection, defective contact, short circuit with ground in wiring harness between controller C02 (18) and TVC solenoid C13 (2) ((-) side)</li> <li>4. Defective governor, pump controller</li> </ol>
E03	E203	Short circuit in swing holding brake solenoid system	<ol style="list-style-type: none"> <li>1. Short circuit with ground, short circuit inside swing holding brake solenoid</li> <li>2. Short circuit with ground in wiring harness between controller C01 (3) and solenoid V06 (2) ((+) side)</li> <li>3. Defective governor, pump controller</li> </ol>
	E213	Disconnection in swing holding brake solenoid system	<ol style="list-style-type: none"> <li>1. Disconnection, defective contact inside swing holding brake solenoid</li> <li>2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (3) and solenoid V06 (2) ((+) side)</li> <li>3. Disconnection, defective contact in wiring harness between solenoid V06 (1) and chassis ground ((-) side)</li> <li>4. Defective governor, pump controller</li> </ol>

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
<ul style="list-style-type: none"> <li>Resistance of solenoid: 10 - 22Ω</li> </ul>	<ol style="list-style-type: none"> <li>1. Make output to TVC solenoid 0.</li> <li>2. Displays user code E02 on monitor panel.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<ol style="list-style-type: none"> <li>1. No current flows to the pump TVC solenoid. Therefore, when the load is large, there is a big drop in the engine speed which may result in the engine stalling.</li> <li>2. The swing acceleration is poor</li> </ol>
<ul style="list-style-type: none"> <li>Resistance of solenoid: 10 - 22Ω</li> <li>Current: 1000 mA (H/O mode, auto-deceleration ON, levers at neutral, fuel control dial at MAX.)</li> </ul>	<ol style="list-style-type: none"> <li>1. The current stops flowing to the TVC solenoid, so no particular action is taken.</li> <li>2. If there is a short circuit with the ground at the (-) end, the current (min. 1A) continues to flow to the TVC solenoid.</li> <li>3. It displays user code E02 on the monitor panel.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<ol style="list-style-type: none"> <li>1. In the case of 1, it is the same as E232.</li> <li>2. In the case of 2, the current (min. 1A) continues to flow to the pump TVC solenoid, so the output of the pump TVC valve increases and the overall speed becomes slower.</li> </ol>
<ul style="list-style-type: none"> <li>Resistance of solenoid: 20 - 60Ω</li> </ul>	<ol style="list-style-type: none"> <li>1. Makes output to TVC solenoid 0.</li> <li>2. displays user code E03 on monitor panel.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<p>When the swing is operated, the motor brake is not released, so the upper structure does not swing.</p>
<ul style="list-style-type: none"> <li>Resistance of solenoid: 20 - 60 Ω</li> </ul>	<ol style="list-style-type: none"> <li>1. The current stops flowing to the solenoid, so no particular action is taken.</li> <li>2. Displays user code E03 on monitor panel.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<p>Same as display for E203</p>

**ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY  
OCCURS AND PROBLEMS ON MACHINE**

**TROUBLESHOOTING**

User code	Service code	Abnormal system	Nature of abnormality
-	E201	Short circuit in LS bypass solenoid system	<ol style="list-style-type: none"> <li>1. Short circuit with ground, short circuit inside LS bypass solenoid</li> <li>2. Short circuit with ground in wiring harness between controller c01 (2) and solenoid V05 (2) ((+) side)</li> <li>3. Defective governor , pump controller</li> </ol>
-	E205	Short circuit in 2-stage relief solenoid system	<ol style="list-style-type: none"> <li>1. Short circuit with ground, short circuit inside 2-stage relief solenoid</li> <li>2. Short circuit with ground in wiring harness between controller c01 (10) and solenoid V25 (2) ((+) side)</li> <li>3. Defective governor, pump controller</li> </ol>
-	E206	Short circuit in travel speed solenoid system	<ol style="list-style-type: none"> <li>1. Short circuit with ground, short circuit inside travel speed solenoid</li> <li>2. Short circuit with ground in wiring harness between controller C01 (9) and solenoid V04 (2) ((+) side)</li> <li>3. Defective governor, pump controller</li> </ol>
-	E211	Disconnection in LS bypass solenoid system	<ol style="list-style-type: none"> <li>1. Disconnection, defective contact inside LS bypass solenoid</li> <li>2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (2) and solenoid V05 (2) ((+) side)</li> <li>3. disconnection, defective contact in wiring harness between solenoid V05 (1) and chassis ground ((-) side)</li> <li>4. Defective governor, pump controller</li> </ol>
-	E215	Disconnection in 2-stage relief solenoid system	<ol style="list-style-type: none"> <li>1. Disconnection, defective contact inside 2-stage relief solenoid</li> <li>2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (10) and solenoid V25 (2) ((+) side)</li> <li>3. Disconnection, defective contact in wiring harness between solenoid V25 (1) and chassis ground ((-) side)</li> <li>4. Defective governor, pump controller</li> </ol>
-	E216	Disconnection in travel speed solenoid system	<ol style="list-style-type: none"> <li>1. Disconnection, defective contact inside travel speed solenoid</li> <li>2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (9) and solenoid V04 (2) ((+) side)</li> <li>3. Disconnection, defective contact in wiring harness between solenoid V04 (1) and chassis ground ((-) side)</li> <li>4. Defective governor, pump controller</li> </ol>
-	E217	Model selection input error	<ol style="list-style-type: none"> <li>1. Disconnection, defective contact, short circuit with ground in model selection wiring harness C17 (5) (6) (7) (13) (14)</li> <li>2. Defective governor, pump controller</li> </ol>

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
<ul style="list-style-type: none"> <li>Resistance of solenoid: 20 - 60Ω</li> </ul>	<ol style="list-style-type: none"> <li>Makes output to solenoid O.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<ol style="list-style-type: none"> <li>With swing + boom RAISE, the boom is slow.</li> <li>With swing + arm IN, the arm IN movement is slow.</li> <li>With swing + arm OUT, the arm OUT movement is slow.</li> <li>With swing+ travel, there is a big drop in the travel speed.</li> </ol>
<ul style="list-style-type: none"> <li>Resistance of solenoid: 20 - 60 Ω</li> </ul>	<ol style="list-style-type: none"> <li>Makes output to solenoid O.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<p>The pump merge/divider valve continues to merge the oil flow.</p> <ol style="list-style-type: none"> <li>In the L/O and F/O modes, the work equipment and swing speeds become faster.</li> <li>The steering is difficult to turn.</li> </ol>
<ul style="list-style-type: none"> <li>Resistance of solenoid: 20 - 60Ω</li> </ul>	<ol style="list-style-type: none"> <li>Makes output to solenoid O.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<p>Even if the travel speed is switched, the travel speed does not change (remains at Lo)</p>
<ul style="list-style-type: none"> <li>Resistance of solenoid: 20 - 60Ω</li> </ul>	<ol style="list-style-type: none"> <li>The current stops flowing to the solenoid, so no particular action is taken.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<p>Same content as display for E201</p>
<ul style="list-style-type: none"> <li>Resistance of solenoid: 20 - 60 Ω</li> </ul>	<ol style="list-style-type: none"> <li>The current stops flowing to the solenoid, so no particular action is taken.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<p>Same content as display for E205</p>
<ul style="list-style-type: none"> <li>Resistance of solenoid: 20 - 60 Ω</li> </ul>	<ol style="list-style-type: none"> <li>The current stops flowing to the solenoid, so no particular action is taken.</li> </ol> <p>★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)</p>	<p>Same content as display for E206</p>
<ul style="list-style-type: none"> <li>Between C17 (13) and chassis: Max. 1 Ω</li> <li>Between C17 (5), (7), (14) (6) and chassis: Min. 1 MX</li> </ul>	<p>Detect abnormality in input</p> <ol style="list-style-type: none"> <li>Retains data when starting switch is ON</li> </ol>	<ol style="list-style-type: none"> <li>Engine stalls, or</li> <li>Work equipment, swing, travel speeds are all slow, and there is no power</li> </ol>

**ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY  
OCCURS AND PROBLEMS ON MACHINE**

**TROUBLESHOOTING**

User code	Service code	Abnormal system	Nature of abnormality
-	E218	Network response overtime error	<ol style="list-style-type: none"> <li>1. Disconnection, short circuit, short circuit with ground in network wiring harness</li> <li>2. Abnormality in governor, pump controller</li> <li>3. Abnormality in monitor</li> </ol>
-	E222	Short circuit in LS-EPC solenoid system	<ol style="list-style-type: none"> <li>1. Short circuit with ground, short circuit inside LS-EPC solenoid</li> <li>2. Short circuit with power source, short circuit with ground in wiring harness between controller C02 (7) and solenoid C10 (1) ((+) side)</li> <li>3. Short circuit with power source in wiring harness between controller C02 (17) and solenoid C10 (2) ((-) side)</li> <li>4. Defective governor, pump controller</li> </ol>
-	E223	Disconnection in LS-EPC solenoid system	<ol style="list-style-type: none"> <li>1. Disconnection, defective contact inside LS-EPC solenoid</li> <li>2. Disconnection, defective contact in wiring harness between controller C02 (7) and solenoid C10 (1) ((+) side)</li> <li>3. Disconnection, defective contact, short circuit with ground in wiring harness between controller C02 (17) and solenoid C10 (2) ((-) side)</li> <li>4. Defective governor, pump controller</li> </ol>
-	E224	Abnormality in pump pressure sensor system	<ol style="list-style-type: none"> <li>1. Disconnection, defective contact, short circuit, short circuit with ground inside pump pressure sensor</li> <li>2. Disconnection, defective contact, short circuit in wiring harness between controller C03 (6) and pressure sensor C08 (2) ((+) side) and between C03 (16) and C08 (1) ((-) side)</li> <li>3. Disconnection, defective contact, short circuit with power source, short circuit with ground in wiring harness between controller C03 (3) and pressure sensor C08 (3) (SIG side)</li> <li>4. Defective governor, pump controller</li> </ol>
-	E226	Abnormality in pressure sensor power source system	<ol style="list-style-type: none"> <li>1. Short circuit, short circuit with ground inside pump pressure sensor</li> <li>2. Short circuit, short circuit with ground in wiring harness between controller C03 (6) and pressure sensor C08 (2)</li> <li>3. Defective governor, pump controller</li> </ol>
-	E227	Abnormality in speed sensor system	<ol style="list-style-type: none"> <li>1. Disconnection defective contact, short circuit inside engine speed sensor</li> <li>2. Disconnection, defective contact, short circuit with ground in wiring harness between controller C16 (1) and speed sensor E07 (2) ((-) side) and between C16 (2) and E07 (1) (SIG side)</li> <li>3. Defective governor, pump controller</li> </ol>

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
	1. When communications are impossible with the monitor, control is carried out with the following settings. ① Working mode: G/O ② Priority mode: OFF ③ Travel speed: Lo ④ Auto-deceleration: ON ⑤ Power max. : ON (others are as usual)	1. ① Even when travel is operated, the power max. function does not work ② The swift speed-down function does not work ③ The auto-deceleration cannot be canceled ④ The travel speed does not increase ⑤ The priority mode has no effect ⑥ the automatic mode has no effect
<ul style="list-style-type: none"> <li>Resistance of solenoid: 7 - 14 Ω</li> </ul>	1. Makes output to LS-EPC solenoid O. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. The Lo travel speed is too fast. 2. In L/O and F/O modes, the work equipment speed is too fast. 3. When the engine is running at low idling, the swing speed is too fast.
<ul style="list-style-type: none"> <li>Current: Approx. 705 mA (Levers at neutral, low idling)</li> </ul>	1. The current stops flowing to the LS-EPC solenoid, so no particular action is taken. 2. If there is a short circuit with the ground at the (-) end, the current (min. 1A) continues to flow to the LS-EPC solenoid. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. In the case of 1, it is the same as E222 2. In the case of 2, electric current (min. 1A) continues to flow to the LS-EPC solenoid, so the work equipment, travel, and swing speeds are slow
<ul style="list-style-type: none"> <li>Between C03 (3) and (16): 0.5 - 4.5 V</li> <li>Between C03 (6) and (16): 18 - 28 V</li> <li>Between C03 (female) (3) and (16), (3) and chassis</li> <li>Resistance: Min. 1 MΩ (Disconnect connectors C03 and C08.)</li> </ul>	1. Takes pump pressure as 0 MPa (0 kg/cm <sup>2</sup> ) when actuating. * If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. The travel speed does not automatically shift (it does not change from Hi to Lo). ★ If the button is operated manually, the panel display is switched.
<ul style="list-style-type: none"> <li>Voltage between C03 (6) and (16): 18 - 28 V</li> </ul>	1. Takes front pump and rear pump pressure as 0 MPa (0 kg/cm <sup>2</sup> ) when actuating. 2. When abnormality is detected, it switches the output OFF, and when all levers are returned to neutral, it outputs again. ★ This automatic resetting is repeated up to 3 times.	1. The travel speed does not automatically shift (it does not change from Hi to Lo). ★ If the button is operated manually, the panel display is switched.
<ul style="list-style-type: none"> <li>Resistance: 500 - 1000 Ω</li> <li>Voltage (AC range) : 0.5 - 3.0 V (engine started)</li> </ul>	1. It functions in the equivalent of the G/O mode (the speed rises)	It operated about the same as G/O mode (prolix) (the power is slightly lower)



## JUDGEMENT TABLE FOR GOVERNOR, PUMP CONTROLLER (PUMP CONTROL SYSTEM) AND HYDRAULIC RELATED PARTS

Failure mode		Governor, pump controller (E2:XX system)																
		Self-diagnostic display																
				Abnormality in controller power source			Short circuit in pump TVC solenoid system			Disconnection in pump TVC solenoid system			Short circuit in LS bypass solenoid system			Disconnection in LS bypass solenoid system		
		User code	Service code	LED	E02	E03	E04	E05	E06	E07	E08	E09	E10	E11	E12	E13	E14	
All work equipment travel, swing	Speeds of all work equipment, swing, travel are slow or lack power		•	•	•													
	There is excessive drop in engine speed, or engine stalls		•	•														
	No work equipment, travel, swing move																	
	Abnormal noise generated (around pump)																	
	Auto-deceleration does not work		•															
Work equipment	Fine control ability is poor or response is poor																	
	Boom is slow or lacks power																	
	Arm is slow or lacks power																	
	Bucket is slow or lacks power																	
	Boom does not move																	
	Arm does not move																	
	Bucket does not move																	
	Excessive hydraulic drift																	
	Excessive time lag (engine at low idling)																•	
	Other equipment moves when single circuit is relieved																•	
	In L/O, F/O modes, work equipment speed is faster than specified speed																•	
Compound operations	Lack of power when pressure rises																•	
	In compound operations, work equipment with larger load is slow																•	
	In swing + boom (RAISE), boom is slow																•	
	In work equipment (BOOM RAISE) + travel travel speed drops excessively																•	
Travel system	In swing + travel, travel speed drops excessively																•	
	Travel deviation																	
	Deviation is excessive during normal travel																	
	Deviation is excessive when starting																	
	Travel speed is slow																	
Swing system	Steering does not turn or lacks power																	
	Travel speed does not switch or is faster than specified speed																	
	Does not move (one side only)																	
	Does not swing	Both left and right																
	One direction only																	
Swing system	Swing acceleration is poor or swing speed is slow	Both left and right																
	One direction only																	
	Excessive overrun when stopping swing	Both left and right																
	One direction only																	
	Excessive shock when stopping swing (one direction only)																	
	Excessive abnormal noise when stopping swing																	
	Excessive hydraulic drift of swing	When holding brake is released																
When holding brake is applied																		
Swing speed is faster than specified swing speed																	•	
Troubleshooting code when service code is displayed																		
Troubleshooting code when there is abnormality in monitoring check																		


• : This shows applicable item for service code  
 \* : This shows item that needs only checking with monitoring  
 ○ : This shows item to check with monitoring or machine monitor

**JUDGEMENT TABLE FOR GOVERNOR, PUMP CONTROLLER  
(PUMP CONTROL SYSTEM) AND HYDRAULIC RELATED PARTS**

★ If service code E218 (abnormality in network system) is displayed, go to troubleshooting for N mode.

Governor, pump controller (E2XX system)					Check items in monitoring mode														
Self-diagnostic display					Pressure switch										Actuation of solenoid				
Abnormality in pump pressure sensor system																			
Abnormality in pressure sensor power source system																			
Abnormality in engine speed sensor system																			
Swing																			
Travel																			
Boom LOWER																			
Boom RAISE																			
Arm IN																			
Arm OUT																			
Bucket CURL																			
Bucket DUMP																			
Swing lock switch																			
Kerosene mode																			
Knob switch																			
LS bypass																			
Swing holding brake																			
2-stage relief																			
Travel speed																			
Model code																			
Engine speed input																			
Pump discharge pressure input																			
Pump TVC current output																			
LS-EPC current output																			
Troubleshooting code if no service code is displayed																			
					Bit pattern								Monitoring code						
224	226	227	20						21	22	23			02	10	11	13	15	
		•												※	※	※	※	H-1	
									○					※		※		H-2	
																		H-3	
																		H-4	
																		H-5	
		○	○	○	○	○	○	○										H-6	
																		H-7	
					○		○									※		H-8	
								○		○						※		H-9	
																		H-10	
																		H-11	
							○		○	○							※	H-12	
																		H-13	
																	※	H-14	
							○	○	○	○		○		※				H-15 C-21	
																		H-16	
													※					H-17	
												※						H-18	
						※	※					※						H-19	
																		H-20	
																		H-21	
													※					H-22	
													※	※	※			H-23	
•	•			○										※	※		※	H-24	
									○									H-25	
																		H-26	
														※				H-27	
																		H-28	
																		H-29	
																		H-30	
																		H-31	
C-17	C-19	C-20	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
-	-	-	F-1	F-2	F-3	F-4	F-5	F-6	F-7	F-8	F-9	F-10	F-11	-	-	-	-		

# ELECTRICAL CIRCUIT DIAGRAM FOR C MODE 1/2




ELECTRICAL CIRCUIT DIAGRAM FOR C MODE 1/2

FIGURE 20-170  
ELEM000C(SHOP), PARE

# ELECTRICAL CIRCUIT DIAGRAM FOR C MODE 2/2

ELECTRICAL CIRCUIT DIAGRAM FOR C MODE 2/2



WIRE FILE # 20-171  
ELE2MODEC(SHOP).PARE


# C-1 Abnormality in controller power source system (controller LED is OFF)

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ Check that fuse 1 is not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ When the starting motor rotates normally. (If the starting motor also does not rotate, go to E-8.)

	Cause	Remedy
<p>1 YES</p> <p>Is voltage between C01 (7) (13) and C02 (11) (21) normal?</p> <p>• Turn starting switch ON. • 20 - 30 V</p>	Defective governor, pump controller	Replace
<p>2 YES</p> <p>Is voltage between fuse 1 and chassis normal?</p> <p>• Turn starting switch ON. • 20 - 30V</p>	Defective contact or disconnection in wiring harness between fuse 1 and C01 (female) (7) (13)	Repair or replace
<p>NO</p> <p>NO</p>	Defective contact, or disconnection in wiring harness between fuse 1 - H15 (2) - M14 (2) (1) - battery relay M	Repair or replace

## C-1 Related electric circuit diagram

Governor, pump controller  
C01(MIC13)



## C-2 [E232] Short circuit in pump TVC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No.2	Troubleshooting No. 3	Troubleshooting No.4	Resistance value
Between C13 (male) (1) - (2)	Between C02 (female) (8) - (18)	Between C05 (female) (3) - (4)	10 - 22 Ω
Between C13 (male) (1) - chassis	Between C02 (female) (8) - chassis	Between C05 (female) (3) - chassis	Min. 1 MΩ

Table 2

Troubleshooting No.5	Resistance value
Between C05 (male) (1) - (3), (2) - (4)	Max. 1 Ω
Between C05 (male) (1) (2) (3) (4) - chassis	Min. 1 MΩ

C-2 Related electric circuit diagram



## C-3 [E233] Disconnection in pump TVC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch On and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ If there is a disconnection in the solenoid or wiring harness, no current flows to the solenoid. If the No. 2 pin of the solenoid is short circuiting with the ground, the current (approx. 1 A) continues to flow to the solenoid.
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




Table 1


Troubleshooting No.2	Troubleshooting No. 3	Troubleshooting No.4	Resistance value
Between C13 (male) (1) - (2)	Between C02 (female) (8) - (18)	Between C05 (female) (3) - (4)	10 - 22 Ω
Between C13 (male) (2) - chassis	Between C02 (female) (18) - chassis	Between C05 (female) (4) - chassis	Min. 1 MΩ

Table 2

Troubleshooting No.5	Resistance value
Between C05 (male ) (1) - (3), (2) - (4)	Max. 1 Ω
Between C05 (male) (1) (2) (3) (4) - chassis	Min. 1 MΩ



C-3 Related electric circuit diagram



## C-6 [E201] Short circuit in LS bypass solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adaper and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Between V05 (male) (1) - (2)	20 - 60 Ω
Between v05 (male) (2) - chassis	Min. 1 MΩ

### C-6 Related electric circuit diagram



## C-7 [E211] Disconnection LS bypass solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Voltage	Measurement condition
Between C01 (male) (2) - chassis	Between V05 (female) (2) - chassis	0 - 3V	When swing lock switch is ON
		20 - 30V	When swing lock switch is OFF
			When swing and travel are operated at same time

### C-7 Related electric circuit diagram



## C-8 [E203] Short circuit in swing brake solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Always turn the swing lock prolix switch OFF, then turn the swing lock switch OFF before checking.





Table 1

Between V06 (male) (1) - 92)	20 - 60 Ω
Between V06 (male) (2) - chassis	Min. 1 MΩ

C-8 Related electric circuit diagram



# C-9 [E213] Disconnection in swing brake solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Always turn the swing lock prolix switch OFF, then turn the swing lock switch OFF before checking.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

**Flowchart Steps:**


- Step 1:** Interchange connector with other solenoid. Is [E213] displayed?
  - YES: Turn starting switch OFF, Interchange V06 with other connector, Turn starting switch ON.
  - NO: Proceed to Step 2.
- Step 2:** Is resistance between V06 (male) (1) and (2) normal?
  - YES: Turn starting switch ON, Disconnect C01. Proceed to Step 3.
  - NO: Proceed to Step 4.
- Step 3:** Is voltage between C01 (male) (3) and chassis as shown in Table 1?
  - YES: Go to A.
  - NO: Proceed to Step 4.
- Step 4:** Is voltage between X05 (male) (3) and chassis as shown in Table 1?
  - YES: Turn starting switch ON, Disconnect X05, Min. 1Ω. Proceed to Step 5.
  - NO: Proceed to Step 6.
- Step 5:** Is resistance between X05 (female) (3) and (4) normal?
  - YES: Turn starting switch OFF, Disconnect X05, Min. 1Ω. Proceed to Step 6.
  - NO: Proceed to Step 6.
- Step 6:** Is voltage between V06 (female) (2) and chassis as shown in Table 1?
  - YES: Turn starting switch ON, Disconnect V. Proceed to Step 7.
  - NO: Proceed to Step 7.
- Step 7:** Is voltage between V06 (female) (1) and chassis ground?
  - YES: Defective swing holding brake solenoid (internal disconnection or short circuit with power source).
  - NO: Defective contact or disconnection in wiring harness between V06 (female) (1) and chassis ground.

Cause	Remedy
Defective governor, pump controller	Replace
Defective swing holding brake solenoid (internal disconnection or short circuit with power source)	Replace
Defective contact or disconnection in wiring harness between V06 (female) (1) and chassis ground	Repair or replace
Short circuit with power source, defective contact, or disconnection in wiring harness between X05 (male) (4) - X01 (6) - H13 (7) - V06 (female) (2)	Repair or replace
Defective swing lock switch (internal disconnection or short circuit with power source)	Replace
Short circuit with power source, defective contact, or disconnection in wiring harness between C01 (female) (3) - A26 (1) (2) - H13 (1) - X01 (7) - X05 (male) (3)	Repair or replace

Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Troubleshooting No. 6	Voltage	Measurement condition
Between C01 (male) (3) - chassis	Between X05 (male) (3) - chassis	Between V06 (male) (2) - chassis	0 - 3V	5 seconds after all levers are returned to neutral
			20 - 30V	Swing lever operated

C-9 Related electric circuit diagram



## C-10 [E205] Short circuit in 2-stage relief solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Between V25 (male) (1) - (2)	20 - 60 Ω
Between v25 (male) (2) - chassis	Min. 1 MΩ

### C-10 Related electric circuit diagram





## C-11 [E215] Disconnection in 2-stage relief solenoid system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy	
<p>1</p> <p>Interchange connector with other solenoid. Is [E215] displayed?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF</li> <li>• Interchange V25 with other connector.</li> <li>• Turn starting switch ON.</li> </ul>	<p>2</p> <p>Is resistance between V25 (male) (1) and (2) normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect V25</li> <li>• 20 - 60 Ω</li> </ul>			
	<p>3</p> <p>Is voltage between C01 (male) (10) and chassis as shown in Table 1?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• Disconnect C01.</li> </ul>	<p>4 YES</p> <p>Is voltage between V25 (female) (2) and chassis as shown in Table 1?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• Disconnect V25</li> </ul>	<p>Defective contact or disconnection in wiring harness between V25 (female) (1) and chassis ground</p> <p>Repair or replace</p>	<p>NO</p> <p>Short circuit with power source, defective contact, or disconnection in wiring harness between C01 (female) (10) -V25 (female) (2)</p> <p>Repair or replace</p>
			<p>Defective governor, pump controller</p> <p>Replace</p>	
			<p>Defective 2-stage relief solenoid (internal disconnection or short circuit with power source)</p> <p>Replace</p>	

Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Voltage	Measurement condition
Between C01 (male) (10) - chassis	Between V25 (female) (2) - chassis	0 - 3V	All levers at neutral
		20 - 30V	Travel operated independently

### C-11 Related electric circuit diagram



## C-12 [E206] Short circuit in travel speed solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Between V04 (male) (1) - (2):	20 - 60 Ω
Between v04 (male) (2) - chassis	Min. 1 MΩ

### C-12 Related electric circuit diagram



## C-13 [E216] Disconnection in travel speed selector solenoid system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
<p>1</p> <p>Interchange connector with other solenoid. Is [E216] displayed?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Interchange V04 with other connector.</li> <li>• Turn starting switch ON.</li> </ul>	<p>YES</p> <p>Is resistance between V04 (male) (1) and (2) normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect V06.</li> <li>• 20 - 60 Ω</li> </ul>		
	<p>NO</p> <p>2</p> <p>Is voltage between C01 (male) (9) and chassis as shown in Table 1?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• Disconnect C01.</li> </ul>		
	<p>YES</p> <p>3</p> <p>Is voltage between V04 (female) (2) and chassis as shown in Table 1?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• Disconnect V</li> </ul>		
	<p>NO</p> <p>4</p> <p>Is voltage between V04 (female) (2) and chassis as shown in Table 1?</p>	<p>YES</p> <p>Defective contact or disconnection in wiring harness between V04 (female) (1) and chassis ground</p> <p>Repair or replace</p>	<p>NO</p> <p>Short circuit with power source, defective contact, or disconnection in wiring harness between C01 (female) (9) - V04 (female) (2)</p> <p>Repair or replace</p>
	<p>NO</p> <p>Defective governor, pump controller</p> <p>Replace</p>		
	<p>NO</p> <p>Defective travel speed solenoid (internal disconnection or short circuit with power source)</p> <p>Replace</p>		

Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Voltage	Measurement condition
Between C01 (male) (10) - chassis	Between V04 (female) (2) - chassis	0 - 3V	Travel speed switch at Lo
		20 - 30V	Travel speed switch at Mi or Hi
			Operate the lever slightly not enough to move the machine

### C-13 Related electric circuit diagram



## C-14 [E217] Model selection input error is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




Table 1 Monitoring code display


Model code display	Model selection signal input display	
Monitoring codes 02, 03	Monitoring code 21	Monitoring code 22

- ★ The diagram shows monitoring code 02.
- ★ Check the bit pattern display marked with ←.

Table 2 Voltage of wiring harness

C17	Between (5) - chassis	Between (6) - chassis	Between (7) - chassis	Between (13) - chassis	Between (14) - chassis
Voltage	Max. 1 V	20 - 30 V	20 - 30 V	Max. 1 V	20 -30 V

C-14 Related electric circuit diagram



## C-15 [E222] Short circuit in LS-EPC solenoid system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p>Is resistance between C10 (male) (1) and (2), (1) and chassis as shown in Table 1?</p> <p>• Turn starting switch OFF. • Disconnect C10.</p> <p>YES 1</p> <p>Is resistance between C02 (female) (7) and (17), (7) and chassis as shown in Table 1?</p> <p>• Turn starting switch OFF. • Disconnect C02.</p> <p>NO</p> <p>2 YES</p>	<p>Defective governor, pump controller</p> <p>Short circuit with ground or short circuit with power source in wiring harness between C02 (female) (7) - C10 (female) (1), or short circuit with power source in wiring harness between C02 (female) (17) - C10 (female) (2)</p> <p>Defective LS-EPC solenoid (internal short circuit with ground or short circuit with power source)</p>	<p>Replace</p> <p>Repair or replace</p> <p>Replace</p>

Table 1

Troubleshooting No. 1	Troubleshooting No. 2	Resistance value
Between C10 (male) (1) - (2)	Between C02 (female) (7) - (17)	7 - 14 Ω
Between C10 (male) (1) - chassis	Between C02 (female) (7) - chassis	Min. 1 MΩ

### C-15 Related electric circuit diagram



BKP00251

## C-16 [E223] Disconnection in LS-EPC solenoid system displays


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<div style="display: flex; align-items: flex-start;"> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">                     Is resistance between C10 (male) (1) and (2), (2) and chassis as shown in Table 1?                      • Turn starting switch OFF.                      • Disconnect C10                 </div> <div style="margin-right: 10px;">                     YES 1                 </div> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">                     Is resistance between C02 (female) (7) and (17), (17) and chassis as shown in Table 1?                      • Turn starting switch OFF.                      • Disconnect C02.                 </div> <div style="margin-right: 10px;">                     YES 2                 </div> </div>	Defective governor, pump controller	Replace
	Defect contact or short circuit with chassis ground in wiring harness between C02 (female) (7) and C10 (female) (1), or defective contact, short circuit with ground, or disconnection in wiring harness between C02 (female) (17) - C10 (female) (2)	Repair or replace
	Defective LS-EPS solenoid (internal disconnection, defective contact, or short circuit with ground)	Replace

Table 1

Troubleshooting No. 1	Troubleshooting No. 2	Resistance value
Between C10 (male) (1) - (2)	Between C02 (female) (7) - (17)	7 - 14 Ω
Between C10 (male) (1) - chassis	Between C02 (female) (7) - chassis	Min. 1 MΩ

### C-16 Related electric circuit diagram



BKP00251

### C-17 [E224] Abnormality in pump pressure sensor system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
<p>Is voltage between C08 (2) and (1) normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• 18 - 28 V</li> </ul>	YES	Defective governor, pump controller	Replace
	NO	Short circuit with power source, defective contact, or disconnection in wiring harness between C03 (female) (3) - C08 (female) (3)	Repair or replace
	NO	Short circuit with ground, defective contact, or disconnection in wiring harness between C03 (female) (6) and C08 (female) (1)	Repair or replace
	NO	Short circuit with ground, defective contact, or disconnection in wiring harness between C03 (female) (6) and C08 (female) (2)	Repair or replace

<p>Is voltage between C03 (3) and (16) normal?</p> <ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Operate repeatedly arm IN relief ← lever NEUTRAL</li> <li>• 0.5 - 4.5 V</li> </ul>	YES		
NO	3	YES	
NO	NO		

#### C-17 Related electric circuit diagram






## C-19 [E226] Abnormality in pressure sensor power source system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p style="text-align: center;">2 YES</p> <p>Is voltage between C03 (6) and (16) normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• Disconnect C08.</li> <li>• 18 - 28 V</li> </ul>	<p>Defective front pump pressure sensor (internal short circuit or short circuit with ground)</p>	<p>Replace</p>
<p style="text-align: center;">NO</p> <p>Is resistance between C03 (female) (6) and (16), (6) (16) and chassis normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect C03, and C08.</li> <li>• Min. 1 MΩ</li> </ul>	<p>Defective governor, pump controller</p> <p>Short circuit or short circuit with ground in wiring harness of system where resistance value is defective</p>	<p>Replace</p> <p>Repair or replace</p>

### C-19 Related electric circuit diagram




## C-20 [E227] Abnormality in engine speed sensor system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p style="text-align: center;">2 YES</p> <p>Is resistance between C16 (female) (1) and (2) normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect C16.</li> <li>• 500 - 1000 Ω</li> </ul> <p style="text-align: center;">NO</p>	<p>Defective governor, pump controller</p> <p>Short circuit with ground, defective contact, or disconnection in wiring harness between C16 (female) (1) - E08 (10) - E07 (female) (2), or between C16 (female) (2) - E08 (9) - E07 (female) (1)</p> <p>Defective engine speed sensor (internal disconnection, defective contact, or short circuit with ground)</p>	<p>Replace</p> <p>Repair or replace</p> <p>Replace</p>
<p style="text-align: center;">1 YES</p> <p>Is resistance between E07 (male) (1) and (2) normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect E07.</li> <li>• 500 - 1000Ω</li> </ul> <p style="text-align: center;">NO</p>		

### C-20 Related electric circuit diagram



BKP00255




## TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER (INPUT SIGNAL SYSTEM) (F MODE)

Electrical circuit diagram for F mode .....	20-197
F- 1 Bit pattern 20- (1) Swing oil pressure switch does not light up .....	20-198
F- 2 Bit pattern 20-(2) Travel oil pressure switch does not light up .....	20-199
F- 3 Bit pattern 20-(3) boom LOWER oil pressure switch does not light up .....	20-200
F- 4 Bit pattern 20-(4) Boom RAISE oil pressure switch does not light up .....	20-201
F- 5 Bit pattern 20-(5) Arm IN oil pressure switch does not light up .....	20-202
F- 6 Bit pattern 20-(6) Arm OUT oil pressure switch does not light up .....	20-203
F- 7 Bit pattern 21-(1) Bucket CURL oil pressure switch does not light up .....	20-204
F- 8 Bit pattern 21-(2) Bucket DUMP oil pressure switch does not light up .....	20-205
F- 9 Bit pattern 21-(3) Swing lock switch does not light up .....	20-206
F- 10 Bit pattern 22-(5) Kerosene mode connection does not light up .....	20-207
F- 11 Bit pattern 22-(6) L.H. knob switch does not light up .....	20-208


# ELECTRICAL CIRCUIT DIAGRAM FOR F MODE 1/2

ELECTRICAL CIRCUIT DIAGRAM FOR F MODE 1/2



# ELECTRICAL CIRCUIT DIAGRAM FOR F MODE 2/2

ELECTRICAL CIRCUIT DIAGRAM FOR MODE F 2/2



ELEZMODEF (SHOP) ,PARE

# F-1 Bit pattern 20-(1) Swing oil pressure switch does not light up

★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ Turn the swing lock switch ON before operating the swing lever.

★ If there is no display when the lever is operated on one side, the PPC shuttle valve is defective. (See H-5) (When measuring with the engine stopped, charge the accumulator first.)

★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.


★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p>1</p> <p>Is voltage between C16 (5) and chassis normal?</p> <p>• Start engine. • Swing lever at neutral : 20 - 30 V • Swing lever operated : Max. 1V</p> <p>YES</p>	Defective governor, pump controller	Replace
<p>NO</p> <p>2</p> <p>Is resistance between S08 (male) (1) and (2) normal, and is circuit insulated from chassis?</p> <p>• Disconnect S08. • Start engine. • Swing lever at neutral: Min. 1 MΩ • Swing lever operated: Max. 1 Ω • See Note 1.</p> <p>YES</p> <p>3</p> <p>Is resistance between C16 (female) (5) and S08 (female) (2) normal, and is circuit insulated from chassis?</p> <p>• Turn starting switch OFF. • Disconnect C16 and S08. • Between C16 and S08: Max. 1 Ω • Between wiring harness and chassis: Min. 1 MΩ</p> <p>NO</p>	Defective contact or disconnection in wiring harness between S08 (female) (1) and chassis ground	Repair or replace
	Defective contact, short circuit with ground, or disconnection in wiring harness between C16 (female) (5) and S08 (female) (2)	Repair or replace
	Defective swing oil pressure switch (If the condition does not return to normal even when the switch is replaced, go the H-5.	Replace

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (5) and the chassis.

- If it is 20 - 30 V: Go to Yes
- If it is less than 1 V: Go to No

## F-1 Related electric circuit diagram



## F-2 Bit pattern 20-(2) Travel oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.
- ⚠ Before operating the travel lever, check that the surrounding area is safe.
- ★ If there is no display when the travel lever is operated on one side, the PPC shuttle valve is defective. (See H-5)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


	Cause	Remedy
<p><b>1</b></p> <p>Is voltage between C16 (13) and chassis normal?</p> <ul style="list-style-type: none"> <li>• Start engine.</li> <li>• Travel lever at neutral : 20-30 V</li> <li>• Travel lever operated : Max. 1 V</li> </ul>		
<p><b>2</b></p> <p>Is resistance between S01 (male) (1) and (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>• Disconnect S01</li> <li>• Start engine.</li> <li>• Travel lever at neutral : Min. 1MΩ</li> <li>• Travel lever operated : Max: 1 Ω</li> <li>• See Note 1.</li> </ul>		
<p><b>3</b></p> <p>Is resistance between C16 (female) (13) and S01 (female) (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect C16 and S01.</li> <li>• Between C16 and S01: Max. 1 Ω</li> <li>• Between wiring harness and chassis: Min. 1 M Ω</li> </ul>	<p>Defective governor, pump controller</p> <p>Defective contact, or disconnection in wiring harness between S01 (female) (1) and chassis ground</p> <p>Defective contact, short circuit with ground, or disconnection in wiring harness between C16 (female) (13) S01 (female) (2) and A27 (1) (2)</p> <p>Defective travel oil pressure switch (if the condition does not return to normal even when the switch is replaced, go to H-5.)</p>	<p>Replace</p> <p>Repair or replace</p> <p>Repair or replace</p> <p>Replace</p>

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (13) and the chassis.

- If it is 20 - 30 V: Go to YES
- If it is less than 1 V: Go to NO

### F-2 Related electric circuit diagram

Governor, pump controller





### F-3 Bit pattern 20-(3) Boom LOWER oil pressure switch does not light up

★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adpate, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubelshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p><b>1</b></p> <p>Is voltage between C17 (10) and chassis normal?</p> <ul style="list-style-type: none"> <li>• Start engine.</li> <li>• Boom lever at neutral: 20 - 30 V</li> <li>• Boom lever operated to LOWER: Max. 1V</li> </ul> <p>YES</p>	Defective governor, pump controller	Replace
<p><b>2</b></p> <p>Is resistance between S04 (male) (1) and (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>• Disconnect S04.</li> <li>• Start engine.</li> <li>• Boom lever at neutral: Min. 1 MΩ</li> <li>• Boom lever operated to LOWER: Max. 1 Ω</li> <li>• See Note 1.</li> </ul> <p>YES</p>	Defective contact, or disconnection in wiring harness between S04 (female) (1) and chassis ground	Repair or replace
<p><b>3</b></p> <p>Is resistance between C17 (female) (10) and S04 (female) (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect C17 and S04.</li> <li>• Between C17 and S04: Max. 1Ω</li> <li>• Between wiring harness and chassis : Min. 1 MΩ</li> </ul> <p>YES</p>	Defective contact, short circuit with ground, or disconnection in wiring harness between C17 (female) (10) - H13 (11) - S04 (female) (2)	Repair or replace
<p>NO</p>	Defective boom LOWER oil pressure switch (if the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (10) and the chassis.

- If it is 20 - 30 V: Go to YES
- If it is less than 1 V: Go to NO

#### F-3 Related electric circuit diagram



BKP00259

## F-4 Bit pattern 20-(4) Boom RAISE oil pressure switch does not light up

★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)

★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.


★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p>1</p> <p>Is voltage between C17 (2) and chassis normal?</p> <ul style="list-style-type: none"> <li>Start engine.</li> <li>Boom lever at neutral: 20 - 30V</li> <li>Boom lever operated to RAISE : Max. 1 V</li> </ul>	Defective governor, pump controller	Replace
<p>2</p> <p>Is resistance between S02 (male) (1) and (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>Disconnect S02.</li> <li>Start engine.</li> <li>Boom lever at neutral: Min. 1 MΩ</li> <li>Boom lever operated to RAISE : Max. 1 Ω</li> <li>See Note 1.</li> </ul>	Defective contact, or disconnection in wiring harness between S02 (female) (1) and chassis ground	Repair or replace
<p>3</p> <p>Is resistance between C17 (female) (2) and S02 (female) (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>Turn starting switch OFF.</li> <li>Disconnect C17 and S02.</li> <li>Between C17 and S02: Max. 1 Ω</li> <li>Between wiring harness and chassis : Min. 1 MΩ</li> </ul>	Defective contact, short circuit with ground, or disconnection in wiring harness between C17 (female) (2) - H13 (9) - S02 (female) (2)	Repair or replace
	Defective boom RAISE oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (2) and the chassis.

- If it is 20 - 30V : Go to YES
- If it is less than 1V: Go to NO

### F-4 Related electric circuit diagram



BKP00280

## F-5 Bit pattern 20-(5) Arm IN oil pressure switch does not light up


★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)

★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.


★ Always connect any disconnected connectors before going on the next step.



Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (3) and the chassis.

- If it is 20 - 30V: Go to YES
- If it is less than 1V: Go to NO

### F-5 Related electric circuit diagram



BKP00261

## F-6 Bit pattern 20-6 Arm Out oil pressure switch does not light up

★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)

★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.


★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p>1</p> <p>Is voltage between C17 (11) and chassis normal?</p> <ul style="list-style-type: none"> <li>Start engine.</li> <li>Arm lever at neutral: 20 - 30V</li> <li>Arm lever operated to OUT: Max. 1 V</li> </ul> <p>YES</p> <p>NO</p> <p>2</p> <p>Is resistance between S03 (male) (1) and (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>Disconnect S03.</li> <li>Start engine.</li> <li>Arm lever at neutral: Min. 1 MΩ</li> <li>arm lever operated to OUT: Max. 1 Ω</li> <li>See Note 1.</li> </ul> <p>YES</p> <p>NO</p> <p>3</p> <p>Is resistance between C17 (female) (11) and S03 (female) (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>Turn starting switch OFF/O</li> <li>Disconnect C17 and S03.</li> <li>Between C17 and S03: Max. 1 Ω</li> <li>Between wiring harness and chassis : Min. 1 MΩ</li> </ul>	Defective governor, pump controller	Replace
	Defective contact, or disconnection in wiring harness between S03 (female) (1) and chassis ground	Repair or replace
	Defective contact, short circuit with ground, or disconnection in wiring harness between C17 (female) (11) - H13 (12) - S03 (female) (2)	Repair or replace
	Defective arm OUT oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (11) and the chassis.

- If it is 20 - 30V: Go to YES
- If it is less than 1V: Go to NO

### F-6 Related electric circuit diagram



BKP00262

# F-7 Bit pattern 21-(1) Bucket CURL oil pressure switch does not light up

★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.



When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p><b>1</b> Is voltage between C16 (11) and chassis normal?</p> <ul style="list-style-type: none"> <li>• Start engine.</li> <li>• Bucket lever at neutral: 20 - 30V</li> <li>• Bucket lever operated to CURL: Max. 1 V</li> </ul> <p>YES</p> <p>NO</p>	Defective governor, pump controller	Replace
<p><b>2</b> Is resistance between S06 (male) (1) and (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>• Disconnect S06.</li> <li>• Start engine.</li> <li>• Bucket lever at neutral: Min. 1 MΩ</li> <li>• Bucket lever operated to CURL: Max. 1 Ω</li> <li>• See Note 1.</li> </ul> <p>YES</p> <p>NO</p>	Defective contact, or disconnection in wiring harness between S06 (female) (1) and chassis ground	Repair or replace
<p><b>3</b> Is resistance between C16 (female) (1) and S06 (female) (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect C16 and S06.</li> <li>• Between C16 and S06: Max. 1 Ω</li> <li>• Between wiring harness and chassis : Min. 1 MΩ</li> </ul> <p>YES</p> <p>NO</p>	Defective contact, short circuit with ground, or disconnection in wiring harness between C16 (female) (11) and S06 (female) (2)	Repair or replace
	Defective bucket CURL oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (11) and the chassis.

- If it is 20 - 30V: Go to YES
- If it is less than 1V: Go to NO

## F-7 Related electric circuit diagram



BKP00263

## F-8 Bit pattern 21-(2) Bucket DUMP oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.



When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p><b>1</b> Is voltage between C16 (12) and chassis normal?</p> <ul style="list-style-type: none"> <li>• Start engine.</li> <li>• Bucket lever at neutral: 20 - 30V</li> <li>• Bucket lever operated to DUMP: Max. 1 V</li> </ul>		
<p><b>2</b> Is resistance between S07 (male) (1) and (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>• Disconnect S07.</li> <li>• Start engine.</li> <li>• Bucket lever at neutral : Min. 1 MΩ</li> <li>• Bucket lever operated to DUMP: Max. 1 Ω</li> <li>• See Note 1.</li> </ul>		
<p><b>3</b> Is resistance between C16 (female) (12) and S07 (female) (2) normal, and is circuit insulated from chassis?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect C16 and S07.</li> <li>• Between C16 and S07: Max. 1 Ω</li> <li>• Between wiring harness and chassis: Min. 1 MΩ</li> </ul>	<p>Defective governor, pump controller</p> <p>Defective contact or disconnection in wiring harness between S07 (female) (2) and chassis ground</p> <p>Defective contact, short circuit with ground, or disconnection in wiring harness between C16 (female) (12) and S07 (female) (2)</p> <p>Defective bucket DUMP oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)</p>	<p>Replace</p> <p>Repair or replace</p> <p>Repair or replace</p> <p>Replace</p>

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (12) and the chassis.

- If it is 20 - 30V: Go to YES
- If it is less than 1V: Go to NO


### F-8 Related electric circuit diagram




BKP00264

## F-9 Bit pattern 21-(3) Swing lock switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.
- ★ If the panel display is normal. (If the swing lock lamp does not light up, go to M-21.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



### F-9 Related electric circuit diagram




## F-10 Bit pattern 22-(5) Kerosene mode connection does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy	
<p>1</p> <p>Is voltage between C17 (15) and chassis normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• M36 connector connected</li> <li>• Max. 1V</li> <li>• Open: 20 - 30V</li> </ul>	YES	Defective governor, pump controller	Replace	
	<p>2</p> <p>Is resistance between C17 (female) (15) and M36 (female) (1) normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect C17 and M36.</li> <li>• Max. 1 Ω</li> </ul>	YES	Defective contact, or disconnection in wiring harness between M36 (male) (1) and chassis ground	Repair or replace
		NO	Defective contact or disconnection in wiring harness between C17 (female) (15) and M36 (female) (1)	Repair or replace

### F-10 Related electric circuit diagram




BKP00266




## F-11 Bit pattern 22-(6) L.H. knob switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.
- ★ When fuse No. 5 is not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



### F-11 Related electric circuit diagram



# TROUBLESHOOTING OF HYDRAULIC, MECHANICAL SYSTEM (H MODE)

Table of failure modes and causes .....	20-210
All work equipment, travel, swing	
H- 1	Speeds of all work equipment, swing, travel are slow or lack power ..... 20-214
H- 2	There is excessive drop in engine speed, or engine stalls ..... 20-216
H- 3	No work equipment, travel, swing move ..... 20-217
H- 4	Abnormal noise generated (around pump) ..... 20-217
H- 5	Auto-deceleration does not work ..... 20-218
H- 6	Fine control ability is poor or response is poor ..... 20-218
Work equipment	
H- 7	Boom is slow or lacks power ..... 20-220
H- 8	Arm is slow or lacks power ..... 20-222
H- 9	Bucket is slow or lacks power ..... 20-224
H- 10	Work equipment (boom, arm, bucket) does not move ..... 20-225
H- 11	Excessive hydraulic drift (boom, arm, bucket) ..... 20-226
H- 12	Excessive time lag (engien at low idling) ..... 20-226
H- 13	Other equipment moves when single circuit is relieved ..... 20-226
H- 14	In F/O modes, work equipment speed is faster than set speed ..... 20-227
H- 15	Lack of power when pressure rises ..... 20-227
Compound operations	
H- 16	In compound operations, work equipment with larger load is slow ..... 20-227
H- 17	In swing + boom RAISE, boom RAISE is slow ..... 20-228
H- 18	In swing + arm, arm is slow ..... 20-228
H- 19	In swing + travel, travel speed drops excessively ..... 20-228
Travel system	
H- 20	Travel deviation ..... 20-229
H- 21	Travel speed is slow ..... 20-230
H- 22	Steering does not turn easily or lacks power ..... 20-232
H- 23	Travel speed doen not switch or is faster than set speed ..... 20-234
H- 24	Travel does not move (one side only) ..... 20-234
Swing system	
H- 25	Does not swing (both left and right, one direction only) ..... 20-235
H- 26	Swing acceleration is poor or swing speed is slow (both left and right, one direction only) ..... 20-236
H- 27	Excessive overrun when stopping swing (both left and right, one direction only) ..... 20-238
H- 28	Excessive shock when stopping swing (one direction only) ..... 20-239
H- 29	Excessive abnormal noise when stopping swing ..... 20-239
H- 30	Excessive hydraulic drift of swing (when brake is ON, when brake is OFF) ..... 20-240
H- 31	Swing speed is faster than specified speed ..... 20-241

TABLE OF FAILURE MODES AND CAUSES (1/2)

Failure mode		Parts causing failure		Piston pump								
				TVC valve	LS valve	Servo piston	Pump proper	Control pump	Strainer	Damper	Control valve	
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power			<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>				
	There is excessive drop in engine speed, or engine stalls			<input type="checkbox"/>		<input type="checkbox"/>						
	No work equipment, travel, swing move					<input type="checkbox"/>	<input type="checkbox"/>			<input type="checkbox"/>		
	Abnormal noise generated (around pump)					<input type="checkbox"/>		<input type="checkbox"/>				
	Auto-deceleration does not work											
	Fine control ability is poor or response is poor				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>					
Work equipment	Boom is slow or lacks power											<input type="checkbox"/>
	Arm is slow or lacks power											<input type="checkbox"/>
	Bucket is slow or lacks power											<input type="checkbox"/>
	Boom does not move											<input type="checkbox"/>
	Arm does not move											<input type="checkbox"/>
	Bucket does not move											<input type="checkbox"/>
	Excessive hydraulic drift											
	Excessive time lag (engine at low idling)											
	Other equipment moves when single circuit is relieved											
	In F/O modes, work equipment speed is faster than specified speed				<input type="checkbox"/>							
	Lack of power when pressure rises											
	Compound operations	In compound operations, work equipment with larger load is slow										
In swing + boom (RAISE), boom is slow												<input type="checkbox"/>
In swing +travel, travel speed drops excessively												
In work equipment boom raise + travel, travel speed drops excessively												
Travel system	Travel deviation	Deviation excessive during normal travel										<input type="checkbox"/>
		Deviation is excessive when starting										
	Travel speed is slow											<input type="checkbox"/>
	Steering does not turn or lacks power											
	Travel speed does not switch or is faster than specified speed											
Does not move ( one side only)												
Swing system	Does not swing	Both left and right										<input type="checkbox"/>
		One direction only										<input type="checkbox"/>
	Swing acceleration is poor or swing speed is slow	Both left and right										<input type="checkbox"/>
		One direction only										<input type="checkbox"/>
	Excessive overrun when stopping swing	Both left and right										<input type="checkbox"/>
		One direction only										<input type="checkbox"/>
	Excessive shock when stopping swing(one direction only)											
	Excessive abnormal noise when stopping swing											
Excessive hydraulic drift of swing	When brake ON											<input type="checkbox"/>
	When brake OFF											<input type="checkbox"/>
Swing speed is faster than specified swing speed				<input type="checkbox"/>								

★ In the failure modes, modes for compound operations are used when independent operations are normal

Control valve														Troubleshooting code
Main relief valve	Unload valve	Pressure compensation valve	LS circuit check valve	LS shuttle valve	LS select valve	LS circuit throttle	Arm counterbalance valve	Boom	Arm	Rege-neration valve	Safety-suction valve	Suction valve	LS bypass valve	
<input type="checkbox"/>	<input type="checkbox"/>												<input type="checkbox"/>	H-1
														H-2
														H-3
														H-4
														H-5
						<input type="checkbox"/>								H-6
								<input type="checkbox"/>				<input type="checkbox"/>		H-7
		<input type="checkbox"/>							<input type="checkbox"/>		<input type="checkbox"/>			H-8
		<input type="checkbox"/>	<input type="checkbox"/>								<input type="checkbox"/>			H-9
													<input type="checkbox"/>	H-10
													<input type="checkbox"/>	
													<input type="checkbox"/>	
		<input type="checkbox"/>							<input type="checkbox"/>		<input type="checkbox"/>			H-11
		<input type="checkbox"/>						<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>			H-12
		<input type="checkbox"/>												H-13
<input type="checkbox"/>														H-14
														H-15
														H-16
					<input type="checkbox"/>								<input type="checkbox"/>	H-17
					<input type="checkbox"/>								<input type="checkbox"/>	H-18
												<input type="checkbox"/>		H-19
		<input type="checkbox"/>										<input type="checkbox"/>	<input type="checkbox"/>	H-20
		<input type="checkbox"/>		<input type="checkbox"/>							<input type="checkbox"/>	<input type="checkbox"/>		H-21
		<input type="checkbox"/>	<input type="checkbox"/>								<input type="checkbox"/>	<input type="checkbox"/>		H-22
											<input type="checkbox"/>			H-23
														H-24
														H-25
												<input type="checkbox"/>		
		<input type="checkbox"/>	<input type="checkbox"/>						<input type="checkbox"/>		<input type="checkbox"/>			H-26
													<input type="checkbox"/>	H-27
												<input type="checkbox"/>		
												<input type="checkbox"/>		H-28
													<input type="checkbox"/>	H-29
		<input type="checkbox"/>												H-30
														H-31

TABLE OF FAILURE MODES AND CAUSES (2/2)


Failure mode	Parts causing failure		Solenoid valve					Swing motor
	LS-EPC	LS bypass	2-stage relief	Swing holding brake	Travel speed selector	Safety-suction valve	Leakage, breakage inside body	
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power		○	○				
	There is excessive drop in engine speed, or engine stalls							
	No work equipment, travel, swing move							
	Abnormal noise generated (around pump)							
	Auto-deceleration does not work							
	Fine control ability is poor or response is poor							
Work equipment	Boom is slow or lacks power							
	Arm is slow or lacks power							
	Bucket os slow or lacks power							
	Boom does not move							
	Arm does not move							
	Bucket does not move							
	Excessive hydraulic drift							
	Escessive time lag (engine at low idling)		○					
	Other equipment moves when single circuit is relieved							
	In F/O modes, work equipment speed is faster than specified speed		○					
Compound operations	Lack of power when pressure rises				○			
	In compound operations, work equipment with larger load is slow							
	In swing + boom (RAISE), boom is slow							
	In swing + travel. Travel speed drops excessively				○			
Travel system	In work equipment boom raise + travel, travel speed drops excessively				○			
	Travel deviation	Deviation excessive during normal travel						
		Deviation is excessive when starting						
	Travel speed is slow		○	○				
	Steering does not turn or lacks power						○	
	Travel speed does not switch or is faster than specified speed		○				○	
Does not move ( one side only)								
Swing system	Does not swing	Both left and right						○
		One direction only						○
	Swing acceleration is poor or swing speed is slow	Both left and right		○				○
		One direction only						○
	Excessive overrun when stopping swing	Both left and right						○
		One direction only						○
	Excessive shock when stopping swing(one direction only)							
	Excessive abnormal noise when stopping swing							○
Excessive hydraulic drift of swing	When brake ON				○			
	When brake OFF						○ ○	
Swing speed is faster than specified swing speed		○						

★ In the failure modes, modes for compound operations are used when independent operations are normal



# H-1 Speeds of all work equipment, swing, travel are slow or lack power

- ★ Carry out troubleshooting in the H/O mode.
- ★ Check that no abnormal noise is being generated from the main pump before carrying out troubleshooting. (If there is any abnormal noise, carry out troubleshooting for H-4.)




	<b>Cause</b>	<b>Remedy</b>
	Defective piston pump assy.	Replace
	Defective operation of LS control EPC solenoid valve	Replace
	Defective operation of unload valve	Repair or replace
	Defective operation of main relief valve	Replace
	Defective operation of LS bypass valve	Replace
	Defective operation of LS bypass solenoid valve	Replace
	Defective hydraulic equipment in control pump circuit (See TESTING AND ADJUSTING)	Adjust or replace



## H-2 There is excessive drop in engine speed, or engine stalls


- ★ Carry out troubleshooting in the H/O mode.
- ★ Check that the main relief pressure is normal.




\* Engine speed (reference) at arm IN relief when engine and pump are normal

Engine speed at arm IN relief	Conditions
2.100 ± 100rpm	<ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Power max.mode</li> <li>• Swing lock switch ON</li> <li>• Measure the speed at the point where the drop in engine speed is greatest when the arm cylinder is at the end of stroke and the lever is operated slowly to the full position.</li> </ul>

### H-3 No work equipment, travel, swing move



### H-4 Abnormal noise generated (around pump)



### H-5 Auto-deceleration does not work (when PPC shuttle valve is cause)

★ The control pressure for the travel and swing passes through the PPC shuttle valve and is supplied to the pressure switch.

		Cause	Remedy
Does condition become normal when pressure switch is replaced?	1 YES	Defective pressure switch	Replace
	NO	Defective operation of PPC shuttle valve in applicable system (swing or travel)	Repair or replace


### H-6 Fine control ability is poor or response is poor

		Cause	Remedy
Is throttle in LS circuit clogged?	1 YES	Cloggd throttle in LS circuit	Clean
	NO	Defective servo valve assembly (LS valve), or defective servo piston	Replace




## H-7 Boom is slow or lacks power

- ★ When travel and swing speeds are normal.
- ★ Carry out troubleshooting in the H/O mode.



Note 1: If auto-deceleration is canceled when boom RAISE or boom LOWER is operated, system is normal.


Note 2: After inspection, do not forget to return the interchanged valves to the original position.



Cause	Remedy
Defective operation of boom lock valve	Correct or replace
Defective boom cylinder piston packing	Correct or replace
Defective operation of LS shuttle valve (LS shuttle for arm or bucket)	Correct or replace
Defective boom lock valve or suction valve for boom in control valve	Replace
Defective operation of boom lock valve	Correct or replace
Defective operation of boom regeneration valve	Correct or replace
Defective operation of boom pressure compensation valve or pressure compensation piston (for boom RAISE end)	Correct or replace
Defective operation of control valve spool (for boom RAISE end)	Correct or replace
Defective PPC valve	Replace
Defective boom RAISE or boom LOWER pressure switch	Replace

## H-8 Arm is slow or lacks power

- ★ When travel and swing speeds are normal.
- ★ Carry out troubleshooting in the H/O mode.



Note 1: If the auto-declaration is canceled when arm IN or arm OUT is operated, the system is normal.


Note 2: After inspection, do not forget to return the interchanged valves to the original position.

	Cause	Remedy
<p>7 YES</p> <p>Is leakage from arm cylinder normal?</p> <ul style="list-style-type: none"> <li>• Max. 20 cc/min</li> <li>• Engine at high idling</li> </ul>	Defective operation of arm regeneration valve or arm counterbalance valve.	Correct or replace
<p>NO</p>	Defective arm cylinder piston packing	Correct or replace
	Defective operation of LS shuttle valve (LS shuttle for bucket)	Correct or replace
	Defective safety-suction valve for arm	Replace
	Defective operation of arm pressure compensation valve or pressure compensation piston	Correct or replace
	Defective operation of control valve spool	Correct or replace
	Defective PPC valve	Replace
	Defective arm IN or arm OUT pressure switch	Replace



# H-9 Bucket is slow or lacks power

★ When travel and swing speeds are normal.



Note 1: If the auto-deceleration is canceled when bucket CURL or bucket DUMP is operated, the system is normal.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

## H-10 Work equipment (boom, arm, bucket) does not move (but travel and swing are normal)

★ When boom, arm, and bucket are each operated independently.

		Cause	Remedy
<p>1 YES</p> <p>Is output pressure of PPC valve normal?</p> <ul style="list-style-type: none"> <li>• Min. 2.7 MPa (28 kg/cm<sup>2</sup>)</li> <li>• Engine at high idling</li> </ul>	YES	Defective control valve spool	Correct or replace
	NO	Defective PPC valve	Replace

## H-11 Excessive hydraulic drift (boom, arm, bucket)

### 1) Excessive hydraulic drift of boom

		Cause	Remedy	
<p>1 YES</p> <p>Does speed of downward movement become faster when lever is operated?</p> <ul style="list-style-type: none"> <li>• See TESTING AND ADJUSTING.</li> <li>• It is also possible to measure leakage of cylinder.</li> <li>• Max. 20 cc/min</li> <li>• At relief</li> <li>• Engine at high idling</li> </ul>	YES	Defective hydraulic cylinder piston packing	Replace	
	NO	2 YES	Defective operation of safety-suction valve	Replace
	NO	NO	Defective operation of boom lock valve	Correct or replace


### 2) Excessive hydraulic drift of arm or bucket

		Cause	Remedy	
<p>1 YES</p> <p>Does speed of downward movement become faster when lever is operated?</p> <ul style="list-style-type: none"> <li>• See TESTING AND ADJUSTING.</li> <li>• It is also possible to measure leakage of cylinder.</li> <li>• Max. 20 cc/min</li> <li>• At relief</li> <li>• Engine at high idling</li> </ul>	YES	Defective hydraulic cylinder piston packing	Replace	
	NO	2 YES	Defective operation of safety-suction valve	Replace
	NO	3 YES	Defective control valve spool	Replace
	NO	NO	Damaged slipper seal of pressure compensation valve, or defective operation of pressure compensation piston	Correct or replace

• It is also possible to interchange with other compensation valve.  
 • See Note 1.

Note 1: After inspection, do not forget to return the interchanged valves to the original position.

### H-12 Excessive time lag (engine at low idling)




Note 1: Output pressure of LS-EPC solenoid

- Approx 2.5 MPa (Approx 26 kg/cm<sup>2</sup>) is output from the LS-EPC solenoid when the engine is at low idling (approx. 1100 rpm or below) regardless of the working mode.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

### H-13 Other equipment moves when single circuit is relieved



### H-14 In F/O modes, work equipment speed is faster than specified speed

		Cause	Remedy
Is output pressure of LS-EPC solenoid valve normal? • See Note 1.	1 YES	Defective LS valve	Correct or replace
	NO	Defective operation of LS-EPC solenoid valve	Correct or replace

★ Output pressure of LS control EPC solenoid (travel OFF)  
 Approx 2.5 MPa (Approx 26 kg/cm<sup>2</sup>) is output from the LS control EPC solenoid when the engine speed is approx. 1100 rmp or less in the F/O mode. (In the F/O mode, the engine speed is set at 1900 rpm when the fuel control dial is at the MAX position.)

### H-15 Lack of power when pressure rises

		Cause	Remedy
Is oil pressure switch normal? • Operate each control lever, and if auto-deceleration is canceled, condition is normal.	1 YES	Defective main relief valve	Replace
	2 YES	Defective operation of 2-stage relief solenoid valve	Repair or replace
	NO	Defective oil pressure switch	Replace

Is output pressure of 2-stage relief solenoid valve normal?  
 • Min 2.7 Mpa (28 kg/cm<sup>2</sup>) NO  
 • H/O or G/O mode  
 • Power max. mode  
 • L.H. knob switch ON  
 • Arm IN relief

### H-16 In compound operations, work equipment with larger load is slow

Cause	Remedy
Defective operation of pressure compensation valve	Replace (replace pressure compensation valve on side where load is lower)

	Combination of compound operation	Side where load is larger
1	Boom RAISE + arm IN	Boom RAISE
2	Boom RAISE + arm OUT	Arm OUT
3	Boom RAISE + bucket CURL	Boom RAISE
4	Arm OUT + bucket CURL	Arm OUT
5	Boom LOWER + arm OUT	Arm OUT

### H-17 In swing + boom RAISE, boom RAISE is slow

★ If swing and boom RAISE work normally when operated independently.

		Cause	Remedy
<p>1 YES</p> <p>Is output pressure of LS select solenoid valve normal?</p> <ul style="list-style-type: none"> <li>• Min. 2.7 MPa (28 kg/cm<sup>2</sup>)</li> <li>• Operate boom RAISE (operate lever slightly)</li> </ul>	YES	Defective operation of LS select valve	Correct or replace
	NO	Defective operation of PPC shuttle valve for LS select circuit	Correct or replace

### H-18 In swing + travel, travel speed drops excessively

★ If swing and travel work normally when operated independently.

		Cause	Remedy		
<p>1 YES</p> <p>Is pressure of LS bypass solenoid valve circuit normal?</p> <ul style="list-style-type: none"> <li>• 0.2 ± 0.2 MPa (2 ± 2 kg/cm<sup>2</sup>)</li> <li>• Engine at high idling</li> <li>• Operate swing and travel simultaneously.</li> </ul>	YES	Does LS bypass valve move smoothly?			
	YES	2 YES <p>Is pressure of LS select valve circuit normal?</p> <ul style="list-style-type: none"> <li>• Min. 2.7 MPa (28 kg/cm<sup>2</sup>)</li> <li>• Engine at high idling</li> <li>• Operate travel lever fully.</li> </ul>	3 YES	Defective operation of LS select valve	Repair or replace
	NO	NO	Defective operation of PPC shuttle valve (PPC shuttle for LS select)	Repair or replace	
	NO	NO	Defective operation of LS bypass valve	Repair or replace	
	NO	Defective operation of LS bypass solenoid valve	Repair or replace		

### H-19 In work equipment boom RAISE + travel, travel speed drops excessively


★ If work equipment (boom RAISE) and travel work normally when operated independently.

		Cause	Remedy
<p>1 YES</p> <p>Is pressure of LS bypass solenoid valve circuit normal?</p> <ul style="list-style-type: none"> <li>• 0.2 ± 0.2 MPa (2 ± 2kg/cm<sup>2</sup>)</li> <li>• Engine at high idling</li> <li>• Operate boom RAISE and travel simultaneously.</li> </ul>	YES	Defective operation of LS bypass valve	Repair or replace
	NO	Defective operation of LS bypass solenoid valve	Repair or replace

## H-20 Travel deviation

- ★ Carry out troubleshooting in the H/O mode.
- ★ When swing and work equipment speeds are normal.

### a) When there is deviation in normal travel




Note 1: Remove the PPC shuttle block inlet hose, fit an adapter, and block the tip, If the adapter for blocking the circuit is not available, interchange the travel PPC hoses with the PPC hoses for the bucket (CURL, DUMP), boom (LOWER), or arm (IN) at both the inlet and outlet ports of the shuttle block, and check operation.

### b) Excessive travel deviation when starting

Cause	Remedy
Defective operation of travel counterbalance valve	Correct or replace
Defective operation of travel parking brake (mechanical brake)	Correct or replace.

# H-21 Travel speed is slow

- ★ Check that the spool of the travel PPC valve is moving the full stroke before carrying out troubleshooting.
- ★ Carry out troubleshooting in the H/O mode.
- ★ When swing and work equipment speeds are normal.



Note 1: • Measure the travel speed under no load or measure the time taken to travel 20 m. (See MAINTENANCE STANDARD FOR CHASSIS RELATED PARTS.)  
 • When measuring the speed of the travel motor under no load → Remove connector of LS control EPC solenoid, and measure travel speed in Lo and Hi.

Note 2: Output pressure of LS-EPC solenoid

unit: MPa (kg/cm<sup>2</sup>)

Lo	Mi	Hi
2.0 ± 0.2 (20.0 ± 2.0)	2.2 ± 0.2 (22.7 ± 2.0)	0.2 ± 0.2 (2.0 ± 2.0)
• Engine at high idle. • Travel lever at time control position (auto-deceleration canceled)		

		Cause	Remedy
<p>3</p> <p>Is output pressure of LS bypass solenoid valve normal?</p> <ul style="list-style-type: none"> <li>• Travel operated independently.</li> <li>• 2.9 ± 0.5 MPa (30 ± 5kg/cm<sup>2</sup>)</li> <li>• Engine at high idling</li> </ul>	YES		
	<p>4 YES</p> <p>Does LS bypass valve move smoothly?</p>	Defective operation of LS shuttle valve (for boom, arm, bucket)	Repair or replace
		Defective operation of LS bypass valve	Repair or replace
	NO	Defective operation of LS bypass solenoid valve	Replace
		Defective operation of LS-EPC solenoid valve	Correct or replace
		Defective travel pressure switch	Replace
<p>9</p> <p>Does condition become normal when travel suction valve for control valve is replaced?</p> <ul style="list-style-type: none"> <li>• See Note 1.</li> </ul>	YES		
	NO	Defective operation of travel suction valve for control valve	Correct or replace
		Defective travel motor assembly	Correct or replace
		Defective pressure compensation valve, or defective operation of pressure compensation piston	Correct or replace
		Defective operation of travel spool for control valve	Correct or replace
		Defective operation of junction valve	Correct or replace
		Defective PPC shuttle	Correct or relace
		Defective PPC valve	Replace

Note 3: After inspection, do not forget to return the interchanged valves to the original position.


Note 4: Remove the PPC shuttle block inlet hose, fit an adapter, and block the tip.

If the adapter for blocking the circuit is not available, interchange the travel PPC hoses with the PPC hoses for the bucket (CURL, DUMP), boom (LOWER), or arm (IN) at both the inlet and outlet ports of the shuttle block, and check operation.



# H-22 Steering does not turn easily or lacks power

★ Carry out troubleshooting in the H/O mode.



		Cause	Remedy
		Go to H-13	-
5 YES Does LS bypass solenoid valve move smoothly? NO		Defective operation of LS shuttle valve (any one of boom, arm, or bucket)	Repair or replace
		Defective operation of LS bypass valve	Repair or replace
		Defective operation of LS bypass solenoid valve	Repair or replace
7 YES Is output pressure of travel speed solenoid valve normal? NO		Defective travel motor servo piston or center swivel joint	Repair or replace
		Defective operation of travel speed solenoid valve	Repair or replace
		Defective operation of travel junction valve	Repair or replace
		Defective operation of pressure compensation valve or pressure compensation valve piston	Repair or replace
		Defective operation of suction valve of control valve	Repair or replace
		Defective travel motor check valve	Replace
		Defective travel motor safety valve	Replace
		Defective travel oil pressure switch	Replace

## H-23 Travel speed does not switch or is faster than specified speed

★ Carry out troubleshooting in the H/O mode.





Table 1. Output pressure of LS-EPC solenoid

Unit: MPa (kg/cm<sup>2</sup>)


Travel speed	Lo	Mi	Hi
LS-EPC output pressure	2.0 ± 0.2 (20.0 ± 2.0)	2.2 ± 0.2 (22.7 ± 2.0)	0.2 ± 0.2 (2.0 ± 2.0)
Remarks	<ul style="list-style-type: none"> <li>• Engine at high idling</li> <li>• Operate travel lever slightly (auto-deceleration cancel position)</li> </ul>		

## H-24 Travel does not move (one side only)




# H-25 Does not swing

## a) Does not swing to either left or right




## b) Does not swing in one direction



# H-26 Swing acceleration is poor or swing speed is slow

- ★ Carry out troubleshooting in the H/O mode.
- ★ If condition is normal when work equipment is operated independently.

## a) Swing acceleration is poor




Note: If the adapter for blocking the circuit is not available, interchange PPC hose of swing with one of bucket (CURL, DUMP), boom (LOWER), or arm (IN).

		Cause	Remedy
		Defective swing motor assembly	Repair or replace
		Defective LS bypass valve	Replace
		Defective LS bypass solenoid valve	Replace
		Defective operation of LS shuttle valve (all LS shuttles)	Repair or replace
<p>9 YES</p> <p>Does condition become normal when left and right safety valves of motor are interchanged?</p>		Defective swing motor safety valve	Replace
<p>* It is also possible to NO measure relief pressure of motor.</p> <p>• Relief pressure: 30,4 - 33.8 MPa (310 - 345 kg/cm<sup>2</sup>)</p>		Defective swing motor suction valve	Replace
		Defective operation of pressure compensation valve or compensation valve piston	Repair or replace
		Defective operation of control valve spool	Repair or replace
		Defective operation of PPC shuttle valve (for swing)	Repair or replace
		Defective PPC valve	Replace

# H-27 Excessive overrun when stopping swing


## a) One direction only




## b) Both directions

Cause	Remedy
Defective swing motor	Repair or replace

### H-28 Excessive shock when stopping swing (one direction only)




### H-29 Excessive abnormal noise when stopping swing






# H-30 Excessive hydraulic drift of swing

## a) When swing holding brake is released



## b) When swing holding brake is applied



## H-31 Swing speed is faster than specified swing speed




Table 1. Output pressure of LS-EPC solenoid valve

unit: MPa (kg/cm<sup>2</sup>)

H/O mode	G/O mode	F/O mode	L/O mode
0.2 ± 0.2 (2.0 ± 2.0)	0.2 ± 0.2 (2.0 ± 2.0)	1.2 ± 0.2 (12 ± 2.0)	0.2 ± 0.2 (2.0 ± 2.0)
• Enginge at high idling • Travel OFF • Swing lock switch OFF			



# TROUBLESHOOTING OF MACHINE MONITOR SYSTEM (M MODE)

Action taken by panel and condition of machine when abnormality occurs .....	20-244
Electrical circuit diagram for monitor system .....	20-246
M- 1 [E101] Abnormality in error data is displayed [E102] Error in clock data is displayed .....	20-248
M- 2 [E103] Short circuit in buzzer output or contact of 24V wiring harness with buzzer drive harness is displayed .....	20-249
M- 3 [E104] Air cleaner clogging detected is displayed .....	20-250
M- 4 [E106] Drop in engine oil pressure Hi detected is displayed .....	20-250
M- 5 [E108] Engine water temperature 105°C detected is displayed .....	20-251
M- 6 When starting switch is turned ON, none of lamps on monitor panel light up for 3 seconds ...	20-252
M- 7 When starting switch is turned ON, monitor panel lamps all stay lighted up and do not go out .....	20-254
M- 8 When starting switch is turned ON, items lighted up on monitor panel are different from actual machine (model) .....	20-254
M- 9 When starting switch is turned ON (engine stopped), basic check items flash .....	20-255
M- 10 Preheating is not being used but preheating monitor lights up .....	20-257
M- 11 When starting switch is turned ON and engine is started, basic check items flash .....	20-258
M- 12 When starting switch is turned ON (engine stopped), caution items, emergency stop items flash .....	20-260
M- 13 When starting switch is turned ON and engine is started, caution items, emergency stop items flash .....	20-262
M- 14 When starting switch is turned ON (engine stopped), buzzer does not sound for 1 second Caution item flashes but buzzer does not sound .....	20-265
M- 15 No abnormality is displayed on monitor but buzzer sounds .....	20-265
M- 16 Night lighting on monitor panel does not light up (liquid crystal display is normal) .....	20-266
M- 17 Coolant temperature gauge does not rise .....	20-267
M- 18 Coolant temperature gauge does not give any display .....	20-267
M- 19 Fuel level gauge always displays FULL .....	20-268
M- 20 Fuel level gauge does not give any display .....	20-268
M- 21 Swing lock switch is turned ON (LOCK) but swing lock monitor does not light up .....	20-269
M- 22 Swing prolix switch is turned ON (prolix), but swing lock monitor does not flash .....	20-269
M- 23 Service meter does not advance while engine is running .....	20-270
M- 24 When starting switch is at OFF and time switch is pressed, time and service meter are not displayed .....	20-270
M- 25 Defective fuel level sensor system .....	20-271
M- 26 Defective coolant temperature sensor system .....	20-272
M- 27 Defective engine oil level sensor system .....	20-273
M- 28 Defective coolant level sensor system .....	20-274
M- 30 Wiper does not work or switch is not being used but wiper is actuated .....	20-275


## ACTION TAKEN BY MONITOR PANEL WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

User code	Service code	Abnormal system	Nature of abnormality
-	E101	Abnormality in error data	<ol style="list-style-type: none"> <li>1. Abnormality in internal memory</li> <li>2. Excess voltage (more than 36V) has occurred</li> <li>3. Low voltage (less than 12V) has occurred</li> <li>4. Connector has separated</li> </ol>
-	E102	Abnormality in clock data	<ol style="list-style-type: none"> <li>1. Abnormality in internal clock function</li> <li>2. Excess voltage (more than 36V) has occurred</li> <li>3. Low voltage (less than 12V) has occurred</li> <li>4. Connector has separated</li> </ol>
-	E103	Short circuit in buzzer output system	<ol style="list-style-type: none"> <li>1. Short circuit inside buzzer</li> <li>2. Power line in contact with wiring harness between monitor (P01 (7) pin) and buzzer</li> <li>3. Abnormality in monitor panel</li> </ol>
-	E104	Air cleaner clogging detected is displayed	<ol style="list-style-type: none"> <li>1. Air cleaner clogging sensor has detected clogging</li> </ol>
-	E106	Drop in engine oil Hi pressure detected is displayed	<ol style="list-style-type: none"> <li>1. Engine oil pressure Hi sensor has detected drop in oil pressure</li> </ol>
-	E108	Engine water temperature 105°C detected is displayed	<ol style="list-style-type: none"> <li>1. Coolant temperature gauge has detected water temperature of 105°C</li> </ol>

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
<ul style="list-style-type: none"> <li>When starting switch is turned ON, keep time switch pressed for 5 seconds to actuated clear function</li> </ul>	-	<ol style="list-style-type: none"> <li>Service code cannot be cleared</li> <li>Time becomes 00:00</li> </ol>
	-	<ol style="list-style-type: none"> <li>Service code cannot be cleared</li> <li>Time becomes 00:00</li> <li>Clock does not advance.</li> </ol>
<ul style="list-style-type: none"> <li>Voltage between P01 (7) - chassis Buzzer On: Max. 1V Buzzer OFF: 20 - 30V</li> <li>★ When there is a disconnection, E103 is not displayed and the buzzer does not sound</li> </ul>	-	<ol style="list-style-type: none"> <li>Buzzer does not sound</li> </ol>
<ul style="list-style-type: none"> <li>Resistance between P11 (male) - P12 (male): Min 1Ω (engine started)</li> </ul>	-	<ol style="list-style-type: none"> <li>If abnormality detection continues, air cleaner clogging caution lamp flashes and buzzer sounds</li> </ol>
<ul style="list-style-type: none"> <li>Resistance between sensor terminal and chassis: Min. 1 MΩ (engine at mid-range speed or above)</li> </ul>	-	<ol style="list-style-type: none"> <li>If abnormality detection continues, engine oil pressure caution lamp flashes and buzzer sounds</li> </ol>
<ul style="list-style-type: none"> <li>Resistance between P07 (1) - (2): Min. 3.156 Ω (engine started)</li> </ul>	-	<ol style="list-style-type: none"> <li>If abnormality detection continues, coolant temperature caution lamp flashes and buzzer sounds</li> <li>If abnormality detection continues, engine speed is reduced to low idling</li> </ol>


# ELECTRICAL CIRCUIT DIAGRAM FOR M MODE 1/2

ELECTRICAL CIRCUIT DIAGRAM FOR M MODE



ELE (MODE) (SHOP), FARE

# ELECTRICAL CIRCUIT DIAGRAM FOR M MODE 2/2



ELECTRICAL CIRCUIT DIAGRAM FOR M MODE 2/2

ELEZMODEM(SHOP),PARE




# M-1 [E101] Abnormality in error data is displayed [E102] Error in clock data is displayed

- ★ This is not an abnormality. It occurs during troubleshooting when disconnecting and connecting connector P02 (for the monitor panel electrical system), fuse No. 13, connector M14, connector M11, battery relay terminal B, or the battery terminal.  
(When the monitor panel power source circuit is shut off with the starting switch turned OFF.)
- ★ If the service code display appears again after the system has been reset, carry out troubleshooting as follows.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p>1</p> <p>Does service code display appear again after system has been reset?</p> <p>YES</p> <p>2</p> <p>Is voltage between P02 (8) (14) and chassis normal?</p> <p>• Turn starting switch OFF.</p> <p>• 20 - 30 V</p> <p>NO</p> <p>NO</p> <p>• After resetting system, carry out normal operations for a short time and wanted the condition. (See Note 1.)</p>	Defective monitor panel	Replace
	Disconnect, defective contact, short circuit with ground in wiring harness between battery - battery relay B - M11 (1) (2) - H14 (1) - fuse No. 13 - P02 (female) (8) (14)	Repair or replace
	Normal	-

Note 1: Resetting operation:  
Turn the starting switch OFF. Then keep the time switch at the back of the monitor panel depressed, switch the starting switch ON again, and keep the time switch depressed for 5 seconds to return the system to normal.  
(With this operation, all the service codes in the internal memory are erased.)

### M-1 Related electric circuit diagram



## M-2 [E103] Short circuit in buzzer output or contact of 24 V wiring harness with buzzer drive harness is displayed


- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the system has been reset.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

	Cause	Remedy
<p style="text-align: center;">2 YES</p> <p style="text-align: center;">NO</p> <p style="text-align: center;">1 YES</p> <p style="text-align: center;">NO</p> <p>Is resistance between P04 (male) (1) - (2), (2) - chassis as shown in the table?</p> <ul style="list-style-type: none"> <li>• Turn starting switch OFF.</li> <li>• Disconnect P04.</li> </ul> <p>Is voltage between P04 (2) and chassis normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• Buzzer ON: Max. 1 V</li> <li>• Buzzer OFF: 20 - 30 V</li> </ul>	<p>Defective monitor panel</p> <p>Short circuit with power source in wiring harness between P01 (female) (7) and P04 (female) (2) or short circuit in wiring harness between P04 (1) and (2)</p> <p>Defective buzzer</p>	<p>Replace</p> <p>Repair or replace</p> <p>Replace</p>

Table

P04 (male)	Resistance value
Between (1) and (2)	200 - 300 Ω
Between (2) and chassis	Min. 1 M Ω

### M-2 Related electric circuit diagram



### M-3 [E104] Air clogging detected is displayed

		Cause	Remedy
<p>1</p> <p>Is air cleaner clogging caution lamp on monitor flashing?</p> <p>YES</p> <p>NO</p> <p>2</p> <p>Is "E" service code displayed?</p> <p>YES</p> <p>NO</p> <p>• Turn starting switch ON.</p>	YES	(See M-13 f)	-
	YES	Defective monitor panel	Replace
	NO	Failure in engine system (See Note 1)	-


Note 1: The monitor panel display has returned to normal, but the air cleaner clogging sensor has detected symptoms of clogging in the past, so carry out troubleshooting of the engine to remove the problem

### M-4 [E106] Drop in engine oil pressure detected is displayed

		Cause	Remedy
<p>1</p> <p>Is engine oil pressure caution lamp on monitor flashing?</p> <p>YES</p> <p>NO</p> <p>2</p> <p>Is "E" service code displayed?</p> <p>YES</p> <p>NO</p> <p>• Turn starting switch ON.</p>	YES	(See M-13 a)	-
	YES	Defective monitor panel	Replace
	NO	Failure in engine system (See Note 1)	-

Note 1: The monitor panel display has returned to normal, but the engine oil pressure sensor has detected symptoms of a drop in the oil pressure in the past, so carry out troubleshooting of the engine to remove the problem.

### M-5 [E108] Engine water temperature 105°C detected is displayed




Note 1: The monitor panel display has returned to normal, but the coolant temperature sensor has detected symptoms of the coolant temperature reaching 105°C in the past, so carry out troubleshooting of the engine to remove the problem.

## M-6 When starting switch is turned ON, none of the lamps on the monitor panel light up for 3 seconds

- ★ Check that fuses No. 10 and 13 are not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


### a) None of lamps on monitor panel light up



### b) Some of lamps on monitor panel do not light up

Cause	Remedy
Defective monitor panel	Replace

M-6 a) Related electric circuit diagram



BKP00274

**M-7 When starting switch is turned ON, monitor panel lamps all stay lighted up and do not go out**


	Cause	Remedy
	Defective monitor panel	Replace

**M-8 When starting switch is turned ON, items lighted up on monitor panel are different from actual machine (model)**

★ Immediately after replacing the monitor panel, turn the starting switch OFF, then turn it On again

	Cause	Remedy
<p>1 YES</p> <p>Is display of monitoring code 01 as shown in table?</p> <p>• Turn starting switch ON. • Set to monitoring code 01.</p>	Defective monitor panel	Replace
<p>NO</p>	Go to troubleshooting for C mode (See C-14)	

Table




## M-9 When starting switch is turned ON (engine stopped), basic check items flashes

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

### a) (coolant level) flashes


- ★ Check that the coolant is at the specified level before carrying out troubleshooting.



Table

Short connector	Continuity
Connected	Yes
Disconnected	No

### M-9 a) Related electric circuit diagram




BKP00277



b)  (coolant level) flashes

SAP00523


★ Chek that the engine oil is at the specified level before carrying out troubleshooting.



Table

Chassis ground	Continuity
Connected	Yes
Disconnected	No

M-9 b) Related electric circuit diagram




# M-10 Preheating is not being used but (preheating monitor) lights up

SAP0052C

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
<p>Is voltage between starting switch terminal R1 and chassis normal?</p> <p>1 YES</p> <p>2 YES</p> <p>NO</p> <p>NO</p>	<p>Is voltage between P01 (18) and chassis normal?</p> <ul style="list-style-type: none"> <li>• Turn starting switch ON.</li> <li>• Max. 1 V</li> </ul>	Defective monitor panel	Replace
		Short circuit with power source in wiring harness between starting switch R1 - X07 (3) - H13 (6) - P01 (female) (18) or heater relay- H13 (female) (6)	Repair or replace
	<ul style="list-style-type: none"> <li>• Disconnect terminal R1.</li> <li>• Turn starting switch ON.</li> <li>• Max. 1 V</li> </ul>	Defective starting switch	Replace


## M-10 Related electric circuit diagram




## M-11 When starting switch is turned ON and engine is started, basic check items flash

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Check both the alternator system and the engine oil pressure system.

### a) Alternator system




### M-11a) Related electric circuit diagram



**b) Engine oil pressure system**  
 ★ When engine oil pressure is normal.

	Cause	Remedy
1 YES When engine is running at low idling and wiring harness of oil pressure sensor is removed. Does display go out?	Defective oil pressure sensor	Replace
• Engine at low idling 2 NO Is there continuity between C16 (female) (15) and chassis?	Contact of chassis ground with wiring harness between C16 (female) (15) - E08 (8) - P10 (c) or P10 (A) - E08 (11) - C03 (16)	Repair or replace
• Turn starting switch OFF. • Disconnect sensor wiring harness C16. 3 YES Is bit (1) of monitoring code 24 lighted up?	Defective governor, pump controller	Replace
• Engine at low idling • Set to monitoring code 24. NO	Defective monitor panel	Replace


**M-11b) Related electric circuit diagram**




## M-12 When starting switch is turned ON (engine stopped), caution items, emergency items flash (battery, engine oil pressure lamps do not light up)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Check both the alternator system and the engine oil pressure system.


### a) Alternator system




### M-12 a) Related electric circuit diagram



**b) Engine oil pressure sensor system**  
 ★ When engine oil pressure is normal.



**M-12b) Related electric circuit diagram**




### M-13 When starting switch is turned ON and engine is started, caution items, emergency items flash (when there is no abnormality in engine or items to check before troubleshooting)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

a)  (engine oil pressure) flashes

SAP00520

- ★ Check that the engine oil pressure is normal before carrying out troubleshooting.



Cause	Remedy
See M-11 b)	

b)  (coolant level) flashes

SAP00519


- ★ Check that the coolant level is normal before carrying out troubleshooting.



Cause	Remedy
See M-9 a)	

c)  (battery charge) flashes

SAP00522




Cause	Remedy
See M-11 a)	


d)  (coolant temperature) flashes

SAP00527

★ Check that the coolant temperature is normal before carrying out troubleshooting



M-13 d) Related electric circuit diagram




BKP00284


e)  (fuel level) flashes

SAP00528

★ Check that there is fuel before carrying out troubleshooting.



M-13 e) Related electric circuit diagram




BKP00285




f)  (air cleaner clogging) flashes  
SAP00521

★ Check that the air cleaner is not clogged before carrying out troubleshooting




M-13 f) Related electric circuit diagram



BKP00286

## M-14 When starting switch is turned ON (engine stopped), buzzer does not sound for 1 second Caution item flashes but buzzer does not sound


- ★ Of the caution items, the buzzer will not sound even if there is an abnormality in the battery charge or fuel level.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



Cause	Remedy
Defective monitor panel	Replace
Defective contact or disconnection in wiring harness between P01 (female) (7) and P04 (female) (2)	Repair or replace
Disconnection, defective contact, short circuit with ground in wiring harness between P04 (female) (1) and fuse No. 13	Repair or replace
Defective buzzer	Repalce


## M-15 No abnormality is displayed on monitor but buzzer sounds

- ★ When the buzzer sounds continuously.  
(If the buzzer sounds intermittently, carry out troubleshooting M-14.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



Cause	Remedy
Contact of chassis ground with wiring harness between P01 (female) (7) and P04 (female) (2), or defective buzzer	Repair or replace
Defective monitor panel	Replace


### M-14, 15 Related electric circuit diagram




BKP00273

# M-16 Night lighting on monitor panel does not light up (liquid crystal display is normal)

★ When the front lamp and working lamp light up normally.




## M-16 Related electric circuit diagram




## M-17 Coolant temperature gauge does not rise

- ★ If the coolant temperature actually does not rise, check the engine system.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




## M-18 Coolant temperature gauge does not give any display (none of gauge lamps light up during operation)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




### M-17, 18 Related electric circuit diagram



BKP00284

## M-19 Fuel level gauge always displays FULL


- ★ Check if the tank is actually full before carrying out troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



Cause	Remedy
Defective fuel level sensor system (see M-25)	-
Contact of chassis ground with wiring harness between C03 (female) (2) and P06 (female) (1)	Repair or replace
Defective monitor panel	Replace
Defective governor, pump controller	Replace


## M-20 Fuel level gauge does not give display

- ★ Check that there is actually no fuel before carrying out troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



Cause	Remedy
Defective fuel level sensor system (see M-25)	-
Defective governor, pump controller	Replace
Defective monitor panel	Replace
Defective contact, or disconnection in wiring harness between C03 (female) (2) and P06 (female) (1)	Repair or replace

### M-19, 20 Related electric circuit diagram



BKP00285

## M-21 Swing lock switch is turned ON (LOCK) but (swing lock monitor) does not light up




- ★ Carry out this troubleshooting only if the swing lock is actually being actuated.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
1 YES Is voltage between P05 and chassis as shown in table? NO	YES	Defective monitor panel	Replace
	NO	Defective contact or disconnection in wiring harness between P01 (female) (5) - X01 (4) - X05 (male)	Repair or replace

• Turn starting switch ON.

### M-21 Related electric circuit diagram



Table

Swing lock switch ON	Max. 1 V
Swing lock switch OFF	20 - 30 V

## M-22 Swing prolix switch is turned ON (prolix), but (swing lock monitor) does not flash




- ★ Carry out this troubleshooting only if the swing prolix is actually being actuated.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
1 YES Is voltage between C17 (8) and chassis as shown in table? NO	YES	Defective monitor panel	Replace
	NO	Defective governor, pump controller	Replace
	2 YES	Defective contact or disconnection in wiring harness between C17 (female) (8) and prolix switch (4)	Repair or replace

• Turn starting switch ON.

• Turn starting switch up.  
• Set to monitoring code 21.


### M-22 Related electric circuit diagram




Table

Swing prolix switch ON	Max. 1 V
Swing prolix switch OFF	20 - 30 V

### M-23 Service meter does not advance while engine is running




### M-24 When starting switch is at OFF and time switch is pressed, time and service meter are not displayed




# M-25 Defective fuel level sensor system

★ Remove the fuel level sensor when carrying out the troubleshooting



Table

Top (FULL) stopper position	Approx. 12Ω or below
Bottom (EMPTY) stopper position	Approx. 85 - 110 Ω



**Note 1: Difference between fuel level and gauge display**


For gauge display position 14 (FULL), the amount of fuel is 78-100%; and for display position 1 (EMPTY) it is below 14,5%. If the chassis is at an angle, the displayed amount of fuel will be different from the actual amount. Therefore, when checking, stop the machine at a horizontal place and wait for at least 2 minutes before checking the gauge. (The display is given a time delay so that the gauge can deal with sudden changes in the fuel level.)

**Note 2:** There is the possibility of defective installation or interference with the sensor inside the tank, so be careful when installing.

**Note 3:** Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.




# M-26 Defective coolant temperature sensor system



Table

Normal temperature (20°C)	Approx. 70 ~ 78 kΩ
100°C	Approx. 3Ω




Note 1: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.

Note 2: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.


## M-27 Defective engine oil level sensor system

★ Remove the engine oil level sensor when carrying out troubleshooting



Table

Float UP	Max. 1 Ω
Float DOWN	Min. 1 MΩ



BLP00292

Note 1: Variations in oil level.

The oil level may change according to the angle of the machine, the engine speed, or the temperature of the oil, so if there is any display, check the oil level again with the machine at a horizontal place.


Note 2: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.

Note 3: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

Note 4: Defective installation is a possible cause, so be careful when installing. If the problem occurs again, check for any vibration of the mount, and if there is excessive vibration, take the appropriate action.


# M-28 Defective coolant level sensor system

★ Remove the coolant level sensor when carrying out troubleshooting.



Table

Float UP	Max. 1 Ω
Float DOWN	Min. 1 MΩ



BLP00293

Note 1: Variations in coolant level

The coolant level may change according to the angle of the machine, or the swaying of the machine, so if there is any display, check the coolant level again with the machine at a horizontal place.

Note 2: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.

Note 3: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

Note 4: Defective installation is a possible cause, so be careful installing. If the problem occurs again, check for any vibration of the mount, and if there is excessive vibration, take the appropriate action.

# M-30 Wiper does not work or switch is not being used but wiper is actuated

## a) Wiper does not work

★ Check that fuse No. 7 is normal.




Table 1


Actuation mode	M18 (female)	W08 (female)	Resistance (Ω)
INT mode	Between (1) - (4)	Between (12) - (15)	Max. 1 Ω
	Between (1) - (2)	Between (12) - (14)	Max. 1 MΩ
	Between (2) - (4)	Between (14) - (15)	
	Between (1) - (4)	Between (12) - (15)	
OFF mode	Between (1) - (2)	Between (12) - (14)	Max. 1 MΩ
	Between (2) - (4)	Between (14) - (15)	
ON mode	Between (1) - (2)	Between (12) - (14)	Max. 1 Ω
	Between (1) - (4)	Between (12) - (15)	Max. 1 MΩ
	Between (2) - (4)	Between (14) - (15)	

Table 2

Between W04 (female) (1) - W08 (female) (7)	Max. 1 Ω
Between W04 (female) (3) - W08 (female) (6)	
Between W04 (female) (4) - W08 (female) (11)	
Between W04 (female) (5) - W08 (female) (9)	
Between W04 (female) (6) - W08 (female) (10)	
Between W04 (female) (1) (3) (4) (5) (6) - GND	Min. 1 MΩ


Table 3

Timing chart (when wiper is ON)




Item	Symbol	Set time
Length of pause until next actuation	Tla	0.13 sec
Safety circuit during operation of wiper [safety function (1)]	Tsa	10 sec
Length of pause when stowing wiper blade	Tlp	1.5 sec
Safety circuit during stowing of wiper [safety function (2)]	Tsp	10 sec

Timing chart (for wiper INT)



Item	Symbol	Set time
Length of pause until next actuation	Tla	4 sec
Safety circuit during operation of wiper [safety function (1)]	Tsa	10 sec
Length of pause when stowing wiper blade	Tlp	1.5 sec
Safety circuit during stowing of wiper [safety function (2)]	Tsp	10 sec

M-30 Related electric circuit diagram



b) Wiper switch is not being used but wiper is actuated





Table 1

Actuation mode	M18 (female)	W08 (female)	Resistance (Ω)
INT mode	Between (1) - (4)	Between (12) - (15)	Max. 1 Ω
	Between (1) - (2)	Between (12) - (14)	Max. 1 MΩ
	Between (2) - (4)	Between (14) - (15)	
OFF mode	Between (1) - (2)	Between (12) - (14)	Max. 1 MΩ
	Between (1) - (4)	Between (12) - (15)	
	Between (2) - (4)	Between (14) - (15)	
ON mode	Between (1) - (2)	Between (12) - (14)	Max. 1 Ω
	Between (1) - (4)	Between (12) - (15)	Max. 1 MΩ
	Between (2) - (4)	Between (14) - (15)	


Table 3

Timing chart (when wiper is ON)




Item	Symbol	Set time
Length of pause until next actuation	Tla	0.13 sec
Safety circuit during operation of wiper [safety function (1)]	Tsa	10 sec
Length of pause when stowing wiper blade	Tlp	1.5 sec
Safety circuit during stowing of wiper [safety function (2)]	Tsp	10 sec

Timing chart (for wiper INT)



Item	Symbol	Set time
Length of pause until next actuation	Tla	4 sec
Safety circuit during operation of wiper [safety function (1)]	Tsa	10 sec
Length of pause when stowing wiper blade	Tlp	1.5 sec
Safety circuit during stowing of wiper [safety function (2)]	Tsp	10 sec

M-30 Related electric circuit diagram











---

## 30 DISASSEMBLY AND ASSEMBLY


---

METHOD OF USING MANUAL .....	30-3	SWING MACHINERY ASSEMBLY	
PRECAUTIONS WHEN CARRYING		Removal and Installation .....	30-27
OUT OPERATION .....	30-5	SWING MOTOR	
SPECIAL TOOL LIST .....	30-7	Disassembly and Assembly .....	30-28
GOVERNOR MOTOR ASSEMBLY		REVOLVING FRAME ASSEMBLY	
Removal and Installation .....	30-10	Removal .....	30-36
HYDRAULIC COOLER ASSEMBLY		Installation .....	30-37
Removal .....	30-11	SWING CIRCLE ASSEMBLY	
RADIATOR, HYDRAULIC COOLER		Removal and Installation .....	30-38
ASSEMBLY		IDLER, RECOIL SPRING ASSEMBLY	
Removal .....	30-12	Removal and Installation .....	30-40
Installation .....	30-13	RECOIL SPRING ASSEMBLY	
ENGINE, MAIN PUMP ASSEMBLY		Disassembly .....	30-41
Removal .....	30-14	Assembly .....	30-42
Installation .....	30-17	IDLER ASSEMBLY	
DAMPER ASSEMBLY		Disassembly .....	30-43
Removal and Installation .....	30-18	Assembly .....	30-44
FUEL TANK ASSEMBLY		TRACK ROLLER ASSEMBLY <sup>74</sup>	
Removal and Installation .....	30-19	Removal and Installation <sup>00</sup> .....	30-46
CENTER SWIVEL JOINT ASSEMBLY		Disassembly .....	30-47
Removal and Installation .....	30-20	Assembly .....	30-48
Disassembly and Assembly .....	30-21	CARRIER ROLLER ASSEMBLY	
TRAVEL MOTOR ASSEMBLY		Removal and Installation .....	30-50
Removal and Installation .....	30-22	Disassembly .....	30-51
FINAL DRIVE ASSEMBLY		Assembly .....	30-52
Removal and Installation .....	30-23	TRACK SHOE ASSEMBLY	
SPROCKET		Removal and Installation .....	30-54
Removal and Installation .....	30-25		
SWING MOTOR ASSEMBLY			
Removal and Installation .....	30-26		




<b>HYDRAULIC TANK ASSEMBLY</b>		<b>BUCKET CYLINDER ASSEMBLY</b>	
Removal .....	30-55	Removal .....	30-85
Installation .....	30-56	Installation .....	30-86
<b>MAIN PUMP ASSEMBLY</b>		<b>HYDRAULIC CYLINDER ASSEMBLY</b>	
Removal .....	30-57	Disassembly .....	30-87
Installation .....	30-58	Assembly .....	30-89
<b>CONTROL VALVE ASSEMBLY</b>		<b>WORK EQUIPMENT ASSEMBLY</b>	
Removal .....	30-59	Removal .....	30-92
Installation .....	30-60	Installation .....	30-93
Disassembly and Assembly .....	30-61	<b>BUCKET ASSEMBLY</b>	
<b>LS SELECT VALVE ASSEMBLY</b>		Removal .....	30-94
Disassembly and Assembly .....	30-64	Installation .....	30-94
<b>LS SHUTTLE VALVE</b>		<b>ARM ASSEMBLY</b>	
Disassembly and Assembly .....	30-65	Removal .....	30-94
<b>PRESSURE COMPENSATION VALVE ASSEMBLY</b>		Installation .....	30-94
Disassembly and Assembly .....	30-67	<b>BUCKET, ARM ASSEMBLY</b>	
<b>MAIN RELIEF VALVE ASSEMBLY</b>		Removal .....	30-96
Disassembly .....	30-68	Installation .....	30-97
Assembly .....	30-69	<b>BOOM ASSEMBLY</b>	
<b>LS CONTROL EPC VALVE ASSEMBLY</b>		Removal .....	30-98
Removal and installation .....	30-70	Installation .....	30-99
<b>EPC SOLENOID VALVE ASSEMBLY</b>		<b>OPERATOR'S CAB ASSEMBLY</b>	
Removal and Installation .....	30-72	Removal .....	30-100
<b>PPC SHUTTLE VALVE ASSEMBLY</b>		Installation .....	30-102
Removal .....	30-73	<b>COUNTERWEIGHT ASSEMBLY</b>	
Installation .....	30-74	Removal and Installation .....	30-103
Disassembly .....	30-75	<b>GOVERNOR, PUMP CONTROLLER ASSEMBLY</b>	
Assembly .....	30-76	Removal and Installation .....	30-104
<b>WORK EQUIPMENT PPC VALVE ASSEMBLY</b>		<b>MONITOR PANEL ASSEMBLY</b>	
Removal and Installation .....	30-77	Removal and Installation .....	30-105
<b>TRAVEL PPC VALVE ASSEMBLY</b>		<b>FINAL DRIVE ASSEMBLY</b>	
Removal and Installation .....	30-78	Disassembly .....	30-111
Disassembly .....	30-79	Assembly .....	30-122
Assembly .....	30-79	(Special tools) .....	30-134
<b>BOOM CYLINDER ASSEMBLY</b>		<b>SWING MACHINERY ASSEMBLY</b>	
Removal .....	30-81	Disassembly .....	30-141
Installation .....	30-82	Assembly .....	30-157
<b>ARM CYLINDER ASSEMBLY</b>		(Special tools) .....	30-177
Removal .....	30-83		
Installation .....	30-84		

## METHOD OF USING MANUAL



### 1. When removing or installing unit assemblies

- ① When removing or installing a unit assembly, the order of work and techniques used are given for the removal operation; the order of work for the installation operation is not given.
- ② Any special techniques applying only to the installation procedure are marked , and the same mark is placed after the relevant step in the removal procedure to indicate which step in the installation procedure it applies to.

(Example)

- REMOVAL OF ○○○○ ASSEMBLY ..... Title of operation
-  ..... Precautions related to safety when carrying out the operation
  - 1. XXXX(1) ..... Step in operation
    - ★ ..... Technique or important point to remember when removing XXXX (1).
  - 2. Δ Δ Δ Δ (2): .....  Indicates that a technique is listed for use during installation
  - 3. □□□□ assembly (3)
  -  ..... Quantity of oil or water drained

INSTALLATION OF ○○○○ ASSEMBLY ..... Title of operation



- Carry out installation in the reverse order to removal.
  -  ..... Technique used during installation
  - ★ ..... Technique or important point to remember when installing Δ Δ Δ Δ (2).
  - Adding water, oil ..... Step in operation
    - ★ ..... Point to remember when adding water or oil
    -  ..... Quantity when filling with oil and water
2. General precautions when carrying out installation or removal (disassembly or assembly) of units are given together as PRECAUTIONS WHEN CARRYING OUT OPERATION, so be sure to follow these precautions when carrying out the operation.


### 3. Listing of special tools

- ① For details of the description, part number, and quantity of any tools (A1, etc.) that appear in the operation procedure, see the SPECIAL TOOLS LIST given in this manual.

**4. General tightening torque table (when using torque wrench)**

- ★ In the case of metric nuts and bolts for which there is no special instruction, tighten to the torque given in the table below.

Thread diameter	Width across flats		
		SAD00481	SAD00482
mm	mm	kgm	Nm
6	10	1.35 ± 0.15	13.2 ± 1.4
8	13	3.2 ± 0.3	31.4 ± 2.9
10	17	6.7 ± 0.7	65.7 ± 6.8
12	19	11.5 ± 1.0	112 ± 9.8
14	22	18.0 ± 2.0	177 ± 19
16	24	28.5 ± 3	279 ± 29
18	27	39 ± 4	383 ± 39
20	30	56 ± 6	549 ± 58
22	32	76 ± 8	745 ± 78
24	36	94.5 ± 10	927 ± 98
27	41	135 ± 15	1320 ± 140
30	46	175 ± 20	1720 ± 190
33	50	225 ± 25	2210 ± 240
36	55	280 ± 30	2750 ± 290
39	60	335 ± 35	3280 ± 340



SAD00483

**5. Table of tightening torques for flared nuts**

- ★ In the case of flared nuts for which there is no special instruction, tighten to the torque given in the table below.

Thread diameter	Width across flats	Tightening torque	
		kgm	Nm
14	19	2.5 ± 0.5	24.5 ± 4.9
18	24	5 ± 2	49 ± 19.6
22	27	8 ± 2	78.5 ± 19.6
24	32	14 ± 3	137.3 ± 29.4
30	36	18 ± 3	176.5 ± 29.4
33	41	20 ± 5	196.1 ± 49
36	46	25 ± 5	245.2 ± 49
42	55	30 ± 5	294.2 ± 49

**6. Table of tightening torques for split flange bolts**

- ★ In the case of split flange bolts for which there is no special instruction, tighten to the torque given in the table below.

Thread diameter	Width across flats	Tightening torque	
		Kgm	Nm
10	14	6.7 ± 0.7	65.7 ± 6.8
12	17	11.5 ± 1	112 ± 9.8
16	22	28.5 ± 3	279 ± 29

## PRECAUTIONS WHEN CARRYING OUT OPERATION

[When carrying out removal or installation (disassembly or assembly) of units, be sure to follow the general precautions given below when carrying out the operation.]

### 1. Precautions when carrying out removal work

- If the coolant contains antifreeze, dispose of it correctly.  
After disconnecting hoses or tubes, cover them or fit blind plugs to prevent dirt or dust from entering.
- When draining oil, prepare a container of adequate size to catch the oil.
- Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake when assembling.
- To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors. Do not pull the wires.
- Fit wires and hoses with tags to show their installation position to prevent any mistake when installing.
- Check the number and thickness of the shims, and keep in a safe place.
- When raising components, be sure to use lifting equipment of ample strength.
- When using forcing screws to remove any components, tighten the forcing screws uniformly in turn.
- Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.

### ★ Precautions when handling piping during disassembly

Fit the following blind plugs into the piping after disconnecting it during disassembly operations.

- 1) Hoses and tubes using sleeve nuts


Nominal number	Plug (nut end)	Sleeve nut (elbow end) Use the two items below as a set
02	07376-50210	07221-20210 (Nut), 07222-00210 (Plug)
03	07376-50315	07221-20315 (Nut), 07222-00312 (Plug)
04	07376-50422	07221-20422 (Nut), 07222-00414 (Plug)
05	07376-50522	07221-20522 (Nut), 07222-00515 (Plug)
06	07376-50628	07221-20628 (Nut), 07222-00616 (Plug)
10	07376-51034	07221-21034 (Nut), 07222-01018 (Plug)
12	07376-51234	07221-21234 (Nut), 07222-01219 (Plug)

### 2) Split flange type hoses and tubes

Nominal number	Flange (hose end)	Sleeve head (tube end)	Split flange
04	07379-00400	07378-10400	07371-30400
05	07379-00500	07378-10500	07371-30500

### 3) If the part is not under hydraulic pressure, the following corks can be used.

Nominal number	Part Number	Dimensions		
		D	d	L
06	07049-00608	6	5	8
08	07049-00811	8	6.5	11
10	07049-01012	10	8.5	12
12	07049-01215	12	10	15
14	07049-01418	14	11.5	18
16	07049-01620	16	13.5	20
18	07049-01822	18	15	22
20	07049-02025	20	17	25
22	07049-02228	22	18.5	28
24	07049-02430	24	20	30
27	07049-02734	27	22.5	34



DEW00401

**2. Precautions when carrying out installation work**

- Tighten all bolts and nuts (sleeve nuts) to the specified (KES) torque.
  - Install the hoses without twisting or interference.
  - Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
  - Bend the cotter pins and lock plates securely.
  - When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2 - 3 drops of adhesive.
  - When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
  - Clean all parts, and correct any damage, dents, burrs, or rust.
  - Coat rotating parts and sliding parts with engine oil.
  - When press fitting parts, coat the surface with anti-friction compound (LM-P).
  - After fitting snap rings, check that the snap ring is fitted securely in the ring groove.
  - When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
  - When using eyebolts, check that there is no deformation or deterioration, screw them in fully, and align the direction of the hook.
  - When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- ★ When operating the hydraulic cylinders for the first time after reassembling cylinders, pumps and other hydraulic equipment removed for repair, always bleed the air as follows:
1. Start the engine and run at low idling.
  2. Operate the work equipment control lever to operate the hydraulic cylinder 4 - 5 times, stopping the cylinder 100 mm from the end of its stroke.
  3. Next, operate the hydraulic cylinder 3 - 4 times to the end of its stroke.
  4. After doing this, run the engine at normal speed.
- ★ When using the machine for the first time after repair or long storage, follow the same procedure.

**3 Precautions when completing the operation**

- If the coolant has been drained, tighten the drain valve, and add water to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
- If the hydraulic equipment has been removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- If the piping or hydraulic equipment have been removed, always bleed the air from the system after reassembling the parts.
  - ★ For details, see TESTING AND ADJUSTING, Bleeding air.
- Add the specified amount of grease (molybdenum disulphide grease) to the work equipment parts.



## SPECIAL TOOL LIST

Nature of work	Symbol	Part No.	Part Name	Q'ty	Remarks	
• Engine • hydraulic pump assembly	B	796-460-1210	Oil stopper	1		
• Radiator • hydraulic oil cooler assembly						
• Control pump assembly						
• Hydraulic pump assembly						
• Removal, installation of TVC • LS valve assembly						
Disassembly of center swivel joint assembly	D	790-101-2501	Push-puller	1		
Removal installation of swing circle	E	790-331-1110	Wrench	1	Tightening of circle bolt	
Removal, installation of recoil spring assembly	H	1	791-600-2001 or 791-685-8005	Compressor (A) Compressor (B)	1 1	Removal, press fitting of master pin
			791-635-3160	Extension	1	
			790-101-1600	Cylinder (70-ton)	1	
			790-101-1102	Pump	1	
			790-201-1500	Push tool kit		
		2		• 790-201-1620 • Plate	1	Installation of recoil spring piston dust seal
			• 790-101-5021 • Grip	1		
			• 01010-50816 • Bolt	1		
	Removal, installation of track shoe assembly	I	790-630-3000	Remover & Installer	1	Removal, press fitting of master pin
790-101-1300			Cylinder (70 ton)	1		
790-101-1102			Pump	1		


Nature of work	Symbol	Part No.	Part Name	Q'ty	Remarks	
Assembly of idler assembly	P	1	790-434-1630	Installer	1	Installation of floating seal
		2	791-601-1000	Oil pump	1	Charging with oil, checking for air leakage
Disassembly, assembly of track roller assembly	K	1	790-434-1640	Installer	1	Installation of floating seal
		2	791-601-1000	Oil pump	1	Charging with oil, checking for air leakage
		3	790-331-1110	Wrench	1	Tightening of track roller assembly mounting bolt
Disassembly, assembly of carrier roller assembly	L	1	797-101-1121	Wrench	1	Removal, installation of nut
		2	796-430-1110	Push tool	1	Press fitting of bearing
		3	791-434-1650	Installer	1	Installation of floating seal
		4	791-601-1000	Oil pump	1	Charging with oil, checking for air leakage
Installation of track roller	M	790-331-1110	Wrench	1	Tightening of track roller bolt	
Disassembly, assembly of hydraulic cylinder	1	790-502-1003	Cylinder repair stand	1		
		790-101-1102	Pump	1		
	2	790-102-1330	Socket (width across flats: 75 mm)	1		
		790-302-1430	Socket (width across flats: 85 mm)	1		
	3	790-720-1000	Expander	1	Expansion of piston ring	
	4	796-720-1670	Ring	1		
		07281-01279	Clamp	1		
		796-720-1660	Ring	1		
		07281-01159	Clamp	1		

Nature of work	Symbol	Part No.	Part Name	Q'ty	Remarks
<ul style="list-style-type: none"><li>• Removal, installation of work equipment assembly</li><li>• Boom assembly</li></ul>	P	792-785-1100	Remover	1	Removal of boom foot pin
		790-101-3800	Puller (50 ton long)	1	
		790-101-1102	Pump (30 ton)	1	

## REMOVAL OF GOVERNOR MOTOR ASSEMBLY

**⚠** Disconnect the cable from the negative (-) terminal of the battery.

1. Open engine hood and disconnect governor motor connector.
2. Remove motor rod (1).
3. Remove governor motor assembly (2). \* 1
  - ★ Rotate the shaft of the governor motor and do not stop it suddenly.



## INSTALLATION OF GOVERNOR MOTOR ASSEMBLY

- Carry out installation in the reverse order to removal.

\* 1

- ★ Adjust the rod. For details, see TESTING AND ADJUSTING, Testing and adjusting of governor motor lever stroke.

## REMOVAL OF HYDRAULIC OIL COOLER ASSEMBLY

- ⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- Remove the hydraulic tank strainer, and using tool **B**, stop the oil.
  - When not using tool **B**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.



Hydraulic tank: Approx. 120 ℓ





1. Remove battery and set oil container under chassis.
2. Disconnect hoses (4) and (5).
  - ★ Disconnect hose (4) at the cooler end, and hose (5) at the chassis end.
  - ★ Put blind plugs in the places that have been disconnected.
3. Remove mounting bolts (6) at side of hydraulic oil cooler assembly.
4. Sling hydraulic oil cooler assembly (7), remove 2 mounting bolts each on left and right, then lift off hydraulic oil cooler assembly (7).



Hydraulic oil cooler assembly: 60 kg

## INSTALLATION OF HYDRAULIC OIL COOLER ASSEMBLY

- Carry out installation in the reverse order to removal.
- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.



# REMOVAL OF RADIATOR • HYDRAULIC OIL COOLER ASSEMBLY




**⚠** Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

- Remove the hydraulic tank strainer, and using tool **B**, stop the oil.
  - When not using tool **B**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.




Hydraulic tank: Approx. 120 l


- Drain engine coolant.
1. Remove undercover under radiator.
  2. Disconnect small diameter from radiator (near cap) to reservoir tank.
  3. Disconnect cooler hoses (4) and (5).
  4. Disconnect radiator upper hose (9), and remove clamps of heater hose (10) from right side of radiator assembly.
  5. Remove fan guard (11).



6. Disconnect radiator support rods (12) and (13).  
 ★ Loosen the mounting bolts, then remove the top mounting bolts and move the rods towards the rear of the engine.



7. Disconnect radiator lower hose (14) and heater hose (15).  
 ★ The radiator lower hose is fixed by a clamp to the radiator, so always disconnect the clamp.
8. Sling radiator and hydraulic oil cooler assembly, remove 4 bottom mounting bolts, then lift off radiator and hydraulic oil cooler assembly.  
 ★ When raising the radiator and hydraulic oil cooler assembly, check the position carefully and do not let it hit the fan when removing it.



Radiator • hydraulic oil cooler assembly :  
 115 kg

## INSTALLATION OF RADIATOR • HYDRAULIC OIL COOLER ASSEMBLY

- Carry out installation in the reverse order to removal.
- Refilling with water
  - ★ Add water through the water filler to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.

## REMOVAL OF ENGINE • HYDRAULIC PUMP ASSEMBLY

**⚠** Disconnect the cable from the negative (-) terminal of the battery.

**⚠** Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

- Remove the hydraulic tank strainer, and using tool **B**, stop the oil.

- when not using tool **B**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.






Hydraulic tank: Approx. 120 ℓ

- Drain engine coolant.


- Remove pump bottom cover and engine bottom cover.
- Open engine hood and remove pump top cover.
- Remove engine step, control valve top cover, partition, and exhaust muffler cover .
- Disconnect alternator wiring (5).
  - ★ Mark the wiring with tags to show the connection position.
- Disconnect engine oil pressure sensor wiring.
- Disconnect intake hose (7).
- Remove radiator inlet hose (8).
- Remove fan guard (9) and belt guards.
- Loosen fan belt, remove connecting bolt at pulley and spacer, then remove fan.

❖ I








10. Disconnect heater hose (12).
11. Disconnect water pump inlet hose (13).




13. Disconnect coolant temperature sensor wiring connector (14).
14. Disconnect electrical intake air heater wiring (15).
15. Disconnect governor motor wiring connector (16)
16. Disconnect TVC • LS valve wiring connector (17).
17. Remove clamp (18), and remove spill hose (19).
18. Disconnect fuel hose (20)
  - ★ When the hose is disconnected, fuel will flow out, so insert a wooden plug into the hose to prevent the fuel from leaking out.
19. Disconnect starter motor wiring (21).



20. Disconnect engine oil level sensor wiring connector (22).
21. Disconnect starting motor wiring connector (23).




22. Remove control pump suction tube (24).
23. Disconnect main pump suction tube (25).
24. Disconnect control pump outlet hose (26).
25. Disconnect main pump outlet hose (27).
26. Disconnect main pump drain hose (28).
27. Disconnect TVC • LS valve inlet hoses at side of main pump.
28. Disconnect engine speed wiring connector.
29. Disconnect earth wiring.



31. Remove mount bolt, then lift off engine and hydraulic pump assembly (36) slowly. \* 3
- ★ When removing the engine and hydraulic pump assembly, check that all wiring and piping has been disconnected, and be careful not to hit any part when removing.



Engine • hydraulic pump assembly: 600 kg



205F06482

## INSTALLATION OF ENGINE • HYDRAULIC PUMP ASSEMBLY

- Carry out installation in the reverse order to removal.

✳ 1


- ★ Adjust the fan belt tension.  
For details, see TESTING AND ADJUSTING, Testing and adjusting fan belt tension.

✳ 2


- ★ Check that the O-ring is not damaged or deteriorated, then connect the hoses.

✳ 3

- ★ Set the engine mount rubber as shown in the diagram, then install the engine and hydraulic pump assembly.

 **kgm** Engine mount mounting bolt:  
276.9 ± 31.9 Nm (28.25 ± 3.25 kgm)


- Refilling with water
  - ★ Add water through the water filler to the specified level.  
Run the engine to circulate the water through the system. Then check the water level again.
- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level.  
Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air from the hydraulic pump.  
For details, see TESTING AND ADJUSTING, Bleeding air.
- Fill with refrigerant (R-134a).



## REMOVAL OF DAMPER ASSEMBLY

1. Remove main pump assembly. For details, see REMOVAL OF MAIN PUMP ASSEMBLY.
2. Remove damper assembly (1).

\* 1



## INSTALLATION OF DAMPER ASSEMBLY

- Carry out installation in the reverse order to removal.

\* 1



kgm

Damper mounting bolt;


$171.05 \pm 7.35 \text{ Nm}$  ( $7.25 \pm 0.75 \text{ kgm}$ )



Thread of Damper mounting bolt;

Thread tightener (LT-2)

## REMOVAL OF FUEL TANK ASSEMBLY

 Disconnect the cable from the negative (-) terminal of the battery.

1. Loosen drain valve (1) of fuel tank and drain fuel.





Fuel tank: Approx. 250 ℓ (when tank is full)

2. Disconnect fuel supply hose (2) and return hose (3).
3. Remove handrail (4), battery case (5), and cover (6).
4. Remove connector (7) from holder, and disconnect it.
  - ★ Remove the wiring from the clamp, then disconnect from the fuel tank.
5. If refueling pump is fitted disconnect hose from tank tube.
6. Remove mounting bolts, and lift off fuel tank assembly (8)




Fuel tank assembly: 100 kg





## INSTALLATION OF FUEL TANK ASSEMBLY

- Carry out installation in the reverse order to removal.



 Fuel tank mounting bolt:  
276.9 ± 31.9 Nm (28.25 ± 3.25 kgm)

- Refilling with oil (fuel tank)  
Add fuel.



## REMOVAL OF CENTER SWIVEL JOINT ASSEMBLY

**⚠** Release the remaining pressure in the hydraulic circuit. For details, see TESTING AND ADJUSTING.  
Releasing remaining pressure from hydraulic circuit.





- ★ Mark all the piping with tags to prevent mistakes in the mounting position when installing.
- 1. Disconnect hoses (1), (2), (3), and (4) and tubes (5) and (6), and remove filter and bracket assembly.
  - ★ Machines equipped with additional attachment circuit.
- 2. Disconnect hoses (7), (8), (9), and (10) between travel motor and swivel joint.
- 3. Remove elbow (11).
- 4. Disconnect drain hose (12).
- 5. Disconnect hoses (13) and (14) between control valve and swivel joint.
- 6. Disconnect travel speed selector hose (15).
- 7. Disconnect plate (16).
- 8. Remove center swivel joint assembly (17). \* 1



Center swivel joint assembly: 45 kg

## INSTALLATION OF CENTER SWIVEL JOINT ASSEMBLY


- Carry out installation in the reverse order to removal.
- \* 1
  - ★ Assemble the center swivel as shown in the diagram below.



- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air from the travel motor. For details, see TESTING AND ADJUSTING, Bleeding air.

## DISASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY

1. Remove cover (1).
2. Remove snap ring (2).
3. Using tool D, pull out swivel rotor (4) and ring (3) from swivel shaft (5).
4. Remove O-ring (6) and slipper seal (7) from swivel rotor.



## ASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY

1. Assemble slipper seal (7) and O-ring (6) to swivel rotor.
2. Set swivel shaft (5) to block, then using push tool, tap swivel rotor (4) with a plastic hammer to install.



Contact surface of rotor, shaft:


Grease (G2-LI)

- ★ When installing the rotor, be extremely careful not to damage the slipper seal and the O-ring.

3. Install ring (3) and secure with snap ring (2).
4. Fit O-ring and install cover (1).



Mounting bolt:  $31.4 \pm 2.9$  Nm ( $3.2 \pm 0.3$  kgm)



## REMOVAL OF TRAVEL MOTOR ASSEMBLY

1. Remove sprocket. For details, see REMOVAL OF SPROCKET.

**⚠** Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

2. Remove cover (1).
3. Disconnect 4 travel motor hoses (2), and lift off final drive assembly (3).
  - ★ Be extremely careful not to damage the nipple tool surface of the hose mount.



Travel motor: 95 kg

## INSTALLATION OF TRAVEL MOTOR ASSEMBLY




- Carry out installation in the reverse order to removal.



Travel motor mounting bolt:

$549 \pm 59 \text{ Nm}$  ( $56 \pm 6 \text{ kgm}$ )

- Bleeding air
  - ★ Bleed the air from the travel motor. For details, see TESTING AND ADJUSTING, Bleeding air.
- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.






## REMOVAL OF FINAL DRIVE ASSEMBLY

1. Remove sprocket and travel motor .For details, see REMOVAL OF SPROCKET and REMOVAL OF TRAVEL MOTOR.

**!** Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

2. Remove cover 1
3. Disconnect 4 travel motor hoses (2), and lift off final drive assembly (3). 
  - ★ Be extremely careful not to damage the nipple tool surface of the hose mount.



Final drive assembly:

195 kg (without travel motor and sproket)

330 kg (with travel motor and sprocket)

## INSTALLATION OF FINAL DRIVE ASSEMBLY




- Carry out installation in the reverse order to removal.



Final drive mounting bolt:

$549 \pm 59 \text{ Nm}$  ( $56 \pm 6 \text{ kgm}$ )

- Bleeding air
  - ★ Bleed the air from the travel motor.For details, see TESTING AND ADJUSTING, Bleeding air.
- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.



**FITTING OF THE HYDRAULIC MOTOR.**

Clean the mating area and the pilot diameter of the gearbox where the motor is to be mounted.


After mounting the motor, verify, through of a depth slide gauge, the axial dimension of the gearbox measured from input side of the flanged hub to the brake shaft:

**Axial dimension = 111,4 - 112,2 mm**

Place the hydraulic motor and tighten the 2 hexagonal head screws M20x60, grade 8.8, by a torque wrench at a torque of 41,5 daNm.


**INSTALLATION OF THE GEARBOX TO THE MACHINE**


- a) Clean the mating surfaces from oils or paint and fit the gearbox to the undercarriage.
- b) Fix the gearbox to the frame with 16 screws M20 minimum grade 8.8, tightened by a torque wrench at a torque of 41,5 daNm.
- c) Clean the area which mates to the sprocket. To fit the sprocket use 16 screws M20, grade 8.8, tightened at 41,5 daNm torque.



Dwg.4 - Gearbox installation scheme

## REMOVAL OF SPROCKET

1. Remove track shoe assembly. For details, see REMOVAL OF TRACK SHOE ASSEMBLY.
2. Swing work equipment 90°, then push up chassis with work equipment and set block 1 between track frame and track shoe.
3. Lift off sprocket (1). 



## INSTALLATION OF SPROCKET

- Carry out installation in the reverse order to removal.



Thread of sprocket mounting bolt:  
Thread tightener (LT-2)



Sprocket mounting bolt:  
637 ± 49Nm (65 ± 5 kgm)

## REMOVAL OF SWING MOTOR ASSEMBLY

**⚠** Lower the work equipment completely to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then set the safety lock lever to the LOCK position.

1. Disconnect hoses (1), (2), (3), and (4), and tubes (5) and (6), then remove filter and bracket assembly.
  - ★ Machines equipped with additional attachment circuit
2. Remove hose clamps (7) and (8).
3. Disconnect swing motor inlet and outlet hoses (9), (10), and (11).
4. Remove bracket (12).
5. Disconnect drain hoses (13) and (14).
6. Disconnect pilot hose (15).
7. Remove swing motor assembly (16). \* I




Swing motor assembly 30 kg





## INSTALLATION OF SWING MOTOR ASSEMBLY

- Carry out installation in the reverse order to removal.
- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- ★ Bleeding air
  - ★ Bleed the air from the swing motor. For details, see TESTING AND ADJUSTING, Bleeding air.

\* I



Swing motor mounting bolt:  
277 ± 32 Nm (28.3 ± 3.3 kgm)



## REMOVAL OF SWING MACHINERY ASSEMBLY

1. Remove swing motor assembly. For details, see REMOVAL OF SWING MOTOR ASSEMBLY.
2. Using eyebolts ①, remove swing machinery assembly (1).
  - ★ When removing the swing machinery assembly, lift off slowly and be careful not to damage the hoses.



Swing machinery assembly: 120 kg

## INSTALLATION OF SWING MACHINERY ASSEMBLY

- Carry out installation in the reverse order to removal.
  - ★ Swing machinery mounting bolt:  
 $548.8 \pm 49 \text{ Nm}$  ( $56 \pm 5 \text{ kgm}$ )
- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air from the swing motor. For details, see TESTING AND ADJUSTING, Bleeding air.


**FITTING OF THE HYDRAULIC MOTOR**

Clean the mating area and the pilot diameter of the gearbox where the motor is to be mounted.

After mounting the motor, verify, through of a depth slide gauge, the axial dimension of the gearbox measured from input side of the motor adaptor flange to the brake shaft:

**Axial dimension = 93 - 94,5 mm.**


Place the hydraulic motor and tighten the 2 hexagonal head screws M16 x 40, grade 8.8, by a torque wrench at a torque of 21,5 daNm.



*Dwg. Verify the axial dimension of the gearbox*

**INSTALLATION OF THE SLEW DRIVE TO THE MACHINE**

- a) Clean the mating surfaces from oils or paint and fit the gearbox to the undercarriage.
- b) Fix the slew drive to the frame with 10 screws M20 minimum grade 8.8, tightened by a torque wrench at a torque of 41,5 daNm.




*Dwg. - Gearbox installation scheme*

DISASSEMBLY AND ASSEMBLY OF SWING MOTOR

F12	Nm ± 10
60	60


F12	A±0.25 mm	B±0.25 mm	Tool
60	11	38.0	3894185




F12	Thread	Tool
60	M24 x 1.5	3793077

**Dissassembly**


Put the unit in a bench with a hole or place it on a fixture for assembly. Loosen the 4 bolts.




Lift off the housing



Lift out the pistons




Turn the bearing housing upside down and loosen the retaining ring holding the seal ring carrier.







Loosen the seal carrier using two screwdrivers.




Loosen the retaining ring holding the bearing and bearing play adjustment washers.




Push out the shaft with a press or a plastic mallet.



If it is necessary to remove the bearing races, use a drift or a press.



For disassembly the valve plate has got a thread in the centre. Use the special tool to pull it out.




Thread specification:

F12	Thread	Tool
60	M24x1.5	3793077


### Assembly

Push the shaft into the bearings in the housing. Use as many washers as needed to just allow the retaining ring on the shaft to enter into its groove.




Install pistons, cylinder barrel support and cylinder barrel.

**Note:** The shaft has got one tooth marked with a punchmark and the barrel has got one space marked. It is absolutely necessary that these are mating to ensure correct alignment for the pistons in the cylinders. Also choose correct adjustment shim to ensure correct backlash.




Install the barrel housing and tighten the screws.




Backlash and correct timing can be checked through the drainhole.

Correct tightening torque is:

F12 Nm $\pm$ 10	
60	60



<i>Item</i>	<i>Title</i>
110	BARREL HOUSING ASSY
121	VALVE PLATE
131	BLEEDER PLUG
132	SEAL WASHER
211	BEARING HOUSING
221	O-RING
225	O-RING
229	O-RING
231	SEAL CARRIER
233	SHAFT SEAL
237	RETAINING RING
256	PLUG
257	SEAL WASHER
311	SHAFT TYPE
411	CYLINDER BARREL
415	NEEDLE BEARING
430	BARREL SUPPORT
440	PISTON ASSY
442	PISTON RING
451	GUIDE PIN
452	RING GEAR
460	TAP ROL BEARING
470	CYL BEARING
476	SPACER WASHER
478	RETAINING RING
488	SHIM
491	HEX SOCKET SCREW







## REMOVAL OF REVOLVING FRAME ASSEMBLY

1. Remove 2 boom cylinder assemblies. For details, see REMOVAL OF BOOM CYLINDER ASSEMBLY.
2. Remove work equipment assembly. For details, see REMOVAL OF WORK EQUIPMENT ASSEMBLY.
3. Remove counterweight assembly. For details, see REMOVAL OF COUNTERWEIGHT ASSEMBLY.
4. Disconnect top mounting hoses (1), (2), and (3) of swivel joint assembly at swivel joint assembly end.
5. Remove stopper link (4).
6. Remove mounting bolts, then lift off revolving frame assembly (5).

- ★ Leave 2 bolts ① each at the front and rear, use a lever block to adjust the balance of the revolving frame assembly to the front and rear, and left and right, then remove the remaining bolts, and lift off.

**⚠** When removing the revolving frame assembly, be careful not to hit the center swivel joint assembly.


 Revolving frame assembly:  
7100 kg (without work equipment)




## INSTALLATION OF REVOLVING FRAME ASSEMBLY

- Carry out installation in the reverse order to removal.

 1

 Mating surface of swing circle:  
Gasket sealant (LG-1)

 Thread of revolving frame mounting bolt:  
Thread tightener (LT-2)

 **kgm** Revolving frame mounting bolt:

Model \ Item	Mounting bolt		Mounting bolt tightening torque
	Size	Q'ty	Nm (kgm)
	20-105	26	549 ± 59 (56 ± 6)



- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air. For details, see TESTING AND ADJUSTING, Bleeding air.

## REMOVAL OF SWING CIRCLE ASSEMBLY

1. Remove revolving frame assembly. For details, see REMOVAL OF REVOLVING FRAME ASSEMBLY.
2. Remove swing circle mounting bolts (1), leaving 1 bolt each in front and rear direction. ※ 1
3. Sling swing circle assembly (2) at three points, then remove remaining mounting bolts.
4. Lift off swing circle assembly (2). ※ 2



Swing circle assembly 240 kg







## INSTALLATION OF SWING CIRCLE ASSEMBLY

- Carry out installation in the reverse order to removal.


✳ 1


 Thread of swing circle mounting bolt:  
Thread tightener (LT-2)

 Swing circle mounting bolt:  
 $549 \pm 49\text{Nm}$  ( $56 \pm 6 \text{kgm}$ )

✳ 2

- ★ Set the soft zone **S** mark on the inside ring of the inner race facing the right side as shown in the diagram, then install to the track frame.

 Swing circle: Grease (G2-LI) 8/



## REMOVAL OF IDLER • RECOIL SPRING ASSEMBLY

1. Remove track shoe assembly. For details, see REMOVAL OF TRACK SHOE ASSEMBLY.
2. Sling idler and recoil spring assembly (1), and pull out to the front to remove.



Idler • recoil spring assembly: 275 kg

3. Disconnect recoil spring assembly (3) from idler assembly (2).



\* 1



Idler assembly: 140 kg



Recoil spring assembly: 135 kg




## INSTALLATION OF IDLER • RECOIL SPRING ASSEMBLY

- Carry out installation in the reverse order to removal.


\* 2

- ★ When installing the idler assembly and recoil spring assembly, assemble so that the position of the greasing plug on the idler is on the outside for the right side of the machine and on the inside for the left side of the machine.

## DISASSEMBLY OF RECOIL SPRING ASSEMBLY



1. Remove piston assembly (2) from recoil spring assembly (1).
2. Disassembly of recoil spring assembly
  - 1) Set recoil spring assembly (1) to tool H1.
    - ⚠ The recoil spring is under large installed load, so be sure to set the tool properly. Failure to do this is dangerous.
    - ★ Installed load of spring: 133,000 N (13,610 kg).
  - 2) Apply hydraulic pressure slowly to compress spring, and remove lock plate (3), then remove nut (4).
    - ★ Compress the spring to a point where the nut becomes loose.
    - ★ Release the hydraulic pressure slowly and release the tension of the spring.
    - ★ Free length of spring: 587.5 mm
- 3) Remove yoke (6), cylinder (7), and dust seal (8) from spring (5).
3. Disassembly of piston assembly
  - 1) Remove lock plate (10) from piston (9), then remove valve (11).
  - 2) Remove snap ring (12), then remove U-packing (13) and ring (14).




## ASSEMBLY OF RECOIL SPRING ASSEMBLY

### 1. Assembly of piston assembly

- 1) Assemble ring (14) and U-packing (13) to piston (9), and secure with snap ring (12).
- 2) Tighten valve (11) temporarily, and secure with lock plate (10).


### 2. Assembly of recoil spring assembly

- 1) Using tool **H2**, install dust seal (8) to cylinder (7).
- 2) Assemble cylinder (7) and yoke (6) to spring (5), and set in tool **H1**.



 Sliding portion of cylinder: Grease (G2-LI)

- 3) Apply hydraulic pressure slowly to compress spring, and tighten nut (4) so that installed length of spring is dimension "a", then secure with lock plate (3).
  - ★ Installed length "a" of spring : 466 mm.
- 4) Remove recoil spring assembly (1) from tool **H1**.

### 3. Assemble piston assembly (2) to recoil spring assembly (1).


 Sliding portion of piston, wear ring:  
Grease (G2-LI)

- ★ Assemble the cylinder assembly so that the mounting position of the valve is 90° to the side.
- ★ Fill the inside of the cylinder with 300 cc of grease (G2-LI), then bleed the air and check that grease comes out of the grease hole.




## DISASSEMBLY OF IDLER ASSEMBLY



1. Remove dowel pin (1), then remove support (2).
2. Remove floating seal (3) from support (2) and idler (4).
3. Pull out idler (4) from shaft (5) and support (7) assembly.
  - ★ It is filled with 80 cc. of oil, so drain the oil at this point or lay a cloth to prevent the area from becoming dirty.



4. Remove floating seal (6) on opposite side from idler (4) and shaft (5) and support (7) assembly.





5. Remove dowel pin (8), then remove support (7) from shaft (5).
6. Remove bushings (9) and (10) from idler (4).



# ASSEMBLY OF IDLER ASSEMBLY



1. Press fit bushings (9) and (10) to idler (4).




2. Fit O-ring and install support (7) to shaft (5) with dowel pin (8).

3. Using tool **G1**, install floating seal (6) to idler (4) and shaft (5) and support (7) assembly.



- ★ Coat the sliding surface of the floating seal with oil, and be careful not to let any dirt or dust get stuck to it.
- ★ Remove all grease and oil from the contact surface of the O-ring and the floating seal.



4. Assemble shaft (5) and support (7) assembly to idler (4).



5. Using tool **G1**, install floating seal (3) to idler (4) and support (2).
  - ★ Coat the sliding surface of the floating seal with oil, and be careful not to let any dirt or dust get stuck to it.
  - ★ Remove all grease and oil from the contact surface of the O-ring and the floating seal.




6. Install O-ring, then install support (2) with dowel pin (1).
7. Add oil and tighten plug.



Oil: Approx. 80 cc (SAE30)



Plug:  $205.9 \pm 49$  Nm ( $21 \pm 5$  kgm)



## REMOVAL OF TRACK ROLLER ASSEMBLY

1. Lower work equipment, then loosen lubricator (1), and relieve track tension. \* 1  
The adjustment cylinder is under extremely high pressure. Never loosen the lubricator more than one turn. If the grease does not come out easily, move the machine backwards and forwards.
2. Remove mounting bolts of track roller, then swing work equipment 90°, jack up machine, and remove track roller assembly (2) towards outside of machine. \* 2



Track roller assembly: 40 kg

## INSTALLATION OF TRACK ROLLER ASSEMBLY

- Carry out installation in the reverse order to removal.

\* 1

- ★ Adjust the track tension. For details, see TESTING AND ADJUSTING, Testing and adjusting track tension.





\* 2

- ★ Place the plug on the outside of the chassis, and set the track roller assembly in the mounting position.
- ★ Operate the work equipment levers to lower the machine slowly, then tighten the mounting bolts temporarily.
- ★ Operate the work equipment levers to lower the machine completely to the ground, then tighten the mounting bolts fully.

Track roller assembly mounting bolt:



1st pass: Tighten to  $196.1 \pm 19.6$  Nm ( $20 \pm 2$  kgm)

- 2nd pass:
1. When using tool K3.
    - Using an angle tightening wrench, tighten bolt  $90 \pm 5^\circ$ .
  2. When not using tool K3.
    - 1) Using the angle of the bolt head as the base, make start marks on the track roller and socket.
    - 2) Make an end mark at a point  $90 \pm 5^\circ$  from the start mark.
    - 3) Tighten so that the start mark on the socket is aligned with the end mark on the track roller at the  $90 \pm 5^\circ$  position.









# DISASSEMBLY OF TRACK ROLLER ASSEMBLY





1. Remove pin (1), then remove collar (2).
2. Remove floating seal (3) from collar (2) and roller (4).



3. Pull out roller (4) from shaft (5).
  - ★ It is filled with 190 - 215 cc. of oil, so drain the oil at this point or lay a cloth to prevent the area from becoming dirty.
4. Remove floating seal (6) on opposite side from roller (4) and shaft (5).









5. Remove pin (7), then remove collar (8) from shaft (5).
6. Remove bushings (9) and (10) from roller (4).




# ASSEMBLY OF TRACK ROLLER ASSEMBLY


1. Using push tool ①, press fit bushings (9) and (10) to roller (4).
2. Assemble collar (8) to shaft (5), and install pin (7).
3. Using tool **K1**, install floating seal (6) to shaft (5).
  - ★ When assembling the floating seal, clean the contact surface of O-ring (6c) and floating seal (6a), remove all grease and oil, and dry it. Make sure that no dirt or dust sticks to the contact surface of the floating seal.
4. Using tool **K1**, install floating seals (6) and (3) to roller (4).
  - ★ For details of the precautions when installing floating seals (6b) and (6d), and (3b) and (3d), see the precaution for Step 3.
5. Assemble shaft (5) to roller (4).
6. Turn over roller (4) and shaft (5) assembly.
7. Using tool **K1**, install floating seal (3) to collar (2).
  - ★ For details of the precautions when installing floating seals (3a) and (3c), see the precaution for Step 3.




8. Assemble collar (2) to shaft (5), and install pin (1).






9. Using tool **K2**, apply basic pressure to roller oil filler port, and check for leakage of air from seal.
- ★ Basic pressure: 98 kPa (1 kg/cm<sup>2</sup>)
  - ★ The basic pressure shall be maintained for 10 seconds and the indicator of the gauge shall not go down.



10. Using tool **K2**, fill track roller assembly with oil, then tighten plug (11).

 **kgm** Plug: 14.7 ± 4.9 Nm (1.5 ± 0.5 kgm)

 Track roller oil: 190 - 215 cc (SAE30)




## REMOVAL OF CARRIER ROLLER ASSEMBLY

1. Lower work equipment, then loosen lubricator (1), and relieve track tension. \* 1

**⚠** The adjustment cylinder is under extremely high pressure. Never loosen the lubricator more than one turn. If the grease does not come out, move the machine backwards and forwards.

2. Using hydraulic jack ①, push up track to a position where carrier roller assembly can be removed, then remove carrier roller assembly (2). \* 2



## INSTALLATION OF CARRIER ROLLER ASSEMBLY


- Carry out installation in the reverse order to removal.

\* 1


★ Adjust the track tension. For details, see TESTING AND ADJUSTING, Testing and adjusting track tension.


\* 2

Thread of carrier roller assembly mounting bolt:  
Thread tightener (LT-2)



# DISASSEMBLY OF CARRIER ROLLER ASSEMBLY











1. Remove plug (1) and drain oil.  
 Carrier roller assembly : 230 - 250 cc
2. Set carrier roller assembly on stand ①.
3. Remove cover (2).
4. Remove ring (3).
5. Using tool **L1**, remove nut (4).
6. Using push tool ②, pull out shaft assembly (5) from roller (6) with press, then remove inner race (7).
7. Remove outer races (8) and (9) from roller (6).

## 8. Disassembly of shaft assembly

- 1) Using puller ③, remove inner race (10).

- 2) Remove floating seals (11).
- 3) Using push tool ④, remove collar (12) from shaft (13).



## ASSEMBLY OF CARRIER ROLLER ASSEMBLY

- Using push tool ⑤, press fit outer races (8) and (9) to roller (6).

### 2. Assembly of shaft assembly

- Using push tool ⑥, press fit collar (12) to shaft (13).

★ When press fitting, be careful that there is no scuffing.

 Fitting portion of shaft: SAE30

- Using tool L3, assemble floating seals (11).

★ When assembling the floating seal, clean the contact surface of O-ring (11c) and floating seal (11a), remove all grease and oil, and dry it. Make sure that no dirt or dust sticks to the contact surface of the floating seal.

- Assemble floating seals (11), then using push tool ⑦, press fit inner race (10).

★ For details of the precautions when installing floating seals (11b) and (11d), see the precaution for Step 2).

- Assemble roller (6) to shaft assembly (5).









- Using push tool ⑧, press fit inner race (7).

★ When press fitting the bearing, rotate the roller, and press fit to a point where the rotation becomes slightly heavier.


- Using tool L1, tighten nut (4) to a point where drill hole in shaft is aligned with drill hole in nut.

- Install ring (3).


- Using push scale ⑨, check that it rotates smoothly.



8. Fit O-ring and install cover (2).




9. Using tool **L2**, apply basic pressure to roller oil filler port, and check for leakage of air from seal.
- ★ Basic pressure: 98 kPa (1 kg/cm<sup>2</sup>)
  - ★ Method of checking  
The basic pressure shall be maintained for 10 seconds and the indicator of the gauge shall not go down.



10. Using tool **L4**, fill carrier roller assembly with oil, then tighten plug (1).





Carrier roller oil: 230 - 250 cc (SAE30)





## REMOVAL OF TRACK SHOE ASSEMBLY

1. Stop machine at a point where master pin is midway between idler and carrier roller, and where there is space to lay out track assembly on ground.
2. Lower work equipment, then loosen lubricator (1), and relieve track tension. \* 1
  - ⚠ The adjustment cylinder is under extremely high pressure. Never loosen the lubricator more than one turn. If the grease does not come out, move the machine backwards and forwards.
3. Using tool I, pull out master pin (2) \* 2
4. Remove tool I, and move machine forward so that position of temporary pin ② is at front of idler, and set block ① in position.
5. Remove temporary pin ②, and remove dust seal, then drive machine in reverse to lay out track 3. \* 3



## INSTALLATION OF TRACK SHOE ASSEMBLY

- \* 1
  - ★ Adjust the track tension. For details, see TESTING AND ADJUSTING, Testing and adjusting track tension.
- \* 2
  - ★ Use tool I and press fit so that the protrusion of the master pin is dimension "a".  
Protrusion "a" of master pin:  $4 \pm 2$  mm
- \* 3
  - ★ When assembling the dust seal, coat the bushing contact surface with grease (G2-LI).






## REMOVAL OF HYDRAULIC TANK ASSEMBLY

1. Drain oil from hydraulic tank.




Hydraulic tank: Approx. 120 ℓ

2. Open engine hood, and remove covers (1), (2), (3), and (4).




3. Remove engine room partition plate (5), then remove partition plate (6).



4. Remove frame (7).


5. Disconnect hydraulic filter inlet hoses (8), (9), (10), and (11).



6. Remove pressure sensor wiring clamps (12).

7. Remove solenoid valve wiring clamp (13).

9. Remove wiring connector bracket (15).




## DISASSEMBLY AND ASSEMBLY

---

10. Disconnect hydraulic tank inlet hose (16).
11. Remove main pump inlet tube (17), then remove pump suction tube (18).
12. Remove mounting bolts, and lift off hydraulic tank assembly (19). \* 1



Hydraulic tank assembly: 125 kg



## INSTALLATION OF HYDRAULIC TANK ASSEMBLY

- Carry out installation in the reverse order to removal.

\* 1




Thread of hydraulic tank mounting bolt:  
Thread tightener (LT-2)



Hydraulic tank mounting bolt:  
 $276.9 \pm 31.9 \text{ Nm}$  ( $28.25 \pm 3.25 \text{ kgm}$ )

- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level.  
Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air.  
For details, see TESTING AND ADJUSTING, Bleeding air.



## REMOVAL OF MAIN PUMP ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.


⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

- Remove the hydraulic tank strainer, and using tool **B**, stop the oil.
  - When not using tool **B**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.



Hydraulic tank: Approx. 120 ℓ

2. Open engine hood, and remove main pump top cover, then remove exhaust muffler covers (1) and (2).
3. Disconnect connecting pipe portion at turbocharger end, and remove exhaust muffler (3) together with bracket.
4. Disconnect hoses (4), and remove filter assembly (5) together with bracket.
5. Remove control pump suction tube (6).
6. Disconnect main pump suction tube (7).
8. disconnect control pump outlet hose (9).
9. Disconnect main pump outlet hose (10)
10. Disconnect main pump drain hose (11).
11. Disconnect TVC • LS valve inlet hoses (12).



## DISASSEMBLY AND ASSEMBLY

12. disconnect engine speed sensor wiring connector (13), and remove bracket (14).
13. Disconnect TVC solenoid wiring connector (15), and remove bracket (16).
14. Disconnect ground connection (17).
15. Remove exhaust drain pipe (18).
16. Sling main pump assembly (19), remove mounting bolts, then use forcing screws ① to remove.

※ 1



Main pump assembly: 100 kg

## INSTALLATION OF MAIN PUMP ASSEMBLY




- Carry out installation in the reverse order to removal.

※ 1



Mating surface of pump case:  
Gasket sealant (LG-6)






- Refilling with oil (PTO gear case)
  - ★ Add engine oil through the oil filler to the specified level.
- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level.
  - Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air from main pump.
  - For details, see TESTING AND ADJUSTING, Bleeding air.



## REMOVAL OF CONTROL VALVE ASSEMBLY

**⚠** Release the remaining pressure in the hydraulic circuit.  
For details, see TESTING AND ADJUSTING, Releasing pressure in hydraulic circuit.



1. Remove engine room partition plate and chassis bodywork cover above control valve assembly.
2. Remove clamp (1), then disconnect hoses (2), (3), (4), and (5).
3. Disconnect hoses (6) and (7).
4. Remove clamp (8), then remove hoses (2), (3), (4), and (5).
5. Disconnect hoses (9), (10), (11), (12), and (13).
6. Disconnect hoses (14), (15), and (16).
7. Disconnect hoses (17), (18), (19), and (20).  
★ Disconnect 2 hoses (18).
8. Disconnect hoses (21), (22), and (23).



- 9. Remove connector (24) from clip, then disconnect it.
  - ★ Disconnect the wiring harness form the harness clamps (3 places)
- 10. Remove harness bracket (25).
- 11. Disconnect hose (26).
- 12. Remove mounting bolts, and lift off control valve assembly (27).




Control valve assembly : 70 kg





## INSTALLATION OF CONTROL VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.
- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air from the circuit between the valve and the hydraulic cylinder. For details, see TESTING AND ADJUSTING, Bleeding air.
















## DISASSEMBLY OF CONTROL VALVE ASSEMBLY



- ★ The set pressure of the safety valve and arm counterbalance valve, cannot be adjusted when they are installed on the machine, so do not disassemble.
  - The following explanation describes the spools control valve.
1. **Main relief valve**  
Remove main relief valve (1).
  2. **Unload valve, safety-suction valves, suction valves**
    - 1) Remove unload valve (3)
    - 2) Remove safety-suction valves (4), (5), (6), (7), and (8).
    - 3) Remove suction valves (9) and (10).
  3. **Pressure compensation valves**
    - ★ Before removing any pressure compensation valve, check and mark its mounting position.
    - 1) Remove bucket CURL pressure compensation valve (11), arm IN pressure compensation valve (11), boom LOWER pressure compensation valve (11), Right travel REVERSE pressure compensation valve (12), Left travel REVERSE pressure compensation valve (12), and swing RIGHT pressure compensation valve (13) and service valve pressure compensation valve (14).
      - ★ After removing the pressure compensation valves, remove check valve (17) from each pressure compensation valve mount.
    - 2) Remove bucket DUMP pressure compensation valve (18), arm OUT pressure compensation valve (19), boom RAISE pressure compensation valve (19), Right travel FORWARD pressure compensation valve (20), Left travel FORWARD pressure compensation valve (20), and swing LEFT pressure compensation valve (21), and service valve pressure compensation valve (22).
      - ★ After removing the pressure compensation valves, remove check valve (24) from each pressure compensation valve mount.
  4. **LS shuttle, LS select valve**  
Remove LS shuttle valves (25a) and (25b), and LS select valve (26).
    - ★ Mark the mounting positions of LS shuttle valves (25a), and (25b), and be careful not to make any mistake when installing.
  5. **Bucket control valve, arm control valve, boom control valve, swing control valve, service control valve**
    - 1) Remove case (27), then remove spring (28) and retainer (29).
    - 2) Remove spool assembly (30).
      - ★ Do not disassemble spool (30).
    - 3) Remove case (31), then remove spring (32) and retainer (33).
      - ★ To avoid assembling spring (32) in mistake for spring (39), mark with tags.
  6. **Right travel control valve, Left travel control valve**
    - 1) Remove case (34), then remove spring (35) and retainer (36).
    - 2) Remove spool assembly (37).
      - ★ Do not disassemble spool (37)
    - 3) Remove case (38), then remove spring (39) and retainer (40).
      - ★ To avoid assembling the spring of the control valve in Step 5 in mistake for spring (39), mark with tags.
  7. **Arm counterbalance valve, check valve, cover**
    - 1) Remove arm counterbalance valve (41).
    - 2) Remove flange (42), then remove spring (43) and check valve (44).
    - 3) Remove covers (45) and (46).
  8. **Lift check valve**  
Remove case (47), then remove spring (48), piston (49), and sleeve (50).
  9. **Cooler bypass valve**  
Remove case (51), then remove spring (52), piston (53), and sleeve (54).






## ASSEMBLY OF CONTROL VALVE ASSEMBLY

- Before assembling coat the sliding surface with engine oil.
1. **Cooler bypass valve**  
Assemble sleeve (54), piston (53), and spring (52) to cover (46), then fit O-ring to case (51) and install.
  2. **Lift check valve**  
Assemble sleeve (50), piston (49), and spring (48) to cover (46), then fit O-ring to case (47) and install.
  3. **Cover, check valve, arm counterbalance valve**
    - 1) Fit O-rings and install cover (46) and (45).  
 Mounting bolt of cover (46):  
 $277.1 \pm 32.3 \text{ Nm}$  ( $28.3 \pm 3.3 \text{ kgm}$ )
    -  Mounting bolt of cover (45):  
 $166.3 \pm 10.3 \text{ Nm}$  ( $17 \pm 1 \text{ kgm}$ )
      - ★ Tighten the mounting bolts in the order shown in the diagram.
    - 2) Assemble check valve (44) and spring (43), then fit O-ring to flange (42) and install.
    - 3) Fit O-ring to arm counterbalance valve (41) and install. Mounting bolt:  
 $31 \pm 3.5 \text{ Nm}$  ( $3.2 \pm 0.4 \text{ kgm}$ )
    - ★ Tighten the mounting bolts in the order shown in the diagram.
  4. **Travel control valve, stabiliser control valve**
    - 1) assemble spool assembly (37) to valve body.
    - 2) Assemble retainer (40) and spring (39) to spool, then fit O-ring to case (38) and install.  
 ★ Check springs (32) and (39), and be careful not to mistake them when installing. Mounting bolt:  
 $11.3 \pm 1.5 \text{ Nm}$  ( $1.2 \pm 0.2 \text{ kgm}$ )
  5. **Bucket control valve, arm control valve, boom control valve, swing control valve**
    - 1) Assemble spool assembly (30) to valve body.
    - 2) Assemble retainer (33) and spring (32) to spool, then fit O-ring to case (31) and install.  
 ★ Check spring (32) when installing. Mounting bolt:  
 $11.3 \pm 1.5 \text{ Nm}$  ( $1.2 \pm 0.2 \text{ kgm}$ )
    - 3) Assemble retainer (29) and spring (28) to spool, then fit O-ring to case (27) and install. Mounting bolt:  
 $11.3 \pm 1.5 \text{ Nm}$  ( $1.2 \pm 0.2 \text{ kgm}$ )
  6. **LS shuttle valve, LS select valve**
    - 1) Fit O-ring and install LS select valve (26).  
 LS select valve:  
 $127.5 \pm 19.6 \text{ Nm}$  ( $13 \pm 2 \text{ kgm}$ )
    - 2) Fit O-rings and install LS shuttle valves (25a) and (25b).  
 LS shuttle valve:  
 $166.7 \pm 19.6 \text{ Nm}$  ( $17 \pm 2.0 \text{ kgm}$ )
      - ★ Check valve (25a) and (25b) and be careful not to mistake them when installing.
  7. **Pressure compensation valve**  
Check marks made on each pressure compensation valve when disassembling, and install pressure compensation valves in correct position.
    - 1) Before installing pressure compensation valves below, install check valves (17) and (24).
    - 2) Fit O-ring, then install swing LEFT pressure compensation valve (21) Right and Left, travel FORWARD pressure compensation valve (20), boom RAISE pressure compensation valve (19), and bucket DUMP pressure compensation valve (18)
    - 3) Fit O-ring, then install swing RIGHT pressure compensation valve (13), Right and Left travel REVERSE pressure compensation valve (12), boom LOWER pressure compensation valve (11), arm IN pressure compensation valve (11), and bucket CURL pressure compensation valve (11).  
 Pressure compensation valve:  
 $225.5 \pm 19.5 \text{ Nm}$  ( $23 \pm 2 \text{ kgm}$ )
  8. **Suction valves, safety-suction valves, unload valve**
    - 1) Fit O-rings and install suction valves (10) and (9).  
 Suction valve:  
 $147.1 \pm 9.8 \text{ Nm}$  ( $15 \pm 1 \text{ kgm}$ )
    - 2) Fit O-rings and install safety-suction valves (8), (7), (6), (5) and (4).  
 Safety-suction valve:  
 $147.1 \pm 9.8 \text{ Nm}$  ( $15 \pm 1 \text{ kgm}$ )
    - 3) Fit O-ring and install unload valve (3).  
 Unload valve :  
 $166.7 \pm 19.7 \text{ Nm}$  ( $17 \pm 2 \text{ kgm}$ )
  9. **Main relief valve**
    - 1) Fit O-ring and install main relief valve (1).  
 Main relief valve:  
 $98.1 \pm 9.8 \text{ Nm}$  ( $10 \pm 1 \text{ kgm}$ )




## DISASSEMBLY OF LS SELECT VALVE




1. Remove sleeve (2) and spring (3) from sleeve (1).
2. Remove O-rings (4) and (5), and seal (6) from sleeve (1).
3. Remove plug (7), then remove pistons (8) and (9), and spring (10).
4. Remove O-ring (11) from plug (7), then remove seal (12) and O-ring (13) from piston (9).
  - ★ After disassembling, if there is any abnormality in any part except O-rings (4), (5), (11), or seal (6), replace the whole LS select valve assembly.

## ASSEMBLY OF LS SELECT VALVE

- Before assembling coat the sliding surface with engine oil.
1. Install O-ring (13) and seal (12) to piston (9), then assemble piston (8) and spring (10), and install in sleeve (1).
  2. Assemble O-ring (11) to plug (7) and install to sleeve (1).
    -  **kgm** Plug:  $68.6 \pm 9.9$  Nm ( $7 \pm 1$  kgm)
  3. Assemble spring (3) to sleeve (2), and install to sleeve (1).
  4. Install O-rings (4) and (5), and seal (6) to sleeve (1).

## DISASSEMBLY OF LS SHUTTLE VALVE

- A: LS shuttle valve for work equipment (bucket, arm, boom).
- B: LS shuttle valve for right travel C: LS shuttle valve for left travel
- ★: The structure of the parts is the same, but the parts number for the assembly is different, so be careful when assembling.



202F06543

1. Remove seat (2) from plug (1), then remove O-ring (3) and ring (4).
2. Remove ball (5) from plug (1), then remove O-rings (6) and (7), and ring (8).
  - ★ After disassembling, if there is any abnormality in plug (1), seat (2), or ball (5), replace the whole LS shuttle valve assembly.

## ASSEMBLY OF LS SHUTTLE VALVE


- Before assembling coat the sliding surface with engine oil.
1. Install ring (8) and O-rings (7) and (6) to plug (1).
  2. Fit ring (4) and O-ring (3) to seat (2), then assemble ball (5) to plug (1), and install seat (2).

## IDENTIFICATION OF LS SHUTTLE VALVE


Shuttle valves are identified by markings on the valve assembly.

- Type A - 1 mark
- Type B - No mark
- Type C - 3 marks


Type A




Type B



Type C



## DISASSEMBLY OF PRESSURE COMPENSATION VALVE ASSEMBLY



- **Disassembly of pressure compensation valves A,C,D**

- The structure of the parts for pressure compensation valves A, C and D is the same, but the part number for the assembly marked ★ is different, so be careful when assembling.

1. Remove piston (2) and spring (3) from sleeve (1).
2. Remove plug (4) and ball (5) from piston (2).
3. Remove seals (6) and (7) from piston (2).
4. Remove O-ring (8) from sleeve (1), then remove seals (9) and (10), and O-ring (11).

- \* After disassembling, if there is any abnormality in sleeve (1), piston (2), plug (4), ball (5), or seals (6) and (7), replace the whole pressure compensation valve assembly.

- **Disassembly of pressure compensation valve B**

1. Remove piston (13) and spring (14) from sleeve (12).
2. Remove seals (15) and (16) from piston (13), then remove O-ring (17), seals (18) and (19), and O-ring (20) from sleeve (12).

- \* After disassembling, if there is any abnormality in sleeve (12), piston (13), or seals (15) and (16), replace the whole pressure compensation valve assembly.

### IDENTIFICATION OF PRESSURE COMPENSATION VALVE ASSEMBLY

Valves are identified by markings on the valve assembly.

Type A - 1 mark.

Type C - 3 marks.


Type D - 4 marks.

Type B - No mark.

## ASSEMBLY OF PRESSURE COMPENSATION VALVE ASSEMBLY


## Pressure compensation valves

- A: For bucket CURL/DUMP, boom Lower, arm IN.  
 C: For swing LEFT/RIGHT  
 D: For arm OUT, boom RAISE  
 B: For travel



- Before assembling coat the sliding surface with engine oil.
- **Assembly of pressure compensation valve B**
  1. Install O-rings (17) and (20), and seals (19) and (18) to sleeve (12).
  2. Fit seals (16) and (15) to piston (13), then assemble spring (14) and install to sleeve (12).
- **Assembly of pressure compensation valves A, C, D**
  1. Install O-rings (8) and (11), and seals (10) and (9) to sleeve (1).
  2. Fit seals (7) and (6) to piston (2), then assemble ball (5), plug (4), and spring (3), and install to sleeve (1).


## DISASSEMBLY OF MAIN RELIEF VALVE ASSEMBLY



202F06545


1. Remove ring (1), then remove valve (2) and spring (3).
  2. Loosen nut (4) and remove plug (5), then remove O-ring (6) and nut (4) from plug (5).
  3. Loosen nut (7) and remove holder (8), then remove retainer (9), O-ring (10), and nut (7) from holder (8).
  4. Remove spring (12) and poppet (13) from sleeve (11), then remove sleeve (14) and seat (15).
  5. Remove ring (16) and O-ring (17) from seat (15).
  6. Remove O-ring (18), seal (19), and O-ring (20) from sleeve (11).
- ★ After disassembling, if there is any abnormality in valve (2), holder (8), retainer (9), sleeve (14), seat (15), ring (16), O-ring (17), or sleeve (11), replace the whole main relief valve assembly.

## ASSEMBLY OF MAIN RELIEF VALVE ASSEMBLY




202F06545

- Before assembling coat the sliding surface with engine oil.
- 1. Install O-ring (17) and ring (16) to seat (15), and assemble sleeve (11).
- 2. Assemble sleeve (14) to sleeve (11).
- 3. Install nut (7) and O-ring (10) to holder (8), then assemble retainer (9), poppet (13), and spring (12), and install to sleeve (11).
  - ★ Set contact surface of seat (15) and poppet (13) in position securely.
- 4. Assemble nut (4) and O-ring (6) to plug (5), and install to holder (8).
- 5. Assemble spring (3) and valve (2) to sleeve (11), and install ring (1).
- 6. Install O-rings (20) and (18), and seal (19) to sleeve (11).
- 7. Tighten nut (7) to specified torque.

 **kgm** Nut: 58.8±4.9 Nm (6±0.5 kgm)


- 8. Tighten nut (4) to specified torque.


 **kgm** Nut: 44.1±4.9 Nm (4.5±0.5 kgm)

- ★ After installing to the control valve assembly, adjust the pressure.  
For details, see TESTING AND ADJUSTING, Testing and adjusting oil pressure of work equipment, swing, travel circuits.



## REMOVAL OF LS CONTROL EPC VALVE ASSEMBLY


1. Remove cover.
2. Disconnect wiring connector (1).
3. Disconnect hose (2).
4. Remove LS control EPC valve assembly (3). 



## INSTALLATION OF LS CONTROL EPC VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.





 LS control EPC valve mounting bolt:  
11.3±1.5 Nm(1.15±0.15 kgm)

## REMOVAL OF SOLENOID VALVE ASSEMBLY

**⚠** Disconnect the cable from the negative (-) terminal of the battery.

1. Open R.H. side cover.
  2. Remove wiring connector cover (1).
  3. Remove 5 solenoid wiring connectors (2) from clip, then disconnect.
    - ★ Mark the male and female ends of each connector with tags to prevent mistakes when connecting.
  4. Disconnect 10 hoses (3).
    - ★ Fit tags on the hoses.
  5. Remove mounting bolts, then remove solenoid valve assembly (4).
- When removing solenoid valve as an individual part Remove mounting nut (5), then remove solenoid valve (6).





## INSTALLATION OF SOLENOID VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.



**\* I**





**kgm** Mounting nut (5):  
4.9±0.98 Nm (0.5±0.1 kgm)

**kgm** Solenoid valve (6) (individual part):  
39.2±9.8 Nm (4±1 kgm)




## REMOVAL OF PPC SHUTTLE VALVE ASSEMBLY

- ⚠** Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
1. Disconnect the cable from the negative (-) terminal of the battery.
    - ★ Make match marks at the male and female ends of the oil pressure switch connectors.
    - ★ Before disconnecting any hoses, check the distinguishing tape stuck to the hose, or make match marks.
  1. Disconnect 8 oil pressure switch connectors (1).  
2. Disconnect 12 PPC hoses (2). 
  3. Disconnect 15 control valve hoses (3) (quick joint connection). 
  4. Disconnect 4 straight-travel hoses (4).
    - ★ The elbows on the front two hoses are long, so hold the elbow with a wrench when disconnecting the hoses.



5. Disconnect clamp (5).
6. Remove mounting bolts, then remove PPC shuttle valve assembly (6).




## INSTALLATION OF PPC SHUTTLE VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.

**\*** 1

- Check that the quick joint does not come out when the hose is pulled.
- **Refilling with oil (hydraulic tank)**
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.

## DISASSEMBLY OF PPC SHUTTLE VALVE ASSEMBLY



SDP00610

**1. Disconnection of valve**

Remove mounting bolts (1), and disconnect shuttle valve assembly (2), travel junction valve assembly (3) and plate (4).


**2. Disassembly of shuttle valve assembly**

- 1) Remove 8 oil pressure switches (5).
- 2) Remove 2 slow return valves (6).
- 3) Remove shuttle valve (7).
- 4) Remove plugs (8), then remove balls (9).
  - ★ There are 6 plugs and 6 balls.

**3. Disassembly of travel junction valve assembly**

- 1) Remove 2 each of plug (10), spring (11), and retainer (12).
- 2) Remove spool (13).
- 3) Remove 2 plugs (14).


## ASSEMBLY OF PPC SHUTTLE VALVE ASSEMBLY



SDP00610


**1. Assembly of travel junction valve assembly.**

- 1) Fit O-ring and install 2 plugs (14).

 Plug:

**17.16±2.45 Nm (1.75±0.25 kgm)**

- 2) Assemble spool (13), and install 2 retainers (12) and springs (11).
- 3) Fit O-ring and install 2 plugs (10).


 Plug:

**107.9±14.7 Nm (11.0 ± 1.5 kgm)**

**2. Assembly of shuttle valve assembly**

- 1) Fit O-ring and assemble balls (9), then install plugs (8).

★ There are 6 plugs and 6 balls.

 Plug:

**34.3 ± 4.9 Nm (3.5 ± 0.5 kgm)**

- 2) Fit O-ring and install shuttle valve (7).
  - ★ If the shuttle valve has been disassembled, be careful of the direction of installation of the poppet when assembling.
- 3) Fit O-ring and install 2 slow return valves (6).

★ If the slow return valve has been disassembled, be careful of the direction of installation of the poppet when assembling.

- 4) Install 8 oil pressure switches (5).

**3. Connection of valve**

Fit O-ring and assemble shuttle valve assembly (2), travel junction valve assembly (3) and plate (4), then tighten mounting bolts (1).



 Mounting bolt:

**66.19±7.35 Nm (6.75±0.75 kgm)**

## REMOVAL OF WORK EQUIPMENT • SWING PPC VALVE ASSEMBLY

**⚠** Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.


1. Remove armrest and rubber boot, remove cover, and disconnect wiring connector (1).
2. Remove boot (2) from cover, raise boot, then remove lever (3).
  - ★ Mark the mounting position of the lever before removing.
3. Remove 4 mounting bolts (5) of cover (4), then remove.
  - ★ Remove the lock with a screwdriver and gradually lift the cover up to remove.
4. Remove joint bolt (6), and disconnect hose (7). \* 1
5. Remove mounting bolts, raise PPC valve assembly (8). Then disconnect hoses (9) and (10), and remove. \* 2
  - ★ Mark the connecting position of the hoses before disconnecting.




## INSTALLATION OF WORK EQUIPMENT • SWING PPC VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.




\* 1

 **kgm** Hose mounting joint bolt:  
29.4±4.9 Nm (3.0±0.5 kgm)

\* 2

 **kgm** Hose mounting joint bolt:  
39.2±4.9 Nm (4.0±0.5 kgm)



- ★ If there is excessive play in the control levers, adjust the PPC valve. for details, see TESTING AND ADJUSTING, Adjusting PPC valve.



## REMOVAL OF TRAVEL PPC VALVE ASSEMBLY

**⚠** Lower the work equipment completely to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then set the safety lock lever to the LOCK position.

1. Remove floor mat.
2. Remove travel PPC valve bottom cover.
3. Remove pedals (1) and levers (2). \* 1
4. Remove cover (3). \* 2
5. Remove covers (4), then remove springs (5).
6. Disconnect 6 PPC Hoses (7), and remove travel PPC valve assembly (8). \* 4



## INSTALLATION OF TRAVEL PPC VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.



\* 1 ★ Adjust the travel lever. For details, see TESTING AND ADJUSTING, Adjusting travel lever.

\* 2 Cover mounting bolt:  
19.6±2 Nm (2.0±0.2 kgm)

\* 3 Sliding portion of pin: Grease (G2-LI)

\* 4 Hose mounting joint bolt (width across flats: 30 mm): 39.2 ± 4.9 Nm (4.0 ± 0.5 kgm)

Hose mounting joint bolt (width across flats: 22 mm) 29.4 ± 4.9 Nm (3.0 ± 0.5 kgm)






## DISASSEMBLY OF TRAVEL PPC VALVE ASSEMBLY

1. Remove cover and cam assembly (1), then remove shims (2).
  - ★ Check the number and thickness of shims (2) for each mounting position, and keep in a safe place.
2. Remove plate (3).
3. Remove seal (4) and collar (5).
4. Pull out piston (6), and remove retainer (7), springs (8) and (9), and shims (10).
  - ★ Check the number and thickness of shims (10) for each mounting position, and keep in a safe place.
5. Pull out valve (11) from body (12).


## ASSEMBLY OF TRAVEL PPC VALVE ASSEMBLY


1. Assemble valve (11) in body (12).
2. Assemble shims (10) and spring (9) to valve (11).
  - ★ Assemble the same number and thickness of shims (10) as was removed during disassembly. Standard shim thickness: 0.3 mm
  - ★ Spring (9) is not symmetrical at the top and bottom, so assemble with the small coil diameter (inside diameter) at the shim end.

3. Assemble spring (8), retainer (7), and piston (6).

 Outside circumference of piston, body hole:  
Grease (G2-LI)



4. Fit O-ring to collar (5) and assemble in body (11), then install seal (4).
5. Assemble plate (3).
6. Fit cover and cam assembly (1) and assemble shims (2), then tighten with bolt.


 Sliding portion of shaft, connecting portion of lever and piston: Grease (G2-LI)



22TF01532

- ★ Assemble the same number and thickness of shims (2) as was removed during disassembly.  
Standard shim thickness: 1,6 mm

-  **kgm** Mounting bolt (a):  
27.9 ± 3.4 Nm (2.85 ± 0.35 kgm)
-  **kgm** Mounting bolt (b):  
30.9 ± 3.4 Nm (3.15 ± 0.35 kgm)






## REMOVAL OF BOOM CYLINDER ASSEMBLY

**⚠** Extend the arm and bucket fully, lower the work equipment completely to the ground, and put the safety lock lever in the LOCK position.

1. Disconnect grease hose (1).
2. Sling boom cylinder assembly (2), and remove lock bolt (3). \* 1
3. Remove plate, then remove head pin (4). \* 2
  - ★ There are shims installed, so check the number and thickness, and keep in a safe place.
4. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.
  - ★ Set stand ① under the cylinder assembly, and adjust the position for slinging.
  - ⚠ Release the remaining pressure in the hydraulic circuit. For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
5. Disconnect hoses (5).
6. Remove plate, then using forcing screws ②, remove bottom pin (6), and remove boom cylinder assembly (2). \* 3
  - ★ There are shims installed, so check the number and thickness, and keep in a safe place.



Boom cylinder assembly 135 kg




## INSTALLATION OF BOOM CYLINDER ASSEMBLY


- Carry out installation in the reverse order to removal.


✳ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 - 1.5 mm.

✳ 2


 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)


 Greasing after assembling pin:  
Grease (LM-G)


 When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between cylinder rod (7) and plate (8) is below 1 mm.
- ★ Standard shim thickness: 0.5 mm, 1.0 mm

✳ 3




 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)

 Greasing after assembling pin:  
Grease (LM-G)

 When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between cylinder bottom (9) and bracket (10) is below 1 mm.
- ★ Standard shim thickness: 0.8 mm, 1.5 mm

- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air from the cylinder. For details, see TESTING AND ADJUSTING, Bleeding air from hydraulic cylinder.



## REMOVAL OF ARM CYLINDER ASSEMBLY


**⚠** Extend the arm cylinder piston rod approx. 200 mm, lower the work equipment completely to the ground, then set the remaining safety lock lever to the LOCK position.

1. Set block ① between arm cylinder and boom.
2. Remove plate, then remove head pin (1). \* 1
3. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.
 

**⚠** Release the remaining pressure in the hydraulic circuit. For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
4. Disconnect hoses (2).
5. Disconnect grease hose (3).
6. Raise arm cylinder assembly, remove plate, remove bottom pin (4), then remove arm cylinder assembly (5). \* 2
  - ★ There are shims installed, so check the number and thickness, and keep in a safe place.




Arm cylinder assembly 200 kg




## INSTALLATION OF ARM CYLINDER ASSEMBLY

- Carry out installation in the reverse order to removal.


※ 1


 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)

 Greasing after assembling pin: Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.

※ 2

 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)


 Greasing after assembling pin: Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between cylinder bottom (6) and bracket (7) is below 1 mm.

- ★ Standard shim thickness: 0.8 mm, 1.5 mm

- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air from the cylinder. For details, see TESTING AND ADJUSTING, Bleeding air from hydraulic cylinder.



## REMOVAL OF BUCKET CYLINDER ASSEMBLY

**⚠** Extend the bucket cylinder piston rod approx. 200 mm, lower the work equipment completely to the ground, then set the safety lock lever to the LOCK position.



1. Set block ① under arm top.
2. Set block ② between link and arm, and block ③ between bucket cylinder and arm.
3. Remove lock bolt (1). \* 1
4. Remove plate, then remove head pin (2). \* 2
  - ★ There are shims installed, so check the number and thickness, and keep in a safe place.
5. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.

**⚠** Release the remaining pressure in the hydraulic circuit. For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.

6. Disconnect 2 hoses (3).
7. Raise bucket cylinder assembly, remove plate, remove bottom pin (4), then remove bucket cylinder assembly (5). \* 3
  - ★ There are shims installed, so check the number and thickness, and keep in a safe place.



Bucket cylinder assembly: 130 kg




## INSTALLATION OF BUCKET CYLINDER ASSEMBLY


- Carry out installation in the reverse order to removal.

✳ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 - 1.5 mm.

✳ 2

 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)


 Grease after assembling pin: Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between link (6) and link (7) is below 1 mm.

✳ 3

- ★ Standard shim thickness: 0.8 mm, 1.5 mm

 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)




 Grease after assembling pin: Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between cylinder bottom (8) and bracket (9) is below 1 mm.

- ★ Standard shim thickness: 0.8 mm, 1.5 mm

- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air from the cylinder. For details, see TESTING AND ADJUSTING, Bleeding air from hydraulic cylinder.









## DISASSEMBLY OF HYDRAULIC CYLINDER ASSEMBLY

1. Piston rod assembly
  - 1) Remove piping from cylinder assembly.
  - 2) Remove mounting bolts, and disconnect head assembly (1).
  - 3) Pull out piston rod assembly (2).
    - ★ Place a container to catch the oil under the cylinder.
- 4) Disassemble piston rod assembly as follows.
  - i) Set piston rod assembly (2) in tool O<sub>1</sub>.
  - ii) Using tool O<sub>2</sub>, remove nut (3).
    - ★ Width across flats of nut

Unit: mm


Model	Cylinder		
	Boom	Arm	Bucket
PC180/PC160	75	85	75

- iii) Remove piston assembly (4).
- iv) Remove plunger (5).
  - Boom and arm cylinder only
- v) Remove collar (6).
  - Boom and arm cylinder only
- vi) Remove head assembly (7).
- vii) Remove cap (8), and pull out 12 balls (9), then remove plunger (10).
  - Arm cylinder only




**2. Disassembly of piston assembly**

- 1) Remove rings (11).
- 2) Remove wear rings (12).
- 3) Remove piston ring (13).

**3. Disassembly of cylinder head assembly**

- 1) Remove O-ring and backup ring (14).
- 2) Remove snap ring (15), then remove dust seal (16).
- 3) Remove rod packing (17).
- 4) Remove buffer ring (18).
- 5) Remove bushing (19).






## ASSEMBLY OF HYDRAULIC CYLINDER ASSEMBLY

- ★ Be careful not to damage the packings, dust seals, and O-rings.
- ★ Do not try to force the backup ring into position. Warm it in warm water (50 - 60°C) before fitting it.



### 1. Assembly of cylinder head assembly

- 1) Using tool **O<sub>5</sub>**, press fit bushing (19).
- 2) Assemble buffer ring (18).
- 3) Assemble rod packing (17).
- 4) Using tool **O<sub>6</sub>**, install dust seal (16), and secure with snap ring (15).
- 5) Install backup ring and O-ring (14).




### 2. Assembly of piston assembly

- 1) Using tool **O<sub>3</sub>**, expand piston ring (13).
  - ★ Set the piston ring on the tool **O<sub>3</sub>**, and turn the handle 8 - 10 times to compress the ring.
- 2) Set tool **O<sub>4</sub>** in position, and retract piston ring (13).




- 3) Assemble wear ring (12).
- 4) Assemble ring (11).
  - ★ Be careful not to open the end gap of the ring too wide.

 Ring groove: Grease (G2-LI)




3. Piston rod assembly

- 1) Set plunger (10) to piston rod, and assemble 12 balls (9), then secure with cap (8).
  - ★ Check that there is a slight play at the tip of the plunger.
  - Arm cylinder only



- 2) Assemble head assembly (7).
- 3) Fit O-ring and backup ring, and assemble collar (6).
  - Boom and arm cylinder only
- 4) Assemble plunger (5).
  - Boom and arm cylinder only
- 5) Assemble piston assembly (4).




- 6) Set piston rod assembly (2) to tool O<sub>1</sub>.
- 7) Using tool O<sub>2</sub>, tighten nut (3).

Nut: Thread tightener (LT-2)

Nut:

Unit: kNm (kgm)


Cylinder Model	Boom	Arm	Bucket
PC180	6.3±0.1	7.75±0.25	6.3±0.1
PC160	(642.5±10.5)	(790.5±25.5)	(642.5±10.5)



- 8) Assemble piston rod assembly (2).

Seal: Grease (G2-LI)

- ★ Set the end gap of the ring at the horizontal (side) position, align the center of shaft and cylinder tube, then insert.
- ★ After inserting, check that the ring is not broken and has not come out, then push in fully.




9) Tighten head assembly (1) with mounting bolts.

 Mounting bolt:



Cylinder	Tightening torque
Boom Arm Bucket	330±10 Nm (33.7±1.0 kgm)

10) Install piping.



## REMOVAL OF WORK EQUIPMENT ASSEMBLY

**!** Extend the arm and the bucket fully and lower the work equipment completely to the ground, then operate the control levers 2 to 3 times.

1. Remove lock bolt (1). (See F) 
2. Remove pin (2). (See F1) 
  - ★ Sling the boom cylinder assembly and remove the pin.





**!** Start the engine and retract the boom cylinder rod, then tie the rod with wire to prevent it from coming out, and lower it onto the block.

- ★ Disconnect the boom cylinder on the opposite side in the same way.

**!** Release the remaining pressure in the circuit. For details, see TESTING AND ADJUSTING, Releasing pressure in hydraulic circuit for machines with PPC valve.

3. Disconnect hoses (3). (See F2)
4. Disconnect wiring (4). (See F2)
5. Remove pin (5). (See F3)
  - ★ Sling work equipment assembly (6), then using tool H, remove the pin.
6. Remove work equipment assembly (6). (See F4)

 600kg




## INSTALLATION OF WORK EQUIPMENT ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 - 1.5 mm.


※ 2


 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)

 Grease after assembling pin: Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between cylinder rod (10) and plate (11) is below 1 mm.
- ★ Standard shim thickness: 0.8 mm, 1.5 mm




※ 3

 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)

 Grease after assembling pin: Grease (LM-G)





- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between boom (12) and bracket (13) is below 1 mm.
- ★ Standard shim thickness: 0.5 mm, 1.0 mm


- Refilling with oil (hydraulic tank)
  - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air
  - ★ Bleed the air from the cylinder. For details, see TESTING AND ADJUSTING, Bleeding air from hydraulic cylinder.



## REMOVAL OF BUCKET ASSEMBLY

- ⚠ Set the back of the bucket facing down, lower the work equipment completely to the ground, and operate the control levers 2 of 3 times.

1. Remove lock bolt (1). (See F1) 
2. Remove plate (2). (See F1) 
3. Remove pin (3). (See F1) 
4. Remove lock bolt (4). (See F1) 
5. Remove pin (5). (See F1)
6. Remove bucket assembly (6). (See F1)
  - ★ Raise the work equipment and disconnect the arm from the bucket.



## INSTALLATION OF BUCKET ASSEMBLY

- Carry out installation in the reverse order to removal.



- ★ Tighten with the locknut so that the clearance between the bucket boss and nut is 0.5 - 1.5mm. (See F2)




- ★ Adjust the shim thickness so that the clearance between bucket boss (7) and spacer (8) is 2mm. (See F3)



- ★ When aligning the position of the pin hole, run the engine at low idling, and align slowly.  
Never insert your fingers in the pin hole.

## REMOVAL OF ARM ASSEMBLY

1. Bucket assembly  
For details, see REMOVAL OF BUCKET ASSEMBLY.
2. Set work equipment
  - ★ Secure the bucket cylinder assembly to the arm, then pull in the arm, and lower it onto block ①.
3. Remove pin (1). (See F4) 
  - ★ Sling the arm cylinder assembly, and remove the pin.

- ⚠ Start the engine, and retract the arm cylinder rod, then tie the rod with wire to prevent it from coming out.



- Release the remaining pressure in the circuit. For details, see TESTING AND ADJUSTING, Releasing pressure in hydraulic circuit for machines with PPC valve.

4. Disconnect hoses (2). (See F4)
5. Remove pin (3). (See F4)
6. Remove arm assembly (4). (See F4)
  - ★ Raise the boom and disconnect the boom from the arm.



See Weight Table.

## INSTALLATION OF ARM ASSEMBLY

- Carry out installation in the reverse order to removal.




- ⚠ When aligning the position of the pin hole, run the engine at low idling, and align slowly.  
Never insert your fingers in the pin hole.


- Bleeding air
  - ★ Bleed the air from the cylinder.  
For details, see TESTING AND ADJUSTING, Bleeding air from hydraulic cylinder.
  - ★ After bleeding the air from the cylinder, check the level of the oil in the hydraulic tank.




F4




F1



F2




F3





## REMOVAL OF ARM, BUCKET ASSEMBLY

Extend the arm and bucket fully, lower the work equipment completely to the ground, and operate the control levers 2 or 3 times.

1. Remove pin (1). (See F1) 

★ Set block ① between the arm and the boom, then sling the arm cylinder, and remove the pin.

 Start the engine, and retract the arm cylinder rod, then tie the rod with wire to prevent it from coming out.

 Release the remaining pressure in the circuit. For details, see TESTING AND ADJUSTING, releasing pressure in hydraulic circuit for machines with PPC valve.

2. Disconnect hose (2). (See F2)

3. Remove pin (3). (See F2)

★ Sling the arm and bucket assembly, then remove the pin.

4. Remove arm and bucket assembly (4). (See F2)




See Weight Table.

## INSTALLATION OF ARM, BUCKET ASSEMBLY

- Carry out installation in the reverse order to removal.




 When aligning the position of the pin hole, run the engine at low idling, and align slowly. Never insert your fingers in the pin hole.

- Bleeding air


- ★ Bleed the air from the cylinder. For details, see TESTING AND ADJUSTING, Bleeding air from hydraulic cylinder.
- ★ After bleeding the air from the cylinder, check the level of the oil in the hydraulic tank.

F1





F20505339


F2




F20106128

## REMOVAL OF BOOM ASSEMBLY

1. Arm and bucket assembly  
For details, see REMOVAL OF ARM, BUCKET ASSEMBLY.
2. Remove lock bolt (1). (See F1) 
3. Remove pin (2). (See F1) 
  - ★ Sling the boom cylinder assembly, and remove the pin.

 Start the engine, and retract the boom cylinder rod, then tie the rod with wire to prevent it from coming out, and lower it into the block.


- ★ Disconnect the boom cylinder assembly on the opposite side in the same way.

 Release the remaining pressure in the circuit. For details, see TESTING AND ADJUSTING, Releasing pressure in hydraulic circuit for machines with PPC valve.


4. Disconnect hose (3). (See F1)
5. Disconnect wiring (4). (See F2)
6. Remove pin (5). (See F3)
  - ★ Sling the boom assembly, then use tool H to remove the pin.
7. Remove boom assembly (6). (See F4)

 See Weight Table.


F1




F2



F3



F4




# INSTALLATION OF BOOM ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 - 1.5 mm.


※ 2


 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)

 Grease after assembling pin: Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between cylinder rod (10) and plate (11) is below 1 mm.
- ★ Standard shim thickness: 0.8 mm, 1.5 mm

※ 3

 Inside surface of bushing when assembling pin: Anti-friction compound (LM-P)

 Grease after assembling pin: Grease (LM\_G)




- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between boom (12) and bracket (13) is below 1 mm.
- ★ Standard shim thickness: 0.5 mm, 1.0 mm

### Refilling with oil (hydraulic tank)

- ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.

- Bleeding air

- ★ Bleed the air from the cylinder. For details, see TESTING AND ADJUSTING, Bleeding air from hydraulic cylinder.



## REMOVAL OF OPERATOR'S CAB ASSEMBLY





**⚠** Disconnect the table from the negative (-) terminal of the battery.

1. Remove floor mat (1).
2. Remove operator's seat assembly (2).





Operator's seat assembly: 40 kg

3. Remove knob (3).
4. Remove 4 caps (4) and clip (5), then remove middle panel (6).
5. Remove bottom panel (7).
  - ★ The panel is held by a clip, so remove the clip when removing the panel and be careful not to damage it.
6. Disconnect washer hose (8).
7. Remove radio (11) if fitted (refer to radio operation manual).
  - ★ Remove plate (9), then remove cover (10).
8. Lift cover (10) away carefully to locate speaker harness connector. Disconnect and remove panel completely.




9. Remove divider board (13).
10. Remove heater duct of air conditioner ducts (14) and (15) (if fitted).
11. Disconnect wiring connectors CN-H01 (16), CN-H02 (17), CN-H03 (18), CN-H04 (19), CN-H05 (20), CN-H06 (21), CN-K01 (22), CN-H07 CN-H08 CN-H09



12. Disconnect heater cables or air conditioner cables (24) (if fitted).

13. Remove 11 cab mounting bolts (marked \*).




14. Using eyebolts ①, remove operator's cab assembly (25).



Operator's cab assembly: 300 kg

- ★ When raising the cab assembly, check that all the wiring has been disconnected, then lift off slowly and be careful not to hit any part.



## INSTALLATION OF OPERATOR'S CAB ASSEMBLY

- Carry out installation in the reverse order to removal.




## REMOVAL OF COUNTERWEIGHT ASSEMBLY

1. Set lifting hook chains of counterweight assembly in position, and sling.
2. Remove mounting bolts (2) and (3). \* 1  
★ Be careful not to lose the shims when removing.
3. Lift off counterweight (1) horizontally with wire or chain block. \* 2  
★ Be careful not to hit the engine, radiator and cooler assembly.



Counterweight assembly: 2950 kg



## INSTALLATION OF COUNTERWEIGHT ASSEMBLY

- Carry out installation in the reverse order to removal.

\* 1




Thread of counterweight mounting bolt:  
Thread tightener (LT-2)



Counterweight mounting bolt:  
 $1,720 \pm 190\text{Nm}$  ( $175 \pm 20\text{kgm}$ )

\* 2



- ★ Installing and adjusting counterweight
  - 1) Sling counterweight with crane and set in position on frame.
  - 2) Use counterweight pusher bolt (2) and align mounting bolts holes. Then install shim and mounting bolts (2) and (3), and adjust to following dimensions.
    - Clearance from revolving frame:  
 $10 \pm 5\text{ mm}$  (left and right)
    - Clearance from bodywork door:  
 $10 \pm 5\text{ mm}$  (left and right)
    - Stepped difference (b) from revolving frame in left-to-right direction:  
Max. 5 mm
    - Stepped difference (a) from bodywork door in left-to-right direction:  
 $10 \pm 4\text{ mm}$
    - Stepped difference (c) from bodywork top cover in up-down direction:  
Max. 5 mm



## REMOVAL OF GOVERNOR PUMP CONTROLLER ASSEMBLY

**⚠** Disconnect the cable from the negative (-) terminal of the battery.

1. Remove radio (2) if fitted.
2. Remove plate (1), then remove cover (3).
3. Lift cover (3) away carefully to locate speaker harness connector. Disconnect and remove panel completely.
4. Remove divider board (5).
5. Remove heater / air conditioner duct (5).
6. Disconnect 3 wiring connectors (6), then remove governor and pump controller assembly (7).




## INSTALLATION OF GOVERNOR, PUMP CONTROLLER ASSEMBLY

- Carry out installation in the reverse order to removal.

**\* 1**


- Check the performance of the work equipment, travel, and swing. For details, see TESTING AND ADJUSTING.



## REMOVAL OF MONITOR PANEL ASSEMBLY

**⚠** Disconnect the cable from the negative (-) terminal of the battery.

1. Remove 4 screws (1), and disconnect monitor panel assembly (2) from bracket.
2. Disconnect connectors (3), then remove monitor panel assembly (2). \* 1







## INSTALLATION OF MONITOR PANEL ASSEMBLY

- Carry out installation in the reverse order to removal.


\* 1

- Check the mode setting and display function. For details, see TESTING, AND ADJUSTING, AND TROUBLESHOOTING.





DISASSEMBLY AND ASSEMBLY



P082741

# ADAPTER WELDING INSTRUCTION - ELECTRODE WELDING

**BE SAFE!**

When performing the procedures described in this catalog, you should WEAR OSHA-approved hard hat, safety glasses, work gloves and safety shoes.

**IMPORTANT!**

ESCO weld-on Helilok adapters are hardened typically to 415BHN. In order to eliminate cracking commonly associated with welding steel at these hardness levels, follow these procedures carefully and employ good welding techniques and practices.

**Summary of Welding Procedures**

Mating surfaces to be welded should be shiny base metal, free of carbon arc surface, hardfacing, grease or dirt.

Use E-7016 or E-7018 low-hydrogen electrodes (keep dry!), or E-70T-5 low-hydrogen wire.

Preheat the lip and adapter to 200°F (95°C); 350° to 400°F (117° to 204°C) if surrounding air temperature is 40°F (5°C) or less. Measure temperature with a Tempilstik®.

Maintain preheat temperature while welding.

Maximum interpass temperature should not exceed 500°F (260°C).

After welding, postheat to 350° to 400°F (117° to 204°C) if surrounding air temperature is 40°F (5°C) or less, then let air-cool. If air temperature is above 40°F, postheating is not necessary.

Welds should fill J-grooves to a 45° angle. If an adapter does not have a J-groove, apply fillet welds according to the following:



Bucket Size (volume)

Yards <sup>3</sup>	Meter <sup>3</sup>	Fillet Size
2	1.8	1/2" (13mm)
2 1/4 - 5	2 - 4.6	5/8" (16mm)
5 1/2 - 12	5 - 11	3/4" (19mm)
above 12	above 11	1" (25mm)

For complete welding information and procedures, refer to ESCO Products Maintenance Manual, Catalog 100-A, "How to weld ESCO alloy 12 series."

**Lip Adapter Installation**

1. Locate the adapters on a clean bucket, then tackweld them in place, followed by a root layer all the way around.




- To prevent the introduction of weld-weakening impurities, every weld pass should begin and end across a starter/runoff plate. Install these plates, made from scrap steel, as shown in the diagram.

**Do not stop or start a weld at the rear of the adapter leg!**

If rod length, adapter size, and welder position allow a continuous weld without stopping, use two starter/runoff plates near the lip leading edge.


On large adapters and where stops for welder repositioning are required, use two additional starter/runoff plates at the midpoint on both sides of the adapter.

These procedures also apply to the bottom leg of 1½- and 2-leg adapters.




- If using four starter/runoff plates, weld the rear half of the adapter with alternating clockwise and counter clockwise passes. Build up the weld to a full fillet.

If using only two starter/runoff plates, use the same technique, welding to the ends of the J-groove, then proceed to step 5. **Do not weld to the lip leading edge!**





- If using four plates, continue welding to the ends of the J-groove. **Do not weld to the lip leading edge!** Alternate from side to side until the weld is complete. Maintain a full fillet weld and tie weld ends together.



- Remove the starter/runoff plates, then smooth the forward edge of the welds with a conical grinder. Blend the welds concave to remove stress concentrations.

- Turn the bucket over.

- One-leg Flushmount Adapters** fillet weld across the adapter equal to the lip leading edge thickness. Grind the ends smooth at weld junctions. If a lighter cavity extends forward of the lip leading edge, cover the opening with weld. Maintain a full fillet width over the entire weld.



## Corner Adapter Modification and Installation

Helilok adapters can be modified by cutting to fit bucket side plates. A **bucket should never be cut to fit an adapter!**


The corner adapter should be positioned so the point cuts clearance for the bucket. The best bucket wear protection is achieved when the adapter is positioned so the nose is flush with an imaginary line extending forward from the outside edge of the bucket side plate.

If a clean trench is desired, corner adapters can be mounted so points are positioned flush with the outside of the bucket.

When modifying an adapter, **never remove more than 50% of the adapter top leg.** The edges of the cuts should be chamfered  $1/2"$  X  $30^\circ$  for weld preparation.


Following welding procedures described in "Lip Adapter Installation."

Install Helilok points according to the procedures described in ESCO Maintenance Catalog 100-1B (Rev. 1), Helilok Tooth System Installation and Removal instructions.





## DISASSEMBLY OF FINAL DRIVE ASSEMBLY



*Filling, draining and oil level scheme*

### 1. START UP

Operate the gearbox after the motor is filled with hydraulic oil.

Leave breather open and fill with oil until flows out without foam. Add more oil if necessary.

Air trapped in the hydraulic system may generate noise in motor and valves as well as foaming in the tank.

Start the gearbox at low speed and increase speed gradually after checking that the gearbox runs smoothly with no noise or vibrations.

Do not run at max pressure until all solid particles are captured and removed by the filler.

Checks the following points:

- no oil leaks,
- revolution and direction of rotation are correct,
- the oil temperature (both motor and gearbox) does not rise exceed prescribed values,
- operation is smooth without noise or vibrations,
- no other defects.

### 2. MAINTENANCE


Under normal operating circumstances, no routine maintenance is required, other than routine oil checks and oil changes. As recommended in this manual, unusual operating characteristics, such as noise or overheat, should indicate further investigation

### 3. DSASSEMBLING

Initial inspection of the gears and the hydraulic motor, can be made without dismantling the track and the track drive from the machine.


#### STEP 1

Fix the equipment AT709C15 on the flanged hub (pos. 18), by screwing the threaded bar, push the disc on the discs retainer (pos. 21), thus removing the force of the springs (pos. 22) on the circlip (pos. 20) and allowing its disassembling.




#### STEP 2

Using pliers remove the circlip (pos. 20) from its groove in the the flanged hub (pos. 18).




**DISASSEMBLING****STEP 3**

Remove springs retainer (pos. 21) from the flanged hub (pos. 18)

**STEP 4**


Remove the springs (pos. 22) from their grooves in the brack piston (pos. 23).

**STEP 5**

Remove the brake piston (pos. 23)


**⚠ Caution**

To get it easier, pumping compressed air into the brake port hole (max. 0,2 bar).




**DISASSEMBLING****STEP 6**


Remove the brake shaft (pos. 27).

**STEP 7**

Remove brake discs pack (pos. 25-26).


**STEP 8**

Remove the O-rings (pos. 28-29) from their grooves in the flanged hub (pos. 18).




**DISASSEMBLING****STEP 9**

Overturn the gearbox, unscrew and remove the 2 plugs M22x1,5 (pos. 4) and the 2 washers (pos. 3) from the end cover (pos. 2).

**STEP 10**

Unscrew and remove the 10 socket head screws M10x25 (pos. 1), grade 12.9, from the cover (pos. 2).


**STEP 11**

Remove the end cover (pos. 2) using 2 screw M22x1,5 tightened to the oil plugs holes.




**DISASSEMBLING****STEP 12**


Remove the O-ring (pos. 5) from its groove in the end cover (pos. 2).

**STEP 13**

Remove the 1st stage sun gear (pos. 7).


**STEP 14**

Remove the 1st reduction assembly (pos. 8).




**DISASSEMBLING****STEP 15**


Remove the 2nd stage sun gear (pos. 9)

**STEP 16**

Remove the 2nd reduction assembly (pos. 10)


**STEP 17**

Remove the 3rd stage sun gear (pos. 11)




**⚠ Note**


In order to proceed with the slew drive disassembling, it is not necessary to remove it from the machine and bring it to a properly equipped workshop

**STEP 18**

Unscrew the 4 socket head screws M20x100 (pos. 12), grade 10.9, fixing the 3rd reduction assembly (pos. 13) to the flanged hub (pos. 18)

**STEP 19**


By means of a puller, remove the 3rd reduction planet carrier from the flanged hub (pos. 18).






**DISASSEMBLING****STEP 20**

Using the equipment AT709C16, remove the bush (pos. 14) from the flanged hub (pos. 18) or from the 3rd reduction planet carrier.

**STEP 21**

Using the equipment AT709C16 remove the 4 planet assemblies of the 3rd reduction (pos. 13).

**STEP 22**

Remove the centering ring (pos. 17) from the flanged hub (pos. 18).



## DISASSEMBLING

### STEP 23

Using a press and a metal stopper, remove the flanged hub (pos. 18) from the gearbox housing (pos. 15).



## 4. LIFETIME SEAL CHECK

### Caution

In case of oil leakages, it should be necessary to check and eventually replace the lifetime seal (pos. 16), which means both the metal rings parts and the O-rings.


### STEP 24

Using the equipment AT709C16 remove the 4 planet assemblies of the 3rd reduction (pos. 13).




**DISASSEMBLING****STEP 25**

Remove the 2<sup>nd</sup> half seal (pos. 16) from the gearbox housing (pos. 15).

**STEP 26**

Using a puller remove the inner ring of the bearing from the flanged hub (pos. 18).

**⚠ Note**

The track drive disassembling ends with the above operation: all items are now available for the necessary inspections.


## ASSEMBLY OF FINAL DRIVE ASSEMBLY

### 7. ASSEMBLY

#### 1.1 IMPORTANT NOTES BEFORE ASSEMBLY

When proceeding with the gearbox reassembly, it is necessary to follow up the rules listed below:

- a) In case of damaged gears, for example a planet, do not replace the single gear, but the whole reduction stage.
- b) Always replace the O-rings of the item to be reassembled after having carefully cleaned the seats and having buttered some grease on the grooves themselves and on the O-rings to make easier the reassembly.



Dwg. - Detail of seal


#### 1.2 INSTRUCTIONS FOR THE INSTALLATION OF THE HALF SALES.

To follow these instructions at the time of fitting, in order to obtain the correct seal:


- a) Carefully clean the seats "1" and "2" using, if necessary, metal brushes or solvent (surfaces in contact with or "3" must be perfectly clean and dry).
- b) Make sure that sealing surfaces "4" of metal rings "5" are free from scratches, dings or foreign substances; metal ring surfaces must be perfectly clean and dry.
- c) Carefully clean the lapped surface "4" of metal rings "5" and remove dust or fingerprints. Then lubricate them with a thin oil film, taking care not to oil the other components.

**ASSEMBLING****STEP 27**


Assemble the half seals (pos. 16) on the tool AT709C07.

**STEP 28**

Assemble the 1st half seal (pos. 16) on the gearbox housing (pos. 15).

**STEP 29**


Assemble, by using the same tool AT709C07, the half seal (pos. 15) on the flanged hub (pos. 18).



## ASSEMBLING


## STEP 30

Clean carefully the metallic faces of the half-seals, and Lube them metallic with a thin oil film.




## STEP 31

Fit the lower ball row (ref. d), into the gearbox housing (pos. 15) holding the inner raceway (ref. c) with spacers (ref. a-b)




## STEP 32

Remove the spacer (ref. b).  
Place the bearing spacer (ref. e) into its position and drop the upper ball row (ref. f).  
Drop the inner raceway (ref. g).



**ASSEMBLING****STEP 33**

Place the flanged hub (pos. 18) inside the gearbox housing (pos. 15). Using a press and a metallic stopper, push the flanged hub (pos. 18) against the shoulder on the gearbox housing (pos. 15) until assembling of the unit is complete.


**STEP 34**

Assemble correctly the discs retainer (pos. 17) in the flanged hub (pos. 18)

**STEP 35**


Place the 4 bushes (pos. 14) into their grooves on the flanged hub (pos. 18).

Through a press, push the bushes (pos. 14) against the shoulder inside their grooves into the flanged hub (pos. 18) until assembling is complete.




**ASSEMBLING****STEP 36**

Using a press, push the 4 planet assemblies of the 3rd reduction (pos. 13) against the shoulder on the flanged hub (pos. 18).

**STEP 37**

Place the 3rd reduction planet carrier (pos. 13) on the flanged hub (pos. 18) and through a press push it against the shoulder until assembling is complete.

**STEP 38**


Apply LOCTITE type 242 on the 4 socket head screws M20x100 (pos. 12), grade 10.9, and insert them in the thread holes.






**ASSEMBLING****STEP 39**


Tighten the 4 socket head screws M20x100 (pos. 12), grade 10.9, by a torque wrench at a torque of 58,5 daNm.

**STEP 40**

Insert the 3rd stage sun gear (pos. 11).


**STEP 41**

Assemble the 2nd reduction assembly (pos. 10).



**ASSEMBLING****STEP 42**


Insert the 2nd stage sun gear (pos. 90)

**STEP 43**

Assemble the 1st reduction assembly (pos. 8).

**STEP 44**

Insert the 1st stage sun gear (pos.7).



**ASSEMBLING****STEP 45**


Mount the O-ring (pos. 5) into its groove in the cover (pos. 2).

**STEP 46**

Place the cover (pos. 2) on the gearbox housing (pos. 15) and fix it through 10 socket head screws M10x25 (pos. 1) grade 12.9, tightened by a torque wrench at a torque of 7,5 daNm.


**STEP 47**

Mount the washers (pos. 3) and tighten the plugs M22x1,5 (pos. 4) by a torque wrench at a torque of 6-8 daNm.




**ASSEMBLING****STEP 48**


Apply in the internal seal's grooves of the flanged hub (pos. 18) a coat of grease, and insert the O-rings (pos. 28-29)

**STEP 49**

Assemble the brake shaft (pos. 27)


**STEP 50**

Assemble a new brake discs package according to the following order: firstly insert an external toothed sintered bronze disc (pos. 26). Then insert, an internal toothed steel disc (pos. 25). Repete the operating untill reaching the number of 6 sintered broze and 5 steel discs.




**ASSEMBLING****STEP 51**


Insert the brake piston (pos. 23) inside the flanged hub (pos. 18), paying attention not to damage the seals already fitted.

**STEP 52**

Insert the springs (pos. 22) into the grooves in the brake piston (pos. 23).


**STEP 53**

Insert the springs retainer (pos. 21).




**ASSEMBLING****STEP 54**

Fixed the equipment AT709C15 to the flanged hub (pos. 18) and screw the threaded screw up the springs retainer disc (pos. 21) is lowerd below the circlip groove (pos. 20).


**STEP 55**

Through pliers, assemble the circlip (pos. 20) into groove.

**STEP 56****⚠ Note**

Ater mounting the hydraulic motor, verify, trough a depth slide gauge, the axial dimension of the gearbox measured by input side of the flanged hub (pos. 18) to the brake shaft (pos. 27).


Asial dimension = 111,4 - 112,2 mm



## 2.1 BRAKE CHECK

In order to verify the correct assembly of the brake group, it is necessary to carry out a test of the seal rings. Connect the brake port to a pump and release the brake by pumping oil. By means of a pressure gauge verify that the pressure does not decrease (see dwg). In otherwise case, the seal rings of the brake leak oil and it is necessary to disassemble the brake and provide for their replacement.

Test data: Oil pressure = 50 bar  
Test duration = 3 minutes




*Dwg. - Correct brake assembly check*

### STEP 57

After having reassembled the gearbox, fit the hydraulic motor (taking care to include the O-ring (pos. 19), through 2 fixing screws M20x50 (pos. 24), grade 8,8 tightened at a torque of 41,5 daNm. Fill the gearbox with the lubricant oil as shown in section 4.2.


(SPECIAL TOOLS FOR FINAL DRIVE)




TOOL FOR HALF SEALS MOUNTING TRACK DRIVES




**(SPECIAL TOOLS FOR FINAL DRIVE)**






TUBE GUIDE FOR FITTING MAIN BEARING AND HOUSING TO THE GEARBOX 709C3B




(SPECIAL TOOLS FOR FINAL DRIVE)




(SPECIAL TOOLS FOR FINAL DRIVE)




(SPECIAL TOOLS FOR FINAL DRIVE)





SPARE PART INCLUDING HOUSING AND MAIN BEARING GEARBOX

DISASSEMBLY AND ASSEMBLY



## DISASSEMBLY OF SWING MACHINERY ASSEMBLY

### 1. START UP

Operate the track drive after the motor is filled with hydraulic oil.

Leave breather open and fill with oil until oil flows out without foam. Add more oil if necessary.

Air trapped in the hydraulic system may generate noise in motor and valves as well as foaming in the tank.

Start the track drive at low speed and increase speed gradually after checking that the track drive runs smoothly with no noise or vibrations.

Do not run at max pressure until all solid particles are captured and removed by the filter.

Checks the following points:


- no oil leaks,
- revolution and direction of rotation are correct,
- the oil temperature (both motor and gearbox) does not rise exceed prescribed values,
- operation is smooth without noise or vibrations,
- no other defects.

### 2. MAINTENANCE

Under normal operating circumstances, no routine maintenance is required, other than routine oil checks and oil changes. As recommended in this manual, unusual operating characteristics, such as noise or heat, should indicate further investigation

### 3. DISASSEMBLING

Initial inspection of the gears and the hydraulic motor, can be made without dismantling the slew drive from the machine.




#### Note

Before starting the gearbox disassembly, it is better to mark the assembly position of: motor adaptor (pos. 50), brake housing (pos. 32), toothed rings (pos. 25-18), cover (pos. 21) and gearbox housing (pos. 7) in order to obtain an exact reference of position at reassembly.

Unscrew and remove the 2 screws M16x40 (pos. 49), grade 8.8, and remove the hydraulic motor and the O-ring (pos. 51).

#### STEP 1


Unscrew the draining plug M18x1,5 (pos. 9) and its washer (pos. 8) from the gearbox housing (pos. 7) and drain the oil from the gearbox.






**DISASSEMBLING****STEP 2**


Remove the extensions (pos. 10), the elbow (pos. 11) and the washer (pos. 8) from the gearbox housing (pos. 7).

**STEP 3**

Unscrew the plug G1/4 (pos. 47) from the motor adaptor (pos. 50)


**STEP 4**

Unscrew the elbow (pos. 46) from the motor adaptor (pos. 50).




**DISASSEMBLING****STEP 5**


Unscrew the dipstick for oil filling and level kit (pos. 52).

**STEP 6**

Unscrew the 8 socket head screws M10x30 (pos. 48) grade 8.8, fixing the motor adaptor (pos. 50) to the brake housing (pos. 32).

**STEP 7**

Remove the 8 socket head screws (pos. 48), the bracket of oil filling and level kit (pos. 52) and remove the motor adaptor (pos. 50).




**DISASSEMBLING****STEP 8**

Remove the O-ring (pos. 44) from its seat in the motor adaptor (pos. 50).

**STEP 9**

Unscrew the 11 socket head screws M10x70 (pos. 33) grade 8.8 and remove the brake assembly.

**STEP 10**


Overturn the brake assembly and remove the O-ring (pos. 24) from its seat in the brake housing (pos. 33).



**DISASSEMBLING**


**STEP 11**

Remove the brake shaft (pos. 35).




**STEP 12**

Remove the toothed ring (pos. 25).




**STEP 13**

Remove the 1st stage sun gear (pos. 27).



**DISASSEMBLING****STEP 14**


Remove the 1st reduction assembly (pos. 26).

**STEP 15**

Remove the O-ring (pos. 24) from its seat in the cover (pos. 21).


**STEP 16**

Using pliers remove the elbow and the extension of the oil filling and level kit (pos. 52) from the cover (pos. 21) and all plugs and washers present in the gearbox too.




**DISASSEMBLING****STEP 17**


Unscrew the 4 socket head screws M12x80 (pos. 22), grade 12.9, and the 12 socket head screws M12x90 (pos. 23), grade 12.9, and remove the cover (pos. 21).

**STEP 18**

Remove the O-ring (pos. 12) from its seat in the end cover (pos. 21).


**STEP 19**

Remove the 2nd stage sun gear (pos. 19).




**DISASSEMBLING****STEP 20**


Remove the 2nd reduction assembly (pos. 17).

**STEP 21**

Remove the toothed ring (pos. 18).


**STEP 22**

Remove the O-ring (pos. 12) from its seat in the gearbox housing (pos. 7).




**⚠ Note**


In order to proceed with the slew drive disassembling, it is now necessary to remove it from the machine and bring it to a properly equipped workshop.

**STEP 23**

By means of a punch, remove the caulking in the edge of the nut (pos. 15).

**STEP 24**


Using the tool AT709C06, unscrew the nut M75x2 (pos. 15).






**DISASSEMBLING****STEP 25**


Overturn the output assembly (pos. 16), unscrew and remove the 8 socket head screws M8x20 (pos. 4), grade 8.8, from the front cover (pos. 5)

**STEP 26**

Place the gearbox housing (pos. 7) on three spacers and through a press push on the pinion shaft (pos. 1) and remove it from the gearbox housing (pos. 7).


**STEP 27**

Place the pinion shaft (pos. 1), front cover (pos. 5) and bearing (pos. 6) group on a spacer. Through a press push on the pinion shaft (pos. 1) and extract the bearing (pos. 6).




**DISASSEMBLING****STEP 28**


Remove the front cover (pos. 5).

**STEP 29**

Use a screwdriver to remove the ringseals (pos. 3) from their groove in the front cover (pos. 5)

**STEP 30**

Use a rubber hammer a metal stopper to remove the bearing (pos. 14) from the the gearbox housing (pos. 7).



**DISASSEMBLING****STEP 31**


Use a rubber hammer a metal stopper to remove the seal ring (pos. 13) from the the gearbox housing (pos. 7).

**⚠ Important**


Disassemble the seal ring only in case it has to be replaced.

**STEP 32**

Through a press and a metal stopper, push on the spring retainer (pos. 42), thus removing the force of the springs (pos. 41) on the circlip (pos. 43) and through pliers remove it.


**STEP 33**

Remove the springs retainer (pos. 42).




**DISASSEMBLING****STEP 34**

Remove the springs (pos. 41) from their grooves in the brake piston (pos. 40).

**STEP 35**

Remove the brake piston (pos. 40).

To get it easier, pumping compressed air into the brake port hole (max. 0,2 bar), taking care the piston (pos. 40) doesn't jump out the brake housing (pos. 32).


**STEP 36**

Remove the 1 st O-rings (pos. 34) from its seat in the brake housing (pos. 32).




**DISASSEMBLING****STEP 37**


Remove spacer (pos. 38) and remove the 2nd O-rings (pos. 34) from its groove in the brake housing (pos. 32).

**STEP 38**

Remove the O-ring (pos. 39) from its seat in the spacer (pos. 38).


**STEP 39**

Remove brake discs pack (pos. 36-37).




**DISASSEMBLING****STEP 40**

Through pliers remove the circlip (pos. 29) from its groove in the brake housing (pos. 32).

**STEP 41**

Remove the discs retainer (pos. 30)

**⚠ Note**

The gearbox disassembling ends with the above operation: all items are now available for the necessary inspections.

## 4. ASSEMBLY


### 4.1 IMPORTANT NOTES BEFORE THE ASSEMBLING

When proceeding with the gearbox reassembly, it is necessary to follow up the rules listed below:

- a) In case of damaged gears, for example a planet, **do not replace the single gear, but the whole reduction stage.**
- b) **Always replace the O-rings of the item to be reassembled** after having carefully cleaned the seats and having butterd some grease on the grooves themselves and on the O-rings to make easier the reassembly.


#### STEP 42

Place correctly the spacer (pos. 2) on th pinion shaft (pos. 1).



#### STEP 43

Through a press and a metal stopper push the spacer (pos. 2) against the shoulder on the pinion shaft (pos. 1) untill assembling is complete.




**ASSEMBLING****STEP 44**


Mount the seal ring (pos. 3) into its groove in the front cover (pos. 5).

**STEP 45**

Mount the front cover (pos. 5) on the pinion shaft (pos. 1).

**STEP 46**


Apply on the bearing (pos. 6) a coat of grease type **NGLI 2** with **EP** characteristics.






**ASSEMBLING****STEP 47**


Place the bearing (pos. 6) on the pinion shaft (pos. 1).  
Through a press and a metal stopper, push the bearing (pos. 6) against the spacer shoulder (pos. 2).

**STEP 48**

Place the seal ring (pos. 13) inside the gearbox housing (pos. 7).


**STEP 49**

Through a press and the proper metal stopper AT709C14, push the seal ring (pos. 13) against the shoulder on the gearbox housing (pos. 7).




**ASSEMBLING****STEP 50**


Overturn the gearbox housing (pos. 7) and fill with grease type **NGLI 2 with EP characteristics** the upper chamber placed between the seal ring (pos. 13) and the bearing (pos. 6).

**STEP 51**

Place the pinion shaft (pos. 1) -spacer (pos. 2) -front cover (pos. 5) -bearing (pos. 6) group in the gearbox housing (pos. 7).


**STEP 52**

Use a press and a proper metal stopper to push the pinion shaft (pos. 1) against the shoulder on the gearbox housing (pos. 7) until assembling of the unit is complete.




**ASSEMBLING****STEP 53**


Tighten the 6 socket head screws M8x20 (pos. 4), grade 8.8, by a torque wrench at a torque of 2,5 daNm.

**STEP 54**

Overturn the gearbox (pos. 7) and place inside it the bearing (pos. 14).


**STEP 55**

Use a press and the metal stopper to push the bearing (pos. 14) against the shoulder in the gearbox housing (pos. 7).




**ASSEMBLING****STEP 56**


Place a new ring nut (pos. 15) on the pinion shaft (pos. 1).  
Never use the nut disassembled because already deformed.

**STEP 57**

Use the tool AT709C06 to tighten the ring nut M75x2 (pos. 15), by a torque wrench, at a torque of 110-120 daNm.

**STEP 58**


Caulk the ring nut (pos. 13) next to 3 spaces placed at 120° of the pinion shaft spline (pos. 1).




**ASSEMBLING****STEP 59**

Apply in the O-ring's seat in the gearbox housing (pos. 7) a coat of grease.


Mount the 1st O-ring (pos. 12).

**STEP 60**

Assemble the 2nd reduction assembly (pos. 17).


**STEP 61**

Insert the 2nd stage sun gear (pos. 19).




**ASSEMBLING****STEP 62**

Assemble the toothed ring (pos. 18).


**STEP 63**

Apply in the O-ring's seat in the cover (pos. 21) a coat of grease.

Mount the 2nd O-ring (pos. 12).

**STEP 64**


Place the cover (pos. 21) on the toothed ring (pos. 18) and fix it through 4 socket head screws M12x80 (pos. 22), grade 8.8, and through 12 socket head screws M12x90 (pos. 23), grade 8.8, tightened by a torque wrench at 12 daNm torque.




**DISASSEMBLING****STEP 65**

Apply in the O-ring's seat in the cover (pos. 17) a coat of grease.


Mount the 1st O-ring (pos. 24).

**STEP 66**

Assemble the 1st reduction assembly (pos. 26).


**STEP 67**

Insert the 1st stage sun gear (pos. 27).




**ASSEMBLING****STEP 68**

Assemble the toothed ring (pos. 25).

**STEP 69**

Apply in the internal seal's grooves of the brake housing (pos. 32) a coat of grease, and insert the O-rings (pos. 34).

**STEP 70**


Apply in the inside surface of the spacer (pos. 38) a coat of grease.  
Fit the O-ring (pos. 39) into its seat in the spacer (pos. 38).






**ASSEMBLING****STEP 71**


Assemble correctly the spacer (pos. 38) to the brake piston (pos. 40), paying attention not to damage the O-ring (pos. 39) already fitted.

**STEP 72**

Insert the brake piston-spacer group (pos. 40-38) inside the brake housing (pos. 32), paying attention not to damage the seals already fitted.


**STEP 73**

Insert the springs (pos. 41) into the holes in the brake piston (pos. 40), according the picture arrangement.




**ASSEMBLING****STEP 74**


Insert the springs retainer (pos. 42).

**STEP 75**

Through a press and a metal stopper, push on the springs retainer (pos. 42), in lowering it in order to permit the assembly of the circlip (pos. 43) in its groove in the brake housing (pos. 32).


**STEP 76**

Overturn the brake housing (pos. 32) and assemble the brake discs package according to the following order: firstly insert an external toothed sintered bronze disc (pos. 37).




**ASSEMBLING****STEP 77**


Then insert, an internal toothed steel disc (pos. 36).  
Repete the operation untill reaching the number of 6  
sintered bronze and 5 stell discs.

**STEP 78**

Assemble the brake shaft (pos. 35) and insert oil at a pres-  
sure of 20 bar from the brake pilot port (see installation  
drawing ref. 4) in order to permit the assembling of the last  
sintered bronze disc (pos. 37) and the discs retainer (pos.  
30).


**STEP 79**

Assemble correctly the discs retainer (pos. 30) in the brake  
housing (pos. 32).




**ASSEMBLING****STEP 80**


Through pliers, assemble the circlip (pos. 29) into its groove. Then remove the compressed air from the brake assembly and dismount the brake shaft (pos. 35).

**STEP 81**

Apply in the O-ring's seat in the brake housing (pos. 32) a coat of grease. Mount the 2nd O-ring (pos. 24).


**STEP 82**

Assemble the brake shaft (pos. 35).




**ASSEMBLING****STEP 83**

Assemble the brake assembly.

**STEP 84**

Tighten the 11 socket head screws M10x70 (pos. 33), grade 8.8, by a torque wrench at 5 daNm torque.

**STEP 85**


Mount the O-ring (pos. 44) into its seat in the motor flange (pos. 50).




**ASSEMBLING****STEP 86**

Place the motor flange (pos. 50) on the brake housing (pos. 32) and insert the 8 socket head screws M10x30 (pos. 48) grade 8.8.


Contemporary assemble the flask of the filling and oil level kit (pos. 52).

**STEP 87**

Tighten the 8 socket head screws M10x30 (pos. 48), grade 8.8, by a torque wrench at 5 daNm torque.


**STEP 88**

Using pliers, screw the washer (pos. 8), the elbow and the extension of the filling and oil level kit (pos. 52) in the cover (pos. 21).




**ASSEMBLING****STEP 89**

Mount and tighten the dipstick of the filling and oil level kit (pos. 52).

**STEP 90**

Insert and screw all plugs M18x1,5 (pos. 9) and washers (pos. 8) in the gearbox.


**STEP 91**

Assemble the angle (pos. 46) in the motor flange (pos. 50).




**ASSEMBLING****STEP 92**


Assemble the breather plug G1/4 (pos. 47).

**STEP 93**

Assemble the extensions (pos. 10), the angle (pos. 11) and the washer (pos. 8) in the gearbox housing (pos. 7).

**STEP 94**

Assemble the plug M18x1,5 (pos. 9).






**ASSEMBLING****STEP 95****⚠ Important**

After mounting the hydraulic motor, verify, through a depth slide gauge, the axial dimension of the gearbox measured by input side of the motor adaptor (pos. 50) to the brake shaft (pos. 35).

Axial dimension = 93-94,5 mm.


**STEP 96**

After having reassembled the gearbox, fit the hydraulic motor (taking care to include the O-ring pos. 51), through 2 fixing screws M16x40 (pos. 49), grade 8.8 tightened at a torque of 21,5 daNm. Fill the gearbox with the lubricant oil as shown in section 4.2.


## 5. BRAKE CHECK

In order to verify the correct assembly of the brake group, it is necessary to carry out a test of the seal rings. Connect the brake port to a pump and release the brake by pumping oil. By means of a pressure gauge verify that the pressure does not decrease (see dwg. 6). In Otherwise case, the seal rings of the brake leak oil and it is necessary to disassembly the brake and provide for their replacement.


Test data: **Test duration = 3 minutes.**



(SPECIAL TOOLS FOR SWING MACHINERY)



(SPECIAL TOOLS FOR SWING MACHINERY)







---

# 40 MAINTENANCE STANDARD


---

Engine mount .....	40-	2
Swing machinery .....	40-	3
Swing circle .....	40-	5
Final drive .....	40-	6
Track frame and recoil spring .....	40-	8
Idler .....	40-	9
Carrier roller .....	40-	11
Track roller .....	40-	12
Track .....	40-	13
Control valve .....	40-	15
Suction-safety valve .....	40-	23
Swing motor .....	40-	24
Work equipment, swing PPC valve .....	40-	25
Travel PPC valve .....	40-	26
Service PPC valve .....	40-	27
PPC shuttle valve, travel junction valve .....	40-	28
EPC solenoid valve .....	40-	29
Center swivel joint .....	40-	30
Boom safety valve (Arm safety valve) .....	40-	31
Hydraulic cylinder .....	40-	32
Work equipment .....	40-	34


# ENGINE MOUNT



**A - A**



**B - B**




**C - C**

Unit:mm

No.	Check item	Criteria		Remedy
		Standard size	Repair limit	
1	Free height of front mount rubber A	84	-	Replace
2	Free height of rear mount rubber B & C	84	-	


# SWING MACHINERY





Pos.	Check item	Standard clearance (mm)	Clearance limit (mm)	Component	Check measurement standard (mm)	Check measurement limit (mm)
1	Backlash between motor shaft and brake shaft	0,064 - 0,155	0,33	Motor Shaft:	Measurement over pin $\phi$ 4mm 34,144 -0,054 -0,120	Measurement over pin $\phi$ 4mm 33,90
				Brake shaft:	Measurement over pin $\phi$ 3,5mm 22,484 +0,171 +0,063	Measurement over pin $\phi$ 3,5mm 22,85
2	Backlash between brake shaft and 1st stage sun gear	0,020 - 0,098	0,27	Brake shaft:	Measurement over pin $\phi$ 3,5mm 32,611 +0,101 +0,001	Measurement over pin $\phi$ 3,5mm 32,89
				Sun gear:	Measurement over pin $\phi$ 3,5mm 43,311 -0,030 -0,076	Measurement over pin $\phi$ 3,5mm 43,10
3	Backlash between 1st stage sun gear and 1st stage planet gear	0,093 - 0,165	0,43	Sun gear:	Span measurement over 4 teeth 27,729 -0,037 -0,080	Span measurement over 4 teeth 27,52
				Planet gear:	Span measurement over 4 teeth 27,531 -0,050 -0,075	Span measurement over 4 teeth 27,33
4	Backlash between 1st stage planet gear and toothed ring	0,133 - 0,213	0,48	Planet gear:	Span measurement over 4 teeth 27,531 -0,050 -0,075	Span measurement over 4 teeth 27,33
				Toothed ring:	Measurement over pin $\phi$ 4mm 192,072 +0,350 +0,210	Measurement over pin $\phi$ 4mm 192,77
5	Backlash between 1st stage planet carrier and 2nd stage sun gear	0,020 - 0,098	0,27	Planet carrier:	Measurement over pin $\phi$ 3,5mm 49,879 +0,088 +0,002	Measurement over pin $\phi$ 3,5mm 50,12
				Sun gear:	Measurement over pin $\phi$ 3,5mm 59,847 -0,029 -0,075	Measurement over pin $\phi$ 3,5mm 59,64
6	Backlash between 2nd stage sun gear and 2nd stage planet gear	0,112 - 0,192	0,51	Sun gear:	Span measurement over 4 teeth 33,511 -0,045 -0,090	Span measurement over 4 teeth 33,27
				Planet gear:	Span measurement over 4 teeth 32,911 -0,060 -0,090	Span measurement over 4 teeth 32,67
7	Backlash between 2nd stage planet gear and toothed ring	0,160 - 0,255	0,58	Planet gear:	Span measurement over 4 teeth 32,911 -0,060 -0,090	Span measurement over 4 teeth 32,67
				Toothed ring:	Measurement over pin $\phi$ 5mm 299,720 +0,426 +0,256	Measurement over pin $\phi$ 5mm 230,57
8	Backlash between 2nd stage planet carrier and swing pinion	0,020 - 0,098	0,27	Planet carrier:	Measurement over pin $\phi$ 4mm 60,579 +0,094 -0,002	Measurement over pin $\phi$ 4mm 60,84
				Pinion shaft:	Measurement over pin $\phi$ 4mm 73,232 -0,034 -0,082	Measurement over pin $\phi$ 4mm 73,01
9	Backlash between swing pinion and swing circle	0,018 - 1,235	2,30	Pinion shaft:	Span measurement over 3 teeth 78,90 -0,050 -0,200	Span measurement over 3 teeth 78,20
				Swing circle:	Measurement over pin $\phi$ 15mm 924,3 +2,260 +0,470	Measurement over pin $\phi$ 15mm 927,98
10	Wear of swing pinion oil seal contact surface					$\phi$ 84,5


SWING CIRCLE




Unit: mm

No.	Check item	Criteria		Remedy
		Standard clearance	Clearance limit	
1	Axial clearance of bearing (When mounted on machine)	0.5 - 1.6	3.2	Replace

# FINAL DRIVE






Unit: mm

Pos.	Check item	Standard clearance (mm)	Clearance limit (mm)	Component	Check measurement standard (mm)	Check measurement limit (mm)
1	Backlash between motor shaft and brake shaft	0,064- 0,154	0,33	Motor Shaft:	Measurement over pin $\phi$ 4,5mm 45,137 -0,050 -0,111	Measurement over pin $\phi$ 4,5mm 44,91
				Brake shaft:	Measurement over pin $\phi$ 3,5mm 32,739 +0,121 +0,044	Measurement over pin $\phi$ 3,5mm 33,01
2	Backlash between brake shaft and 1st stage sun gear	0,064- 0,155	0,33	Brake shaft:	Measurement over pin $\phi$ 3,5mm 22,484 +0,171 +0,063	Measurement over pin $\phi$ 3,5mm 22,85
				Sun gear:	Measurement over pin $\phi$ 4mm 34,144 -0,054 -0,120	Measurement over pin $\phi$ 4mm 33,90
3	Backlash between 1st stage sun gear and 1st stage planet gear	0,096 - 0,165	0,43	Sun gear:	Span measurement over 4 teeth 27,93 -0,040 -0,080	Span measurement over 4 teeth 27,73
				Planet gear:	Span measurement over 4 teeth 27,425 -0,050 -0,075	Span measurement over 4 teeth 27,23
4	Backlash between 1st stage planet gear and toothed ring	0,133 - 0,213	0,48	Planet gear:	Span measurement over 4 teeth 27,531 -0,050 -0,075	Span measurement over 4 teeth 27,23
				Toothed ring:	Measurement over pin $\phi$ 4mm 192,072 +0,350 +0,210	Measurement over pin $\phi$ 4mm 192,77
5	Backlash between 1st stage planet carrier and 2nd stage sun gear	0,020 - 0,098	0,27	Planet carrier:	Measurement over pin $\phi$ 3,5mm 49,879 +0,088 +0,002	Measurement over pin $\phi$ 3,5mm 50,12
				Sun gear:	Measurement over pin $\phi$ 3,5mm 59,847 -0,029 -0,075	Measurement over pin $\phi$ 3,5mm 59,64
6	Backlash between 2nd stage sun gear and 2nd stage planet gear	0,149 - 0,255	0,68	Sun gear:	Span measurement over 4 teeth 43,996 -0,060 -0,120	Span measurement over 4 teeth 43,68
				Planet gear:	Span measurement over 4 teeth 43,996 -0,060 -0,120	Span measurement over 4 teeth 43,52
7	Backlash between 2nd stage planet gear and toothed ring	0,213 - 0,399	0,83	Planet gear:	Span measurement over 4 teeth 43,996 -0,060 -0,120	Span measurement over 4 teeth 43,52
				Toothed ring:	Measurement over pin $\phi$ 6,5mm 266,50 +0,720 +0,340	Measurement over pin $\phi$ 6,5mm 267,78
8	Backlash between 2nd stage planet carrier and 3rd stage sun gear	0,020 - 0,098	0,27	Planet carrier:	Measurement over pin $\phi$ 4mm 60,579 +0,094 -0,002	Measurement over pin $\phi$ 4mm 60,84
				Sun gear:	Measurement over pin $\phi$ 4mm 73,232 -0,034 -0,082	Measurement over pin $\phi$ 4mm 73,01
9	Backlash between 3rd stage sun gear and 3rd stage planet gear	0,149 - 0,255	0,68	Sun gear:	Span measurement over 3 teeth 32,08 -0,060 -0,120	Span measurement over 3 teeth 31,76
				Planet gear:	Span measurement over 4 teeth 43,90 -0,080 -0,120	Span measurement over 4 teeth 43,58
10	Backlash between 3rd stage planet gear and toothed ring	0,213 - 0,399	0,83	Planet gear:	Span measurement over 4 teeth 43,90 -0,080 -0,120	Span measurement over 4 teeth 43,52
				Toothed ring:	Measurement over pin $\phi$ 4mm 266,50 +0,720 +0,340	Measurement over pin $\phi$ 6,5mm 267,78
11	Wear of sprocket teeth	Repair limit: 6				
12	Sprocket tooth width	Standard size	Repair limit	Rebuild or replace		
		72	68			

# TRACK FRAME, RECOIL SPRING


★ Figure shows the PC180LC-6K



Unit: mm

No.	Check item	Criteria					Remedy	
			Standard size	Tolerance	Repair limit			
1	Vertical width of idler guide	Track frame	107			Rebuild or replace		
		Idler support	105					
2	Horizontal width of idler guide	Track frame	250			Rebuild or replace		
		Idler support	247.4					
3	Recoil spring	Standard size			Repair limit		Replace	
			Free length X O.D.	Installed length	Installed load	Free length		Installed load
		PC180/160	587.5 x 243	466	133.5 kN (13,610 kg)	576		106,8 kN (10,885 kg)

# IDLER




205F05186

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size	Tolerance		Repair limit		
1	Outside diameter of protrusion	560			-	Rebuild or replace	
		520			508		
2	Outside diameter of tread	85			-		
3	Width of protrusion	164			-		
4	Total width	39.5			45.5		
5	Width of tread	Standard size		Tolerance		Standard clearance	Clearance limit
		65	Shaft	Hole	0.214 - 0.424		
6	Clearance between shaft and bushing	65	-0.250 -0.350	+0.074 -0.036	0.03 - 0.180	-	Replace bushing
7	Clearance between shaft and support	65	-0.250 -0.290	-0.110 -0.220	0.03 - 0.180	-	Replace
8	Interference between idler and bushing	Standard size		Tolerance		Standard interference	Interference limit
		72	Shaft	Hole	0.065 - 0.161		
9	Side clearance of idler (each)	Standard clearance		Clearance limit			
		0.39 - 1.00		1.5			

# CARRIER ROLLER




205F05188

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size	Tolerance		Repair limit		
1	Outside diameter of flange (outside)	Standard size	Repair limit		-	Rebuild or replace	
		165					
2	Outside diameter of tread	140	130				
3	Width of tread	43	50				
4	Interference between shaft and bearing	Standard size	Tolerance		Standard interference	Interference limit	
			Shaft	Hole			
		50	0 -0.016	0 -0.012	-0.016 - 0.012	-	
5	Interference between roller and bearing	80	0 -0.013	-0.021 -0.051	0.008 - 0.051	-	Replace
6	Side clearance of roller	Standard clearance		Clearance limit			
		0.01 - 0.18		-			



TRACK ROLLER





205F05187A

Unit: mm

No.	Check item	Criteria				Remedy
		Standard size	Tolerance		Repair limit	
1	Outside diameter of flange (outside)	Standard size			Repair limit	Rebuild or replace
		186			-	
2	Outside diameter of tread	154			142	
3	Width of tread	44.5			52	
4	Width of flange	24.4			-	
5	Clearance between shaft and bushing	Standard size	Tolerance		Standard clearance	Clearance limit
			Shaft	Hole		
		60	-0.215 -0.315	+0.195 0	0.215 - 0.510	1.5
6	Interference between roller and bushing	Standard size	Tolerance		Standard interference	Interference limit
			Shaft	Hole		
		67	+0.153 +0.053	+0.030 0.	0.023 - 0.153	-
7	Side clearance of roller (both sides)	Standard clearance		Clearance limit		Replace
		0.41 - 0.95		1.5		

# TRACK SHOE




205F05189-1

Unit: mm


No.	Check item		Criteria				Remedy	
			Standard size	Tolerance		Standard interference		Interference limit
1	Link pitch						Turn or replace	
			190.25	+0.074	0	0.190 - 0.304		0.100
2	Outside diameter of bushing		59.3	+0.264	-0.138 - -0.200	0.210 - 0.422	0.140	Lug welding rebuild or replace
3	Height of grouser	Triple	26	+0.062	0	0.138 - 0.230	0.130	
		Swamp	102.5					
4	Height of link		105	4.85				Adjust
5	Interference between bushing and link		59	+0.304	+0.074	0.190 - 0.304	0.100	Replace with over size
				+0.264	0			
6	Interference between regular pin and link		38	+0.222	-0.138	0.210 - 0.422	0.140	
7	Interference between master pin and link		37.8	+0.230	+0.062	0.138 - 0.230	0.130	
				+0.200	0			
8	Protrusion of bushing		4.85				Adjust	
9	Tightening torque of shoe bolt		Initial tightening torque: 392 ± 39.2 Nm (40 ± 4 kgm) Additional tightening angle: 120° ± 10°				Tighten	





Unit: mm


No.	Check item	Criteria				Remedy	
		Standard size			Repair limit		Replace spring if any damages or deformations are found.
1	Pressure compensation valve spring (work equipment, swing)	Free length X O.D.	Installed length	Installed load	Free length	Installed load	
				34.4 x 12	20	17.6 ± 1.0 N (1.8 ± 0.1 kg)	
2	Pressure compensation valve spring (travel)	27.3 x 12	20	25.5 N (2.6 kg)	-	19.6 N (2.0 kg)	
3	Pressure compensation valve adjuster spring service	16.9	15.5	74.5 N (7.6 kg)	-	55.9 N (5.7 kg)	




B-B

Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
1	Spool return spring (work equipment, swing)	Free length X O.D.	Installed length	Installed load	Free length	Installed load	Replace spring if any damages or deformations are found.
		45.6 x 28	43	230.3 ± 14.7 N (23.5 ± 1.5 kg)	-	208.7 N (21.3 kg)	
2	Spool return spring (travel)	45.7 x 28	43	221.5 ± 13.7 N (22.6 ± 1.4 kg)	-	179.3 N (18.3 kg)	






C-C



D-D









202F06295

Unit: mm


No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
		Free length X O.D.	Installed length	Installed load	Free length	Installed load	
1	Lift check valve spring.	72.7 x 20.6	42.5	135.2 ± 4.9 N (13.8 ± 0.5 kg)	-	112.7 N (11.5 kg)	Replace spring if any damages or deformations are found.
2	Cooler bypass valve spring.	72.7 x 20.6	42.5	135.2 ± 4.9 N (13.8 ± 0.5 kg)	-	112.7 N (11.5 kg)	



202F06296




L-L



M-M

202F06297

# SUCTION-SAFETY VALVE FOR SERVICE VALVE




202F06298

Unit: mm


No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
1	Suction valve spring.	Free length X O.D.	Installed length	Installed load	Free length	Installed load	Replace spring if any damages or deformations are found.
		16.3 x 21.3	9.5	2.1 N (0.21 kg)	-	1.6 N (0.16 kg)	
2	Main valve spring	20 x 7	14	2.1 N (0.21 kg)	-	1.6 N (0.16 kg)	

# SWING MOTOR



202F06299


WORK EQUIPMENT, SWING PPC VALVE



Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
		Free length X O.D.	Installed length	Installed load	Free length	Installed load	
1	Centering spring (for P3, P4)	43.3 X 19.5	33.5	17.7 N (1.8 kg)	-	13.7 N (1.4 kg)	Replace spring if there is damage or deformation
2	Centering spring (for P1, P2)	45.5 X 19.6	33.5	29.0 N (3.0 kg)	-	23.2 N (2.4 kg)	
3	Metering spring	27.6 X 9.5	26	16.7 N (1.7 kg)	-	13.7 N (1.4 kg)	

TRAVEL PPC VALVE




SBP00435

Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
1	Metering spring	Free length X O.D.	Installed length	Installed load	Free length	Installed load	Replace spring if there is damage or deformation
		26.5 X 8.15	24.7	16.7 N (1.7 kg)	-	13.7 N (1.4 kg)	
2	Centering spring	48.1 X 15.5	32.5	107.9 N (11 kg)	-	86.3 N (8.8 kg)	

# SERVICE PPC VALVE




Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
1	Centering spring	Free length X O.D.	Installed length	Installed load	Free length	Installed load	Replace spring if there is damage or deformation
		41.5 X 18.2	31.5	60 N (6.1 kg)	(40.3)	57.5 N (5.8 kg)	
2	Metering spring	28.5 X 7.6	26.5	17 N (1.7 kg)	(27.6)	16.3 N (1.7 kg)	





# PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE



Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
		Free length X O.D.	Installed length	Installed load	Free length	Installed load	
1	Spool return spring	23.6 x 13.3	20	14.7 N (1.5 kg)	-	11.8 N (1.2 kg)	Replace spring if there is damage or deformation

# EPC SOLENOID VALVE FOR LS VALVE




SBP00438

Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
1	Return spring	Free length X O.D.	Installed length	Installed load	Free length	Installed load	Replace EPC valve assembly if there is damage or deformation
		9.0 x 11.4	7.9	3.14 N (0.32 kg)	-	-	

# CENTER SWIVEL JOINT




SBP00439

Unit: mm

No.	Check item	Criteria			Remedy
		Standard size	Standard clearance	Clearance limit	
1	Clearance between rotor and shaft	90	0.56 - 0.105	0.111	Replace

## ARM, BOOM SAFETY VALVE

- ★ For machine equipped with arm safety valve, the Maintenance Standard of arm safety valve is the same as this valve.




Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
		Free length	Installed length	Installed load	Free length	Installed load	
1	Pilot valve spring. N01 (Boom safety valve)	30.9 mm	29.0	69.6 N (7.1 kg)	-	55.9 N (5.7 kg)	Replace spring if any damages or deformations are found
	Pilot valve spring N01 (Arm safety valve)	32.5 mm	29	85.3 N (8.7 kg)	-	68.6 N (7.0 kg)	
2	Pilot valve spring N02 (Boom and arm safety valve)	31.8 mm	25	29.4 N (3.0 kg)	-	23.5 N (2.4 kg)	
3	Check valve spring. (Boom and arm safety valve)	24.5 mm	18	4.9 N (0.5 kg)	-	3.9 N (0.4 kg)	

# HYDRAULIC CYLINDER

PC160-6k, PC180LC/NLC-6K



FK203P5097


Unit: mm

No.	Check item	Name of cylinder	Standard size	Tolerance		Standard clearance	Clearance limit	Remedy
				Shaft	Hole			
1	Clearance between piston rod and bushing	Boom	75	-0.030 -0.076	+0.270 +0.065	0.095 - 0.346	0.446	Replace bushing
		Arm	85	-0.036 -0.090	+0.222 +0.047	0.083 - 0.312	0.412	
		Bucket	75	-0.030 -0.076	+0.270 +0.065	0.095 - 0.346	0.446	
2	Clearance between piston rod support and bushing	Boom	70	-0.030 -0.104	+0.198 +0.124	0.154 - 0.302	1.0	Replace pin and bushing
		Arm	80	-0.030 -0.104	+0.211 +0.124	0.154 - 0.315	1.0	
		Bucket	70	-0.030 -0.076	+0.198 +0.124	0.154 - 0.274	1.0	
3	Clearance between cylinder bottom support shaft and bushing	Boom	70	-0.030 -0.100	+0.198 +0.124	0.154 - 0.298	1.0	Replace pin and bushing
		Arm	80	-0.030 -0.104	+0.211 +0.124	0.154 - 0.315	1.0	
		Bucket	70	-0.030 -0.104	+0.198 +0.124	0.154 - 0.315	1.0	




# WORK EQUIPMENT


PC160-6k, PC180LC/NLC-6K




202F05664




Section A—A




Section D—D




Section H—H




Section E—E




Section J—J




Section B—B




Section F—F




Section K—K



Section C—C



Section G—G



Section L—L

202F05665

Unit: mm


No.	Check item	Criteria					Remedy
		Standard size	Tolerance		Standard clearance	Clearance limit	
Shaft	Hole						
1	Clearance between bushing and connecting pin of revolving frame and boom	80	-0.030 -0.104	+0.331 +0.265	0.295 - 0.435	1.0	Replace
2	Clearance between bushing and connecting pin of boom and arm	80	-0.030 -0.104	+0.337 +0.273	0.303 - 0.441	1.0	
3	Clearance between bushing and connecting pin of arm and link	70	-0.030 -0.076	+0.331 +0.270	0.300 - 0.407	1.0	
4	Clearance between bushing and connecting pin of arm and bucket	70	-0.030 -0.076	+0.331 +0.270	0.300 - 0.407	1.0	
5	Clearance between bushing and connecting pin of link and bucket	70	-0.030 -0.076	+0.335 +0.275	0.305 - 0.411	1.0	
6	Clearance between bushing and connecting pin of link and link	70	-0.030 -0.076	+0.335 +0.275	0.305 - 0.411	1.0	



# DIMENSIONS OF WORK EQUIPMENT

PC180LC-6K, PC160-6K


## 1. ARM




SAP00446

No.		Model	2.25 m ARM	2.6 m ARM
	1		$\varnothing 80 \begin{matrix} +0.1 \\ 0 \end{matrix} / \begin{matrix} -0.030 \\ -0.104 \end{matrix}$	$\varnothing 80 \begin{matrix} +0.1 \\ 0 \end{matrix} / \begin{matrix} -0.030 \\ -0.104 \end{matrix}$
	2		$98 \begin{matrix} +1.0 \\ 0 \end{matrix} 96 \pm 1.2$	$98 \begin{matrix} +1.0 \\ 0 \end{matrix} 96 \pm 1.2$
	3		$284 \begin{matrix} +0.5 \\ 0 \end{matrix} / \begin{matrix} -0.3 \\ -0.8 \end{matrix}$	$284 \begin{matrix} +0.5 \\ 0 \end{matrix} / \begin{matrix} -0.3 \\ -0.8 \end{matrix}$
	4		$\varnothing 80 \begin{matrix} +0.337 \\ +0.273 \end{matrix} / \begin{matrix} -0.030 \\ -0.104 \end{matrix}$	$\varnothing 80 \begin{matrix} +0.337 \\ +0.273 \end{matrix} / \begin{matrix} -0.030 \\ -0.104 \end{matrix}$
	5		$395.8 \pm 2$	$399.5 \pm 2$
	6		$203.8 \pm 1$	$173.8 \pm 1$
	7		$745.3 \pm 1$	$753 \pm 1.0$
	8		$2995.3$	$3357.6 \pm 3$
	9		$2377 \pm 1.0$	$2377 \pm 1.0$
	10		$330 \pm 0.5$	$330 \pm 0.5$
	11		$583 \pm 0.5$	$583 \pm 0.5$
	12		$524 \pm 0.5$	$524 \pm 0.5$
	13		$400.8$	$400.8$
	14		$(1348)$	$(1348)$
	15		$\varnothing 70 \begin{matrix} +0.2 \\ 0 \end{matrix} / \begin{matrix} -0.030 \\ -0.076 \end{matrix}$	$\varnothing 70 \begin{matrix} +0.2 \\ 0 \end{matrix} / \begin{matrix} -0.030 \\ -0.076 \end{matrix}$
	16		$311.5 \pm 1$	$311.5 \pm 1$
	17		$\varnothing 70 \begin{matrix} +0.2 \\ 0 \end{matrix} / \begin{matrix} -0.030 \\ -0.076 \end{matrix}$	$\varnothing 70 \begin{matrix} +0.2 \\ 0 \end{matrix} / \begin{matrix} -0.030 \\ -0.076 \end{matrix}$
18	Arm as individual part		$276 \begin{matrix} 0 \\ -0.5 \end{matrix}$	$276 \begin{matrix} 0 \\ -0.5 \end{matrix}$
	When press fitting bushing		$310$	$310$
19	Min.		$1547$	$1547$
	Max.		$2560$	$2560$

1. BUCKET



SAP00447




No.	Model PC180LC-6K, PC160-6K
3	103° 23'
4	400
5	1348
7	-
9	$\varnothing 70^{+0.3}_{+0.2}$
10	$311.5^{+0.2}_0$
11	50
12	96
13	$440^{+1}_0$
14	$\varnothing 18$
15	$\varnothing 130$
16	$\varnothing 130$
17	$440^{+0.1}_0$
18	$\varnothing 18$
19	R95
20	R95
21	$311.5^{+0.2}_0$
22	96



# OPERATION OF CLSS SYSTEM AS A WHOLE

- 1. When all work equipment is at neutral
- ★ The diagram shows the situation when all work equipment is at neutral.
- ★ The valves and circuits that are not connected with the explanation of the operation of the CLSS hydraulic system have been omitted.



**Operation**

- When the levers are at neutral, the pump is at the minimum swash plate angle, and the oil flow is drained from unload valve (6).
- The LS pressure is connected to hydraulic tank (1) by LS bypass valve (14). The LS differential pressure  $P_{LS}$  (unload pressure - tank pressure) at this point is  $P_{LS} >$  pump LS control pressure, so the pump swash plate angle is the minimum.

1. Hydraulic tank

**Hydraulic pump**

2. Main pump
3. TVC valve
4. LS valve

**Control valve**

6. Unload valve
7. Bucket valve
  - 7A. Spool
  - 7B. Pressure compensation valve (DUMP)
  - 7C. Pressure compensation valve (CURL)
  - 7D. LS shuttle valve
8. Arm valve
  - 8A. Spool
  - 8B. Pressure compensation valve (OUT)
  - 8C. Pressure compensation valve (IN)
  - 8D. LS shuttle valve
9. Boom valve
  - 9A. Spool
  - 9B. Pressure compensation valve (RAISE)
  - 9C. Pressure compensation valve (LOWER)
  - 9D. LS shuttle valve
  - 9E. Check valve
10. R.H. travel valve
  - 10A. Spool
  - 10B. Pressure compensation valve (FORWARD)
  - 10C. Pressure compensation valve (REVERSE)
11. L.H. travel valve
  - 11A. Spool
  - 11B. Pressure compensation valve (FORWARD)
  - 11C. Pressure compensation valve (REVERSE)
  - 11D. LS shuttle valve
12. Swing valve
  - 12A. Spool
  - 12B. Pressure compensation (LEFT)
  - 12C. Pressure compensation valve (RIGHT)
13. LS select valve
14. LS bypass valve
15. Main relief valve
16. Cooler bypass valve
17. Lift check valve


**Actuator**

18. Bucket cylinder
19. Arm cylinder
20. Boom cylinder
21. L.H. travel motor
22. R.H. travel motor
23. Swing motor

- ★ The arm counterbalance valve, safety-suction valve, and suction valve are not shown.

# Boom RAISE

★ The diagram shows the boom RAISE





**Operation**

- When the boom RAISE is operated, main pump (2) is at the maximum swash plate angle, and unload valve (6) is closed.
- At this point, for the meter-in opening of boom spool (9A) even if main pump is at the maximum swash plate angle, the LS differential pressure is set to be smaller than the pump LS control pressure.  
In other words, LS differential pressure  $\Delta P_{LS}$  is  $\Delta P_{LS} < \text{pump LS control pressure}$ , so the pump swash plate angle becomes the maximum.

1. Hydraulic tank

**Hydraulic pump**

2. Main pump
3. TVC valve
4. LS valve

**Control valve**

6. Unload valve
7. Bucket valve
  - 7A. Spool
  - 7B. Pressure compensation valve (DUMP)
  - 7C. Pressure compensation valve (CURL)
  - 7D. LS shuttle valve
8. Arm valve
  - 8A. Spool
  - 8B. Pressure compensation valve (OUT)
  - 8C. Pressure compensation valve (IN)
  - 8D. LS shuttle valve
9. Boom shuttle
  - 9A. Spool
  - 9B. Pressure compensation valve (RAISE)
  - 9C. Pressure compensation valve (LOWER)
  - 9D. LS shuttle valve
  - 9E. Check valve
10. R.H. travel valve
  - 10A. Spool
  - 10B. Pressure compensation valve (FORWARD)
  - 10C. Pressure compensation valve (REVERSE)
  - 10D. LS shuttle valve
11. L.H. travel valve
  - 11A. Spool
  - 11B. Pressure compensation valve (FORWARD)
  - 11C. Pressure compensation valve (REVERSE)
  - 11D. LS shuttle valve
12. Swing valve
  - 12A. Spool
  - 12B. Pressure compensation valve (LEFT)
  - 12C. Pressure compensation valve (RIGHT)
13. LS select valve
14. LS bypass valve
15. Main relief valve
16. Cooler bypass valve
17. Lift check valve


**Actuator**

18. Bucket cylinder
19. Arm cylinder
20. Boom cylinder
21. L.H. travel motor
22. R.H. travel motor
23. Swing motor

- ★ The arm counterbalance valve, safety-suction valve, and suction valve are not shown.

**Swing operated independently**

★ The diagram shows the swing operated independently



**Operation**

- When the swing is operated, main pump (2) of the arm group is at the maximum swash plate angle, and unload valve (6) is closed. LS pressure  $P_{Ls}$  becomes the load pressure of swing motor (23).
- In the swing circuit, the difference between pump discharge pressure  $P_p$  and LS pressure  $P_{Ls}$  (LS differential pressure  $\Delta P_{Ls}$ ) becomes the same pressure as the LS set pressure of LS valve (4).
- As a result, the swash plate of main pump (2) is kept at a position midway between the minimum and maximum swash plate angle, and the main pump discharges the demand flow (approx. 50%) for the swing circuit.
- When the swing is operated independently, pump discharge amount  $Q$  does not become 100%.

1. Hydraulic tank

**Hydraulic pump**

2. Main pump
3. TVC valve
4. LS valve

**Control valve**

6. Unload valve
7. Bucket valve
  - 7A. Spool
  - 7B. Pressure compensation valve (DUMP)
  - 7C. Pressure compensation valve (CURL)
  - 7D. LS shuttle valve
8. Arm valve
  - 8A. Spool
  - 8B. Pressure compensation valve (RAISE)
  - 8C. Pressure compensation valve (IN)
  - 8D. LS shuttle valve
9. Boom valve
  - 9A. Spool
  - 9B. Pressure compensation valve (RAISE)
  - 9C. pressure compensation valve (LOWER)
  - 9D. LS shuttle valve
  - 9E. Check valve
10. R.H. travel valve
  - 10A. Spool
  - 10B. Pressure compensation valve (FORWARD)
  - 10C. Pressure dcompensation valve (REVERSE)
  - 10D. LS shuttle valve
11. L.H. travel valve
  - 11A. Spool
  - 11B. Pressure compensation valve (FORWARD)
  - 11C. Pressure compensation valve (REVERSE)
  - 11D. LS shuttle valve
12. Swing valve
  - 12A. Spool
  - 12B. Pressure compensation valve (LEFT)
  - 12C. Pressure compensation valve (RIGHT)
13. LS select valve
14. LS bypass valve
15. Main relief valve
16. Cooler bypass valve
17. Lift check valve


**Actuator**

18. Bucket cylinder
19. Arm cylinder
20. Boom cylinder
21. L.H. travel motor
22. R.H. travel motor
23. Swing motor

- ★ The arm counterbalance valve, safety-suction valve, and suction valve are not shown.

**Compound operation**

★ The diagram shows the boom RAISE + arm IN



**Operation**

- 1) When the arm and boom are operated simultaneously, the swash plate angle for main pump becomes the maximum.

When this happens, the load pressure at the boom RAISE side is higher than at the arm side, so the LS pressure passes through ports **E** and **F** of boom spool (9A), enters LS shuttle valve (9,0) and is sent to the LS circuit. This LS pressure is transmitted to port **G** of arm pressure compensation valve (8B), and acts to increase the set pressure of the pressure compensation valve. because of this, the pressure between port **H** or arm spool (8A) and port **I** or pressure compensation valve (8B) rises, and pool meter-in LS differential pressure (pump pressure - LS pressure =  $\Delta P_{LS}$ ) becomes the same as that at the boom end.

- 2) Because of the above operation, the oil flow is divided in proportion to the size of the opening area of boom spool (9A) and the opening area to arm spool (8A).

Meter-in LS differential pressure  $\Delta P_{LS}$  during boom RAISE + arm IN is  $\Delta P_{LS} <$  boom LS control pressure, so the main pump swash plate angle is set to maximum.

1. Hydraulic tank

**Hydraulic pump**

2. Main pump  
3. TVC valve  
4. LS valve

**Control valve**

6. Unload valve  
7. Bucket valve  
7A. spool  
7B. Pressure compensation valve (DUMP)  
7C. Pressure compensation valve (CURL)  
7D. LS shuttle valve  
8. Arm valve  
8A. Spool  
8B. Pressure compensation valve (IN)  
8C. Pressure compensation valve (OUT)  
8D. LS shuttle valve  
9. Boom valve  
9A. Spool  
9B. Pressure compensation valve (RAISE)  
9C. Pressure compensation valve (LOWER)  
9D. LS shuttle valve  
9E. Check valve  
10. R.H. travel valve  
10A. Spool  
10B. Pressure compensation valve (FORWARD)  
10C. Pressure compensation valve (REVERSE)  
10D. LS shuttle valve  
11. L.H. travel valve  
11A. Spool  
11B. Pressure compensation valve (FORWARD)  
11C. Pressure compensation valve (REVERSE)  
11D. LS shuttle valve  
12. Swing valve  
12A. Spool  
12B. Pressure compensation valve (LEFT)  
12C. Pressure compensation valve (RIGHT)  
13. LS select valve  
14. LS bypass valve  
15. Main relief valve  
16. Cooler bypass valve  
17. Lift check valve


**Actuator**

18. Bucket cylinder  
19. Arm cylinder  
20. Boom cylinder  
21. L.H. travel motor  
22. R.H. travel motor  
23. Swing motor

- ★ The arm counterbalance valve, safety-suction valve, and suction valve are not shown.

**Boom OUT, standard mode relief (cut-off control)**

★ The diagram shows the boom DUMP and standard mode relief



**Operation**

- When boom cylinder (20) reaches the end of its stroke, main relief valve (15) opens and pump discharge amount **Q** is relieved to tank (1).
- When pump discharge pressure **Pp** comes close to the relief pressure, the pump controller sends a signal to the solenoid of TVC valve (3) to carry out the cut-off function to make pump discharge amount **Q** the minimum.
- The cylinder is at the end of its stroke, so no oil flows to the upstream or downstream side of boom spool (9A). Pump discharge pressure **Pp** and LS differential pressure  $\Delta P_L$  becomes 0.
- LS differential pressure  $\Delta P_L$  is lower than the LS set pressure of LS valve (4), so LS valve (4) acts to make the pump swash plate angle the maximum. However, because of the mechanism, the operation of TVC valve (3) is given priority over the operation of LS valve (4), so the pump is kept at the minimum swash plate angle by the cut-off function of TVC valve (3).

1. Hydraulic tank

**Hydraulic pump**

2. Main pump
3. TVC valve
4. LS valve

**Control valve**

5. LS bypass valve
6. Unload valve
7. Bucket valve
  - 7A. Spool
  - 7B. Pressure compensation valve (DUMP)
  - 7C. Pressure compensation valve (CURL)
  - 7D. LS shuttle valve
8. Arm valve
  - 8A. Spool
  - 8B. Pressure compensation valve (OUT)
  - 8C. Pressure compensation valve (IN)
  - 8D. LS shuttle valve
9. Boom valve
  - 9A. Spool
  - 9B. Pressure compensation valve (RAISE)
  - 9C. Pressure compensation valve (LOWER)
  - 9D. LS shuttle valve
  - 9E. Check valve
10. R.H. travel valve
  - 10A. Spool
  - 10B. Pressure compensation valve (FORWARD)
  - 10C. Pressure compensation valve (REVERSE)
  - 10D. LS shuttle valve
11. L.H. travel valve
  - 11A. Spool
  - 11B. Pressure compensation valve (FORWARD)
  - 11C. Pressure compensation valve (REVERSE)
  - 11D. LS shuttle valve
12. Swing valve
  - 12A. Spool
  - 12B. Pressure compensation valve (LEFT)
  - 12C. Pressure compensation valve (RIGHT)
13. LS select valve
14. LS bypass valve
15. Main relief valve
16. Cooler bypass valve
17. Lift check valve

**Actuator**

18. Bucket cylinder
19. Arm cylinder
20. Boom cylinder
21. L.H. travel motor
22. R.H. travel motor
23. Swing motor

- ★ The arm counterbalance valve, safety-suction valve, and suction valve are not shown.








# ELECTRONIC CONTROL SYSTEM

## CONTROL FUNCTION



★ For details of the self-diagnostic function, see TROUBLESHOOTING

**TOTAL SYSTEM DIIAGRAM**  
PC180LC-6k, PC160-6k

