

# Operation & Maintenance Manual

---

**LIFT TRUCKS**

**GC15S-5, GC18S-5, GC20SC-5**

 **WARNING**

Do not start, operate or service this machine unless you have read and understood these instructions and received proper training.  
Unsafe or improper use of the machine may cause serious injury or death.  
Operators and maintenance personnel must read this manual and receive training before operating or maintaining the machine.  
This manual should be kept with the machine for reference and periodically reviewed by the machine operator and by all personnel who will come into contact with it.

The following warning is provided pursuant to California Health & Safety Code Sections 25247.5 et, seq,

 **WARNING**

**California Proposition 65**

Engine Exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

**WASH HANDS AFTER HANDLING.**

# Table of Contents

## Information Section

Foreword .....	2
----------------	---

## Safety Section

Important Safety Information .....	4
Safety .....	5
Warning Signs and Labels .....	5
Operation Information .....	11
Maintenance Information .....	14
Pressure Air .....	14
Fluid Penetration .....	14
Crushing or Cutting Prevention .....	14
Burn Prevention .....	15
Operator Restraint System (If Equipped) .....	17
Avoiding Lift Truck Tipovers .....	22
Safety Rules .....	24
How to Survive in a Tipover .....	29

## General Section

Specifications .....	31
Noise and Vibration .....	33
Serial Number .....	34
Operator's Warning and Identification Plate .....	35

## Operation Section

Operator's Station and Monitoring Systems .....	37
Seat Switch System (If Equipped) .....	40
Lift Truck Controls .....	43
Refueling .....	46
Before Starting the Engine .....	48
Starting the Engine .....	50
After Starting the Engine .....	53
Lift Truck Operation .....	81
Operating Techniques .....	83
Parking the Lift Truck .....	87
Lift Fork Adjustment .....	88
Storage Information .....	89
Transportation Hints .....	90
Towing Information .....	91

## Maintenance Section

Inspection, Maintenance and Repair of Lift Truck Forks .....	92
Torque Specifications .....	96
Cooling System Specifications .....	98
Fuel Specifications .....	100
Lubricant Specifications .....	101
Lubricant Viscosities and Refill Capacities .....	104
Maintenance Intervals .....	105
When Required .....	107
Every 10 Service Hours or Daily .....	111
First 50-100 Service Hours or a Week .....	115
First 250 Service Hours or a Month .....	118
Every 250 Service Hours or Monthly .....	119
Every 500 Service Hours or 3 Months .....	125
Every 1000 Service Hours or 6 Months .....	129
Every 1500 Service Hours or 9 Months .....	134
Every 2000 Service Hours or Yearly .....	136
Every 2500 Service Hours or 15 Months .....	141
Every 3000 Service Hours or 18 Months .....	145
Every 4500 Service Hours or two Years .....	145

## Index Section

Index .....	146
-------------	-----

## Foreword

### Literature Information

This manual should be stored in the operator's compartment in the literature holder or seat back literature storage area.

This manual contains safety, operation, transportation, lubrication and maintenance information.

Some photographs or illustrations in this publication show details or attachments that can be different from your lift truck. Guards and covers might have been removed for illustrative purposes.

Continuing improvement and advancement of product design might have caused changes to your lift trucks which are not included in this publication. Read, study and keep this manual with the lift truck.

Whenever a question arises regarding your lift truck, or this publication, please consult your DOOSAN dealer for the latest available information.

### Safety

The Safety Section lists basic safety precautions. In addition, this section identifies the text and locations of warning signs and labels used on the lift truck. Read and understand the basic precautions listed in the Safety Section before operating or performing lubrication, maintenance and repair on this lift truck.

### Operator Restraint System (If Equipped)

This manual contains safety, operation and maintenance information for the DOOSAN operator restraint system. Read, study and keep it handy.

#### **WARNING**

**Your DOOSAN truck comes equipped with an operator restraint system. Should it become necessary to replace the seat for any reason, it should only be replaced with another DOOSAN operator restraint system.**

---

Photographs or illustrations guide the operator through correct procedures of checking, operation and maintenance of the DOOSAN operator restraint system.

SAFE and EFFICIENT OPERATION of a lift truck depends to a great extent on the skill and alertness on the part of the operator. To develop this skill the operator should read and understand the Safe Driving Practices contained in this manual.

Forklift trucks seldom tipover, but in the rare event they do, the operator may be pinned to the ground by the lift truck or the overhead guard. This could result in serious injury or death.

Operator training and safety awareness is an effective way to prevent accidents, but accidents can still happen. The DOOSAN operator restraint system can minimize injuries. The DOOSAN operator restraint system keeps the operator substantially within the confines of the operator's compartment and the overhead guard.

This manual contains information necessary for Safe Operation. Before operating a lift truck make sure that the necessary instructions are available and understood.

### Operation

The Operation Section is a reference for the new operator and a refresher for the experienced one. This section includes a discussion of gauges, switches, lift truck controls, attachment controls, transportation and towing information.

Photographs and illustrations guide the operator through correct procedures of checking, starting, operating and stopping the lift truck.

Operating techniques outlined in this publication are basic. Skill and techniques develop as the operator gains knowledge of the lift truck and its capabilities.

## Maintenance

The Maintenance Section is a guide to equipment care. The illustrated, step-by-step instructions are grouped by servicing intervals. Items without specific intervals are listed under "When Required" topics. Items in the "Maintenance Intervals" chart are referenced to detailed instructions that follow.

## Maintenance Intervals

Use the service hour meter to determine servicing intervals. Calendar intervals shown (daily, weekly, monthly, etc.) can be used instead of service hour meter intervals if they provide more convenient servicing schedules and approximate the indicated service hour meter reading. Recommended service should always be performed at the interval that occurs first.

Under extremely severe, dusty or wet operating conditions, more frequent lubrication than is specified in the "Maintenance Intervals" chart might be necessary.

Perform service on items at multiples of the original requirement. For example, at "Every 500 Service Hours or 3 Months", also service those items listed under "Every 250 Service Hours or Monthly" and "Every 10 Service Hours or Daily".

## Environment Management

Note that DOOSAN Infracore VEHICLE B.G. is ISO 14001 certified which is harmonized with ISO 9001. Periodic ENVIRONMENTAL AUDITS & ENVIRONMENTAL PERFORMANCE EVALUATIONS have been made by internal and external inspection entities. LIFE-CYCLE ANALYSIS has also been made through out the total product life.

ENVIRONMENT MANAGEMENT SYSTEM includes DESIGN FOR ENVIRONMENT from the initial stage of the design.

ENVIRONMENT MANAGEMENT SYSTEM considers environmental laws & regulations, reduction or elimination of resource consumption as well as environmental emission or pollution from industrial activities, energy saving, environment-friendly product design (lower noise, vibration, emission, smoke, heavy metal free, ozone depleting substance free, etc.), recycling, material cost reduction, and even environmentally oriented education for the employee.

## Important Safety Information

Most accidents involving product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards, and use common sense. Persons must also have the necessary training, skills and tools before attempting to perform these functions.

**Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.**

**Do not operate or perform any lubrication, maintenance or repair on this product, until you have read and understood the operation, lubrication, maintenance and repair information.**

**Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or other persons.**

The hazards are identified by the "Safety Alert Symbol" and followed by a "Signal Word" such as "WARNING" as shown below.



The meaning of this safety alert symbol is as follows:

**Attention! Become Alert! Your Safety is involved.**

The message that appears under the warning, explaining the hazard, can be either written or pictorially presented.

Operations that may cause product damage are identified by NOTICE labels on the product and in this publication.

DOOSAN cannot anticipate every possible circumstance that might involve a potential hazard, and common sense is always required. The warnings in this publication and on the product are therefore not all inclusive. Before any tool, procedure, work method or operating technique not specifically recommended by DOOSAN is used, you must be sure that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the operation, lubrication, maintenance or repair procedures you choose.

The information, specifications, and illustration in this publication are on the basis of information available at the time it was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service given to the product. Obtain the complete and most current information before starting any job. DOOSAN dealers have the most current information available.

## Safety

The safety rules and regulations in this section are representative of some, but not all rules and regulations noted under the Occupational Safety and Health Act (OSHA) and are paraphrased without representation that the OSHA rules and regulations have been reproduced verbatim.

Please refer to 1910. 178 in Federal Register Vol. 37, No. 202, the National Fire Protection Association No. 505 (NFPA), American National Standard, ANSI B56. 1 Safety Standard for Low lift and High Lift Trucks and subsequent revisions for a complete list of OSHA rules and regulations as to the safe operation of powered industrial lift trucks. Since regulations vary from country to country outside in U.S.A., operate this lift truck in accordance with local regulations.

DOOSAN lift trucks are manufactured according to the regulations and standards laid down in EU Machinery Directive 98/37/EC and EMC directive 89/336/EC. Please refer to the Directives 89/655/EC and 89/391/EC and its amendments for the safe use of DOOSAN lift trucks.

The most effective method of preventing serious injury or death to the lift truck operator or others is for the lift truck operator to be familiar with the proper operation of the lift truck, to be alert and to avoid actions or conditions which can result in an accident.

Do not operate a lift truck if in need of repair, defective or in any way unsafe. Report all defects and unsafe conditions immediately. Do not attempt any adjustments or repairs unless trained and authorized to do so.

## Warning Signs and Labels

### Warning Signs and Labels

There are several specific safety signs on your lift truck. Their exact location and description of the hazard are reviewed in this section. Please take the time to familiarize yourself with these safety signs.

Make sure that you can read all safety signs. Clean or replace these if you cannot read the words or see the pictures. When cleaning the labels use a cloth, water and soap. Do not use solvent, gasoline, etc.

You must replace a label if it is damaged, missing or cannot be read. If a label is on a part that is replaced, make sure a new label is installed on the replaced part. See your dealer for new labels.

### Training Required To Operate or Service Warning



Located on the right of the steering wheel.

### **WARNING**

**Improper operation or maintenance could result in injury or death. Do not operate or work on the lift truck unless you are properly trained. Read and understand the Operation and Maintenance Manual. Additional manuals are available from DOOSAN LIFT TRUCK dealers.**

## General Warnings to Operator



Located on the right side of the operator's seat.

### **WARNING**

**Only trained and authorized personnel may operate this machine. For safe operation, read and follow the operation and maintenance Manual furnished with this lift truck and observe the following warnings:**


1. Before starting machine. Check all controls and warning devices for proper operation.
  2. Refer to machine identification plate for allowable machine capacity. Do not overload. Operate machines equipped with attachments as partially loaded machines when not handling a load.
  3. Put directional control or shift lever in neutral before "ON - OFF" switch is turned on.
  4. Start, turn and brake smoothly. Slow down for turns, slippery or uneven surfaces. Extremely poor surfaces should be repaired. Avoid running over loose objects or holes in the roadway surfaces. Use extreme caution when turning on inclines.
  5. Travel with load as low as possible and tilted back. If load interferes with visibility, travel with load trailing.
  6. On grade operations travel with load up grade.
  7. Watch out for pedestrians and obstructions. Check overhead clearances.
  8. Do not permit riders on forks or machine at any time.
  9. Do not allow anyone to stand or pass under the elevated portion of any machine.
  10. Be sure operating surface can safely support machine.
  11. Operate machine and attachments only from operator's position.
  12. Do not handle unstable or loosely stacked loads.
  13. Use minimum tilt when picking up or depositing a load.
  14. Use extreme care when handling long, high, or wide loads.
  15. Forks should be completely under load and spread apart as far as load permits.
  16. Machine should be equipped with overhead guard or equivalent protection. Where load requires it, use load backrest extension. Use extreme caution if operating without these devices.
  17. Parking - Lower lifting mechanism to floor. Put directional control or shift lever in neutral. Set parking/secondary brake. Turn "ON - OFF" switch off. Chock wheels if machine is on incline. Disconnect battery when storing electric machines.
  18. Observe safety rules when handling fuel for engine powered machine and when changing batteries for electric machines.
-



### Pressure Warning

**⚠ WARNING**

Contents under pressure may be hot. Allow to cool before opening.




Located on the radiator top tank by the radiator cap.

### Hand Placement Warning

**⚠ WARNING**



No hands. Do not place hands in this area. Do not touch, lean on, or reach through the mast or permit others to do so.




Located on the mast.

### No Standing On Forks Warning, No Standing Under Forks Warning

**⚠ WARNING**

Do not stand or ride on the forks. Do not stand or ride on a load or pallet on the forks. Do not stand or walk under the forks.



Located on the lift cylinder.

### Load Backrest Must Be In Place Warning

**⚠ WARNING**

Operation without this device in place may be hazardous.



Located on the load backrest.

### Overhead Guard Must Be In Place Warning

**⚠ WARNING**

Operation without this device in place may be hazardous. This guard conforms to A.N.S.I. B56.1 and F.E.M. Section 4.

This design has been tested with an impact of appropriate value.



Located on the Overhead Guard.

### No Riders Warning

**⚠ WARNING**

To avoid personal injury, allow no riders. A lift truck is designed for only one operator and no riders.



Located beside the operator's station.

### Moving Fan Warning

**⚠ WARNING**

To avoid personal injury, stay clear of moving fan.



Located inside the engine compartment cover.

### Packing brake




Pull the lever BACK to engage the parking brake.



Push the lever FORWARD to release the parking brake.

Applying the parking brake puts the transmission in NEUTRAL. The parking brake must be applied when leaving the lift truck and when starting the engine. If the operator leaves the seat without applying the parking brake, an audible alarm will sound.



**⚠ WARNING**

When leaving machine apply parking brake! Parking brake is not automatically applied. Alarm will sound if parking brake is not applied.

---

**⚠ WARNING**

Correct adjustment is necessary to provide adequate braking. See the MAINTENANCE section for adjustment procedures. The lift truck may creep at engine idle and can cause damage, injury or death. Always apply the parking brake when leaving the lift truck. The parking brake is NOT automatically applied.

---

## General Hazard Information



Attach a “Do Not Operate” or similar warning tag to start switch or controls before servicing or repairing the lift truck.

Do not start or service the lift truck when a “DO NOT OPERATE” or similar warning tag is attached to the start switch or controls.

Wear a hard hat, protective glasses and other protective equipment as required by job conditions.

Know the width of your attachments so proper clearance can be maintained when operating near fences, boundary obstacles, etc.

Do not wear loose clothing or jewelry that can catch on controls or other parts of the lift truck.

Keep the lift truck, especially the deck and steps, free of foreign material such as debris, oil tools and other items which are not part of the lift truck.

Secure all loose items such as lunch boxes, tools and other items which are not part of the lift truck.

Know the appropriate work-site hand signals and who gives them. Accept signals from one person only.

Always use the overhead guard. The overhead guard is intended to protect the lift truck operator from overhead obstructions and from falling objects.

A truck that is used for handling small objects or uneven loads must be fitted with a load backrest.

If the lift truck must be operated without the overhead guard in place due to low overhead clearance, use extreme care. Make sure there is no possibility of falling objects from any adjacent storage or work area. Make sure the load is stable and fully supported by the carriage and the load backrest extension (if equipped).

Do not raise loads any higher than necessary and never raise a load higher than 1830 mm (72 in) with the overhead guard removed.

Always use load backrest extension when the carriage or attachment does not fully support the load. The load backrest extension is intended to prevent the load or any part of the load from falling backwards into the operator's station.

When operation the lift truck, do not depend only on flashing lights or back-up alarm (if equipped) to warn pedestrians.

Always be aware of pedestrians and do not proceed until the pedestrians are aware of your presence and intended actions and have moved clear of the lift truck and/or load.

Do not drive lift truck up to anyone standing in front of an object.

Obey all traffic rules and warning signs.


Keep hands, feet and head inside the operator station. Do not hold onto the overhead guard while operating the lift truck. Do not climb on any part of the mast or overhead guard or permit others to do so.

Do not allow unauthorized personnel to ride on the forks or any other part of the lift truck, at any time.

When working in a building or dock, observe floor load limits and overhead clearances.

Inhaling freon gas through a lit cigarette or other smoking method or inhaling fumes released from a flame contacting freon can cause bodily harm or death. Do not smoke when servicing air conditioners or wherever freon gas may be present.

Never put maintenance fluids into glass containers.  
 Use all cleaning solutions with care.  
 Do not use steam, solvent, or high pressure to clean electrical components.  
 Report all needed repairs.



Inspect the part of the chain that is normally operated over the crosshead roller. When the chain bends over the roller, the movement of the parts against each other causes wear.

Inspect to be sure that chain link pins do not extend outside of the bore hole.

If any single link pin is extended beyond its connecting corresponding link, it should be suspected of being broken inside of its bore hole.

Inspect the chain anchor and the anchor links for wear.

Do not change any factory set adjustment values (including engine rpm setting) unless you have both authorization and training. Especially Safety equipment and switches may not be removed or adjusted incorrectly. Repairs, adjustments and maintenances that are not correct can make a dangerous operating condition.

For any checkup, repair, adjustments, maintenance and all other work concerning your forklift truck, please contact your DOOSAN dealer. We would like to draw your attention to the fact that any secondary damages due to improper handling, insufficient maintenance, wrong repairs or the use of other than original DOOSAN spare parts waive any liability by DOOSAN.

## Operation Information

### Mounting and Dismounting

Mount and dismount the lift truck carefully.

Clean your shoes and wipe your hands before mounting.

Face the lift truck when mounting and dismounting.

Use both hands face the lift truck when mounting and dismounting.

Use the handgrips for mounting and dismounting.

Do not try to climb on or off the lift truck when carrying tools or supplies.

Never get on or off a moving lift truck.

Do not use any controls as handholds when entering or leaving the operator's station.

Never get on or off a moving lift truck. Never jump off the lift truck.

Keep hands and steering wheel free of slippery material.

### Before Starting the Lift Truck

Perform a walk-around inspection daily and at the start of each shift. Refer to the topic "Walk-around Inspection" in "Every 10 Service Hours or Daily" section of this manual.

Adjust the seat so that full brake pedal travel can be obtained with the operator's back against the seat back.

Make sure the lift truck is equipped with a lighting system as required by conditions.

Make sure all hydraulic controls are in the HOLD position.

Make sure the direction control lever is in the NEUTRAL position.

Make sure the parking brake is engaged.

Make sure no one is standing and/or working on, underneath or close to the lift truck before operating the lift truck.

## Safety Section

Operate the lift truck and controls only from the operator's station.

Make sure the lift truck horn, lights, backup alarm (if equipped) and all other devices are working properly.


Check for proper operation of mast and attachments. Pay particular attention to unusual noises or erratic movement which might indicate a problem.

Make sure service and parking brakes, steering, and directional controls are operational.

Make sure all personnel are clear of lift truck and travel path.

Refer to the topic "Lift Truck Operation" in the "Operation Section" of this manual for specific starting instructions.

### Starting the Lift truck



Do not start the engine or move any of the controls if there is a "DO NOT OPERATE" or similar warning tag attached to the start switch or controls.

### Before Operating the Lift Truck

Test brakes, steering controls, horn and other devices for proper operation. Report faulty performance. Do not operate lift truck until repaired.

Learn how your lift truck operates. Know its safety devices. Know how the attachments work.

Before moving the lift truck, look around. Start, turn and brake smoothly.

An operator must constantly observe his lift truck for proper operation.

### Operating the Lift Truck

Always keep the lift truck under control.

Obey all traffic rules and warning signs.


Never leave the lift truck with the engine operating, or with the parking brake disengaged.

Operate the engine only in a well ventilated area.

Lower mast, with or without load, before turning or traveling. Tip over could result. Watch out for overhead obstructions.

Always observe floor load limits and overhead clearance.

Start, turn, and brake smoothly, slow down for turns, grades, slippery or uneven surfaces.



Use special care when operation on grades. Do not angle across or turn on grades. Do not use lift truck on slippery grades. Travel with forks downgrade when unloaded. Travel with load upgrade.

Do not overload, or handle offset, unstable, or loosely stacked loads. Refer to load capacity plate on the lift truck. Use extreme caution when handling suspended, long, high or wide load.



Tilt elevated load forward only when directly over unloading area and with load as low as possible.

Do not stunt ride or indulge in horseplay.

Always look and keep a clear view of the path of travel.

Travel in reverse if load or attachment obstructs visibility. Use extreme caution if visibility is obstructed.

Stay in designated travel path, clear of dock edges, ditches, other dropoffs and surfaces which cannot safely support the lift truck.

Slow down and use extra care through doorways, intersections and other location where visibility is reduced.

Slow down for and avoid pedestrians, other vehicles, obstruction, pot holes and other hazards or objects in the path of travel.

Always use overhead guards except where operation conditions do not permit. Do not operate lift truck in high stacking areas without overhead guards.

When stacking, watch for falling objects. Use load backrest extension and overhead guard.

Refer to the topic "Operation Techniques" in the "Operation Section" of this manual.

### Loading or Unloading Trucks/Trailers

Do not operate lift trucks on trucks or trailers which are not designed or intended for that purpose.

Be certain truck or trailer brakes are applied and wheel chocks in place (or be certain unit is locked to the loading dock) before entering onto trucks or trailers.

If trailer is not coupled to tractor, make sure the trailer landing gear is properly secured in place. On some trailers, extra supports may be needed to prevent upending or corner dipping.

Be certain dock plates are in good condition and properly placed and secured. Do not exceed the rated capacity of dock boards or bridge plates.

### Lift Truck Parking

When leaving the operator station, park the lift truck in authorized areas only. Do not block traffic.



- Park the lift truck level, with the forks lowered and the mast tilted forward until the fork tips touch the floor.
- Move the direction control lever to NEUTRAL.
- Engage the parking brake.
- Turn the key switch off and remove the key.
- Turn the disconnect switch to OFF and remove the key (if equipped).
- Block the drive wheels when parking on an incline.

## Maintenance Information

Perform all maintenance unless otherwise specified as follows:

- Park the lift truck in authorized areas only.
- Park the lift truck level, with the forks lowered and the mast tilted forward until the fork tips touch the floor.
- Place the transmission controls in neutral.
- Engage the parking brake.
- Stop the engine.
- Remove the start switch key and turn the disconnect switch OFF (if equipped).
- Block the drive wheels when parking on an incline.

## Pressure Air

Pressure air can cause personal injury. When using pressure air for cleaning, wear a protective face shield, protective clothing and protective shoes.

The maximum air pressure must be below 205 kPa (30 psi) for cleaning purposes.

## Fluid Penetration

Always use a board or cardboard when checking for a leak. Escaping fluid under pressure, even a pin-hole size leak, can penetrate body tissue, causing serious injury, and possible death. If fluid is injected into your skin, it must be treated by a doctor familiar with this type of injury immediately.

## Crushing or Cutting Prevention

Support equipment and attachments properly when working beneath them. Do not depend on hydraulic cylinders to hold it up. Any attachment can fall if a control is moved, or if a hydraulic line breaks.

Never attempt adjustments while the lift truck is moving or the engine is running unless otherwise specified.

Where there are attachment linkages, the clearance in the linkage area will increase or decrease with movement of the attachment.

Stay clear of all rotating and moving parts. Keep objects away from moving fan blades. They will throw or cut any object or tool that falls or is pushed into them.

Do not use a kinked or frayed wire rope cable. Wear gloves when handling the wire rope cable.

Retainer pins, when struck with force, can fly out and injure nearby persons. Make sure the area is clear of people when driving retainer pins.

Wear protective glasses when striking a retainer pin to avoid injury to your eyes.

Chips or other debris can fly off objects when struck. Make sure no one can be injured by flying debris before striking any object.

## Falling Objects Protective Structure(FOPS)

This is an attached guard located above the operator's compartment and secured to the lift truck.

To avoid possible weakening of the Falling Objects Protective Structure (FOPS), consult a DOOSAN dealer before altering, by adding weight to, welding on, or cutting or drilling holes into the structure.

The overhead guard is not intended to protect against every possible impact. The overhead guard may not protect against some objects penetrating into the operator's station from the sides or ends of the lift truck.

The lift truck is equipped with an overhead guard and FOPS as standard. If there is a possibility of overhead objects falling through the guard, the guard must be equipped with smaller holes or a plexiglass cover.

Any altering done that is not specifically authorized by DOOSAN invalidates DOOSAN's FOPS certification. The protection offered by this FOPS will be impaired if it has been subjected to structural damage. Structural damage can be caused by an overturn accident, by falling objects, etc.

Do not mount any item such as fire extinguishers, first aid kits and lights by welding brackets to or drilling holes in any FOPS structure. See your DOOSAN dealer for mounting guidelines.



## Burn Prevention

### Coolant

At operating temperature, the engine coolant is hot and under pressure. The radiator and all lines to heaters or the engine contain hot water or steam. Any contact can cause severe burns.

Steam can cause personal injury.

Check the coolant level only after engine has been stopped and the fill cap is cool enough to remove with your bare hand.

Remove the cooling system fill cap slowly to relieve pressure.

Cooling system additive contains alkali that can cause personal injury. Avoid contact with the skin and eyes and do not drink.

Allow cooling system components to cool before draining.

### Oils

Hot oil and components can cause personal injury. Do not allow hot oil or components to contact the skin. At operation temperature, the hydraulic tank is hot and can be under pressure.

Remove the hydraulic tank fill cap only after the engine has been stopped and the fill cap is cool enough to remove with your bare hand.

Remove the hydraulic tank fill cap slowly to relieve pressure.

Relieve all pressure in air, oil fuel or cooling systems before any lines, fittings or related items are disconnected or removed.

### Batteries

Batteries give off flammable fumes which can explode.

Do not smoke when observing the battery electrolyte levels.

Electrolyte is an acid and can cause personal injury if it contacts skin or eyes.

Always wear protective glasses when working with batteries.

## Fire or Explosion Prevention

All fuels, most lubricants and some coolant mixtures are flammable.

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire.

Do not smoke while refueling or in a refueling area.

Do not smoke in areas where batteries are charged, or where flammable materials are stored.

Batteries in series can be located in separate compartments. When using jumper cables always connect positive(+) cable to positive(+) terminal of battery connected to starter solenoid and negative(-) cable from external source to starter negative(-) terminal.

(If not equipped with starter negative(-) terminal, connect to engine block.)

See the Operation Section of this manual for specific starting instructions.

Clean and tighten all electrical connections. Check daily for loose or frayed electrical wires. Have all loose or frayed electrical wires tightened, repaired or replaced before operation the lift truck.

Keep all fuels and lubricants stored in properly marked containers and away from all unauthorized persons.

Store all oily rags or other flammable material in a protective container, in a safe place.

Do not weld or flame cut on pipes or tubes that contain flammable fluids. Clean them thoroughly with nonflammable solvent before welding or flame cutting on them.

Remove all flammable materials such as fuel, oil and other debris before they accumulate on the lift truck.

Do not expose the lift truck to flames, burning brush, etc., if at all possible.

Shields, which protect hot exhaust components from oil or fuel spray in the event of a line, tube or seal failure, must be installed correctly.

Do not operate in areas where explosive gases exist or are suspected.

### Fire Extinguisher

Have a fire extinguisher-type BC and 1.5KG minimum capacity-on rear overhead guard leg with latch and know how to use it. Inspect and have it serviced as recommended on its instruction plate.

### Ether

Ether is poisonous and flammable.

Breathing ether vapors or repeated contact of ether with skin can cause personal injury.

Use ether only in well-ventilated areas.

Do not smoke while changing ether cylinders.

Use ether with care to avoid fires.

Do not store replacement ether cylinders in living areas or in the operator's compartment.

Do not store ether cylinders in direct sunlight or at temperatures above 39°C (102°F).

Discard cylinders in a safe place. Do not puncture or burn cylinders.

Keep ether cylinders out of the reach of unauthorized personnel.

### Lines, Tubes and Hoses

Do not bend or strike high pressure lines. Do not install bent or damaged lines, tubes or hoses.

Repair any loose or damaged fuel and oil lines, tubes and hoses. Leaks can cause fires. Contact your DOOSAN dealer for repair or replacement.

Check lines, tubes and hoses carefully. Do not use your bare hand to check for leaks. Use a board or cardboard to check for leaks. See Fluid Penetration in the Safety Section for more details. Tighten all connections to the recommended torque. Replace if any of the following conditions are found.


- End fittings damaged or leaking.
- Outer covering chafed or cut and wire reinforcing exposed.
- Outer covering ballooning locally.
- Evidence of kinking or crushing of the flexible part of hose.
- Armouring embedded in the outer cover.
- End fittings displaced.

Make sure that all clamps, guards and heat shields are installed correctly to prevent vibration, rubbing against other parts, and excessive heat during operation.

### Tire Information

Explosions of air-inflated tires have resulted from heat-induced gas combustion inside the tires. The heat, generated by welding or heating rim components, external fire, or excessive use of brakes can cause gaseous combustion.

A tire explosion is much more violent than a blowout. The explosion can propel the tire, rim and axle components as far as 500 m (1500 ft) or more from the lift truck. Both the force of the explosion and the flying debris can cause personal injury or death, and property damage.



Do not approach a warm tire closer than the outside of the area represented by the shaded area in the above drawing.

Dry nitrogen(N2) gas is recommended for inflation of tires. If the tires were originally inflated with air, nitrogen is still preferred for adjusting the pressure. Nitrogen mixes properly with air.

Nitrogen inflated tires reduce the potential of a tire explosion, because nitrogen does not support combustion. Also, nitrogen helps prevent oxidation and the resulting deterioration of rubber and corrosion of rim components.

Proper nitrogen inflation equipment and training in its use are necessary to avoid overinflation. A tire blowout or rim failure can result from improper or misused equipment.

Stand behind the tread and use a self-attaching chuck when inflation a tire.

Servicing, changing tires and rims can be dangerous and should be done only by trained personnel using proper tools and procedures. If correct procedures are not followed while servicing tires and rims, the assemblies could burst with explosive force and cause serious personal injury or death. Follow carefully the specific information provided by your tire or rim servicing personnel or dealer.

## Operator Restraint System (If Equipped)

### Warning Signs and Labels

Your DOOSAN lift truck has the following tipover warning decals.


Make sure that you can read all safety signs. Clean or replace these if you cannot read the words or see the pictures. When cleaning the labels use a cloth, water and soap. Do not use solvent, gasoline, etc. You must replace a label if it is damaged, missing or cannot be read. If a label is on a part that is replaced, make sure a new label is installed on the replaced part. See your DOOSAN Lift Truck dealer for new labels.

The most effective method of preventing serious injury or death to yourself or others is to familiarize yourself with the proper operation of the lift truck, to be alert, and to avoid actions or conditions which can result in an accident.



**Tipover can occur if the truck is improperly operated. In the event of tipover, injury or death could result.**






The “Survive in tipover” warning is located on the overhead guard. It shows the proper use of the operator restraint system.

**⚠ WARNING**

**Do not place your hand or fingers under the seat. Injury may occur as the seat moves up and down.**

### Seat Adjustment



Move the lever, slide the seat to the desired position, and release the lever.

Adjust the seat before operating the lift truck. After adjusting, set the seat to make sure it is properly locked. Do not adjust the seat while the truck is in motion.

## If Optional Suspension Seat (Weight Adjusting Type) Equipped

### Forward and Backward Adjustment

The seat can be adjusted by pushing the lever on the right side of seat.



Adjust the seat before operating the lift truck. After adjusting, set the seat to make sure it is properly locked. Do not adjust the seat while the truck is in motion.

### Weight adjustment

Pull the weight adjustment lever upwards and move right or left side.  
Adjust to driver's weight in 7 steps (50 ~ 110 kg)


#### NOTICE

Do NOT place your hand or fingers under the seat. Injury may occur as the seat moves up and down.



### Backrest Inclination


The backrest angle can be adjusted by using the lever on the left side of seat.




**Seat Belt**

The Operator Restraint System, Prevents the operator from jumping from the operator's compartment in the event of forward or side tipover. The system is designed to keep the operator on the seat and in the operator's compartment in the event of tipover.

**Inspection**




1. If the seat belt is torn, if pulling motion is interrupted during extension of the belt, or if the belt cannot be inserted into the buckle properly, replace the seat belt assembly.



2. Belt Maintenance – Every 500 service hours. Check that the belt fastening works properly and that winding device is free from run lock when jerked. Check that the belt is suitably fastened to the seat. Check that the seat is correctly secured to the hood and the chassis. On visual inspection, fastenings must be intact, otherwise, contact the safety manager.

**⚠ WARNING**

Your DOOSAN truck comes equipped with a DOOSAN operator restraint system. Should it become necessary to replace the seat for any reason, it should only be replaced with another DOOSAN operator restraint system.



3. In the event of tipover, the seat and restraint system should be inspected for damage and replaced, if necessary.


**NOTE:** Operator restraints shall be examined at the regular truck service intervals. It is recommended that they be replaced if any of the following conditions are found:

- Cut or frayed strap
- Worn or damaged hardware including anchor points
- Buckle or retractor malfunction
- Loose stitching

**⚠ WARNING**

The seat belt may cause the operator to bend at the waist. If you are pregnant or have suffered from some abdominal disease, consult a doctor before you use the seat belt.

**Fasten the Seat Belt**




1. Grip the plate (connector) of the belt and insert the plate into the slot of the buckle until a snap is heard. Adjust the belt to fit snugly across your hips. Pull on the belt to confirm it is latched.
2. Make sure the belt is not twisted.

**⚠ WARNING**

**If you fasten the belt across your abdomen, the belt may injure your abdomen in an accident.**


The belt will automatically retract when released. Hold the plate of the belt and allow the belt to slowly retract.



1. Be sure to fasten the belt across your hips, not across your abdomen.

**NOTE:** The belt is designed to automatically adjust to your size and movement. A quick pull on the belt will confirm that the automatic adjuster will hold the belt position in the event of an accident.


**Release the Seat Belt**



Push the button of the buckle to release the belt.


## Avoiding Lift Truck Tipovers

### Lift Truck Stability




Counterbalanced lift truck design is based on the balance of two weights on opposite sides of a fulcrum (the front axle). The load on the forks must be balanced by the weight of the lift truck. The location of the center of gravity of both the truck and the load is also a factor. This basic principle is used for picking up a load. The ability of the lift truck to handle a load is discussed in terms of center of gravity and both forward and sideways stability.

### Center of Gravity (CG)




The point within an object, at which the whole weight of the object may be regarded as being concentrated, is called the center of gravity or CG. If the object is uniform, its geometric center will coincide with its CG. If it is not uniform, the CG could be at a point outside of the object. When the lift truck picks up a load, the truck and load have a new combined CG.

### Stability and Center of Gravity



The stability of the lift truck is determined by the location of its CG; or, if the truck is loaded, the combined CG of the truck and load. The lift truck has moving parts and, therefore, has a CG that moves. The CG moves forward or backward as the mast is tilted forward or backward. The CG moves up or down as the mast moves up or down. The CG and, therefore, the stability of the loaded lift truck, is affected by a number of factors such as :


- the size, weight, shape and position of the load
- the height to which the load is lifted
- the amount of forward or backward tilt
- tire pressure
- dynamic forces created when the lift truck is accelerated, braked or turned
- condition and grade of surfaces on which the lift truck is operated



These same factors are also important for unloaded lift trucks. They tip over sideways easier than a loaded lift truck carrying its load in the lowered position.



## Lift Truck Stability Base




For the lift truck to be stable (not tip over forward or to the side), the CG must stay within the area of the lift truck stability base  $\Delta$  a triangular area between the front wheels and the pivot of the steer wheels. If the CG moves forward of the front axle, the lift truck will tip forward. If the CG moves outside of the line on either side of the stability base, the lift truck will tip to the side.

### **⚠ WARNING**

Dynamic forces (braking, acceleration, turning) also affect stability and can produce tipover even when the CG is within the stability triangle.

## Capacity Load (Weight and Load Center)



The capacity load of the lift truck is shown on the capacity/nameplate riveted to the truck. It is determined by the weight and load center. The load center is determined by the location of the CG of the load. The load center shown on the nameplate is the horizontal distance from the front face of the forks, or the load face of an attachment, to the CG of the load. The location of the CG in the vertical direction is the same as the horizontal dimension.

Remember that, unless otherwise indicated, the capacity load shown on the nameplate is for a standard lift truck with standard backrest, forks and mast, and having no special-purpose attachment. In addition, the capacity load assumes that the load center is no further from the top of the forks than it is from the face of the backrest. If these conditions do not exist, the operator may have to reduce the safe operating load because the truck stability may be reduced. The lift truck should not be operated if its capacity/nameplate does not indicate capacity load.

**NOTE :** If the load is not uniform, the heaviest portion should be placed closer to the backrest and centered on the forks.

### **⚠ CAUTION**

1. Capacity/Nameplates originally attached to forklifts sold by DOOSAN shall not be removed, altered or replaced without DOOSAN's approval.
2. DOOSAN assumes no responsibility for lift trucks placed in service without a valid DOOSAN Nameplate.
3. If necessary to change your specification, contact your DOOSAN lift truck dealer.

## Safety Rules




Only properly trained and authorized personnel should operate forklift trucks. Wear a hard hat and safety shoes when operating a lift truck. Do not wear loose clothing.



Inspect and check the condition of your forklift truck using the operator's check list before starting work. Immediately report to your supervisor any obvious defects or required repairs.




Do not operate your truck in unauthorized areas. Know your forklift truck and think safety. Do not compromise safety. Follow all safety rules and read all warning signs.




Do not operate a lift truck unless you are in the operator's seat. Keep hands and feet inside the operator's compartment. Do not put any part of the body outside of the operator's compartment. Never put any part of body into the mast structure or between the mast and the truck




Do not start, stop, turn or change direction suddenly or at high speed. Sudden movement can cause the lift truck to tip over. Slow the speed of your truck and use the horn near corners, exits, entrances, and near people.



Never operate a lift truck with wet hands or shoes. Never hold any controls with grease on your hands. Your hands or feet will slide off of the controls and cause an accident.



Do not raise anyone on the forks of your lift truck. Do not let other people ride on the truck. Lift trucks are designed to carry loads, not people.



Do not overload. Always handle loads within the rated capacity shown on the capacity plate. Do not add extra counterweight to the truck. An overload can cause the truck to roll over and cause injury to personnel and damage to the lift truck.



Do not operate your truck without the load backrest extension and overhead guard. Keep the load against the backrest with the mast tilted backward



Do not drive on soft ground. Observe all signs, especially those on maximum permitted floor loadings, elevator capacities and clearance heights. Handle loads carefully and check them closely for stability and balance.




Do not lift or move loads that are not safe. Do not pick up an off center load. Such a load increases the possibility of a tipover to the side. Make sure loads are correctly stacked and positioned across both forks. Always use the proper size pallet. Position the forks as wide as possible under the load. Position loads evenly on the forks for proper balance. Do not lift a load with one fork.




Do not drive on slippery surfaces. Sand, gravel, ice or mud can cause a tipover. If unavoidable, slow down.

Safety Section




Do not permit anyone to stand or walk under the load or lifting mechanism. The load can fall and cause injury or death to anyone standing below.




Do not elevate the load with the mast tilted forward. Do not tilt the elevated loads forwards. This will cause the lift truck to tip over forward.




Look out for overhead obstructions when raising or stacking loads. Do not travel with a raised load. Do not travel with the mast raised. The lift truck can roll over and cause injury or death to you or other personnel.




Do not jump off if your truck starts to tip over. Stay in your seat to survive.




Do not move loose loads that are higher than the load backrest. Be alert for falling loads when stacking. Travel with the load tilted back and the forks as low as possible. This will increase stability to the truck and load and permit better visibility for you.




Go up ramps in forward direction and down ramps in reverse direction when moving loads. Never elevate a load with the forklift truck on an incline. Go straight off and straight down. Use an assistant when going up or down a ramp with a bulky load.




Do not stack or turn on ramps.  
Do not attempt to pick-up or deposit a load unless the lift truck is level. Do not turn on or drive across an incline.




Do not drive in forward direction when loads restrict your visibility. Operate your lift truck in reverse to improve visibility except when moving up a ramp.




Do not go over rough terrain. If unavoidable, slow down. Cross railroad tracks slowly and diagonally whenever possible. A railroad crossing can give a loaded forklift truck a real jolt. For smoother crossing, cross the railroad diagonally so one wheel crosses at a time.



Be careful when operating a lift truck near the edge of a loading dock or ramp. Maintain a safe distance from the edge of docks, ramps and platforms. Always watch tail swing. The truck can fall over the edge and cause injury or death.




Avoid running over loose objects.  
Look in the direction of travel. Look out for other persons or obstructions in your path of travel. An operator must be in full control of his lift truck at all times.




Do not operate on bridge plates unless they can support the weight of the truck and load. Make sure that they are correctly positioned. Put blocks on the vehicle you enter to keep it from moving.


Safety Section




Do not operate your truck close to another truck. Always keep a safe distance from other trucks and make sure there is enough distance to stop safely. Never overtake other vehicles.



Do not use your lift truck to push or tow another truck. Do not let another push or tow your truck. If a truck will not move, call a service technician.




Forklift trucks may only be refueled at specially reserved locations. Switch off the engine when refueling. Smoking and handling of naked flames during refueling are strictly prohibited. This prohibition also applies during the changing of the LPG (liquefied propane gas) tank.



Mop up spilt fuel and do not forget to close the fuel tank before restarting the engine.

Park your lift truck in authorized areas only. Fully lower the forks to the floor, put direction lever in NEUTRAL position, engage the parking brake, and turn the key to the OFF position. Remove the key and put blocks behind the wheels to prevent the truck from rolling. Shut off your forklift truck when leaving it unattended.

Check the condition of your forklift truck after the day's work.



Exhaust from all internal combustion engines contains carbon monoxide, a colorless, odorless, tasteless, poisonous gas. Exposure to carbon monoxide can cause serious injury or health problems, including death, and avoid unnecessary idling of the engine. If nausea, dizziness or headaches are experienced stop the truck and seek fresh air.

## How to Survive in a Tipover



In the event of a tipover, the risk of serious injury or death will be reduced if the operator is using the operator restraint system and follows the instructions provided.


Always use operator restraint system.



DON'T jump.



Hold on tight.



Brace your feet and keep them within the operator's compartment.

Safety Section



Lean away from the direction of fall.




Lean forward.



# Specifications

CHARACTERISTICS							
1	Manufacturer			DOOSAN	DOOSAN	DOOSAN	
2	Model			GC15S-5(TIER-3)	GC18S-5(TIER-3)	GC20SC-5(TIER-3)	
3	Capacity	at rated load center	lb/kg	3000/1500	3500/1750	4000/2000	
4	Load center	distance	inch/mm	24/500	24/500	24/500	
5	Power type	electric, diesel, gasoline, lp-gas		LP	LP	LP	
6	Operator type	stand-on, rider-seated		Rider - seated	Rider - seated	Rider - seated	
7	Tire	c=cushion, p=pneumatic		C	C	C	
8	Wheels(x=driven)	number, front/rear		X 2/2	X 2/2	X 2/2	
DIMENSIONS							
9	Lift with STD	maximum fork height with rated load	inch/mm	118/3000	118/3000	118/3000	
10	two-stage mast	free lift	inch/mm	5.1/130	5.1/130	5.3/135	
11		special free lift	mm				
12	Fork carriage	ISO class		II	II	II	
13	Forks	thickness X width X length	inch	1.4 x 4 x 41	1.4 x 4 x 41	1.6 x 4 x 41	
14	Tilt of mast	forward/backward	deg	6 / 8	6 / 8	6 / 8	
15	Overall dimensions	length without forks	inch/mm	80.8/2051.5	82.9/2106.5	84.1/2138.5	
16		width	inch/mm	37/940	39/991	39/991	
17		mast lowered height	inch/mm	78/1980	78/1980	78/1980	
18		mast extended height	inch/mm	159/4045	159/4045	159/4050	
19		overhead guard height	inch/mm	81/2060	81/2060	81/2060	
20		seat height	inch/mm	39.3/1000	39.3/1000	39.3/1000	
21	Outside turning radius			inch/mm	71.5/1816	74/1881	76/1932
22	Load moment constant			inch/mm	15.5/394	15.5/394	15.7/399
23	90° stacking aisle			inch/mm	86/2184	88/2235	89/2261
23a	90° intersecting aisle			inch/mm	63.1/1603	64.7/1643	65.1/1653
PERFORMANCE							
24	Speeds	travel, loaded/unloaded	mph	11.3/11.6	11.3/11.6	11.3/11.6	
			kph	18.0/18.5	18.0/18.5	18.0/18.5	
25		lift, loaded/unloaded	fpm	118.1/128	118.1/128	118.1/128	
			mm/s	600/650	600/650	600/650	
26		lowering, loaded/unloaded	fpm	98.4/88.6	98.4/88.6	98.4/88.6	
			mm/s	500/450	500/450	500/450	
28	Drawbar pull	at 1.0 mph, loaded	lb/kg	3086/1400	3086/1400	3086/1400	
30	Gradeability	at 1.6 mph, loaded	%	37	32	30	
31	Acceleration	traveling loaded/unloaded	s				
WEIGHT							
32	Total weight	unloaded	lb/kg	5940/2695	6510/2955	6800/3085	
33	Axle load	with loaded, front/rear	lb	7840/1100	8345/1450	9400/1400	
			kg	3685/510	4035/670	4435/650	
34		without loaded, front/rear	lb	2370/3570	2190/4320	2095/4695	
			kg	1075/1620	995/1960	955/2130	
CHASSIS							
35		number of front/rear		2 / 2	2 / 2	2 / 2	
36	Tires	front size	inch	18 X 6 X 12.12	18 X 7 X 12.12	18 X 7 X 12.12	
37		rear size	inch	14 X 5 X 10	14 X 5 X 10	14 X 5 X 10	
38	Wheel base			inch/mm	48.2/1225	48.2/1225	
39	Tread	front/rear	inch	31/31	32/31	32/31	
			mm	787/787	813/787	813/787	
40	Ground clearance	at loaded, the lowest point	inch/mm	3/75	3/75	3/75	
41		at loaded, the center of wheelbase	inch/mm	4.3/110	4.3/110	4.3/110	
42	Service brake			foot/hydraulic	foot/hydraulic	foot/hydraulic	
43	Parking brake			hand/mech	hand/mech	hand/mech	
DRIVE							
45	Battery	voltage/capacity	V/AH	12 / 45	12 / 45	12 / 45	
49		manufacturer/model		G420FE	G420FE	G420FE	
50	Engine	rated output (at rpm)	hp/rpm	45.5@2300	45.5@2300	45.5@2300	
			ps/rpm	46.1@2300	46.1@2300	46.1@2300	
51		max. torque	lb-ft	112@1600	112@1600	112@1600	
			kg.m/rpm	15.5@1600	15.5@1600	15.5@1600	
52		cycle/cylinders/displacement	cc	1975	1975	1975	
53		fuel consumption	l/hr				
55	Transmission	type		Powershift	Powershift	Powershift	
56		no. speeds forward/reverse		1/1	1/1	1/1	

General Section




## Noise and Vibration

Model	Sound Pressure Level at Operator's ear (Leq.) according to EN12053 Guaranteed Sound	Whole-body Vibration Level according to EN13059 (m/s <sup>2</sup> )	
	dB(A)	Mean	Uncertainty
GC15/18S-5, GC20SC-5	82	1.8	0.5

# Serial Number


## Serial Number Locations

For quick reference, record your lift truck's serial numbers in the spaces provided below the photographs.




Lift Truck Serial Number

• \_\_\_\_\_




2.0 liter Spark – Ignition Engine Serial Number (G420F(E))

• \_\_\_\_\_



2.3 liter Diesel Engine Serial Number

• \_\_\_\_\_



Power Shift Transaxle Serial Number

• \_\_\_\_\_



Side Shift Serial Number (If Equipped)

• \_\_\_\_\_

## Operator's Warning and Identification Plate


Familiarize yourself with the OPERATOR'S WARNING Plate and, IDENTIFICATION, LIFT CAPACITY and ATTACHMENT PLATES. DO NOT exceed capacity as equipped load ratings.

### Operator's Warning Plate



Located by the right side of the operator's seat on the engine compartment cover.

### Identification, Lift Capacity and Attachment Plate



Located on the cowl to the right side of the steering column.

### Lift Truck Capacity Rating

Do not exceed allowable lift truck working capacity load ratings.

The capacity of the lift truck is given by weight and distance to the load center. For example: a capacity of 1500kg(3300 lb) at 500mm(24in) means that the lift truck can lift 1500kg(3300lb) if the load center is 500 mm (24in) from both the vertical and horizontal faces of the forks.

Before attempting to lift any load, ensure that the weight and load center combination is within the capacity of the lift truck as shown on the capacity rating plate. To determine the load center measure the distance from the face of the carriage to the gravitational center of the load.

The rated capacity on the plate refers to the capacity of the lift truck as it left the factory. Subsequent changes of any form to the equipment or battery can alter the lift truck's rating.

The rated capacity of the lift truck applies to operating conditions where the lift truck is on level ground. The capacity of the lift truck is reduced on inclines.

Below are abbreviations that may appear on the IDENTIFICATION, LIFT CAPACITY and ATTACHMENTPLATES and their meanings.

## Mast Abbreviations

<b>STD -</b>	Standard Mast (single inner member, low free lift)
<b>FF -</b>	Full Free Lift Mast (single inner member with high free lift duplex cylinder)
<b>FFT -</b>	Triple Lift Mast (two inner members) with either low or full free lift characteristics.
<b>QUAD -</b>	Quadruple (Quad) Mast (with three inner members)

**NOTE :** When only a mast-type is listed on the Nameplate, a standard carriage and forks are used.

## Attachment Abbreviations (includes Special Forks)


<b>SC-</b>	Special Carriage - increased width, height or outreach
<b>SSS -</b>	Shaft-type Sideshift Carriage
<b>HSS -</b>	Hook-type Sideshift Carriage (ITA)
<b>CW -</b>	Counterweight
<b>SF -</b>	Special Forks
<b>SWS -</b>	Swing Shift, Sideshift
<b>RAM -</b>	Ram or Boom
<b>DBCBH -</b>	Double Cube Block Handler
<b>HFP -</b>	Hydraulic Fork Positioner
<b>CR -</b>	Crane Arm or Crane Boom
<b>TH -</b>	Tire Handler
<b>CTH -</b>	Container Handler
<b>LPP -</b>	Load Push-Pull Device
<b>CC -</b>	Carton Clamp
<b>RC -</b>	Roll Clamp
<b>LS -</b>	Load Stabilizer
<b>PWH -</b>	Pulp Wood Handler
<b>SS-ST -</b>	Sideshift-Side Tilt Carriage

# Operator's Station and Monitoring Systems


## Instrument Panel

Your lift truck may not have the same indicator or warning lights as shown in the illustrations. Due to the various options available, typical instrument panels are shown. However, the symbols on the indicators and lights on your panel identify what those particular items are. Also, the symbol for each of the items is identified and an explanation of their function and location is described on the following pages.

### Diesel (12V)



### LPG/GAS (12V)





**1. Engine Oil Pressure Indicator Light -**

Indicates insufficient engine oil pressure. The light will come on when the ignition switch is turned to the ON position. The light should go off after the engine is started. If the light turns on while operating the lift truck, insufficient engine oil pressure is indicated. Park the lift truck and stop the engine.

Check the system for a malfunction. The light will turn on when the oil pressure drops to approximately 70kPa (10psi).



**2. Alternator Indicator Light -**

Indicates if the battery charging system is operational. The light will come on when the ignition switch is turned to the ON position.

The light should go off after the engine is started, indicating the alternator is producing sufficient voltage to charge the battery. If the light turns on with the engine running, check the alternator charging system for a malfunction.



**3. Diesel Engine Start Preheat Indicator Light (Diesel Engine Only) -**

The light will come ON when the key is turned to the ON position from the OFF position. This indicates that the glow plugs are preheating the pre-combustion chambers for easier starting.

The amount of time needed to preheat the pre-combustion chambers is approximately seven seconds, depending on the surrounding air temperature. When the light goes OFF the maximum pre-combustion chamber temperature has been reached and the key can be turned to the START position to start the engine.



**4. Diesel Engine Water in Fuel Filter Indicator Light -**

Indicates when the engine is running, there is water in the fuel filter exceeds 100cc.

The light will come ON when the ignition switch is turned to the ON position. The light should go off after the engine is started. If the light turns on with the engine running, park the lift truck and stop the engine.

Drain some fuel (and any water) until clean fuel flows from the filter which approximately takes 5 to 6 seconds.



**5. Fuel Level Gauge -**

Indicates fuel level (Gas, Diesel, or Dual Fuel Trucks Only)



**6. Engine Coolant Temperature Gauge -**

Indicates coolant temperature. If both tenth & ninth flash out of phase while operating the lift truck, overheating is indicated. Park the lift truck and stop the engine.

Check the cooling system for a malfunction. Both tenth & ninth will flash out of phase when the coolant temperature reaches approximately 106°C (223°F) on all engines.



**7. Transmission Oil Temperature Gauge -**

Indicates transmission oil temperature. If both tenth & ninth flash out of phase while operating the lift truck, excessive transmission oil temperature is indicated. Park the lift truck and stop the engine.

Check the system for a malfunction. Both tenth & ninth will flash out of phase when the transmission oil temperature reaches approximately 80 to 100° C (175 to 220° F).



**8. G420F(E) LP Engine Malfunction Indicator Lamp (MIL) -**

G420F(E) engine control system is equipped with built-in fault diagnostics. Detected system faults can be displayed by the Malfunction Indicator Lamp (MIL) as Diagnostic Fault Codes(DFC) or flash codes, and viewed in detail with the use of service tool software. When the ignition key is turned ON the MIL will perform a self-test, illuminate once and then go OFF. If a detected fault condition exists, the fault or faults will be stored in the memory of the engine control module(ECM). Once a fault occurs the MIL will illuminate and remain ON. This signals the operator that a fault has been detected by the SECM.



**9. Seat Belt Warning Light -**

Indicates when the seat belt does not fastened by operator. The light will come ON when the ignition switch is turned to the on position the light should go off often engine is started.



**10. Service Hour Meter -**

Indicates the total number of hours the engine and the lift truck have operated. The hour meter will operate when the ignition switch is in the ON position, whether the engine is running or not. The hour meter is used to determine lubrication and maintenance intervals.



**11. Parking indicator light -**

The light will come ON when the parking lever is applied.



**12. Front Floodlights -**

Push down on the switch(17), to the first step, to turn the front floodlights on.

**Front and Rear Floodlights -** Push down on the switch(17), to the second step, to turn both the front and rear floodlights on. The floodlights are optional.





**13. Transmission Neutral Position Light** - Indicates the neutral position of transmission.



**14. Brake Fluid Oil Light (If Equipped)** - The light is ON when the brake fluid oil of brake reservoir comes down to low level position. Refill the proper brake fluid oil if its light is ON.



**15. Low Level Light of LP GAS** - Indicates the low Level of LP GAS (LP or DUAL only)



**16. Directional Turning Indicator Light**




**17. Front and Rear Floodlights Switch** - The front floodlight is ON when push down switch to the first step.

The front and rear floodlights are ON when push down switch to the second step.



**18. Horn Switch** - Push on the horn button to sound the horn.

## Electrical Disconnect Switch (If Equipped)



**1. ON** - Connects the battery for electrical power to all electrical circuits.



**2. OFF** - Disconnects the battery from all electrical circuits.

## Seat Switch System (If Equipped)



The lift truck is equipped with a SEAT SWITCH SYSTEM. In normal operation if the direction lever is placed in either forward or reverse, the lift truck will move at a speed proportional to the accelerator pedal's position. If the operator leaves the seat without setting the parking brake, within three seconds after leaving the seat, the SEAT SWITCH SYSTEM will automatically disengage the transmission. The directional lever, however, will remain in that forward or reverse location although internally the transmission will have shifted into neutral.

Before exiting the lift truck, the parking brake should always be applied.

### **WARNING**

**WHEN LEAVING MACHINE APPLY PARKING BRAKE!**

**PARKING BRAKE IS NOT AUTOMATICALLY APPLIED.**

**NOTE:** Some trucks may be equipped (ask your dealer if this applies to your truck) with an alarm that will sound if the parking brake is not applied when leaving the machine.

---


### **NOTICE**

1. Prior to operating the lift truck, be sure to understand and check the SEAT SWITCH SYSTEM.
  2. While in normal operation and on level ground, select a direction with the directional lever and with the park brake released. You will note that the truck will move slowly in the selected direction. If you lift your hips off of the seat, within three seconds, the SEAT SWITCH SYSTEM will disengage the transmission allowing the truck to coast but not automatically stop.
  3. To restore the lift truck to normal operation, while sitting in the operator's seat depress the brake pedal to hold the lift truck, return the directional lever to the neutral position, and then reselect a direction of travel (either forward or reverse). The transmission will then re-engage.
  4. If seat or seat switch replacement becomes necessary, be sure to use genuine DOOSAN Infracore lift truck parts. Lift trucks should never be operated without an operational SEAT SWITCH SYSTEM.
-

## Engine Compartment



1. The engine compartment is accessible by pulling the latch and raising the hood and seat assembly.



2. The hood and seat assembly is held up by a support cylinder. Make certain the air cylinder is operating properly and will hold the hood up before doing anything in the engine compartment.

## Circuit Breaker



**Circuit Breaker** - Protects the main electrical circuits. To reset the circuit breaker, push the button in. It is Located in the engine compartment.

## Seat

**NOTE :** Seat arrangements may vary. Basic operation will be similar.

Seat adjustment should be checked at the beginning of each shift and when operators change. Lock the seat into position before operating, to prevent an unexpected seat change.



Adjust seat to allow full brake pedal travel with operator's back against seat back.

**NOTE :** The seat can only be correctly adjusted with the operator fully seated.

## Tilting Steering Column






To adjust the steering column, push down the knob(1) and move the steering column to the desired position, then release the knob(1)

## Lift Truck Controls


### Direction Control Lever



- 
**1. Forward** - Push the lever forward for FORWARD direction travel.
- 
**2. Neutral** - Move the lever to center position for NEUTRAL.
- 
**3. Reverse** - Pull the lever back for REVERSE direction travel.

### Transmission Inching Control Pedal




- 
**Inching Control Pedal** - Pushing down on the inching pedal, modulates the hydraulic pressure to the clutch packs, permitting disc slippage.

Further pushing on the pedal completely relieves clutch pack pressure and applies the service brakes to stop and hold the lift truck.

**NOTE :** The purpose of the inching control pedal is to provide precise inching control at slow travel speed, with high engine rpm. This is used for fast hydraulic lift during load approach, pickup or positioning.

### Service Brake Pedal




Push **DOWN** on the brake pedal to slow or stop the lift truck.



**RELEASE** the brake pedal to allow the lift truck to move.

### Parking Brake Lever




Pull the lever **BACK** to engage the parking brake.



Push the lever **FORWARD** to release the parking brake.

### Accelerator Pedal




Push **DOWN** on the pedal to increase engine rpm (speed).



**RELEASE** the pedal to decrease engine rpm (speed).

### Lift Control



**NOTE :** To prevent a sudden change of position of the load, operate all lift, tilt and attachment controls smoothly.



**1. Lower Position** - Push the lever **FORWARD** smoothly to lower the load.



**2. Hold Position** - When the lever is released it will return to the **HOLD** or center position. Lifting or lowering action will stop.



**3. Lift Position** - Pull the lever **BACK** smoothly to lift the load.

## Tilt Control



1. **Mast Tilt Back** - Pull the lever **BACK** smoothly to tilt the mast backward.



2. **Mast Hold** - When the lever is released it will return to the **HOLD** or center position. Tilting action will stop.



3. **Mast Tilt Forward** - Push the lever **FORWARD** smoothly to tilt the mast forward.

## Sideshift Attachment Control (If Equipped)



1. **Sideshift Left** - Push the lever **FORWARD** to shift the carriage to the left.



2. **Sideshift Hold** - When the lever is released it will return to the **HOLD** or center position. Sideshifting action will stop.



3. **Sideshift Right** - Pull the lever **BACK** to shift the carriage to the right.

## Refueling

### WARNING

**Only trained, authorized personnel should fill or exchange LP-Gas tanks.**

Personnel engaged in filling of LP-Gas containers should wear protective clothing such as face shield, long sleeves and gauntlet gloves.

Do not refuel or store LP-Gas powered lift trucks near any underground entrance, elevator shafts or any other place where LP-Gas could collect in a pocket causing a potentially dangerous condition.

Examine all LP-Gas containers before filling and again before reuse, for damage to various valves, liquid gauge, fittings and hand valve wheels.

All defective or damaged LP-Gas containers must be removed from service.

Explosive fumes may be present during refueling.

Do not smoke in refueling areas.

Lift truck should be refueled only at designated safe locations. Safe outdoor locations are preferable to indoor locations.

Stop the engine and get off the lift truck during refueling.

The careless handling of LP-Gas containers can result in a serious accident.

Use extreme care when transporting containers to prevent damage to them.

## Changing LP-Gas Tanks

1. Park the lift truck on level ground, with the parking brake applied, the transmission in NEUTRAL, the forks lowered and the engine running at low idle.



2. Close the fuel shutoff valve at the LP-Gas tank. Run the engine until it stops, then turn off the ignition switch.
3. Disconnect the fuel supply line.




4. Loosen the retaining clamps and remove the tank.
5. Check the mounting to be sure the locating pin (dowel) is not missing or broken.


### NOTICE

**If the locating pin (dowel) is missing or broken, be sure the pin is replaced.**






6. Check to be sure that the LP-Gas warning plate is in position on the lift truck and is legible.
7. Check to be sure the replacement tank is of the correct type.
8. Inspect the replacement tank for damage such as dents, scrapes or gouges and for indication of leakage at valves or threaded connections.



9. Check for debris in the relief valve, for damage to various valves and liquid level gauge.
10. Inspect the quick-disconnect couplings for deterioration, damage or missing flexible seals.



11. Position the replacement tank so that the locating pin(dowel) is in place.

**⚠ CAUTION**

**The LP-Gas tank must not extend past the counterweight.**

---

12. Clamp the tank securely
13. Connect the fuel supply line.
14. Open the fuel valve by slowly turning the valve counterclockwise. If the fuel valve is opened too quickly, a back pressure check valve will shut off the fuel supply. If this happens, close the fuel valve completely. Wait five seconds and then open the fuel valve very slowly.
15. Inspect the LP-Gas fuel lines and fittings with a soap solution after filling the tank or when looking for leaks.

## Before Starting the Engine

### Walk-Around Inspection

Make a thorough walk-around inspection before mounting the lift truck or starting the engine. Look for such items as loose bolts, debris buildup, oil or coolant leaks and cut or gouged tires. Check condition of tires, mast, carriage, forks or attachments. Have repairs made as needed and all debris removed.

Before starting the gas engine, push the accelerator pedal all the way down once and then slowly it to set the automatic choke.



1. Inspect the operator's compartment for loose items and cleanliness.
2. Inspect the instrument panel for broken or damaged indicator lights or gauges.
3. Test the horn and other safety devices for proper operation.




4. Inspect the mast and lift chains for wear, broken links, pins and loose rollers.

5. Inspect the carriage, forks or attachments for wear, damage and loose or missing bolts.
6. Inspect the tires and wheels for cuts, gouges, foreign objects, inflation pressure and loose or missing bolts.



7. Inspect the overhead guard for damage and loose or missing mounting bolts.
8. Inspect the hydraulic system for leaks, worn hoses or damaged lines.
9. Look for transmission and drive axle leaks on the lift truck and on the ground.




Typical Example

10. Inspect the engine compartment for oil, coolant and fuel leaks.




Typical Example

11. Measure the engine crankcase oil level with the dip stick. Maintain the oil level between the MAX. and MIN., (or FULL and ADD) notches on the dip stick.



Typical Example

12. Observe the engine coolant level in the coolant recovery bottle. With the engine cold, maintain the level to the COLD mark. If the recovery bottle is empty, also fill the radiator at the top tank.



13. Observe the fuel level gauge after starting the truck. Add fuel if necessary.

**⚠ WARNING**

Personal injury may occur from accidents caused by improper seat adjustment. Always adjust the operator's seat before starting the lift truck engine.

Seat adjustment must be done at the beginning of each shift and when operators change.



14. To position the seat, PUSH the lever away from the seat track and move the seat forward or backward to a comfortable position.


## Starting the Engine

### Prestart Conditions

**NOTE:** The engine will not start unless the transmission directional control lever is in the NEUTRAL position.



1. Engage the parking brake, if not already engaged. Place the directional control lever in the NEUTRAL position.



2. Lift trucks equipped with electrical disconnect switches ; the engine will not start unless the disconnect switch is in the ON (closed) position. Before starting, turn the disconnect switch to the OFF (open) position.

### Gasoline Engine

---

#### NOTICE

Do not leave the key in ON position when engine is not running.  
Do not engage the starter more than 10 seconds at any one time

---

1. Don't press accelerator pedal, and turn the ignition switch to the START position.
2. Once the engine starts, release the ignition switch.
3. If the engine does not start, repeat step 1.
4. If engine coolant is cold, engine speed could be higher than low idle speed. Don't drive forklift until engine speed becomes normal low idle speed.

---

#### NOTICE

If the inside of engine cylinder is wet by gasoline, the engine could not start. In this case, press accelerator pedal fully and turn the ignition switch to ON position for 10 seconds. The inside of cylinder would be dry because ECM does not allow gasoline fuel injection. Repeat it three times. Don't press accelerator pedal and turn the ignition switch to the START position to start engine.


---

## LP-Gas Engine

### **WARNING**

**LP - Gas fuel is flammable and can cause personal injury.**

**Inspect LP - Gas fuel lines and fitting for leaks.  
Inspect tank for secure mounting.**



1. Turn the tank fuel valve ON by slowly turning the valve counterclockwise. Observe the LP – Gas gauge (if equipped).
2. Don't press accelerator pedal, and turn the ignition switch to the START position.
3. Once the engine starts, release the ignition switch.
4. If the engine does not start, repeat step 2.
5. If engine coolant is cold, engine speed could be higher than normal low idle speed. Don't drive forklift until engine speed becomes normal low idle speed.

## Diesel Engine

### Starting a Cold Diesel Engine

1. Turn the key to the ON position. The start preheat light will come ON. The preheat light will stay ON approximately seven seconds, depending on the surrounding air temperature.

---

### NOTICE

Do not engage the starter for more than 10 seconds.

---

2. When the preheat light goes OFF, turn the key to the START position, with the accelerator pedal fully depressed.
3. Release the key when the engine starts and release the accelerator pedal to a low idle position.
4. If the engine stalls or does not start, turn the key to the OFF position, then repeat steps 1 thru 3.

### Starting a Warm Diesel Engine

1. Turn the key to the ON position and then to START position, without waiting for the preheat light to go OFF. At the same time fully depress the accelerator.
2. Release the key when the engine starts and release the accelerator pedal to a low idle position.

## Starting From a 12 Volt External Source

---

**⚠ WARNING**

Sparks occurring near the battery could cause vapors to explode.

Always connect the external power source ground cable to a point away from and below the battery, and well clear of fuel system components.

---



Typical Example

---

**NOTICE**

Do not reverse battery cables. It can cause damage to the alternator.

Always connect the external power source cables in parallel with the lift truck battery cables : POSITIVE(+) to POSITIVE(+) and NEGATIVE(-) to NEGATIVE(-).


Attach ground cable last, remove first. All lift trucks equipped with DOOSAN built internal combustion engines are NEGATIVE(-) ground.

---


## After Starting the Engine

Observe all indicator lights and gauges frequently during operation, to make sure all systems are working properly. All of the indicator lights will come ON with the ignition switch in the ON position before the engine is started.

### Diesel (12V)




### LPG/GAS (12V)



1. The engine oil pressure indicator light (1), will not come ON with the engine running, unless there is low or no oil pressure. Stop the engine immediately, if the light comes ON.
2. The alternator indicator light (2), should not come ON during normal operation. The alternator is not producing the sufficient voltage to charge the battery if the light comes ON with the engine running.
3. The Spark-ignition G420F(E) engine MIL (Malfunction Indicator Light) (3) will not come ON with the engine running, unless the fault or faults are stored in the memory of the engine control module (ECM). Stop the engine and check the electric engine control system if the light comes ON. Refer G420E Engine of this section.

4. The diesel engine water in fuel filter indicator light(4), will not come ON with the engine running, unless water in fuel filter exceeds 100cc. Stop the engine immediately and drain the water if the light comes ON.
5. Observe the fuel level gauge (5) for fuel level in the tank.
6. The engine coolant temperature gauge pointer (6), will be in the green band with the engine running, unless the coolant temperature is excessive.
7. The transmission oil temperature gauge pointer (7), will be in the green band with the engine running, unless the oil temperature is excessive.




8. Observe the hour meter(8) make sure it is operating properly.

## Electronic Controlled Spark-Ignition Engines

### G420FE Engine

EMS (Engine management system) of G420F(E) engine engine is a closed loop system utilizing a 3-way catalytic muffler to reduce the emission level in the exhaust gas. In order to obtain maximum effect from the catalyst, an accurate control of the air fuel ratio is required. A small engine control module

(SECM) uses two heated exhaust gas oxygen sensors (HEGO) in the exhaust system to monitor exhaust gas content. One HEGO is installed in front of the catalytic muffler and one is installed after the catalytic muffler.



**EMS schematic of G420FE Dual fuel engine**

The SECM makes any necessary corrections to the air fuel ratio by controlling the inlet fuel pressure to the air/fuel mixer by modulating the dual fuel trim valves (FTV) connected to the regulator. Reducing the fuel pressure leans the air/fuel mixture and increasing the fuel pressure enriches the air/fuel mixture. To calculate any necessary corrections to the air fuel ratio, the SECM uses a number of different sensors to gain information about the engine's performance. Engine speed is monitored by the SECM through a variable reluctance (VR) or Hall Effect sensor. Intake manifold air temperature and absolute pressure are monitored with a TMAP sensor. MI-07 is a drive-by-wire (DBW) system connecting the accelerator pedal to the electronic throttle through the electrical harness; mechanical cables are not used. A throttle position sensor (TPS) monitors throttle position in relation to the accelerator pedal position sensor (APP) command. Even engine coolant temperature and adequate oil

pressure are monitored by the SECM. The SECM controller has full adaptive learning capabilities, allowing it to adapt control function as operating conditions change. Factors such as ambient temperature, fuel variations, ignition component wear, clogged air filter, and other operating variables are compensated.


MPI (multi-point injection) is used for this system. Fuel injection pressure and flow rate depend on engine-specific fuel injection requirements. A variety of regulators and injectors can be used to fit individual needs. The gasoline fuel pressure regulator is a one-way, non-return configuration. All gasoline specific components are automotive production parts and validated to strict automotive standards. Four (4) sequential injection channels are supported.



## G420F Engine

EMS (Engine management system) of G420F engine engine is an open loop LP system and/or closed loop gasoline system. 3-way catalytic muffler is not used for this system.

LPG regulator and the mixer are operated in open loop as no mixture adjustments are made by the SECM. Manifold pressure from the TMAP, rpm from the crank position sensor and throttle position is used by the SECM to calculate load. Feedback from the electronic throttle is still provided to the SECM by the throttle position sensors (TPS).



**EMS schematic of G420F Dual Fuel engine**

## Basic Troubleshooting(LP)

The MI-07 systems are equipped with built-in fault diagnostics. Detected system faults can be displayed by the Malfunction Indicator Lamp (MIL) and are covered in the Advanced Diagnostics section. Items such as fuel level, plugged fuel lines, clogged fuel filters and malfunctioning pressure regulators may not set a fault code by the Small Engine Control Module (SECM). Below are

basic checks that should be made before referring to the Advanced Diagnostics section, if engine or drivability problems are encountered.

Locating a problem in a propane engine is done exactly the same way as with a gasoline engine. Consider all parts of the ignition and mechanical systems as well as the fuel system.

Problem	Probable Cause	Corrective Action
<b>Engine Cranking but Will Not Start</b>	Fuel container empty	Fill fuel container <ul style="list-style-type: none"> <li>● Do not exceed 80% of liquid capacity</li> </ul>
	Liquid valve closed	Slowly open liquid valve
	Excess flow valve closed	Reset excess flow valve <ul style="list-style-type: none"> <li>● Close liquid valve</li> <li>● Wait for a "click" sound</li> <li>● Slowly open liquid valve</li> </ul>
	Plugged fuel line	Remove obstruction from the fuel line <ul style="list-style-type: none"> <li>● Close liquid fuel valve</li> <li>● Using caution, disconnect the fuel line (some propane may escape)</li> <li>● Clear obstruction with compressed air</li> <li>● Re-connect fuel line</li> <li>● Slowly open liquid fuel valve</li> <li>● Leak test</li> </ul>
	Broken Fuse - SECM	Replace Fuse for SECM <ul style="list-style-type: none"> <li>● See Maintenance Section, Fuses replacement</li> </ul>
	Clogged fuel filter	Repair/replace as required <ul style="list-style-type: none"> <li>● See <i>Maintenance Section, LP Fuel Filter replacement</i></li> </ul>
	Faulty vapor connection between the pressure regulator/converter and the mixer	Check connection <ul style="list-style-type: none"> <li>● Verify no holes in hose</li> <li>● Clamps must be tight</li> <li>● Look for kinked, pinched and/or collapsed hose</li> </ul>
	Fuel Lock-off malfunction	Repair/replace Fuel Lock-off <ul style="list-style-type: none"> <li>● See <i>Engine Service Manual</i></li> </ul>
	Pressure regulator/converter malfunction	Test pressure regulator/converter operation <ul style="list-style-type: none"> <li>● See <i>Engine Service Manual</i></li> </ul>
	Incorrect air/fuel or ignition/spark control	See Advanced Diagnostics
No VR Sensor Signal	Verify the VR signal is present <ul style="list-style-type: none"> <li>● See <i>Advanced Diagnostics</i></li> </ul>	

<b>Problem</b>	<b>Probable Cause</b>	<b>Corrective Action</b>
<b>Difficult to Start</b>	Fuel container almost empty	LPG Vapor from liquid outlet <ul style="list-style-type: none"> <li>● Fill fuel container</li> <li>● Do not exceed 80% of liquid capacity</li> </ul>
	Excess flow valve closed	Reset excess flow valve <ul style="list-style-type: none"> <li>● Close liquid valve</li> <li>● Wait for a “click” sound</li> <li>● Slowly open liquid valve</li> </ul>
	Clogged fuel filter	Repair/replace as required <ul style="list-style-type: none"> <li>● See <i>Maintenance Section, LP Fuel Filter replacement</i></li> </ul>
	Plugged fuel line	Remove obstruction from the fuel line <ul style="list-style-type: none"> <li>● Close liquid fuel valve</li> <li>● Using caution, disconnect the fuel line (some propane may escape)</li> <li>● Clear obstruction with compressed air</li> <li>● Re-connect fuel line</li> <li>● Slowly open liquid fuel valve</li> <li>● Leak test</li> </ul>
	Faulty vapor connection between the pressure regulator/converter and the mixer	Check connection <ul style="list-style-type: none"> <li>● Verify no holes in hose</li> <li>● Clamps must be tight</li> <li>● Look for kinked, pinched and/or collapsed hose</li> </ul>
	Pressure regulator/converter malfunction	Test pressure regulator/converter operation <ul style="list-style-type: none"> <li>● See <i>Engine Service Manual</i></li> </ul>
	Fuel container almost empty	LPG Vapor from liquid outlet <ul style="list-style-type: none"> <li>● Fill fuel container</li> <li>● Do not exceed 80% of liquid capacity</li> </ul>
	Air filter clogged	Check air filter <ul style="list-style-type: none"> <li>● Clean/replace as required</li> </ul>
	Incorrect air/fuel or ignition control	See Advanced Diagnostics
	Engine Mechanical	See Engine Service Manual

<b>Problem</b>	<b>Probable Cause</b>	<b>Corrective Action</b>
<b>Will Not Run Continuously</b>	Fuel container almost empty	LPG Vapor from liquid outlet <ul style="list-style-type: none"> <li>● Fill fuel container</li> <li>● Do not exceed 80% of liquid capacity</li> </ul>
	Excess flow valve closed	Reset excess flow valve <ul style="list-style-type: none"> <li>● Close liquid valve</li> <li>● Wait for a “click” sound</li> <li>● Slowly open liquid valve</li> </ul>
	Clogged fuel filter	Repair/replace as required <ul style="list-style-type: none"> <li>● See <i>Maintenance Section, LP Fuel Filter replacement</i></li> </ul>
	Plugged fuel line	Remove obstruction from the fuel line <ul style="list-style-type: none"> <li>● Close liquid fuel valve</li> <li>● Using caution, disconnect the fuel line (some propane may escape)</li> <li>● Clear obstruction with compressed air</li> <li>● Re-connect fuel line</li> <li>● Slowly open liquid fuel valve &amp; Leak test</li> </ul>
	Pressure regulator freezes	Check level in cooling system <ul style="list-style-type: none"> <li>● Must be full, check coolant strength</li> <li>● -35F minimum</li> </ul> Check coolant hoses <ul style="list-style-type: none"> <li>● Watch for kinks and/or pinched hoses</li> <li>● Verify one pressure hose and one return hose</li> </ul>
	Fuel Lock-off malfunction	Repair/replace Fuel Lock-off <ul style="list-style-type: none"> <li>● See <i>Engine Service Manual</i></li> </ul>
	Incorrect idle speed or ignition problem	See Advanced Diagnostics
	Engine Mechanical	See Engine Service Manual
<b>Will Not Accelerate/Hesitation During Acceleration</b>	Fuel container almost empty	LPG Vapor from liquid outlet <ul style="list-style-type: none"> <li>● Fill fuel container</li> <li>● Do not exceed 80% of liquid capacity</li> </ul>
	Excess flow valve closed	Reset excess flow valve <ul style="list-style-type: none"> <li>● Close liquid valve</li> <li>● Wait for a “click” sound</li> <li>● Slowly open liquid valve</li> </ul>

<b>Problem</b>	<b>Probable Cause</b>	<b>Corrective Action</b>
<b>Will Not Accelerate/Hesitation During Acceleration</b>	Clogged fuel filter	Repair/replace as required <ul style="list-style-type: none"> <li>● See <i>Maintenance Section, LP Fuel Filter replacement</i></li> </ul>
	Faulty vapor connection between the pressure regulator/convertor and the mixer	Check connection <ul style="list-style-type: none"> <li>● Verify no holes in hose</li> <li>● Clamps must be tight</li> <li>● Look for kinked, pinched and/or collapsed hose</li> </ul>
	Throttle butterfly valve not opening or sticking	See Advanced Diagnostics
	Foot Pedal signal incorrect or intermittent	
	Incorrect air/fuel or ignition control	
Engine Mechanical	See Engine Service Manual	
<b>Engine Stalls</b>	Fuel container almost empty	LPG Vapor from liquid outlet <ul style="list-style-type: none"> <li>● Fill fuel container</li> <li>● Do not exceed 80% of liquid capacity</li> </ul>
	Excess flow valve closed	Reset excess flow valve <ul style="list-style-type: none"> <li>● Close liquid valve</li> <li>● Wait for a “click” sound</li> <li>● Slowly open liquid valve</li> </ul>
	Clogged fuel filter	Repair/replace as required <ul style="list-style-type: none"> <li>● See <i>Maintenance Section, LP Fuel Filter replacement</i></li> </ul>
	Plugged fuel line	Remove obstruction from the fuel line <ul style="list-style-type: none"> <li>● Close liquid fuel valve</li> <li>● Using caution, disconnect the fuel line (some propane may escape)</li> <li>● Clear obstruction with compressed air</li> <li>● Re-connect fuel line</li> <li>● Slowly open liquid fuel valve &amp; Leak test</li> </ul>

<b>Problem</b>	<b>Probable Cause</b>	<b>Corrective Action</b>
<b>Engine Stalls</b>	Fuel Lock-off malfunction	Repair/replace Fuel Lock-off ● <i>See Engine Service Manual</i>
	Faulty vapor connection between the pressure regulator/converter and the mixer	Check connection ● Verify no holes in hose ● Clamps must be tight ● Look for kinked, pinched and/or collapsed hose
	Pressure regulator freezes	Check level in cooling system ● Must be full, check coolant strength ● -35F minimum ● Check coolant hoses ● Watch for kinks and/or pinched hoses ● Verify one pressure hose and one return hose
	Pressure regulator malfunction	Test pressure regulator operation ● <i>See Engine Service Manual</i>
	Vacuum leak	Check for vacuum leaks ● Between mixer and throttle body ● Between throttle body and intake manifold ● Between intake manifold and cylinder head
	Air/Fuel Mixer malfunction	Check mixer ● <i>See Engine Service Manual</i>
	Engine Mechanical	See Engine Manufacturers Service Manual
<b>Rough Idle</b>	Faulty vapor connection between the pressure regulator/converter and the mixer	Check connection ● Verify no holes in hose ● Clamps must be tight ● Look for kinked, pinched and/or collapsed hose
	Pressure regulator malfunction	Test pressure regulator operation ● <i>See Engine Service Manual</i>
	Vacuum leak	Check for vacuum leaks ● Between mixer and throttle body ● Between throttle body and intake manifold ● Between intake manifold and cylinder head
	Air/Fuel Mixer malfunction	Check mixer ● <i>See Engine Service Manual</i>

<b>Problem</b>	<b>Probable Cause</b>	<b>Corrective Action</b>
<b>Rough Idle</b>	Incorrect Idle speed control	See Advanced Diagnostics & See Engine Service Manual
	Incorrect timing or spark control	
	Engine Mechanical	See Engine Service Manual
<b>High Idle Speed</b>	Incorrect Idle speed control	See Advanced Diagnostics & See Engine Service Manual
	Throttle sticking	
	Foot pedal sticking or incorrect pedal signal	Check pedal return spring travel for binding <ul style="list-style-type: none"> <li>● <i>See Advanced Diagnostics</i></li> </ul>
<b>Poor High Speed Performance</b>	Clogged fuel filter	Repair/replace as required <ul style="list-style-type: none"> <li>● <i>See Maintenance section, Fuel Filter replacement</i></li> </ul>
	Plugged fuel line	Remove obstruction from the fuel line <ul style="list-style-type: none"> <li>● Close liquid fuel valve</li> <li>● Using caution, disconnect the fuel line (some propane may escape)</li> <li>● Clear obstruction with compressed air</li> <li>● Re-connect fuel line</li> <li>● Slowly open liquid fuel valve &amp; Leak test</li> </ul>
	Air filter clogged	Check air filter <ul style="list-style-type: none"> <li>● Clean/replace as required</li> </ul>
	Faulty vapor connection between the pressure regulator/converter and the mixer	Check connection <ul style="list-style-type: none"> <li>● Verify no holes in hose</li> <li>● Clamps must be tight</li> <li>● Look for kinked, pinched and/or collapsed hose</li> </ul>
	Pressure regulator malfunction	Test pressure regulator operation <ul style="list-style-type: none"> <li>● <i>See Engine Service Manual</i></li> </ul>
	Air/Fuel Mixer malfunction	Check mixer <ul style="list-style-type: none"> <li>● <i>See Engine Service Manual</i></li> </ul>
	Restricted exhaust system	Check exhaust system <ul style="list-style-type: none"> <li>● Measure exhaust back pressure</li> </ul>
	Incorrect ignition control	See Advanced Diagnostics & See Engine Service Manual
	Incorrect air/fuel control	
	Incorrect throttle position	

<b>Problem</b>	<b>Probable Cause</b>	<b>Corrective Action</b>
<b>Excessive Fuel Consumption/LPG Exhaust Smell</b>	Air/Fuel Mixer malfunction	Check mixer ● See <i>Engine Service Manual</i>
	Air filter clogged	Check air filter ● Clean/replace as required
	Vacuum leak	Check system vacuum hoses from regulator to FTV and mixer ● Repair/replace as necessary
	Pressure regulator malfunction/fuel pressure too high	Test pressure regulator operation ● See <i>Engine Service Manual</i>
	Faulty FTV	Check FTV for housing cracks or obstructions ● See <i>Advanced Diagnostics FTV operation</i> ● Repair and/or replace as necessary
	Weak ignition and/or spark control	See <i>Advanced Diagnostics</i>
	Incorrect air/fuel control	See <i>Advanced Diagnostics</i>
	Exhaust system leaks	Repair exhaust system
Oxygen sensor failure	Replace as necessary ● See <i>Advanced Diagnostics</i>	




## Advanced Diagnostics

MI-07 systems are equipped with built-in fault diagnostics. Detected system faults can be displayed by the Malfunction Indicator Lamp (MIL) as Diagnostic Fault Codes (DFC) or flash codes, and viewed in detail with the use of the Service Tool software. When the ignition key is turned on, the MIL will illuminate and remain on until the engine is started. Once the engine is started, the MIL lamp will go out unless one or more fault conditions are present. If a detected fault condition exists, the fault or faults will be stored in the memory of the small engine control module (SECM). Once an active fault occurs the MIL will illuminate and remain ON. This signals the operator that a fault has been detected by the SECM.

## Reading Diagnostic Fault Codes

All MI-07 fault codes are three-digit codes. When the fault codes are retrieved (displayed) the MIL will flash for each digit with a short pause (0.5 seconds) between digits and a long pause (1.2 seconds) between fault codes. A code 12 is displayed at the end of the code list.

EXAMPLE: A code 461 (ETCSticking) has been detected and the engine has shut down and the MIL has remained ON. When the codes are displayed the MIL will flash four times (4), pause, then flash six times (6), pause, then flash one time (1) This identifies a four sixty one (461), which is the ETCSticking fault. If any additional faults were stored, the SECM would again have a long pause, then display the next fault by flashing each digit. Since no other faults were stored there will be a long pause then one flash (1), pause, then two flashes (2). This identifies a twelve, signifying the end of the fault list. This list will then repeat.



(1) Malfunction Indicator Lamp(MIL) for Engine control system

## Displaying Fault Codes (DFC) from SECM Memory

To enter code display mode you must turn OFF the ignition key. Now turn ON the key but do not start the engine. As soon as you turn the key to the ON position you must cycle the foot pedal by depressing it to the floor and then fully releasing the pedal (pedal maneuver). You must fully cycle the foot pedal three (3) times within five (5) seconds to enable the display codes feature of the SECM. Simply turn the key OFF to exit display mode. The code list will continue to repeat until the key is turned OFF.

**Table 2. MI-07 Diagnostic Fault Codes (Flash Codes)**

<b>DFC</b>	<b>PROBABLE FAULT</b>	<b>FAULT ACTION *</b>	<b>CORRECTIVE ACTION FIRST CHECK</b>
<b>12</b>	<b>NONE</b> Signifies the end of one pass through the fault list	NONE	None, used as end of the fault list identification
<b>131</b>	<b>Inj1Open</b> Gasoline Injector 1 open circuit, broken injector 1 wire or defective injector	TurnOnMil	Check INJ1 wiring for an open circuit SECM (Signal) A5 to Injector 1 Pin A Switched 12V to Injector 1 Pin B Check Injector 1 Resistance, 12 to14 ohms (cold)
<b>132</b>	<b>Inj2Open</b> Gasoline Injector 2 open circuit, broken injector 2 wire or defective injector	TurnOnMil	Check INJ2 wiring for an open circuit SECM (Signal) A8 to Injector 2 Pin A Switched 12V to Injector 2 Pin B Check Injector 2 Resistance, 12 to14 ohms (cold)
<b>133</b>	<b>Inj3Open</b> Gasoline Injector 3 open circuit, broken injector 3 wire or defective injector	TurnOnMil	Check INJ3 wiring for an open circuit SECM (Signal) A4 to Injector 3 Pin A Switched 12V to Injector 3 Pin B Check Injector 3 Resistance, 12 to14 ohms (cold)
<b>134</b>	<b>Inj4Open</b> Gasoline Injector 4 open circuit, broken injector 4 wire or defective injector	TurnOnMil	Check INJ4 wiring for an open circuit SECM (Signal) A7 to Injector 4 Pin A Switched 12V to Injector 4 Pin B Check Injector 4 Resistance, 12 to 14 ohms (cold)
<b>141</b> (14)	<b>ECTRangeLow</b> Coolant Sensor failure or shorted to GND	TurnOnMil	Check ECT sensor connector and wiring for a short to GND SECM (Signal) Pin B15 To ECT Pin 3 SECM (Sensor GND) Pin B1 to ECT Pin 1 SECM (System GND) Pin A16, B17
<b>151</b> (15)	<b>ECTRangeHigh</b> Coolant sensor disconnected or open circuit	(1) TurnOnMil (2) DelayedEngine Shutdown (3) CheckEngineLight	Check if ECT sensor connector is disconnected or for an open ECT circuit SECM (Signal) Pin B15 to ECT Pin 3 SECM (Sensor GND) Pin B1 to ECT Pin 1

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. MI-07 Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
161 (16)	<b>ECTOverTempFault</b> Engine coolant temperature is high. The sensor has measured an excessive coolant temperature typically due to the engine overheating.	(1) TurnOnMil (2) DelayedEngine Shutdown (3) CheckEngineLight	Check coolant system for radiator blockage, proper coolant level and for leaks in the system. Possible ECT short to GND, check ECT signal wiring SECM (Signal) Pin B15 to ECT Pin 3 SECM (Sensor GND) Pin B1 to ECT Pin 1 SECM (System GND) Pin A16, B17 Check regulator for coolant leaks
171	<b>ECT_IR_Fault</b> Engine coolant temperature not changing as expected	None	Check for coolant system problems, e.g. defective or stuck thermostat
181	<b>FuelSelectConflict</b> Conflict in fuel select signals, normally set if both of the fuel select signals are shorted to ground	TurnOnMil	Check fuel select switch connection for a short to GND SECM (SIGNAL) Pin A12 SECM (SIGNAL) Pin A15 SECM (Sensor GND) Pin B1
191	<b>CamEdgesFault</b> No CAM signal when engine is known to be rotating, broken crankshaft sensor leads or defective CAM sensor	None	Check CAM sensor connections SECM (SIGNAL) Pin B10 to CAM sensor Pin 2 SECM (Sensor GND) Pin B1 to CAM sensor Pin 3 Switched 12V to CAM sensor Pin 1 Check for defective CAM sensor
192	<b>CamSyncFault</b> Loss of synchronization on the CAM sensor, normally due to noise on the signal or an intermittent connection on the CAM sensor	None	Check CAM sensor connections SECM (SIGNAL) Pin B10 to CAM sensor Pin 2 SECM (Sensor GND) Pin B1 to CAM sensor Pin 3 Switched 12V to CAM sensor Pin 1 Check for defective CAM sensor
193	<b>CrankEdgesFault</b> No crankshaft signal when engine is known to be rotating, broken crankshaft sensor leads or defective crank sensor	None	Check Crankshaft sensor connections SECM (SIGNAL) Pin B5 to Crank sensor Pin 3 SECM (Sensor GND) PIN B1 to Crank sensor Pin 2 Switched 12V to Crank sensor Pin 1 Check for defective Crank sensor
194	<b>CrankSyncFault</b> Loss of synchronization on the crankshaft sensor, normally due to noise on the signal or an intermittent connection on the crankshaft sensor	None	Check Crankshaft sensor connections SECM (SIGNAL) Pin B5 to Crank sensor Pin 3 SECM (Sensor GND) Pin B1 to Crank sensor Pin 2 Switched 12V to Crank sensor Pin 1 Check for defective Crank sensor

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. MI-07 Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
221 (22)	<b>TPS1RangeLow</b> TPS1 sensor voltage out of range low, normally set if the TPS1 signal has shorted to ground, circuit has opened or sensor has failed	TurnOnMil	Check throttle connector connection and TPS1 sensor for an open circuit or short to GND SECM Pin B23 (signal) to ETC Pin 6 SECM Pin B1 (sensor GND) to ETC Pin 2 SECM (system GND) Pin A16, B17
222	<b>TPS2RangeLow</b> TPS2 sensor voltage out of range low, normally set if the TPS2 signal has shorted to ground, circuit has opened or sensor has failed	TurnOnMil	Check throttle connector connection and TPS2 sensor for an open circuit or short to GND SECM Pin B4 (signal) to ETC Pin 5 SECM Pin B1 (sensor GND) to ETC Pin 2 SECM (system GND) Pin A16, B17
231 (23)	<b>TPS1RangeHigh</b> TPS1 sensor voltage out of range high, normally set if the TPS1 signal has shorted to power or the ground for the sensor has opened	TurnOnMil	Check throttle connector and TPS1 sensor wiring for a shorted circuit SECM Pin B23 (signal) to ETC Pin 6 SECM Pin B1 (sensor GND) to ETC Pin 2
232	<b>TPS2RangeHigh</b> TPS2 sensor voltage out of range high, normally set if the TPS2 signal has shorted to power or the ground for the sensor has opened	TurnOnMil	Check throttle connector and TPS1 sensor wiring for a shorted circuit SECM Pin B4 (signal) to ETC Pin 5 SECM pin B1 (sensor GND) to ETC Pin 2
241 (24)	<b>TPS1AdaptLoMin</b> Learned closed throttle end of TPS1 sensor range lower than expected	None	Check the throttle connector and pins for corrosion. To check the TPS disconnect the throttle connector and measure the resistance from: TPS Pin 2 (GND) to Pin 6 (TPS1 SIGNAL) (0.7 Ω ± 30%) TPS Pin 3 (PWR) to Pin 6 (TPS1 SIGNAL) (1.4 Ω ± 30%)
242	<b>TPS2AdaptLoMin</b> Learned closed throttle end of TPS2 sensor range lower than expected	None	Check the throttle connector and pins for corrosion. To check the TPS disconnect the throttle connector and measure the resistance from: TPS Pin 2 (GND) to Pin 5 (TPS2 SIGNAL) (1.3K Ω ± 30%) TPS PIN 3 (PWR) to PIN 5 (TPS2 SIGNAL) (0.6K Ω ± 30%)
251 (25)	<b>TPS1AdaptHiMax</b> Learned WOT end of TPS1 sensor range higher than expected	None	N/A
252	<b>TPS2AdaptHiMax</b> Learned WOT end of TPS2 sensor range higher than expected	None	N/A
271	<b>TPS1AdaptHiMin</b> Learned WOT end of TPS1 sensor range lower than expected	None	N/A

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
272	<b>TPS2AdaptHiMin</b> Learned WOT end of TPS2 sensor range lower than expected	None	N/A
281	<b>TPS1AdaptLoMax</b> Learned closed throttle end of TPS1 sensor range higher than expected	None	N/A
282	<b>TPS2AdaptLoMax</b> Learned closed throttle end of TPS2 sensor range higher than expected	None	N/A
291	<b>TPS_Sensors_Conflict</b> TPS sensors differ by more than expected amount <b>NOTE: The TPS is not a serviceable item and can only be repaired by replacing the DV-EV throttle assembly.</b>	(1) TurnOnMil (2) Engine Shutdown	Perform checks for DFCs 241 & 242
331 (33)	<b>MAPTimeRangeLow</b> Manifold Absolute Pressure sensor input is low, normally set if the TMAP pressure signal wire has been disconnected or shorted to ground or the circuit has opened to the SECM	None	Check TMAP connector and MAP signal wiring for an open circuit TMAP Pin 4 to SECM Pin B18 (signal) TMAP Pin 1 to SECM Pin B1 (sensor GND) TMAP Pin 3 to SECM Pin B24 (XDRP +5 Vdc) Check the MAP sensor by disconnecting the TMAP connector and measuring at the sensor: TMAP Pin 1(GND) to Pin 4 (pressure signal KPA) (2.4kΩ - 8.2kΩ) TMAP Pin 3 (power) to Pin 4 (pressure signal KPA) (3.4kΩ - 8.2kΩ)
332	<b>MAPRangeLow</b> Manifold Absolute Pressure sensor input is low, normally set if the TMAP pressure signal wire has been disconnected or shorted to ground or the circuit has opened to the SECM	(1) TurnOnMil (2) CutThrottle	Check TMAP connector and MAP signal wiring for an open circuit TMAP Pin 4 to SECM Pin B18 (signal) TMAP Pin 1 to SECM Pin B1 (sensor GND) TMAP Pin 3 to SECM Pin B24 (XDRP +5 Vdc) Check the MAP sensor by disconnecting the TMAP connector and measuring at the sensor: TMAP Pin 1(GND) to Pin 4 (pressure signal KPA) (2.4kΩ - 8.2kΩ) TMAP Pin 3 (power) to Pin 4 (pressure signal KPA) (3.4kΩ - 8.2kΩ)

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
<b>341</b> (34)	<b>MAPTimeRangeHigh</b> Manifold Absolute Pressure Sensor Input is High, normally set if the TMAP pressure signal wire has become shorted to power, shorted to the IAT signal, the TMAP has failed or the SECM has failed.	None	Check TMAP connector and MAP signal wiring for a shorted circuit TMAP Pin 4 to SECM Pin B18 (signal) TMAP Pin 1 to SECM Pin B1 (sensor GND) TMAP Pin 3 to SECM Pin B24 (XDRP +5 Vdc) Check the MAP sensor by disconnecting the TMAP connector and measuring at the sensor: TMAP Pin 1(GND) to Pin 4 (pressure signal KPA) (2.4kΩ - 8.2kΩ) TMAP Pin 3 (power) to Pin 4 (pressure signal KPA) (3.4kΩ - 8.2kΩ)
<b>342</b>	<b>MAPRangeHigh</b> Manifold Absolute Pressure Sensor Input is High, normally set if the TMAP pressure signal wire has become shorted to power, shorted to the IAT signal, the TMAP has failed or the SECM has failed	(1) TurnOnMil (2) CutThrottle	Check TMAP connector and MAP signal wiring for a shorted circuit TMAP Pin 4 to SECM Pin B18 (signal) TMAP Pin 1 to SECM Pin B1 (sensor GND) TMAP Pin 3 to SECM Pin B24 (XDRP +5 Vdc) Check the MAP sensor by disconnecting the TMAP connector and measuring at the sensor: TMAP Pin 1(GND) to Pin 4 (pressure signal KPA) (2.4kΩ - 8.2kΩ) TMAP Pin 3 (power) to Pin 4 (pressure signal KPA) (3.4kΩ - 8.2kΩ)
<b>351</b>	<b>MAP_IR_HI</b> MAP sensor indicates higher pressure than expected	None	Check for vacuum leaks. Check that TMAP sensor is mounted properly. Possible defective TMAP sensor.
<b>352</b>	<b>MAP_IR_LO</b> MAP sensor indicates lower pressure than expected	None	Possible defective TMAP sensor.
<b>353</b>	<b>MAP_STICKING</b> MAP sensor not changing as expected	None	Check that TMAP sensor is mounted properly. Possible defective TMAP sensor.
<b>371</b> (37)	<b>IATRangeLow</b> Intake Air Temperature Sensor Input is Low normally set if the IAT temperature sensor wire has shorted to chassis ground or the sensor has failed.	TurnOnMil	Check TMAP connector and IAT signal wiring for a shorted circuit TMAP Pin 2 to SECM Pin B12 (signal) TMAP Pin 1 to SECM Pin B1 (sensor GND) To check the IAT sensor of the TMAP disconnect the TMAP connector and measure the IAT resistance Resistance is approx 2400 ohms at room temperature.

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

<b>DFC</b>	<b>PROBABLE FAULT</b>	<b>FAULT ACTION *</b>	<b>CORRECTIVE ACTION FIRST CHECK</b>
<b>381</b> (38)	<b>IATRangeHigh</b> Intake Air Temperature Sensor Input is High normally set if the IAT temperature sensor wire has been disconnected or the circuit has opened to the SECM.	TurnOnMil	Check TMAP connector and IAT signal wiring for a shorted circuit TMAP Pin 2 to SECM Pin B12 (signal) TMAP Pin 1 to SECM Pin B1 (sensor GND) To check the IAT sensor of the TMAP disconnect the TMAP connector and measure the IAT resistance Resistance is approx 2400 ohms at room temperature.
<b>391</b>	<b>IAT_IR_Fault</b> Intake Air Temperature not changing as expected	None	Check connections to TMAP sensor. Check that TMAP sensor is properly mounted to manifold.
<b>421</b>	<b>EST1_Open</b> EST1 output open, possibly open EST1 signal or defective spark module	TurnOnMil	Check coil driver wiring and connector for open circuit SECM Pin A9 (EST1) to OEM ignition system. See application note. Verify GND on ignition module Pin A (of both connectors) Verify +12 Vdc on ignition module Pin B (of both connectors) Refer to application manual for specific engine details.
<b>422</b>	<b>EST2_Open</b> EST2 output open, possibly open EST2 signal or defective spark module	TurnOnMil	Check coil driver wiring and connector for open circuit SECM Pin A10 (EST2) to OEM ignition system. See application note. Verify GND on ignition module Pin A (of both connectors) Verify +12 Vdc on ignition module Pin B (of both connectors) Refer to application manual for specific engine details.
<b>423</b>	<b>EST3_Open</b> EST3 output open, possibly open EST3 signal or defective spark module	TurnOnMil	Check coil driver wiring and connector for open circuit SECM Pin A3 (EST3) to OEM ignition system. See application note. Verify GND on ignition module Pin A (of both connectors) Verify +12 Vdc on ignition module Pin B (of both connectors) Refer to application manual for specific engine details.

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

<b>DFC</b>	<b>PROBABLE FAULT</b>	<b>FAULT ACTION *</b>	<b>CORRECTIVE ACTION FIRST CHECK</b>
<b>424</b>	<b>EST4_Open</b> EST4 output open, possibly open EST4 signal or defective spark module	TurnOnMil	Check coil driver wiring and connector for open circuit SECM Pin A6 (EST4) to OEM ignition system. See application manual. Verify GND on ignition module Pin A (of both connectors) Verify +12 Vdc on ignition module Pin B (of both connectors) Refer to application manual for specific engine details.
<b>425</b>	<b>EST5_Open</b> EST5 output open, possibly open EST5 signal or defective spark module	None	N/A
<b>426</b>	<b>EST6_Open</b> EST6 output open, possibly open EST6 signal or defective spark module	None	N/A
<b>427</b>	<b>EST7_Open</b> EST7 output open, possibly open EST7 signal or defective spark module	None	N/A
<b>428</b>	<b>EST8_Open</b> EST8 output open, possibly open EST8 signal or defective spark module	None	N/A
<b>431</b>	<b>EST1_Short</b> EST1 output shorted high or low, EST1 signal shorted to ground or power or defective spark module	TurnOnMil	Check coil driver wiring and connector for shorts SECM Pin A9 (EST1) to ignition module Pin D (4-pin connector) Verify GND on ignition module Pin A (of both connectors) Verify +12 Vdc on ignition module Pin B (of both connectors) Refer to application manual for specific engine details.

(\*) Fault actions shown are default values specified by the OEM.



**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

<b>DFC</b>	<b>PROBABLE FAULT</b>	<b>FAULT ACTION *</b>	<b>CORRECTIVE ACTION FIRST CHECK</b>
<b>432</b>	<b>EST2_Short</b> EST2 output shorted high or low, EST2 signal shorted to ground or power or defective spark module	TurnOnMil	Check coil driver wiring and connector for shorts SECM Pin A10 (EST2) to ignition module Pin D (4-pin connector) Verify GND on ignition module Pin A (of both connectors) Verify +12 Vdc on ignition module Pin B (of both connectors) Refer to application manual for specific engine details.
<b>433</b>	<b>EST3_Short</b> EST3 output shorted high or low, EST3 signal shorted to ground or power or defective spark module	TurnOnMil	Check coil driver wiring and connector for shorts SECM Pin A3 (EST3) to ignition module Pin D (4-pin connector) Verify GND on ignition module Pin A (of both connectors) Verify +12 Vdc on ignition module Pin B (of both connectors) Refer to application manual for specific engine details.
<b>434</b>	<b>EST4_Short</b> EST4 output shorted high or low, EST4 signal shorted to ground or power or defective spark module	TurnOnMil	Check coil driver wiring and connector for shorts SECM Pin A6 (EST4) to ignition module Pin D (4-pin connector) Verify GND on ignition module Pin A (of both connectors) Verify +12 Vdc on ignition module Pin B (of both connectors) Refer to application manual for specific engine details.
<b>435</b>	<b>EST5_Short</b> EST5 output shorted high or low, EST5 signal shorted to ground or power or defective spark module	None	N/A
<b>436</b>	<b>EST6_Short</b> EST6 output shorted high or low, EST6 signal shorted to ground or power or defective spark module	None	N/A

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
437	<b>EST7_Short</b> EST7 output shorted high or low, EST7 signal shorted to ground or power or defective spark module	None	N/A
438	<b>EST8_Short</b> EST8 output shorted high or low, EST8 signal shorted to ground or power or defective spark module	None	N/A
461 (26)	<b>ETC_Sticking</b> Electronic Throttle Control is sticking. This can occur if the throttle plate (butterfly valve) inside the throttle bore is sticking. The plate sticking can be due to some type of obstruction, a loose throttle plate, or worn components shaft bearings. <b>NOTE: The throttle assembly is not a serviceable item and can only be repaired by replacing the DV-EV throttle assembly.</b>	(1) TurnOnMil (2) EngineShutdown (3) CutThrottle	Check for debris or obstructions inside the throttle body Perform the throttle test using the Service Tool and re-check for fault • Check throttle-plate shaft for bearing wear • Check the ETC driver wiring for an open circuit SECM Pin A17 to ETC + Pin 1 SECM Pin A18 to ETC - Pin 4 Check the ETC internal motor drive by disconnecting the throttle connector and measuring the motor drive resistance at the throttle TPS Pin 1 (+DRIVER) to Pin 4 (-DRIVER) ~3.0-4.0Ω
471	<b>ETC_Open_Fault</b> Electronic Throttle Control Driver has failed, normally set if either of the ETC driver signals have opened or become disconnected, electronic throttle or SECM is defective.	None	Check the ETC driver wiring for an open circuit SECM Pin A17 to ETC + Pin 1 SECM Pin A18 to ETC - Pin 4 Check the ETC internal motor drive by disconnecting the throttle connector and measuring the motor drive resistance at the throttle TPS Pin 1 (+DRIVER) to Pin 4 (-DRIVER) ~3.0-4.0Ω
481 (28)	<b>ETCSpringTest</b> Electronic Throttle Control Spring Return Test has failed. The SECM will perform a safety test of the throttle return spring following engine shutdown. If this spring has become weak the throttle will fail the test and set the fault. <b>NOTE: The throttle assembly is not a serviceable item and can only be repaired by replacing the DV-EV throttle assembly.</b>	(1) TurnOnMil (2) EngineShutdown	Perform throttle spring test by cycling the ignition key and re-check for fault

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
<b>491</b> (29)	<b>HbridgeFault_ETC</b> Electronic Throttle Control Driver has failed. Indeterminate fault on Hbridge driver for electronic throttle control. Possibly either ETC+ or ETC- driver signals have been shorted to ground	TurnOnMil	Check ETC driver wiring for a shorted circuit SECM Pin A17 to ETC + Pin 1 SECM Pin A18 to ETC - Pin 4 • Perform the throttle test using the Service Tool and re-check for fault Check the ETC internal motor drive by disconnecting the throttle connector and measuring the motor drive resistance at the throttle TPS Pin 1 (+DRIVER) to Pin 4 (-DRIVER) ~3.0-4.0Ω
<b>521</b> (52)	<b>LowOilPressureFault</b> Low engine oil pressure	(1) TurnOnMil (2) DelayedEngine Shutdown (3) CheckEngine Light	Check engine oil level Check electrical connection to the oil pressure switch SECM Pin B9 to Oil Pressure Switch
<b>531</b> (53)	<b>SysVoltRangeLow</b> System voltage too low	TurnOnMil	Check battery voltage • Perform maintenance check on electrical connections to the battery and chassis ground • Check battery voltage during starting and with the engine running to verify charging system and alternator function • Measure battery power at SECM with a multimeter (with key on) SECM Pin A23 (DRVP) to SECM Pin A16 (DRVG) SECM Pin A23 (DRVP) to SECM Pin B17 (DRVG)
<b>541</b> (54)	<b>SysVoltRangeHigh</b> System voltage too high	TurnOnMil	Check battery and charging system voltage • Check battery voltage during starting and with the engine running • Check voltage regulator, alternator, and charging system • Check battery and wiring for overheating and damage • Measure battery power at SECM with a multimeter (with key on) SECM Pin A23 (DRVP) to SECM Pin A16 (DRVG) SECM Pin A23 (DRVP) to SECM Pin B17 (DRVG)

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
<b>551</b> (55)	<b>SensVoltRangeLow</b> Sensor reference voltage XDRP too low	(1) TurnOnMil (2) EngineShutdown	Measure transducer power at the TMAP connector with a multimeter TMAP Pin 3 XDRP +5 Vdc to TMAP Pin 1 XDRG GND Verify transducer power at the SECM with a multimeter SECM Pin B24 +5 Vdc to SECM Pin B1 XDRG GND Verify transducer power at ETC with a multimeter ETC Pin 3 XDRP PWR to ETC Pin 2 XDRG GND Verify transducer power to the foot pedal with a multimeter.
<b>561</b> (56)	<b>SensVoltRangeHigh</b> Sensor reference voltage XDRP too high	(1) TurnOnMil (2) EngineShutdown	Measure transducer power at the TMAP connector with a multimeter TMAP Pin 3 XDRP +5 Vdc to TMAP Pin 1 XDRG GND Verify transducer power at the SECM with a multimeter SECM Pin B24 +5 Vdc to SECM Pin B1 XDRG GND Verify transducer power at ETC with a multimeter ETC Pin 3 XDRP PWR to ETC Pin 2 XDRG GND Verify transducer power to the foot pedal with a multimeter.
<b>571</b> (57)	<b>HardOverspeed</b> Engine speed has exceeded the third level (3 of 3) of overspeed protection	(1) TurnOnMil (2) HardRevLimit	Usually associated with additional ETC faults • Check for ETC Sticking or other ETC faults Verify if the lift truck was motored down a steep grade
<b>572</b>	<b>MediumOverspeed</b> Engine speed has exceeded the second level (2 of 3) of overspeed protection	(1) TurnOnMil (2) MediumRevLimit	Usually associated with additional ETC faults • Check for ETC Sticking or other ETC faults Verify if the lift truck was motored down a steep grade
<b>573</b>	<b>SoftOverspeed</b> Engine speed has exceeded the first level (1 of 3) of overspeed protection	(1) TurnOnMil (2) SoftRevLimit	Usually associated with additional ETC faults • Check for ETC Sticking or other ETC faults Verify if the lift truck was motored down a steep grade
<b>611</b> (61)	<b>APP1RangeLow</b> APP1 sensor voltage out of range low, normally set if the APP1 signal has shorted to ground, circuit has opened or sensor has failed	(1) TurnOnMil (2) CheckEngineLight	Check foot pedal connector • Check APP1 signal at SECM PIN B7

(\*) Fault actions shown are default values specified by the OEM.

Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
612 (65)	<b>APP2RangeLow</b> APP2 sensor voltage out of range low, normally set if the APP2 signal has shorted to ground, circuit has opened or sensor has failed	TurnOnMil	Check foot pedal connector • Check APP2 signal at SECM PIN B16
621 (62)	<b>APP1RangeHigh</b> APP1 sensor voltage out of range high, normally set if the APP1 signal has shorted to power or the ground for the sensor has opened	(1) TurnOnMil (2) CheckEngine Light	Check foot pedal connector • Check APP1 signal at SECM PIN B7
622 (66)	<b>APP2RangeHigh</b> APP2 sensor voltage out of range high, normally set if the APP2 signal has shorted to power or the ground for the sensor has opened	TurnOnMil	Check foot pedal connector • Check APP2 signal at SECM PIN B16
631 (63)	<b>APP1AdaptLoMin</b> Learned idle end of APP1 sensor range lower than expected	None	Check APP connector and pins for corrosion • Cycle the pedal several times and check APP1 signal at SECM Pin B7
632 (67)	<b>APP2AdaptLoMin</b> Learned idle end of APP2 sensor range lower than expected	None	Check APP connector and pins for corrosion • Cycle the pedal several times and check APP2 signal at SECM Pin B16
641 (64)	<b>APP1AdaptHiMax</b> Learned full pedal end of APP1 sensor range higher than expected	None	N/A
642 (68)	<b>APP2AdaptHiMax</b> Learned full pedal end of APP2 sensor range higher than expected	None	N/A
651	<b>APP1AdaptHiMin</b> Learned full pedal end of APP1 sensor range lower than expected	None	N/A
652	<b>APP2AdaptHiMin</b> Learned full pedal end of APP2 sensor range lower than expected	None	N/A
661	<b>APP1AdaptLoMax</b> Learned idle end of APP1 sensor range higher than expected	None	N/A
662	<b>APP2AdaptLoMax</b> Learned idle end of APP2 sensor range higher than expected	None	N/A
691 (69)	<b>APP_Sensors_Conflict</b> APP position sensors do not track well, intermittent connections to APP or defective pedal assembly	(1) TurnOnMil (2) Level1PowerLimit	Check APP connector and pins for corrosion • Cycle the pedal several times and check APP1 signal at SECM Pin B7 • Cycle the pedal several times and check APP2 signal at SECM Pin B16

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
711 (71)	<b>LSDFault_Dither1</b> Dither Valve 1 Fault, signal has opened or shorted to ground or power or defective dither 1 valve	TurnOnMil	Check FTV1 for an open wire or FTV connector being disconnected FTV1 Pin 1 (signal) to SECM Pin A1 FTV1 Pin 2 (power) to SECM (DRVP) Pin A23 Check FTV1 for an open coil by disconnecting the FTV connector and measuring the resistance ( $\sim 26\Omega \pm 2\Omega$ )
712	<b>LSDFault_Dither2</b> Dither Valve 2 Fault, signal has opened or shorted to ground or power or defective dither 2 valve	TurnOnMil	Check FTV1 for an open wire or FTV connector being disconnected or signal shorted to GND FTV2 Pin 1 (signal) to SECM Pin A2 FTV2 Pin 2 (power) to SECM (DRVP) Pin A23 Check FTV1 for an open coil by disconnecting the FTV connector and measuring the resistance ( $\sim 26\Omega \pm 2\Omega$ )
714	<b>LSDFault_CheckEngine</b> Check Engine Lamp Fault, signal has opened or shorted to ground or power or defective check engine lamp	None	Check 'Check Engine Lamp' for an open wire or shorted to GND
715	<b>LSDFault_CrankDisable</b> Crank Disable Fault, signal has opened or shorted to ground or power or defective crank disable relay	None	N/A
717	<b>LSDFault_LockOff</b> Fuel lock off Valve Fault, signal has opened or shorted to ground or power or defective Fuel lock off valve	TurnOnMil	Check fuel lock off valve for an open wire or connector being disconnected or signal shorted to GND Lockoff Pin B (signal) to SECM Pin A11 Lockoff Pin A (power) to SECM (DRVP) Pin A23 Check CSV for an open coil by disconnecting the CSV connector and measuring the resistance ( $\sim 26\Omega \pm 3\Omega$ )
718	<b>LSDFault_MIL</b> Malfunction Indicator Lamp Fault, signal has opened or shorted to ground or power or defective MIL lamp	None	Check MIL lamp for an open wire or short to GND.
721 (72)	<b>GasFuelAdaptRangeLo</b> In LPG mode, system had to adapt rich more than expected	TurnOnMil	Check for vacuum leaks. Check dual dither valves, e.g. leaking valve or hose Check for missing orifice(s).

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
<b>731</b> (73)	<b>GasFuelAdaptRangeHi</b> In LPG mode, system had to adapt lean more than expected	TurnOnMil	Check dual dither valves, e.g. plugged valve or hose. Check for plugged orifice(s).
<b>741</b> (74)	<b>GasO2NotActive</b> Pre-catalyst O2 sensor inactive on LPG, open O2 sensor signal or heater leads, defective O2 sensor	(1) TurnOnMil (2) DisableGasO2Ctrl	Check that Pre-catalyst O2 sensor connections are OK. O2 (signal) Pin 3 to SECM Pin B13 O2 Pin 2 (HEATER GND) to SECM (DRVG GNG) Pins A16, B17 O2 Pin 1 (HEATER PWR) to SECM (DRVP + 12V) Pin A23 Verify O2 sensor heater circuit is operating by measuring heater resistance ( $2.1\Omega \pm 0.4\Omega$ ) O2 Pin 2 (HEATER GND) to Pin 1 (HEATER PWR)
<b>742</b>	<b>GasPostO2NotActive</b> Post-catalyst O2 sensor inactive on LPG, open O2 sensor signal or heater leads, defective O2 sensor.	(1) TurnOnMil (2) DisableGasPostO2Ctrl	Check that Post-catalyst O2 sensor connections are OK. O2 (signal) Pin 3 to SECM Pin B19 O2 Pin 2 (HEATER GND) to SECM (DRVG GNG) Pins A16, B17 O2 Pin 1 (HEATER PWR) to Post O2 Heater Relay. Relay pin 87. This relay only turns on after engine has been running for some time and SECM has calculated that water condensation in exhaust has been removed by exhaust heat. Post O2 Heater Relay has SECM (DRVP + 12V) applied to the relay coil power. The relay coil ground is controlled by SECM Pin A20 to activate the relay to flow current through the post O2 heater. Verify O2 sensor heater circuit is operating by measuring heater resistance ( $2.1\Omega \pm 0.4\Omega$ ) O2 Pin 2 (HEATER GND) to Pin 1 (HEATER PWR)
<b>751</b>	<b>GasO2FailedLean</b> Pre-catalyst O2 sensor indicates extended lean operation on LPG	(1) TurnOnMil (2) DisableGasO2Ctrl	Check for vacuum leaks. Check dual dither valves, e.g. leaking valve or hose. Check for missing orifice(s).
<b>752</b>	<b>GasPostO2FailedLean</b> Pre-catalyst O2 sensor indicates extended lean operation on LPG	(1) TurnOnMil (2) DisableGasPostO2Ctrl	Correct other faults that may contribute to 752 (e.g. faults pertaining to dither valves, Pre-Cat O2, Post Cat O2 sensor) Check for vacuum leaks Check for leaks in exhaust, catalytic converter, HEGO sensors; repair leaks. Check all sensor connections (see fault 742 corrective actions).
<b>771</b> (77)	<b>GasO2FailedRich</b> Pre-catalyst O2 sensor indicates extended rich operation on LPG	(1) TurnOnMil (2) DisableGasO2Ctrl	Check dual dither valves, e.g. plugged valve or hose. Check for plugged orifice(s).

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

DFC	PROBABLE FAULT	FAULT ACTION *	CORRECTIVE ACTION FIRST CHECK
772	<b>GasPostO2FailedRich</b> Pre-catalyst O2 sensor indicates extended rich operation on LPG	(1) TurnOnMil (2) DisableGasPostO2Ctrl	Correct other faults that may contribute to 772 (e.g. faults pertaining to FTVs, Pre-Cat O2, Post Cat O2 sensor) Look for leaks in exhaust, catalytic converter, HEGO sensors; repair leaks. Check all sensor connections (see fault 742 corrective actions).
821	<b>LiqFuelAdaptRangeHi</b> In Gasoline mode, system had to adapt lean more than expected	TurnOnMil	Check for vacuum leaks. Low gasoline fuel pressure, perform gasoline pressure test. Injector problems, e.g. plugged, defective injector.
831	<b>LiqFuelAdaptRangeLow</b> In Gasoline mode, system had to adapt rich more than expected	TurnOnMil	Low gasoline fuel pressure, perform gasoline pressure test Injector problems, e.g. leaking, defective injector.
841	<b>LiqO2NotActive</b> Pre-catalyst O2 sensor inactive on gasoline, open O2 sensor signal or heater leads, defective O2 sensor	(1) TurnOnMil (2) DisableLiquidO2Ctrl	Check that Pre-catalyst O2 sensor connections are OK. O2 (signal) Pin 3 to SECM Pin B13 O2 Pin 2 (HEATER GND) to SECM (DRVG GNG) Pins A16, B17 O2 Pin 1 (HEATER PWR) to SECM (DRVP + 12V) PIN A23 Verify O2 sensor heater circuit is operating by measuring heater resistance ( $2.1\Omega \pm 0.4\Omega$ ) O2 Pin 2 (HEATER GND) to Pin 1 (HEATER PWR)
842	<b>LiqPostO2NotActive</b> Post-catalyst O2 sensor inactive on gasoline, open O2 sensor signal or heater leads, defective O2 sensor.	(1) TurnOnMil (2) DisableLiqPostO2Ctrl	Check that Post-catalyst O2 sensor connections are OK. O2 (signal) Pin 3 to SECM Pin B19 O2 Pin 2 (HEATER GND) to SECM (DRVG GNG) Pins A16, B17 O2 Pin 1 (HEATER PWR) to Post O2 Heater Relay. Relay pin 87. This relay only turns on after engine has been running for some time and SECM has calculated that water condensation in exhaust has been removed by exhaust heat. Post O2 Heater Relay has SECM (DRVP + 12V) applied to the relay coil power. The relay coil ground is controlled by SECM Pin A20 to activate the relay to flow current through the post O2 heater. Verify O2 sensor heater circuit is operating by measuring heater resistance ( $2.1\Omega \pm 0.4\Omega$ ) O2 Pin 2 (HEATER GND) to Pin 1 (HEATER PWR)
851	<b>LiqO2FailedLean</b> Pre-catalyst O2 sensor indicates extended lean operation on gasoline	(1) TurnOnMil (2) DisableLiquidO2Ctrl	Check for vacuum leaks. Low gasoline fuel pressure, perform gasoline pressure test. Injector problems, e.g. plugged, defective injector

(\*) Fault actions shown are default values specified by the OEM.



**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**

<b>DFC</b>	<b>PROBABLE FAULT</b>	<b>FAULT ACTION *</b>	<b>CORRECTIVE ACTION FIRST CHECK</b>
<b>852</b>	<b>LiqPostO2FailedLean</b> Pre-catalyst O2 sensor indicates extended lean operation on gasoline	(1) TurnOnMil (2) DisableLiqPost O2Ctrl	Correct other faults that may contribute to 852 (e.g. faults pertaining to Injectors, MAP, IAT, Pre-Cat O2, Post Cat O2 sensor) Look for leaks in exhaust, catalytic converter, HEGO sensors; repair leaks. Check all sensor connections (see fault 842 corrective actions).
<b>871</b>	<b>LiqO2FailedRich</b> Pre-catalyst O2 sensor indicates extended rich operation on gasoline	(1) TurnOnMil (2) DisableLiquid O2Ctrl	High gasoline fuel pressure, perform gasoline pressure test Injector problems, e.g. leaking, defective injector
<b>872</b>	<b>LiqPostO2FailedRich</b> Pre-catalyst O2 sensor indicates extended rich operation on gasoline	(1) TurnOnMil (2) DisableLiq PostO2Ctrl	Correct other faults that may contribute to 872 (e.g. faults pertaining to Injectors, MAP, IAT, Pre-Cat O2, Post Cat O2 sensor) Look for leaks in exhaust, catalytic converter, HEGO sensors; repair leaks. Check all sensor connections (see fault 842 corrective actions).
<b>911</b>	<b>O2RangeLow</b> Pre-catalyst O2 sensor voltage out of range low, sensor signal shorted to ground	(1) TurnOnMil (2) DisableLiquid O2Ctrl (3) DisableGas O2Ctrl	Check if O2 sensor installed before the catalyst is shorted to GND or sensor GND. O2 (signal) Pin 3 to SECM Pin B13 SECM (DRVG GND) Pins A16, B17 SECM (XDRG sensor GND) Pin B1
<b>912</b>	<b>O2_PostCatRangeLow</b> Post-catalyst O2 sensor voltage out of range low, sensor signal shorted to ground	(1) TurnOnMil (2) Disable asoline Post-catalyst O2Ctrl (3) Disable LPG Post-catalyst O2Ctrl	Check if O2 installed after the catalyst sensor is shorted to GND or sensor GND. O2 (signal) Pin 3 to SECM Pin B19 Possible sources: SECM (DRVG GND) Pins A16, B17 and SECM (XDRG sensor GND) Pin B1
<b>921</b>	<b>O2RangeHigh</b> Pre-catalyst O2 sensor voltage out of range high, sensor signal shorted to power	(1) TurnOnMil (2) DisableLiquid O2Ctrl (3) DisableGas O2Ctrl	Check if O2 sensor installed before catalyst is shorted to +5Vdc or battery. O2 (signal) Pin 3 to SECM Pin B13 SECM (XDRP + 5V) Pin B24 SECM (DRVP + 12V) Pin A23
<b>922</b>	<b>O2_PostCatRangeHigh</b> Post-catalyst O2 sensor voltage out of range low, sensor signal shorted to ground	(1) TurnOnMil (2) Disable asoline Post-catalyst O2Ctrl (3) Disable LPG Post-catalyst O2Ctrl	Check if O2 sensor installed after catalyst is shorted to +5Vdc or battery. O2 (signal) Pin 3 to SECM Pin B19 Possible voltage sources: SECM (XDRP + 5V) Pin B24 and SECM (DRVP + 12V) Pin A23
<b>931</b>	<b>FuelTempRangeLow</b> Fuel Temperature Sensor Input is Low normally set if the fuel temperature sensor wire has shorted to chassis ground or the sensor has failed.	TurnOnMil	Check fuel temp sensor connector and wiring for a short to GND SECM (signal) Pin B14 to FTS Pin 1 SECM (sensor GND) Pin B1 to FTS Pin 2 SECM (system GND) Pin A16, B17
<b>932</b>	<b>FuelTempRangeHigh</b> Fuel Temperature Sensor Input is High normally set if the fuel temperature sensor wire has been disconnected or the circuit has opened to the SECM.	TurnOnMil	Check if fuel temp sensor connector is disconnected or for an open FTS circuit SECM (signal) Pin B14 to FTS Pin 1 SECM (sensor GND) Pin B1 to FTS Pin 2

(\*) Fault actions shown are default values specified by the OEM.

**Table 2. Diagnostic Fault Codes (Flash Codes) cont'd.**


<b>DFC</b>	<b>PROBABLE FAULT</b>	<b>FAULT ACTION *</b>	<b>CORRECTIVE ACTION FIRST CHECK</b>
<b>933</b>	<b>TransOilTemp</b> Excessive transmission oil temperature	(1) TurnOnMil (2) DelayedEngine Shutdown	Refer to drivetrain manufacturer's transmission service procedures.
<b>994</b>	<b>ServiceFault4</b> Service Interval 4 has been reached-replace HEGO sensors	TurnOnMil	Replace Pre-catalyst HEGO sensor Replace Post-catalyst HEGO sensor
<b>995</b>	<b>ServiceFault5</b> Service Interval 5 has been reached-replace timing belt	TurnOnMil	Replace engine timing belt

(\*) Fault actions shown are default values specified by the OEM.

# Lift Truck Operation

## Power Shift Transaxle

1. Start the engine. See topic "Starting the Engine."



2. Push down on the service brake pedal to hold the lift truck until ready to move it.
3. Release the parking brake.

**NOTE :** The parking brake must be released before the directional control can be used.



4. Select the direction of travel by pushing the directional lever FORWARD for forward direction or by pulling the lever BACK for reverse direction.

### WARNING

A lift truck with the engine running but without an operator can move slowly (creep) if the transmission is engaged.

This could result in personal injury.

**Always place the transmission control lever in the NEUTRAL (center) position and apply the parking brake before dismounting the lift truck.**

5. Release the service brake.
6. Push down on the accelerator pedal to obtain the desired travel speed. Release the pedal to decrease travel speed.




### WARNING

Sudden reversal of a loaded lift truck traveling forward can cause the load to fall or the lift truck to tip over.

**Stop the loaded lift truck completely, before shifting to reverse.**

**Failure to comply could result in personal injury.**


**NOTE :** Where conditions permit, directional changes can be made under full power at speeds up to 8 km/h (5 mph). A speed of 8 km/h (5 mph) is a fast walk. Directional shift changes at speeds above 8 km/h (5 mph) are considered abusive. Bring the lift truck to a complete stop where load stability or other factors prevent safe operation under full power shifts safe operation under full power shifts.



7. To change the lift truck direction of travel, release the accelerator pedal.
8. Push down on the service brake pedal to reduce the lift truck speed as necessary.




9. Move the directional lever to the desired direction of travel. Slowly push down on the accelerator pedal as the lift truck changes direction.
10. When the direction change is completed, continue to push down on the accelerator pedal to obtain the desired travel speed.



11. To stop the lift truck when traveling in either direction, release the accelerator pedal.
12. Push down on the service brake pedal and bring the lift truck to a smooth stop.

## Inching


**NOTE :** The purpose of the inching pedal is to provide precise lift truck inching control at very slow travel speed and high engine rpm. This is used for fast hydraulic lift, during load approach, pick up or load positioning.




1. To inch (creep) in either direction, slowly push down on the inching pedal. This will start to apply the service brakes and allow the transmission clutch discs to slip.
2. Vary the position of the inching pedal and the accelerator pedal to control the inching speed and distance.
3. Pushing down further on the inching pedal will disengage the transmission completely and apply the service brakes fully to stop and hold the lift truck. This will provide full engine power for fast hydraulic lift.

## Operating Techniques

### Inching into Loads




1. Move the lift truck slowly FORWARD into position and engage the load. The truck should be square with load, forks spaced evenly between pallet stringers and as far apart as load permits.




2. Move the lift truck FORWARD until the load touches the carriage.

### Lifting the Load

1. Lift the load carefully and tilt the mast back a short distance.



2. Tilt the mast further back to cradle the load



3. Operate the lift truck in reverse until the load is clear of the other material.
4. Lower the cradled load to the travel position.

**NOTE :** Lift and tilt speeds are controlled by engine rpm.


## Traveling with the Load

### NOTICE

Travel with the load as low as possible, while still maintaining ground clearance.




1. Travel with the load uphill on upgrades and downgrades.



2. For better vision, travel in reverse with bulky loads.

## Unloading




1. Move the lift truck into the unloading position.



2. Tilt the mast FORWARD only when directly over the unloading area.

### **⚠ WARNING**

**Do not tilt the mast forward with the load unless directly over the unloading area, even if the power is off.**




3. Deposit the load and BACK away carefully to disengage the forks.



4. Lower the carriage and forks to the travel position or to the park position.

## Turning




1. When turning sharp corners, keep close to the inside corner. Begin the turn when the inside drive wheel meets the corner.




2. In narrow aisles, keep away from the stockpile when turning into the aisle. Allow for counterweight swing.

## Lifting Drums or Round Objects



1. Block drums or round objects. Tilt the mast FORWARD and slide the fork tips along the floor to get under the load.



2. Before lifting, tilt the mast BACK slightly until the load is cradled on the forks.

## Operating in Hot Weather

Keep the following points in mind when you operate the lift truck in hot weather.

1. Check the radiator. Clogging can cause the overheating. Clean them out regularly with a blast of compressed air. Also, check the leakage of water.
2. Check the fan belt tension and adjust to proper tension
3. Even if the engine overheats and the coolant boils over, let the engine idle for a while with opening engine hood until temperature falls before shut off the engine.



## Parking the Lift Truck

Park the lift truck level, with the forks lowered and the mast tilted forward until the fork tips touch the floor. Block the drive wheels when parking on an incline.



1. Park in an authorized area only. Do not block traffic. If LP - Gas equipped, do not park near elevator shafts or any other area where LP-Gas could collect in a pocket (low area), causing a potentially dangerous condition.




2. Place the transmission controls in NEUTRAL.
3. Engage the parking brake.
4. Lower the forks to the ground.

### **WARNING**

**Blocking the wheels will prevent unexpected lift truck movement, which could cause personal injury.**



5. Turn the key in the ignition switch to the OFF position and remove the key.



**NOTE :** If an LP- Gas equipped lift truck is stopped or parked for an indefinite or prolonged period of time, shut off the LP-Gas fuel tank valve.

6. Actuate each loading lever several times to remove the residual pressure in the respective cylinders and hoses.
7. Block the drive wheels if parking on an incline.


## Lift Fork Adjustment

**⚠ WARNING**

When adjusting the fork spread, be careful not to pinch your hand between forks and the carriage slot.

---

### Hook-on type Fork



1. Move up the hook pin to the free position.
2. Raise the hook pin in each fork to side the fork on the carriage bar.
3. Adjust the forks in the position most appropriate for the load and as wide as possible for load stability.
4. When adjusting the forks, make sure that the weight of the load is centered on the truck.
5. After adjustment, set the fork locks to keep the forks in place.

**⚠ WARNING**

Make sure the forks are locked before carrying a load.

---

## Storage Information

### Before Storage

Before storing your lift truck, clean and inspect as the following procedures.

- Wipe away grease, oil, etc. adhering to the body of the truck with waste cloth, and use water, if needed.
- While cleaning the truck, check general condition of the truck. Especially check the truck body for recess or damage and tires for wear or nails or stones in the tread.
- Fill the fuel tank with fuel specified.
- Check for leakage of hydraulic oil, engine oil, fuel, or coolant, etc.
- Apply grease, where needed.
- Check for looseness of nuts and bolts, especially hub nuts.
- Check mast rollers to see that they rotate smoothly.
- Prime the oil into the lift cylinders by actuating the lift lever all the way several times.
- Drain off coolant completely in water of cold weather, if antifreeze is not used.

### Long Time Storage

Perform the following service and checks in addition to the "Parking the lift truck" services.

- Taking the rainy season into consideration, park the machine at a higher and hard ground.
  - Avoid parking on soft grounds such as an asphalt ground in summer.
  - Dismount the battery from the machine. Even though the machine is parked indoors, if the place is hot or humid, the battery should be kept in a dry, cool place. Charge the battery once a month.
  - Apply antirust to the exposed parts which tend to rust.
  - Cover components such as the breather and air cleaner which may be caught with humidity.
- Storage Information

- The machine should be operated at least once a week. Fill the cooling system, if cooling water is discharged, and mount the battery. Start the engine and warm up thoroughly. Move the machine a little forwards and backwards. Operate the hydraulic controls several times.

### To Operate the Lift Truck after a Long Time Storage

- Remove covers and antirust from each of the components and exposed parts.
- Drain the engine crankcase, transmission (clutch type machine), differential and final reduction gear, clean the inside of them and add new oil.
- Drain off foreign matter and water from the hydraulic oil tank and fuel tank.
- Remove the head cover from the engine cylinder. Oil valves and rocker shaft and check each valve for proper operation.
- Add cooling water to the specified level.
- Charge the battery and mount it on the machine. Connect the cables.
- Perform pre-operational checks carefully. (refer to "Before Starting the Engine")
- Warm up the machine.

## Transportation Hints

### Lift Truck Shipping

Check travel route for overpass clearances. Make sure there is adequate clearance if the lift truck being transported is equipped with a high mast, overhead guard or cab.

To prevent the lift truck from slipping while loading or shifting in transit, remove ice, snow or other slippery material from the loading dock and the truck bed before loading.

---

#### NOTICE


**Obey all state and local laws governing the weight, width and length of a load.  
Observe all regulations governing wide loads.**

---

#### NOTICE

**Remove ice, snow or other slippery material from the shipping vehicle and the loading dock.**

---



Always block the trailer or the rail car wheels before loading the lift truck. Position the lift truck on the truck bed or the rail car.

Apply the parking brake and place the directional control lever in NEUTRAL.

Turn the ignition switch to the OFF position and remove the key. If LP-Gas equipped, shut off the LP Gas fuel tank.

Block the wheels and secure the lift truck with tiedowns.

## Machine Lifting and Tiedown Information

---

#### NOTICE

**Improper lifting or tiedowns can allow load to shift and cause injury and/or damage.**

---

1. Weight and instructions given herein apply to lift trucks as manufactured by DOOSAN.
2. Use proper rated cables and slings for lifting. Position the crane for level lift truck lift.
3. Spreader bar widths should be sufficient to prevent contact with the lift truck.
4. Use the tiedown locations provided for lift truck tiedown.

Check the state and local laws governing weight, width and length of a load.

Contact your DOOSAN Lift Truck dealer for shipping instructions for your lift truck.

## Towing Information

### **⚠ WARNING**

**Personal injury or death could result when towing a disabled lift truck incorrectly.**

**Block the lift truck wheels to prevent movement before releasing the brakes. The lift truck can roll free if it is not blocked.**

**Follow the recommendations below, to properly perform the towing procedure.**

These towing instructions are for moving a disabled lift truck a short distance, at low speed, no faster than 2 km/h (1.2 mph), to a convenient location for repair. These instructions are for emergencies only. Always haul the lift truck if long distance moving is required.

Shield must be provided on the towing lift truck to protect the operator if the tow line or bar should break.

Do not allow riders on the lift truck being towed unless the operator can control the steering and/or braking.

Before towing, make sure the tow line or bar is in good condition and has enough strength for the towing situation involved. Use a towing line or bar with a strength of at least 1.5 times the gross weight of the towing lift truck for a disabled lift truck stuck in the mud or when towing on a grade.

Keep the tow line angle to a minimum. Do not exceed a 30° angle from the straight ahead position. Connect the tow line as low as possible on the lift truck that is being towed.

Quick lift truck movement could overload the tow line or bar and cause it to break. Gradual and smooth lift truck movement will better.

Normally, the towing lift truck should be as large as the disabled lift truck. Satisfy yourself that the towing lift truck has enough brake capacity, weight and power, to control both lift trucks for the grade and the distance involved.

To provide sufficient control and braking when moving a disabled lift truck downhill, a larger towing lift truck or additional lift trucks connected to the rear could be required. This will prevent uncontrolled rolling. The different situation requirements cannot be given, as minimal towing lift truck capacity is required on smooth level surfaces to maximum on inclines or poor surface conditions. Consult your DOOSAN Lift Truck dealer for towing a disabled lift truck.



1. Release the parking brake.

### **NOTICE**

**Release the parking brake to prevent excessive wear and damage to the parking brake system.**

2. Check that the service brake pedal is released.
3. Key switch is in the OFF position.
4. Direction control lever is in neutral.
5. Fasten the tow bar to the lift truck.
6. Remove the wheel blocks. Tow the lift truck slowly. Do not tow any faster than 2 km/h (1.2 mph).

### **⚠ WARNING**

**Be sure all necessary repairs and adjustments have been made before a lift truck that has been towed to a service area is put back into operation.**

## Inspection, Maintenance and Repair of Lift Truck Forks

The following section gives practical guidelines for inspection, maintenance and repair of lift truck forks. It also provides general information on the design and application of forks and the common cause of fork failures.

Lift truck forks can be dangerously weakened by improper repair or modification. They can also be damaged by the cumulative effects of age, abrasion, corrosion, overloading and misuse.

A fork failure during use can cause damage to the equipment and the load. A fork failure can also cause serious injury.

A good fork inspection and maintenance program along with the proper application can be very effective in preventing sudden failures on the job.

Repairs and modifications should be done only by the fork manufacturer or a qualified technician who knows the material used and the required welding and heat treatment process.

Users should evaluate the economics of returning the forks to the manufacturer for repairs or purchasing new forks. This will vary depending on many factors including the size and type of fork.

Forks should be properly sized to the weight and length of the loads, and to the size of the machine on which they are used. The general practice is to use a fork size such that the combined rated capacity of the number of forks used is equal to or greater than the "Standard(or rated) Capacity" of the lift truck.

The individual load rating, in most cases, will be stamped on the fork in a readily visible area. This is generally on the top or side of the fork shank.

- A fork rated at 1500 pounds at 24 inch load center will be stamped 1500B24.
- A fork rated at 2000 kg at 600 mm load center will be stamped 2000B600.

The manufacturer identification and year and date of manufacture is also usually shown.

Some countries have standards or regulations which apply specifically to the inspection and repair of forks.

Users may also refer to the International Organization For Standardization - ISO Technical Report 5057 - Inspection and Repair of Fork Arms and ISO Standard 2330 - Fork Arms-Technical Characteristics and Testing.

While there are no specific standards or regulations in the United States, users should be familiar with the requirements for inspection and maintenance of lift trucks as provided by the 29 Code Federal Register 1910.178 Power Industrial Truck, and ANSI/ASME Safety Standard(s) B56.1, B56.5 or B56.6 as applicable to the type of machine(s) in use.

### Environment Protection Section

When servicing this lift truck, use an authorized servicing area and an approved container to collect coolant, oil, fuel, grease, electrolyte and any other potential environmental pollutant before any lines, fittings or related items are disconnected or removed.

After servicing, dispose of those materials in an authorized place and container. When cleaning the lift truck, be sure to use an authorized area.

## Causes of Fork Failure

### Improper Modification or Repair

Fork failure can occur as a result of a field modification involving welding, flame cutting or other similar processes which affect the heat treatment and reduces the strength of the fork.

In most cases, specific processes and techniques are also required to achieve proper welding of the particular alloy steels involved. Critical areas most likely to be affected by improper processing are the heel section, the mounting components and the fork tip.

### Bent or Twisted Forks

Forks can be bent out of shape by extreme overloading, glancing blows against walls or other solid objects or using the fork tip as a pry bar.

Bent or twisted forks are much more likely to break and cause damage or injury. They should be removed from service immediately.

### Fatigue

Parts which are subjected to repeated or fluctuating loads can fail after a large number of loading cycles even though the maximum stress was below the static strength of the part.

The first sign of a fatigue failure is usually a crack which starts in an area of high stress concentration. This is usually in the heel section or on the fork mounting.

As the crack progresses under repetitive load cycling, the load bearing cross section of the remaining metal is decreased in size until it becomes insufficient to support the load and complete failure occurs.

Fatigue failure is the most common mode of fork failure. It is also one which can be anticipated and prevented by recognizing the conditions which lead up to the failure and by removing the fork service prior to failing.

- Repetitive Overloading

Repetitive cycling of loads which exceeds the fatigue strength of the material can lead to fatigue failure. The overload could be caused by loads in excess of the rated fork capacity and by use of the forks tips as pry bars. Also, by handling loads in a manner which causes the fork tips to spread and the forks to twist laterally about their mountings.

- Wear

Forks are constantly subjected to abrasion as they slide on floors and loads. The thickness of the fork blade is gradually reduced to the point where it may not be capable of handling the load for which it was designed.

- Stress Risers

Scratches, nicks and corrosion are points of high stress concentration where cracks can develop. These cracks can progress under repetitive loading in a typical mode of fatigue failure.

### Overloading

Extreme overloading can cause permanent bending or immediate failure of the forks. Using forks of less capacity than the load or lift truck when lifting loads and using forks in a manner for which they were not designed are some common causes of overloading.

## Fork Inspection



Establish a daily and 12 month inspection routine by keeping a record for the forks on each lift truck.

Initial information should include the machine serial number on each the forks are used, the fork manufacturer, type, original section size, original length and capacity. Also list any special characteristics specified in the fork design.

Record the date and results of each inspection, making sure the following information is included.

- Actual wear conditions, such as percent of original blade thickness remaining.
- Any damage, failure or deformation which might impair the use of the truck.
- Note any repairs or maintenance.

An ongoing record of this information will help in identifying proper inspection intervals for each operation, in identifying and solving problem areas and in anticipating time for replacement of the forks.

## First Installation

1. Inspect forks to ensure they are the correct size for the truck on which they will be used. Make sure they are the correct length and type for the loads to be handled.

If the forks have been previously used, perform the "12 Month Inspection".

If the forks are rusted, see "Maintenance and Repair".

2. Make sure fork blades are level to each other within acceptable tolerances. See "Forks, Step 4," in the "2000 Service Hours or Yearly" in "Maintenance Intervals"
3. Make sure positioning lock is in place and working. Lock forks in position before using truck. See "Forks, Step 7", in the "2000 Service Hours or Yearly" in "Maintenance Intervals"

## Daily Inspection

1. Visually inspect forks for cracks, especially in the heel section, around the mounting brackets, and all weld areas. Inspect for broken or jagged fork tips, bent or twisted blades and shanks.
2. Make sure positioning lock is in place and working. Lock the forks in position before using the truck. See "2000 Service Hours or Yearly" in "Maintenance Intervals".
3. Remove all defective forks from service.



## 12 Months Inspection

Forks should be inspected, at a minimum, every 12 months. If the truck is being used in a multi-shift or heavy duty operation, they should be checked every six months. See "Forks" in the "2000 Service Hours or Yearly" in "Maintenance Intervals."

## Maintenance and Repair

1. Repair forks only in accordance with the manufacturer's recommendations.

Most repairs or modifications should be done only by the original manufacturer of the forks or an expert knowledgeable of the materials, design, welding and heat treatment process.

2. The following repairs or modifications SHOULD NOT be attempted.
  - Flame cutting holes or cutouts in fork blades.
  - Welding on brackets or new mounting hangers.
  - Repairing cracks or other damage by welding.
  - Bending or resetting.
3. The following repairs MAY be performed.
  - Forks may be sanded or lightly ground, to remove rust, corrosion or minor defects from the surfaces.
  - Heel sections may be ground with a carbon stone to remove minor surface cracks or defects. Polish the inside radius of the heel section to increase the fatigue life of the fork. Always grind or polish in the direction of the blade and shank length.
  - Repair or replace the positioning locks on hook type forks.
  - Repair or replace most fork retention devices used with other fork types.

4. A fork should be load tested before being returned to service on completion of repairs authorized and done in accordance with the manufacturer's recommendations.

Most manufacturers and standards require the repaired fork to be tested with a load 2.5 times the specified capacity and at the load center marked on the fork arm.

With the fork restrained in the same manner as its mounting on the lift truck, apply the test load twice, gradually and without shock. Maintain the test for 30 seconds each time.

Check the fork arm before and after the second application of the test load. It shall not show any permanent deformation.

Consult the fork manufacturer for further information as may be applicable to the specific fork involved.

Testing is not required for repairs to the positioning lock or the markings.

# Torque Specifications

## Metric Hardware

Most of the nuts, bolts, studs, and threaded holes in your lift truck are metric. In this manual we provide specifications in both metric and U.S. customary measurement. Always replace metric hardware with metric hardware. See the parts books for proper replacement.

**NOTE :** For proper fit, use only metric tools on metric hardware. Non-metric tools might slip and cause injury.

## Torque for Standard Hose Clamps - Worm Drive

### NOTICE

The chart below gives the torques for initial installation of hose clamps on new hose and for reassembly or retightening of hose clamps on existing hose.

Clamp Width	Initial Installation Torque On New Hose	
	N•m <sup>1</sup>	lb•in
16 mm (.625 in)	7.5 + 0.5	65 + 5
13.5 mm (.531 in)	4.5 + 0.5	40 + 5
8 mm (.312 in)	0.9 + 0.2	8 + 2
Clamp Width	Reassembly Or Retightening Torque	
	N•m <sup>1</sup>	lb in
16 mm (.625 in)	4.5 + 0.5	40 + 5
13.5 mm (.531 in)	3.0 + 0.5	25 + 5
8 mm (.312 in)	0.7 + 0.2	6 + 2

<sup>1</sup> 1 Newton meter (N•m) is approximately the same as 0.1 kg•m.

## Torque for Standard Bolts, Nuts, and Taperlock Studs

### NOTICE

The two charts below give general torques for bolts, nuts, and taperlock studs of SAE Grade 5 or better quality.

## Torques for Bolts and Nuts With Standard Threads

Thread Size Inch	Standard Nut and Bolt Torque	
	N•m <sup>1</sup>	lb•ft
1/4	12 + 4	9 + 3
5/16	25 + 7	18 + 5
3/8	45 + 7	33 + 5
7/16	70 + 15	50 + 11
1/2	100 + 15	75 + 11
9/16	150 + 20	110 + 15
5/8	200 + 25	150 + 18
3/4	360 + 50	270 + 37
7/8	570 + 80	420 + 60
1	875 + 100	640 + 75
1 1/8	1100 + 150	820 + 110
1 1/4	1350 + 175	1000 + 130
1 3/8	1600 + 200	1180 + 150
1 1/2	2000 + 275	1480 + 200

<sup>1</sup> 1 Newton meter (N•m) is approximately the same as 0.1 kg•m.

## Torques for Taperlock Studs

Thread Size Inch	Standard Taperlock Stud Torque	
	N•m <sup>1</sup>	lb•ft
1/4	8 + 3	6 + 2
5/16	17 + 5	13 + 4
3/8	35 + 5	26 + 4
7/16	45 + 10	33 + 7
1/2	65 + 10	48 + 7
5/8	110 + 20	80 + 15
3/4	170 + 30	125 + 22
7/8	260 + 40	190 + 30
1	400 + 60	300 + 45
1 1/8	500 + 700	370 + 50
1 1/4	650 + 80	480 + 60
1 3/8	750 + 90	550 + 65
1 1/2	870 + 100	640 + 75

<sup>1</sup> 1 Newton meter (N•m) is approximately the same as 0.1 kg•m.

## Torque for Metric Fasteners

### NOTICE

Be very careful never to mix metric with U.S. customary (standard) fasteners. Mismatched or incorrect fasteners will cause lift truck damage or malfunction and may even result in personal injury.

Original fasteners removed from the lift truck should be saved for reassembly whenever possible. If new fasteners are needed, they must be of the same size and grade as the ones that are being replaced.

The material strength identification is usually shown on the bolt head by numbers (8.8, 10.9, etc.). This chart gives standard torques for bolts and nuts with Grade 8.8.

**NOTE :** Metric hardware must be replaced with metric hardware. Check parts book.

Thread Size Metric	Standard Torque	
	N•m <sup>1</sup>	lb•ft
M6	12 + 4	9 + 3
M8	25 + 7	18 + 5
M10	55 + 10	41 + 7
M12	95 + 15	70 + 11
M14	150 + 20	110 + 15
M16	220 + 30	160 + 22
M20	450 + 70	330 + 50
M24	775 + 100	570 + 75
M30	1600 + 200	1180 + 150
M36	2700 + 400	2000 + 300

<sup>1</sup> 1 Newton meter (N•m) is approximately the same as 0.1 kg•m.

<sup>2</sup> ISO - International Standards Organization.

## Cooling System Specifications

### Coolant Information

**NOTE :** The following information is generic and valid for lift trucks.

Engine operating temperatures have increased to improve engine efficiency. This means proper cooling system maintenance is especially important. Overheating, overcooling, pitting, cavitation erosion, cracked heads, piston seizures, and plugged radiators are classic cooling system failures. In fact, coolant is as important as the quality of fuel and lubricating oil.

---

#### NOTICE

**DOOSAN recommends that the coolant mixture contain a minimum of 30% antifreeze or equivalent.**

**Never add coolant to an overheated engine, engine damage can result. Allow the engine to cool first.**

**All water is corrosive at engine operating temperature. The cooling system should be protected with a 3 to 6% concentration of liquid supplemental coolant additive at all times, regardless of the concentration of antifreeze.**

**Excessive supplemental coolant additive greater than the recommended 6%, together with concentration of antifreeze greater than 65% can cause deposits to form and can result in radiator tube blockage, overheating, and/or water pump seal damage.**

**If the machine is to be stored in, or shipped to, an area with freezing temperatures, the cooling system must be protected to the lowest expected outside (ambient) temperature.**

**The engine cooling system is normally protected to  $-28^{\circ}\text{C}$  ( $-20^{\circ}\text{F}$ ) with antifreeze, when shipped from the factory unless special requirements are defined.**

---

Check the specific gravity of the coolant solution frequently in cold weather to ensure adequate protection.

Clean the cooling system if it is contaminated, if the engine overheats or if foaming is observed in the radiator.

Old coolant should be drained, the system cleaned and new coolant added every 2000 service hours or yearly.

Refer to topic, "Cooling System-Clean, Change" in every 2000 service hours or yearly section.

Filling at over 20 liters (5 U.S. gallons) per minute can cause air pockets in the cooling system.

After draining and refilling the cooling system, operate the engine with the radiator cap removed until the coolant reaches normal operating temperature and the coolant level stabilizes. Add coolant as necessary to fill the system to the proper level.

Never operate without a thermostat in the cooling system. Cooling system problems can arise without a thermostat.

## Coolant Water

Hard water, or water with high levels of calcium and magnesium ions, encourages the formation of insoluble chemical compounds by combining with cooling system additives such as silicates and phosphates.

The tendency of silicates and phosphates to precipitate out-of-solution increases with increasing water hardness. Hard water, or water with high levels of calcium and magnesium ions encourages the formation of insoluble chemicals, especially after a number of heating and cooling cycles.

DOOSAN prefers the use of distilled water or deionized water to reduce the potential and severity of chemical insolubility.

MINIMUM ACCEPTABLE WATER	
Water Content	Limits gr/gal(ppm)
Chlorides (Cl)	2.4(40) maximum
Sulfates (SO <sub>4</sub> )	5.9(100) maximum
Total hardness	10(170) maximum
Total solids	20(340) maximum
PH	5.5 to 9.0

ppm = parts per million

Using water that meets the minimum acceptable water requirement may not prevent drop-out of these chemical compounds totally, but should minimize the rate to acceptable levels.

## Antifreeze

### Make proper antifreeze additions.

Adding pure antifreeze as a makeup solution for cooling system top-up is an unacceptable practice. It increases the concentration of antifreeze in the cooling system which increase the concentration of dissolved solids and undissolved chemical inhibitors in the cooling system. Add antifreeze mixed with water to the same freeze protection as your cooling system.

Use the chart below to assist in determining the concentration of antifreeze to use.

Antifreeze Concentrations	
Protection Temperature	Concentration
Protection to -15°C (5°F)	30% antifreeze and 70% water
Protection to -23°C (-10°F)	40% antifreeze and 60% water
Protection to -37°C (-34°F)	50% antifreeze and 50% water
Protection to -51°C (-60°F)	60% antifreeze and 40% water

# Fuel Specifications

## LP-Gas Specifications

LP-Gas is "Liquefied Petroleum Gas". The exact composition of LP-Gas varies slightly between different parts of the country and different refineries. HD5 is recommended for DOOSAN forklift trucks. Remember LP-Gas is heavier than air and will sink to the lowest spot possible. Avoid areas near floor drains or lubrication pits where escaped fuel may collect.

Composition of HD5	
Propane (C <sub>3</sub> H <sub>8</sub> )	90.0 %
Propylene	up to 5 %
Butane (C <sub>4</sub> H <sub>10</sub> )	2.0 %
iso-Butane	1.5 %
Methane (CH <sub>4</sub> )	1.5 %
Total	100 %

# Lubricant Specifications

## Lubricant Information

Certain abbreviations follow Society of Automotive Engineers (SAE) J754 nomenclature and some classifications follow SAE J183 abbreviations.

The MIL specifications are U.S.A. Military Specifications.

The recommended oil viscosities can be found in the Lubricant Viscosities chart in this publication.

Grease is classified by the National Lubricating Grease Institute (NLGI) based on ASTM D217-68 Worked Penetration characteristics which are given a defined consistency number.

## Engine Oil (DEO and EO)

The following oil specifications provide guidelines for the selection of commercial products :

- LP-Gas Engine : API SJ or higher

---

### NOTICE

**Failure to follow the oil recommendations can cause shortened engine life due to carbon deposits or excessive wear.**

---

Consult the EMA Lubricating Oils Data Book for a listing of oil brands.

**NOTE :** The percentage of sulfur in the fuel will affect the engine oil recommendations. For fuel sulfur effects, the Infrared Analysis or the ASTM D2896 procedure can be used to evaluate the residual neutralization properties of an engine oil. The sulfur products formation depends on the fuel sulfur content, oil formulation, crankcase blowby, engine operating conditions and ambient temperature.

## Hydraulic Oil (HYDO)

The following commercial classifications can be used in the hydraulic system.

- |                     |           |
|---------------------|-----------|
| • ISO 6743/4        | HM        |
| • AFNOR NFE 48-603  | HM        |
| • DIN 51524 TEIL 2  | H-LP      |
| • HAGGLUNDS DENISON | HFO-HF2   |
| • CINCINNATI        | P68,69,70 |

Viscosity : ISO VG32

Industrial premium hydraulic oils that have passed the Vickers vane pump test (35VQ25).

These oils should have antiwear, antifoam, antirust and antioxidation additives for heavy duty use as stated by the oil supplier. ISO viscosity grade of 32 would normally be selected.

---

### NOTICE

**Make-up oil added to the hydraulic tanks must mix with the oil already in the systems. Use only petroleum products unless the systems are equipped for use with special products.**

**If the hydraulic oil becomes cloudy, water or air is entering the system. Water or air in the system will cause pump failure. Drain the fluid, retighten all hydraulic suction line clamps, purge and refill the system. Consult your DOOSAN Lift Truck dealer for purging instructions.**

---

## Transmission Oil (TDTO)

---

### NOTICE

**This oil is formulated for transmissions and drive trains only, and should not be used in engines. Shortened engine life will result.**

---

**NOTE :** Multi-grade oils are not blended by DOO-SAN for use in transmissions. Multi-grade oils which use high molecular weight polymers as viscosity index improvers lose their viscosity effectiveness by permanent and temporary shear of the viscosity index improver and therefore, are not recommended for transmission and drive train compartments.

**NOTE :** Failure to follow this recommendation can cause shortened transmission life due to material incompatibility, inadequate frictional requirements for disk materials and/or excessive gear wear.

The API CD/TO - 2 specification or MIL - L 2104D or E oil could be used.

## Drive Axle Oil

**NOTE :** Failure to follow the recommendation will cause shortened life due to excessive gear wear.

### • Shoe Brake

Select oil that meets below specifications.

API GL-5

MIL-L-2105 C, D

Gear Oil offers maximum protection against the scoring and pitting of gear teeth and rolling element bearings.

Gear Oil can also provide excellent stability under high temperature conditions and has superior low temperature performance. It will also give protection against rust and corrosion.

### • Oil Cooled Disc Brake (OCDB)

Select oil that meets below specifications.

The API CD/TO - 2 specification or MIL - L 2104D or E oil could be used.





## Lubricant Viscosities and Refill Capacities

### Lubricant Viscosities

LUBRICANT VISCOSITIES FOR AMBIENT (OUTSIDE) TEMPERATURES						
Compartment or System	Oil Viscosities	°C		°F		
		Min	Max	Min	Max	
Engine Crankcase (LP-Gas)and Lift chains <b>API SH/SG/SJ</b>	SAE 10W30	-20	+40	-4	+104	
	SAE 5W30	-30	+30	-22	+86	
Power Shift Transmission <b>API CD/TO-2</b>	SAE 10W	-20	+22	-4	+72	
	SAE 30	+10	+50	+50	+122	
Hydraulic and Power Steering System <b>ISO 6743/4 HM</b>	ISO VG32	-20	+30	-4	+86	
	ISO VG46	-10	+40	+14	+104	
	ISO VG68	0	+50	+32	+122	
Drive Axle Housing	Shoe Brake <b>API GL-5</b>	SAE 80W90	-20	+50	-4	+122
	Disc Brake (OCDB) <b>API CD/TO-2</b>	SEA 10W	-20	+22	-4	+72
SAE 30		+10	+50	+50	+122	
Brake Reservoir	Shoe Brake <b>DOT3 DOT4</b>	SAE J1703f	-30	+50	-22	+122
	Disc Brake (OCDB) <b>ISO 6743/ 4 HM</b>	ISO VG10	-20	+30	-4	+86

The SAE grade number indicates the viscosity of oil. A proper SAE grade number should be selected according to ambient temperature.

### Refill Capacities

Refill Capacities (Approximate)		
Compartment or System	Liters	U.S. Gal.
Engine Crankcase w/Filter G420E LP-Gas	4.0	1.1
Cooling System w/Coolant Recovery Bottle G420E Gasoline & LP- Gas	9.5	2.5
Fuel Tank LP-Gas-G-Series	15.2Kg	33.5 lb
Power Shift Transmission	10.0	2.7
Hydraulic & Power Steering System	25	6.25
Drive Axle	5.0	1.3
Brake System	1.0	0.26

# Maintenance Intervals

---

## NOTICE

All maintenance and repair, except every 10 service hours or daily, on the lift truck must be performed by qualified and authorized personnel only.

---



---

## NOTICE

Careless disposal of waste oil can harm the environment and can be dangerous to persons. Always dispose of waste oil to an authorized personnel only.

---

### When Required

Operator's Seat, Hood Latch and Support Cylinder - Check, Lubricate.....	107
Fuses & Relay Change .....	107
Tire and Wheels - Inspect, Check .....	108
Test Fuel System for Leaks .....	109
Wheel Bolts - Inspect .....	110
Carriage Roller Extrusion – Adjust .....	110

### Every 10 Service Hours or Daily

Walk-Around Inspection – Inspect.....	111
Inspect Engine for Fluid Leaks .....	112
Engine Oil Level – Check.....	112
Coolant Level - Check.....	112
Air Intake System - Check .....	113
Mast Channels - Lubricate.....	114
Transmission Oil Level - Check.....	114

### First 50-100 Service Hours or a Week

Parking Brake - Test, Adjust.....	115
Transmission Oil & Strainer - Change, Clean ....	115
Drive Axle Oil - Change.....	116

### First 250 Service Hours or a Month

Hydraulic Return Filter - Change.....	118
---------------------------------------	-----

### Every 250 Service Hours or Monthly

Air Intake System - Check, Clean .....	119
Hydraulic Oil Level - Check.....	121

Drive Axle Oil Level - Check.....	121
Mast, Carriage, Lift Chains & Attachments - Inspect, Lubricate.....	122
Steering Mechanism - Check, Lubricate .....	122
Battery Terminal - Clean, Inspect.....	123
Brake Oil Level - Check.....	123
Engine Oil Filter - Change.....	124

### Every 500 Service Hours or 3 Months

Belts - Check, Adjust .....	125
Tilt Cylinders - Check, Adjust, Lubricate .....	125
Mast Hinge Pin - Lubricate.....	126
Crosshead Roller - Inspect.....	126
Inching & Braking Control Shaft - Lubricate.....	127
Horn & Lights (If Equipped) - Check.....	127
Overhead Guard - Inspect.....	127
Inspect Vacuum Lines and Fittings (G420F(E) Engine Only).....	128
Fuel Trim Valve(FTV) Inspection (G420F(E) Engine Only) .....	128
Inspect Electrical System (G420F(E) Engine Only) .....	128

### Every 1000 Service Hours or 6 Months

Hydraulic Return Filter, Breather & Strainer - Check, Change .....	129
Lift Chains - Test, Check, Adjust .....	130
Transmission Oil & Strainer - Clean, Change.....	132
Inspect Coolant Hoses (LP, Dual Fuel Engines Only) .....	133
LP Regulator/Converter Inspection (LP, Dual Fuel Engine Only).....	133
Fuel Lines & Fittings - Check.....	133
Inspect Mixer Assembly (G420F(E) Engine Only) .....	133
Inspect Throttle Assembly (G420F(E) Engine Only) .....	133

### Every 1500 Service Hours or 9 Months

Drive Axle Oil (Shoe Brake) - Change.....	134
Inspect Ignition System (LP-Gas, Gasoline & Dual Fuel Engines Only) .....	134
Replace LP Fuel Filter Element (LP-Gas, Dual Fuel Engine Only).....	134
Fuel Filter (LP - Gas Engine Only) .....	135
Testing Fuel Lock-off Operation (LP-Gas Engine Only) .....	135

### Every 2000 Service Hours or Yearly

Steer Wheel Bearings - Repack .....	136
Cooling System – Clean, Change .....	137
Fork - Inspect .....	139

**Every 2500 Service Hours or 15 Months**

Hydraulic Oil - Change, Check, Clean ..... 141  
Inspect Battery System ..... 142  
Replace Oxygen Sensor (G420F(E) Engine Only)  
..... 142  
Checking the TMAP Sensor (G420F(E) Engine  
Only) ..... 143  
Inspect for Intake Leaks (G420F(E) Engine Only)  
..... 143  
Replace Spark Plugs (G420F(E) Engine Only).. 144

**Every 3000 Service Hours or 18 Months**

Timing Belt - Change..... 145  
Timing Belt for Counterbalance Shaft - Change 145

**Every 4500 Service Hours or two Years**

Replace Oxygen Sensor ..... 145

## When Required

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.

### Operator's Seat, Hood Latch and Support Cylinder - Check, Lubricate



1. Check the operation of the seat adjuster rod. Make sure that the seat slides freely on its track. Lightly oil the seat slider tracks if necessary.



2. Pull the latch to raise the hood and seat assembly. Make certain the support cylinder will hold the hood open.
3. Lightly oil the hood latch mechanism and the rod for the hood support cylinder.

### Fuses & Relay Change

**NOTE :** If a fuse filament separates, use only the same type and size fuses for replacement. If the filament in a new fuse separates, have the circuits and instruments checked.

---

#### NOTICE

**Always replace fuses with ones of the correct ampere rating.**

---

**Fuse** - Protects an electrical circuit from an overload. Opens (filament separates) if an overload occurs.

Check the fuses. Use a flashlight, if necessary.



**Fuses are identified as follows :**

1. Horn - 10 amp.
2. Head Lamp, Clearance Lamp, Tail Lamp. - 15 amp.
3. Lamp Relay Coil, Fwd/Rev Solenoid, Rear Lamp /Alarm - 10 amp
4. Instrument Panel, Hour Meter, Preheat Controller, Fuel Shut-off Solenoid - 15 amp
5. Stop Lamp, Turn Signal Lamp, Strobe Lamp - 15 amp
6. Starter Relay - 10 amp


**Bulbs**

**Bulbs are identified as follows :**

1. Bulb-head lamp halogen (12V-35W)
  - \*2. Bulb-back up (12V-8W)
  - \*3. Bulb-turn signal (12V-23W)
  - \*4. Bulb-stop & tail (12V-23/8W)
- \*OPTIONALLAMP OR LIGHT

**Circuit Breaker**

1. Raise the hood and seat assembly. Make sure the support cylinder securely holds the hood open.



Typical Example

2. The main circuit breaker is located on the rear of the support for the controls.

**NOTE :** To reset circuit breakers push in on the button. The button should stay in if the breaker is reset. If the button will not stay in, or comes out shortly after reset, have the circuits checked.

**Tire and Wheels - Inspect, Check**




1. Inspect the thickness of the tread area. It should be more than 25 mm (1 inch). If the thickness is less than 25 mm (1 inch), the tire must be replaced.

Consult your DOOSAN dealer. Do not try to replace the tire yourself.

2. Inspect the wheels. They should have no cracks or distortion.

## Test Fuel System for Leaks



1. Obtain a leak check squirt bottle or pump spray bottle.
2. Fill the bottle with an approved leak check solution.
3. Spray a generous amount of the solution on the fuel system fuel lines and connections, starting at the storage container.
4. Wait approximately 15-60 seconds then perform a visual inspection of the fuel system. Leaks will cause the solution to bubble.
5. Repair any leaks before continuing.
6. Crank the engine through several revolutions. This will energize the fuel lock-off and allow fuel to flow to the pressure regulator/converter. Apply additional leak check solution to the regulator/converter fuel connections and housing. Repeat leak inspection as listed above.
7. Repair any fuel leaks before continuing.


**⚠ WARNING**

**Prior to any service or maintenance activity,  
Test Fuel System for Leaks**

---

## Wheel Bolts - Inspect


### Inspect Tightness - Drive Wheels



1. Inspect the tightness of the wheel bolts in a sequence opposite each other  $135 + 15 \text{ N}\cdot\text{m}$  (100lb•ft.).

## Carriage Roller Extrusion – Adjust

1. Set the mast vertical.
2. Lower the carriage completely.
3. On full free lift and full free triple lift models, the bottom of the inner mast must be flush with the bottom of the stationary mast.



4. Measure the distance from the bottom of the inner upright to the bottom of carriage bearing.
5. The measurement (A) must be as follows in Chart below.

Height of carriage roller extrusion (A)		
STD mast	FF mast	FFT mast
-6	11	11



## Every 10 Service Hours or Daily

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.

### Walk-Around Inspection – Inspect

For maximum service lift of the lift truck, make a thorough walk-around inspection. Look around and under the truck for such items as loose or missing bolts, debris or dirt buildup, fuel, oil or coolant leaks and cut gouged tires.

Have any repairs made and debris removed, as needed.



1. Inspect the tires and wheels for cuts, gouges, foreign objects, inflation pressure and loose or missing bolts.
2. Inspect the mast and lift chains for wear, broken links, pins and loose rollers.
3. Inspect the hydraulic system for leaks, worn hoses or damaged lines.
4. Look for transmission and differential leaks on the lift truck and on the ground.



5. Inspect the operator's compartment for loose items and cleanliness.
6. Inspect the instrument panel for broken gauges and indicator lights.
7. Test the horn and other safety devices for proper operation.



8. Inspect the cooling system for leaks, worn hoses and debris buildup.
9. Inspect engine compartment for oil, coolant and fuel leaks.
10. Inspect the forks.
  - Visually inspect forks for cracks, especially in the heel section, around the mounting brackets, and all weld areas.
  - Inspect for broken or jagged fork tips, bent or twisted blades and shanks.
  - Make sure positioning lock is in place and working. Lock the forks in position before using the truck. See "Every 2000 Service Hours or Yearly".
  - Remove all defective forks from service.

## Inspect Engine for Fluid Leaks


1. Start the engine and allow it to reach operating temperatures.
2. Turn the engine off.
3. Inspect the entire engine for oil and/or coolant leaks.
4. Repair as necessary before continuing.

## Engine Oil Level – Check

1. Raise the hood and seat assembly.

### WARNING

Hot oil and components can cause personal injury. Do not allow hot oil or components to contact skin.



2. Measure the crankcase oil level. Maintain the level to FULL mark on the dip stick.

## Coolant Level - Check

### WARNING

At operating temperature, the engine coolant is hot and under pressure.

Steam can cause personal injury.

Check the coolant level only after the engine has been stopped and the fill cap is cool enough to touch with your bare hand.

Remove the fill cap slowly to relieve pressure.

Cooling system conditioner contains alkali. Avoid contact with the skin and eyes to prevent personal injury.



1. Observe the coolant level with engine cold. Maintain coolant level to the proper line on expansion bottle. If the expansion bottle has no coolant, it will be necessary to check coolant at the radiator filler neck.
2. Remove the radiator cap. Fill radiator to the top of the filler neck. Inspect radiator cap. Replace if damaged. Install the radiator cap.
3. Start and run the engine to stabilize the coolant level in the filler neck. If low add coolant until it reaches the top of the filler neck. Install the radiator cap. Observe coolant level in the expansion bottle. If necessary, add coolant to bring the coolant to the appropriate line on the expansion bottle.
4. Stop the engine.
5. Inspect the cooling system for leaks, hose cracks or loose connections.

**⚠ WARNING**

**Pressure air can cause personal injury.**

**When using pressure air for cleaning, wear a protective face shield, protective clothing and protective shoes.**

**Maximum air pressure must be less than 205 kPa (30 psi) for cleaning purposes.**

- 
- Blow any dust and lint from the radiator fins.

## Air Intake System - Check

### Checking Service Indicator



- Observe the air cleaner service indicator.
- Service the air cleaner when the RED band in the service indicator, lock in the visible position. See topic, "Air Intake System - Check, Clean" in "Every 250 Service Hours or Monthly".

**NOTE :** Service the element more frequently, as required, in severe dust or lint conditions. Also, service it more frequently where the operator is required to wear a respirator.

- Close hood and seat assembly.

## Inspect Foot Pedal Operation

- Verify foot pedal travel is smooth without sticking.

**⚠ WARNING**

**When the acceleration pedal harness is connected or disconnected, should be worked KEY OFF condition.**

**If not, occurred malfunction, can cause the personal injury.**

## Inspect Engine for Exhaust Leaks

- Start the engine and allow it to reach operating temperatures.
- Perform visual inspection of exhaust system. Repair any/all leaks found.

## Mast Channels - Lubricate



The channels on the roller-type mast require a break-in period. Apply a light film of lubricant on the channels where the rollers ride. This will prevent metal peel until the rollers set a pattern.

## Transmission Oil Level - Check

### Checking Oil Level

#### **WARNING**

**Hot oil and components can cause personal injury. Do not allow hot oil or components to contact skin.**

1. Start and operate the lift truck until the engine reaches normal operating temperature.
2. Park the lift truck level with the forks lowered, parking brake applied and the transmission controls in NEUTRAL.
3. With the service brake applied and the engine at low idle, shift the directional control lever to forward and then to reverse, to fill the clutches.
4. Shift the direction control lever to the NEUTRAL position.
5. Open the floor plate.



6. Remove the dip stick. Observe the oil level.
7. Maintain the oil level between the MIN and MAX marks on the dip stick.

## First 50-100 Service Hours or a Week

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.

### Parking Brake - Test, Adjust

**NOTE :** Be sure area around the lift truck is clear of personnel and obstructions.

#### Test Operation

1. Drive the lift truck, with a capacity load, forward up a 15% incline [a slope that increases 1.5 meters in 10 meters (1.5 ft increase in 10 ft)].



2. Halfway up the incline, stop the lift truck with the service brake.



3. Engage the parking brake. Slowly release the service brake.
4. The parking brake should hold the lift truck. If the lift truck starts to move, immediately apply the service brakes. Have the parking brake adjusted.

### Transmission Oil & Strainer - Change, Clean

#### Power Shift Transaxle(PTA18)


#### WARNING

**Hot oil and components can cause personal injury. Do not allow hot oil or components to contact skin.**

Park the lift truck level, with the forks lowered, parking brake engaged, transmission in NEUTRAL and the engine stopped.

Component is shown removed from the lift truck for illustrative purposes.

1. Remove drain plug (1). Allow the oil to drain. Check O-ring seal and replace if necessary. Remove the strainer.




2. Wash the strainer in clean, nonflammable solvent and dry it. Install the strainer, and the drain plug.
3. Remove the filler cap. Fill the compartment with oil. See "Refill Capacities". Install the dip stick/filler cap.
4. Start the engine.
5. With the service brake applied and engine at low idle, shift the transmission to forward and reverse to fill the clutches.


6. Shift the transmission into NEUTRAL. Engage the parking brake.
7. Remove the dip stick. Observe the oil level.
8. Maintain the oil level between the MIN and MAX marks on the dip stick.
9. Check for oil leaks at the strainer and drain plug.
10. Stop the engine. Install the floor plate.

## Drive Axle Oil - Change

Park the lift truck on a level surface. Apply the parking brake. Place the directional control lever in NEUTRAL.



1. Raise the carriage high enough to access the drain plug and level/fill plug.
2. Block the bottom of the mast with a block of wood to hold the carriage in the raised position.
3. Turn the ignition switch OFF.
4. Place an appropriate container under the axle to catch the oil as it drains. Remove the drain plug and the level/fill plug.



5. Allow the oil to drain completely out. Discard the old oil according to federal, state, and local regulations.
6. Clean and reinstall the drain plug.
7. Add sufficient fresh oil through the level/fill opening until it reaches the bottom of the hole. See the section **Lubricant Viscosities and Refill Capacities** for the type and amount of oil to use.

8. Clean and reinstall the level/fill plug.
9. Remove the wood blocking and lower the carriage.
10. Operate the lift truck for a few minutes and check oil level again. See the topic, "Drive Axle Oil Level - Check" in "Every 250 Service Hours or Monthly" section.

## First 250 Service Hours or a Month

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.

### Hydraulic Return Filter - Change

**⚠ WARNING**

**Hot oil and components can cause personal injury. Do not allow hot oil or component to contact skin.**

---

Park the lift truck level with the forks lowered, parking brake engaged, transmission in NEUTRAL and the engine stopped.



1. Loosen the bolts of the hydraulic tank top plate assembly.
2. Remove the return filter from tank top plate assembly.
3. Change the return filter.
4. Install the tank top plate assembly and fasten the bolts.



## Every 250 Service Hours or Monthly

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.


### Air Intake System - Check, Clean Servicing Filter Element

---

#### NOTICE


**Never service filter with the engine running.**

---



Service the air cleaner when the red target in the service indicator stays locked in the visible position with the engine stopped.

1. To service the air cleaner, raise the hood and seat assembly. Make certain the support cylinder securely holds the hood open. Loosen the cover latches and remove the cover.



2. Rotate the element slightly to separate it from its base and remove it from the air cleaner housing.

3. Clean and inspect the element or replace with a new element. See topic, "Cleaning Primary Filter Element".
4. Clean the inside of air cleaner housing and the cover. Inspect all connections between the air cleaner and carburetor. Check intake hose for cracks, damage necessary to prevent leakage.

---

#### NOTICE

**Do not allow dirty air to enter the intake hose when cleaning the inside of the cleaner housing.**

---

5. Check the air cleaner housing for loose retaining bolts.
6. Reset the air cleaner service indicator.
7. Install the air filter element.
8. Install the cover and tighten the cover latches.
9. Start the engine and observe the position of the indicator. If the indicator shows RED after the installation of the primary element, install another clean or a new element or, replace the secondary element. See topic, "Air Intake System - Change" in Every 1000 Service Hours or 6 months section.
10. Stop the engine and close the hood and seat assembly.

## Cleaning Primary Filter Elements

### WARNING

Pressure air can cause personal injury.

When using pressure air for cleaning, wear a protective face shield, protective clothing and protective shoes.

The maximum air pressure must be below 205 kPa (30 psi) for cleaning purposes.

### NOTICE

Do not clean the elements by bumping or tapping them.

Inspect filter elements after cleaning. Do not use a filter with damaged pleats, gaskets or seals.


When cleaning with pressure air, use 205 kPa (30 psi) maximum pressure to prevent filter element damage.

When cleaning with pressure water, use 280 kPa (40 psi) maximum pressure to prevent filter element damage.

Have spare elements on hand to use while cleaning used elements.

The primary element should be replaced after 6 months service or after cleaning no more than 3 times.

### Air-205 kPa (30 psi) Maximum Pressure



Direct air on the inside and outside of the element along the length of the pleats. Check the element for any tears, rips or damage.

### Checking Element



1. Insert a light inside the clean dry element and examine it. Discard the element if tears, rips or damage are found.
2. Wrap and store good elements in a clean, dry place.

## Hydraulic Oil Level - Check

### WARNING

At operating temperature, the hydraulic tank is hot and under pressure.

Hot oil can cause burns.

Remove the fill cap only when the engine is stopped, and the cap is cool enough to touch with your bare hand. Remove the fill cap slowly to relieve pressure.


1. Operate the lift truck for a few minutes to warm the oil. Park the lift truck on a level surface, with the forks lowered, mast tilted back, parking brake engaged, transmission in NEUTRAL and the engine stopped.
2. Pull the latch and raise the hood and seat assembly. Make sure the air lift cylinder securely holds the hood open.




3. Remove the breather/dip stick. Maintain the oil level to the FULLmark on the breather/dip stick.

## Drive Axle Oil Level - Check

Park the lift truck on a level surface. Apply the parking brake. Place the directional control lever in NEUTRAL.



1. Raise the carriage high enough to access the level/fill plug.
2. Block the bottom of the mast with a block of wood to hold the carriage in the raised position.
3. Turn the ignition switch OFF.



4. Remove the level/fill plug. The oil level should reach the bottom of the hole. Maintain the oil level, to the bottom of the hole.
5. Clean off the level/fill plug and put it back in place.
6. Remove the wood blocking and lower the load backrest.

## Mast, Carriage, Lift Chains & Attachments - Inspect, Lubricate

1. Operate the lift, tilt and attachment controls. Listen for unusual noises. These may indicate a need for repair.
2. Inspect for loose bolts and nuts on the carriage. Remove any debris from the carriage and mast.
3. Inspect the forks and attachments for free operation and damage. Have repairs made if necessary.



4. Brush a film of oil on all links of the chain.
5. Raise and lower the carriage a few times to work lubricant into the chain links.

---

### NOTICE

**Lubricate chains more frequently than normal in applications where the lift truck is operating in a atmosphere which could cause corrosion of components or when lift truck must work in rapid lift cycles.**

---

6. Inspect the chain anchors and individual links for wear, loose pins or cracked leaves.

## Steering Mechanism - Check, Lubricate



1. Lubricate the steer axle king pins, total of four fittings. Two on the right side and two on the left side.
2. Lubricate the steering link bearings, total of four fittings. Two on the right side and two on the left side.
3. Check for any worn or loose components of the steering mechanism. Remove any debris or trash as required.

## Battery Terminal - Clean, Inspect

### WARNING

Batteries give off flammable fumes that can explode.

Do not smoke when observing the battery electrolyte levels.

Electrolyte is an acid and can cause personal injury if it contacts skin or eyes.


Always wear protective glasses when working with batteries.



Typical Example

1. Clean the top of the battery and terminals.
2. Check terminals for corrosion. Coat terminals with heavy grease.

## Brake Oil Level - Check



The brake reservoir is located on the left side of the steering column.


1. Remove the filler cap.
2. Maintain the brake fluid level to the fluid level mark on the brake system reservoir.
3. Clean and install the filler cap.

## Engine Oil Filter - Change


1. Operate lift truck a few minutes to warm oil. Park the lift truck with the forks lowered, parking brake applied, transmission in neutral and the engine stopped.
2. Raise rear of lift truck off ground and block securely.

### WARNING

Hot oil and components can cause personal injury. Do not allow hot oil or components to contact skin.




3. Remove the crankcase drain plug and allow oil to drain. Clean and install drain plug.
4. Raise the hood and seat assembly.



5. Remove and discard oil filter element.
6. Wipe sealing surface of oil filter element mounting base. Make sure all of the old gasket is removed.

7. Before installing a new filter element, apply a small amount of clean engine oil to the filter element gasket.
8. Install the new filter element. When the gasket contacts the base, tighten it 3/4 of a turn more. Do not overtighten.
9. Raise the lift truck, remove the blocking and lower the lift truck.
10. Fill the crankcase. See **Refill Capacities**.
11. Start the engine and allow the oil to fill the filter and passages.
12. Check for oil leaks




13. Stop the engine and measure the oil level. Maintain the oil level to the FULL mark on the dip stick.
14. Close hood and seat assembly.

## Every 500 Service Hours or 3 Months


You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.

### Belts - Check, Adjust



Typical Example

1. Check the condition and adjustment of the belt. Correct adjustment allows 12mm (0.47 inch) deflection under 98N(22lb) of force.



Typical Example

---

#### NOTICE

**Failure to loosen the alternator mounting bolt will cause excessive stress and break the alternator mounting ear.**


---

2. To adjust the alternator drive belt, loosen adjusting bracket bolt and mounting bolt. Move the alternator in or out as required. Tighten bolts.

### Tilt Cylinders - Check, Adjust, Lubricate


#### Chassis Pivot Eyebolts - Lubricate

1. Remove floor plates.



2. Lubricate two fittings for the pivot eyebolts, one on each tilt cylinder.
3. Check the pivot eye pins for loose retainer bolts and wear.


#### Mast Pivot Eyes-Lubricate



1. Lubricate two fittings for the mast pivot eyes, one on each side of the mast.
2. Check the pivot eye pins for loose retainer bolts and wear.


## Cylinder Rod Extension-Adjust

**NOTE :** The following description is for forward tilt. For cylinder rod back tilt, the collar should be stationary by the tilt eye. If it is not, the O-ring inside the collar may need to be replaced. To adjust back tilt, spacers must be added or removed.



1. Check to make sure the tilt cylinders extend and retract evenly.
2. If one cylinder continues to move after the other cylinder has stopped in full forward or backward tilt, an adjustment must be made to one cylinder.
3. To adjust the cylinder rod extension, move the spacer to the rear and loosen the pinch bolt on the clevis.
4. Turn the cylinder rod in or out of the clevis to obtain the proper adjustment. Turning the rod into the clevis shortens the stroke. Turning the rod out of the clevis lengthens the stroke.
5. Tighten the pinch bolts to a torque of  $95 \pm 15$  N•m ( $70 \pm 10$  lb•ft). Check the cylinder rods again for even travel.

## Mast Hinge Pin - Lubricate



1. Lower the forks and tilt the mast forward.
2. Lubricate the two fittings for the mast hinge pins, one on each side of the mast.

## Crosshead Roller - Inspect

1. Operate the mast through a lift cycle. Watch the chains move over the crosshead rollers. Make sure the chain is tracking over the rollers properly.



Typical Example


2. Check for damaged crosshead rollers, guards and retainer rings.



### Parking Brake - Test, Adjust

See topic, "Parking Brake - Test, Adjust" in "First 50-100 Service Hours."

### Inching & Braking Control Shaft - Lubricate



1. Lubricate three fittings for the inching and brake pedal control shaft.

### Drive Axle Oil (OCDB) - Change


See topic, "Drive Axle Oil - Change" in the "First 50 - 100 Service Hours".

### Horn & Lights (If Equipped) - Check



1. Press horn button, to determine if horn is operational.
2. Check and replace all defective gauges.
3. Check all lights such as warning, directional, backup, driving and flood lights for correct operation. Replace all burned out bulbs. Have repairs made if needed.


### Overhead Guard - Inspect



1. Check tightness of overhead guard mounting bolts at 105 N•m (77 lb•ft)(1) & 60 N•m (44 lb•ft)(2).
2. Check overhead guard for bent or cracked sections. Have repairs made if needed.

## Inspect Vacuum Lines and Fittings (G420F(E) Engine Only)

1. Visually inspect vacuum lines and fittings for physical damage such as brittleness, cracks and kinks. Repair/replace as required.
2. Solvent or oil damage may cause vacuum lines to become soft resulting in a collapsed line while the engine is running.
3. If abnormally soft lines are detected, replace as necessary.



(1) Fuel Trim Valve(FTV) (2) Vacuum lines

## Inspect Electrical System (G420F(E) Engine Only)

1. Check for loose, dirty or damaged connectors and wires on the harness including: Fuel lock-off, TMAP sensor, O2 sensor, Electronic throttle, Control Relays, Fuel Trim Valve, Foot Pedal, and crank sensor.
2. Repair and/or replace as necessary.

## Fuel Trim Valve(FTV) Inspection (G420F(E) Engine Only)

1. Visually inspect the Fuel trim valve for abrasions or cracking. Replace as necessary.
2. To ensure the valve is not leaking a blow-by test can be performed.
3. With the engine off, disconnect the electrical connector to the FTV.
4. Disconnect the vacuum lines from the FTV to the pressure regulator/converter, at the converter's tee connection.
5. Lightly blow through the vacuum line connected to the FTV. Air should not pass through the FTV when de-energized. If air leaks past the FTV when de-energized replace the FTV.

## Every 1000 Service Hours or 6 Months

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.

### Hydraulic Return Filter, Breather & Strainer - Check, Change


#### WARNING

Hot oil and components can cause personal injury. Do not allow hot oil or components to contact skin.

Park the lift truck level with the forks lowered, parking brake engaged, transmission in NEUTRAL and the engine stopped.



1. Remove and discard the air breather.
2. Install a new air breather.
3. Loosen the bolts of the hydraulic tank top plate assembly.



4. Remove the return filter from tank top plate assembly.
5. Change the return filter.
6. Remove the suction strainer from the tank.
7. Install a new strainer by hand.
8. Install the tank top plate assembly and fasten the bolt.
9. Start the engine and operate the hydraulic controls, and the steering system, through a few cycles to fill the lines. Look for oil leaks.
10. Stop the engine and check the oil level. With all cylinders retracted, maintain the oil level to the FULL mark on the dip stick/filler cap assembly.

## Lift Chains - Test, Check, Adjust

### Lift Chain Wear Test

Inspect the part of the chain that is normally operated over the cross head roller. When the chain bends over the roller, the movement of the parts against each other causes wear.

Inspect to be sure that chain link pins do not extend outside of the link hole. If any single link pin is extended beyond its connecting corresponding link, it should be suspected of being broken inside of its link hole. Lift chains are required to check for wear about every 1,000 service hours or 6 months.

Chain wear test is a measurement of wear of the chain links and pins. Take the following steps to check chain wear.

1. Lift the mast and carriage enough for getting tension on lift chains.



2. Measure precisely ten links of chain distance at the center of pins in millimeter.
3. Calculate chain wear rate\*.
4. If the chain wear rate is 2% or more, replace the lift chain.

\*Chain wear rate (%)

$$= \left( \frac{\text{Actual measurement} - \text{Pitch}^{**} \times 10}{\text{Pitch}^{**} \times 100} \right) \times 100$$

\*\*Chain Pitch for GC15/18S-5, GC20SC-5  
= 15.88mm(0.63 in)

### Check for Equal Tension



Lift the carriage and the mast high enough for getting tension on lift chains. Check the chains, and make sure the tension is the same. Lift chains are required to check for equal tension about every 1,000 service hours or 6 months.

### WARNING

Personal injury can be caused by sudden movement of the mast and carriage. Keep hands and feet clear of any parts that can move.

### Lift Chain Adjustment



Typical example for carriage equal tension

If the tension is not the same on both chains, take the procedure as follows.


**NOTE :** If carriage height is not correct, make adjustments by following procedures.

### Carriage Chain Adjustment


Make sure that carriage height is correct. If correct, adjust the chain for equal tension. If not, adjust the chain for correct carriage height by adjusting anchor nuts(1),(2).

**NOTE :** See the previous section, “Carriage Roller Extrusion” in “When Required”. for proper height of carriage.

1. Fully lower the carriage and tilt mast forward or lift the carriage and put blocks under the carriage to release the tension from the lift chains.
2. Loosen nut(1) and adjust nut(2) to get proper distance from bottom of inner upright to the bottom of carriage bearing.



Typical example for carriage chain of STD mast




Typical example for carriage chain of FF,FFT mast


3. Make adjustment anchor nut(1),(2) for equal chain tension.

4. Set the mast vertical and raise the carriage and check equal chain tension. If not equal, repeat the same procedure as step 1 through step 3.
5. Put LOCTITE No. 242 Tread lock on the threads of the anchor nuts(1),(2) after the adjustment is completed.

### Mast Chain Adjustment - FF,FFT Mast



Typical example for FF mast



Typical example for FFT mast

Make sure that mast height is correct. If correct, adjust chain for equal tension. If not, adjust mast chain for correct mast height by adjusting anchor nuts(3),(4).

**NOTE :** See the previous section, “Carriage Roller Extrusion” in “When Required”. for proper inner mast height.

1. Lift the inner mast and put blocks under the inner mast to release the tension from the lift chains.
2. Loosen nut(3) and adjust nut(4) to make inner mast rail flush with outer mast rail bottom.

## Maintenance section


3. Make adjustment anchor nuts(3),(4) for equal chain tension.
4. Raise the inner mast and check equal chain tension. If not equal, repeat the same procedure as step 1 through step 3.
5. Put LOCTITE No. 242 tread lock on the threads of the anchor nuts(3),(4) after the adjustment is completed.

### **Transmission Oil & Strainer - Clean, Change**

See topic, "Transmission Oil & Strainer - Clean, Change" in "First 50-100 Service Hours".

## Inspect Coolant Hoses (LP, Dual Fuel Engines Only)

1. Visually inspect coolant hoses and clamps. Remember to check the two coolant lines that connect to the pressure regulator/converter.
2. Replace any hose that shows signs of swelling, cracking, abrasion or deterioration.



- (1) LP Regulator/Converter  
(2) Coolant hose


## LP Regulator/Converter Inspection (LP, Dual Fuel Engine Only)

1. Visually inspect the pressure regulator/converter housing for coolant leaks. Refer to the pressure regulator/converter section of the service manual if maintenance is required.

**NOTE :** For pressure testing and internal inspection of the pressure regulator/converter, refer to the pressure regulator/converter section of the service manual.

## Fuel Lines & Fittings - Check

Visually inspect fuel lines and fittings for physical damage. Replace as required.



- (1) Fuel line  
(2) LP mixer  
(3) Throttle Assembly

## Inspect Mixer Assembly (G420F(E) Engine Only)

Refer to the LP mixer section of the engine service manual for procedures.

## Inspect Throttle Assembly (G420F(E) Engine Only)

1. Visually inspect the throttle assembly motor housing for coking, cracks and missing cover-retaining clips. Repair and/or replace as necessary.

**NOTE :** Refer to the LP mixer and throttle section of the service manual for procedures on removing the mixer and inspecting the throttle plate.

## Every 1500 Service Hours or 9 Months

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.

### Drive Axle Oil (Shoe Brake) - Change

"See topic, "Drive Axle Oil - Change" in "First 50 - 100 Service Hours"

### Inspect Ignition System (LP-Gas, Gasoline & Dual Fuel Engines Only)

1. Disconnect Battery Cables.
2. Remove and inspect the spark plugs. Replace as required.
3. Inspect the ignition coil for cracks and heat deterioration. Visually inspect the coil heat sink fins. If any fins are broken replace as required.


#### G420F(E) Engine



### Replace LP Fuel Filter Element (LP-Gas, Dual Fuel Engine Only)

Park the lift truck in an authorized refueling area with the forks lowered, parking brake applied and the transmission in Neutral.

1. Close the fuel shutoff valve on the LP-Fuel tank. Run the engine until the fuel in the system runs out and the engine stops.
2. Turn off the ignition switch.
3. Scribe a line across the filter housing covers, which will be used for alignment purposes when re-installing the filter cover.




(1) screws

4. Remove the cover retaining screws (1).



## Fuel Filter (LP - Gas Engine Only) Disassembly




1. Check bottom cover O-ring seal (6) for damage. Replace if necessary.
2. Re-assemble the filter assembly aligning the scribe lines on the top and bottom covers.
3. Install the cover retaining screws, tightening the screws in an opposite sequence across the cover.
4. Open the fuel valve by slowly turning the valve counterclockwise.
5. Crank the engine several revolutions to open the fuel lock-off. **DO NOT START THE ENGINE.** Turn the ignition key switch to the off position.
6. Check the filter housing, fuel lines and fittings for leaks. Repair as necessary.

## Testing Fuel Lock-off Operation (LP-Gas Engine Only)

1. Start engine.
2. Locate the electrical connector for the fuel lock
3. Disconnect the electrical connector.
4. The engine should run out of fuel and stop within a short period of time.
5. Turn the ignition key switch off and re-connect the fuel lock-off connector.

**NOTE:** The length of time the engine runs on trapped fuel vapor increases with any increase in distance between the fuel lock-off and the pressure regulator/converter.




- (1) LP fuel lock-off
- (2) Regulator / couverter
- (3) Fuel Trim valve (FTV)


## Every 2000 Service Hours or Yearly

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.

### Steer Wheel Bearings - Repack



1. Raise the steer wheels off the ground. Block the lift truck up with blocking under the frame and steer axle.
2. Remove the hub cap.
3. Straighten the lockwasher tangs.
4. Remove the locknut, lockwasher and flat washer.
5. Remove the outer wheel bearing.
6. Remove the wheel assembly.
11. Install the inner bearing.
12. Install the wheel assembly on the steering knuckle.
13. Install the outer wheel bearing.
14. Install the flat washer, lockwasher and locknut.
15. Tighten the locknut to 135 N•m (100 lb•ft), while turning wheel hub to seat the bearing.
16. Loosen the locknut. Torque the locknut to 50 N•m (37 lb•ft). Bend the lockwasher tang to secure lock-nut.
17. Install the hub cap.
18. Raise the lift truck and remove the blocking. Lower the lift truck to the ground.



7. Examine the seal for damage and wear. Replace the seal, if necessary.
8. Remove the inner bearing.
9. Clean and lubricate the steering knuckle.
10. Repack the inner and outer bearings.

## Cooling System – Clean, Change

### WARNING

At operating temperature, the engine coolant is hot and under pressure.

Steam can cause personal injury.

Check the coolant level only after the engine has been stopped and the filler cap is cool enough to touch with your bare hand.

Remove the filler cap slowly to relieve pressure.

Coolant is included antifreeze for forbidding corrosion. Avoid contact with the skin and eyes to prevent personal injury.


Use all cleaning solution with care.

The Lift truck must be level, the forks lowered, the parking brake engaged, the transmission in NEUTRAL and the engine stopped and cool.

1. Turn the radiator cap slowly to relieve the pressure, and then remove the cap.



2. Remove the drain plug or water hose on engine block.



G420F(E) 2.0L LPG/Gasoline Engine

3. Open the radiator drain valve. Allow the coolant to drain into a suitable container. Drain the recovery bottle.



---

**NOTICE**


Hold the drain port when the radiator drain valve is turned because the tank and the drain port are separated.

---



4. After draining the coolant completely, close the radiator drain valve and the block drain plug, fill the engine and the radiator full with a radiator cleaner, and clean the engine and the radiator.
5. Start and run the engine for 30 minutes.
6. Stop the engine and drain the cleaning solution into a suitable container.
7. Flush the system with clean water, until draining water is clear.
8. Close the drain valve and install the block drain plug. Fill coolant to top of the filler neck.
9. Start and run the engine to stabilize the coolant level. See topic, "Coolant Level – Check" in "Every 10 Service hours or Daily".

## Fork - Inspect




Forks should be inspected, at a minimum, every 12 months. If the truck is being used in a multi-shift or heavy duty operation, they should be checked every six months.


1. Inspect the forks carefully for cracks. Special attention should be given to the heel section (A), all weld areas and mounting brackets (B). Inspect the top and bottom hooks on forks used on hook type carriages and tubes on shaft mounted forks.

Forks with cracks should be removed from service. "Wet Test" magnetic particle inspection is generally preferred due to its sensitivity and the ease of interpreting the results. Portable equipment is usually recommended so it can be moved to the lift truck.

Inspectors should be trained and qualified in accordance with The American Society for Non Destructive Testing, Level II Qualifications.




2. Check the angle between the upper face of the blade and the front face of the shank. The fork should be withdrawn from service if angle (C) exceeds 93 degrees or deviates by more than 3 degrees from an original angle other than 90 degrees, as may be found in some special application forks.



3. Check the straightness of the upper face of blade (D) and the front face of shank (E) with a straight edge.


The fork should be withdrawn from service if the deviation from straightness exceeds 0.5 percent of the length of the blade and/or the height of the shank respectively 5 mm/1000 mm (0.18"/36").



4. Check the difference in height of one fork tip to the other when mounted on the fork carrier. A difference in fork tip height can result in uneven support of the load and cause problems with entering loads.


The maximum recommended difference in fork tip elevation (F) is 6.5 mm (0.25") for pallet forks and 3 mm (0.125") for fully tapered forks. The maximum allowable difference in fork tip elevation between the two or more forks is 3 percent of blade length (L).

Replace one or both forks when the difference in fork tip height exceeds the maximum allowable difference. Contact your local DOOSAN Lift Truck Dealer for further information.



5. Check the fork blade (J) and shank (H) for wear with special attention to the heel (G). The fork should be withdrawn from service if the thickness is reduced to 90 percent or less of the original thickness.

Fork blade length may also be reduced by wear, especially on tapered forks and platens. Remove the forks from service when the blade length is no longer adequate for the intended loads.




6. Check the fork mountings (K) for wear, crushing and other local deformation, which can cause excessive side to side wobble of the forks. Excessive clearance on hook type forks may allow them to fall from the carrier. Forks which show visible signs of such damage should be removed from service.
7. Check the positioning lock and other fork retention devices to make sure they are in place and working.

Hook type forks use a spring loaded pin (M), located in the top hook, to engage notches in the top carriage bar to hold the fork in place.

When adjusting the fork spacing, the forks are prevented from sliding off the end of the carriage by stop blocks. These stop blocks are

at both ends of the carriage and in the path of the bottom fork hook. The load backrest extension may be used in place of the stop blocks in some cases.

Shaft mounted forks may use set collars or spacers on the shaft to either side of the fork. They may also use U bolts, pins, or similar devices which engage the fork through the top structure of the carriage.



8. Check fork markings (N) for legibility. Renew markings as required to retain legibility.
9.
  - a. Lift the mast and operate the tilt control lever, until the top surface of the forks is parallel with the floor. Place two straight bars that are the same width as the carriage, across the forks as shown.
  - b. Measure the distance from the bottom of each end of the two bars to the floor. The forks must be parallel within 3 mm (.12 in) for Full Tapered and Polished (FTP) forks, all other forks 6.4 mm (.25 in), for their complete length.
  - c. Put one fork, one third from the tip, under a fixture that will not move. Then operate the tilt control with caution until the rear of the truck lifts just off the floor. Follow the same procedure with the second fork. Repeat Step a.

## Every 2500 Service Hours or 15 Months

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.


### Hydraulic Oil - Change, Check, Clean

#### WARNING

Hot oil and components can cause personal injury. Do not allow hot oil or components to contact skin.

5. Start the engine and operate the hydraulic controls, and the steering system, through a few cycles to fill the lines. Look for oil leaks.
6. Stop the engine and check the oil level. With all cylinders retracted, maintain the oil level to the FULL mark on the breather/dip stick.

Park the lift truck level with the forks lowered, parking brake engaged, transmission in NEUTRAL and the engine stopped.




1. Remove the hydraulic tank drain plug. Allow the oil to drain. Clean and install the plug.



2. Remove the breather/dip stick.
3. Remove the strainer. Wash the breather and strainer in clean, nonflammable solvent and dry.
4. Install the strainer. Fill the hydraulic tank. See topic **Refill Capacities**. Install the breather/dip stick.



## Inspect Battery System

1. Clean battery outer surfaces with a mixture of baking soda and water.
2. Inspect battery outer surfaces for damage and replace as necessary.
3. Remove battery cable and clean, repair and/or replace as necessary.



## Replace Oxygen Sensor (G420F(E) Engine Only)

### G420F(E) Engine



When indicated by MIL, replace oxygen sensor on the exhaust manifold and oxygen sensor on muffler assembly.

1. Stop engine and wait until the exhaust pipe and exhaust pipe is cooled.
2. Disconnect the electrical connector of oxygen sensor
3. Remove oxygen sensor
4. Assemble new oxygen sensor  
Tightening torque : 45 N•m (32.5 lb•ft)
5. Connect the electrical connector of oxygen sensor

### **WARNING**

**When assembling the filters, check the arrow mark on the filter surface.**

**The arrow mark position is same as fuel flow direction.**




### Checking the TMAP Sensor (G420F(E) Engine Only)

1. Verify that the TMAP sensor (F) is mounted tightly into the manifold adapter (E), with no leakage.
2. If the TMAP is found to be loose, remove the TMAP retaining screw and the TMAP sensor from the manifold adapter.
3. Visually inspect the TMAP O-ring seal for damage. Replace as necessary.
4. Apply a thin coat of an approved silicon lubricant to the TMAP o-ring seal.
5. Re-install the TMAP sensor into the manifold adapter and securely tighten the retaining screw.

### Inspect for Intake Leaks (G420F(E) Engine Only)

1. Visually inspect the intake manifold, throttle assembly (2), and manifold adapters (3), for looseness and leaks. Repair as necessary.

### Replace PCV Valve and breather element (LP-Gas, Gasoline and Dual Fuel Engines) - Change




1. Loosen the hose clamps and remove the PCV valve.
2. Assemble new PCV valve and hose.
3. Tighten the hose clamps

## Replace Spark Plugs (G420F(E) Engine Only)

1. Disconnect Battery Cables.
2. Remove the ignition wiring harness.
3. Remove the ignition coil assy.
4. Remove spark plugs.
5. Gap the new spark plugs to the proper specifications.  
G420F(E) Engine : 0.7 ~ 0.8
6. Apply anti-seize compound to the spark plug threads and install.  
G420F(E) Engine : 25 N•m (18 lb•ft)

**⚠ WARNING**

**DO NOT OVERTIGHTEN THE SPARK PLUGS.**



(1) Ignition wiring harness (2) Ignition Coil Assy (3) Spark plug

## Every 3000 Service Hours or 18 Months

You must read and understand the warnings and instructions contained in the Safety section of this manual, before performing any operation or maintenance procedures.

### Timing Belt - Change


See the “Service Manual” for the procedure and specifications.

### Timing Belt for Counterbalance Shaft - Change

See the “Service Manual” for the procedure and specifications.

## Every 4500 Service Hours or two Years

### Replace Oxygen Sensor



(1) Oxygen Sensor

1. Stop engine and wait until the exhaust pipe and exhaust pipe is cooled.
2. Disconnect the electrical connector of oxygen sensor
3. Remove oxygen sensor
4. Assemble new oxygen sensor  
Tightening torque : 45 N•m (32.5 lb•ft)
5. Connect the electrical connector of oxygen sensor

# Index

## #

12 Months Inspection .....95

## A

Accelerator Pedal .....44  
 Advanced Diagnostics.....63  
 After Starting the Engine.....53  
 Air Intake System - Check ..... 113  
 Air Intake System - Check, Clean ..... 119  
 Antifreeze .....99  
 Attachment Abbreviations (includes Special Forks)  
 .....36  
 Avoiding Lift Truck Tipovers .....22

## B

Basic Troubleshooting(LP).....56  
 Battery Terminal - Clean, Inspect..... 123  
 Before Operating the Lift Truck .....12  
 Before Starting the Engine.....48  
 Before Starting the Lift Truck.....11  
 Before Storage.....89  
 Belts - Check, Adjust..... 125  
 Bent or Twisted Forks .....93  
 Brake Fluid ..... 103  
 Brake Oil Level - Check ..... 123  
 Bulbs..... 108  
 Burn Prevention.....15

## C

Capacity Load (Weight and Load Center) .....23  
 Carriage Roller Extrusion – Adjust ..... 110  
 Causes of Fork Failure.....93  
 Center of Gravity (CG) .....22  
 Changing LP-Gas Tanks.....46  
 Chassis Pivot Eyebolts - Lubricate..... 125  
 Check for Equal Tension..... 130  
 Checking Oil Level..... 114  
 Checking Service Indicator..... 113  
 Checking the TMAP Sensor (G420F(E) Engine  
 Only) ..... 143  
 Circuit Breaker .....41

Circuit Breaker ..... 108  
 Cleaning Primary Filter Elements ..... 120  
 Coolant Information ..... 98  
 Coolant Level - Check ..... 112  
 Coolant Water ..... 99  
 Cooling System – Clean, Change ..... 137  
 Cooling System Specifications..... 98  
 Crosshead Roller - Inspect..... 126  
 Crushing or Cutting Prevention..... 14  
 Cylinder Rod Extension-Adjust..... 126

## D

Daily Inspection..... 94  
 Diesel Engine ..... 51  
 Direction Control Lever..... 43  
 Disassembly..... 135  
 Displaying Fault Codes (DFC) from SECM Memory  
 ..... 63  
 Drive Axle Oil..... 102  
 Drive Axle Oil - Change..... 116  
 Drive Axle Oil (OCDB) - Change ..... 127  
 Drive Axle Oil (Shoe Brake) - Change..... 134  
 Drive Axle Oil Level - Check ..... 121

## E

Electrical Disconnect Switch (If Equipped) ..... 39  
 Electronic Controlled Spark-Ignition Engines ..... 54  
 Engine Compartment..... 41  
 Engine Oil (DEO and EO) ..... 101  
 Engine Oil Filter - Change ..... 124  
 Engine Oil Level – Check..... 112  
 Environment Management..... 3  
 Environment Protection Section ..... 92  
 Every 10 Service Hours or Daily..... 111  
 Every 1000 Service Hours or 6 Months ..... 129  
 Every 1500 Service Hours or 9 Months ..... 134  
 Every 2000 Service Hours or Yearly ..... 136  
 Every 250 Service Hours or Monthly..... 119  
 Every 2500 Service Hours or 15 Months ..... 141  
 Every 3000 Service Hours or 18 Months ..... 145  
 Every 4500 Service Hours or two Years ..... 145  
 Every 500 Service Hours or 3 Months..... 125

**F**

Fasten the Seat Belt.....	20
Fatigue.....	93
Fire or Explosion Prevention.....	15
First 250 Service Hours or a Month .....	118
First 50-100 Service Hours or a Week.....	115
First Installation.....	94
Fluid Penetration.....	14
Foreword .....	2
Fork - Inspect.....	139
Fork Inspection .....	94
Fuel Filter (LP - Gas Engine Only) .....	135
Fuel Lines & Fittings - Check.....	133
Fuel Specifications .....	100
Fuel Trim Valve(FTV) Inspection (G420F(E) Engine Only).....	128
Fuses & Relay Change .....	107

**G**

G420F Engine.....	55
G420FE Engine .....	54
Gasoline Engine .....	50
General Hazard Information .....	10
General Warnings to Operator .....	6

**H**

Hand Placement Warning .....	7
Hook-on type Fork.....	88
Horn & Lights (If Equipped) - Check .....	127
How to Survive in a Tipover.....	29
Hydraulic Oil - Change, Check, Clean .....	141
Hydraulic Oil (HYDO) .....	101
Hydraulic Oil Level - Check.....	121
Hydraulic Return Filter - Change.....	118
Hydraulic Return Filter, Breather & Strainer - Check, Change.....	129

**I**

Identification, Lift Capacity and Attachment Plate.....	35
If Optional Suspension Seat (Weight Adjusting Type) Equipped .....	19
Important Safety Information .....	4
Improper Modification or Repair .....	93
Inching .....	82
Inching & Braking Control Shaft - Lubricate .....	127

Inching into Loads.....	83
Inspect Battery System.....	142
Inspect Coolant Hoses (LP, Dual Fuel Engines Only) .....	133
Inspect Electrical System (G420F(E) Engine Only) .....	128
Inspect Engine for Exhaust Leaks.....	113
Inspect Engine for Fluid Leaks.....	112
Inspect Foot Pedal Operation .....	113
Inspect for Intake Leaks (G420F(E) Engine Only) .....	143
Inspect Ignition System (LP-Gas, Gasoline & Dual Fuel Engines Only) .....	134
Inspect Mixer Assembly (G420F(E) Engine Only) .....	133
Inspect Throttle Assembly (G420F(E) Engine Only) .....	133
Inspect Tightness - Drive Wheels.....	110
Inspect Vacuum Lines and Fittings (G420F(E) Engine Only).....	128
Inspection, Maintenance and Repair of Lift Truck Forks .....	92
Instrument Panel.....	37

**L**

Lift Chain Adjustment .....	130
Lift Chain Wear Test.....	130
Lift Chains - Test, Check, Adjust .....	130
Lift Control .....	44
Lift Fork Adjustment.....	88
Lift Truck Capacity Rating .....	35
Lift Truck Controls.....	43
Lift Truck Operation .....	81
Lift Truck Parking.....	13
Lift Truck Shipping .....	90
Lift Truck Stability.....	22
Lift Truck Stability Base.....	23
Lifting Drums or Round Objects.....	86
Lifting the Load.....	83
Literature Information .....	2
Load Backrest Must Be In Place Warning .....	7
Long Time Storage .....	89
LP Regulator/Converter Inspection (LP, Dual Fuel Engine Only).....	133
LP-Gas Engine.....	51
LP-Gas Specifications .....	100
Lubricant Information.....	101
Lubricant Specifications .....	101

Index Section

Lubricant Viscosities..... 104  
Lubricant Viscosities and Refill Capacities ..... 104  
Lubricating Grease (MPGM)..... 103

**M**

Machine Lifting and Tiedown Information .....90  
Maintenance .....3  
Maintenance and Repair .....95  
Maintenance Information .....14  
Maintenance Intervals ..... 3, 105  
Make proper antifreeze additions.....99  
Mast Abbreviations .....36  
Mast Channels - Lubricate ..... 114  
Mast Hinge Pin - Lubricate..... 126  
Mast Pivot Eyes-Lubricate ..... 125  
Mast, Carriage, Lift Chains & Attachments - Inspect,  
Lubricate..... 122  
Metric Hardware .....96  
Mounting and Dismounting .....11  
Moving Fan Warning .....8

**N**

No Riders Warning .....8  
No Standing On Forks Warning, No Standing Under  
Forks Warning.....7  
Noise and Vibration .....33

**O**

Operating in Hot Weather .....86  
Operating Techniques .....83  
Operating the Lift Truck.....12  
Operation.....2  
Operation Information.....11  
Operator Restraint System (If Equipped)..... 2, 17  
Operator's Seat, Hood Latch and Support Cylinder -  
Check, Lubricate..... 107  
Operator's Station and Monitoring Systems .....37  
Operator's Warning and Identification Plate .....35  
Operator's Warning Plate .....35  
Overhead Guard - Inspect ..... 127  
Overhead Guard Must Be In Place Warning .....8  
Overloading.....93

**P**

Packing brake .....8

Parking Brake - Test, Adjust ..... 115, 127  
Parking Brake Lever ..... 44  
Parking the Lift Truck..... 87  
Power Shift Transaxle ..... 81  
Power Shift Transaxle(PTA18) ..... 115  
Pressure Air..... 14  
Pressure Warning ..... 7  
Prestart Conditions ..... 50

**R**

Reading Diagnostic Fault Codes ..... 63  
Refill Capacities ..... 104  
Refueling ..... 46  
Replace LP Fuel Filter Element (LP-Gas, Dual Fuel  
Engine Only)..... 134  
Replace Oxygen Sensor ..... 145  
Replace Oxygen Sensor (G420F(E) Engine Only)  
..... 142  
Replace PCV Valve and breather element (LP-Gas,  
Gasoline and Dual Fuel Engines) - Change ..... 143  
Replace Spark Plugs (G420F(E) Engine Only) . 144

**S**

Safety..... 2, 5  
Safety Rules ..... 24  
Seat..... 42  
Seat Adjustment..... 18  
Seat Switch System (If Equipped)..... 40  
Serial Number ..... 34  
Serial Number Locations ..... 34  
Service Brake Pedal ..... 44  
Servicing Filter Element ..... 119  
Sideshift Attachment Control (If Equipped)..... 45  
Specifications ..... 31  
Stability and Center of Gravity ..... 22  
Starting a Cold Diesel Engine ..... 51  
Starting a Warm Diesel Engine..... 51  
Starting From a 12 Volt External Source..... 52  
Starting the Engine ..... 50  
Starting the Lift truck..... 12  
Steer Wheel Bearings - Repack ..... 136  
Steering Mechanism - Check, Lubricate ..... 122  
Storage Information ..... 89

**T**

Test Fuel System for Leaks ..... 109

Test Operation .....	115
Testing Fuel Lock-off Operation (LP-Gas Engine Only) .....	135
Tilt Control .....	45
Tilt Cylinders - Check, Adjust, Lubricate .....	125
Tilting Steering Column .....	42
Timing Belt - Change .....	145
Timing Belt for Counterbalance Shaft - Change .....	145
Tire and Wheels - Inspect, Check .....	108
To Operate the Lift Truck after a Long Time Storage .....	89
Torque for Metric Fasteners .....	97
Torque for Standard Bolts, Nuts, and Taperlock Studs .....	96
Torque for Standard Hose Clamps - Worm Drive .....	96
Torque Specifications .....	96
Torques for Bolts and Nuts With Standard Threads .....	96
Torques for Taperlock Studs .....	97
Towing Information .....	91
Training Required To Operate or Service .....	5
Transmission Inching Control Pedal .....	43
Transmission Oil & Strainer - Change, Clean ...	115
Transmission Oil & Strainer - Clean, Change ...	132
Transmission Oil (TDTO) .....	102
Transmission Oil Level - Check .....	114
Transportation Hints .....	90
Traveling with the Load .....	84
Turning .....	85

## U

Unloading .....	84
-----------------	----

## W

Walk-Around Inspection .....	48
Walk-Around Inspection – Inspect .....	111
Warning Signs and Labels .....	5, 17
Wheel Bolts - Inspect .....	110
When Required .....	107