

Operation & Maintenance Manual

PC35R-8 PC45R-8

HYDRAULIC EXCAVATOR

SERIAL NUMBERS PC35R-8 - F20518
PC45R-8 - F20666 and up

This material is proprietary to Komatsu America International Company and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America International Company.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

1.1 FOREWORD

- This manual is provided by Komatsu in order to supply their customers with all the necessary information on the machine and the safety regulations related to it, together with the use and maintenance instructions that enable the operator to exploit the capacity of the machine with optimal results and to keep the machine efficient over time.
- The operation manual, together with the parts book, is an integral part of the machine and must accompany it, even when it is resold, until the machines.
- The manual must be handled with the greatest care and always kept on board the machine, so that it can be consulted at any moment; it must be placed in the appropriate compartment behind the seat, where also the ownership documents and the logbook are usually kept.
- This manual must be given to the persons who use the machine and carry out the routine maintenance operations; they must read the contents carefully more than once, in such a way as to clearly understand what are the correct operating conditions and the dangerous conditions that must be avoided.
In case of loss or damage of this manual, request a new copy to Komatsu or your Komatsu Dealer.
- Komatsu machines are constantly being improved in order to increase their efficiency and reliability; this manual sums up all the information regarding the most recent techniques applied at the moment in which the machine is marketed. For any further or updated information, contact your Komatsu Dealer.
- Punctual periodic annotations regarding the maintenance operations that have been carried out are important to have a clear prospect of the situation and to know exactly what has been done and what has to be done after the next maintenance interval. Therefore, consult the hour meter and the maintenance plan frequently.
- Over the years Komatsu Dealers have gathered considerable experience in customer service.
If more information is needed, do not hesitate to contact your Komatsu Dealer: he always knows how to get the best performance from the machine, he can suggest the use of the equipment that is most suitable for specific needs and can provide the technical assistance necessary for any change that may be required to conform the machine to the safety standards and traffic rules. Furthermore, Komatsu Dealers also ensure their assistance for the supply of Komatsu genuine spare parts, which alone guarantee safety and interchangeability.
- The table included in this manual must be filled in with the machine data, which are the data that must always be indicated to the Dealer when requiring assistance and ordering spare parts.



WARNING

- **Improper operation and maintenance of this machine may be hazardous and cause serious injuries and even death.**
- **Operators and maintenance personnel must carefully read this manual before operating the machine or performing maintenance operations.**
- **Some actions involved in the operation and maintenance of the machine may cause serious injuries or even death, if they are not performed in compliance with the instructions given herein.**
- **The procedures and precautions described in this manual are valid for application to the machine only when it is used correctly. If the machine is used for any purpose or in any way other than those described herein, the operator is risking serious bodily injury or death.**

CALIFORNIA PROPOSITION 65 WARNING

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

CALIFORNIA PROPOSITION 65 WARNING

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

1.2 INFORMATION ON SAFETY

Many accidents are caused by insufficient knowledge of and failure to comply with the safety regulations prescribed for the maintenance and operations of the machine.

In order to avoid accidents, before starting work and before carrying out any maintenance operation, carefully read and be sure to understand all the information and warnings contained in this manual and given on the labels applied onto the machine.

To identify the messages regarding safety that are included in this manual and written on the machine labels, the following words have been used.



DANGER

- This word is used on safety messages and safety labels where there is a high probability of serious injury or death if the hazard is not avoided. These safety messages or labels usually describe precautions that must be taken to avoid the hazard. Failure to avoid this hazard may also result in serious damage to the machine.
-



WARNING

- This word is used on safety messages and safety labels where there is a potentially dangerous situation which could result in serious injury or death if the hazard is not avoided. These safety messages or labels usually describe precautions that must be taken to avoid the hazard. Failure to avoid this hazard may also result in serious damage to the machine.
-



CAUTION

- This word is used on safety messages and safety labels for hazards which could result in minor or moderate injury if the hazard is not avoided. Failure to follow caution may also result in damage to the machine.
-



IMPORTANT

- This word is used when precautions are indicated, which must be taken to avoid actions that may shorten the life of the machine.
-

Komatsu cannot reasonably predict every circumstance that might involve a potential hazard during the operation or maintenance of the machine; for this reason, the safety messages included in this manual and applied onto the machine may not include all possible safety precautions.

If any procedures or actions not specifically recommended or allowed in this manual are used, you must be sure that you and others can do such procedures and actions safely and without damaging the machine. In case of doubt regarding the safety measures necessary for some procedures, contact your local Komatsu dealer.



DANGER

- Before starting any maintenance operation, position the machine on a firm and level surface, lower the equipment to the ground, engage the safety locks of the equipment and of the controls and stop the engine.
-



WARNING

- To make the information clearer, some illustrations in this manual represent the machine without safety guards. Do not use the machine without guards and do not start the engine when the engine protection casing is open, if this is not expressly prescribed for some specific maintenance operations.
-

**WARNING**

- It is strictly forbidden to modify the setting of the hydraulic system safety valves; Komatsu cannot be held liable for any damage to persons, property or the machine, if this has been tampered with by modifying the standard setting of the hydraulic system.
-

**IMPORTANT**

- Before carrying out any electrical welding, disconnect the battery and the alternator (See “2.8.13 PRECAUTIONS CONCERNING THE BATTERY AND THE ALTERNATOR”).
-

**WARNING**

- Install only authorized additional equipment (See “6.1.3 CHARACTERISTICS OF THE OPTIONAL EQUIPMENT”).
-

**WARNING**

- Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual must be kept inside the cab for reference and periodically reviewed by all personnel who will come in contact or be working near the machine.
-

1.3 INTRODUCTION

1.3.1 INTENDED USES

The Komatsu HYDRAULIC EXCAVATOR described in this manual have been designed and constructed to be used mainly for the following functions:

- DIGGING WORKS
- SMOOTHING WORKS
- DITCHING WORKS
- SIDE DITCHING WORKS
- LOADING WORKS

If provided with suitable safety devices, they can be used with authorized optional equipment having the characteristics illustrated at point "6.1 AUTHORIZED OPTIONAL EQUIPMENT".

1.3.2 IMPROPER OR UNAUTHORIZED USES



CAUTION

- **This paragraph describes some of the improper or unauthorized uses of the machine; since it is impossible to predict all the possible improper uses, if the machine happens to be used for particular applications, contact your Komatsu Dealer before carrying out the work.**
-



IMPORTANT

- **The instructions regarding the authorized optional equipment are given in the relevant operation and maintenance manuals; if the equipment is supplied by Komatsu, these publications are enclosed to this manual.**
 - **The instructions regarding the assembly of the authorized equipment, the controls requiring special arrangements on the machine and the hydraulic couplings necessary for the operation of the equipment are grouped in the final section of this manual.**
-

Komatsu MACHINES are constructed exclusively for the handling, excavation and treatment of inert materials; therefore, the following uses are absolutely forbidden:

- USE OF THE MACHINE BY MINORS OR INEXPERIENCED PERSONS.
- USE OF THE MACHINE FOR LIFTING PERSONS OR OBJECTS.
- USE OF THE MACHINE FOR TRANSPORTING PERSONS.
- TRANSPORT OF CONTAINERS WITH FLAMMABLE OR DANGEROUS FLUIDS.
- USE OF THE BUCKET FOR DRIVING OR EXTRACTING PILES.
- USE OF THE MACHINE FOR TOWING DAMAGED VEHICLES.

1.3.3 MAIN CHARACTERISTICS

- Simple and easy operation.
- Hydrostatic transmission obtained through two axial piston motors that operate epicyclic reduction gears.
- Revolving frame swing achieved by means of an axial piston hydraulic motor acting on an epicyclic reduction gear.
- Main equipment servolevers ensuring also combined movements that can be modulated proportionally and continually.
- Pedal controls for the boom swing and the optional equipment.
- Lever controls for travel and blade.
- Travel speed increase achieved through a pedal-operated push button.
- Complete series of instruments visible from the operating position.
- Lever accelerator.
- Easy maintenance with simplified intervals.

1.3.4 RUNNING-IN

Every machine is scrupulously adjusted and tested before delivery.

A new machine, however, must be used carefully for the first 100 hours, in order to ensure proper running-in of the various components.

If the machine is subjected to excessive work load at the beginning of operation, its potential yield and its functionality will be shortly and untimely reduced.

Every new machine must be used carefully, paying special attention to the following indications:

- After the start, let the engine idle for 5 minutes, in such a way as to warm it up gradually before actual operation.
- Avoid operating the machine with the limit loads allowed or at high speed.
- Avoid abrupt starts or accelerations, useless sudden decelerations and abrupt reversals.
- After the first 250 hours, carry out the following operations, in addition to those to be performed every 250 hours:
 - 1 - Change the oil in the travel reduction gears.
 - 2 - Check and adjust the engine valve clearance.



IMPORTANT

- **When changing the oil filters (cartridges), check their inner part to make sure that there are no deposits. If considerable deposits are observed, find out what may have caused them before starting the machine.**
 - **The number of operating hours is indicated by the hour meter.**
-


1.4 PRODUCT IDENTIFICATION

The Komatsu EXCAVATOR and its main components are identified by serial numbers stamped on the identification plates.

The serial number and the identification numbers of the components are the only numbers that must be indicated to the Dealer when requiring assistance and ordering spare parts.



1.4.1 MACHINE SERIAL NUMBER

The machine serial number is stamped on the front upper part of the main frame, on the left side.



1.4.2 MACHINE IDENTIFICATION PLATE



The Komatsu EXCAVATORS described in the present manual are provided with the CE mark, which certifies that they are in compliance with the harmonized standards of the European Community. The plate provided with the mark is applied onto the front wall of the main frame, on the left side.



1.4.3 ENGINE SERIAL NUMBER AND EMISSION LABEL


The engine serial number is stamped on the plate positioned on the top of the engine cylinder head cover.

The emission label is applied on the front of the engine cylinder head cover.




1.4.4 TRAVEL REDUCTION GEAR SERIAL NUMBER

The serial number of the travel reduction gear is stamped on the plate positioned on the outer side of the reduction gear cover.




1.4.5 SWING REDUCTION GEAR SERIAL NUMBER

The serial number is stamped on the plate positioned laterally on the reduction gear body.



1.4.6 CAB SERIAL NUMBER

The CAB serial number is stamped on the plate positioned on the right side of the front base cross member.



1.4.7 SERIAL NUMBERS AND DEALER'S ADDRESS

Machine n. _____ Model _____

Engine n. _____

Travel reduction gear n. _____

Swing reduction gear n. _____

Cab n. _____

Dealer:

Address: _____

_____ Tel. _____

Person to contact: _____

NOTES: _____

TABLE OF CONTENTS

1.1 FOREWORD	1
1.2 INFORMATION ON SAFETY	2
1.3 INTRODUCTION	4
1.3.1 INTENDED USES	4
1.3.2 IMPROPER OR UNAUTHORIZED USES	4
1.3.3 MAIN CHARACTERISTICS	5
1.3.4 RUNNING-IN	5
1.4 PRODUCT IDENTIFICATION	6
1.4.1 MACHINE SERIAL NUMBER	6
1.4.2 MACHINE IDENTIFICATION PLATE	6
1.4.3 ENGINE SERIAL NUMBER	7
1.4.4 TRAVEL REDUCTION GEAR SERIAL NUMBER	7
1.4.5 SWING REDUCTION GEAR SERIAL NUMBER	8
1.4.6 CAB SERIAL NUMBER	8
1.4.7 SERIAL NUMBERS AND DEALER'S ADDRESS	9
SAFETY AND ACCIDENT PREVENTION	
2.1 SAFETY PLATES	18
2.1.1 POSITION OF THE SAFETY PLATES	18
2.1.2 POSITION OF THE PICTOGRAMS	34
2.1.3 PICTOGRAMS AND RELEVANT MEANINGS	36
2.1.4 VIBRATIONS TO WHICH THE OPERATOR IS SUBJECTED	37
2.2 GENERAL PRECAUTIONS	38
2.2.1 GENERAL SAFETY RULES	38
2.2.2 SAFETY DEVICES AND GUARDS	38
2.2.3 CLOTHING AND PERSONAL PROTECTION ITEMS	38
2.2.4 UNAUTHORIZED MODIFICATIONS	39
2.2.5 LEAVING THE OPERATOR'S SEAT	39
2.2.6 GETTING ON AND OFF THE MACHINE	40
2.2.7 PREVENTING FIRES DUE TO FUEL AND OIL	40
2.2.8 PREVENTING BURNS	41
2.2.9 PREVENTING DAMAGE DUE TO ASBESTOS POWDER	41
2.2.10 PREVENTING DAMAGE CAUSED BY THE WORK EQUIPMENT	41
2.2.11 FIRE EXTINGUISHERS AND FIRST AID KIT	42
2.2.12 PRECAUTIONS CONCERNING THE CAB STRUCTURE	42
2.2.13 PRECAUTIONS CONCERNING THE EQUIPMENT	42
2.3 PRECAUTIONS TO BE TAKEN BEFORE STARTING THE ENGINE	43
2.3.1 SAFETY ON THE WORK SITE	43
2.3.2 FIRE PREVENTION	43
2.3.3 PRECAUTIONS TO BE TAKEN FOR THE OPERATOR'S CAB	43
2.3.4 ROOM VENTILATION	44
2.3.5 PRECAUTIONS TO BE TAKEN FOR THE LIGHTS	44
2.3.6 CLEANING THE WINDOWS - CHECKING THE WINDSHIELD WIPER BLADES	44

2.4	PRECAUTIONS TO BE TAKEN WHEN WORKING	45
2.4.1	STARTING THE ENGINE	45
2.4.2	CHECK THE DIRECTION BEFORE STARTING THE MACHINE	45
2.4.3	CHECKS FOR TRAVELLING IN REVERSE	45
2.4.4	MOVING THE MACHINE	46
2.4.5	MOVING ON SLOPES	47
2.4.6	WORKING ON SLOPES	48
2.4.7	UNAUTHORIZED OPERATIONS	48
2.4.8	PREVENTING ELECTROCUTION	49
2.4.9	VISIBILITY	50
2.4.10	WORKING ON ICY OR SNOW-COVERED SURFACES	50
2.4.11	PREVENTING DAMAGE CAUSED BY THE WORK EQUIPMENT	50
2.4.12	WORKING ON LOOSE GROUND	50
2.4.13	PARKING THE MACHINE	51
2.5	TRANSPORTING THE MACHINE ON OTHER VEHICLES	52
2.5.1	LOADING AND UNLOADING	52
2.5.2	TRANSPORT	52
2.6	BATTERY	53
2.6.1	PREVENTING RISKS THAT MAY BE DUE TO THE BATTERY	53
2.6.2	STARTING WITH BOOSTER CABLES	53
2.7	PRECAUTIONS FOR EMERGENCY RECOVERY	54
2.8	PRECAUTIONS TO BE TAKEN DURING MAINTENANCE	55
2.8.1	WARNING PLATES	55
2.8.2	TOOLS	55
2.8.3	PERSONNEL	56
2.8.4	EQUIPMENT	56
2.8.5	WORKING UNDER THE MACHINE	56
2.8.6	CLEANING THE MACHINE	56
2.8.7	USE OF THE ENGINE DURING MAINTENANCE OPERATIONS	57
2.8.8	PERIODICAL CHANGE OF THE PARTS THAT ARE CRITICAL FOR SAFETY	57
2.8.9	STOP THE ENGINE BEFORE CARRYING OUT ANY MAINTENANCE OPERATION OR INSPECTION	57
2.8.10	RULES TO BE FOLLOWED DURING FUEL OR OIL TOPPING UP	58
2.8.11	CHECKING THE COOLANT LEVEL IN THE RADIATOR	58
2.8.12	USING LAMPS	58
2.8.13	PRECAUTIONS CONCERNING THE BATTERY AND THE ALTERNATOR	59
2.8.14	PRECAUTIONS CONCERNING THE STARTER	59
2.8.15	HANDLING HIGH-PRESSURE PIPES	60
2.8.16	PRECAUTIONS TO BE TAKEN WHEN HANDLING HIGH-PRESSURE OIL	60
2.8.17	PRECAUTIONS FOR MAINTENANCE OPERATIONS AT HIGH TEMPERATURES AND HIGH PRESSURE	60
2.8.18	COOLING FAN AND BELT	61
2.8.19	WASTE MATERIALS	61

	Page
DESCRIPTION AND USE OF THE MACHINE	
3.1 SAFETY LOCKS	64
3.1.1 MACHINE LOCKS	64
3.2 GENERAL VIEWS	65
3.2.1 GENERAL VIEW OF THE MACHINE WITH CAB	65
3.2.2 GENERAL VIEW OF THE MACHINE WITH CANOPY	66
3.2.3 GENERAL VIEW OF THE DRIVER'S SEAT	67
3.3 INSTRUMENTS AND CONTROLS	68
3.3.1 INSTRUMENTS, WARNING LIGHTS AND PUSH BUTTONS	68
3.3.2 MACHINE CONTROLS	74
3.4 FUSES AND RELAYS	83
3.4.1 FUSES	83
3.4.1.1 EQUIPMENT FUSES	83
3.4.1.2 MAIN FUSE	84
3.4.2 RELAYS	85
3.5 GUARDS AND DRIVER'S SEAT	86
3.5.1 ENGINE HOOD	86
3.5.2 CANOPY	87
3.5.3 CAB	87
3.5.4 VENTILATION AND HEATING	90
3.5.5 SEAT	90
3.5.6 SAFETY BELT	91
3.5.7 EMERGENCY EXIT	91
3.5.8 TECHNICAL DOCUMENTATION CASE	92
3.5.9 FIRE EXTINGUISHER	92
3.5.10 FIRST AID KIT	92
3.6 USE OF THE MACHINE	93
3.6.1 CHECKS BEFORE STARTING THE ENGINE	93
3.6.1.1 VISUAL CHECKS	93
3.6.1.2 DAILY CHECKS	93
3.6.1.3 OPERATIONAL CHECKS	94
3.6.2 STARTING THE ENGINE	95
3.6.2.1 STARTING WITH WARM ENGINE OR IN TEMPERATE CLIMATES	95
3.6.2.2 STARTING WITH COLD ENGINE OR IN COLD CLIMATES	96
3.6.3 WARMING THE ENGINE	97
3.6.4 HEATING THE HYDRAULIC OIL	97
3.6.5 HOW TO MOVE THE MACHINE	97
3.6.5.1 STEERING (CHANGING DIRECTION)	99
3.6.5.2 MOVING ON SLOPES	100
3.6.5.3 MAXIMUM IMMERSION DEPTH	101
3.7 PARKING THE MACHINE	102
3.7.1 PARKING ON LEVEL GROUND	102
3.7.2 PARKING ON SLOPES	103

3.8	STOPPING THE ENGINE	104
3.9	TRANSPORTING THE MACHINE ON OTHER VEHICLES	105
3.9.1	LOADING AND UNLOADING THE MACHINE	105
3.9.2	TRANSPORT	106
3.10	LIFTING THE MACHINE	107
3.11	PRECAUTIONS TO BE TAKEN IN THE COLD SEASON	108
3.11.1	FUEL AND LUBRICANTS	108
3.11.2	COOLANT	108
3.11.3	BATTERY	108
3.11.4	OTHER PRECAUTIONS	109
3.11.5	PRECAUTIONS TO BE TAKEN AT THE END OF WORK	109
3.12	PRECAUTIONS TO BE TAKEN IN THE WARM SEASON	110
3.13	USING THE WORK EQUIPMENT	111
3.13.1	ORGANIZING THE WORK AREA	111
3.13.2	POSITIONING THE MACHINE FOR DIGGING OPERATIONS	112
3.13.3	DIGGING METHOD	113
3.13.4	CHANGING THE BUCKET	114
3.14	LONG PERIODS OF INACTIVITY	115
3.14.1	BEFORE THE PERIOD OF INACTIVITY	115
3.14.2	DURING THE PERIOD OF INACTIVITY	116
3.14.3	AFTER THE PERIOD OF INACTIVITY	116
3.15	TROUBLESHOOTING	117
3.15.1	OCCURRENCES THAT ARE NOT FAILURES	117
3.15.2	HOW TO REMOVE THE MACHINE	117
3.15.3	AFTER THE FUEL HAS RUN OUT	118
3.15.4	IF THE BATTERY IS DOWN	118
3.15.4.1	STARTING WITH BOOSTER CABLES	119
3.15.5	OTHER TROUBLES	120
3.15.5.1	ELECTRICAL CIRCUIT	120
3.15.5.2	HYDRAULIC SYSTEM	120
3.15.5.3	ENGINE	121

	Page
MAINTENANCE	
4.1 GUIDE TO MAINTENANCE	124
4.2 MAINTENANCE NOTES	126
4.2.1 NOTES REGARDING THE ENGINE	126
4.2.1.1 ENGINE OIL	126
4.2.1.2 COOLANT	126
4.2.1.3 FUEL	127
4.2.2 NOTES REGARDING THE HYDRAULIC SYSTEM	127
4.2.3 NOTES REGARDING THE ELECTRICAL SYSTEM	128
4.2.4 NOTES REGARDING LUBRICATION	128
4.2.5 PARTS SUBJECT TO WEAR THAT PERIODICALLY NEED CHANGING	129
4.3 FUEL, COOLANT AND LUBRICANTS	130
4.4 NUT AND BOLT TIGHTENING TORQUES	134
4.4.1 STANDARD TIGHTENING TORQUES	134
4.4.2 SPECIFIC TIGHTENING TORQUES	134
4.5 LUBRICATION	135
4.5.1 LUBRICATION DIAGRAM	135
4.6 PERIODICAL CHANGE OF THE COMPONENTS THAT ARE CONNECTED WITH SAFETY	136
4.7 MAINTENANCE PLAN	140
4.7.1 WHEN REQUIRED	142
4.7.1.a WASHING THE COOLING CIRCUIT	142
4.7.1.b DRAINING THE FUEL TANK	143
4.7.1.c CHECKING THE ELECTRICAL SYSTEM	143
4.7.1.d CHECKING THE STEEL TRACK TENSION	144
4.7.1.e CHECKING THE RUBBER TRACKS	146
4.7.1.f CHECKING THE RUBBER TRACK TENSION	148
4.7.1.g CHANGING THE RUBBER TRACK	150
4.7.1.h CHECKING, CLEANING OR CHANGING THE AIR CLEANER CARTRIDGE ..	152
4.7.2 MAINTENANCE INTERVALS IN CASE OF USE OF THE DEMOLITION HAMMER (BREAKER)	153
4.7.2.a CHANGING THE HYDRAULIC OIL FILTER	153
4.7.2.b CHANGING THE HYDRAULIC OIL	153
4.7.3 CHECKS BEFORE STARTING	154
4.7.3.a VARIOUS CHECKS	154
4.7.3.b CHECKING THE COOLANT LEVEL	154
4.7.3.c CHECKING THE FUEL LEVEL	155
4.7.3.d CHECKING THE ENGINE OIL LEVEL	155
4.7.3.e CHECKING THE OIL LEVEL IN THE HYDRAULIC CIRCUIT	156
4.7.3.f CHECKING THE AIR CLEANER CLOGGING INDICATOR	157
4.7.3.g CHECKING THE FUEL FILTER FOR SEDIMENT AND WATER	157
4.7.4 MAINTENANCE EVERY 100 HOURS OF OPERATION	158
4.7.4.a LUBRICATING THE JOINTS AND THE BALL-BEARING RING	158

	Page
4.7.5 MAINTENANCE AFTER THE FIRST 250 HOURS OF OPERATION	160
4.7.6 MAINTENANCE EVERY 250 HOURS OF OPERATION	160
4.7.6.a ADJUSTING THE FAN BELT TENSION	160
4.7.6.b CHECKING THE BATTERY ELECTROLYTE LEVEL	161
4.7.6.c CHECKING THE OIL LEVEL IN THE TRAVEL REDUCTION GEARS	161
4.7.6.d CHANGING THE ENGINE OIL	162
4.7.7 MAINTENANCE EVERY 500 HOURS OF OPERATION	163
4.7.7.a CHANGING THE ENGINE OIL FILTER	163
4.7.7.b CHANGING THE FUEL FILTER	164
4.7.7.c CHANGING THE FUEL PUMP PRECLEANER	165
4.7.7.d CLEANING THE OUTSIDE OF THE RADIATORS	166
4.7.7.e CHANGING THE HYDRAULIC SYSTEM OIL FILTER	167
4.7.8 MAINTENANCE EVERY 1000 HOURS OF OPERATION	168
4.7.8.a CHANGING THE OIL IN THE TRAVEL REDUCTION GEARS	168
4.7.9 MAINTENANCE EVERY 2000 HOURS OF OPERATION	169
4.7.9.a CHANGING THE HYDRAULIC SYSTEM OIL AND CLEANING THE SUCTION FILTER	169
4.7.9.b CHANGING THE COOLANT	172
4.7.9.c CHECKING AND ADJUSTING THE ENGINE VALVE CLEARANCE	172
4.7.9.d CHECKING THE ALTERNATOR AND THE STARTER	172

TECHNICAL DATA

5.1 TECHNICAL DATA	174
5.1.1 STANDARD OVERALL DIMENSIONS (for PC35R only)	174
5.1.2 TECHNICAL CHARACTERISTICS PC35R	176
5.1.3 STANDARD OVERALL DIMENSIONS (for PC45R only)	177
5.1.4 TECHNICAL CHARACTERISTICS PC45R	179
5.1.5 LIFTING CAPACITY WITH CAB (for PC35R only)	180
5.1.6 LIFTING CAPACITY WITH CANOPY (for PC35R only)	181
5.1.7 LIFTING CAPACITY WITH CAB (for PC45R only)	182
5.1.8 LIFTING CAPACITY WITH CANOPY (for PC45R only)	183

	Page
AUTHORIZED OPTIONAL EQUIPMENT	
6.1 AUTHORIZED OPTIONAL EQUIPMENT	186
6.1.1 PRECAUTIONS REGARDING SAFETY	186
6.1.2 PRECAUTIONS REGARDING THE INSTALLATION OF EQUIPMENT	187
6.1.3 CHARACTERISTICS OF THE OPTIONAL EQUIPMENT	188
6.2 ARRANGEMENT FOR THE INSTALLATION OF THE DEMOLITION HAMMER (BREAKER)	189
6.2.1 DESCRIPTION AND CONTROL	189
6.2.2 USE OF THE DEMOLITION HAMMER AND RULES TO BE OBSERVED	189
6.2.3 INSTALLING AND REMOVING THE DEMOLITION HAMMER	193
6.2.3.1 INSTALLING THE HAMMER	193
6.2.3.2 REMOVING THE HAMMER	194
6.2.4 MAINTENANCE	194
6.3 ARRANGEMENT FOR THE OPERATION OF OPTIONAL EQUIPMENT	195
6.3.1 SELECTION VALVE (1)	195
6.3.2 CONTROL PEDAL (2)	196
6.3.3 ASSEMBLYING AND CONNECTING THE EQUIPMENT	197
6.3.4 MAINTENANCE	198


SAFETY AND ACCIDENT PREVENTION

2.1 SAFETY PLATES

2.1.1 POSITION OF THE SAFETY PLATES


- The safety plates must always be legible and in good conditions; for this reason, if they are dirty with dust, oil or grease, it is necessary to clean them with a solution made of water and detergent. Do not use fuel, petrol or solvents.
- If the plates are damaged, they must be replaced before operation of the product is resumed. Contact your Komatsu Dealer for replacement labels.
- In case of replacement of a component provided with a safety plate, make sure that this plate is applied also on the replaced component.
- The machine can be provided with other plates in addition to those indicated below; which must be followed for safe operation.

MACHINE WITH CAB



RWA33180

MACHINE WITH CANOPY



RWA33190

SAFETY PLATES

1.

- Warning Decal.

WARNING

Improper operation and maintenance can cause serious injury or death.

Read manual and labels before operation and maintenance.
Follow instructions and warnings in manual and in labels on machine.

Keep manual in machine cab near operator.
Contact Komatsu distributor for a replacement manual.

RWA16810

2.

- Height Decal

DANGER


Hazardous voltage hazard. Serious injury or death can occur if machine or attachments are not kept safe distance away from electrical lines.

Line Voltage	Safe Distance
6.6 kV	At least 10ft (3m)
66.0 kV	At least 16ft (5m)
275.0 kV	At least 33ft (10m)

RWA24350


3.

- Warning Decal



4.

- Sudden Movement



SAFETY PLATES


5.

- Do Not Operate Tag



6.

- Hydraulic Oil



7.

- Battery Decal

WARNING

EXPLOSIVE GASES

- When attaching booster cables, always make last connection on machine frame away from battery to avoid sparks at the battery.
- Keep cigarettes, flames, and sparks away from battery to avoid explosion.
- Always shield eyes and face from battery.
- Do not charge, use booster cables, or adjust post connections without proper instruction and training.

POISON CAUSES SEVERE BURNS

Contains Sulfuric Acid

- Avoid contact with skin, eyes, or clothing.
- In the event of contact, flush affected area with water and call a physician immediately.

Do not risk serious injury or death.

RWA16870

8.

- Window warning (only cab version)

WARNING


- When raising window, sit back in operator's seat and lock it in place with lock pins on both sides to avoid contact from unexpected window movement.

Failure to follow instructions can cause severe injury.

RWA16880

9.

- Accumulator (OPTIONAL EQUIPMENT)

 **WARNING**

HIGH PRESSURE AND BURN HAZARD

1. When breakdown or trouble develops in the accumulator, do not attempt to disassemble or repair. Always contact your nearest authorized service station.
2. Do not attempt to fill or re-fill with gas. Authorized servicemen, or persons licensed to handle high pressure gases, are the only persons allowed.
3. Never hammer a gas filled accumulator, or place one close to a fire.
4. Never attempt to attach a part to or bore a hole in the accumulator's wall.
5. Always completely exhaust the accumulator of all contaminated gas when disassembling or discarding the accumulator.
6. To exhaust the gas, use the air relief valve mounted on the accumulator. When there is no such valve, remove the accumulator's gas filling valve cap and release the gas by depressing the valve core (pin) with a suitable tool (screw driver).

(1) Type of gas -	Nitrogen
(2) Maximum Working Pressure -	<u>210 bar</u>
(3) Testing Pressure -	<u>315 bar</u>

Do not risk serious injury or death.

RWA16890

10.

- Air Filter

IMPORTANT

- Element must be kept free of cracks and oil.
- For cleaning and replacement of elements, refer to the Operator's Manual.
- Do not put oil into this cleaner.

RWA16900

11.

- Hot Water Hazard

**12.**

- Fuel tank

**13.**

- Do not use ether



14.

- Running engine warning



15.

- Pinch point



16.

- Keep out swing area

**17.**

- Lever lock



- Never leave operators compartment without placing the safety lock lever in locked position.
DO NOT RISK SERIOUS INJURY OR DEATH.
-

**18.**

- High pressure hazard




19.

- ISO pattern warning

! WARNING

In order to prevent an accident resulting in injury or death caused by inadvertent movement, confirm the machine motion and indicated operating pattern, when operating machines.
Pay attention to the circumference and operate slowly when confirming the machine motion.

ISO PATTERN




RWA32740

20.

- Emergency exit (only cab version)

! NOTICE




In an emergency where normal exits are blocked, use hammer mounted below to break rear glass. If hammer is not present, contact your local Komatsu distributor.

RWA24420


21.

- Control pattern change



22.


- Levers Control



SAFETY PLATES


23.

- Accelerator control lever




24.

- Blade control lever




25.

- Speed increase pedal




26.

- Hammer/Clamshell




27.

- Lifting capacity (for PC35 only)






A - Outreach starting from the rotation center
B - Height at bucket pin
P - Lifting capacity



W = 0.5 m
 W = 1.6 ft

 Kg 80
 lb 114






> 1000 kg


			A			
			2 m 6.5 ft	3 m 9.8 ft	4 m 13 ft	MAX
L = 1.35 m L = 4.4 ft	3 m	Kg	---	580	440	440
	9.8 ft	lb	---	1276	968	968
	2 m	Kg	990	580	390	340
	6.5 ft	lb	2178	1276	858	748
	1 m	Kg	990	630	390	340
	3.3 ft	lb	2178	1386	858	748
	0.0 m	Kg	990	630	390	340
	0.0 ft	lb	2178	1386	858	748
	-1 m	Kg	990	580	390	340
-3.3 ft	lb	2178	1276	858	748	
L = 1.75 m L = 5.7 ft	0.0 m 0.0 ft	Kg lb	990 2178	550 1210	340 748	290 638

RWA33260

- Lifting capacity (for PC45 only)






A - Outreach starting from the rotation center
B - Height at bucket pin
P - Lifting capacity



W = 0.6 m
 W = 9 ft

 Kg 115
 lb 253


> 1000 kg

			A			
			2 m 6.5 ft	3 m 9.8 ft	4 m 13 ft	MAX
L = 1.48 m L = 4.8 ft	3 m	Kg	---	700	610	480
	9.8 ft	lb	---	1540	1342	1056
	2 m	Kg	990	990	660	430
	6.5 ft	lb	2178	2178	1452	946
	1 m	Kg	990	960	610	430
	3.3 ft	lb	2178	2112	1342	946
	0.0 m	Kg	990	960	610	430
	0.0 ft	lb	2178	2112	1342	946
	-1 m	Kg	990	960	610	480
-3.3 ft	lb	2178	2112	1342	1056	
L = 1.90 m L = 6.2 ft	0.0 m 0.0 ft	Kg lb	990 2178	800 1760	510 1122	330 726

RWA33270


28.

- Lubrication




29.

- Lubricating point



30.


- Equipment fuse decal



POSITION	COLOR	CAPACITY (A)	INVOLVED CIRCUIT
1	Green	30	Engine stop
2	Violet	3	Engine accosting alarm, start relay, instrument power supply
3	Light blue	15	Fan
4	Red	10	Arrangement for radio set installation
5	Brown	7.5	Revolving light, servocontrol solenoid valve
6	Red	10	Fuel pump, horn, TBG
7	Brown	7.5	Hammer solenoid valve
8	Brown	7.5	Outlet, cab
9	Brown	7.5	Alternator, speed increase solenoid valve
10	Brown	7.5	Engine stop solenoid
11	Brown	7.5	Working light

31.


- Lifting machine




2.1.2 POSITION OF THE PICTOGRAMS

- The pictograms must always be legible and in good conditions; for this reason, if they are dirty with dust, oil or grease, it is necessary to clean them with a solution made of water and detergent. Do not use fuel, petrol or solvents.
- If the plates are damaged, they must be replaced before operation of the product is resumed. Contact your Komatsu Dealer for replacement labels.
- In case of replacement of a component provided with a pictogram, make sure that this plate is applied also on the replaced component.
- The machine can be provided with other plates in addition to those indicated below; which must be followed for safe operation.

MACHINE WITH CAB



MACHINE WITH CANOPY




RWA33320

2.1.3 PICTOGRAMS AND RELEVANT MEANINGS

The warning and danger plates applied onto the machine are accompanied or represented by pictograms. The personnel in charge with the operation and maintenance of the machine must know the symbols contained in the pictograms perfectly; the following description illustrates what they look like and their respective meanings.


DANGER IN THE WORK AREA

- Do not approach or stand within the equipment operating radius when the boom and the bucket are raised.




MOVING PARTS IN ENGINE COMPARTMENT

- Keep clear; moving parts hazard inside engine compartment.




SAFETY DISTANCE


- Do not get near or stand within the machine working area.




ENGINE LUBRICATING OIL FILTER









FUEL FILTER



ENGINE AIR SUCTION FILTER



HYDRAULIC OIL LEVEL**HYDRAULIC OIL FILTER****ELECTRIC OUTLET****ANCHORAGE POINT****LIFTING POINT****EMERGENCY EXIT****2.1.4 VIBRATIONS TO WHICH THE OPERATOR IS SUBJECTED**

- According to the results of the tests carried out to determine the vibrations transmitted to the operator by the machine, the upper limbs are subjected to vibrations lower than 2.5 m/sq.sec. (1.7 ft/sq.sec.), while the seated part of the body is subjected to vibrations lower than 0.5 m/sq.sec. (8.2 ft/sq.sec.)

2.2 GENERAL PRECAUTIONS

2.2.1 GENERAL SAFETY RULES


- Only trained and authorized personnel can use the machine and perform maintenance operations.
- Follow all the safety rules, precautions and instructions when using the machine or performing maintenance operations.
- When working with other operators or when the work site is often occupied by other operators, make sure that everyone knows and understands all the agreed signals and, in any case, that everyone works in such a way as to be able to see the machine and to be visible to the operator.

2.2.2 SAFETY DEVICES AND GUARDS

- Make sure that all the guards and covers are in the correct position. Have guards and covers changed or repaired if damaged. Neither use the machine without guards, nor remove the guards when the engine is running.
- Always use the proper safety devices to lock the machine when parking and fasten the safety belt.
- For the safety devices, see “3.1 SAFETY LOCKS”.
- For the safety belt, see “3.5.6 SAFETY BELT”.
- Do not remove the safety devices and always keep them in good operating conditions.
- Any improper use of the safety devices may result in serious injuries or even death.

2.2.3 CLOTHING AND PERSONAL PROTECTION ITEMS

- Do not wear large or loose clothes, rings and watches and do not approach the machine with loose long hair, since they can get entangled in the moving parts of the machine and cause serious injuries or damage.
Avoid also wearing clothes dirty with oil or fuel, since they are flammable.
- Wear a hard hat, goggles, safety shoes, mask, gloves and headphones when operating the machine or performing maintenance operations.
- Always wear safety goggles, a hard hat and heavy gloves if your job involves scattering metal chips or minute materials; these precautions are particularly useful when driving the equipment connection pins with a hammer and when blowing compressed air into the air filter and the radiator to clean them.
During these operations, make also sure that no one is standing or working near the machine without the necessary protections.
- When working for 8 hours with a noise level exceeding 90 dBA, it is necessary to use headphones or ear plugs and be particularly careful, especially at the end of the work shift.







2.2.4 UNAUTHORIZED MODIFICATIONS

- Any modification made without the authorization of Komatsu can involve hazards.
- Before making a modification, consult your Komatsu Dealer. Komatsu declines any responsibility for injuries or damage caused by unauthorized modifications.

2.2.5 LEAVING THE OPERATOR'S SEAT



- When leaving the operator's seat, even if temporarily, make sure that the machine is in a safe position. (See "2.4.13 PARKING THE MACHINE").
- Before leaving the operator's seat, carry out the following operations in the sequence indicated below:
 - 1 - Rest the equipment onto the ground.
 - 2 - Connect the safety devices of the boom swing, optional equipment and upper structure rotation controls.
 - 3 - Lock the equipment control by shifting the safety device lever to the lock position.
 - 4 - Stop the engine (See "3.8 STOPPING THE ENGINE").

If you have to go so far away that you will not be able to see the machine, extract the ignition key.



2.2.6 GETTING ON AND OFF THE MACHINE

- Do not jump on or off the machine, either when it is at rest and when it is moving.
- When getting on or off the machine, always use the handles and the tracks; get on and off the machine very carefully.
- Never hold or rest on the control levers.
- Either when getting on and when getting off the machine, always maintain three points of contact (holding or resting points), in order to avoid losing your balance and falling down.
- Tighten the handle connection screws if they are loose and clean the handles and tracks if they are dirty with oil or grease. Carefully clean the cab floor if it is dirty with oil, grease, mud or rubble.



2.2.7 PREVENTING FIRES DUE TO FUEL AND OIL

Fuel, oil and some types of antifreeze can be easily ignited if they get in contact with a flame. Fuel is particularly flammable and therefore extremely hazardous.

- Keep any naked flame away from flammable fluids.
- Stop the engine and do not smoke when refuelling.
- Top up with fuel and oil only after stopping the engine and in well ventilated areas.
- Top up with fuel and oil in a well delimited area and do not allow unauthorized persons to approach.
- When refuelling, hold the fuel gun firmly and keep it constantly in contact with the filler until you have finished, in order to avoid sparks due to static electricity.
- After topping up, tighten the fuel and oil safety caps securely.
- Do not fill the tank completely, in order to leave room for the fuel to expand.
- In case some fuel is spilled, wipe it up immediately.





2.2.8 PREVENTING BURNS

- If the engine coolant, the engine oil and the hydraulic oil are hot, use heavy cloths and wear gloves, heavy clothing and safety goggles before carrying out any check or touching the hot parts.
- Before checking the coolant level, stop the engine and let the fluid cool down.
If a check is necessary due to the overheating of the engine, slowly loosen the radiator plug to release any residual pressure before removing it. The hot fluid that spurts out may cause serious burns.
- Before checking the engine oil and hydraulic circuit oil levels, stop the engine and let the oil cool down. The hot oil that can be sprayed out of the tank may cause serious burns.




2.2.9 PREVENTING DAMAGE DUE TO ASBESTOS POWDER

- Asbestos powder can be hazardous to your health if it is inhaled.
- If you handle materials containing asbestos fibers, keep to the instructions given below:
 - 1 - **Do not use compressed air, but only aspirators** to clean the machine and make sure that the room in which you are working is properly ventilated.
 - 2 - Use low-pressure water to keep down the dust when cleaning.
 - 3 - If there is danger that there may be asbestos powder in the air, operate the machine with the wind to your back whenever possible.
 - 4 - Even if the cab provides suitable protection, use an approved and homologated respirator.
 - 5 - The powder gathered during the cleaning operations must be dampened and put in a sealed and marked container, so that it can be safely disposed of according to the regulations in force.




2.2.10 PREVENTING DAMAGE CAUSED BY THE WORK EQUIPMENT

- Do not stand within or approach the operating radius of the work equipment, even when the operator is on board the machine and the engine is running.
- Do not stand or work under the arms or the articulations when the arms are lifted, if you are not sure that the safety locks have been duly engaged.
- Do not carry out any operation requiring the lifting of the arms, if you are not sure that the locks are correctly positioned and coupled to the arms.



2.2.11 FIRE EXTINGUISHERS AND FIRST AID KIT

- Make sure that fire extinguishers have been provided and check their position.
- Periodically make sure that the fire extinguishers are loaded and that you know how to use them.
- Find out where the first aid kit has been located.
- Periodically make sure that the first aid kit contains the necessary disinfectants, bandages, medicines, etc.
- It is necessary to know what to do in case of fire.
- Make sure that you have the phone numbers of the persons or structures you may need to contact in case of an emergency at hand (either at the work site and where maintenance operations are performed).



2.2.12 PRECAUTIONS CONCERNING THE CAB STRUCTURE

- If the cab is inadvertently hit or the machine overturns during work, the cab may be damaged with consequent reduction of its stiffness and of the safety that must be guaranteed to the operator.
Consult Komatsu or your Komatsu Dealer to have the cab structure and resistance checked in case of impact or damage.


2.2.13 PRECAUTIONS CONCERNING THE EQUIPMENT

- When installing and using optional equipment, carefully read the relevant instruction manual and keep to the indications given therein.
- Do not use optional or special equipment without the authorization of Komatsu or the Komatsu Dealer.
The installation and use of unauthorized equipment may create safety problems and adversely affect the efficiency and life of the machine.
- Komatsu cannot be held liable for any injury, accident, product failure resulting from the installation and use of unauthorized equipment.

2.3 PRECAUTIONS TO BE TAKEN BEFORE STARTING THE ENGINE

2.3.1 SAFETY ON THE WORK SITE

- Before starting the engine, thoroughly check the area for any unusual condition of the ground due to which work may be dangerous.
- Check the conditions of the ground at the work site and before starting the engine define the work plan and the best and safest operating procedure.
- Make the ground surface as level as possible before carrying out any operation.
- In case of work on the road, protect pedestrians and cars by designating a person for work site traffic duty and install fences around the work site.
- If water lines, gas lines, and telephone or high-voltage electrical lines are located under the work site, contact the relevant utility company in order to find out their exact positions or to make them ineffective until the end of the operations. Be careful not to sever or damage any of these lines.
- Check the depth and flow of water before operating in water or on river banks.



2.3.2 FIRE PREVENTION

- Completely remove all wood chips, rubbish, paper and other flammable materials that may have accumulated inside the engine compartment, since they can cause fires.
- Check the fuel and hydraulic system pipes for leaks and if necessary repair them. Wipe up any excess oil, fuel or other flammable fluids.
- Make sure that fire extinguishers are available in the work area.



2.3.3 PRECAUTIONS TO BE TAKEN FOR THE OPERATOR'S CAB

- Do not leave objects or tools lying around in the operator's cab. They may hinder the operation of the controls and cause serious accidents.
- Keep the cab floor and the controls (pedals and levers) clean, by removing any trace of oil and grease and, as far as the floor is concerned, remove any excess dirt (earth, stones, etc.).
- Check the safety belt and change it if it is broken or damaged.
Replace any component only with homologated parts available at Komatsu or its Dealers.

2.3.4 ROOM VENTILATION

- Before starting the machine in confined or poorly ventilated places, provide for proper ventilation or connect the engine exhaust pipe to a suction duct. The engine exhaust gases can be deadly.



2.3.5 PRECAUTIONS TO BE TAKEN FOR THE LIGHTS

- Remove any trace of dirt from the lights, in such a way as to ensure perfect visibility on the work area.
- Make sure that the working lights are installed as prescribed. Make also sure that they come on correctly.

2.3.6 CLEANING THE WINDOWS - CHECKING THE WINDSHIELD WIPER BLADES

- Remove any trace of dirt from the cab windows, in order to ensure perfect visibility on the work area.
- Check the conditions of the windshield wiper blades; the scraping wire must be smooth, with no indentations and attached to the rubber back of the blade.
In case of doubts on the efficiency of the scraping wire, change the blades.


2.4 PRECAUTIONS TO BE TAKEN WHEN WORKING

2.4.1 STARTING THE ENGINE

- Before getting on the machine, walk around it and check for people and objects that might be in the way.
- Do not start the engine if warning plates have been attached to the control levers.
- When starting the engine, sound the horn as an alert signal.
- Start the engine only while seated with fastened safety belt.
- Do not allow anyone to get on the machine.



2.4.2 CHECK THE DIRECTION BEFORE STARTING THE MACHINE

- Before operating the machine travel levers, check the position of the blade.
If the blade is positioned on the back of the machine, the operation of the travel levers is inverted.
In this condition, take care not to mistake the travel movements during the use of the machine.
(See “3.6.5 HOW TO MOVE THE MACHINE”).





2.4.3 CHECKS FOR TRAVELLING IN REVERSE

- When operating in areas that may be hazardous or have poor visibility, designate a person to direct the movements of the machine and traffic on the work site.
- Make sure that no unauthorized person is within the machine operating radius or in its travel direction.
If necessary, put up appropriate fences.
- Before moving the machine, sound the horn in order to warn the persons near the work area.
- There are blind spots behind the machine, which cannot be seen and where someone may be standing: therefore, it is necessary to make sure that there is no one behind the machine before travelling in reverse.







2.4.4 MOVING THE MACHINE

- When moving the machine, position the bucket at about 40-50 cm (16 to 20 in) from the ground; this position makes it possible to evaluate the space required for the movements more precisely and at the same time ensures the stability of the machine.
- Make sure that the driver's seat is directed towards the blade. Otherwise, pay attention to the steering and advance manoeuvres, since they are inverted.
- If the equipment control levers must be used during travel, avoid moving them abruptly; sudden manoeuvres change the attitude of the machine and make driving difficult.
- When travelling on rough ground, keep the speed low and avoid sudden movements of the bucket arm.
- If possible, avoid moving on obstacles. If the machine has to travel over an obstacle, keep the equipment as close to the ground as possible and travel at low speed. Never move on obstacles that may incline the machine considerably (over 10°).
- If one of the two rubber tracks moves on an obstacle or gets into a hole in the ground, the machine may overturn. In these cases, reduce the speed to minimum and be very careful to the balance of the machine.





2.4.5 MOVING ON SLOPES

- Operations on slopes and on river or lake banks with damp ground may result in the tipping over or slipping of the machine.
- On hills, banks or slopes, keep the bucket very close to the ground (20-30 cm (8 to 12 in) from the ground) and in case of emergency quickly lower it to the ground to help the machine stop.
- Do not change direction and avoid travelling obliquely when working on slopes. It is advisable to go down or up to a flat place to perform these operations.
- Do not travel on wet grass or thick layers of leaves: if the machine moves obliquely in these conditions, it may slip.
- Do not move on slopes with inclination exceeding 30°, since the machine may overturn.
- When the fuel level indicator reaches the red reserve area during work on a slope, immediately provide for refuelling; due to the inclination of the machine, the engine may suck in air and suddenly stop, which represents a grave risk for the safety of the operator and of the persons before the machine.
- If the engine should stop all of a sudden, immediately lower the bucket to the ground.





2.4.6 WORKING ON SLOPES

- When working on slopes, if possible avoid rotating the upper structure, since the machine may lose balance and overturn. It is particularly dangerous to swing on slopes when the bucket is full.
- If these operations must last longer, accumulate soil in such a way as to create a horizontal platform on which the machine can be positioned.



2.4.7 UNAUTHORIZED OPERATIONS

- Do not dig under overhangs. The protruding surface, in fact, may collapse on the machine.
- Do not dig too deeply under the front part of the machine, since the ground may collapse and cause the machine to fall down.




2.4.8 PREVENTING ELECTROCUTION

- Digging operations near overhead electric lines are extremely dangerous and they may also cause death due to electrocution; for this reason, when working near overhead electrical lines always respect the minimum safety distances prescribed by the competent authorities and by the accident-prevention rules in force.
- As far as underground long-distance lines are concerned, the minimum distance depends on the covering of the ducts in which the cables are laid.
- The basic safety precautions to be taken to prevent this risk are the following:
 - 1 - Wear shoes with thick rubber or leather soles.
 - 2 - Request the aid of another person who can warn you if the machine gets too close to the electric line.
 - 3 - Operate at low speed.
 - 4 - Learn what is to be done first in case of electrocution.
 - 5 - Keep the phone number of the electricity company and of the nearest first aid station at hand.
- If the work equipment gets accidentally entangled in the cables, the operator must not leave the cab until the electricity company has insulated the line.
- When carrying out this kind of operations, warn everyone standing in the work area to keep at the minimum distance prescribed from the machine and the work equipment.
- Ask the electricity company what are the voltage of the cables and the minimum safety distance in advance.



- **The minimum distances from overhead lines can vary in the different countries, according to the climate and to the humidity percentage in the air. Indicatively, the distances indicated in the table should be respected.**

Cable voltage	Min. safety distance	
	m	ft
6.6 kV	3 m	10 ft
66.0 kV	5 m	16 ft
275.0 kV	10 m	33 ft



2.4.9 VISIBILITY

- Switch on the working lights as soon as visibility decreases.
- If visibility decreases due to mist, smoke or heavy rain, stop the machine in a safe position and wait for the weather to improve until visibility becomes acceptable.

2.4.10 WORKING ON ICY OR SNOW-COVERED SURFACES

- If the ground is icy or covered with snow, even a slight slope may cause the machine to slip sideways, therefore it is advisable to move at low speed and to avoid abrupt starts, stops or turns.
- When it has snowed heavily, the road shoulders and any obstacle are buried in the snow and are not visible, therefore proceed with care when clearing the snow.

2.4.11 PREVENTING DAMAGE CAUSED BY THE WORK EQUIPMENT


- When working in tunnels, galleries, under electric cables or other ducts (air, telephone lines) and wherever the height is limited, proceed with the greatest care to prevent the bucket or the arms from causing any damage.

2.4.12 WORKING ON LOOSE GROUND


- Avoid operating the machine too close to the edge of cliffs, overhangs and deep ditches. These areas may collapse, making the machine fall down or tip over and this could result in serious injuries or death.
Remember that after heavy rain or earthquakes these dangerous conditions usually get worse.
- The earth laid near ditches is loose and can easily collapse due to the weight or vibrations of the machine. Be extremely careful: always fasten the safety belt and close the cab door, if provided.
- In case of work in areas where stones or other material may fall on the machine, install the FOPS protection device.

2.4.13 PARKING THE MACHINE


- Park the machine on firm and level ground. If this is not possible and it is necessary to park on a slope, position the machine with the bucket directed downwards and carry out the following operations:
 - 1 - Rotate the bucket to the dumping position and lower the arms until thrusting the teeth into the ground.
 - 2 - Stop the engine.
 - 3 - Put wedges or safety blocks under the tracks.
- Always rest the work equipment on the ground; if it is necessary to park with raised arms, make sure that the safety locks are engaged.
- Lock the equipment control by shifting the safety device lever to the lock position.
- When leaving the machine, remove the ignition key.
- If it is necessary to park on public roads, provide for signalling the presence of the machine according to the local regulations in force (signalling fires, fences, road works ahead, alternated direction and direction signs, etc.).



RWA07010



RWA02000




RWA05000

2.5 TRANSPORTING THE MACHINE ON OTHER VEHICLES

2.5.1 LOADING AND UNLOADING

- Loading and unloading the machine on/from a motor vehicle always involves potential hazards. Proceed with extreme care.
- Perform loading and unloading on firm, level ground. Maintain a safety distance from the edges of ditches or from road sides.
- If the vehicles used have not been appositely equipped, put support blocks under the ramps, in order to avoid any bending.
- Always lock the wheels of the transporting vehicle with wedges.
- Always use ramps that are sufficiently wide and can support the weight of the machine. The longitudinal axes of the ramps must be parallel to each other and perpendicular to the loading side board and their distance must be suitable for the tread of the machine.
- Make sure that the ramps are securely positioned and fastened to the loading board and that they have the same length.
- Position the ramps with a maximum inclination of 15°.
- Make sure that the ramp surface is clean and there is no trace of grease, oil, soil and ice; remove dirt from the tracks before starting to load the machine on the vehicle.
- The machine must be loaded on the vehicle with the bucket directed forwards, that is, in the direction of advancement of the vehicle.
- Do not correct the trajectory of the machine on the ramps. If necessary, get down the ramps and start the operation again.
- After loading the machine, block the tracks with wedges and secure it with tie-downs or chains that prevent even any sideward shift (see "3.9 TRANSPORTING THE MACHINE ON OTHER VEHICLES").






2.5.2 TRANSPORT

- Define the route to be followed, taking in consideration the width, height and weight of the transport means and of the machine.
Make sure that the dimensions of the machine are compatible with the road and any gallery, subway, bridge, electric and telephone lines, etc.
- Keep to the regulations in force regarding the permissible width, height, weight of the machine and the transport speed.

2.6 BATTERY


2.6.1 PREVENTING RISKS THAT MAY BE DUE TO THE BATTERY

- Electrolytic batteries contain sulphuric acid that can quickly burn the skin and corrode clothes making holes in the fabric. If you spill acid on yourself, immediately rinse the involved area with plenty of water.
- Battery acid may cause blindness if splashed into the eyes. If acid gets accidentally into your eyes, flush them immediately with plenty of water and consult a doctor without delay.
- If you accidentally swallow some acid, drink a large quantity of water or milk, beaten egg white or vegetable oil and in any case antacid substances like magnesia, bicarbonate, etc. call a doctor or a poisoning prevention center immediately.
- When handling batteries, always wear safety goggles.
- Batteries generate hydrogen. Hydrogen is highly explosive and can be easily ignited with small sparks or naked flames.
- Before working with batteries, stop the engine and remove the ignition key.
- Avoid short-circuiting the battery terminals through accidental contact with metal objects or tools or through the inversion of the terminals.
- Tighten the battery terminals securely. Loose terminals may generate sparks and even cause the explosion of the battery.




2.6.2 STARTING WITH BOOSTER CABLES

- When starting the machine with booster cables, always wear safety goggles.
- When starting the engine by means of another machine, avoid any contact between the two machines.
- Be sure to connect the positive cable (+) first and then the negative or earth cable (-) when connecting the booster cables. Disconnect first the negative or earth (-) cable and then the positive cable (+) after the start.
- Connect the batteries in parallel: positive to positive and negative to negative.
- When connecting the earth cable to the frame of the machine to be started, operate as far as possible from the battery. (See "3.15.4 IF THE BATTERY IS DOWN").




2.7 PRECAUTIONS FOR EMERGENCY RECOVERY

- The draw hook must be used only for the first aid and not for towing the machine.
- Before moving the machine, make sure that all the controls are in neutral.
- Incorrect manoeuvres may result in serious injuries or even death.
- To move the machine, use properly dimensioned steel cables; do not use worn cables or cables with broken strands (A), twisted cables (B), deformed cables (C).
- During the removal, no one can be allowed to get near the machines or the cable.
- Do not get astride the cable.
- Remove the machine only as much as necessary to permit the required repairs.
- Put wooden blocks between the towing cable and the machine body, in order to avoid wear or damage.
- Do not remove the machine in any way other than that indicated at point "3.15.2 HOW TO REMOVE THE MACHINE".



CAUTION


- **The maximum applicable force for the removal is the following:**
F=3670 kg (8090 lb) (for PC35R only)
F=4760 kg (10493 lb) (for PC45R only).
- **Use cables having the same length and draw continuously and constantly, without jerks.**
- **Arrange and couple the machine to be removed by positioning it on the same axis as the towing vehicle; the drawing force must be parallel to the axis of movement of the machine.**



2.8 PRECAUTIONS TO BE TAKEN DURING MAINTENANCE



2.8.1 WARNING PLATES

- Before starting any maintenance operation, position the machine on a firm and level surface, rest the equipment onto the ground, engage the safety locks of either the equipment and the controls and stop the engine.
- If another person starts the engine and operates the control levers while the operator is providing for service, this may result in serious injuries or even death.
- To avoid these risks, always attach warning plates to the control levers and to the ignition key before performing any maintenance operation; if necessary, attach additional warning tags also around the machine and in particular on the cab door handles.



2.8.2 TOOLS

- Use only the tools provided with the machine and high-quality tools suitable for the tasks to be performed.
- Do not use worn, damaged, low-quality tools or tools that are not suitable for the tasks to be performed, in order to avoid any personal injury.
- After use, always clean the tools carefully and put them in the appropriate compartment (1) positioned inside the seat support.




2.8.3 PERSONNEL

- Only authorized and duly trained personnel can service and repair the machine; additional precautions must be taken when grinding, welding and using a sledge hammer or heavy hammers.
- When assembling the equipment or cylinder connection pins, use wooden, plastic or in any case not excessively hard tools to check the centering of the holes.
Do not use your fingers, since you run the risk of cutting them.

2.8.4 EQUIPMENT

- The normal or special equipment that must be installed on the machine or that have been removed must be stored in safe places, preventing them from falling down. If they fall on someone, they can cause serious bodily harm.
- When assembling or removing any equipment, make sure that the ropes and the lifting hook are in good conditions and properly dimensioned for the load to be lifted.




2.8.5 WORKING UNDER THE MACHINE

- Always lower the work equipment to the ground or in any case to its lowest position before performing service or repairs under the machine.
- Always lock the machine tracks securely.
- Do not work under the machine, if this is not sufficiently supported.



2.8.6 CLEANING THE MACHINE

- Spilled oil or grease, scattered tools or broken pieces are dangerous, because they may cause someone to slip or trip. Always keep the machine and the work site clean and tidy.
- To clean the machine, use a pressurized jet of warm water or steam and the appropriate detergents available on the market. Do not use gas oil, oil or solvents, since the former leave an oily coat that favours the sticking of dust, while the latter (even if weak) damage the painted surfaces and therefore facilitate rusting.
- While cleaning the machine, keep the pressurized jet at a minimum distance of approx. 60 cm (24 in) in order not to damage the warning plates and the pictograms.
If the plates are damaged, request Komatsu or your Komatsu Dealer to send you spare plates and change them.
- Water into the electrical system provokes the oxidation of the contacts and may hinder the start of the machine or even make it start suddenly and abruptly. For this reason, never use water or steam jets to clean sensors, connectors or the inside of the operator's cab.



2.8.7 USE OF THE ENGINE DURING MAINTENANCE OPERATIONS



- During maintenance operations, let the engine run only when indispensable. If it is necessary to have the engine running (for example, to wash the cooling circuit or to check the functionality of the alternator), an operator should constantly remain in the cab, in order to be able to stop the engine whenever necessary.
- During maintenance operations with running engine, never move the control locking devices from the “lock” position or change the position of the travel levers.
Service personnel must not move any control lever.
- When carrying out maintenance operations, do not touch the moving parts of the machine and avoid wearing large and loose clothes.

2.8.8 PERIODICAL CHANGE OF THE PARTS THAT ARE CRITICAL FOR SAFETY

- Periodically change the following parts, which are important to prevent fires.
Fuel supply system: fuel delivery and return pipes.
Hydraulic system: main delivery pipes of the hydraulic pump.
- Even if they seem to be in good conditions, these components must be periodically changed with new ones. In fact, these components tend to deteriorate over time.
- If one of these parts is defective, change or repair it even if the change interval has not elapsed yet. (See “4.6 PERIODICAL CHANGE OF THE COMPONENTS CONNECTED WITH SAFETY”).

2.8.9 STOP THE ENGINE BEFORE CARRYING OUT ANY MAINTENANCE OPERATION OR INSPECTION

- Stop the machine only on firm and level ground and stop the engine before carrying out any maintenance operation or inspection.
- If the engine must turn during a maintenance operation, shift the safety device lever to the LOCK position and carry out the maintenance operation with the help of another person; one operator must remain on the machine and the words and signs to be used must be agreed upon in advance.
- The person who carries out the maintenance operation must be very careful not to touch any moving part of the engine.




2.8.10 RULES TO BE FOLLOWED DURING FUEL OR OIL TOPPING UP

- Keep away from naked flames while refuelling or topping up oil.
- Spilled fuel or oil make the ground slippery and may cause accidents; clean any dirty area immediately and carefully.
- Always tighten the fuel tank and the hydraulic circuit oil safety caps securely.
- Do not use fuel to clean any part of the machine that may be dirty with oil or dust.
- Always top up the fuel and oil tanks in properly ventilated place and avoid smoking.
- When refuelling, hold the fuel gun firmly and keep it constantly in contact with the filler until you have finished, in order to avoid sparks due to static electricity.
- Do not fill the tank completely, in order to leave room for the fuel to expand.




2.8.11 CHECKING THE COOLANT LEVEL IN THE RADIATOR

- Let the engine and the radiator cool down before checking the coolant level.
- If it is necessary to remove the cap with hot engine, wear suitable clothes and protections and loosen the cap slowly, in order to gradually release the pressure.



2.8.12 USING LAMPS

- When checking the fuel, oil, coolant or battery electrolyte levels, always use homologated explosion-proof lamps. If such lighting equipment is not used, there is danger of fire or explosion.





2.8.13 PRECAUTIONS CONCERNING THE BATTERY AND THE ALTERNATOR

- When repairing the electrical system, disconnect the battery in order to stop the flow of current.

 **IMPORTANT**



- **Disconnect first the negative earth cable (-) and then the positive cable (+).
At the end of the operation, reconnect first the positive cable (+) and then the negative cable (-).**

- If electrical welding operations are to be carried out on the machine, it is necessary to disconnect the battery and also the alternator.



2.8.14 PRECAUTIONS CONCERNING THE STARTER

- Do not start the engine by tampering with the terminals of the starter, since the machine may move.
- Sudden or accidental movements of the machine may cause serious injuries or even death.





2.8.15 HANDLING HIGH-PRESSURE PIPES

- Do not bend high-pressure pipes or rub them with abrasive or cutting objects.
Do not use any bent or cracked pipes or hoses that were previously rejected because of leaks or fastening defects, since they may burst during use.
- Always repair or replace any loose or faulty fuel or oil pipe. Any leakage of fuel or oil may cause fires.

2.8.16 PRECAUTIONS TO BE TAKEN WHEN HANDLING HIGH-PRESSURE OIL

- Do not forget that the work equipment circuits are always under pressure; for this reason, when it is necessary to add or drain hydraulic oil or to perform maintenance operations or inspections on the hydraulic circuit, it is advisable to lower the equipment to the ground and completely release the pressures and the residual pressure present in the tank.
Small leakages from pipes under pressure and the resulting jets are extremely dangerous, since they can perforate the skin and penetrate in the blood circulation or injure the eyes.
For this reason, always wear goggles and thick gloves during the inspections and use a piece of cardboard or a sheet of plywood to check for oil leakages.
If you are hit by a jet of high-pressure oil or are injured, even if slightly, immediately consult a doctor.




2.8.17 PRECAUTIONS FOR MAINTENANCE OPERATIONS AT HIGH TEMPERATURES AND HIGH PRESSURE

- When the machine is stopped at the end of operations, the engine coolant, the oil and all the components are hot and the hydraulic circuits are under pressure.
In these conditions, if the coolant, the hydraulic oil and the engine oil are to be drained in order to change them or the filters, there are serious risks of damage and burns.
Wait for the temperature to lower within the normal operating range 40-45°C (104-113°F) before carrying out the maintenance operations in accordance with the procedures indicated in the relevant sections of this manual).




2.8.18 COOLING FAN AND BELT

- Be careful to the revolving parts and do not allow anyone to get too close to these parts, since clothes or parts of the body may get caught into them.
- If hands, clothes, or tools touch the fan blades or the belt, they may be cut, torn or seriously damaged; for this reason, avoid touching the revolving parts.



2.8.19 WASTE MATERIALS

- Do not dispose of used oil in the sewer system, rivers, etc.
- Always put used oil in containers. Never drain the oil directly onto the ground.
- Keep to the laws and regulations in force when disposing of harmful substances such as oil, fuel, solvents, used filters and batteries.



PAGE INTENTIONALLY LEFT BLANK



**THE MACHINE AND
ITS OPERATIONS**





3.1 SAFETY LOCKS



- If it is necessary to stop the machine, lower the equipment to the ground and always engage the safety device by shifting the lever to the lock position. (See “3.3.2 pos. 8-9 MACHINE CONTROLS”).
- If the operator expects that he may need to stop the machine with raised arms, he is responsible for preparing and installing locks or safety devices that must ensure safety.
- During travel, position the upper structure so that it is directed towards the blade before engaging the antirotation lock.
- Non-compliance with these rules may result in serious damage.


3.1.1 MACHINE LOCKS

- The machine is provided with an upper structure antirotation lock (1) that can be operated from the driving position; always lock the upper structure rotation before leaving and when transporting the machine.
- The other applications of the safety locks concern:
 - a) The engagement of the lock (2) on the boom swing control pedal and of the lock (3) on the optional equipment control pedal.
 - b) The lock position of the safety device (4) for the locking of the equipment, travel and boom swing controls.



3.2 GENERAL VIEWS

3.2.1 GENERAL VIEW OF THE MACHINE WITH CAB




- 1 - Bucket
- 2 - Bucket cylinder
- 3 - Arm
- 4 - Arm cylinder
- 5 - Boom
- 6 - Lifting cylinder
- 7 - Cab
- 8 - Sprocket
- 9 - Undercarriage

- 10 - Revolving support
- 11 - Idler roller
- 12 - Track
- 13 - Blade
- 14 - Blade cylinder

RWA05560

3.2.2 GENERAL VIEW OF THE MACHINE WITH CANOPY




- 1 - Bucket
- 2 - Bucket cylinder
- 3 - Arm
- 4 - Arm cylinder
- 5 - Boom
- 6 - Lifting cylinder
- 7 - Canopy
- 8 - Sprocket
- 9 - Undercarriage

- 10 - Revolving support
- 11 - Idler roller
- 12 - Track
- 13 - Blade
- 14 - Blade cylinder


RWA08830

3.2.3 GENERAL VIEW OF THE DRIVER'S SEAT




RWA08840

- 1 - Left safety lever
- 2 - Arm-upper structure rotation control
- 3 - Left track control lever
- 4 - Right track control lever
- 5 - Boom swing control pedal
- 6 - Bucket - boom lifting control
- 7 - Right safety lever
(only for machines with canopy)
- 8 - Blade control
- 9 - Dashboard
- 10 - Accelerator control
- 11 - Speed increase control
- 12 - Optional equipment control pedal
- 13 - Rotation locking pin



RWA05590







RWA08850




3.3 INSTRUMENTS AND CONTROLS

3.3.1 INSTRUMENTS, WARNING LIGHTS AND PUSH BUTTONS

- 1 - Hour meter
- 2 - Engine coolant temperature indicator
- 3 - Fuel level indicator
- 4 - Engine oil pressure warning light
- 5 - Generator warning light
- 6 - Pre-heating warning light
- 7 - Fan switch
(with cab only)
- 8 - Working light and instrument light switch
- 9 - Ignition switch
- 10 - Boom overload alarm switch
(if installed)
- 11 - Revolving light switch
(if installed)
- 12 - Horn
- 13 - Engine acoustic alarm



- 14 - Windshield wiper / washer switch
(with cab only)
- 15 - Overhead lamp
(with cab only)
- 16 - Electric outlet




1 - HOUR METER

This instrument indicates the total number of operating hours of the engine. The count is continuous and the number is increased by 1 when the engine has run for one hour, independently of its speed.

The hour meter keeps functioning even if the machine is not travelling or working.

The reading is to be considered valid for the calculation of the maintenance intervals.



2 - ENGINE COOLANT TEMPERATURE INDICATOR


It indicates the temperature of the engine coolant, which must normally be 80-85°C (176-185°F).

After the start, it is necessary to let the engine warm up before beginning work.

If during operation the indicator exceeds the limit values and enters the overheating sector (red), let the engine idle until the indicator returns to the normal temperature sector (green).


When the indicator is in the overheating sector (red), the acoustic alarm sounds, too.

If this inconvenience occurs again, try to locate the fault (see 3.15.5.3 TROUBLE-SHOOTING - ENGINE).



3 - FUEL LEVEL INDICATOR


It indicates the fuel level in the tank; this information is available only when the ignition key is in position «I» (see pos. 9).



4 - ENGINE OIL PRESSURE WARNING LIGHT

This warning light comes on and makes the acoustic alarm sound with engine at rest when the ignition circuit is operated, then goes out as soon as the engine lubrication circuit is pressurized.

If this warning light remains on or comes on when the engine is running, stop the machine immediately and try to locate the trouble.




5 - GENERATOR WARNING LIGHT


This warning light comes on and makes the acoustic alarm sound when the ignition circuit is energized and goes out when the engine exceeds the idling speed; if this warning light remains on even when the engine is running at the normal operating speed, this means that the alternator does not work and the battery is not charged correctly.


IMPORTANT

- If the warning light remains off when the ignition key is turned to position «I», this means that the alternator is faulty or broken.




6 - PRE-HEATING WARNING LIGHT

This warning light comes on when the ignition key is turned to position «» to start the engine at low temperatures (see “3.6.2.2 STARTING WITH COLD ENGINE OR IN COLD CLIMATES”).



7 - FAN SWITCH (with cab only)


This is a two-speed switch that operates the fan motor. If operated after the opening of the tap installed in the engine compartment, it ensures the circulation of warm air and serves as heating switch. (See “3.5.4 VENTILATION AND HEATING”).





8 - WORKING LIGHT AND INSTRUMENT LIGHT SWITCH


This is a rotary switch with three positions marked by the following symbols: (OFF - 1 - 2).

- 1) Enables the instrument light circuit
- 2) Enables the working light circuit




9 - IGNITION SWITCH

This is a rotary key switch with four positions marked by the following symbols: «» - ○ (OFF) - I - «» (START).
For the use of this switch, see “3.6.2 STARTING THE ENGINE”.




**10 - BOOM OVERLOAD ALARM SWITCH
(if installed)**

This is a rotary switch with two positions (OFF - ON) and, if operated, makes it possible to define when the capacity limit has been reached.




**11 - REVOLVING LIGHT SWITCH
(if installed)**

This is a tow-position rotary switch and, if pressed, operates the revolving light.



12 - HORN

This push button is positioned on the right lever grip and serves to warn the persons in the vicinity at the beginning of work and in case of danger.




13 - ENGINE ACOUSTIC ALARM

This alarm starts sounding when the circuits are energized with the ignition key (rotation to position "I") and is automatically disconnected when the engine is started.


If the alarm sounds during the use of the machine, it indicates:

- Engine oil low pressure.
- Overheating of the engine cooling circuit.
- Faulty alternator or worn out belt.



14 - WINDSHIELD WIPER / WASHER SWITCH (only on machines with cab)


With the first click it operates the windshield wiper, while with the second click (with automatic return to the first) it operates the windshield washer.



15 - OVERHEAD LAMP (only on machines with cab)

It is used to check the instruments and the inside of the cab when visibility is insufficient.

To turn it on, press the switch to position ON.




16 - ELECTRIC OUTLET


An electric outlet is positioned on the front part of the machine for the connection of a lighting device for routine and maintenance operations.

It is a two-pole outlet and is in compliance with the ISO 4165-1979 standard.

Power supply 12V




3.3.2 MACHINE CONTROLS




RWA08890

- 1 - Left equipment control lever
- 2 - Right equipment control lever
- 3 - Left travel and steering control lever
- 4 - Right travel and steering control lever
- 5 - Boom swing control pedal
- 6 - Blade control lever
- 7 - Accelerator lever
- 8 - Left safety device control lever
- 9 - Right safety device control lever
(only on machines with canopy)
- 10 - Speed increase push button
- 11 - Optional equipment control pedal
- 12 - Upper structure rotation locking lever



RWA08900



RWA08910


1-2 - EQUIPMENT CONTROL LEVERS



- Before carrying out any manoeuvre with these levers, the operator must be seated in the work position with fastened safety belt; before any manoeuvre he must perform the operations described in “3.13 USING THE WORK EQUIPMENT”).
- Before leaving the operating position, lower the equipment to the ground and lock the safety device, then stop the engine.


The control lever (1) is positioned on the operator's left and controls the arm and the upper structure rotation, while the control lever (2) is positioned at the operator's right and controls the boom and the bucket.

The following diagrams show the basic manoeuvres and the possible combined manoeuvres.




LEVER 1 (BASIC MANOEUVRES)

- N - Neutral
- A - Arm opening
- B - Rotation to the right
- C - Arm folding
- D - Rotation to the left



LEVER 2 (BASIC MANOEUVRES)


- N - Neutral
- A - Boom lowering
- B - Bucket opening
- C - Boom raising
- D - Bucket folding



If the levers are operated in directions that are inclined with respect to the machine axis, simultaneous movements proportional to the angle of inclination are obtained, since the two hydraulic distributors corresponding to each single function are engaged at the same time.


LEVER 1 (COMBINED MANOEUVRES)

- N - Neutral
- A - Arm opening and rotation to the left
- B - Arm opening and rotation to the right
- C - Rotation to the right and arm folding
- D - Rotation to the left and arm folding



LEVER 2 (COMBINED MANOEUVRES)

- N - Neutral
- A - Boom lowering and bucket folding
- B - Boom lowering and bucket opening
- C - Bucket opening and boom lifting
- D - Bucket folding and boom lifting



 **IMPORTANT**

- Before rotating the upper structure, make sure that the rotation locking pin is raised (released).
- The horn is positioned on the right lever grip and must be used to warn the persons in the vicinity at the beginning of work and in case of danger.
- All movements are locked by shifting the safety device lever to the lock position (see pos. 8/9).

3-4 - TRAVEL AND STEERING CONTROL LEVERS

! WARNING


- Before carrying out any manoeuvre with these levers, the operator must be seated in the work position with fastened safety belt.
- Before moving, make sure that the upper structure is directed towards the blade and that all the safety devices have been engaged; if the upper structure is turned by 180°, the controls are inverted.
(See “3.6.5 HOW TO MOVE THE MACHINE”).
- Failure to comply with these rules may result in serious accidents.

The levers (3) and (4) serve to operate the left and right travel motors, respectively, and control the forward and the reverse gear according to the movements indicated.


- N - Neutral
- A - Forward gear
- B - Reverse gear

! IMPORTANT

- As option the machine could be equipped with travel warning alarm which will be activated when moving the travel levers.
- All movements are locked by shifting the safety device lever to the lock position (see pos. 8/9).



RWA07310



RWA07300

5 - BOOM SWING CONTROL PEDAL

! WARNING


- Always engage the safety device (1) when the use of this control pedal is not required, during travel and when parking the machine.
If this control pedal is inadvertently pressed, it may cause serious accidents.

This pedal controls the boom swing to the right and to the left according to the movements indicated.


- N - Neutral
- A - Swing to the left
- B - Swing to the right

! IMPORTANT

- All movements are locked by shifting the safety device lever to the lock position (see pos. 8/9).
- The boom swing is useful when it is necessary to dig beyond the track outline; do not use it during the work cycle.



RWA05660



RWA05650


6 - BLADE CONTROL LEVER



- Before moving the machine, make sure that the blade is completely raised.

This lever controls the raising and lowering of the blade according to the movements indicated.

- N - Neutral
- A - Blade lowering
- B - Blade raising




7 - ACCELERATOR LEVER

This lever serves to adjust the speed and power of the engine.

- Idling position (1):
Lever pushed completely forward.
- Maximum speed position (2):
Lever pulled completely backward.

Use the accelerator lever with care, especially when the machine is under strain or is working in difficult conditions. Avoid any useless acceleration, in order to reduce consumption and extend the life of either the engine and the machine.



8 - LEFT SAFETY DEVICE CONTROL LEVER

WARNING




- Before leaving the operating position, lower the equipment to the ground and shift the safety device lever to the lock position.

To lock the safety device, raise the lever (8), which will automatically shift to the lock position.

To unlock the safety device, push the lever (8) downwards until engaging it in the check coupling.

IMPORTANT

- The movements of the equipment, the travel and the boom swing are locked when the safety device lever is in the lock position.



9 - RIGHT SAFETY DEVICE CONTROL LEVER (only on machines with canopy)

 **WARNING**

- Before leaving the operating position, lower the equipment to the ground and shift the safety device lever to the lock position.




The machine with canopy is provided with two levers for the control of the safety device and each one of them operates independently of the other, even if both have the same function.

To lock the safety device, raise the lever (9), which will automatically shift to the lock position.

To unlock the safety device, push the lever (9) downwards until engaging it in the check coupling.

 **IMPORTANT**

- The movements of the equipment, the travel and the boom swing are locked when the safety device lever is in the lock position.




10 - SPEED INCREASE PUSH BUTTON

This pedal makes it possible to increase the machine travel speed.

By pressing it, you increase the speed; by releasing it, you return to the normal speed.

 **IMPORTANT**

- Do not use the speed increase pedal when changing direction or performing a counter-rotation.



11 - OPTIONAL EQUIPMENT CONTROL PEDAL

 **WARNING**

- Always engage the safety lock (1) when it is not necessary to use this pedal, when the machine is travelling and when it must be parked.
If the control pedal is inadvertently pressed, this may cause serious accidents.



This pedal controls the delivery and return of the optional equipment oil, according to the movements indicated below.

N - Neutral (IDLE)

A - Left delivery

B - Right delivery

For the use of the pedal, see “6.1 AUTHORIZED OPTIONAL EQUIPMENT”.



12 - UPPER STRUCTURE ROTATION LOCKING LEVER



WARNING

- During travel and transport of the machine the rotation locking lever must be shifted to the lock position; shift the lever to the lock position after rotating the upper structure so that it is parallel to the undercarriage.
- During travel, make sure that the upper structure is directed towards the blade; if the upper structure is rotated by 180°, the controls are inverted.



When the lever is in the lock position, it prevents the rotation of the upper structure.

To release the upper structure from the mechanical constraint, raise the lever and set it to the unlock position.



IMPORTANT

- Do not rotate the upper structure when the lever is in the lock position.
-



3.4 FUSES AND RELAYS



👉 IMPORTANT

- When changing a fuse, make sure that the ignition key is in position «O».
- If the fuses are oxidized, corroded or do not fit perfectly in their seat, replace them only with new fuses having the same capacity.
- If the engine does not run when the ignition switch is turned to position (🔑) (START), check the main fuse and if necessary change it.

3.4.1 FUSES

The equipment fuses are grouped on a single base positioned on the left control box, while the main fuse is positioned inside the battery compartment.


3.4.1.1 EQUIPMENT FUSES



POSITION	COLOR	CAPACITY (A)	INVOLVED CIRCUIT
1	Green	30	Engine stop
2	Violet	3	Engine accosting alarm, start relay, instrument power supply
3	Light blue	15	Fan
4	Red	10	Arrangement for radio set installation
5	Brown	7.5	Revolving light, servocontrol solenoid valve
6	Red	10	Fuel pump, horn, TBG
7	Brown	7.5	Hammer solenoid valve
8	Brown	7.5	Outlet, cab
9	Brown	7.5	Alternator, speed increase solenoid valve
10	Brown	7.5	Engine stop solenoid
11	Brown	7.5	Working light

FUSES AND RELAYS

3.4.1.2 MAIN FUSE







RWA09020

POSITION	COLOR	CAPACITY (A)	INVOLVED CIRCUIT
1	—	60	System main fuse

3.4.2 RELAYS

The horn relay is positioned inside the right control box, under the dashboard, while the other relays are grouped on a single base positioned inside the left control box.



POSITION	DESCRIPTION
1	Horn relay
2	Engine acoustic alarm
3	Preheating warning light timer
4	Preheating relay
5	Solenoid excitation timer (start)
6	Solenoid excitation relay (start)
7	Safety relay

3.5 GUARDS AND DRIVER'S SEAT

3.5.1 ENGINE HOOD



WARNING



- Do not open the engine hood when the engine is running.
- Do not use the machine without engine hood and do not start the engine when the hood is open, unless this is expressly prescribed for certain maintenance operations.
- When carrying out an inspection or maintenance operation inside the engine hood, always engage the hood in the safety coupling in order to keep it open.
- Non-compliance with these rules may result in serious accidents.

OPENING THE HOOD

After releasing the lock, press the push button (1) and lift the engine hood (2); fix it in this position with the tie rod (3), making sure that it is engaged in the appropriate seat.

CLOSING THE HOOD

Remove the tie rod (3) and lock it in the appropriate retainer. Lower the hood slowly and push it downwards until it engages in the lock. Lock the hood.




3.5.2 CANOPY



WARNING

- The safety canopy is TOPS homologated in compliance with the ISO EN474.5 standard and with level 1 of the FOPS standard; if the canopy is subjected to an impact, or if the machine overturns, immediately contact your Komatsu Dealer, who will check the stiffness of the canopy and make sure that the operator's safety is guaranteed.




3.5.3 CAB



WARNING


- The cab is TOPS homologated in compliance with the ISO EN474.5 standard; if it is provided with an upper safety protection, it also complies with level 1 of the FOPS standard. If the cab is subjected to an impact, or if the machine overturns, immediately contact your Komatsu Dealer, who will check the stiffness of the cab and make sure that the operator's safety is guaranteed.



The cab is provided with total opening of the door, while the front upper windshield can be opened by positioning and fixing it under the cab roof. The lower windshield can be removed and can be opened partially by sliding the windows to the right side.


These solutions are particularly useful during the summer, since they ensure constant air circulation and therefore reduced stress for the operator.

The small tank (1) containing the detergent for the front windshield is positioned inside the cab; make sure that this tank is always filled with detergent





GUARDS AND DRIVER'S SEAT



- The cab door (2) is a sliding door and can be opened completely and kept open by the couplings (3). The coupling is automatic and takes place when the door (2) hits against the retainer (4). To release the door from the coupling (3), use the opening and closing handle (5).





- The front windshield (6) can be opened only after disengaging the couplings (7), by pulling and lifting the window. Open the windshield (6) by means of the opening handles (8), after disengaging the couplings (7). Move the windshield to the correct position: it will automatically fit in the upper locking seats. To close the windshield, repeat the opening procedure in the reverse order.



- With open front windshield, disengage the couplings (9) and remove the lower windshield (10). Position it behind the driver's seat and fasten it to the locking seats (11) by means of the couplings.



- The side windows (12) and (13) positioned on the right side of the cab can be opened by sliding them; press the handle (14) and pull it.



3.5.4 VENTILATION AND HEATING




The ventilation and heating of the cab serve to reduce the operator's stress either in the summer and in the winter; these functions also serve to eliminate the condensate from the front window, thus ensuring visibility during both work and travel.

Ventilation and air change are achieved by means of a 2-speed fan positioned inside the cab, under the seat support.

Air distribution is achieved by means of two fixed outlets (1) with adjustable capacity for the inner flow, while the flow that has the function to defrost and defog the front window is achieved by means of a fixed outlet (2) with adjustable capacity.

A radiator having the function to heat the air conveyed into the cab is installed beside the fan; it is used in the cold season and receives the hot water necessary for the heat exchange directly from the engine cooling circuit.

The water supply flow is divided or excluded by means of a tap (3) positioned inside the engine compartment.




3.5.5 SEAT

The seat can be adjusted as follows:

- a - Longitudinal position adjustment.
- b - Adjustment of the suspension degree, aimed at cushioning the inevitable vibrations and jerks as much as possible.

The seat is assembled on a unit that slides longitudinally and can be moved forward or backward together with the control levers, the dashboard and the cutout boxes. The operator can thus choose the driving position that is most suitable for his physique.

The longitudinal adjustment of the seat is obtained by operating the lever (1) and making the seat slide on the guides; once the desired position has been found, release the lever and carry out slight movements, in order to make sure that the lock pin is engaged in its seat.




The adjustment of the degree of suspension is carried out with the snap lever (2), according to the operator's weight.

The suspension can be stiffened or lightened according to the operator's needs; adjust the seat suspension with the lever (2) after rotating its knob to position (+) to stiffen the suspension or to the opposite position (-) to lighten it.

The seat is fixed to the sliding control unit and the whole can be shifted forward or backward for 80 mm and can be locked in 6 different positions.

The longitudinal shift of the whole control-seat unit is obtained by operating the lever (3) and making the unit slide on the guides; once the desired position has been found, release the lever and carry out slight movements, in order to make sure that the lock pin is engaged in its seat.




3.5.6 SAFETY BELT



WARNING

- Before starting the engine, fasten the safety belt.
- The safety belt must be changed if it is broken, damaged or worn, and in any case it must be changed every 4 years.

The safety belt (1) is of the type with two coupling points and adjustable length (2); it must be well tightened and hold the operator's hips, while leaving the upper part of the body completely free.



3.5.7 EMERGENCY EXIT



The machines with cab are provided with an emergency exit located in the rear window (1).

Inside the cab you will find a hammer (2) to be used to break the window (1) in case of emergency.



IMPORTANT

- Make sure that the hammer is always available and in the correct position inside the cab.




3.5.8 TECHNICAL DOCUMENTATION CASE



CAUTION

- The operation manual and the spare parts catalogue are integral parts of the machine and must accompany it even in case of resale.

The technical documentation case is positioned in the appropriate container (1) inside the seat support. Keep the use and maintenance manual in this place, so that you can consult it at any moment.




3.5.9 FIRE EXTINGUISHER



CAUTION

- The machine's owner must provide for installing and fixing the fire extinguisher where prescribed.
- Periodically check the fire extinguisher support.
- Periodically make sure that the fire extinguisher is full.

If the operator expects that he may need the fire extinguisher (1) on the machine, he must install it by fixing it on the rear compartment of the seat by means of the appropriate support.




3.5.10 FIRST AID KIT



CAUTION

- Periodically make sure that the first aid kit contains the necessary disinfectants, bandages, medicins, etc. and check their conditions and expiry date.

The first aid kit must be installed by the owner of the machine and positioned inside the seat support, where also the technical documentation is usually kept.



3.6 USE OF THE MACHINE

3.6.1 CHECKS BEFORE STARTING THE ENGINE

3.6.1.1 VISUAL CHECKS



WARNING

- **Dirt, oil and fuel in the engine compartment near its hot parts may damage the machine and even cause fires.**

Check frequently and eliminate any leakage; if leakages occur repeatedly, contact your Komatsu Dealer.

Before starting the engine, check around and under the machine to verify:

- 1 - if there are loose screws or nuts;
- 2 - if there are oil, fuel or coolant leakages;
- 3 - the wear of the work equipment;
- 4 - the fastening of the electrical connections;
- 5 - the fastening of the engine exhaust pipe and manifold;
- 6 - the track tension and the fastening of the sprockets;
- 7 - if the safety and warning plates are sufficiently clean;
- 8 - if the handles of the operator's cab are clean.

Any leak or anomaly must immediately be repaired/eliminated and any trace of oil or grease must be removed.

Further visual checks concern:

- 9 - the condition of the safety belt;
- 10 - the efficiency of the instruments and of the dashboard;
- 11 - the condition of the cab windows and the efficiency of the working lights.

3.6.1.2 DAILY CHECKS



WARNING

- **Do not smoke while refuelling or topping up the oils and do not use naked flames or non-homologated lighting means to check the fuel and oil levels, in order not to cause fires.**
 - **If fuel, oil, or lubricant are spilled while filling the tanks, clean the dirty areas immediately.**
-

Before starting any operation, check the engine coolant, engine oil and hydraulic circuit oil levels.

At the end of work, provide for refuelling, in order to avoid the formation of condensate, always checking the fuel level on the indicator provided on the dashboard.



IMPORTANT

- **Avoid filling the tank completely, in order to leave room for the gas oil to expand.**
 - **After refuelling, put back the filler cap, making sure that the bleed hole is completely open.**
 - **Check the engine oil level with the machine in horizontal position and the hydraulic circuit oil level with the arm and bucket cylinders retracted and the bucket teeth on the ground.**
-

3.6.1.3 OPERATIONAL CHECKS




WARNING

- All the checks must be carried out by the operator while seated, with fastened safety belt.
 - If the machine has been stopped after use or in order to carry out maintenance operations, the safety devices may have been disconnected; when the operator gets on the cab, he must make sure that all the safety locks of the equipment controls are in the correct position and therefore that the equipment cannot move suddenly and cause accidents.
-

The checks concern:

- 1 - the lock position of the safety device;
- 2 - the accelerator idling position;
- 3 - the neutral position of the controls.

The following check is carried out by turning the ignition key to position «I» to apply voltage to the control panel and check the functionality of the acoustic alarm, the fuel level indicator and the engine oil pressure, generator and preheating warning lights.



3.6.2 STARTING THE ENGINE



WARNING

- Before starting the engine, carefully read the instructions and information regarding safety given in this manual and make sure that you know the controls.
From the moment in which the engine is started, the operator is directly responsible for any damage that may be caused by wrong manoeuvres and non-compliance with the safety regulations and the rule of the road.
- Before starting the engine, make sure that there is no one within the operating radius of the machine and sound the horn.
- Before starting the engine, turn the ignition key to position «I» to operate the automatic check and make sure that the acoustic alarm and the warning lights are working correctly.


3.6.2.1 STARTING WITH WARM ENGINE OR IN TEMPERATE CLIMATES

- 1 - Pull the accelerator lever until reaching approximately half of its stroke and turn the ignition key directly to position «G» (START).
- 2 - As soon as the engine starts, release the ignition key, which will automatically return to position «I» and reduce the speed to idling.




IMPORTANT


- If the engine does not start within 15 seconds, release the key, which will automatically return to position «I» and wait for 15 seconds before trying again.



RWA06000



RWA01970






RWA01980

3.6.2.2 STARTING WITH COLD ENGINE OR IN COLD CLIMATES





! WARNING

- Do not use any fluid or product that facilitate the cold starting of the engine, since these are ether-based and may cause explosions.

- 1 - Pull the accelerator lever until reaching the end of its stroke and turn the ignition key to the preheating position «» the preheating warning light on the dashboard will come on. Keep the key in this position for not longer than 15 seconds in the coldest season. The preheating time is determined according to the outer temperature and the ratio is approximately 1 second per each degree below zero.
- 2- Turn the ignition key to position «» (START) until the engine starts and for maximum 15 seconds.
- 3 - As soon as the engine starts, release the ignition key, which will automatically return to position «» and reduce the speed to idling.

👉 IMPORTANT

- If the engine does not start at the first attempt, repeat the operations 1 and 2 after at least 30 seconds, in order not to overload the battery.



3.6.3 WARMING THE ENGINE

- 1 - After starting the engine, let it warm up before starting work.
- 2 - The ideal warming up of the engine is achieved with the engine running at idling speed, which is obtained with the hand accelerator.



IMPORTANT

- **Do not accelerate completely or abruptly until the coolant temperature has reached at least 60°C (140°F).**
-

- 3 - To reduce the time necessary to warm up the engine, accelerate now and then.
- 4 - During the warming up of the engine, check the colour of the exhaust gases and verify if abnormal noises or vibrations can be noticed; any anomaly must be verified and its cause must be eliminated.

3.6.4 HEATING THE HYDRAULIC OIL

When warming up the engine, especially in the cold season, it is advisable to heat also the hydraulic system oil. For this reason, when the coolant temperature has reached approximately 60°C, proceed as follows:

- 1 - Release the safety device of the controls (See “3.1 SAFETY LOCKS”).
- 2 - Slowly extend and retract the arm and the bucket completely for several times.
- 3 - Lower the bucket to the ground and lock the safety device again.

3.6.5 HOW TO MOVE THE MACHINE




WARNING

- **Before moving the machine, make sure that you know the control functions and all the relevant safety regulations perfectly.**
 - **Make sure that the upper structure is directed towards the blade and lock it in this position by means of the rotation lock.**
 - **The operator must be sitting in the driving position with fastened safety belt.**
 - **Before moving the machine, make sure that there is no one within the operating radius of the machine and that there are no obstacles in the surrounding area.**
 - **Be extremely careful when engaging the reverse and make sure that there are no persons, working means or obstacles in the way.**
 - **Avoid manoeuvres or changes of direction when travelling at full speed, since the manoeuvres carried out in these conditions cause abrupt movements.**
 - **Do not use the speed increase pedal when changing direction or carrying out a counter-rotation.**
-


USE OF THE MACHINE

Before moving the machine, check the instruments, warm up the engine and the hydraulic oil, make sure that the rotation lock is engaged, that the safety device is released, that the blade is raised and that the work equipment is at least at 40÷50 cm from the ground; the control levers must be in the neutral position.


- 1 - Pull the accelerator lever and set the engine running at idling speed.



- 2 - Operate the levers (right and left) at the same time, shifting them forward to make the machine advance or backward to make it move in reverse.



- 3 - Press the speed increase pedal to increase the speed of the machine.



3.6.5.1 STEERING (CHANGING DIRECTION)

! WARNING


- When the blade is directed backward, the operation of the travel levers is inverted; before operating the travel levers, check the position of the blade.
- If possible, avoid any abrupt change of direction. Counter-rotations should be carried out with the machine at rest.
- Due to the considerable friction created when changing direction, it is advisable not to use the speed increase pedal.

CHANGING DIRECTION WHEN THE MACHINE IS NOT MOVING

To turn to the left, operate the RIGHT travel lever as indicated below. To move FORWARD, push the lever. To move BACKWARD, pull the lever.

! IMPORTANT

- To turn to the right, operate the LEFT travel lever in the same way.




RWA07380

CHANGING DIRECTION WHEN THE MACHINE IS MOVING (the left and right travel levers are in the same position)

To turn to the left, shift the LEFT travel lever back to the neutral position; the machine will turn to the left.

! IMPORTANT

- To turn to the right, operate the RIGHT travel lever in the same way.




RWA07390

HOW TO CARRY OUT A COUNTER-ROTATION (with the machine not moving)

To turn to the left, pull the LEFT travel lever backward and push the RIGHT travel lever forward.

! IMPORTANT

- To carry out a counter-rotation to the right, pull the RIGHT travel lever backward and push the LEFT travel lever forward.



RWA07400

3.6.5.2 MOVING ON SLOPES





WARNING

- Do not work on slopes with inclination exceeding 30°, since in these conditions the machine may overturn.
- When moving on slopes, do not use the travel speed increase pedal.

When working on slopes some precautions should be taken to avoid risks for the operator and anyone in the vicinity; the checks and operations to be carried out are the following:

- 1 - Always check the work area for snow, landslips, gravel, loose ground and anything that may suddenly modify the work conditions and the stability of the machine.
- 2 - When it is necessary to travel downhill, the bucket must always be directed downwards, in the position indicated in the figure.
- 3 - When travelling uphill, the bucket must always be directed upward.
- 4 - When moving the machine during work, always lower the bucket.
- 5 - Carry out any lateral movement on a flat surface at the beginning or at the end of the slope; if this is not possible, move obliquely, keeping the machine axis as parallel to the slope directrix as possible.

Do not move too obliquely or, even worse, with the machine axis rotated by 90° with respect to the slope directrix.




3.6.5.3 MAXIMUM IMMERSION DEPTH



- If it is necessary to work with the machine immersed in water on river banks or sea shores, always check the water depth and the current flow.
 - Make sure that the surface on which you are working is sufficiently firm.
-

If it is necessary to work with the machine immersed in water, make sure that the maximum depth does not exceed half the height of the upper roller and in any case that the engine cooling fan does not touch the water, since it may get damaged or even break.




- When working in water or on muddy ground, lubricate the articulations more frequently than usual.
 - After work, remove any dirt or mud and lubricate the articulations.
-

3.7 PARKING THE MACHINE




3.7.1 PARKING ON LEVEL GROUND



- Park the machine on firm and level ground, in a sufficiently wide space, so that the checks, the daily lubrication and the refuelling can be carried out without problems.
- Lower the blade and the work equipment to the ground.
- Keep to all the safety rules, in order to avoid any movement of the machine when the operator is absent.
- When leaving the machine, remove the ignition key, use the handles and lock the cab, if provided.



- 1 - Park the machine on firm and level ground, in a sufficiently wide space.
- 2 - Lower the blade and the bucket to the ground; if there is not enough space, the work equipment must be folded and secured with the appropriate locks.
- 3 - Engage the safety lock of the boom swing control, of the optional equipment control and of the upper structure rotation and shift the safety device lever to the lock position.
- 4 - Stop the engine following the procedure indicated in paragraph "3.8 STOPPING THE ENGINE".
- 5 - Leave the driving position using the tracks and the handles.
- 6 - Refuel, taking the necessary precautions.
- 7 - Remove the ignition key and lock the cab, if provided.







3.7.2 PARKING ON SLOPES



- The movement of the machine when the operator is not on board may cause serious accidents and even death; to prevent this, carry out the operations described below.
- Park on slopes only when it is absolutely necessary.
- Park only with the bucket directed downwards.

- 1 - Park the machine with the bucket directed downwards and resting against an obstacle.
If this is not possible due to the absence of natural obstacles, rotate the bucket in the dumping position and thrust the teeth into the ground.
- 2 - Lower the blade to the ground.
- 3 - Engage the safety lock of the boom swing control, of the optional equipment control and of the upper structure rotation and shift the safety device lever to the lock position.
- 4 - Stop the engine following the procedure indicated in paragraph "3.8 STOPPING THE ENGINE".
- 5 - Leave the driving position using the tracks and the handles.
- 6 - Put wedges under the tracks.
- 7 - Refuel, taking the necessary precautions.
- 8 - Remove the ignition key and lock the cab, if provided.



3.8 STOPPING THE ENGINE



 **IMPORTANT**

- The sudden stop of the engine while it is running shortens its life. Do not stop the engine suddenly, except in case of emergency.
- It is likewise recommended not to stop the engine suddenly if it has been running for a long period and is still hot; in this case, let the engine idle for about 5 minutes, in order to allow it to cool down gradually before stopping it.

Before stopping the engine, proceed as follows:

- 1 - Rest the work equipment onto the ground.
- 2 - Shift the levers to the neutral position and connect the safety devices.
- 3 - Shift the accelerator lever to the idling position.

Stop the engine by turning the ignition key to position «O» (OFF).



3.9 TRANSPORTING THE MACHINE ON OTHER VEHICLES



3.9.1 LOADING AND UNLOADING THE MACHINE



WARNING

- The loading and unloading of the machine on/from the means of transport must be carried out on a flat surface and at a safety distance from the edges of ditches or from the road side.
- Block the means of transport by positioning wedges before and behind each wheel.
- Make sure that the ramps are sufficiently strong; if necessary, reinforce them with blocks, in order to prevent any dangerous bending.
- Make sure that the ramps have the same length, are firmly anchored to the motor vehicle, are parallel to each other and perpendicular to the loading board; the distance between the ramps must be suitable for the machine gauge.
- Position the ramps with a maximum inclination of 15°.
- Remove any trace of oil, grease or ice from the ramps and the loading board.
- Do not change direction when the machine is already on the ramps; if necessary, go down and find the correct direction.

- 1 - The machine must get on the ramps with the bucket (1) directed forward and raised from the ground.
- 2 - Once the machine has been loaded, rotate the upper structure by 180° and engage the antirotation lock, lower the blade (2) and the work equipment to the ground and shift the safety device lever to the lock position.
- 3 - Stop the engine and remove the ignition key.
- 4 - Keep the machine in position also by putting wedges (3) before and behind the tracks.
- 5 - Fix the machine with tie-downs or chains (4) in the anchorage points (6).
- 6 - Protect the end of the exhaust pipe (5).



3.9.2 TRANSPORT

- 1 - Check the overall dimensions; the height, width and weight of the means of transport - machine included - must be compatible with the road and any tunnel, subway, bridge, electric or telephone line that may be found on the way.
- 2 - Keep to the regulations in force regarding signals, speed limits, road traffic, authorizations, etc.

3.10 LIFTING THE MACHINE




DANGER

- To lift the machine, the cables and the upper lifting bar used must be properly sized; do not use worn cables or cables with broken strands.
- Do not lift the machine before the operator has got off and make sure that there is no one around before lifting it.

Lift the machine by proceeding as follows.

- 1 - Rotate the upper structure so that the blade is behind the operator and raise the blade completely. Extend the bucket, boom and arm cylinders completely and make sure that the control levers are in neutral.
- 2 - Swing the boom to the central position and engage the control pedal safety device.
- 3 - Shift the safety device lever to the lock position and stop the engine.
- 4 - Insert a metal or nylon rope in the two holes provided on the blade ends and in the boom hole. Fix the ropes with appropriate locks or safety pins.
- 5 - Connect the ropes to the upper lifting bar as indicated in the figure.



IMPORTANT

- Always use the three coupling points provided for the lifting operations.
- 6 - Lift the machine slowly until the ropes are stretched and make sure that the fastenings are correct before lifting the machine definitively.



CAUTION

- When lifting the machine, make sure that it is correctly balanced and that it remains in horizontal position during the lifting operations.
- Do not lift the machine with swung boom or without using the lifting bar.

3.11 PRECAUTIONS TO BE TAKEN IN THE COLD SEASON

During the cold season or in areas where the temperature is particularly low, especially during the night, it is necessary to take some countermeasures meant to limit the damage deriving from low temperatures.

3.11.1 FUEL AND LUBRICANTS

- 1 - Change the fuel and use the winter fuel ASTM D975 N. 1. When ambient temperature is below -10°C (14°F).
- 2 - Change the engine oil with an oil with suitable viscosity.
For the relevant specifications, see "4.3 FUEL, COOLANT AND LUBRICANTS".

3.11.2 COOLANT



WARNING

- **The coolant containing antifreeze is flammable; do not smoke and do not use naked flames during the checks and when preparing the mixture.**
 - **Do not use methanol-, ethanol- or propanol-based antifreezes.**
-

- 1 - If no permanent antifreeze is available, use an antifreeze mixture made of ethylene glycol added to anticorrosion and antifoam products.
Use this mixture only during the winter and when changing the coolant (in autumn or spring) wash the cooling circuit (see "4.7.8 WHEN REQUIRED").
- 2 - When it is necessary to calculate the antifreeze-water ratio, refer to the lowest temperature measured in the past and consider a temperature 10° C (18°F) lower than that. (See "4.2.1.2 COOLANT").
- 3 - Do not use plugging additives, either alone or added to the antifreeze, to eliminate leakages.
- 4 - Do not mix antifreezes of different brands.
- 5 - If a permanent antifreeze is used during the year, it is not necessary to change it and to wash the circuit.
- 6 - The required standards for the permanent antifreeze are SAE-J1034 and FEDERAL STANDARD O-A-548D.
In case of doubt regarding the compliance of the antifreeze used with the standards, contact the manufacturer and ask for precise information.

3.11.3 BATTERY



WARNING

- **To avoid explosions due to the presence of gas, do not provoke sparks and do not use naked flames near the battery.**
 - **The battery electrolyte is dangerous. If it comes in contact with the eyes or the skin, immediately rinse with plenty of water and consult a doctor without delay.**
-

- 1 - When the ambient temperature decreases, the battery capacity decreases accordingly and, if the battery charge is low, the electrolyte may freeze.
Keep the battery completely charged and insulate it to protect it against low temperatures, so that the machine can be started without problems the following day.
- 2 - Measure the specific weight of the fluid and check the battery charge percentage, making reference to the following table:

CHARGE PERCENTAGE	FLUID TEMPERATURE			
	20°C (68°F)	0°C (32°F)	-10°C (14°F)	-20°C (-4°F)
100%	1.28	1.29	1.30	1.31
90%	1.26	1.27	1.28	1.29
80%	1.24	1.25	1.26	1.27
75%	1.23	1.24	1.25	1.26

- 3 - When the electrolyte level is low, add distilled water before starting work, rather than after work, in order to prevent the fluid from freezing during the night.

3.11.4 OTHER PRECAUTIONS

- 1 - Before using the machine in normal operating conditions, carry out some slow movements either forward and in reverse, and operate all the work equipment cylinders slowly more than once.
These operations serve to warm up and fluidize the oil in the hydraulic circuit and the reduction gears.

3.11.5 PRECAUTIONS TO BE TAKEN AT THE END OF WORK

- 1 - Completely remove mud and water from the machine body.
Park the machine on firm ground; if the machine must be parked near banks or ditches, park it on wooden boards in order to distribute the weight of the machine on a larger surface.
- 2 - Be careful to water drops forming on the hydraulic cylinder rods: these drops must be completely removed, since if they freeze the cylinder gaskets may be damaged.
After removing the water drops, protect the rods with oil.
- 3 - Drain the condensate that may have formed in the tank, to prevent the water from freezing during the night.
- 4 - Since the battery capacity may decrease considerably at low temperatures, after work cover the battery or remove it and store it at a suitable temperature.

3.12 PRECAUTIONS TO BE TAKEN IN THE WARM SEASON

1 - At the end of the cold season, change the lubricants, the coolant and the fuel.



IMPORTANT

- **The coolant must be changed only if it is not permanent.**
For the relevant specifications, see “4.3 FUEL, COOLANT AND LUBRICANTS”.
-

2 - Make sure that the cooling fan belt is in good conditions.

3 - Make sure that the fins of the radiator and of the heat exchanger are clean.

4 - Check the radiator cap gasket and spring; in case of doubt regarding tightness and setting, change the cap.

3.13 USING THE WORK EQUIPMENT



WARNING

- Always fasten the safety belt before any manoeuvre.
 - Before starting work, warn the persons in the vicinity by means of the horn positioned on the right lever.
 - If due to a sudden failure the machine stops with raised equipment, turn the ignition key to position «I», release the safety device, gradually operate the boom lowering control lever until the bucket rests on the ground and release any residual pressure.
-



IMPORTANT

- The basic illustrations shown are those necessary for a correct use and exploitation of the machine; the operator must get to know the controls, the described operating method and learn how to organize work in a free area while seated in the driving position.
-

3.13.1 ORGANIZING THE WORK AREA

If after a first inspection the area results to be uneven, encumbered with big obstacles or characterized by considerable height differences, it is advisable to level the ground as much as possible before starting work, both for the machine and for the vehicles to be loaded.

These preliminary operations will make work quicker, ensure better results and at the same time reduce the operator's stress and the straining of the machine components; furthermore, this will considerably reduce the time necessary to carry out the excavation or to load the trucks destined to the transport of the material.

3.13.2 POSITIONING THE MACHINE FOR DIGGING OPERATIONS

WARNING




- Before moving the equipment, make sure that no one is standing in the work area.
- Carry out all the possible movements and make sure that the control levers work properly.
- If visibility is not perfect or there are ducts or lines of any kind, work at reduced speed and ask the assistance of another operator.

1 - Center the machine with respect to the digging line.

IMPORTANT

- If this is not possible, because it is necessary to dig along walls or banks, swing the boom sideways and position the machine beside the point where the excavation must be carried out.

- 2 - Release the boom swing from the safety lock (1) and release the upper structure rotation by lifting the antirotation pin (2).
- 3 - Fasten the safety belt and accelerate until reaching a medium speed.
- 4 - Shift the safety device lever (3) to the release position and start work.




3.13.3 DIGGING METHOD




WARNING

- The geometry of the rotation fulcrum of the arms and the bucket make it possible to dig even beyond the stabilizer line, which makes the ground give way. Do not dig beyond the boom fulcrum line, since the ground may collapse and cause the machine to overturn.


- 1 - At the beginning of work, keep the bucket at the correct penetration angle.
- 2 - Once the desired digging depth has been reached, position the bucket with its back parallel to bottom of the excavation and then start filling.
- 3 - During the collection phase, make the bucket, the boom and the arm move simultaneously; combined movements facilitate the filling of the bucket and therefore increase productivity.
- 4 - The removal depth must be correct and suitable for the type of ground; excessive depth may lock the movements, overload the engine and the pump and slow down the digging operations.
- 5 - To dump on heaps, dump the bucket as soon as it gets near the dumping area; the inertia resulting from the movement will ensure the compaction of the material with no need to use the bucket for this purpose, which avoids impacts and vibrations that facilitate the wear of pins and bushings.




CORRECT
The bucket works with its flat surface parallel to the ground.



INCORRECT
The bucket is thrust downwards, slowing down the digging work.



INCORRECT
The bucket is pushed upwards and therefore is not filled completely.



CORRECT DIGGING METHOD
(Sequence 1 - 2 - 3)

3.13.4 CHANGING THE BUCKET


 **WARNING**

- When the coupling pins are removed or installed, chips may come off; always use gloves, goggles and helmet.
- The change of the equipment must be carried out by two persons, who must decide together the words and signals to use during operations.
- Do not use your fingers to center the holes, since they may be injured or even cut in case of sudden or uncontrolled movements.
- The described procedures are valid also for the coupling of the mechanical constraints of the optional equipment.

-
- 1 - Position the bucket on a level surface, directing it so that the flat part of its back rests on the ground.
 - 2 - Remove the tie rod pin (1) and the arm connection pin (2).
 - 3 - Change the bucket, taking care to clean the pins, the bushings and the seals perfectly and to grease the pins slightly before reinstalling them.

 **IMPORTANT**

- Install first the arm connection pin, making sure that the seals are in good conditions.
-
- 4 - Put back all the safety pins (3) and lubricate by means of the appropriate grease nipple.




3.14 LONG PERIODS OF INACTIVITY

3.14.1 BEFORE THE PERIOD OF INACTIVITY



WARNING

- When draining the fuel, do not smoke or bring naked flames near the machine.
Place a container under the machine to gather the fuel and prevent it from spreading around.
If some fuel is spilt, clean the dirty surface immediately.



IMPORTANT

- To protect the cylinder rods when the machine is not used, position the work equipment as shown in the figure. (This serves to prevent the cylinder rods from rusting).

If the machine must be stored for a long period of inactivity, it is advisable to put it in a sheltered place and to take the following precautions, in order to keep all its components sound and efficient:

- 1 - Clean the machine thoroughly, repainting it where necessary in order to prevent oxidation.
- 2 - Drain and change all the fluids of the hydraulic circuits and the lubricants (engine and reduction gears), following the maintenance rules.
- 3 - Change all the filtering elements (air cleaner, engine oil filter, hydraulic circuit filters, diesel oil filter).
- 4 - Drain the coolant and replace it with a corrosion inhibitor (permanent fluid).
- 5 - Drain the normal fuel and fill the tank with at least 5 liters of special washing and protecting fuel.
- 6 - Let the engine run for about 10 minutes, in such a way as to eliminate the residual normal fuel from the filters, the injection pump and the entire fuel supply system. This operation avoids the locking of the injection pump and the injectors.
Stop the engine and refuel with normal diesel oil.
- 7 - Remove the battery, check the electrolyte level and make sure that the battery charge is sufficient.
Store the battery in a room with suitable temperature and periodically recharge it.
- 8 - Grease the hydraulic cylinder rods and the equipment joints.
- 9 - Seal the end of the exhaust pipe and the fuel tank cap.
- 10 - Move the machine controls to the neutral position and engage all the safety locks.
- 11 - Hang a warning notice on the controls to indicate the condition of the machine.
- 12 - Lock the fuel tank cap, the engine hood and, if provided, the cab door.

3.14.2 DURING THE PERIOD OF INACTIVITY



WARNING

- **If it is necessary to carry out a rust-prevention treatment while the machine is kept indoors, open doors and windows to increase ventilation and avoid poisoning by gas.**
-

Start the engine and move the machine for a short distance once a month, so that a new oil film covers all the moving parts and the surfaces of the components. Provide also for charging the battery.

3.14.3 AFTER THE PERIOD OF INACTIVITY



IMPORTANT

- **If the machine is stored without carrying out the monthly rust-prevention treatment, have maintenance performed by your Komatsu Dealer.**
-

When using the machine after a long period of inactivity, proceed as follows.


- 1 - Release the exhaust pipe and the fuel tank from the seals.
- 2 - Check all the levels (engine oil, coolant, fuel, hydraulic circuit oil).
- 3 - Make sure that the battery is charged and install it on the machine.
- 4 - Start the engine and let it idle for about 20 minutes.
- 5 - While the engine is warming up, remove the protection grease from the hydraulic cylinder rods.
- 6 - Before moving the machine, make sure that the instruments, warning lights and working lights operate correctly.
- 7 - Warm the hydraulic cylinders as soon as possible, by slowly moving all the equipment.

3.15 TROUBLESHOOTING


3.15.1 OCCURRENCES THAT ARE NOT FAILURES

The following occurrences are not failures:

- 1 - When the boom is retracted, the movement speed decreases temporarily, according to the position of the boom (more or less vertical).
- 2 - The boom speed decreases temporarily according to the position of the bucket teeth (more or less horizontal).
- 3 - When travelling down a steep slope at low speed, a noise coming from the travel motor may be heard.



RWA06050



RWA06060


3.15.2 HOW TO REMOVE THE MACHINE



- **When removing the machine, use a wire rope suitable for the weight of the machine to be removed.**

If the machine gets stuck in mud and cannot get out using only its motive power, or in case of breakdown, use a wire rope as shown in the figure on the right.

Place wooden blocks between the wire rope and the machine body, in order to avoid damaging the rope and the machine.



RWA05390

3.15.3 AFTER THE FUEL HAS RUN OUT





Before starting the engine, when the fuel has run out and therefore air has entered the fuel supply circuit, it is necessary to bleed the fuel supply circuit.

For the necessary operations, see "4.7.5 MAINTENANCE EVERY 500 HOURS OF OPERATION".

3.15.4 IF THE BATTERY IS DOWN



- When checking or carrying out any operation on the battery, stop the engine and make sure that the ignition key is in position «O».
- The battery produces hydrogen, which may explode. Do not use naked flames and do not smoke near the battery, and avoid producing sparks.
- The battery electrolyte is made of diluted sulphuric acid that may corrode the clothes and even the skin; in case of contact with this fluid, immediately rinse the involved part with plenty of water.
If the acid gets into the eyes, immediately rinse with plenty of water and consult a doctor without delay.
- When working on the battery, always wear goggles and gloves.
- When removing the battery, disconnect first the earth cable (-); when installing the battery, connect first the positive cable (+).
- If a tool comes into contact with the positive terminal and with the machine structure at the same time, this may generate sparks with consequent risk of explosion.
- Carefully tighten the connection terminals, since false contacts may generate sparks with consequent risk of explosion.



3.15.4.1 STARTING WITH BOOSTER CABLES



WARNING

- When starting the engine with the aid of another machine, connect the batteries in parallel.
- When connecting the cables, avoid any contact between the positive cable (+) and the negative cable (-).
- When starting the engine with booster cables, always wear safety goggles.
- Take care to avoid any contact between the machine to be started and the machine used as starting aid, in order to avoid sparks and therefore the explosion of the hydrogen produced by the batteries. The explosion of the battery causes serious damage and injuries.
- Take care not to invert the cables and connect the earth cable (-) last, as far from the battery as possible.
- Remove the cables with great care; prevent the cables disconnected from the battery from touching other parts of the machine, in order to avoid the explosion of the hydrogen.




IMPORTANT

- The cables and pliers must be suitable for the current load that must be transferred.
- The battery to be used for the starting must have greater capacity or at least the same capacity as the battery of the machine to be started.
- Make sure that the cables and pliers are neither corroded, nor damaged.
- Make sure that the pliers hold the terminals firmly.

CONNECTING THE CABLES AND STARTING THE ENGINE


- 1 - Make sure that the ignition key is in position «O».
- 2 - Connect the positive poles (+) of the two batteries with each other (A).
- 3 - Connect the cable of the negative terminal (-) of the charged battery to the earth block of the machine to be started (B).
- 4 - Start the engine of the machine that supplies current and increase its speed.
- 5 - Start the engine of the machine that does not work. (See "3.6.2 STARTING THE ENGINE").



REMOVING THE CABLES

When the engine has started, remove the cables in the reverse order with respect to their connection.

- 1 - Disconnect the negative cable (-) from the earth block of the engine that has been started and then from the battery (B).
- 2 - Disconnect the positive cable (+) first from the battery used for the starting and then from the exhausted battery (A).



3.15.5 OTHER TROUBLES

(●): Always contact your Komatsu Dealer when you have to carry out this operation.

- : If the anomaly or its cause are not included in the failures indicated below, contact your Komatsu Dealer for the necessary repair.

3.15.5.1 ELECTRICAL CIRCUIT

TROUBLE	CAUSE	REMEDY
Lights do not work satisfactorily even with engine running at high speed:	<ul style="list-style-type: none"> • Faulty cables. • Faulty fan belt tension. 	<ul style="list-style-type: none"> (●) Check and repair any loose terminal and connection. • Adjust fan tension (see “EVERY 250 HOURS”).
Lights come on intermittently with engine running:		
Alternator charge warning light does not go out with engine running and increasing speed:	<ul style="list-style-type: none"> • Faulty alternator. • Faulty cables. 	<ul style="list-style-type: none"> (●) Change. (●) Check and repair.
Alternator emits an abnormal noise:	<ul style="list-style-type: none"> • Faulty alternator. 	<ul style="list-style-type: none"> (●) Change.
Starter does not turn with key in START position:	<ul style="list-style-type: none"> • Faulty cables. • Battery charge insufficient. • Faulty main fuse. 	<ul style="list-style-type: none"> (●) Check and repair. • Charge battery. • Change.
Starter pinion engages and then disengages:	<ul style="list-style-type: none"> • Battery charge insufficient. 	<ul style="list-style-type: none"> • Charge battery.
Starter makes engine run slowly:	<ul style="list-style-type: none"> • Battery charge insufficient. • Faulty starter. 	<ul style="list-style-type: none"> • Charge battery. (●) Change.
Starter disengages before engine has started:	<ul style="list-style-type: none"> • Faulty cables. • Battery charge insufficient. 	<ul style="list-style-type: none"> (●) Check and repair. • Charge battery.
Engine oil pressure warning light does not come on when engine is stopped (ignition key in position «I»):	<ul style="list-style-type: none"> • Faulty bulb. • Faulty pressure sensor. 	<ul style="list-style-type: none"> (●) Change. (●) Change.
Alternator charge warning light does not come on when engine is stopped (ignition key in position «I»):	<ul style="list-style-type: none"> • Faulty bulb. • Faulty cables. 	<ul style="list-style-type: none"> (●) Change. (●) Check and repair.

3.15.5.2 HYDRAULIC SYSTEM

TROUBLE	CAUSE	REMEDY
Pump emits an abnormal noise:	<ul style="list-style-type: none"> • No oil in the tank. • Faulty pump. • Hydraulic oil unsuitable for the temperature. 	<ul style="list-style-type: none"> • Top up. (●) Repair or change. • Change.
Equipment control levers do not return automatically to neutral position:	<ul style="list-style-type: none"> • Broken return spring or seized element. 	<ul style="list-style-type: none"> (●) Change spring or distributor element.
Equipment moves only at low speed:	<ul style="list-style-type: none"> • Faulty pump. • Max. pressure valve setting incorrect, or valves not closed due to impurities. • Dirty drain filter. 	<ul style="list-style-type: none"> (●) Repair or change. (●) Set or change. • Change.

3.15.5.3 ENGINE

TROUBLE	CAUSE	REMEDY
Oil pressure warning light remains on even with engine at high speed:	<ul style="list-style-type: none"> • Oil level in oil pan too low. • Oil filter clogged. • Oil unsuitable for the season. 	<ul style="list-style-type: none"> • Top up. • Change filter. • Change.
<p>Steam comes out of radiator breather pipe:</p> <p>Engine coolant temperature indicator enters the red overheating field:</p>	<ul style="list-style-type: none"> • Fluid level low, fluid leakages. • Fan belt slackened. • Mud or limestone accumulated in cooling system. • Radiator fins damaged or closed. • Faulty thermostat. • Radiator cap loose or broken. Working at considerable altitude. 	<ul style="list-style-type: none"> • Top up, repair. • Check belt tension. • Change fluid and clean cooling system. • Repair or clean. (•) Change. • Tighten cap or change unit.
Engine coolant temperature indicator always on the right end of the scale:	<ul style="list-style-type: none"> • Faulty instrument. 	(•) Change.
Engine coolant temperature indicator always on the left end of the scale:	<ul style="list-style-type: none"> • Faulty thermostat. • Faulty instrument. 	<ul style="list-style-type: none"> (•) Change. (•) Change.
Engine does not start with starter running:	<ul style="list-style-type: none"> • No fuel. • Air in fuel system. • Compression defect (valves with wrong clearance). 	<ul style="list-style-type: none"> • Refuel. • Bleed system. (•) Adjust valve clearance.
Exhaust gases white or light blue:	<ul style="list-style-type: none"> • Too much oil in oil pan. • Unsuitable fuel. 	<ul style="list-style-type: none"> • Correct oil level. • Change with suitable fuel.
Exhaust gases occasionally tend to be black:	<ul style="list-style-type: none"> • Air cleaner clogged. • Faulty injectors. • Faulty compression. 	<ul style="list-style-type: none"> • Clean or change. (•) Change. (•) Adjust valve clearance.
Combustion noise occasionally resembles a blow:	<ul style="list-style-type: none"> • Faulty injectors. 	(•) Change.
Abnormal noises (during combustion or in mechanical parts):	<ul style="list-style-type: none"> • Fuel with low cetane rating. • Overheating. • Exhaust silencer inside damaged. • Excessive valve clearance. 	<ul style="list-style-type: none"> • Change with fuel in compliance with standards. • See “defects of temperature indicator”. (•) Change. (•) Adjust valve clearance.

PAGE INTENTIONALLY LEFT BLANK

MAINTENANCE

4.1 GUIDE TO MAINTENANCE

- Before opening the engine hood, engage all the safety locks and stop the engine.
- If it is necessary to check the oil level in the hydraulic tank, retract the bucket and arm cylinders completely and lower the bucket teeth to the ground.
- Carry out any operation on firm and level ground.
- Use Komatsu genuine oils and greases; choose oils suitable for the ambient temperature.
- Use clean oils and greases. Keep the oil and grease containers clean. Keep any foreign matter away from oils and greases.
- Always keep the machine clean. This makes it easier to find out any part causing troubles. In particular, keep the grease nipples, the breathers and the areas near the openings for the level checks clean and prevent any impurities from getting into/on them.
- Draining hot oil or coolant immediately after stopping the engine is hazardous. Wait for the engine to cool down until reaching at least 40-50° C (104-122°F).
- When changing the oils or the filters, check if metal particles are present. If you find large quantities of metal particles, contact your Komatsu Dealer.
- Check and change the oil in a clean place and prevent any impurities from getting into the tank.
- Before carrying out any maintenance operation, hang the warning plates on the ignition switch, the control levers and the cab door, if the machine is provided with cab, in order to prevent anyone from starting the engine by mistake.
- When performing maintenance operations, always take the precautions indicated on the safety plates applied onto the machine.
- Instructions for arc welding.
 - 1 - Turn the ignition key to position «O».
 - 2 - Disconnect the battery (first the negative pole and then the positive pole).
 - 3 - Disconnect the alternator.
 - 4 - Do not apply more than 200V continuously.
 - 5 - Connect the earth cable within 1 m from the point in which the welding must be carried out.
 - 6 - Avoid placing gaskets and bearings between the welding area and the earth cable.
- Do not use flammable fluids to clean the machine parts. Keep naked flames or lit cigarettes away from these fluids.
- When O-rings and gaskets are removed, clean the sealing surfaces thoroughly and replace the O-rings and gaskets with new ones. Fit the O-rings and gaskets correctly when reassembling.
- Avoid keeping loose objects or tools in your pockets: they may fall out and drop into the machine, especially when you open covers and work on the machine while bending over it.
- When washing the machine, do not direct the high-pressure water jet onto the radiator and the heat exchanger.
- When washing the machine, protect the electric system connectors and avoid wetting the ignition switch.
- Before starting work in mud, under the rain, on seashores or river banks, carry out a general lubrication. Wash the machine immediately after work to protect the components from rust. Lubricate the equipment joints more frequently than usual.
- When working at dusty work sites, proceed as follows:
 - 1 - Check the air cleaner for any clogging and clean it more frequently than usual.
 - 2 - Clean the radiator and the heat exchanger frequently, to avoid any clogging of the fins.
 - 3 - Change the diesel oil filter more frequently than usual.
 - 4 - Clean the electrical components, especially the starter and the alternator, to avoid any accumulation of dust.

- Never mix oils of different brands.
Do not top up with any oil different from the oil used in the machine. If necessary, drain all the oil and fill the tank with the oil of the new brand.

**WARNING**

- **Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the regulations in force.**
 - **The combustible material of some components may become extremely dangerous if it burns. For this reason, avoid any contact of burnt material with your skin or eyes and do not inhale the fumes.**
-

4.2 MAINTENANCE NOTES

- Use only Komatsu genuine spare parts.
- Do not mix different types of oil.
- Unless specified otherwise, the oils and the coolant used by Komatsu to fill the tanks before the delivery of the machine are the following:

ITEM	SPECIFICATIONS
• Engine oil	SAE 15W-30 API classification CD
• Hydraulic system oil	SAE 10W API classification CD
• Travel reduction gear oil	SAE 10W API classification CD
• Swing reduction gear oil	SAE 10W API classification CD
• Fuel	Ambient temperature above -10°C (14°F). ASTM D975 no. 2 diesel oil
	Ambient temperature below -10°C (14°F). ASTM D975 no. 1 diesel oil
• Radiator	Permanent, ethylene glycol-based antifreeze, with corrosion inhibitor for protection up to -36°C (-33°F)

4.2.1 NOTES REGARDING THE ENGINE

4.2.1.1 ENGINE OIL

- The engine oil must be selected very carefully, since it lubricates the engine, which is the machine's heart; the main maintenance operations required for the engine oil are the following:
 - 1 - daily check of the oil level;
 - 2 - check of the oil pollution degree;
 - 3 - periodical change.

4.2.1.2 COOLANT

- The coolant serves to keep the engine at the correct temperature and therefore to ensure optimal operating conditions; check the coolant level in the expansion tank daily and top up if necessary.
- The coolant containing antifreeze is flammable; do not use naked flames near the coolant and do not smoke while topping up.

- The quantity of antifreeze to be added to the coolant depends on the minimum temperatures in the place where the machine is used. Keep to the following reference table:

QUANTITY OF ANTIFREEZE TO BE ADDED TO THE WATER

Minimum ambient temperature		(°C)	-4	-6	-9	-12	-16	-20	-26	-32	-36
		(°F)	24.8	21.2	15.8	10.4	3.2	-4	-14.8	-25.6	-32.8
Quantity of antifreeze	PC35R	(l)	0.68	1.02	1.36	1.7	2.04	2.38	2.72	3.06	3.4
		(US gal)	0.18	0.27	0.36	0.45	0.54	0.63	0.72	0.81	0.90
	PC45R	(l)	0.75	1.12	1.5	1.87	2.25	2.62	3	3.37	3.75
		(US gal)	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
Quantity of water	PC35R	(l)	6.12	5.78	5.44	5.1	4.76	4.42	4.08	3.74	3.4
		(US gal)	1.61	1.52	1.43	1.34	1.25	1.16	1.07	0.98	0.90
	PC45R	(l)	6.75	6.38	6	5.63	5.25	4.88	4.5	4.13	3.75
		(US gal)	1.78	1.68	1.58	1.48	1.38	1.28	1.18	1.09	1

- Use drinkable water and in any case soft water.
- Do not use corrosion inhibitors containing soluble oil, since they damage the rubber couplings.
- In case of doubt, contact your Komatsu Dealer.

4.2.1.3 FUEL

- Always use fuel suitable for the engine. Other fuels with different specifications may damage the engine or reduce its power.
- Always refuel at the end of the work day.
- When refuelling, make sure that there is no water on the fuel drum cover and take care not to draw the condensate from the drum bottom.
- If fuel runs out, or if the fuel filter has been replaced, it is necessary to bleed the circuit.

4.2.2 NOTES REGARDING THE HYDRAULIC SYSTEM

- Be extremely careful when performing maintenance operations on the hydraulic system, since soon after work the oil is very hot.
The circuit is pressurized not only during work, but also at the end of work.
- The maintenance operations required for the hydraulic system are the following:
 - 1 - daily check of the oil level in the tank;
 - 2 - periodical change of the oil filter;
 - 3 - periodical change of the oil.
- Always bleed the circuit after changing the oil filter or the oil.
- When a component is removed from the circuit, check the gaskets and O-rings and change them if they are damaged.
- When a cylinder or a component of the hydraulic circuit is removed, after reassembly bleed the circuit by proceeding as follows:
 - 1 - start the engine and let it idle;
 - 2 - make all the cylinders perform 4-5 movements, stopping them at approx. 100 mm (4 in) from the end of their stroke;
 - 3 - slowly make all the cylinders reach the end of their stroke for 3-4 times.

4.2.3 NOTES REGARDING THE ELECTRICAL SYSTEM

- If the cables are wet or their insulating material is damaged, the electrical system leaks and this may result in malfunctions of the machine.
- The maintenance operations required for the electrical system are the following:
 - 1 - check of the alternator belt tension;
 - 2 - check of the alternator belt for damage or breakages;
 - 3 - check of the battery electrolyte level.
- Do not remove or eliminate any electric component installed on the machine and do not install any electric component with characteristics different from those specified and approved by Komatsu.
- Be careful to keep the electric system dry.
- When working on seashores or river or lake banks, protect the jack plugs from corrosion.
- Do not connect any optional device to the fuses, ignition switch, battery, relays, etc.; for the installation of any optional equipment, contact your Komatsu Dealer.
- If any electric welding operation has to be carried out, disconnect the battery and the alternator.

4.2.4 NOTES REGARDING LUBRICATION

- Lubrication makes the operations carried out with the machine and work equipment smoother, while preventing wear and the noise that may be produced if the articulations are dry. Lubrication is to be carried out with grease or oil.
- The maintenance operations required for the components that need lubricating are the following:
 - 1 - check of the levels;
 - 2 - oil change;
 - 3 - injection of grease through the grease nipples.
- Use only the specified lubricants, according to the ambient temperature.
- Always clean the grease nipples before injecting grease and remove any excess grease after lubrication; this cleaning operation must be performed with extreme care on the revolving parts.
- Keep the lubricants at the correct levels; excessive or insufficient quantities are to be avoided.

4.2.5 PARTS SUBJECT TO WEAR THAT PERIODICALLY NEED CHANGING

The parts subject to wear such as filters, bucket teeth, etc. must be replaced according to the periodic maintenance intervals prescribed or when they reach the wear limit.

The timely change of these parts ensures an economic use of the machine.

Use only Komatsu kgenuine parts, which alone can guarantee excellent quality and interchangeability.

ITEM	DESCRIPTION	Q.TY	CHANGE INTERVAL
Hydraulic oil filter	Cartridge	1	EVERY 500 HOURS
Engine oil filter	Cartridge	1	EVERY 500 HOURS
Fuel filter	Cartridge	1	EVERY 500 HOURS
Fuel pump precleaner	Filter	1	EVERY 500 HOURS
Air cleaner	Cartridge	1	WHEN NEEDED
Bucket	Tooth	AR	—
	Screw	AR	—
	Nut	AR	—

4.3 FUEL, COOLANT AND LUBRICANTS

PROPER SELECTION ACCORDING TO THE AMBIENT TEMPERATURE

RESER-VOIR	FLUID	AMBIENT TEMPERATURE										CAPACITY		
		-30	-20	-10	0	10	20	30	40	50°C		1 st filling	Change	
		-22	-4	14	32	50	68	86	104	122°F				
Engine oil pan	OIL API CD	SAE 10W										PC35R	6.9 l (1.8 US gal)	6.9 l (1.8 US gal)
		SAE 20W-20												
		SAE 30												
		SAE 40										PC45R	8 l (2.1 US gal)	8 l (2.1 US gal)
		SAE 10W-30												
		SAE 15W-30												
SAE 15W-40														
Hydraulic system	OIL API CD	SAE 10W											63 l (16.6 US gal)	33 l (8.7 US gal)
Travel reduction gears (ea.)	OIL API CD	SAE 10W										PC35R	1 l (0.26 US gal)	1 l (0.26 US gal)
												PC45R	1.3 l (0.34 US gal)	1.3 l (0.34 US gal)
Fuel tank	DIESEL OIL	*											52 l (13.7 US gal)	—
		ASTM D975 N. 2												
Engine cooling system	WATER + ANTI-FREEZE											PC35R	6.8 l (1.8 US gal)	—
												PC45R	7.5 l (1.98 US gal)	—
	WATER											PC35R	6.8 l (1.8 US gal)	—
												PC45R	7.5 l (1.98 US gal)	—
	PERMANENT COOLANT											PC35R	6.8 l (1.8 US gal)	—
												PC45R	7.5 l (1.98 US gal)	—

* ASTM D975 N.1

LUBRICATION WITH GREASE

LUBRICATION POINTS	CONSISTENCY	TYPE
Articulations, ball-bearing ring, ball-bearing ring pinion	NLGI 2	(see Note 1)

Note (1):

The recommended lubricating grease is No.2 multi-purpose lithium grease with 3% molybdenum disulfide (Lithio EP + MoS₂).



IMPORTANT

- When the diesel oil sulphur content is less than 0.5%, change the engine oil according to the periodic maintenance intervals indicated in the operation and maintenance manual. If the diesel oil sulphur content exceeds 0.5%, change the engine oil according to the following table:

Sulphur content	Engine oil change interval
from 0.5 to 1.0%	1/2 of regular interval
over 1.0%	1/4 of regular interval

- When starting the engine at temperatures below 0°C (32°F), use engine oil SAE 10W, 20W-20, 10W-30 and 15W-30 even if during the day the temperature increases by 10°C (18°F).
- Use engine oil with CD classification; if oil with CC classification is used, reduce the engine oil change interval by a half.
- Use Komatsu genuine products whose characteristics have been specifically formulated and approved for use in the engine, in the work equipment hydraulic circuit and in the reduction gears.

First filling quantity: total quantity of oil, including the oil for the components and pipes.

Oil change quantity: quantity of oil necessary to fill the system or unit during the normal inspection and maintenance operations.

ASTM: American Society of Testing and Materials

SAE: Society of Automotive Engineers

API: American Petroleum Institute

FUEL, COOLANT AND LUBRICANTS

No.	Supplier	Engine Oil API CD, CE or CF-4	Transmission Oil GM Dexron® II C4 Allison C4	Grease LI, EP, MoS ₂	Anti-freeze Coolant Permanent type
1	KOMATSU	Premium multi grade Engine Oils PM701 SAE 10W/30 SAE 15W/40	Komatsu PM704 (1902) Dexron® III	Komatsu Super Grease NLGI 2 PM706 ASTM D 128	—
2	AMOCO	Amoco 300 SAE15W/40	Dexron II ATF	Molyolith grease 2	Ready Antifreeze
3	ARCO	Arcofleet S3 Plus SAE 15W/40 Hy-Vis HD extra S3 plus SAE 15W/40	ATF Dexron II	Litholine HEP 2 Arco EP moly D	Sincol-Blu (-40°C)
4	BP	Vanellus C3 SAE 15W/40 Vanellus C3 Extra SAE 15W/40	Autran MBX	Grease LTX2-M	Sigil Fluid (-40°C)
5	CALTEX	RPM Delo 500 RPM Delo 600 RPM Delo SPH	ATF-HD	Molytex EP2	AF eng. coolant CX eng. coolant
6	CASTROL	Turbomax RX super	TQ - Dexron II	Spheerol LMM	Anti-freeze (pure)
7	CHEVRON	Delo 400 Delo 500	Supreme Automatic Transmission Fluid	Moly grease	Flurant
8	CITGO	—	D-21571	—	—
9	CONOCO	Fleet motor oil SAE 15W/40	D21718 D21570	—	Fleet Heavy Duty
10	EXXON (ESSO)	Essolube TD SAE 15W/40 Heavy Truck Diesel Motor Oil SAE15W/40	ATF Dexron II D D-21849 (East Canada) D-21848 (West Canada)	MP Grease Moly	All season coolant
11	GULF	Super Duty SAE 15W/40 Super Duty plus SAE 15W/40	—	Gulfcrown EP2 Gulfcrown EP sp.I	Antifreeze and coolant
12	MOBIL	Delvac 1300 Super SAE 15W/40 Delvac 1200 Super SAE 15W/40 Delvac 1300 Super SAE 10W/30	ATF 220	Mobilgrease sp.I	—
13	PENNZOIL	Supreme duty fleet SAE 14W/40	Pennzoil ATF	Multi-purpouse white grease 705 707L white-bearing grease	Antifreeze and sum- mer coolant
14	SHELL	Rimula Super SAE 15W/40 Myrina X SAE 15W/40 Rotella T SAE 10W/30	Donag TG (Dexron II)	Alvania EP grease MP MOS (Can.) Retinax AM (Corea)	Shellzone all season antifreeze

No.	Supplier	Engine Oil API CD, CE or CF-4	Transmission Oil GM Dexron® II C4 Allison C4	Grease LI, EP, MoS ₂	Anti-freeze Coolant Permanent type
15	SUN	—	—	Sunoco ultra prestige 2EP Sun prestige 742	Sunoco antifreeze and summer coolant
16	TEXACO	Ursa Super TD SAE 15W/40 Ursa Super LA SAE 15W/40	Havoline ATF Dexron II Texamatic 7045 (9226)	Molytex EP2	—
17	UNION	Guardol	D21460	Unoba EP	—

4.4 NUT AND BOLT TIGHTENING TORQUES

4.4.1 STANDARD TIGHTENING TORQUES

★ Nm (Newton metre): 1 Nm = 0.102 kgm (0.738 lb ft)

Thread diameter (mm)	Pitch (mm)	wrench size (mm)	8.8			10.9		
			kgm	Nm	lb ft	kgm	Nm	lb ft
6	1	10	0.96 ± 0.1	9.5 ± 1	7 ± 0.74	1.3 ± 0.15	13.5 ± 1.5	10 ± 1
8	1.25	13	2.3 ± 0.2	23 ± 2	17 ± 1.5	3.2 ± 0.3	32.2 ± 3.5	24 ± 2.6
10	1.5	17	4.6 ± 0.5	45 ± 4.9	32 ± 3.6	6.5 ± 0.6	63 ± 6.5	47 ± 4.8
12	1.75	19	7.8 ± 0.8	77 ± 8	57 ± 5.9	11 ± 1	108 ± 11	80 ± 8
14	2	22	12.5 ± 1	122 ± 13	90 ± 9.6	17.5 ± 2	172 ± 18	127 ± 13
16	2	24	19.5 ± 2	191 ± 21	141 ± 15	27 ± 3	268 ± 29	198 ± 22
18	2.5	27	27 ± 3	262 ± 28	194 ± 21	37 ± 4	366 ± 36	270 ± 26
20	2.5	30	38 ± 4	372 ± 40	275 ± 30	53 ± 6	524 ± 57	387 ± 42
22	2.5	32	52 ± 6	511 ± 57	377 ± 42	73 ± 8	719 ± 80	531 ± 59
24	3	36	66 ± 7	644 ± 70	475 ± 52	92 ± 10	905 ± 98	668 ± 72
27	3	41	96 ± 10	945 ± 100	698 ± 74	135 ± 15	1329 ± 140	980 ± 103
30	3.5	46	131 ± 14	1287 ± 140	950 ± 103	184 ± 20	1810 ± 190	1336 ± 140



IMPORTANT

- This driving torque table is not valid for screws or nuts that must lock nylon parts or alike onto washers or components made of nylon or nonferrous materials.

4.4.2 SPECIFIC TIGHTENING TORQUES


ITEM	DESCRIPTION	kgm	Nm	lb ft
Engine	Front support central nuts	6.75 ± 0.75	66 ± 7.3	48.6 ± 5.3
	Rear support central nuts	6.75 ± 0.75	66 ± 7.3	48.6 ± 5.3
Front engine supports Rear engine supports	Engine fastening screws	6.75 ± 0.75	66 ± 7.3	48.6 ± 5.3
	Engine fastening screws	6.75 ± 0.75	66 ± 7.3	48.6 ± 5.3

4.5 LUBRICATION

4.5.1 LUBRICATION DIAGRAM

 **IMPORTANT**

- For the lubrication procedures for the single points, see “4.7 MAINTENANCE PLAN”.
- The type of lubricant to be used is indicated in the lubricant table (See “4.3 FUEL, COOLANT AND LUBRICANTS”).



4.6 PERIODICAL CHANGE OF THE COMPONENTS THAT ARE CONNECTED WITH SAFETY

To ensure safety at any moment while driving and using the machine, the operator must carry out all the periodic maintenance operations prescribed. Furthermore, the operator must periodically change the components indicated in the table in the following page, which are especially related to safety and accident-prevention rules. These components are subject to wear and since it is particularly difficult to evaluate their conditions through simple periodic maintenance, after a certain period it is advisable to change them independently of their state, in order to keep them efficient over time. Repair or replace these components immediately in case of failures or anomalies, even if the time interval prescribed for their change has not elapsed yet.

If the pipe clamps show signs of deterioration, like deformations or cracks, provide for changing them together with the pipes.

In addition to the periodical change of the components listed in the following page, the inspections described here below are to be carried out on the hydraulic pipes. In case of anomalies, carry out the necessary adjustments and changes, or adopt any other measure required.


Type of check	Check item
Check before starting	Leakages from joints, hydraulic pipes or fuel pipes
Periodical check (monthly check)	Leakages from joints, hydraulic pipes or fuel pipes. Damaged hydraulic or fuel pipes (cracks, wear and tear)
Periodical check (annual check)	Leakages from joints, hydraulic pipes or fuel pipes. Deteriorated, twisted, damaged hydraulic or fuel pipes (cracks, wear and tear) or pipes in contact with other parts of the machine

4.6.1 CRITICAL PARTS FOR SAFETY

FUEL SUPPLY SYSTEM

No	Components related to safety that periodically need changing	Qty	Change interval	
1	Fuel hose (Fuel tank – precleaner)	1	Every 2 years or 4000 hours, whichever occurs first	
2	Fuel hose (Precleaner - fuel pump)	1		
3	Fuel hose (Fuel pump - fuel filter)	1		
4	Fuel hose (Fuel filter – injection pump)	2		
5	Fuel hose (Fuel filter - fuel tank)	1		
6	Fuel recovery hose (Between the injectors)	PC35R		2
		PC45R		3
7	Fuel recovery pipe (Injector - Injection pump)	1		
8	Fuel recovery cap	1		

- For the serial numbers and the quantity of the components that periodically need changing, consult the spare parts catalogue section regarding the components connected with safety and the components that must be periodically changed.
- When changing pipes, always change the O-rings, the gaskets and analogous components.




RWA10500


HYDRAULIC SYSTEM

No.	Components related to safety that periodically need changing	Q.ty	Change interval
1	Hydraulic hose (Main pump delivery)	1	Every 2 years or 4000 hours, whichever occurs first
2	Hydraulic hose (Secondary pump delivery)	1	
3	Hydraulic hose (Pump Pressure PP)	1	
4	Hydraulic hose (Load Sensing signal)	1	
5	Hydraulic hose (Boom cylinder)	4	
6	Hydraulic hose (Arm cylinder)	4	
7	Hydraulic hose (Bucket cylinder)	4	

- For the serial numbers and the quantity of the components that periodically need changing, consult the spare parts catalogue section regarding the components connected with safety and the components that must be periodically changed.
- When changing pipes, always change O-rings, gaskets and analogous components.



RWA33330



RWA33340

OPERATOR'S SAFETY

No.	Components related to safety that periodically need changing	Q.ty	Change interval
1	Safety belt	1	Every 4 years



RWAA9520

4.7 MAINTENANCE PLAN

4.7.1 WHEN REQUIRED

N.	PART	OPERATION	PAGE
a	Cooling circuit	Wash	142
b	Fuel tank	Drain the condensate	143
c	Electrical system	Check	143
d	Steel tracks	Check and adjust the tension	144
e	Rubber tracks	Check	146
f	Rubber tracks	Check and adjust the tension	148
g	Rubber tracks	Change	150
h	Air cleaner	Check, clean or change	152

4.7.2 MAINTENANCE INTERVALS IN CASE OF USE OF THE DEMOLITION HAMMER (BREAKER)

N.	PART	OPERATION	PAGE
a	Hydraulic oil filter	Change the cartridge	153
b	Hydraulic oil tank	Change the oil	153

4.7.3 CHECKS BEFORE STARTING

N.	PART	OPERATION	PAGE
a	Various checks	—	154
b	Coolant	Check and top up	154
c	Fuel tank	Check and top up	155
d	Engine oil pan	Check and top up	155
e	Hydraulic oil tank	Check and top up	156
f	Air cleaner clogging indicator	Check	157
g	Fuel filter	Check	157

4.7.4 MAINTENANCE EVERY 100 HOURS OF OPERATION

N.	PART	OPERATION	PAGE
a	Joint and ball-bearing ring articulations	Lubricate	158

4.7.5 MAINTENANCE AFTER THE FIRST 250 HOURS OF OPERATION (Operations to be carried out together with those prescribed at point “4.7.6 MAINTENANCE EVERY 250 HOURS OF OPERATION”)

N.	PART	OPERATION	PAGE
a	Travel reduction gears	Change the oil	168
b	Engine valves	Check the clearance	172

4.7.6 MAINTENANCE EVERY 250 HOURS OF OPERATION

N.	PART	OPERATION	PAGE
a	Fan belt	Check the fan belt condition and its tension	160
b	Battery	Check the electrolyte level	161
c	Travel reduction gears	Check the levels (n. 2)	161
d	Engine oil	Change	162

4.7.7 MAINTENANCE EVERY 500 HOURS OF OPERATION

N.	PART	OPERATION	PAGE
a	Engine oil filter	Change	163
b	Fuel filter	Change	164
c	Fuel pump precleaner	Change	165
d	Radiators	Clean the outside	166
e	Hydraulic oil drainage filter	Change	167

4.7.8 MAINTENANCE EVERY 1000 HOURS OF OPERATION

N.	PART	OPERATION	PAGE
a	Travel reduction gears	Change the oil	168

4.7.9 MAINTENANCE EVERY 2000 HOURS OF OPERATION

N.	PART	OPERATION	PAGE
a	Hydraulic oil and suction filter	Change the oil and clean the filter	169
b	Coolant	Change	172
c	Engine valves	Check the clearance	172
d	Alternator and starter	Check	172

4.7.1 WHEN REQUIRED

4.7.1.a WASHING THE COOLING CIRCUIT




WARNING


- Be extremely careful when carrying out this maintenance operation, since the engine must be running; one operator must remain on the machine and the operators must decide the words and signals to be used in advance.
- As soon as the machine has been stopped the coolant is very hot and under pressure and may cause serious burns; let the engine cool down until it reaches approximately 40-45°C (104-113°F) before starting the washing operations.
- Slowly loosen the radiator cap, to release the residual pressure.
- Let all the work equipment safety locks engaged.
- Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the anti-pollution regulations in force.

Whenever passing from the use of water to the use of antifreeze fluids and vice versa, it is necessary to wash the circuit in order to eliminate either the oxide deposits and the limestone encrustations. Proceed as follows:

- 1 - Remove the inspection cover (1) (use a 17 mm spanner) and open the engine hood (see “3.5.1 ENGINE HOOD”).
- 2 - While the fluid is still lukewarm, open the radiator drain cock (3), remove the drain plug (4) positioned on the engine block and the radiator cap (2).
Use a 17 mm hexagon spanner.
- 3 - Let all the fluid flow out, put back the plug (4) on the engine block and close the radiator drain cock (3).
- 4 - Introduce a high-quality scale remover in the radiator, in the quantities indicated on the package (remember that the cooling system capacity is approximately 6.8 l (1.8 US gal) for the PC35R and approximately 7.5 l (1.98 US gsal) for the PC45R) and then fill the radiator with water.
- 5 - Start the engine and let it run at high speed for about 15 minutes.
- 6 - Lower the engine speed to low idling and discharge the scale remover through the radiator cock (3), at the same time filling the radiator with running water for at least 40 minutes.
- 7 - Stop the engine, drain all the water, close the radiator cock (3) and definitively fill the system with water or coolant.
- 8 - Start the engine and after a few minutes check the level in the radiator; if necessary, top up before tightening the cap (2).
- 9 - After draining the water from the tank (5), wash the inside of the tank and fill it with water or coolant until reaching a level included between the LOW and FULL marks.
- 10 - Close the engine hood and put back the inspection cover (1).



RWA10840



RWA10850



IMPORTANT

- The circuit must be washed more frequently if the water used contains a high quantity of calcium salts, that is, if the water is very hard.


4.7.1.b DRAINING THE FUEL TANK



WARNING

- When draining the fuel tank, avoid spilling fuel, since this may cause fires.
- If some fuel is accidentally spilled, clean the dirty area immediately, in order to prevent it from getting slippery and to avoid fires.

This operation serves to let all the impurities and the condensate flow out of the tank; open the cock (1) at the base of the tank and wait until clean fuel flows out.



RWA10860



IMPORTANT

- The tank must be drained before starting the engine, with temperatures exceeding 0°C (32°F); when the temperature is below 0°C (32°F), the tank must be drained at the end of work or in any case with the machine at operating temperature, to prevent the condensate from freezing.
- The condensate and the impurities that may have accumulated inside the tank must be eliminated before refuelling.

4.7.1.c CHECKING THE ELECTRICAL SYSTEM



WARNING

- If the fuses are corroded, oxidized or not perfectly held in their seat, replace them only with fuses having the same capacity; before changing a fuse, make sure that the ignition key is in position «O».
- If there are signs of short circuit on the cables, find out the cause and repair them; always contact your Komatsu Dealer for the troubleshooting.

Make sure that there are no disconnected cables or signs of short circuit in the electrical system. Make sure that all the cables are well tightened in the relevant terminals; tighten any loose cables. In particular, check:

1. Battery
2. Starter
3. Alternator

4.7.1.d CHECKING THE STEEL TRACK TENSION





- This operation must be carried out by two operators. One operator must be seated in the cab and operate the machine according to the instructions of the operator who carries out the check and the adjustment.
 - The track tension must be checked with the frame lifted from the ground; be careful not to move any control lever while the operator is carrying out the check.
-

CHECK

Stop the machine on a firm and level surface and lower the equipment to the ground.

- 1 - Raise each track by means of boom and arm.
Operate the control levers slowly during this operation.
- 2 - Measure the distance between the track and the 3rd roller, starting from the sprocket. If the distance is included between 30 and 50 mm (1.2 to 2 in), the tension is normal.
If the value is not included in this interval, adjust the track until reaching the correct value.



ADJUSTMENT



- The grease contained in the hydraulic cylinder is under pressure. For this reason, do not loosen the greasing valve (1) giving it more than one turn; if the valve is loosened excessively, it may be pushed out due to the grease pressure and this is very dangerous for the operator.
Do not loosen any other component apart from the valve (1).
 - If you notice excessive resistance while injecting grease, slowly move the machine forward and backward for a short distance.
-

To increase the tension


- 1 - Carefully clean the greasing valve (1) and inject grease through the greaser (2) until reaching the desired tension.
- 2 - When, owing to the injection of grease, the idler shoe reaches the "S" measure, that is, 0 mm (0 in) and the track tension is not sufficient, this means that the pins and bushings are excessively worn.
It is therefore necessary to turn or change the pins and bushings.
For any change or repair, contact your Komatsu Dealer.

To reduce the tension


- 1 - Gradually loosen the greasing valve (1) to let the grease out; do not give the valve more than one turn.
Use a 19 mm hexagon spanner.
- 2 - If the grease does not flow out freely, move the machine slowly forward and backward for a short distance.
- 3 - Tighten the valve and remove any trace of grease.
- 4 - Move the machine forward and backward and, after stopping it, check the track tension again.

 **IMPORTANT**

- The wear of pins and bushings varies according to the work conditions and the characteristics of the ground on which the machine operates.
Therefore, it is necessary to check the track tension frequently.
- When working on rocky or extremely uneven ground, increase the track tension in order to prevent the introduction of stones or rubble between the tracks and the sprocket; when working on soft or muddy ground, decrease the track tension, since the soil penetrates between rollers, sprocket and tracks and tends to increase it.



RWA09320




RWA06550

4.7.1.e CHECKING THE RUBBER TRACKS


Change the rubber tracks when they reach the prescribed wear limits.

1 - When the height "A" of the rubber claw is lower than 5 mm (0.2 in); if the height of the claw is below 5 mm (0.2 in), the risk of track slipping increases and the advance power will decrease accordingly.


- 1- Roller
- 2- Rubber track




2 - When the steel reinforcement (3) can be seen on two or more points on the track.



3 - When more than a half of the wires of the steel reinforcement positioned at the centre of the track are cut.



4 - When one or more steel reinforcement units (4) come off the track or are ejected due to the excessive tension.



5 - If the rubber track tension is not sufficient after having been adjusted through the injection of grease, check the idler gas-kets and if necessary change them or change the track.
(See "4.7.1.f CHECKING THE RUBBER TRACK TENSION").

 **IMPORTANT**



- If the track tension is adjusted so that the shoe may come off its seat, the track may be lengthened and the idler cylinder may be damaged, too.

6 - If the break between the support claws of the rubber tracks reaches a length (1) of approximately 60 mm (2.4 in), the track must be repaired.

It must be immediately repaired even when the break is very slight, but the steel reinforcement units can be seen.

 **IMPORTANT**

- If the break length (2) is inferior to 30 mm (1.2 in), or its depth is inferior to 10 mm, the track does not need repairing.
- For any change or repair, contact your Komatsu Dealer.



4.7.1.f CHECKING THE RUBBER TRACK TENSION




- This operation must be carried out by two persons. One operator must sit in the cab and move the machine according to the signals of the operator who carries out the check and the adjustment.
- The shoe tension must be checked with the frame lifted from the ground. Do not operate any control lever while the operator is carrying out the check.

CHECK

Stop the machine on a firm and level surface.


- 1 - Position the joint of the rubber track marked with M on the upper part of the track, mid-way between the two axes.
- 2 - Lower the equipment to the ground and lift each track by means of boom and arm.
When carrying out this operation, move the control levers slowly.
- 3 - Measure the distance between the track and the 3rd roller, starting from the sprocket. If the distance is included between 10 and 15 mm (0.4 to 0.6 in), the tension is normal. If the distance exceeds 20 mm (0.8 in), adjust the track until reaching the correct value.




RWA09330



- If the machine is operated with loose rubber tracks, the shoes may come off their seats and consequently off the track, or the steel reinforcement units may wear too quickly.



RWA06380



RWA09340

ADJUSTMENT


WARNING

- The grease contained in the hydraulic cylinder is under pressure. For this reason, do not loosen the greasing valve (1) giving it more than one turn; if the valve is loosened excessively, it may be pushed out due to the grease pressure and this is very dangerous for the operator. Do not loosen any other component apart from the valve (1).
- If you notice excessive resistance while injecting grease, slowly move the machine forward and backward for a short distance.

-
- 1 - To increase the tension, carefully clean the greasing valve (1) and inject grease through the greaser (2) until reaching the desired tension.
 - 2 - To reduce the tension, gradually loosen the greasing valve (1) to let the grease out; do not give the valve more than one turn. Use a 19 mm hexagon spanner.
 - 3 - If the grease does not flow out freely, move the machine slowly forward and backward for a short distance.
 - 4 - Tighten the valve and remove any trace of grease.
 - 5 - Move the machine forward and backward, stop it and check the track tension again.
 - 6 - If the rubber track tension is not sufficient even after the injection of grease, change the track or the idler seals. For these operations, contact your Komatsu Dealer.

IMPORTANT

- The wear of the rubber tracks varies according to the work conditions and to the characteristics of the ground on which the machine is operated. Therefore, it is necessary to check the track tension frequently, in order to keep it constant.
 - After the installation of new tracks, it is advisable to carry out a first check after 30 hours of operation.
-



4.7.1.g CHANGING THE RUBBER TRACK





- This operation must be carried out by two persons. One operator must sit in the cab and move the machine according to the signals of the operator who carries out the check and the adjustment.
- The shoe tension must be checked with the frame lifted from the ground. Do not operate any control lever while the operator is carrying out the check.
- During the check, do not remove any part except the shoe to be changed.
- If the shoe tension cannot be loosened by proceeding as indicated below, contact your Komatsu Dealer, who will carry out the necessary repairs.

REMOVING THE RUBBER TRACK




- The grease contained in the hydraulic cylinder is under pressure. For this reason, do not loosen the greasing valve (1) giving it more than one turn; if the valve is loosened excessively, it may be pushed out due to the grease pressure and this is very dangerous for the operator. Do not loosen any other component apart from the valve (1).
- When assembling or removing the track, before rotating the sprocket make sure that the grease contained in the cylinder has been removed.
- If you notice excessive resistance while injecting grease, slowly move the machine forward and backward for a short distance.



Stop the machine on a firm and level surface and lower the equipment to the ground.


- 1 - Raise the undercarriage by means of boom and arm. When carrying out this operation, move the control levers slowly.
- 2 - Gradually loosen the greasing valve (1) to let the grease out; do not give the valve more than one turn. Use a 19 mm hexagon spanner.
- 3 - If the grease does not flow out freely, move the track slowly forward and backward for a short distance.
- 4 - Insert the steel tubes (2) inside the track, rotate the sprocket as if in reverse (3), so that the steel tubes move with the track and engage in the idler roller; slide the track (4) sideways and remove it.



INSTALLING THE RUBBER TRACK

1 - Raise the undercarriage by means of boom and arm and make sure that the grease contained in the cylinder has been removed.

When carrying out this operation, move the control levers slowly.



2 - Install the rubber tracks on the sprocket, inserting the drive blocks.


3 - Rotate the sprocket as if in reverse (1), pushing the outer edge of the track towards the upper structure.

4 - By means of a steel tube (2), position the track and rotate the sprocket again.

5 - Make sure that the rubber track properly fits in the sprocket and the idler roller.

6 - Adjust the track tension. For further details (See "4.7.1.f CHECKING THE RUBBER TRACK TENSION").

7 - Make sure that the track tension is correct and that the track is properly inserted in the sprocket and the idler roller; place the machine on the ground.



4.7.1.h CHECKING, CLEANING OR CHANGING THE AIR CLEANER CARTRIDGE

! WARNING

- Remove the air cleaner only after stopping the engine and do not start the engine if the air cleaner is open.
- Wear safety goggles during the cleaning operations.

When the red piston of the clogging indicator (1) is visible through the gauge, it is necessary to clean or change the air cleaner cartridge






The air cleaner (2) can be reached by opening the engine hood (see "3.5.1 ENGINE HOOD").

To clean the element, proceed as follows:

- 1 - Remove the couplings (3), remove the cover (4) and extract the filtering element (5).
- 2 - Slightly strike the filtering element on the palm of your hand to remove the dust and blow compressed air on the inner surface, keeping the air jet at a distance of approximately 15 cm (5.9 in) and making sure that the pressure does not exceed 4-5 bars (58-73 psi).
- 3 - Carefully clean the clogging cover (4) and the filter case (6), taking care to prevent the introduction of foreign matters in the suction pipe; reassemble the whole making sure that the ejector on the covers is facing downwards.
- 4 - Press the push button (7) of the clogging indicator (1) in order to restore the pressure of the red piston.

! IMPORTANT

- If shortly after the installation of the clean element the red piston of the clogging indicator is visible again, it is necessary to change the filtering element.
- Change the filtering element when it has been cleaned 5 times or after 1 year of use.



4.7.2 MAINTENANCE INTERVALS IN CASE OF USE OF THE DEMOLITION HAMMER (BREAKER)


The hydraulic oil used in the machines provided with demolition hammer deteriorates more quickly than the oil used in normal digging machines, therefore it is advisable to respect the following maintenance plan.

4.7.2.a CHANGING THE HYDRAULIC OIL FILTER

In new machines, change the filter after the first 100÷150 hours of operation and for the successive changes follow the instructions given in the table on the right.

4.7.2.b CHANGING THE HYDRAULIC OIL

Change the hydraulic oil in the tank according to the instructions given in the table on the right.



4.7.3 CHECKS BEFORE STARTING

4.7.3.a VARIOUS CHECKS



WARNING

- **Dirt, oil and fuel spread in the engine compartment near the hot areas may cause fires and damage the machine.**
Check if there are leakages frequently and carry out the necessary repairs immediately; if this occurs repeatedly, contact your Komatsu Dealer.

Before starting the engine, check:

1. if there are loose screws or nuts;
2. if there are oil, fuel or coolant leakages;
3. if the work equipment is worn;
4. the track tension and wear;
5. the conditions and efficiency of the instruments and warning lights on the dashboard, of the acoustic alarm, of the working lights and of the horn.

The other general checks concern safety, and precisely:

6. soundness of the safety belt;
7. soundness and legibility of the warning plates;
8. cleanliness of the handles used to reach the driver's seat, cleanliness inside the driver's cab.

4.7.3.b CHECKING THE COOLANT LEVEL




WARNING

- **Do not remove the radiator cap; the coolant must be checked with cold engine, through the compensation tank.**

The coolant tank (1) can be reached after opening the engine hood and the coolant level must be included between the LOW and FULL marks.

If necessary, add water or coolant and, if a constant and considerable decrease in the coolant level can be noticed, check the tightness of the engine-radiator unit and of the radiator body.



RWA10510

4.7.3.c CHECKING THE FUEL LEVEL

! WARNING



- When refuelling, avoid spilling fuel to prevent any risk of fire. If some fuel should inadvertently be spilled, clean the dirty area immediately.
- Fuel is flammable; neither use naked flames, nor smoke while refuelling.
- Thrust the filling gun into the filler.

To check the fuel level, use the indicator (1) provided on the dashboard, after turning the ignition key to position «I».

Do not fill the tank completely, in order to leave space for the expansion of the fuel.

👉 IMPORTANT

- It is advisable to refuel after work, in order to avoid the formation of water condensate.
- After refuelling, tighten the filler cap (2) thoroughly and lock the tank.



4.7.3.d CHECKING THE ENGINE OIL LEVEL

! WARNING

- Soon after the machine has been stopped the engine is very hot and may cause burns; let the engine cool down before carrying out any check.



The dipstick can be reached by opening the engine hood (See "3.5.1 ENGINE HOOD").

The check must be carried out with cold engine and the machine positioned on level ground.

The oil level can be checked on the graduated dipstick (1) and must be included between the MIN. and MAX. marks; if the level is near the MIN. mark, top up by adding the oil suitable for the ambient temperature prescribed in the lubricant chart through the filler (2). (See "4.3 FUEL, COOLANT AND LUBRICANTS").

👉 IMPORTANT


- If it is necessary to check the oil level during or soon after work, stop the engine and wait for 15 minutes before carrying out the check.



4.7.3.e CHECKING THE OIL LEVEL IN THE HYDRAULIC CIRCUIT

⚠ WARNING


- The oil level in the hydraulic circuit must be checked with cold oil and the machine positioned on level ground, with retracted bucket and arm cylinders and the bucket teeth resting on the ground.
- If it is necessary to top up, stop the engine and then eliminate the residual pressures present in the equipment (move the controls more than once) and in the tank by slowly loosening the filling cap.



The level gauge can be reached after opening the engine hood. (See “3.5.1 ENGINE HOOD”). The oil level must be visible through the gauge (1) positioned on the tank and must be included between the MIN. and MAX. marks. If the level is near the MIN. mark, top up through the filler (2) with the prescribed hydraulic oil (see “4.3 FUEL, COOLANT AND LUBRICANTS”); put back the filling cap. Use a 24 mm hexagon spanner.

👉 IMPORTANT


- When topping up, do not exceed the MAX. level. This would damage the hydraulic circuit and cause the oil to flow out.



At this point, pressurize the tank; completely extend the boom, arm and bucket cylinders as shown in the figure and remove the fillercap (2). Put back the cap and pressurize the inside of the tank by lowering the equipment to the ground.

👉 IMPORTANT

- If a constant or abnormal decrease in the oil level is observed, carefully check the tightness of the hydraulic circuit, of the pistons and of the pump.




4.7.3.f CHECKING THE AIR CLEANER CLOGGING INDICATOR


The clogging indicator is installed on the air cleaner and can be reached by opening the engine hood.

When the air cleaner is clogged, the red piston of the indicator (1) visible through the gauge indicates that maintenance is required. Check, clean or change the filtering element as described in paragraph "4.7.1.h CHECKING, CLEANING OR CHANGING THE AIR CLEANER CARTRIDGE".

After performing the necessary maintenance operation, press the push button (2) to restore the pressure of the red piston.



RWA10550



RWA09180

4.7.3.g CHECKING THE FUEL FILTER FOR SEDIMENT AND WATER




WARNING

- Fuel is flammable; keep any naked flame away and do not smoke while draining the fuel.
- If some fuel is accidentally spilt, clean the dirty area immediately.


The check can be carried out by means of the red ring (1) installed in the filter.

When the red ring floats on the surface of the water present in the filter, it is necessary to drain the fuel tank by proceeding as follows:

- 1 - Turn the cock (2) to stop the fuel flow.
- 2 - By means of the specific spanner provided, loosen the metal ring (3), remove the container (4) and eliminate the water it contains.
- 3 - Clean the sealing surface of the cover (5), install the O ring and spread some grease on it.
- 4 - Put back the container (4), tighten the metal ring (3) and open the fuel cock.
- 5 - Drain the fuel tank as described in paragraph "4.7.1.b DRAINING THE FUEL TANK".
- 6 - Bleed the fuel circuit as described in paragraph "4.7.7.b CHANGING THE FUEL FILTER - BLEEDING THE FUEL CIRCUIT".



RWA10560



RWA09200

4.7.4 MAINTENANCE EVERY 100 HOURS OF OPERATION

4.7.4.a LUBRICATING THE JOINTS AND THE BALL-BEARING RING

👉 IMPORTANT



- Clean the grease nozzles before applying the greasing pump.
- After lubrication, remove any excess grease.
- If the machine is used in difficult conditions, perform this maintenance operation more frequently.

These maintenance operations must be carried out with the equipment completely extended and resting on the ground. For the lubrication, use a syringe and the prescribed grease. (See “4.3 FUEL, COOLANT AND LUBRICANTS”).

👉 IMPORTANT


- As a general rule, it is important to consider that each cylinder is provided with two greasers positioned on the coupling eyelets and that each pin serving as fulcrum for a movement is provided with at least one greaser.
- When injecting grease to lubricate the rotation pinion and the ball-bearing ring, rotate the upper structure slowly and grease every 90°.

BALL-BEARING RING AND BLADE LUBRICATION POINTS



1 - Ball bearing ring pinion	(1 point)
2 - Ball bearing ring	(1 point)
3 - Boom swing cylinder base pin	(1 point)
4 - Blade cylinder base pin	(1 point)
5 - Blade cylinder head pin	(1 point)
6 - Blade fulcrum pin	(2 points)

EQUIPMENT LUBRICATION POINTS



7 - Boom swing cylinder head pin	(1 point)
8 - Boom swing fulcrum pin	(1 point)
9 - Boom fulcrum pin	(2 points)
10 - Lifting cylinder base pin	(1 point)
11 - Lifting cylinder head pin	(1 point)
12 - Arm cylinder base pin	(1 point)
13 - Arm cylinder head pin	(1 point)
14 - Arm fulcrum pin	(1 point)
15 - Bucket cylinder base pin	(1 point)
16 - Lever fulcrum pin	(1 point)
17 - Bucket cylinder head pin	(1 point)
18 - Tie rod - lever coupling pin	(1 point)
19 - Tie rod - bucket coupling pin	(2 points)
20 - Bucket fulcrum pin	(1 point)

4.7.5 MAINTENANCE AFTER THE FIRST 250 HOURS OF OPERATION

These maintenance operations must be carried out after the first 250 hours of operation, together with those to be carried out “EVERY 250 HOURS”.

- CHANGE THE OIL IN THE TRAVEL REDUCTION GEARS
- CHECK AND ADJUST THE ENGINE VALVE CLEARANCE

For further details on the various maintenance operations, see the sections “4.7.8 MAINTENANCE EVERY 1000 HOURS OF OPERATION” and “4.7.9 MAINTENANCE EVERY 2000 HOURS OF OPERATION”.

For the inspection and adjustment, contact your Komatsu Dealer.

4.7.6 MAINTENANCE EVERY 250 HOURS OF OPERATION

4.7.6.a ADJUSTING THE FAN BELT TENSION

To reach the fan belt, remove the inspection cover (1) (use a 17 mm spanner) and open the engine hood (see “3.5.1 ENGINE HOOD”).

The check is manual: press the belt with your thumb on the indicated point with a force equal to approx. 60 N (13.5 lb); the resulting deflection must be approximately 10-15 mm (0.4 to 0.6 in).

If the deflection exceeds this value, loosen the screw (2) and the nut (3) that fasten the alternator (4) and, with a lever inserted between the motor block and frame, make the alternator slide.


Lock the screw and the nut and check again.

Use 12 mm and 13 mm spanners.


A - Fan pulley

B - Driving shaft pulley

C - Alternator pulley




RWA10600



RWA09220

 **IMPORTANT**

- If the belt is worn, change it and check the tension again after a few hours of operation.



RWA10610

4.7.6.b CHECKING THE BATTERY ELECTROLYTE LEVEL



WARNING


- Check the level only after stopping the engine and if necessary add distilled water only before starting work.
- Always wear safety goggles and waterproof gloves.
- To prevent gas explosions, do not use naked flames, do not smoke and avoid producing sparks due to short circuits.
- The battery electrolyte is dangerous; if it comes in contact with the eyes or skin, rinse with plenty of water and consult a doctor without delay.

The battery (1) can be reached by opening the right door (2). The electrolyte level in each cell must be about 6 mm above the plate edge; if necessary, top up with distilled water only. If, on the contrary, the level is low because some fluid has been spilled, add diluted sulphuric acid until reaching the concentration suitable for the ambient temperature. (See “3.11.3 BATTERY”).



IMPORTANT

- It is advisable to add distilled water before starting work, in order to prevent it from freezing.
- Before putting back the cell plugs, make sure that the breather holes are not clogged.
- Make sure that the connection terminals are not oxidized; if necessary, clean them and cover them with anti-oxidation grease.



4.7.6.c CHECKING THE OIL LEVEL IN THE TRAVEL REDUCTION GEARS



WARNING

- As soon as the machine has been stopped the oil is very hot; let it cool down until it reaches 40-50°C before carrying out the check.


This check must be carried out on each reduction gear positioned with the drain plug (1) downward and aligned with the level plug (2) on the vertical axis.

If necessary, move the machine slightly until reaching the required position, which must absolutely be respected in order to carry out a precise check.

This check is visual: the oil must reach the hole (2); otherwise, top up following the procedures described in paragraph “4.7.8.a CHANGING THE TRAVEL REDUCTION GEAR OIL” and using the prescribed oil.

(See “4.3 FUEL, COOLANT AND LUBRICANTS”).

Use a 8 mm setscrew spanner.



4.7.6.d CHANGING THE ENGINE OIL





WARNING

- Soon after the machine has been stopped the engine oil is very hot and may cause burns; let the engine cool down until it reaches a temperature of 40-45°C (104-113°F) before draining the oil.
- The oil that may be spilled during the change makes the ground slippery, therefore, use anti-slip shoes and immediately remove any trace of oil from the floor.
- Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the anti-pollution regulations in force.

Proceed as follows:

- 1 - Open the engine hood (See "3.5.1 ENGINE HOOD").
- 2 - Remove the drain plug (1) of the oil pan, gathering the used oil that flows out into a container with suitable capacity. (Use a 19 mm hexagon spanner).
While the oil flows out, remove the filling cap (2), so that the oil can flow freely.
- 3 - Tighten the plug (1) onto the pan and pour the prescribed quantity of new oil, using the dipstick (3) to make sure that the oil reaches the MAX. level.
To top up, use oil suitable for the ambient temperature (See "4.3 FUEL, COOLANT AND LUBRICANTS").
- 4 - Put back the filling cap (2), start the engine, let it run for 5 minutes and then stop it.
Check the level again and top up if necessary.
- 5 - Close the engine hood.



4.7.7 MAINTENANCE EVERY 500 HOURS OF OPERATION

These operations must be carried out together with those to be carried out every 100 and 250 HOURS.

4.7.7.a CHANGING THE ENGINE OIL FILTER



WARNING

- Soon after the machine has been stopped the engine oil is very hot and may cause burns; let the engine cool down until it reaches a temperature of 40-45°C (104-113°F) before draining the oil.
- The oil that may be spilled during the change makes the ground slippery, therefore, use anti-slip shoes and immediately remove any trace of oil from the floor.
- Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the anti-pollution regulations in force.

This operation must be carried out every two oil changes.

Proceed as follows:


- 1 - Drain the engine oil (See "4.7.6.d CHANGING THE ENGINE OIL").
- 2 - Unscrew the used filter (1) with the special spanner provided and throw it away.
- 3 - Clean the contact surface between the seal and the filter support.
- 4 - Lubricate the seal of the new filter and screw thoroughly.
- 5 - Give another half turn by hand.
- 6 - Top up with new engine oil and complete the operations as described in point "4.7.6.d CHANGING THE ENGINE OIL".

Start the engine, make sure that there are no leakages and that the oil pressure warning light goes out.



IMPORTANT

- Do not use the spanner to lock the filter, since it may be damaged and cause oil leakages.



4.7.7.b CHANGING THE FUEL FILTER



WARNING

- Change the filtering element after work, when the engine has cooled down to 40-45°C (104-113°F).
- When these operations are carried out, fuel may be spilled; clean the dirty areas immediately, in order to prevent any risk of slipping or fire.
- Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the anti-pollution regulations in force.

The fuel filter can be reached after opening the engine hood (See "3.5.1 ENGINE HOOD").

FUEL FILTER


- 1 - Close the fuel tap (1).
- 2 - Loosen the metal ring (2) by means of the special spanner provided, remove the container (3) and extract the filtering element.
- 3 - Clean the sealing surface of the cover (4) and install the new filter in the container (3); install the O ring of the cover and smear it with some grease.
- 4 - Reassemble the whole unit, open the fuel tap (1) and bleed the fuel supply circuit after shifting the accelerator lever to the idling position.

BLEEDING THE CIRCUIT



WARNING




- The engine may start during the bleeding of the circuit; make sure that there is no one near the machine.

After filling the tank, turn the ignition key to position «» and let the starter run for approximately 15-20 seconds in order to bleed the fuel supply circuit.



IMPORTANT

- If the engine starts without problems and then stops or works irregularly, check if there is air in the circuit; if so, check the tightness of the fuel filter and of the fuel pump prefilter.
- After all the fuel has run out, bleed the circuit by proceeding as described above.





4.7.7.c CHANGING THE FUEL PUMP PRECLEANER



- Change the precleaner after work, when the engine has cooled down to 40-45°C (104-113°F).
- When these operations are carried out, fuel may be spilled; clean the dirty areas immediately, in order to prevent any risk of slipping or fire.
- Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the anti-pollution regulations in force.

- 1 - Place a container under the precleaner (1), to gather the fuel.
- 2 - Shift the accelerator lever to the idling position.
- 3 - Remove the precleaner from the clamp (2).
- 4 - Remove the clamp (3) and disconnect the pipe (4) from the precleaner.
- 5 - Remove the clamp (5), disconnect the pipe (5) from the used precleaner and throw the latter away.
- 6 - Connect the pipes (4) and (6) to a new precleaner and fasten them with the clamps (3) and (5).
- 7 - Install the precleaner in the clamp (2) and bleed the fuel supply circuit (See "4.7.7.b CHANGING THE FUEL FILTER").




4.7.7.d CLEANING THE OUTSIDE OF THE RADIATORS



WARNING

- If compressed air, steam or water are directed against a person, they may cause injuries.
Always wear an eye shield and safety shoes.
-

The outside of the radiators must be cleaned with a jet of compressed air and, if necessary, with a low-pressure water or steam washing cycle; the specific products available on the market can be certainly used, provided that the instructions given on the package are followed and that the washed parts are carefully dried at the end of the operations.



IMPORTANT

- Do not use products containing oily substances, even if in slight quantities, since these facilitate the adhesion of dust, which affects the heat exchange adversely.
 - Clean the outside of the radiators whenever the radiator or the heat exchanger are dirtied, even if accidentally, with oil, diesel oil, greasy or oily substances.
 - If the machine is used in dusty places, clean the radiator and the exchanger more frequently, in order to avoid any clogging of the fins.
-

4.7.7.e CHANGING THE HYDRAULIC SYSTEM OIL FILTER



WARNING

- Soon after the machine has been stopped the hydraulic oil is very hot; let it cool down until it reaches a temperature of 40-45°C (104-113°F) before changing it.
- The hydraulic system is pressurized; loosen the filling cap slowly to release the residual pressure.
- Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the anti-pollution regulations in force.

The filter is positioned on the hydraulic system drain outlet and blocks the metal particles that come off the various components due to their wear.

The filter can be reached by opening the engine hood (see “3.5.1 ENGINE HOOD”).





To change the filter, proceed as follows:

- 1 - Slowly loosen the filling cap (3) in order to release the residual pressure from the tank.
Use a 24 mm hexagon spanner.
- 2 - Remove the screws (2) that fasten the filter cover (3).
Use a 17 mm hexagon spanner.
- 3 - Remove the spring (4), the valve (5) and extract the cartridge (6).
- 4 - Carefully clean the filter holder and change the filtering cartridge (6).
- 5 - Reassemble the whole unit by proceeding in the reverse order and make sure that the cover seal (3) is in perfect conditions and positioned in the seat provided on the tank.
- 6 - Extend the boom, arm and bucket cylinders completely, as indicated in the figure, and remove the filling cap (1).
Put back the cap and pressurize the inside of the tank by lowering the equipment to the ground.
- 7 - Close the engine hood.



IMPORTANT

- The hydraulic oil used in machines provided with demolition hammer deteriorates sooner than the oil used in machines that carry out only normal digging operations. On new machines the filter must be changed after the first 100-50 hours of operation, while the successive changes must be carried out according to the intervals indicated on table beside.



4.7.8 MAINTENANCE EVERY 1000 HOURS OF OPERATION

These operations must be carried out together with those to be carried out every 100, 250, 500 HOURS.

4.7.8.a CHANGING THE OIL IN THE TRAVEL REDUCTION GEARS



WARNING

- Soon after the machine has been stopped the engine oil is very hot; let the engine cool down until it reaches a temperature of 40-45°C (104-113°F) before changing the oil.
 - Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the anti-pollution regulations in force.
-


This operation must be carried out with the machine on level ground at a temperature of 40-45°C (104-113°F), so that the oil is more fluid and can be drained easily together with the suspended solid particles.

- 1 - Move the machine until the drain plug (1) is in low position and aligned with the level plug (2) on the vertical axis.
- 2 - Remove the drain plug (1) and let the used oil flow out completely, gathering it into a container with suitable capacity. While the oil flows out, remove the level plug (2). Use a 8 mm setscrew spanner.
- 3 - After draining the oil, put back the plug (1) and pour new oil of the prescribed type through the hole (2) until reaching the lower edge of the hole itself.
- 4 - Put back the plug (2).

Carry out some movements, stop the machine and check the levels again.

Use only the prescribed oil.

(See "4.3 FUEL, COOLANT AND LUBRICANTS").



4.7.9 MAINTENANCE EVERY 2000 HOURS OF OPERATION

Carry out these operations together with those to be performed every 100, 250, 500 and 1000 HOURS.

4.7.9.a CHANGING THE HYDRAULIC SYSTEM OIL AND CLEANING THE SUCTION FILTER



WARNING





- Retract the bucket and arm cylinder completely, lower the bucket teeth to the ground and, after stopping the engine, release the residual pressures from the work equipment circuits (by operating the controls more than once) and from the tank (by slowly loosening the filling cap).
- Let the oil cool down until it reaches 40-45°C (104-113°F) before carrying out any maintenance operation.
- Immediately clean any area dirty with oil.
- Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the anti-pollution regulations in force.

- 1 - Rotate the upper structure of 45°, in such a way as to leave the lower part of the hydraulic oil tank free from the tracks.
- 2 - Retract the bucket and arm cylinder completely and lower the boom until the bucket teeth touch the ground.
- 3 - Lower the blade to the ground.
- 4 - Stop the engine and eliminate the residual pressures present in the equipment (by moving the controls several times).
- 5 - Remove the left cover (1) (use a 17 mm spanner), the lower cover (2) (use a 17 mm spanner), open the engine hood and slowly loosen the filling cap (3) in order to release the residual pressure (use a 24 mm spanner).
- 6 - Remove the drain plug (4) and let the oil flow out, gathering it in a container with suitable capacity. Use a 32 mm hexagon spanner.
- 7 - Loosen the clamps (5), remove the suction pipe (6) and let the remaining oil flow out of the tank.
- 8 - Remove the screws (7) and the flange (8) and clean the suction filter (9). Use a 17 mm hexagon spanner.




IMPORTANT

- Carefully check the filtering element grid and if it is not in perfect conditions, change it.




MAINTENANCE PLAN

- 9 - Put back the drain plug (4) and the lower flange (8) with the filter (9), making sure that the gasket and the suction pipe (6) with the clamps (5) are in perfect conditions.
- 10 - Top up with the prescribed oil until reaching the level (10).
To top up, use only the prescribed type of oil (see "4.3 FUEL, COOLANT AND LUBRICANTS").
- 11 - Loosen the bleeding screw (11) positioned on the hydraulic pump, until no air bubbles can be seen in the oil that flows out of the screw.
Use a 10 mm spanner.
After bleeding the system, tighten the screw (11).
Put back the filling cap (3).
- 12 - Extend the boom, arm and bucket cylinders completely, as indicated in the figure, and remove the filling cap (3).
Put back the cap and pressurize the inside of the tank by lowering the equipment to the ground.
- 13 - Make sure that all the control levers are in neutral and let the engine idle for 2÷3 minutes before operating the work equipment.
Move each piston more than once in order to deaerate the system; check again and top up if necessary.
- 14 - Put back the left cover (1) and the lower cover (2) and close the engine hood.



RWA10810




RWA10820




CAUTION


- Do not start the engine with empty tank, since this would certainly damage the pump.



RWA10830




RWA06730



RWA11040

IMPORTANT


- The hydraulic oil used in machines provided with demolition hammer deteriorates sooner than the oil used in machines that carry out only normal digging operations. Change the oil according to the indications given in table below.



4.7.9.b CHANGING THE COOLANT

⚠ WARNING


- Soon after the machine has been stopped the coolant is very hot and under pressure and it may cause serious burns; let the engine cool down until it reaches approximately 40-45°C (104-113°F) before changing the coolant.
- Slowly loosen the radiator cap, in order to release the residual pressure.
- Oils, filters, the coolant and the battery are considered special waste and must be collected and disposed of according to the anti-pollution regulations in force.



👉 IMPORTANT

- The following operations refer to the change of permanent coolants; if the coolant is water or water with antifreeze, which is used according to the season, it is necessary to wash the cooling circuit in order to eliminate any encrustation. (See “4.7.1.a WASHING THE COOLING CIRCUIT”).

- 1 - Remove the inspection cover (1) (use a 17 mm spanner) and open the engine hood (see “3.5.1 ENGINE HOOD”).
- 2 - Loosen and remove the radiator upper cap (2).
- 3 - Open the radiator drain cock (3), remove the drain plug (4) positioned on the engine block and let the fluid flow out. Use a 17 mm hexagon spanner. While the fluid flows out, empty the coolant tank (5).
- 4 - Close the drain cock (3), put back the plug (4) on the engine block and fill the radiator with new fluid (see “4.3 FUEL, COOLANT AND LUBRICANTS”).
- 5 - Start the engine and let it run at idling speed for a few minutes; check again and top up before positioning the upper cap (2).
- 6 - Fill the tank (5) until reaching the maximum level.
- 7 - Close the engine hood and put back the inspection cover (1).



4.7.9.c CHECKING AND ADJUSTING THE ENGINE VALVE CLEARANCE

Since the check and adjustment of the engine valve clearance require the use of special tools, have these operations carried out by your Komatsu Dealer.

4.7.9.d CHECKING THE ALTERNATOR AND THE STARTER


For any inspection and/or repair, contact your Komatsu Dealer.
If the engine is started frequently, have an inspection carried out every 1000 hours of operation.

**TECHNICAL
SPECIFICATIONS**


5.1 TECHNICAL DATA

5.1.1 STANDARD OVERALL DIMENSIONS (for PC35R only)

MACHINE WITH CAB AND STANDARD DIGGING ARM




MACHINE WITH CANOPY AND STANDARD DIGGING ARM




IMPORTANT

- If the machine is equipped with steel shoes instead of rubber shoes, the overall dimensions indicated in the drawing remain unchanged.

MACHINE WITH CAB AND LONG DIGGING ARM L=1750mm (5'9")



MACHINE WITH CANOPY AND LONG DIGGING ARM L=1750mm (5'9")



IMPORTANT

- If the machine is equipped with steel shoes instead of rubber shoes, the overall dimensions indicated in the drawing remain unchanged.

5.1.2 TECHNICAL CHARACTERISTICS PC35R

TOTAL MASS

Total mass with TOPS-FOPS canopy and steel shoes	kg 3555 (7837 lb)
Total mass with TOPS cab and steel shoes	kg 3670 (8090 lb)
Total mass with TOPS-FOPS canopy and rubber tracks	kg 3460 (7627 lb)
Total mass with TOPS cab and rubber tracks	kg 3575 (7881 lb)

STANDARD BUCKET CAPACITY

Capacity (SAE)	cu.m. 0.095 (0.12 cu.yd.)
--------------------------	---------------------------

ENGINE

Komatsu diesel engine model	3D84E-3FA
Maximum power (2500 rpm EEC 80/1269)	kW 20.6 (28 HP)
Maximum torque (1800 rpm EEC 80/1269)	Nm 90 (66 lb.ft.)

ELECTRICAL SYSTEM

Alternator	12V
Electrical output	40 A
Earthing	negative
Battery	80 Ah - 12V
Starter	kW 1.2


UPPER STRUCTURE ROTATION

Upper structure rotation speed	rpm 9.0
--	---------


SPEEDS

Travel speed with steel shoes	km/h 2.8 (1.73 MPH)
Travel speed with rubber tracks	km/h 2.8 (1.73 MPH)
Travel speed with increase and steel shoes	km/h 4.6 (2.85 MPH)
Travel speed with increase and rubber tracks	km/h 4.6 (2.85 MPH)

**5.1.3 STANDARD OVERALL DIMENSIONS (for PC45R only)
MACHINE WITH CAB AND STANDARD DIGGING ARM**




MACHINE WITH CANOPY AND STANDARD DIGGING ARM




IMPORTANT

- If the machine is equipped with steel shoes instead of rubber shoes, the overall dimensions indicated in the drawing remain unchanged.

MACHINE WITH CAB AND LONG DIGGING ARM L=1900mm (6'2")



MACHINE WITH CANOPY AND LONG DIGGING ARM L=1900mm (6'2")



IMPORTANT

- If the machine is equipped with steel shoes instead of rubber shoes, the overall dimensions indicated in the drawing remain unchanged.

5.1.4 TECHNICAL CHARACTERISTICS PC45R

TOTAL MASS

Total mass with TOPS-FOPS canopy and steel shoes	kg 4640 (10229 lb)
Total mass with TOPS cab and steel shoes	kg 4760 (10493 lb)
Total mass with TOPS-FOPS canopy and rubber tracks	kg 4530 (9986 lb)
Total mass with TOPS cab and rubber tracks	kg 4650 (10251 lb)

STANDARD BUCKET CAPACITY

Capacity (SAE)	cu.m 0.15 (0.19 cu.yd.)
--------------------------	-------------------------

ENGINE

Komatsu diesel engine model	4D84E-3FA
Maximum power (2500 rpm EEC 80/1269)	kW 28.3 (38 HP)
Maximum torque (1800 rpm EEC 80/1269)	Nm 118 (87 lb.ft.)

ELECTRICAL SYSTEM

Alternator	12V
Electrical output	40 A
Earthing	negative
Battery	80 Ah - 12V
Starter	kW 1.2

UPPER STRUCTURE ROTATION

Upper structure rotation speed	rpm 9.0
--	---------


SPEEDS

Travel speed with steel shoes	km/h 2.8 (1.73 MPH)
Travel speed with rubber tracks	km/h 2.8 (1.73 MPH)
Travel speed with increase and steel shoes	km/h 4.6 (2.85 MPH)
Travel speed with increase and rubber tracks	km/h 4.6 (2.85 MPH)

5.1.5 LIFTING CAPACITY WITH CAB (for PC35R only)




- Do not attempt to lift loads unless the machine is standing on firm, level ground.




 L	A \ B		2 m (6.5 ft)	3 m (9.8 ft)	4 m (13 ft)	MAX
			 ---	 ---	 ---	 ---
L = 1.35 m L = 4.4 ft	3m	Kg	---	580	440	440
	9.8 ft	lb	---	1276	968	968
	2m	Kg	990	580	390	340
	6.5 ft	lb	2178	1276	858	748
	1m	Kg	990	630	390	340
	3.3 ft	lb	2178	1386	858	748
	0.0m	Kg	990	630	390	340
	0.0 ft	lb	2178	1386	858	748
	-1m	Kg	990	580	390	340
	-3.3 ft	lb	2178	1276	858	748
L = 1.75 m L = 5.7 ft	0.0m	Kg	990	550	340	290
	0.0 ft	lb	2178	1210	748	638

5.1.6 LIFTING CAPACITY WITH CANOPY (for PC35R only)



CAUTION

- Do not attempt to lift loads unless the machine is standing on firm, level ground.




	A \ B		2 m (6.5 ft)	3 m (9.8 ft)	4 m (13 ft)	MAX
L = 1.35 m L = 4.4 ft	3m	Kg	---	580	440	440
	9.8 ft	lb	---	1276	968	968
	2m	Kg	990	580	390	340
	6.5 ft	lb	2178	1276	858	748
	1m	Kg	990	630	390	340
	3.3 ft	lb	2178	1386	858	748
	0.0m	Kg	990	630	390	340
	0.0 ft	lb	2178	1386	858	748
	-1m	Kg	990	580	390	340
	-3.3 ft	lb	2178	1276	858	748
L = 1.75 m L = 5.7 ft	0.0m	Kg	990	550	340	290
	0.0 ft	lb	2178	1210	748	638

5.1.7 LIFTING CAPACITY WITH CAB (for PC45R only)




CAUTION

- Do not attempt to lift loads unless the machine is standing on firm, level ground.




5.1.8 LIFTING CAPACITY WITH CANOPY (for PC45R only)



CAUTION

- Do not attempt to lift loads unless the machine is standing on firm, level ground.



PAGE INTENTIONALLY LEFT BLANK

**AUTHORISED
OPTIONAL
EQUIPMENT**

6.1 AUTHORIZED OPTIONAL EQUIPMENT



CAUTION

- **Komatsu machines can be supplied with optional equipment in addition to the standard equipment; if optional equipment is installed and used, carefully read the relevant operation manual and keep to the instructions given therein.**
 - **Use exclusively optional or special equipment recommended and approved by Komatsu and complying with the requisites indicated in the table (See “6.1.3 CHARACTERISTICS OF THE OPTIONAL EQUIPMENT”).**
 - **Komatsu cannot be held liable for any damage, accident, reduction of the machine efficiency due to the application and use of unauthorized equipment.**
-

6.1.1 PRECAUTIONS REGARDING SAFETY

The installation of optional accessories and equipment other than those authorized by Komatsu negatively affects the life of the machine, but can also cause problems concerning safety.

It is advisable to contact a Komatsu Dealer before installing any accessory not indicated in this operation and maintenance manual.

In case of failure to comply with this rule, Komatsu declines any responsibility for accidents or damage.



WARNING

- **When removing or installing any equipment, take the following precautions and be careful to the safety conditions.**
 - **Carry out installation and removal on a firm and flat surface.**
 - **When the operations are carried out by two or more operators, decide the communication signals in advance and respect them during the operations.**
 - **Use a crane to handle objects weighing more than 25 kg (55 lb).**
 - **Always support any heavy part before moving it. When heavy parts are lifted, be always careful to the center of gravity of the object being handled.**
 - **It is very dangerous to carry out any operation with a suspended load, therefore, always position the load on a support and make sure that it is in a safe position.**
 - **When installing or removing any equipment, make sure that it is stable and cannot fall down.**
 - **Do not stand under loads being lifted by a crane.**
Take care to choose a safe position, where you do not run any risk in case the load should fall down.
-



IMPORTANT

- **Specialized personnel is required to operate cranes. Do not allow non-specialized personnel to use cranes.**
-


For further details regarding installation and removal operations, contact your Komatsu Dealer.

6.1.2 PRECAUTIONS REGARDING THE INSTALLATION OF EQUIPMENT




- The use of lengthened work equipment reduces the stability of the machine.
If it is necessary to rotate the upper structure on a slope or to travel downhill, be particularly careful, since the machine may lose its balance and overturn.
The following operations are particularly dangerous, therefore it is highly recommended not to perform them.


1 - Travelling downhill with raised work equipment.



2 - Transversal crossing of slopes.



3 - Rotation of the upper structure on slopes.



- When installing work equipment with dimensions exceeding those of the standard equipment, be careful to the space necessary for the movements of the equipment and for the rotation of the upper structure.
- Always keep to the correct procedure when installing the boom and arm. Failure to carry out the correct procedure may result in grave risks, therefore it is advisable to contact a Komatsu Dealer before the installation.

6.1.3 CHARACTERISTICS OF THE OPTIONAL EQUIPMENT

(FOR MODEL PC35R ONLY)

(Specific weight of the handled material = 1.8 t/cu.m.)

EQUIPMENT	MAX. WEIGHT kg (lb)	MAX. DIMENSIONS		MAX. SAE CAPACITY cu. m (cu. yd.)	MAX. OPERATING PRESSURE bar (psi)	MAX. FLOW RATE l/min. (gpm)
		Width mm (inch)	Height mm (inch)			
Bucket	90 (198)	750 (29.5)	— (—)	0.120 (0.15)	— (—)	— (—)
Ditch-cleaning bucket	50 (110)	1400 (55.1)	— (—)	0.075 (0.09)	— (—)	— (—)
Ditch-digging bucket	80 (176)	1000 (39.3)	— (—)	0.100 (0.13)	— (—)	— (—)
Clamshell bucket	150 (330)	500 (19.6)	1200 (47.2)	0.050 (0.06)	210 (3045)	35 (507)
Hydraulic hammer	200 (441)	— (—)	1000 (39.3)	— (—)	140 (2030)	50 (725)
Drill	130 (286)	300* (11.8)	2200● (86.6)	— (—)	210 (3045)	60 (870)

* Measure referred to the tool diameter

● Measure referred to the tool length

(FOR MODEL PC45R ONLY)

(Specific weight of the handled material = 1.8 t/cu.m.)

EQUIPMENT	MAX. WEIGHT kg (lb)	MAX. DIMENSIONS		MAX. SAE CAPACITY cu. m (cu. yd.)	MAX. OPERATING PRESSURE bar (psi)	MAX. FLOW RATE l/min. (gpm)
		Width mm (inch)	Height mm (inch)			
Bucket	110 (242)	800 (31.5)	— (—)	0.175 (0.22)	— (—)	— (—)
Ditch-cleaning bucket	60 (132)	1500 (59)	— (—)	0.100 (0.13)	— (—)	— (—)
Ditch-digging bucket	100 (220)	1000 (39.3)	— (—)	0.125 (0.16)	— (—)	— (—)
Clamshell bucket	200 (441)	600 (23.6)	1300 (51.1)	0.060 (0.07)	210 (3045)	40 (580)
Hydraulic hammer	200 (441)	— (—)	1000 (39.3)	— (—)	140 (2030)	60 (870)
Drill	200 (441)	350 * (13.7)	2200 ● (86.6)	— (—)	210 (3045)	60 (870)

* Measure referred to the tool diameter

● Measure referred to the tool length

6.2 ARRANGEMENT FOR THE INSTALLATION OF THE DEMOLITION HAMMER (BREAKER)






WARNING

- For the characteristics of the hammer, see “6.1.3 CHARACTERISTICS OF THE OPTIONAL EQUIPMENT”.
- The demolition hammer is very noisy, therefore always wear headphones when using it.

6.2.1 DESCRIPTION AND CONTROL

The machine is fitted for the application of a demolition hammer; the operation of the hammer is obtained by means of an additional distributor controlled by a pedal (1) positioned on the left side. The hammer is operated by pressing the pedal (1) with the toe, since pressurized oil is thus introduced in the delivery circuit (left side); the oil flow is interrupted and the hammer is thus stopped by releasing the pedal.

To use the demolition hammer, make sure that the control of the selection valve (2) is completely rotated anticlockwise (Pos. A).



6.2.2 USE OF THE DEMOLITION HAMMER AND RULES TO BE OBSERVED


The choice of the suitable tool is a very important factor to obtain the maximum productivity from the demolition hammer.

The geometry of the tool must be defined according to the nature of the material to be broken and to the type of work to be carried out.

The hammer is used to break floors, cement structures, walls, small rocky surfaces, excavations with open section, asphalt, etc. With the application of special tools it can also be used as asphalt-cutter or compactor.

FOR A CORRECT USE, IT IS NECESSARY TO:

- 1 - Make sure that the position of the hammer with respect to the material to be broken is as perpendicular as possible and that the arm thrust is sufficient, so that all the power of the hammer can be exploited.




ARRANGEMENT FOR THE INSTALLATION OF THE DEMOLITION HAMMER (BREAKER)

- 2 - Keep the pressure of the excavator on the hammer constant as the bit penetrates in the material.


Always follow the hammer in the penetration phase and operate the excavator arms in order to obtain a pressure sufficient to keep the undercarriage raised at about 5 mm (0.2 in) from the ground.

Do not raise the undercarriage more than necessary.




- 3 - When working on very hard materials, it is important not to keep hitting the same point for more than 30 seconds.


Hit the same point for a few seconds and change position very frequently, in order to facilitate the breaking of the material.



- 4 - To facilitate the sliding of the tool on its seat, check the thrust direction and always correct the hitting position of the hammer by means of the bucket and arm control.



- 5 - Always check that the arm thrust is optimal, in order to avoid harmful and useless strokes.




 **IMPORTANT**


- During work, do not use the demolition hammer with the bucket cylinder at the end of its stroke, but always leave a minimum space of 5 cm (1.97 in).
-

ALWAYS AVOID THE FOLLOWING INCORRECT USES:


1 - Gathering or moving stones with the demolition hammer.



2 - Rotating the upper structure while using the hammer.




3 - Moving the tool while it is hitting the material to be broken.




ARRANGEMENT FOR THE INSTALLATION OF THE DEMOLITION HAMMER (BREAKER)


4 - Working with the hammer in horizontal position or even with greater inclination.




5 - Lever with the tool after thrusting it into the material to be broken.



6 - Hitting the ground with the hammer bit.



7 - Lifting the machine by levering on the hammer bit with the bucket cylinder extended to the end of its stroke.



6.2.3 INSTALLING AND REMOVING THE DEMOLITION HAMMER

6.2.3.1 INSTALLING THE HAMMER



WARNING

- The machine must be parked on a level surface, with the equipment resting on the ground.
- For the installation, the hammer must be positioned horizontally, with the bit directed towards the machine.
- When the coupling pins are removed or installed, chips may come off; always wear gloves, safety goggles and helmet.
- The change of the equipment must be carried out by two operators, who must decide together the words and signals to be used during operations.
- Do not use your fingers to center the holes, since they may be injured or even cut.
- Release the residual pressure that may be present in the pipes completely.




For the installation of the demolition hammer it is necessary to connect the mechanical constraints of the bucket as described in "3.13.4 CHANGING THE BUCKET" and to carry out the hydraulic connections using the pipes provided. After connecting the mechanical constraints, carry out the hydraulic connections by proceeding as follows:

- 1 - Stop the engine and move the hydraulic controls in all directions, in order to completely release the residual pressures present in the circuits of the machine.
- 2 - Press the hammer control pedal to release the residual pressure present in the hammer delivery pipe.
- 3 - Slowly loosen the hydraulic oil filling cap, in such a way as to release the residual pressure from the tank.
- 4 - Remove the sealing plugs of the rapid couplings of both the machine and the hammer.
- 5 - Connect the right (1) and left (2) pipes. The rapid couplings must be in compliance with the ISO 7241-1 series "B" standard.



CAUTION

- When connecting the pipes, take care to prevent any impurities from getting into them.
- 6 - Rotate the control of the selection valve (3) completely anti-clockwise (Pos. A).
 - 7 - Start the machine and raise the demolition hammer positioning it vertically.



- 8 - Stop the machine again and lubricate the joints (See "4.5 LUBRICATION") and the hammer (See the specific use and maintenance manual).
- 9 - Before starting work, check the seals.



WARNING

- **Always wear thick gloves and safety goggles during this check.**
 - **To check the system for leaks, use a piece of cardboard or a wooden board.**
-

6.2.3.2 REMOVING THE HAMMER

To remove the hammer, proceed as follows:

- 1 - Stop the engine and move the hydraulic controls in all directions, in order to completely release the residual pressures present in the circuits of the machine.
- 2 - Press the hammer control pedal to release the residual pressure present in the hammer delivery pipe.
- 3 - Slowly loosen the hydraulic oil filling cap to release the residual pressure from the tank.
- 4 - Disconnect the hammer feeding and draining pipes.
- 5 - Fit the sealing plugs of the rapid couplings.
- 6 - Disconnect the hammer from the mechanical constraints, as described in "3.13.4 CHANGING THE BUCKET".

6.2.4 MAINTENANCE

The hydraulic system does not require any maintenance operation and inspection other than those prescribed for the machine.



For the maintenance operations required for the hammer, see the specific operation manual.

6.3 ARRANGEMENT FOR THE OPERATION OF OPTIONAL EQUIPMENT

The machine is equipped with an independent hydraulic circuit for the operation of optional equipment that can be installed instead of the standard bucket.

The oil flow in the circuit is controlled by a selection valve (1) and a pedal (2) that controls the additional distributor provided for the operation of the equipment.

Delivery and draining pipes for the oil necessary for the operation of the equipment are also provided as a fixed installation and reach the coupling.



6.3.1 SELECTION VALVE (1)


This is a three-way valve and is used to change the direction of the hydraulic oil flow.

Pos. A (Valve control completely rotated anticlockwise)

The oil returning from the equipment is directly deviated to the tank outlet. This position is specific for the use of the demolition hammer.

Pos. B (Valve control completely rotated clockwise)



The oil flow is deviated to the distributor, thus obtaining a direct passage between the distributor and the equipment. This position is used for equipment with double delivery (clamshell bucket, drill, etc.).




6.3.2 CONTROL PEDAL (2)

This pedal controls the delivery and return of the oil to the optional equipment.


1 - If the pedal is pressed in (A), high-pressure oil is conveyed to the equipment through the left piping (3).



2 - If the pedal is pressed in (B) with the selection valve (1) control in (B), high-pressure oil is conveyed to the equipment through the right piping (4).



3 - If the circuit is arranged for the use of equipment with unidirectional flow (demolition hammer, etc.) and therefore with the selection valve (1) control in pos. (A), press the pedal (2) in (A) only, since the right piping (4) serves exclusively for the return of the oil to the tank.



6.3.3 ASSEMBLY AND CONNECTING THE EQUIPMENT

WARNING

- The machine must be parked on a level surface, with the equipment resting on the ground.
- When the coupling pins are removed or installed, chips may come off; always wear gloves, safety goggles and helmet.
- The change of the equipment must be carried out by two operators, who must decide together the words and signals to be used during operations.
- Do not use your fingers to center the holes, since they may be injured or even cut.
- Release the residual pressure that may be present in the pipes completely.

For the installation of the equipment it is necessary to connect the mechanical constraints of the bucket as described in “3.13.4 CHANGING THE BUCKET” and to carry out the hydraulic connections using the pipes provided.

After connecting the mechanical constraints, carry out the hydraulic connections by proceeding as follows:

- 1 - Stop the engine and move the hydraulic controls in all directions, in order to completely release the residual pressures present in the circuits of the machine.
- 2 - Press the optional equipment control pedal to release the residual pressure present in the delivery pipe.
- 3 - Slowly loosen the hydraulic oil filling cap, in such a way as to release the residual pressure from the tank.
- 4 - Remove the sealing plugs of the machine rapid couplings and of the equipment rapid couplings.
- 5 - Connect the right (1) and left (2) pipes. The rapid couplings must be in compliance with the ISO 7241-1 series “B” standard.


CAUTION

- When connecting the pipes, take care to prevent any impurities from getting into them.


- 6 - Start the machine and perform several manoeuvres with the equipment control pedal, in order to check the seals.

WARNING

- Always wear thick gloves and safety goggles during this check.
- To check the system for leaks, use a piece of cardboard or a wooden board.



RWA07950



RWA11000

6.3.4 MAINTENANCE

The hydraulic system does not require any maintenance operation and inspection other than those prescribed for the machine.

For the maintenance operations required for the equipment, see the specific operation manuals.