

Operation & Maintenance Manual

SEAM042KD200

WA450-2

WHEEL LOADER

SERIAL NUMBERS **WA450 :A25001** and up

KOMATSU

FOREWORD

This manual describes procedures for operation, handling, lubrication, maintenance, checking, and adjustment. It will help the operator or anyone realize peak performance through effective, economical and safe machine operation and maintenance.

- Please read this manual carefully BEFORE operating the machine.
- Please continue studying this manual until proper operation is completely reinforced into personal habit.
- This manual describes the basic techniques. Skill is performed as the operator or anyone get the correct knowledge and performance of the machine.
- Operation, inspection, and maintenance should be carefully carried out, and the safety must be given the first priority. Safety precautions are indicated with **▲** marks and technical precautions with * marks in this manual. The safety information contained in this manual is intended only to supplement safety codes, insurance requirements, local laws, rules and regulations.
- Some photographs and illustration pictures are different from your machine as technical improvement is continuously reflected on it. Revision to up-to-date manual's content is performed in later editions.
- This operation & maintenance manual may contain attachments and optional equipment that are not available in your area. Please consult your local distributor for those items you may require.

Materials and specifications are subject to change without notice.

NOTE

See Cummins Engine Company Ltd. manual

- Operation and Maintenance Manual
L10 Series Engines
(Bulletin No. 3810239-03)

BREAKING IN YOUR NEW MACHINE

Each machine is carefully adjusted and tested before shipment. However, a new machine requires careful operation during the first 100 hours to break in the various parts.

If a machine is subjected to unreasonably hard use at the initial operation stage, the potential of performance will prematurely deteriorate and the service life will be reduced. A new machine must be operated with care, particularly with regard to the following items.

- After starting, let the engine idle for 3 to 5 minutes to allow proper engine warm-up prior to actual operation.
 - Avoid operation with heavy loads or at high speeds.
 - Sudden starting or acceleration, unnecessarily abrupt braking and sharp turning should be avoided.
 - At the first 250 hours of operation, the machine should be maintained in the following manner in addition to usual 250 hours service.
- 1) Replacement of transmission oil filter element.

For replacement procedure and details, see maintenance table in the maintenance section.

- * When replacing oil filter elements (cartridges), check their interiors for dirt and dust. If heavily collected, check for possible cause before starting operation.
- * Hours of operation are indicated by the service meter.

CONTENTS

DESCRIPTION	PAGE
OPERATION	
GENERAL LOCATIONS AND SPECIFICATIONS	2
PERFORMANCE	2
OPERATING WEIGHT	2
ENGINE	2
INSTRUMENTS AND CONTROLS	
MONITOR PANEL	3
CHECK MONITOR GROUP	5
Engine Oil Level Monitor	5
Coolant Level Monitor	5
CAUTION MONITOR GROUP	6
Charge Monitor	6
Fuel Level Monitor	6
CAUTION MONITOR GROUP	7
Brake Line Failure Monitor	7
Engine Oil Pressure Monitor	7
Coolant Level Monitor	7
Air Pressure Monitor	8
Coolant Temperature Monitor	8
Torque Converter Oil Temperature Monitor	8
METER GROUP	9
Parking Brake Pilot Lamp	9
Pilot Lamp for Working Lamp	9
Transmission Cut-Off Selector Pilot Lamp	10
Air Pressure Gauge	10
Engine Cooling Water Temperature Gauge	10
Torque Converter Oil Temperature Gauge	11
Fuel Gauge	11
Turn Signal Pilot Lamp	11
High Beam Pilot Lamp	12
Speedometer	12
Service Meter	13
SWITCHES	13
TRANSMISSION CUT-OFF SELECTOR SWITCH	13
ETHER START SWITCH	14
HORN BUTTON	14
HAZARD LAMP SWITCH	14
PARKING BRAKE SWITCH	15
WORKING LAMP SWITCH	15
STARTING SWITCH	16
LAMP SWITCHES	16
Lamp switch	16
Turn signal lever	16
Dimmer switch	17
ROOM LAMP SWITCH	17
CIGARETTE LIGHTER	18
KICKDOWN SWITCH	18
FRONT WIPER SWITCH	19
REAR WIPER SWITCH	19
LEVERS AND PEDALS	20
DIRECTIONAL LEVER	20
SPEED CONTROL LEVER	20
SPEED CONTROL LEVER STOPPER	21
STEERING COLUMN TILT LEVER	21
ACCELERATOR PEDAL	21

CONTENTS - Continued

DESCRIPTION	PAGE
BRAKE PEDALS	21
Right brake pedal	21
Left brake pedal	22
LIFT ARM CONTROL LEVER	22
BUCKET CONTROL LEVER	22
SAFETY LOCK	23
AIR CLEANER SERVICE INDICATOR	23
SAFETY BAR	23
WORK EQUIPMENT CONTROL LEVER (MONO-LEVER TYPE)	24
CIRCUIT BREAKER (MAIN)	24
DOOR-OPEN LOCK	24
FUSE BOX	26
OPERATOR'S SEAT	26
FORWARD-BACKWARD ADJUSTMENT	26
SEAT ANGLE ADJUSTMENT	26
SEAT CUSHION ADJUSTMENT	26
BACKREST ADJUSTMENT	26
SEAT HEIGHT ADJUSTMENT	27
RIGHT SIDE ARMREST	27
FORWARD-BACKWARD ADJUSTMENT	27
ANGLE ADJUSTMENT	27
SEAT BELT	27
CHECK BEFORE STARTING	28
WALK-AROUND CHECK	28
CHECK MONITOR PANEL	29
CHECK AND REFILL COOLANT	29
CHECK OIL LEVEL AND REFILL IN ENGINE OIL PAN	30
CHECK FUEL LEVEL AND REFILL FUEL	30
CHECK AIR CLEANER SERVICE INDICATOR	31
DRAIN WATER FROM AIR TANKS	31
FUEL-WATER SEPARATOR	32
FAN - INSPECTION	32
DRIVE BELT	32
FAN DRIVE BELT - INSPECTION	32
BELT TENSION - CHECK	33
BELT TENSION - CHECK AND ADJUST	34
FAN DRIVE BELT - ADJUST	34
ALTERNATOR DRIVE BELT - ADJUST	34
OPERATING YOUR MACHINE	35
BEFORE STARTING THE ENGINE	35
TO START THE ENGINE	36
SPECIAL STARTING	37
CHECKS AFTER STARTING	37
TO MOVE THE MACHINE OFF	38
CHANGING GEAR SPEED	38
CHANGING DIRECTION	39
TURNING	40
TO STOP THE MACHINE	41
TO STOP THE ENGINE	41
MAXIMUM DEPTH OF WATER	41
IF WHEEL BRAKE DOES NOT WORK	42
PRECAUTIONS WHEN DRIVING UP OR DOWN SLOPES	42
LOWER THE CENTER OF GRAVITY WHEN TURNING	42
BRAKING ON DOWNHILL SLOPES	42
IF ENGINE STOPS	42
PROPER BUCKET AND TIRE	42


CONTENTS - Continued

DESCRIPTION	PAGE
ADJUSTMENT OF WORK EQUIPMENT	43
ADJUSTING BOOM KICKOUT	43
ADJUSTING BUCKET POSITIONER	44
BUCKET LEVEL INDICATOR	44
USING ACCUMULATORS	45
PRECAUTIONS FOR MAINTENANCE	45
HANDLING TIRES	45
PRECAUTIONS WHEN HANDLING TIRES	45
PRECAUTIONS WHEN DRIVING MACHINE	46
TIRE PRESSURE	46
INFLATING TIRES	47
TOWING	48
TOWING THE MACHINE	48
WHEN ENGINE CAN BE USED	48
WHEN ENGINE CANNOT BE USED	48
RELEASING PARKING BRAKE	48
COLD WEATHER OPERATION	49
PREPARATION FOR LOW TEMPERATURE	49
FUEL AND LUBRICANTS	49
COOLANT	49
BATTERY	49
STARTING IN COLD WEATHER	50
CAUTIONS AFTER COMPLETION OF WORK	51
AFTER COLD WEATHER	51
MEMORANDA	52
MAINTENANCE	
PERIODIC MAINTENANCE	2
BLEEDING AIR FROM CIRCUIT	2
BLEEDING AIR FROM HYDRAULIC CIRCUIT	2
PERIODICAL REPLACEMENT OF SAFETY PARTS	3
MAINTENANCE TABLE	4
OIL FILLER AND LEVEL GAUGE POSITIONS	8
CHECK BEFORE STARTING	9
EVERY 50 HOURS SERVICE	9
FUEL TANK	9
TIRE	9
EVERY 100 HOURS SERVICE	9
HYDRAULIC TANK	9
LUBRICATING	10
AIR CONDITIONER FILTER	10
INITIAL 250 HOURS SERVICE	11
TRANSMISSION OIL FILTER	11
EVERY 250 HOURS SERVICE	11

CONTENTS - Continued

DESCRIPTION	PAGE
ENGINE OIL PAN AND FILTER	11
AIR INTAKE SYSTEM	13
CHECK ELECTROLYTE LEVEL IN BATTERY	13
FUEL FILTER	14
CRANKCASE BREATHER	15
CORROSION RESISTOR (Coolant filter)	16
COOLANT ADDITIVE CONCENTRATION	17
LUBRICATING	18
AIR CONDITIONER COMPRESSOR BELT	20
WHEEL HUB NUTS	21
EVERY 500 HOURS SERVICE	21
TRANSMISSION OIL FILTER	21
LUBRICATING	22
AIR DRYER	22
EVERY 1000 HOURS SERVICE	23
TRANSMISSION CASE AND STRAINER	23
TRANSMISSION CASE BREATHER	24
LUBRICATING	24
EVERY 1500 HOURS SERVICE	27
VALVES AND INJECTORS	27
EVERY 2000 HOURS SERVICE	28
HYDRAULIC TANK AND FILTER	28
AIR CONDITIONER FILTER	29
HYDRAULIC TANK BREATHER	29
AXLE	29
PPC CIRCUIT STRAINER	31
ALTERNATOR AND STARTING MOTOR	31
BRAKE DISC	31
INTERNAL PART OF AIR DRYER	31
ACCUMULATOR	31
EVERY 6000 HOURS SERVICE	32
INJECTORS	32
FUEL PUMP	32
TURBOCHARGER	32
AIR COMPRESSOR	33
WATER PUMP	36
FAN IDLER PULLEY	36
FAN HUB (BELT DRIVEN)	37
COOLANT CHANGE AND FLUSHING THE SYSTEM	37
COOLANT	37
DCA4 UNIT MAINTENANCE GUIDE	37
WHEN REQUIRED	40
TURBOCHARGER MOUNTING NUTS	40
CHECK, CLEAN AND REPLACE AIR CLEANER ELEMENT	41
CHECKING	41
CLEANING OR REPLACING OUTER ELEMENT	41
REPLACING INNER ELEMENT	42
CLEANING OUTER ELEMENT	42
With compressed air	42
With water	42
With cleaning agent	42
CHECK AND REFILL TRANSMISSION OIL	43

CONTENTS - Continued

DESCRIPTION	PAGE
CLEAN RADIATOR FINS	43
CHECK AND REFILL AXLE OIL	44
CLEAN AXLE CASE BREATHER	44
LUBRICATING	45
CLEAN CONDENSER OF AIR CONDITIONER	45
CHECK AIR CONDITIONER	46
CHECK LEVELS OF REFRIGERANT (GAS)	46
CHECK AND REFILL WINDOW WASHING FLUID	47
REPLACING BUCKET TEETH	47
IF THE BUCKET EQUIPPED WITH BOLT-ON TOOTH	47
IF THE BUCKET EQUIPPED WITH TIP TOOTH	48
REVERSING AND REPLACING BOLT-ON CUTTING EDGE	48
IF THE BUCKET EQUIPPED WITH BOLT-ON CUTTING EDGE	48
ADJUSTMENT	49
ADJUSTING PARKING BRAKE	49
ADJUSTING LENGTH OF LEVER	50
TROUBLE SHOOTING GUIDE	51
ELECTRICAL SYSTEM	51
ENGINE	52
CHASSIS	53
TRANSMISSION	53
AXLE	53
DISC BRAKE	53
PARKING BRAKE	53
STEERING	54
SERVICE METER	54
MACHINE AND ENGINE SERIAL NUMBERS	55
FUEL, COOLANT AND LUBRICANTS	56
MEMORANDA	58
SAFETY AND OPERATION	
SAFETY HINTS. . . 	2
OPERATION	2
GENERAL	2
CHECKING JOBSITE CONDITIONS	4
BEFORE STARTING OPERATION	5
CHECK BEFORE STARTING	5
PRECAUTIONS WHEN GETTING ON THE MACHINE	7
PRECAUTIONS WHEN STARTING THE ENGINE	7
CHECKS AFTER STARTING THE ENGINE	8
DURING OPERATION	8
ATTENTION TO SURROUNDINGS	9
RESTRICTIONS CREATED BY JOBSITE	11
PARKING	13
PRECAUTIONS FOR MAINTENANCE	14
GENERAL	14
BEFORE MAINTENANCE	16
DURING MAINTENANCE	17
MISCELLANEOUS	18

CONTENTS - Continued

DESCRIPTION	PAGE
BUCKET OPERATION	19
EXCAVATION	19
LEVELING	22
LOAD AND CARRY OPERATIONS	22
LOADING	22
CROSS DRIVE LOADING	23
V-SHAPE LOADING	23
OPERATING THE AIR CONDITIONER	24
EQUIPMENT ON CONTROL PANEL	24
FAN SWITCH	24
AIR CONDITIONER SWITCH	24
AIR INTAKE SELECTOR LEVER	24
TEMPERATURE CONTROL LEVER	24
PRECAUTIONS FOR USING AIR CONDITIONER	25
HANDLING THE AIR CONDITIONER IN SEASON	26
HANDLING THE AIR CONDITIONER IN OFF SEASONS	26
OPERATING CAB HEATER	26
EQUIPMENT ON CONTROL PANEL	26
FAN SWITCH	26
TEMPERATURE CONTROL LEVER	26
AIR INTAKE SELECTOR LEVER	26
LOCKING CAP	28
HANDLING OF BATTERY	29
PRECAUTIONS FOR CHARGING BATTERY	29
REMOVAL AND INSTALLATION OF BATTERY	29
STARTING ENGINE WITH A BOOSTER CABLE	30
TRANSPORTATION	31
STORAGE	32
BEFORE STORAGE	32
DURING STORAGE	32
AFTER STORAGE	32
COOLANT AND LUBRICANTS	33


SECTION 1
OPERATION



**WARNING! REFER TO AND READ ALL
SAFETY PRECAUTIONS IN SECTION 3.**

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS



WA450-2 with cab and ROPS canopy

- | | |
|---------------------|------------------|
| 1. Tilt lever | 6. Front wheel |
| 2. Lift arm | 7. Lift cylinder |
| 3. Head lamp | 8. Dump cylinder |
| 4. Turn signal lamp | 9. Bucket |
| 5. Rear wheel | |

PERFORMANCE

1. Bucket capacity (Heaped) 4.2 m³
2. Travel speeds

Forward	Max. 31.9 km/h (19.8 MPH)
Reverse	Max. 35.1 km/h (21.8 MPH)


OPERATING WEIGHT 21700 kg

ENGINE

1. Model Cummins LTA 10C diesel engine
2. Flywheel horsepower (at 2100 rpm) 264 HP

NOTE: Specifications are subject to change without notice.

INSTRUMENTS AND CONTROLS MONITOR PANEL



This monitor system consists of monitor lamp groups (A B C), meter group D and warning lamp E.

- To check the monitor system, turn the starting switch to ON before starting the engine. Then all the monitor lamps, the gauges and the warning lamp light up for about 3 seconds and the alarm buzzer sounds for about 1 second. Three figures, 188, are displayed on the speedometer while the monitor system is being checked. After that all lamps go off and the buzzer stops. If any monitor lamp does not light up, ask your distributor to inspect that monitor lamp.
- * When the starting switch is turned to ON, if the directional lever is not at neutral, the warning lamp will flash and the alarm buzzer will continue to sound. If this happens, return the lever to neutral. The lamp will go out and the buzzer will stop.
- * To check the monitor immediately when the engine is stopped, wait for at least 30 seconds after the engine is stopped.

CHECK MONITOR GROUP
(Check items before starting)

If there is any abnormality, the appropriate monitor lamp will flash.

- * When the engine is started, these monitor lamps will go off even if there are abnormalities.

CAUTION MONITOR GROUP
(Caution items)

If any abnormality occurs while the engine is running, the appropriate monitor lamp will flash to indicate the abnormality.

- * Even if any monitor lamp flashes, the machine can operate, but it should be repaired as soon as possible.

CAUTION MONITOR GROUP
(Emergency stop items)

If any abnormality occurs while the engine is running, the appropriate monitor lamp will flash and the alarm buzzer will sound intermittently at the same time.

- * If any monitor lamp flashes, stop the engine or run it at a low idling speed, and repair it immediately.

METER GROUP

This group consists of air pressure gauge, engine water temperature gauge, torque converter oil temperature gauge, fuel gauge, speedometer, service meter and pilot display.


WARNING LAMP

The warning lamp will flash when there is an abnormality in any B group item.

The warning lamp will flash and the alarm buzzer will sound when there is an abnormality in any C group item or when the parking brake is applied, but the directional lever is not at neutral.

CHECK MONITOR GROUP (Check items before starting)


- * Do not rely on the "CHECK MONITOR GROUP (Check before starting)" only for the check before starting. Always make the check by referring to the section on CHECK BEFORE STARTING.



Engine Oil Level Monitor

This monitor indicates a low oil level in the engine oil pan.

If the monitor lamp flashes, check the oil level in the engine oil pan and add oil as required.




Coolant Level Monitor

This monitor indicates a low radiator coolant level.

If the monitor lamp flashes, check the coolant level and add water as required.

- * Park the machine on level ground and check the monitor lamps.
- * Confirm that these monitor lamps light for about 3 seconds after turning the starting switch to ON. If any monitor lamp does not light, ask your distributor to inspect that monitor lamp.



CAUTION MONITOR GROUP (Caution items)


If any abnormality occurs while the engine is running, the appropriate monitor lamp and the warning lamp will flash to indicate the abnormality at the same time.

Charge Monitor

This monitor indicates an abnormality in the charging system while the engine is running.

If the monitor lamp flashes, check the charging circuit.

- * This monitor lamp flashes and the alarm buzzer sounds, when the starting switch is turned to ON immediately after the engine is started or immediately before the engine is stopped. It does not indicate an abnormality.




Fuel Level Monitor

This monitor indicates there is less than 35 liters of fuel in the tank.

If the monitor lamp flashes, add fuel.

- * Park the machine on level ground and check the monitor lamps.
- * Confirm that these monitor lamps light for about 3 seconds after turning the starting switch to ON. If any monitor lamp does not light, ask your distributor to inspect that monitor lamp.



CAUTION MONITOR GROUP (Emergency stop items)


If any abnormality occurs while the engine is running, the appropriate monitor lamp and the warning lamp will flash and the alarm buzzer will sound intermittently at the same time.

Brake Line Failure Monitor

This monitor indicates a drop in the brake oil pressure when the brakes are operated.

If the lamp flashes, stop the machine immediately and check the brake system.

- * After checking and repair of brake system, push in over-stroke sensor rod on the brake chamber. If this operation is not done, a buzzer and lamp will continue to warn of brake line trouble.




Engine Oil Pressure Monitor

This monitor indicates a low engine oil pressure.

If the lamp flashes, the engine oil pressure is below the lower limit. Immediately stop the engine.


- * This monitor lamp flashes and the alarm buzzer sounds, when the starting switch is turned to ON immediately after the engine is started or immediately before the engine is stopped. It does not indicate an abnormality.



Coolant Level Monitor

This monitor indicates a low radiator coolant level.


Check the coolant level when the monitor lamp flashes, stop engine and add water as required.



Air Pressure Monitor

This monitor indicates a drop in the air pressure in the air tank.

If the lamp flashes, increase the engine speed and wait until the lamp goes out.




Coolant Temperature Monitor

This monitor indicates a rise in the cooling water temperature.

When the monitor lamp flashes, run the engine with no load at midrange speed until the green range of the engine water temperature gauge lights.


- * Park the machine on level ground and check the monitor lamps.
- * Confirm that these monitor lamps light for about 3 seconds after turning the starting switch to ON. If any monitor lamp does not light, ask your distributor to inspect that monitor lamp.



Torque Converter Oil Temperature Monitor

This monitor indicates a rise in the torque converter oil temperature.

When the monitor lamp flashes, stop the machine and run the engine with no load at midrange speed until the green range of the temperature gauge lights.




OPERATION

METER GROUP


Pilot Display

When the starting switch is turned to ON, this lights up to indicate that the display items are working.




Parking Brake Pilot Lamp

This lamp lights up when the parking brake is applied.



Pilot Lamp for Working Lamp


This lamp lights up when the working lamps are switched on.



Transmission Cut-Off Selector Pilot Lamp

This lamp lights up when the transmission cut-off selector switch is turned to ON.

- * If the monitor lamp is ON and the left brake pedal is depressed, the transmission will be returned to neutral.


**Air Pressure Gauge**

This gauge indicates the air pressure in the air tank. The green range should be lighted during normal operation.

If the red range lights up during operations, the alarm buzzer will sound, the warning lamp will flash, and the air pressure monitor lamp will flash.


If this happens, stop the machine, increase the engine speed and wait until the green range lights up.

- * If the air pressure drops even lower, the parking brake will be automatically applied.

**Engine Cooling Water Temperature Gauge**

This gauge indicates the temperature of the cooling water. If the temperature is normal during operation, the green range will light. If the red range lights during operation, stop the machine and run the engine with no load at midrange speed until the green range lights.


If the top lamp in the red range lights up, the alarm buzzer will sound, the warning lamp will flash and the coolant temperature monitor lamp will flash at the same time.



Torque Converter Oil Temperature Gauge

This gauge indicates the temperature of the torque converter oil. If the temperature is normal during operation, the green range will light. If the red range lights during operation, stop the machine and run the engine with no load at midrange speed until the green range lights.


If the top lamp in the red range lights up, the alarm buzzer will sound, the warning lamp will light up and the torque converter oil temperature monitor lamp will flash at the same time.



Fuel Gauge

This gauge indicates the amount of fuel in the fuel tank. If there is enough fuel in the tank while the engine is running, the green range lights. If the red range lights, there is less than 35 liters of fuel in the tank.


When the red range lights, add fuel.



Turn Signal Pilot Lamp


When the turn signal lamp flashes, the pilot lamp also flashes.

* If the wiring of the turn signal lamp is disconnected, the pilot lamp will flash faster.



High Beam Pilot Lamp



This lamp lights up when the head lamp is at high beam.



Speedometer

This meter indicates the running speed of the machine.

* A speedometer for MPH is also available.




Service Meter

This meter shows the total operation hours of the machine. The service meter advances while the engine is running-even if the machine is not traveling.

Refer to the section "SERVICE METER".

- * While engine is running, green pilot lamp on the service meter flashes to show the service meter advances.




SWITCHES


TRANSMISSION CUT-OFF SELECTOR SWITCH

This switch selects the operation of the left brake pedal. Normally, put this switch in ON position.

1. OFF:
Depressing the left brake pedal operates the wheel brakes (like right brake pedal).
 2. ON:
Depressing the left brake pedal operates the wheel brakes, and also returns the transmission to NEUTRAL.
- * If the switch is at ON, the transmission cut-off selector pilot lamp will light up.




WARNING! If the machine has to be started on a slope, always turn the transmission cut-off selector switch to OFF and depress the left brake pedal. Then depress the accelerator pedal while releasing the left brake pedal to start the machine off slowly.



ETHER START SWITCH

This switch is used when starting the engine in cold weather.


- (c) ON:
A fixed amount of ether (approx. 3 cc each time) is injected into the engine air intake to make it easier to start the engine in cold weather.
- (d) OFF:
When the switch is released, it automatically returns to the OFF position.



WARNING! Do not keep the switch at the ON position for more than 5 seconds.

HORN BUTTON

When the button in the center of the steering wheel is pressed, the horn will sound.




HAZARD LAMP SWITCH


This switch is used in emergencies, such as when the machine breaks down.

- ON: All turn signal lamps flash.
- * All turn signal lamps and pilot lamp on the steering column flash, when this switch is put to ON.



WARNING! Do not use this switch unless abnormality has occurred.






PARKING BRAKE SWITCH

This switch operates the parking brake.

- (1) ON position:
The parking brake is applied, and the parking brake pilot lamp lights up.
- (2) OFF position:
The parking brake is released.



WARNING! Always apply the parking brake when leaving the machine or parking it.

- * If the directional lever is placed in F (FORWARD) or R (REVERSE) with the parking brake applied, the warning lamp will flash and the alarm buzzer will sound.
- * When the starting switch is turned to OFF, the parking brake is automatically applied.
Before starting the engine, turn the parking brake switch to ON, then turn it to OFF.
- * The machine does not start when the directional lever is operated with parking brake applied.


WORKING LAMP SWITCH

When the front and rear working lamps are turned ON, the pilot lamp and illumination lamp for monitor panel will also light up.

ON: Working lamps are ON.



WARNING! When traveling on public roads, turn the working lamps OFF.



SECTION 1

Page 16

OPERATION

STARTING SWITCH

This switch is used to start or stop the engine.

OFF

Key insertion-withdrawal position. None of electrical circuits activate.

The hazard lamp and the parking lamp will remain on, however, when the switch is turned OFF.


To stop the engine, turn the switch to OFF.

ON

Charging and lamp circuits activate. Keep key at ON after starting.

START

At this key position, the starting motor will crank the engine. Release the key immediately after starting, and the key will return automatically to ON.



LAMP SWITCHES

(for lamps, turn signal lamps, dimmer switch)

Lamp switch

Position 1

Parking lamp lights up.

Position OFF 2


Lamps go off.

Position 3

Clearance lamps, tail lamps and machine monitor lighting light up.

Position 4

Head lamps light up in addition to the lamps in position 3



* The lamp switch can be operated regardless of the position of the lever.

Turn signal lever

This lever operates the turn signal lamps.

1 LEFT TURN:


Push lever FORWARD.

2 RIGHT TURN:

Pull lever BACK.

* When the lever is operated, the turn signal pilot lamp will also light up

* When the steering wheel is turned to the neutral position, the turn signal lever will return automatically to OFF. If not, return the lever to OFF manually.




OPERATION

Dimmer switch



This switches the head lamp between high beam and low beam.

- A Low beam
- B High beam




ROOM LAMP SWITCH

When this switch is moved to ON position, room lamp will light.




OPERATION



CIGARETTE LIGHTER

This is used to light cigarettes. To use, push the lighter in. After the few seconds it will spring back. At that time, remove the lighter and light your cigarette.





KICKDOWN SWITCH

If this switch is pushed when the speed control lever is in 2nd, the transmission shift down to 1st.

This switch is used to increase the drawbar pull in digging operations.

* To cancel the kickdown switch, move the directional lever to REVERSE or NEUTRAL, or move the speed control lever to any position except 2nd. It is also possible to cancel the kickdown switch by operating the parking brake switch or by turning the starting switch OFF.






FRONT WIPER SWITCH

- 1 The wiper is actuated at low speed.
- 2 The wiper works at high speed.


When this switch is turned clockwise, solvent will be sprayed on glass.



REAR WIPER SWITCH

When this switch is pulled to ON position, wiper operates on rear glass.

When this switch is turned clockwise, solvent will be sprayed on glass.




LEVERS AND PEDALS

DIRECTIONAL LEVER

This lever is used to change the direction of travel of the machine.

- 1 Forward
- 2 Reverse
- N Neutral



- * The engine cannot be started if the directional lever is not at N (neutral).
- * When operating the directional lever, place your hand on a steering wheel and operate it by your fingers.
- * It is possible to change the length of the lever. For details of changing the length, see ADJUSTMENT.

**SPEED CONTROL LEVER**

This lever controls the travel speed of machine.

This machine has a 4-FORWARD, 4-REVERSE speed transmission. Place the speed control lever in a suitable position to obtain the desired speed range.

- * 1st and 2nd speeds are used for working.
- 3rd and 4th speeds are used for traveling.
- * It is possible to change the length of the lever. For details of changing the length, see ADJUSTMENT.



SPEED CONTROL LEVER STOPPER


This stopper prevents the speed control lever from entering the 3rd and 4th positions, when working.

Position 1

Stopper actuated.

Position 2

Stopper released.



STEERING COLUMN TILT LEVER


This lever allows the steering column to be tilted forward or backward.

Pull the lever up and move the steering wheel to the desired position. Then push the lever down to lock the steering wheel in position.

* Range of adjustment: 100 mm (stepless)



WARNING! Stop the machine before adjusting the angle of the steering wheel.



ACCELERATOR PEDAL

This pedal controls the engine speed and output. The engine speed can be freely controlled between low idling and full speed.

BRAKE PEDALS

Right brake pedal

The right brake pedal operates the wheel brakes, and is used for normal braking.



WARNING! When traveling downhill, use the engine as a brake, and always use the right brake pedal.

Left brake pedal

The left brake pedal operates the wheel brakes, and if the transmission cut-off selector switch is at ON, it also returns the transmission to neutral.

If the transmission cut-off selector switch is at OFF, the left brake pedal acts in the same way as the right brake pedal.



WARNING! Do not use the brake pedals repeatedly unless necessary.



WARNING! Do not use the brake pedals as footrests. Use them only when applying the brakes.

* When the accelerator is being used for operating the work equipment, always use the left brake pedal to slow or stop the machine after putting the transmission cut-off selector switch in ON.


OPERATION

LIFT ARM CONTROL LEVER

This lever is used to operate the lift arm.

- 1 Raise
- 2 Hold: The lift arm is kept in the same position.
- 3 Lower
- 4 Float: The lift arm moves freely under external force.

- * When the lift arm control lever is pulled further from 1 position, the lever is stopped in this position until lift arm reaches the preset position of kick-out, and the lever is backed to hold position.




BUCKET CONTROL LEVER

This lever operates the bucket.

- 1 Tilt
- 2 Hold: The bucket is kept in the same position.
- 3 Dump

- * When the bucket control lever is pulled further from 1 position, the lever is stopped in this position until bucket reaches the preset position of positioner, and the lever is backed to hold position.





SAFETY LOCK

This is used to lock the lift arm and bucket control levers.



WARNING! When parking or leaving the machine, or when performing maintenance, always lower the bucket to the ground, put the work equipment levers in hold position and check that safety lock lever is locked.




AIR CLEANER SERVICE INDICATOR

This device indicates clogging of the air cleaner element. When red piston (1) appears in the transparent part of this indicator, the element is clogged. Immediately clean element.

After cleaning, push indicator button (2) to return red piston to original position.

Dust indicator is on air cleaner bracket in engine hood.



SAFETY BAR


The safety bar is used during maintenance or when transporting the machine. It locks the front frame and rear frame, and prevents the front and rear frames from bending.



WARNING! Always use the safety bar for maintenance or when transporting the machine.




WARNING! Always remove the safety bar during normal travel operations.



WORK EQUIPMENT CONTROL LEVER (MONO-LEVER TYPE)


This lever is used to operate the lift arm and the bucket.

- 1 Raise
- 2 Hold: The lift arm and the bucket are kept in the same position.
- 3 Lower
- 4 Float: The lift arm moves freely under external force.
- 5 Tilt
- 6 Dump



* When the work equipment control lever is pulled further from 1 position, the lever is stopped in this position until the lift arm reaches the preset position of kick-out, and the lever is backed to hold position.

* When the work equipment control lever is pulled further from 5 position, the lever is stopped in this position until the bucket reaches the preset position of bucket positioner, and the lever is backed to hold position.




OPERATION

CIRCUIT BREAKER (MAIN)

This prevents damage to the electrical components and electric wiring.

When the breaker has been actuated, press the reset button to reset the system. However, if the circuit breaker is actuated again after the button is pressed, or the circuit breaker is frequently actuated, there may be a short circuit in the electrical system. In such cases, contact your distributor for repairs.

- * The circuit breaker is not reset for 45 seconds after the breaker is actuated.




DOOR-OPEN LOCK

This can be used to hold the door open.

Open the door so that tip (2) of the lever is aligned with groove (1) for the lock, then pull down knob (3) as shown in the diagram.

When releasing the lock and closing the door, push up knob (3) and insert pin (4) securely in the groove.

- * When using the door-open lock, be sure to apply the lock securely.




FUSE BOX

The fuses protect the electric devices and wiring from burning out. If any fuse is rusted or coated with white powder, replace it.

- * Replace a fuse with another of the same capacity.



WARNING! Before replacing a fuse, be sure to turn off the starting switch.




OPERATION

FUSE ARRANGEMENT AND CIRCUIT

Fuse box I (Lower side)

No.	Fuse capacity	Circuit
1	20A	Working lamp
2	10A	Parking brake
3	10A	Monitor lamp
4	10A	Bucket positioner Boom kick-out
5	10A	-
6	10A	-
7	20A	Air conditioner (Fan outside room)
8	20A	Air conditioner (Fan inside room)
9	10A	Radio, Room lamp
10	10A	Cigarette lighter
11	10A	Rear wiper
12	10A	Front wiper


Fuse box I



Fuse box II (Upper side)

No.	Fuse capacity	Circuit
1	20A	Starting switch
2	10A	Hazard lamp
3	10A	Left head lamp
4	10A	Red head lamp
5	10A	Right side clearance lamp
6	10A	Right side clearance lamp
7	20A	Lighting
8	10A	Turn signal lamp
9	10A	Brake lamp, Back up lamp
10	10A	Transmission control valve
11	10A	Horn
12	10A	-
13	5A	Engine stop


Fuse box II



OPERATION

OPERATOR'S SEAT

The seat adjustment should be checked at the beginning of each shift and when operators change.



FORWARD-BACKWARD ADJUSTMENT

Move lever (1) to the right, move the seat to the best position and release the lever. The seat can be moved forward or backward within a range of 140 mm in 7 stages.

SEAT ANGLE ADJUSTMENT

Move lever (2) up, set the seat to the desired angle, and release the lever.

The seat can be tilted up or down about 3°.

SEAT CUSHION ADJUSTMENT

Rotate grip (3) under the seat to adjust scale (4) on the cushion adjustment to your own weight. (50 to 120 kg)

BACKREST ADJUSTMENT

Pull lever (5), move the backrest to the best position and release the lever. The backrest can be set to 11 steps.

SEAT HEIGHT ADJUSTMENT

Move lever (6) upward, set the seat to the desired height and release the lever.

The seat can be set within 50 mm.



WARNING! Park the machine in a safe place and stop the engine when carrying out adjustment of the operator's seat.


RIGHT SIDE ARMREST

FORWARD-BACKWARD ADJUSTMENT

Loosen bolts (1) to move the arm-rest to the desired position, and tighten the bolts.

ANGLE ADJUSTMENT

Loosen bolts (2) to move the armrest to the desired angle and tighten the bolts.




SEAT BELT



WARNING! Before fastening the seat belt, inspect the securing brackets and belt for abnormal conditions.

Fasten the belt and remove it in the following manner.

1. Adjust the seat so that the brake pedal can be depressed all the way with the operator's back against the backrest.
2. After positioning the seat, install the tether belt (1). With the seat unoccupied, tense the belt slightly across the seat and install.




WARNING! Check that there are no kinks in the belt.

3. Sit in the seat. Hold buckle (2) and insert (3) into the buckle (2). Check that the belt has locked by pulling it.
 4. When removing the belt, raise the tip of the buckle lever to release it.
- * When leaving the operator's seat, release the seat belt and hang it over the arm rest.
 - * Fasten belt along your body without kinking it. Adjust the lengths of the belt on both the buckle and the insert sides so that the buckle is located at the mid-point of your body front.

Adjust the belt length in the following manner.

- i) To shorten the belt, pull the free end of the belt on either the buckle body or insert side.
 - ii) To lengthen, pull the belt while holding it at a right angle to buckle or insert.
5. When operating a machine equipped with ROPS, be sure to use the seat belt.



- * Inspect bolts and fittings on the chassis for tightness. Retighten any loose bolts to 2 to 3 kgm torque.
- * If the seat is scratched or frayed or if any of the fittings are broken or deformed from long service, replace the seat belt immediately.

OPERATION

CHECK BEFORE STARTING

Pre-operation checks forestall machine trouble. Never neglect them.


WALK-AROUND CHECK

Look around the machine and under the machine to check for loose nut or bolts, collection of dirt, or leakage of oil, fuel, or coolant, and check the condition of the work equipment and hydraulic system. Check also for loose wiring, play, and collection of dust at places which reach high temperatures.

1. Check bucket for wear.
2. Check tire for wear and damage.
3. Check transmission case joints for oil leak.
4. Check brake system for air leak and oil leak.
5. Check tightness of air cleaner mounting bolt.
6. Check tightness of battery terminal.
7. Check radiator for water leak.
8. Check around the engine for water and oil leaks.
9. Check axle for oil leak.
10. Check hydraulic tank joint for oil leak.
11. Check for oil leak at high pressure hose and high pressure hose joints.

CHECK MONITOR PANEL

1. Turn the starting switch to ON.
 2. Check that all the monitor lamps, the gauges and the warning lamp light up for about 3 seconds and the alarm buzzer sounds for about 1 second.
- * If any monitor lamp does not light up, ask your distributor to inspect that monitor lamp.
 - * On the standard machine, following lamp (a) do not light up.
 - (a): Engine pre-heating pilot lamp
This lamp light up only on machines equipped with the pre-heating system. (This is not installed on the machines with the Cummins engine.)
 - * Always make the check by referring to this section on CHECK BEFORE STARTING.




CHECK AND REFILL COOLANT


1. Open the engine side cover located on the left of engine hood, and apply the lock.
2. Check the level of the coolant. The water level must be between the FULL and LOW marks on sub-tank (1).
3. If the level is too low, add water to sub-tank (1).



WARNING! Do not open the radiator cap unless necessary. Check always the coolant level of the sub-tank when engine is cold.




- * If the volume of coolant added is more than usual, check for possible water leakage.
- * Never use a sealing additive to stop leaks in the coolant system. This can result in coolant system plugging and inadequate coolant flow.




CHECK OIL LEVEL AND REFILL IN ENGINE OIL PAN

1. Open the engine side cover located on the right of engine hood, and apply the lock.
2. Use dipstick (G) to check the oil level.
3. The oil level should be between mark L and H, if necessary, add oil at oil filler (F).

- * Never operate the engine with the oil level below the L mark or above the H mark.
- * The type of lubricant used depends on the ambient temperature. Select according to the table "FUEL, COOLANT AND LUBRICANTS."





- * When checking the oil level, park the machine on a level surface and make an oil level check before starting engine or 5 minutes or more after the engine is stopped.



OPERATION

CHECK FUEL LEVEL AND REFILL FUEL

1. Check the fuel level using fuel gauge (G) on the monitor panel.
 2. Upon completion of work, pour in additional fuel from filler (F) until the fuel tank is full.
- * Fuel capacity: 383 l
 - * When adding fuel, never let the fuel overflow. This may cause a fire.




CHECK AIR CLEANER SERVICE INDICATOR

When air cleaner element is clogged, the red piston of dust indicator (1) reaches service level and gets locked.



In that case, clean element referring to the section "WHEN REQUIRED."

After cleaning element, push button to return red piston.



DRAIN WATER FROM AIR TANKS



Upon completion of work, pull rings (1), (2) and (3) on the drain valves, and drain water out of the tank.



FUEL-WATER SEPARATOR

Shut off the engine. Open the drain valve (1). Turn the valve counterclockwise approximately 1 1/2- to 2 turns until draining occurs. Drain the filter sump of water until clear fuel is visible.

- * Do not overtighten the valve. Overtightening can damage the threads.
- * Turn the valve clockwise approximately 1 1/2- to 2 turns to close the drain valve.



OPERATION


FAN - INSPECTION



WARNING! Personal injury can result from a fan blade failure. Never pull or pry on the fan. This can damage the fan blade(s) and cause fan failure.

- * Rotate the crankshaft by using the crankshaft barring techniques recommended by Cummins Engine Company, Inc.

Check for cracks, loose rivets, and bent or loose blades. Check the fan to make sure it is securely mounted. Tighten the capscrews if necessary. Replace any fan that is damaged.




DRIVE BELT

FAN DRIVE BELT - INSPECTION

Replace belts that are cracked or frayed. Adjust belts that have a glazed or shiny surface which indicates belt slippage. Correctly installed and tensioned belts will show even pulley and belt wear.


Belt damage can be caused by:

- Incorrect tension
- Incorrect size or length
- Pulley misalignment
- Incorrect installation
- Severe operating environment
- Oil or grease on the belts



BELT TENSION - CHECK

Use Part No. ST-1293(A), Belt Tension Gauge to measure the tension of the belt. If the belt tension is less than 50 kg it **must** be adjusted. Refer to the Belt Tension Chart. An alternate method (deflection method) can be used to check belt tension by applying 11.3 kg force between the pulleys on v-belts. If the deflection is more than one (1) belt thickness per foot of pulley center distance, the belt tension **must** be adjusted.



OPERATION

BELT TENSION CHART (kg)

Belt Width Inches	Belt Gauge	New Belt Tension Min.-Max.	*Used Belt Installation Tension Min.-Max.
0.380	ST-1274	59 - 68	36.1 - 54
0.440			
1/2			
1-11/16			
3/4	ST-1138	63 ~ 73	41 ~ 54
7/8			
5 or 6 Rib	ST-1293	86 ~ 95	70 ~ 75
8 Rib	ST-1293		

*Adjust used belts to the values in this column, if below minimum, re-tension to maximum.


NOTE: A belt is considered used if it has been in operation for at least 10 minutes.

BELT TENSION - CHECK AND ADJUST

- * Do not use Part No. ST-1274 Belt Tension Gauge on v-ribbed belts. The use of the Part No. ST-1274 Gauge on v-ribbed belts will result in an incorrect adjustment.

Measure the belt tension in the center span of the pulleys.


Refer to the Belt Tension Chart for the specification and the correct gauge for belt tension adjustment. If there is insufficient space to use a gauge, use the deflection method described on Belt Tension-Check.




FAN DRIVE BELT - ADJUST

Caution: Do not adjust belt tension to full value with the adjusting screw (1). Belt tension can increase when the lock nut (2) is tightened and cause reduced belt and bearing life.

- Loosen the idler pulley shaft lock nut.
- Adjust the belt tension to:
 - a. New Belt : 86~95 kg
 - b. Used Belt : 70~75 kg
- Tighten the idler pulley shaft lock nut:




Torque Value: 16.6~19.4 kg.m



ALTERNATOR DRIVE BELT - ADJUST

Measure the belt tension. Refer to the Belt Tension Chart for the correct gauge and tension values.

- A. CHECK THAT PARKING BRAKE WORKS PROPERLY.
- B. CHECK THAT BRAKES WORK PROPERLY.
- C. CHECK THAT HORN SOUNDS PROPERLY.
- D. CHECK THAT LAMPS FLASH PROPERLY; CHECK FOR DIRT OR DAMAGE.
- E. CHECK DIRECTION OF REAR VIEW MIRROR; CHECK FOR DIRT OR DAMAGE.
- F. CHECK THAT ENGINE EXHAUST GAS COLOR AND SOUND ARE NORMAL.
- G. CHECK THAT GAUGES AND INSTRUMENTS WORK PROPERLY.
- H. CHECK STEERING PLAY; CHECK THAT STEERING WORKS PROPERLY.
- I. CHECK THAT BACK-UP BUZZER SOUNDS PROPERLY.
- J. CHECK ELECTRICAL WIRING




Check for any sign of disconnection or short circuit in the electric wiring. Check also for loose terminals and tighten any loose parts.

Check the following points carefully:


- Battery
- Starting motor
- Alternator

OPERATING YOUR MACHINE BEFORE STARTING THE ENGINE



1. Carry out an initial inspection. (For details of the inspection, see CHECK BEFORE STARTING.)
2. With your back against the back rest of the operator's seat, adjust the seat position so that the brake pedal can be easily depressed.
3. Is parking brake switch (1) in ON position?



4. Is directional lever (2) in N (neutral) position?
- * The engine will not start while the directional lever (2) is in any position other than N (neutral).





5. Are work equipment control levers (3) locked by safety lock (4)?
6. Is the machine monitoring system working properly?



OPERATION

TO START THE ENGINE

1. Depress accelerator pedal (1) lightly.
 2. Turn the key of starting switch (2) to the START position to start the engine.
 3. When the engine is started, release the key of starting switch (2) and the key will return automatically to ON.
- * If engine will not start, repeat the starting procedure after about 2 minutes.
 - * Do not leave the key in START for more than 20 seconds.
 - * To start engine in cold weather, refer to COLD WEATHER OPERATION.



SPECIAL STARTING


When starting after running out of fuel, fill with fuel, then fill the fuel filter cartridge with fuel and bleed the air from the fuel system before starting.

Refer to FUEL FILTER in every 250 hours services.

CHECKS AFTER STARTING


After starting make the following checks.

1. Depress accelerator pedal (1) lightly and run the engine with no load at midrange speed for about 3 to 5 minutes.
2. After warm-up run is completed, check monitor lamps for proper operation.
- * Continue to run the engine at light load until the green ranges of the engine water temperature gauge and torque converter oil gauge light.
3. Check if the exhaust color is normal or whether there is any abnormal noise or vibration.
- * Avoid abruptly accelerating the engine until the completion of warm-up.
- * Do not run for more than 10 minutes at low idling or at high idling.





TO MOVE THE MACHINE OFF

1. Check that the warning item is not displayed on the monitor panel.
2. Free the safety lock for work equipment control lever. Bring the work equipment in the traveling posture.
3. Depress right brake pedal (1), and turn parking brake switch (2) to OFF (release) to release the parking brake.
- * When the parking brake is applied with parking brake switch (2) put in OFF, put switch (2) to ON and return it to OFF again.
4. Set speed control lever (3) and directional lever (4) to the desired position.
5. Release right brake pedal (1), then depress accelerator pedal (5) to move the machine off.



WARNING! If the machine has to be started on a slope, always turn the transmission cut-off selector switch to OFF and depress the left brake pedal. Then depress the accelerator pedal while releasing the left brake pedal to start the machine off slowly.





OPERATION

CHANGING GEAR SPEED

Move speed control lever (1) to the desired position.

- * To use 1st or 2nd speeds for digging and loading operations, actuate speed control lever stopper.
- * This machine is equipped with a kickdown switch that shifts the gear down to 1st if the button at the tip of the lift arm control lever is pushed when the machine is traveling in 2nd gear.
- * We recommend the use of the kickdown switch when carrying out digging or loading operations in 1st or 2nd gear. For details of use, see INSTRUMENTS AND CONTROLS.



CHANGING DIRECTION

There is no need to stop the machine even when switching between FORWARD and REVERSE.



Place directional lever (1) in the desired position.



WARNING! Before changing direction, check that it is safe.




WARNING! Never change between FORWARD and REVERSE at high speed.



TURNING

When traveling, use steering wheel (1) to turn the machine.

- * With this machine, the front frame is joined to the rear frame at the center of the machine by the center pin. The front and rear frames bend at this point, and the rear wheels follow in the same track as the front wheels when turning.
- * Turn the steering wheel lightly to follow the machine as it turns. When turning the steering wheel fully, do not turn it beyond the end of the stroke.



WARNING! It is dangerous to turn the machine suddenly at high speed, or to turn on steep hills.



WARNING! If the engine stops when the machine is traveling, the steering cannot be used. This is particularly dangerous on hills, so never stop the engine when the machine is traveling.




WARNING! If the engine should stop, stop the machine immediately in a safe place.


OPERATION

TO STOP THE MACHINE

1. Release accelerator pedal (1), and depress brake pedal (2) to stop the machine.




2. Place directional lever (3) in N (neutral).



3. Turn parking brake switch (4) to ON to apply the parking brake.


* When the parking brake is applied, the transmission is automatically returned to neutral.



4. Operate work equipment lever (5) and lower the bucket to the ground, then locate work equipment control levers (5) to hold position surely and then lock safety lock of control levers.




WARNING! Stop the machine in a safe place on firm level ground. If the machine has to be stopped on a slope, put blocks under the wheels. In addition, dig the bucket into the ground to increase safety.




TO STOP THE ENGINE

1. Run the engine at low idling speed for about 3 to 5 minutes to allow it to gradually cool down.



2. Return starting switch (1) to the OFF position and remove the key.


- * If the engine is abruptly stopped before it has been cooled down, engine life may be greatly shortened. Consequently, do not abruptly stop the engine apart from an emergency.
- * In particular, if the engine has overheated, do not abruptly stop it but run it at medium speed to allow it to cool gradually, then stop it.



MAXIMUM DEPTH OF WATER

When working in water or on swampy ground, do not let the water come above the bottom of the axle housing.

- * After finishing the operation, wash and check the lubricating points.



IF WHEEL BRAKE DOES NOT WORK

If the machine is not stopped by depressing brake pedal, use the parking brake to stop the machine.

PRECAUTIONS WHEN DRIVING UP OR DOWN SLOPES

LOWER THE CENTER OF GRAVITY WHEN TURNING

When turning on slopes, lower the work equipment to lower the center of gravity before turning. It is dangerous to turn the machine with the work equipment raised.

BRAKING ON DOWNHILL SLOPES

When driving down a slope, put the speed control lever in a low speed position and fully apply the engine brake. To apply the service brake, depress the right brake pedal.

If the speed control lever is not placed in a proper speed position, the torque converter oil may overheat. If it overheats, place the speed control lever in the next lower gear speed to lower the oil temperature.

If the temperature gauge does not indicate the green range of the scale even with the lever in the 1st speed position, stop the machine, place the lever in neutral, and run the engine at medium speed until the gauge indicates the green range.

IF ENGINE STOPS

If the engine stops on a slope, depress the right brake pedal fully. Next, lower the work equipment to the ground and apply the parking brake. Then put the directional and speed control levers in neutral, and start the engine again. (If the directional lever is not in neutral, the engine will not start).

PROPER BUCKET AND TIRE

Select the most suitable bucket and tires for the type of work and the ground conditions on the jobsite.


Type of work	Bucket	Ground conditions	Type
<ul style="list-style-type: none"> • Loading materials • Loading and carrying materials 	Stockpile bucket (4.2m ³)	General ground conditions	23.5-25-20PR (Rock) 26.5-25-16PR (Rock)
		Leveled ground	23.5-25-20PR (Traction) 26.5-25-16PR (Rock)
		Hard ground	23.5-25-20PR (Rock) 26.5-25-20PR (Rock)
<ul style="list-style-type: none"> • Loading materials and blasted rock 	Excavating bucket (3.5, 3.8m ³)	General ground conditions	23.5-25-20PR (Rock) 26.5-25-20PR (Rock)
		Hard ground	23.5-25-20PR (Rock) 26.5-25-20PR (Rock)
<ul style="list-style-type: none"> • Loading blasted rock 	Excavating bucket (3.5m ³)	General ground conditions	23.5-25-20PR (Rock)
		Hard ground	23.5-25-20PR (Rock)
	Spade nose bucket (3.5m ³)	Ground with many boulders	23.5-25-20PR (Rock, side steel breaker)
		Soft ground with many boulders	23.5-25-20PR (Rock, side steel breaker)
<ul style="list-style-type: none"> • Loading and carrying blasted rock 	Spade nose bucket (3.5m ³)	General ground conditions	23.5-25-20PR (Rock)
		Hard ground	23.5-25-20PR (Rock)
		Ground with many rocks	23.5-25-20PR (Rock, side steel breaker)
		Soft ground with many rocks	26.5-25-20PR (Rock, side steel breaker)

ADJUSTMENT OF WORK EQUIPMENT

The boom kickout makes it possible to set the bucket so that it automatically stops at the desired lifting height (lift arm higher than horizontal) and the bucket positioner makes it possible to set the bucket so that it automatically stops at the desired digging angle. The setting can be adjusted to match the working conditions.

ADJUSTING BOOM KICKOUT


1. Raise the bucket to the desired height, set the lift arm control lever at HOLD and lock the lever in position. Then stop the engine and adjust as follows.
2. Loosen two bolts (1), and adjust plate (2) so that the bottom edge is in line with the center of the sensing surface of proximity switch (3). Then tighten the bolts to hold the plate in position.



3. Loosen two nuts (4) to make a clearance of 3 to 5 mm between plate (2) and the sensing surface of proximity switch (3). Then tighten the nuts to hold in position.

* Tightening torque: 1.75 ± 0.25 kgm


4. After adjusting, start the engine and operate the lift arm control lever. Check that the lever is automatically returned to HOLD when the bucket reaches the desired height.




OPERATION

ADJUSTING BUCKET POSITIONER

1. Lower the bucket to the ground and adjust the bucket to the desired digging angle. Set the bucket control lever at HOLD, stop the engine and adjust as follows.



2. Loosen two bolts (1) and adjust mounting bracket (4) of the proximity switch so that the rear tip of angle (2) is in line with the center of the sensing surface of proximity switch (3). Then tighten the bolts to hold the bracket in position.
3. Loosen two nuts (5) to make a clearance of 3 to 5 mm between angle (2) and the sensing surface of proximity switch (3). Then tighten the nuts to hold in position.




* Tightening torque: 1.75 ± 0.25 kgm

4. After adjusting, start the engine and raise the lift arm. Operate the bucket control lever to the DUMP position, then operate it to the TILT position and check that the bucket control lever is automatically returned to HOLD when the bucket reaches the desired angle.

BUCKET LEVEL INDICATOR

(A) and (B) at the top rear of the bucket are the level indicators, so the bucket angle can be checked during operations.

- A: Parallel with cutting edge
- B: 90° to cutting edge



USING ACCUMULATORS

PRECAUTIONS FOR MAINTENANCE

The accumulators are on the right inside of the rear frame under the center platform.



WARNING! The accumulators are filled with highly pressurized nitrogen. To avoid explosions, observe the following precautions.


- If accumulators break down or have trouble, immediately ask your distributor to make the repairs.
- Only personnel and those licensed to service high pressure equipment may recharge an accumulator with nitrogen.
- Never strike a charged accumulator or expose it to flames.
- Never weld piping to or cut opening in an accumulator.
- Never overhaul or dispose of an accumulator without first bleeding out all the nitrogen through the air bleeder valve.
- * Always handle an accumulator with the utmost care!
- * Have your distributor check the gas pressure every 2000 hours or every year.

HANDLING TIRES

PRECAUTIONS WHEN HANDLING TIRES

If the following defects are found in tires, for safety reasons the tire should be replaced with a new tire.

- Bead wire is broken or bent, or the tire is greatly deformed.
- Wear is excessive and the carcass ply (excluding breaker) is exposed for more than 1/4 of the circumference.
- Damage to the carcass exceeds 1/3 of the tire width.
- Tire layers are separated.
- Radial cracks reach the carcass.
- Deformation or damage which makes the tire unsuitable for use.



OPERATION

PRECAUTIONS WHEN DRIVING MACHINE

When the machine travels at high speed for a long distance, the tires become extremely hot. This causes early wear of the tires, so it should be avoided as far as possible. If the machine must be driven for a long distance, take the following precautions.

- Follow the regulations related to this machine, and drive carefully.
- The most suitable tire pressure, travel speed, or tire type differ according to the condition of the travel surface. Contact your Komatsu distributor or tire dealer for information.
- The following is a guide to suitable tire pressures and speeds when traveling on a paved surface with standard tires.

Tire pressure: Front 4.0 kg/cm²
 Rear: 3.2 kg/cm²
 Speed: 13 km/h (8.1 MPH)

- Check the tire pressure before starting, when the tire is cool.
- After traveling for 1 hour, stop for 30 minutes. Check the tires and other parts for damage; also check the oil and coolant levels.
- Always travel with the bucket empty.
- Never put calcium chloride or dry ballast in the tires when traveling.

TIRE PRESSURE


Measure the tire pressure before starting operations, when the tires are cool.

If the inflation pressure is too low, it causes overload on the tires; if the inflation pressure is too high, the tire may be cut or may burst under shock. Therefore adjust the inflation pressure to the values in the following table.

Tire size (pattern)	Ply rating	Inflation pressure (kg cm ²)			
		Soft ground (sandy ground)	Normal road		When shipped from factory
			Stockpile	Digging	
23.5 - 25 (L ₂ Rock)	20	2.4 - 3.6	2.6 - 3.6	2.6 - 3.6	Front tire 4.0 Rear tire 3.2
23.5 - 25 (L ₁ Rock)	20				
26.5 - 25 (L ₂ & L ₁ Rock)	16 20	3.5 - 4.0	3.5 - 4.0	3.5 - 4.0	

INFLATING TIRES

Connect the air charge hose to air pickup (1) to inflate the tires.



- * For operations on normal road surfaces, rock digging operations High end of range in air pressure chart
- * Stockpile operations on soft ground Average pressure in air pressure chart
- * Operations on sand (operations not using much digging force) . Low end of range in air pressure chart

If the deflection of the tire is excessive, raise the inflation pressure within the limits given in the table to give a suitable deflection (see deflection ratio).

* Stockpile operations mean the loading of sand and other loose materials.

* **Precautions when carrying out load and carry operations**


When traveling continuously for load and carry operations, select tires to match the various ground conditions, or select ground conditions to match the tires. If this is not done, the tires will be damaged, so consult your distributor or tire suppliers.

* Deflection ratio (deflection/free height)

$$= \frac{H - h}{H} \times 100$$

H: Free height

h: Height when loaded



As a guide for visual checks, the deflection ratio (deflection/free height) of the front tire should be as follows.

Normal loading and carrying operations (lift arm horizontal): approx. 15-25%

Digging operations (rear wheels off ground): approx. 25 - 35%

- * When checking the tire pressure, check also for small cracks and damage, and for wire or small pieces of metal which may cause punctures. Check also for abnormal wear.
- * Operating costs can be reduced and tire life increased by keeping the operating area in good condition and free from fallen rocks.

OPERATION

TOWING

TOWING THE MACHINE

This machine must not be towed except in emergencies. When towing the machine, take the following precautions.



WARNING! If there is a failure in the brake line, the brakes cannot be used, so be extremely careful when towing.

WHEN ENGINE CAN BE USED


- Always keep the engine running when towing the machine, so that the steering and braking can be used.

WHEN ENGINE CANNOT BE USED

- No lubrication oil flows in the transmission, so disconnect the front and rear drive shafts before moving the machine.
- The steering cannot be used, so disconnect the steering cylinder and steering linkage.
- * The machine should be towed only to the nearest place for inspection and maintenance. Do not tow the machine for long distances.
- * If leakage in the air circuit has caused the pressure inside the air tank to drop, the parking brake will be applied. When towing the machine, release the parking brake.

RELEASING PARKING BRAKE

1. Remove air charge socket (1) installed on the front left of the rear frame.
2. Remove the air hose for the parking brake chamber, then install the socket again.
3. Install the air charge hose for the tire to the air charge socket.



WARNING! If there is a failure in the air circuit, the brakes cannot be used. This is dangerous, so always tow the machine at low speed. Keep the engine running so that the steering can be used.

4. Push the end of the hose on the tire valve, and air will be supplied to the brake chamber to release the brake.
5. When the parking brake is released, remove the air charge hose. Tow the machine immediately to a safe place.



WARNING! Stop the machine on a flat surface when releasing the parking brake, and check that the surroundings are safe. In emergencies or when the parking brake must be released on a hill, block the tires carefully before releasing the brake.

COLD WEATHER OPERATION

PREPARATION FOR LOW TEMPERATURE

If the temperature becomes low, it becomes difficult to start the engine, and the coolant may freeze, so do as follows.

FUEL AND LUBRICANTS

Change to fuel and oil with low viscosity for all components.

For details of the specified viscosity, see the TABLE OF FUEL, COOLANT AND LUBRICANTS.

COOLANT

- * DCA4 is recommended for use in Cummins engines.
- * In climates where the temperature is above -37°C [-34°F], use a coolant mixture that contains 50 percent antifreeze. **Antifreeze is essential in any climate.** It broadens the operating temperature range by lowering the coolant freezing point and by raising its boiling point. Do **not** use more than 50 percent antifreeze in the mixture unless additional freeze protection is required. **Never** use more than 68 percent antifreeze under any condition.
- * Maintain supplemental coolant additive levels at 1 unit DCA4 per 3.8 liters of coolant.
- * For details of changing the coolant, see WHEN REQUIRED.

BATTERY

- * As ambient temperature drops, battery capacity will drop, and electrolyte may sometimes freeze if battery charge is low. Maintain battery at a charge level of approx. 100% and insulate it against cold temperature so that machine can be readily started the next morning.
- * Measure specific gravity of fluid and obtain rate of charge from the following conversion table:

Temp. of fluid	20°C	0°C	-10°C	-20°C	-30°C
Rate of charge					
100%	1.28	1.29	1.30	1.31	1.32
90%	1.26	1.27	1.28	1.29	1.30
80%	1.24	1.25	1.26	1.27	1.28
75%	1.23	1.24	1.25	1.26	1.27

- * When electrolyte level is low, add distilled water in the morning before work instead of after the day's work instead of after the day's work. This is to prevent fluid from freezing at night.



WARNING! To avoid gas explosions, do not bring fire or sparks near the battery.




WARNING! If the electrolyte gets on your skin or clothes, immediately wash with plenty of clean water.


OPERATION

STARTING IN COLD WEATHER

When starting the engine in low temperatures, do as follows.




1. Turn the key in starting switch (1) to the START position.
2. Move ether injection switch (2) to the ON position, then release it immediately. (Do not hold it at the ON position for more than 5 seconds. This will cause failure of the solenoid.)
- * If the engine does not start, repeat this 2-3 times.
3. When the engine starts, release the key in starting switch (1) to return it to the ON position.




WARNING! Never operate ether injection switch (2) except when starting the engine.

- * The ether cylinder can be used for about 230 times. (Amount of ether injected: 3cc, total capacity for one cylinder: 710cc)
- * The standard specification machine is designed to work in ambient temperature from -20 to 40°C.



When operating the machine at temperatures below -20°C, special equipment is needed. Contact your distributor for details.

- * For machines where the air dryer is installed as an option, in cold temperatures below -10°C, when operating the machine after it has been stopped for several hours, run the engine for at least 10 minutes after starting before moving the machine.



CAUTIONS AFTER COMPLETION OF WORK

1. Mud and water on the machine body should be completely removed.

Park the machine on concrete or hard ground. If this is impossible, park the machine on wooden boards. This will prevent the accessories from freezing to the ground thereby preventing machine movement the next morning. Particular attention should be given to water drops collected on the surface of the hydraulic cylinder piston rods. Such droplets must be fully wiped off because if water is frozen to the rod when the cylinder is utilized, the cylinder oil seals may be damaged.

2. Drain water collected in air tank and fuel system so that such water may be frozen at night.
3. As battery capacity drops at low ambient temperature, cover the battery or remove it from the machine to be kept warm at night.


AFTER COLD WEATHER

When weather becomes warm, perform the following without fail:

- Replace lubricating oils for various units with the ones specified for warm-weather use.
- If for any reason permanent anti-freeze cannot be used, and an ethyl glycol base antifreeze (winter, one season type) is used instead, or if no antifreeze is used, drain the cooling system completely, then clean out the inside of the cooling system thoroughly, and fill with fresh water.

OPERATION

MEMORANDA



SECTION 2
MAINTENANCE



**WARNING ! REFER TO AND READ ALL
SAFETY PRECAUTIONS IN SECTION 3.**

MAINTENANCE

PERIODIC MAINTENANCE


Proper lubrication and maintenance assure trouble-free operation and long machine life. Time and money spent for scheduled periodic maintenance will be amply compensated by prolonged machine operation and reduced operating cost.

All hourly figures given in the following descriptions are based on service meter readings. In practice, however, it is recommended to rearrange all of them into units of days, weeks and months to, make the maintenance schedule more convenient. Under rough jobsite or operating conditions, it is necessary to somewhat shorten the maintenance intervals stated in this manual.

BLEEDING AIR FROM CIRCUIT

BLEEDING AIR FROM HYDRAULIC CIRCUIT

- After replacing oil, filter element or strainer, bleed the air from the circuit.
- To bleed the air from the hydraulic cylinders or hydraulic piping, run the engine at low idling and do as follows.
 1. Operate each hydraulic cylinder (of steering, bucket and lift arm) 4 to 5 times, stopping 100mm from stroke end.
 2. Next, operate each cylinder 3 to 4 times to the end of its stroke, then stop the engine and loosen air bleeding plug (1) of the hydraulic tank to bleed the air.
 3. Increase the engine speed, and repeat step 2 to bleed the air until no more bubbles come out from plug (1).
- * If the engine is run at high speed at first, or if the cylinder is moved to the end of its stroke, the air in the cylinder may damage the piston packing, etc.
- 4. After bleeding the air, tighten the air bleeding plug (1).
- * Tightening torque of the plug: 1.15 ± 0.15 kgm



PERIODICAL REPLACEMENT OF SAFETY PARTS

The users of our machine should carry out periodical maintenance in order to ensure the working and operation safety. Those parts, as listed on the right, which are closely connected with safety, must be replaced periodically so that the highest safety standard can be maintained.

These parts with the passage of time have a great tendency to deteriorate in quality and to wear or deform. Furthermore, their defective condition is difficult to detect during periodical maintenance. These parts must, therefore, be replaced with new ones after a predetermined service even though there is no apparent abnormality.

It goes without saying that if any abnormality should be found, these parts must be replaced or repaired even before the predetermined period expires.

The periodical replacement is completely different from the replacement due to the claim against the guarantee by the manufacturer, so they must be treated separately.

	Safety parts for periodic replacement	Replacement interval	Remarks
1	Brake hose	Every year	
2	Rubber parts for power cluster	Every year	Replace with repair kit
3	Packings, seals, O-rings of steering cylinder	Every 2 years	
4	Rubber hose for steering cylinder	Every 2 years	
5	Fuel hose	Every 2 years	
6	Rubber parts for treadle valve	Every year	Replace with repair kit
7	Rubber parts for parking brake spring cylinder	Every year	Replace with repair kit
8	Rubber parts for slack adjuster	Every year	Replace with repair kit

MAINTENANCE TABLE

ITEM	SERVICE	PAGE
CHECK BEFORE STARTING		
Walk around check		1-28
Monitor panel	Check	1-28
Coolant	Check and supply	1-29
Engine oil pan	Check and supply	1-29
Fuel tank	Check and supply	1-30
Air cleaner service indicator	Check	1-30
Air tank	Drain water	1-31
Fuel-Water separator	Drain water	1-31
Fan	Check and replace	1-32
Drive belt	Check and replace	1-32
Parking brake	Check function	1-34
Service brakes	Check function	1-34
Horn	Check function	1-34
Lamps	Check function	1-34
Rear view mirror	Check	1-34
Exhaust gas and color	Check	1-34
Instruments	Check function	1-34
Steering wheel	Check play	1-34
Back-up buzzer	Check function	1-34
Electrical wiring	Check	1-34
EVERY 50 HOURS SERVICE		
Fuel tank	Drain water and sediment	2-9
Tires	Check air pressure and damage	2-9
EVERY 100 HOURS SERVICE		
Hydraulic tank	Check and supply	2-9
Lubricating		2-10
Rear axle pivot pin	Lubricate 2 points	2-10
Air conditioner filter	Clean	2-10

MAINTENANCE

ITEM	SERVICE	PAGE
INITIAL 250 HOURS SERVICE		
Transmission oil filter	Replace element	2-11
EVERY 250 HOURS SERVICE		
Engine oil pan and filter	Change oil and replace filter	2-11
Air intake system	Check	2-13
Battery electrolyte	Check fluid level	2-13
Fuel filter	Replace cartridge	2-14
Crankcase breather	Clean element	2-15
Corrosion resistor (Coolant filter)	Replace cartridge	2-16
Coolant additive concentration	Check and supply	2-17
Lubricating		2-18
Bucket pin	Lubricate 2 points	2-18
Dump cylinder pin	Lubricate 2 points	2-18
Bucket link pin	Lubricate 2 points	2-19
Lift cylinder pin	Lubricate 4 points	2-19
Lift arm pivot pin	Lubricate 2 points	2-19
Tilt lever pin	Lubricate 1 point	2-20
Steering cylinder pin	Lubricate 4 points	2-20
Air conditioner compressor belt	Check tension	2-20
Wheel hub nuts	Check and retighten	2-21
EVERY 500 HOURS SERVICE		
Transmission oil filter	Replace element	2-21
Lubricating		2-22
Center drive shaft spline	Lubricate 1 point	2-22
Air dryer	Check	2-22

ITEM	SERVICE	PAGE
EVERY 1000 HOURS SERVICE		
Transmission case and strainer	Change oil and clean strainer	2-23
Transmission case breather	Clean	2-24
Lubricating		2-24
Center hinge pin	Lubricate 2 points	2-24
Front drive shaft	Lubricate 2 points	2-25
Drive shaft center support	Lubricate 1 point	2-25
Center drive shaft	Lubricate 2 points	2-25
Rear drive shaft	Lubricate 3 points	2-25
Parking brake caliper	Lubricate 1 point	2-26
Upper drive shaft	Lubricate 2 points	2-26
Transmission mount trunnion	Lubricate 1 point	2-26
EVERY 1500 HOURS SERVICE		
Valves and injectors	Check and adjust	2-27
EVERY 2000 HOURS SERVICE		
Hydraulic tank and filter	Change oil and replace element	2-28
Air conditioner filter	Replace element	2-29
Hydraulic tank breather	Replace element	2-29
Axle (Front and rear)	Change oil	2-29
PPC circuit strainer	Clean	2-31
Alternator and starting motor	Check	2-31
Brake disc	Check and repair	2-31
Internal part of air dryer	Replace	2-31
Accumulator	Check	2-31
EVERY 6000 HOURS SERVICE		
Injector	Clean and calibrate	2-32
Fuel pump	Clean and calibrate	2-32
Turbocharger	Check and clean	2-32
Air compressor	Check and adjust	2-33

MAINTENANCE



SECTION 2

Page 7

ITEM	SERVICE	PAGE
EVERY 6000 HOURS SERVICE - Continued		
Water pump	Check and repair	2-36
Fan idler pulley	Check and repair	2-36
Fan hub (Belt driven)	Check and repair	2-37
Cooling system	Change coolant	2-37
WHEN REQUIRED		
Turbocharger mounting	Check	2-40
Air cleaner element	Check, clean or replace when required	2-41
Transmission	Check and supply	2-43
Radiator fins	Clean	2-43
Axle oil	Check and supply	2-44
Axle case breather	Clean	2-44
Lubricating		2-45
Work equipment control valve linkage	Lubricate 2 points	2-45
Steering column	Lubricate	2-45
Condenser of air conditioner	Check and clean	2-45
Air conditioner	Check	2-46
Window washer	Check and supply	2-47
Bucket teeth	Replace	2-47
Cutting edge	Reverse and replace	2-48

MAINTENANCE

OIL FILLER AND LEVEL GAUGE POSITIONS



- | | | |
|-------------------------------------------------|------------------------------------------------------|----------------------------------------|
| 1. Front axle drain plug | 10. Front final drive case level plug and oil filler | 17. Fuel tank drive valve |
| 2. Front axle level plug | 11. Front axle brake chamber drain plug | 18. Engine oil pan drain valve |
| 3. Hydraulic tank oil filler | 12. Cooling water inlet | 19. Rear axle drain plug |
| 4. Hydraulic tank level gauge | 13. Engine oil pan level gauge | 20. Rear axle brake chamber drain plug |
| 5. Hydraulic tank drain plug | 14. Engine oil pan oil filler | 21. Rear axle level plug |
| 6. Cooling water drain valve | 15. Rear final drive case level plug and oil filler | 22. Fuel tank oil filler |
| 7. Transmission case level gauge and oil filler | 16. Rear final drive case drain plug | |
| 8. Transmission case drain plug | | |
| 9. Front final drive case drain plug | | |


CHECK BEFORE STARTING

See the section on CHECK BEFORE STARTING aforementioned.

EVERY 50 HOURS SERVICE

FUEL TANK

Loosen valve (1) on the bottom of the tank so that the precipitation and mixed water will be drained in accompaniment with fuel.



TIRE

Measure the tire pressure before operations when the tires are cool. (Refer to HANDLING TIRES)

EVERY 100 HOURS SERVICE


* Maintenance for every 50 hours should be carried out at the same time.

HYDRAULIC TANK

1. Lower the bucket horizontally to the ground and stop the engine. Wait for 5 minutes, then check sight gauge (G), the oil should be visible in sight gauge (G).

2. Add engine oil from oil filler (F), if necessary.

* The type of lubricant used depends on the ambient temperature. Select according to the table "FUEL COOLANT AND LUBRICANTS".




WARNING! When removing the cap, turn it slowly to relieve inner pressure.

MAINTENANCE

LUBRICATING

Apply grease to the grease fittings shown by arrows.

1. Rear axle pivot pin (2 points)




AIR CONDITIONER FILTER


If the air conditioner has been used, the air filter should be cleaned.

* Stop the air conditioner before cleaning the element.

1. Move the operator's seat forward, then tilt the backrest forward.
2. Loosen the bolts and remove the cover.
3. Loosen screw (2) and cover (1) holding the filter element, pull out element (3) and clean it.
4. After cleaning the element, align it with the direction shown by the arrow, and install.



* Direct dry compressed air (less than 7 kg/cm²) to element from inside along its folds, then direct it from outside along its folds and again from inside, and check element.



WARNING! When using compressed air, wear glasses and other things required to maintain safety.

INITIAL 250 HOURS SERVICE

Perform the following maintenance after running the machine for the first 250 hours.

TRANSMISSION OIL FILTER


For details of the method of replacing or maintaining, see the section on EVERY 500 HOURS SERVICE.

EVERY 250 HOURS SERVICE


* Maintenance for every 50 hours should be carried out at the same time.

ENGINE OIL PAN AND FILTER


1. Open the engine side cover located on the right of engine hood.




2. Open oil filler and remove drain plug (1) to drain oil. After draining, tighten the drain plug.
3. Using a filter wrench, remove the engine oil filter by turning it counterclockwise.




4. Clean the filter case and fill a new filter cartridge with engine oil. Then, apply engine oil or a thin coat of grease to the seal.



- * Fill the oil filters with clean lubricating oil.
- * Install the filter as specified by the filter manufacturer.
- * Be careful not to tighten it up excessively.
- * Be sure to fit a genuine Cummins cartridge.
- * Tighten the filters until the gasket contacts the filter head surface.
- * Tighten the filters an additional three-fourths, to one (3/4 to 1) turn or follow the instructions supplied with the filters.



5. After replacing the cartridge, pour in the specified quantity of engine oil from oil filler (F)
6. After refilling with oil, start the engine and idle it for a while. Then stop the engine and check the oil level. Wait for 5 minutes before checking.
7. Close the engine side cover.




- * Refill capacity: 32ℓ
- * The type of lubricant used depends on the ambient temperature. Select according to the table "FUEL COOLANT AND LUBRICANTS".
- * Replace once every 6 months, regardless of the number of hours operated.
- * If engine oil filter is removed immediately after stopping the engine, oil will spill. Wait at least 10 minutes after stopping the engine before replacing the filter cartridge.

AIR INTAKE SYSTEM

Inspect the intake piping for cracked hoses, loose clamps, or punctures which may damage the engine.


Tighten or replace parts as necessary to make sure the air intake system does not leak.

Check for corrosion of the intake system piping under the clamps and hoses. Corrosion can allow corrosive products and dirt to enter the intake system. Disassemble and clean as required.



CHECK ELECTROLYTE LEVEL IN BATTERY

1. Open the battery box covers.
 2. If the electrolyte level is lower than the prescribed level (10 to 12 mm above the plate), supply distilled water.
- * Should any of the acid be spilt, have it replenished by the nearest battery shop with acid of the correct specific gravity.
 - * When inspecting electrolyte level, clean the air hole of the battery cap.



WARNING! If the electrolyte gets on your skin or clothes, immediately wash with plenty of clean water.




WARNING! To avoid gas explosions, do not bring fire or sparks near the battery.




MAINTENANCE

FUEL FILTER

1. Open the engine side cover located on the right of the engine hood.
2. Using a filter wrench, remove cartridge (1) by turning it counterclockwise.
3. Clean the area around the fuel filter head. Remove the fuel filter. Clean the gasket surface of the filter head.
4. Clean the filter base fill the new cartridge with fuel and refit it after applying a dab of oil to the gasket face.




- * Be careful not to tighten it up excessively.
- * Be sure to fit a genuine Cummins cartridge.
- * Tighten the filter until the gasket contacts the filter head surface.
- * Tighten the filter as additional one-half to three-fourths ($1/2$ to $3/4$) turn after the gasket contacts the filter head surface.
- * Replace once every 6 months, regardless of the number of hours operated.



5. Remove the plug from the top of the fuel pump housing.
6. Fill the housing with clean fuel. Install and tighten the plug in the housing.

Plug: 2.8 kgm (20 ft-lb)

- * Whenever the fuel pump is removed, it is necessary to prime the pump after installing it on the engine to remove any trapped air.
- * After replacing the cartridge, start up the engine and check the filter seal face for possible fuel leakage.



CRANKCASE BREATHER

1. Remove the cover from the breather housing.
2. Use solvent to remove the excess oil residue and sludge from the screen.
3. Visually inspect the screen for deterioration.

Visually inspect the cover o-ring.




- * If the screen has deteriorated, pull gently back on the three locking tabs to remove the element and screen from the cover. Discard the screen.

4. Install the new screen and element to the cover.

Use clean 15W-40 oil to lubricate the cover o-ring.

Install the cover on the breather housing.

- * Turn the cover approximately one-eighth of a turn clockwise to lock it in place on the housing.
- * Clean and check once every 6 months, regardless of the number of hours operated.




MAINTENANCE




CORROSION RESISTOR (Coolant filter)



WARNING! Do not remove the radiator cap from a hot engine. Hot steam will cause serious personal injury. Remove the coolant system pressure cap and close the shutoff valve(s), if equipped, before removing the coolant filter. Failure to do so can result in personal injury from heated coolant spray.




1. Close valves (1) (2 points).
2. Using the filter wrench provided, remove cartridge (2) by turning it counterclockwise.
3. Clean the filter base and fit a new cartridge after applying a dab of engine oil to the seal face.
 - * Install the filter as specified by the filter manufacturer.
 - * Be careful not to tighten it up excessively.
 - * Be sure to fit a genuine Cummins cartridge.
 - * Install the new filter and tighten until the sealing ring contacts the filter head surface.
 - * Tighten the filter an additional one-half to three-fourths ($1/2$ to $3/4$) turn or refer to the filter manufacturer's instructions.
4. After replacement, open valves (1) (2 points).
 - * Replace once every 6 months, regardless of the number of hours operated.



COOLANT ADDITIVE CONCENTRATION


- * Inadequate concentration of the coolant additive can result in major corrosive damage to cooling system components. Over concentration can cause formation of "gel" that can cause restriction, plugging of passages, and overheating.
- * If the engine coolant is changed, the coolant filters must also be changed.

The cooling system must contain the proper coolant additive units to provide the best chemical protection.



DCA4 Test Kit: Use only DCA4 Coolant Test Kit, Fleetguard Part No. CC-2600 to check the coolant additive concentration in the cooling system.


- * Check once every 6 months, regardless of the number of hours operated.




MAINTENANCE

LUBRICATING


Apply grease to the grease fittings shown by arrows.





1. Bucket pin (2 points)




2. Dump cylinder pin (2 points)




3. Bucket link pin (2 points)



4. Lift cylinder pin (4 points)




5. Lift arm pivot pin (2 points)




MAINTENANCE

6. Tilt lever pin (1 point)



7. Steering cylinder pin (4 points)




AIR CONDITIONER COMPRESSOR BELT

1. The belt tension should normally deflect by about 10 mm when pressed with the finger at a point midway between the air conditioner compressor pulley and the fan pulley (approx. 6 kg).
 2. To adjust the belt tension, loosen bolt (1) and shift compressor (2) slightly.
 3. After adjustment, tighten bolt (1) securely.
- * When adjusting the V-belt, do not attempt to push compressor (2) directly with a bar or the like, but use a wood pad to prevent damage to the core.
 - * Check each pulley for damage, and V-grooves and V-belt for wear. Particularly, check whether V-belt is in contact with bottom of V-groove through wear.
 - * Replace belt if it has stretched, leaving no allowance for adjustment, or if there is a cut or crack on belt.

WHEEL HUB NUTS

If wheel hub nuts (1) are loose, tire wear will be increased and accidents may be caused. If any hub nuts are loose, tighten them to the specified tightening torque.

- * Tightening torque: 48 ± 5 kgm
- * If any wheel bolt is broken, replace all bolts for that wheel.
- * Always rotate in the direction of tightening when checking for loose nuts.



EVERY 500 HOURS SERVICE

- * Maintenance for every 50, 100 and 250 hours should be carried out at the same time.



TRANSMISSION OIL FILTER

1. Remove drain plug (1) at the bottom of the filter case, and drain the oil. After draining the oil, tighten the plug.
2. Hold case (2) and loosen center bolt (3), then remove case (2).
3. Remove the element, and clean the inside of the case. Assemble a new element, then install the case.

- * Be careful not to apply excessive torque to center bolt (3). Tightening torque: 18.5 ± 1.5 kgm

4. Run the engine for a short time at idling speed, then stop the engine. Check that the oil is at the specified level (for details, see WHEN REQUIRED).

- * Use a genuine Komatsu element.
- * Replace the filter gasket and o-rings with new parts. Coat the gasket and O-rings with clean engine oil before installing.
- * When tightening center bolt (3), install so that chamfered surface (4) of the washer faces the hexagonal head of the center bolt.




MAINTENANCE

LUBRICATING

Apply grease to the grease fitting shown by arrows.

1. Center drive shaft spline (1 point)



AIR DRYER

If the air dryer is installed as an option, carry out the following inspection, and if there is any abnormality, contact your distributor.

- Open the air tank drain valve and check that nothing is drained. Note that if the temperature around the tank is lower than 16°C, a small amount of water may be collected in the drain.
- Check that there is no abnormal inclusion of oil in the water drain from the exhaust port of the air dryer.

EVERY 1000 HOURS SERVICE

- * Maintenance done for every 50, 100, 250 and 500 hours should be carried out at the same time.

TRANSMISSION CASE AND STRAINER

1. Loosen drain plug (P) to drain oil. After draining off the oil, tighten up drain plug (P).




- * After loosening drain plug (P), pull out the plug slowly to prevent the oil spouting out.

2. Loosen drain plug (1) of transmission oil filter to drain oil. After draining off the oil, tighten up drain plug (1).

3. Remove bolt (2) and cover (3), then remove spring (4) together with strainer (5).


4. Remove all dirt from the surface of strainer (5), then wash in clean light oil. If strainer (5) is damaged, replace with a new part.

5. Install spring (4) and strainer (5) in cover (3). Replace the O-ring of the cover with a new part, then install the cover.




MAINTENANCE

6. Pour in the specified amount of engine oil from oil filter (F).
 7. After refilling, check the oil level and ensure that it is correct. (Refer to WHEN REQUIRED.)
- * The type of lubricant used depends on the ambient temperature. Select according to the table "FUEL COOLANT AND LUBRICANTS".
 - * Refill capacity: 59ℓ
 - * Check for oil leak at transmission case and filter.



TRANSMISSION CASE BREATHER


Remove all mud and dirt from around the breather, then remove the breather. Put in cleaning fluid and clean the breather.




LUBRICATING

Apply grease to the grease fittings shown by arrows.


1. Center hinge pin (2 points)




2. Front drive shaft (2 points)




3. Drive shaft center support (1 point)



4. Center drive shaft (2 points)



5. Rear drive shaft (3 points)




SECTION 2


Page 26

MAINTENANCE

6. Parking brake caliper (1 point)



7. Upper drive shaft (2 points)



8. Transmission mount trunnion (1 point)

EVERY 1500 HOURS SERVICE

- * Maintenance for every 50, 100, 250 and 500 hours should be carried out at the same time.

VALVES AND INJECTORS

1. Valves and injectors must be correctly adjusted for the engine to operate efficiently. Valve and injector adjustment must be performed using the values listed in this section.

Adjust the valves and the injectors at 1,500 hours or 1 year maintenance interval. Also, check adjustment after any major repair.

Valve and Injector Adjustment Limits		
"Top Stop" Injector Preload: 5.75~6.9 kg-cm		
	mm	in
Intake valve	0.35	0.014
Exhaust valve	0.68	0.027

2. If valve and injector adjustment is checked troubleshooting or before the 1,500 hours, or 1 year scheduled maintenance interval, adjustment is not required if measurements are within the recheck limits.

Refer to the L10 Troubleshooting and Repair manual, Bulletin No. 3810246, for valve and injector adjustment procedures, or contact a Cummins Authorized Repair location to perform this service.

Valve and Injector Recheck Limits		
"Top Stop" Injector Preload: 0.00 to 0.05 mm [0.000 to 0.0002 in.] Lash		
	mm	in
Intake valve	0.10 to 0.41	0.004 to 0.016
Exhaust valve	0.46 to 0.76	0.018 to 0.030

MAINTENANCE

EVERY 2000 HOURS SERVICE

* Maintenance for every 50, 100, 250, 500 and 1000 hours should be carried out at the same time.

HYDRAULIC TANK AND FILTER

1. Lower the bucket horizontally to the ground and apply the parking brake, then stop the engine.
2. Remove the cap of oil filler (F) and air vent plug (1) on filler case.



WARNING! When removing the cap, turn it slowly to relieve inner pressure.

3. Open drain valve (2) to drain oil. After draining, tighten the drain valve.



WARNING! After loosening the drain valve, pull it out to drain oil.

4. Remove mounting bolt (4) of the filter cover, then remove cover (3).



WARNING! The cover is pushed by a spring, so hold the cover when removing the bolts.

5. Remove spring (5) and bypass valve (6), then remove element (7).

* Check that there is no foreign matter inside the tank before cleaning it.

6. Install a new element, then install bypass valve (6), spring (5), and cover (3).

* If the O-ring of the cover is damaged or deteriorated, replace it with a new part.

* When installing the cover bolts, push down the cover and tighten the bolts evenly.

7. Pour in the specified quantity of engine oil from filler (F).




8. Bleed the air from the hydraulic circuit, lower the bucket horizontally to the ground and stop the engine. See "BLEEDING AIR FROM CIRCUIT" for the air bleed procedure.

9. Check the oil level and ensure that is correct. (Refer to EVERY 100 HOURS SERVICE.)

* The type of lubricant used depends on the ambient temperature. Select according to the table "FUEL, COOLANT AND LUBRICANTS".


* Refill capacity: 14ℓ

* Check that there is no oil leaking from the filter cover mount.



AIR CONDITIONER FILTER

1. Move the operator's seat forward, then tilt the backrest forward.
 2. Open the panel and loosen screw (1) holding the filter element. Pull out element (2).
 3. Install a new element and close the panel.
- * For the installation of the element, refer to EVERY 100 HOURS SERVICE.
4. Return the operator's seat to its original position.




HYDRAULIC TANK BREATHER

1. Remove cap of oil filler (F).



WARNING! When removing the cap, turn it slowly to relieve inner pressure.

2. Remove snap ring on breather (1), then remove breather cap.
3. Replace filter element with a new part, then install cap and snap ring.



- * It is possible to replace the element with the breather installed in the tank. However, if the breather is removed, do not wrap the taper thread of the breather with seal tape when assembling again, and be careful not to tighten too much.


AXLE

Front

1. Remove front and rear oil filler plugs (1), then remove drain plugs (2) to drain the oil.

After draining the oil, tighten drain plugs (2).

2. Remove front and rear drain plugs (3) and (4) of each side, and drain the oil.




SECTION 2

Page 30

MAINTENANCE



Rear

3. Stop the machine so that drain plug (6) of the final drive is at the bottom. Remove oil filler plug (5) and drain plug (6), and drain the oil.
4. After draining the oil, clean drain plugs (3), (4) and (6), then install them.
5. Add oil to the specified level through the oil filler ports (1), (5) of the axle housing and left and right final drives.




6. Check the oil level and ensure that it is correct. (Refer to WHEN REQUIRED.)

- * Use the same procedure to change the oil for the front and rear axles.
- * Refill capacity: 65ℓ (each axle)
- * The type of lubricant used depends on the ambient temperature. Select according to the table "FUEL, COOLANT AND LUBRICANTS".



PPC CIRCUIT STRAINER

1. Loosen bolts (1) (3 pieces).
2. Remove strainer case (2) and pull out the strainer, then wash strainer with clean diesel fuel.
3. Install the strainer in strainer case (2), and mount with bolts (1).



ALTERNATOR AND STARTING MOTOR

As the hours of engine employment indicate that the brushes are already worn out, you should request repair from your distributor.

- * They should be repaired every 1000 hours, if the machine is frequently operated at night.

BRAKE DISC

Ask your distributor to check and repair brake disc.

INTERNAL PART OF AIR DRYER

If the air dryer is installed as an option, replace the following internal parts of the air dryer:

Desiccant, oil filter, filter, and all rubber parts.

Contact your distributor to have these parts replaced.

ACCUMULATOR

Have your distributor check the gas pressure every 2000 hours or every year.

MAINTENANCE


EVERY 6000 HOURS SERVICE

* Maintenance for every 50, 100, 250, 500, 1000, 1500, and 2000 hours should be carried out at the same time.

INJECTORS

Every 6,000 hours or 3 years, clean and calibrate the injectors.


This procedure requires special equipment and **must** be done at a Cummins Authorized Repair Location.



FUEL PUMP

Every 6,000 hours or 3 years, clean and calibrate the fuel pump.

This procedure requires special equipment and **must** be done at a Cummins Authorized Repair Location.




TURBOCHARGER

1. If the engine is equipped with a turbocharger, inspect the turbocharger every 6,000 hours or 3 years. Remove the air intake and the exhaust piping. Check the turbocharger as follows:

- Look for damaged or cracked compressor or turbine blades. Check to see that the turbocharger shaft spins freely.

- * If visual inspections or dimensional checks indicate a problem, contact a Cummins Authorized Repair Location for assistance. Refer to the model number on the turbocharger dataplate.




2. Measure axial clearance (end to end).

Rebuild or replace the turbocharger if axial clearance is greater than specified.

Turbocharger Model No.	Dimension	
	Minimum	Maximum
H2C	0.03 mm [0.001 in.]	0.08 mm [0.003 in.]


Refer to the L10 Troubleshooting and Repair Manual to remove. Refer to Turbocharger Rebuild manual to rebuild.



3. Measure radial clearance (side to side).

- * Hold the shaft toward the feeler gauge to check this dimension.

Turbocharger Model No.	Dimension	
	Minimum	Maximum
H2C		
• Compressor		
• Impeller	0.15 mm [0.006 in.]	0.41 mm [0.016 in.]
• Turbine		
• Wheel	0.27 mm [0.011 in.]	0.47 mm [0.019 in.]




Install the air intake and the exhaust piping.

AIR COMPRESSOR

1. Complete air compressor inspection is required every 6,000 hours or 3 years.

- * All air compressors have a small amount of oil carryover which lubricates the piston rings and moving parts. When this oil is exposed to normal air compressor operating temperatures over a period of time, it will form varnish or carbon deposits. If the following inspections are not done, the air compressor piston rings will be affected by high operating temperatures and pressure and will not seal correctly.





SECTION 2


Page 34

MAINTENANCE


2. Drain the air system wet tank to release the system air pressure. Remove the air discharge line from the air compressor.
- * Pull rings (1) on the drain valves, and drain water and air out of the tank.



3. Measure the total carbon thickness inside the air discharge line as shown. If the total carbon deposit ($X + X$) exceeds 2 mm [1/16-inch], clean and inspect the cylinder head, the valve assembly, and the discharge line. Replace if necessary. Refer to the appropriate Air Equipment Manual listed below for procedures, or contact your Cummins Authorized Repair Location:
- Single Cylinder, Bulletin No. 3810242



If the total carbon deposit exceeds specifications, continue checking the air discharge line connections up to the first tank until total carbon deposit is less than 2 mm [1/16-inch]. Clean or replace any lines or connections that exceed this specification.




MAINTENANCE

SECTION 2

Page 35


4. Inspect any air driers, spitter valves, pressure relief valves, and alcohol injectors for carbon deposits or malfunctioning parts. Inspect for air leaks. Maintain and repair the parts according to the manufacturer's specifications.



5. Remove the capscrews, the lock washers, and the flat washers that secure the unloader valve assembly to the cylinder head cover. Remove the unloader valve assembly and the spring from the cylinder head and the cover.




WARNING! Hold the unloader valve down when removing the capscrews. Personal injury can result from the sudden release of the spring-loaded unloader valve.




6. Visually inspect the unloader valve for carbon buildup. If carbon or heavy varnish is present, remove, clean, and inspect the compressor head and the valve assembly. Replace parts as necessary. Refer to the appropriate Air Equipment Manual listed below for procedures, or contact your nearest Cummins Authorized Repair Location:

- Single Cylinder, Bulletin No. 3810242



If the unloader valve is clean or only lightly varnished, install a new o-ring on the unloader body and a new rectangular seal inside the unloader body cavity.

- * The open side of the rectangular seal must face the top of the unloader body.




SECTION 2

Page 36

MAINTENANCE

7. Lubricate the unloader cap with anti-seize compound. Lubricate the unloader body o-ring with engine oil. Assemble the unloader assembly to the cylinder head cover. Tighten the cap-screws.

Capscrews: 1.38 kgm




WATER PUMP

Every 6,000 hours or 3 years, visually inspect the water pump body for indications of water leakage at the weep hole.

If a water leak is indicated, replace the water pump with a new rebuilt unit as necessary.


Refer to the Troubleshooting and Repair Manual, Bulletin No. 3810246, for removal and replacement instructions.



FAN IDLER PULLEY

Every 6,000 hours or 3 years, measure the pulley end clearance. The end clearance must be 0.05 to 0.25mm [0.002- to 0.010-inch].


If the end clearance does **not** meet the above specifications, it must be rebuilt or replaced. Refer to the Engine Shop manual top rebuild or the Troubleshooting and Repair Manual for replacement procedures.



FAN HUB (BELT DRIVEN)

Every 6,000 hours or 3 years, measure the pulley flange end clearance. The end clearance must be 0.08 to 0.41mm [0.003 to 0.016-inch].

If the end clearance does not meet the above specifications, it must be rebuilt or replaced. Refer to the Troubleshooting and Repair manual for replacement procedures.



COOLANT CHANGE AND FLUSHING THE SYSTEM

COOLANT

Heavy duty diesel engines require a balanced coolant mixture of water, antifreeze, and supplemental coolant additives (supplemental coolant additive recommendations are included in this Section). Drain and replace the mixture every 2 years, or 6,000 hours of operation, whichever occurs first.

- DCA4 is recommended for use in all Cummins engines.
- In climates where the temperature is above -37°C [-34°F], use a coolant mixture that contains 50 percent antifreeze. **Antifreeze is essential in any climate.** It broadens the operating temperature range by lowering the coolant freezing point and by raising its boiling point. Do not use more than 50 percent antifreeze in the mixture unless additional freeze protection is required. **Never** use more than 68 percent antifreeze under any condition.
- Use low silicate antifreeze which meets Engineering Standard GM 6038-M or which contains no more than 0.1 percent anhydrous alkali metasilicate and meets either Engineering Standard GM 1825-M 1899-M which are performance specifications.
- Use soft water in the coolant mixture. Contaminants in hard water neutralize the corrosion inhibitor components. **Water must not** exceed 300 ppm hardness or contain more than 100 ppm of either chloride or sulfate.
- Maintain supplemental coolant additive levels at 1 unit DCA4 per 3.8 liters [1 U.S. gallon] of coolant.

DCA4 UNIT MAINTENANCE GUIDE

Use supplemental coolant additives (corrosion inhibitors) to protect the engine cooling system from corrosion. Antifreeze alone does not provide enough corrosion protection for a heavy duty diesel engine. Supplemental corrosion protection must be supplied through periodic additions of supplemental coolant additives to the coolant.

To protect against corrosion, a new coolant charge must be brought up to 0.26 DCA4 unit per liter [one unit per U.S. gallon] of coolant (initial charge). Maintain the correct DCA4 concentration by changing the maintenance coolant filter at each oil drain interval.

Each time the coolant is drained and replace, the coolant **must** be recharged with supplemental coolant additives. Use the appropriate DCA4 spin-on filter listed in Table 1. The mixture must be drained and replaced every 2 years, or 6,000 hours of operation.

The amount of replacement inhibitor is determined by the length of the service interval and the cooling system capacity. Refer to the DCA4 Maintenance Guide for the selection of the correct filter to replenish the DCA4.

If coolant is added between drain intervals, additional DCA4 will be required. Check the coolant periodically just before changing the coolant filter to make sure that the correct maintenance coolant filter is being used. The DCA4 concentration **must** not fall below 0.13 units per liter or exceed 0.5 units per liter [0.5 units per U.S. gallon nor exceed 2 units per U.S. gallon].


DCA4 UNIT MAINTENANCE GUIDE

	Fleetguard Part No.	Cummins Part No.	DCA4 Units
Table 1:	WF-2071	3315116	4
	WF-2073	3315115	8
	WF-2074	3316053	12
	WF-2075	3318318	15
Table 2:	DCA4 Liquid		
	DCA60L	3315459	4 [1 pint]
	DCA80L	3317428	1760 [55 gallons]
Table 3:	DCA4 Powder		
	DCA95	3318320	20
Table 4:	RESTORE Heavy-Duty Cooling System Cleaner		
	CC2610	None	1 gallon
	CC2611	None	5 gallons
	CC2612	None	55 gallons
	System Capacity (A)	Precharge Filter (B)	Service Filter (C)
Liters	Gallons		
42 to 57	11 to 15	WF-2074	WF-2071


Notes

- A. Total cooling system capacity: 55
- B. After draining and replacing the coolant, **always** precharge the cooling system to maintain the DCA4 concentration between 1 and 2 units per gallon.
- * When performing service which requires draining the cooling system, discard the coolant. Reusing coolant can introduce contaminants or overconcentrated chemicals, resulting in premature failure of cooling system components.
- C. Change coolant filters at every oil and filter change interval to protect the cooling system. The service filters listed above are satisfactory for use with maintenance intervals from 250 to 480 hours.


1. Stop the engine and tighten up corrosion resistor (coolant filter) valve (1).
2. Turn cap (2) slowly until it comes off.
3. Open drain valve (3) at the bottom of the radiator and plug (4) on the under side of water pump to drain off the cooling water.
4. Drain off all the water, then close up drain valve (3), plug (4), and pour in soft water (ex: city water) up to the vicinity of the water filler.
5. When the water reaches the vicinity of the water filler, put the engine at low idling, open drain valve through the cooling system for 10 minutes.



- * When doing this, adjust the inflow and outflow of water so that the radiator is always full.
6. After flushing with water, stop the engine. Close drain valve (3) and drain plug (4) after draining water.
 7. After draining water, use a flushing agent to clean.
- * We recommend the use of Komatsu genuine goods as the flushing agent. Follow the instructions on the label of the flushing agent to clean the system.





8. After washing the cooling system, drain off all the water, then close up drain valve (3) and plug (4), and pour in soft water (ex: city water) up to the vicinity of the water filler.
9. When the water reaches the vicinity of the water filler, put the engine at low idling, open drain valve (3) and plug (4), then pass water through the cooling system until clean water comes out from drain valve (3) and plug (4).



- * When doing this, adjust the inflow and outflow of water so that the radiator is always full.

10. When the water becomes completely clean, stop the engine, close drain valve (3) and plug (4).
 11. Replace the corrosion resistor (coolant filter) cartridge and corrosion resistor (coolant filter) valve (1) (See EVERY 250 HOURS SERVICE).
 12. Supply water up to the vicinity of the water filler.
 13. Run the engine for 5 minutes at low idling to eliminate air trapped in the cooling system, and run the engine for 5 minutes at high idling. (Leave water filler cap (2) off during this operation.)
 14. Stop the engine and 3 minutes later supply water again up to vicinity of the water filler and tighten water filler cap.
 15. Remove radiator level sensor (6), supply water through the sensor hole and fit the sensor.
- * Tightening torque of the sensor: 28 ± 3 kgm
16. Drain the cooling water inside sub-tank (5), then clean the inside of the sub-tank and fill again with water to a point between the H and L lines.



WARNING! Do not remove the cap while cooling water is hot. Hot water may spout out. When removing radiator cap, lift the lever to relieve inner pressure.


- * Drain and replace the mixture every 2 years, or 6000 hours of operation, whichever occurs first.

WHEN REQUIRED

TURBOCHARGER MOUNTING NUTS

Check the turbocharger mounting nuts annually. Tighten the mounting nuts.


Mounting nuts: 6.9 kgm



CHECK, CLEAN AND REPLACE AIR CLEANER ELEMENT


CHECKING

Whenever the red piston in dust indicator (1) appears, clean the air cleaner outer element. Stop the engine when cleaning the element.




CLEANING OR REPLACING OUTER ELEMENT

1. Loosen wing bolt (2) and remove cover (3).
Loosen wing nut and remove outer element.
2. Clean the air cleaner body interior and the removed cover.
3. Clean and inspect the element. (See the item "Cleaning outer element" for cleaning procedure.
4. Install the cleaned element.
5. Push the dust indicator reset button to return the red piston to the original position.



- * Replace the outer element which has been cleaned 6 times repeatedly or use throughout a year. Replace the inner element at the same time.
- * Replace both inner and outer elements when the dust indicator red piston appears soon after installing the cleaned outer element even though it has not been cleaned 6 times.
- * Remove one seal from the outer element. The number of times the outer element has been cleaned can be seen by the number of removed seals.
- * Check inner element mounting nuts for looseness and, if necessary, retighten.
- * Replace seal washer (4) or wing nut (5) if they are broken.



REPLACING INNER ELEMENT

1. First remove the cover and the outer element, and then remove the inner element.
2. Place the cover over the air intake part to prevent dust entering.
Clean the air cleaner body interior, then remove the cover from the air intake port.
3. Fit a new inner element and tighten it with nuts.
4. Install the outer element and the cover. Push the dust indicator reset button.

Note: Do not attempt to reinstall a cleaned inner element.



WARNING! Do not clean or replace the air cleaner element with the engine running.


CLEANING OUTER ELEMENT

With compressed air

Direct dry compressed air (less than 7 kg/cm^2) to element from inside along its folds, then direct it from outside along its folds and again from inside, and check element.



WARNING! When using compressed air, wear safety glasses and other things required to maintain safety.



The following methods require spare parts.


With water

Dash city water (less than 3 kg/cm^2) on element from inside along folds, then from outside and again from inside. Dry and check it.

With cleaning agent

For removing oils and fats as well as carbon etc. attached on the element, the element may be cleaned in lukewarm solution of mild detergent, then rinsed in clean water and left to drip dry.


- * Drying can be speeded up by blowing dried compressed air (less than 7 kg/cm^2) from the inside to the outside of the element.
Never attempt to heat the element.
- * Using warm water (about 40°C) instead of soapy water may also be effective.
- * If small holes or thinner parts are found on element when it is checked with an electric bulb after cleaning and drying, replace the element.
- * If element is usable, wrap it and store it in dry place.
- * Do not use element whose folds or gasket or seal are damaged.
- * When cleaning element, do not hit it or beat it against something.




CHECK AND REFILL TRANSMISSION OIL

Carry out this procedure if there is any sign of oil on the transmission case, or if there is oil mixed with the cooling water.

1. Stop the engine and remove the cap of oil filler (F).
2. Use dipstick (G) to check the oil level.
3. The oil level should be between mark L and H, if necessary, add oil at the oil filler (F).



- * The type of lubricant used depends on the ambient temperature. Select according to the table "FUEL, COOLANT AND LUBRICANTS".
- * There are two sets of level marks on the same side of the dipstick: one is for measuring when the engine is stopped (ENGINE STOP), and the other is for measuring when the engine is idling (ENGINE IDLE).
- * When measuring the oil level, wait for at least 60 minutes after stopping the engine, and measure with the ENGINE STOP marks.



It is possible to measure when the engine is at low idling, but in such cases, do as follows. Start the engine and run it until the oil level is stable, then wait for 5 minutes and measure with the ENGINE IDLE marks.




WARNING! When checking the oil level, apply the parking brake, and lock the front and rear frames with the safety bar and pin.

CLEAN RADIATOR FINS

Carry out this procedure if there is any mud or dirt seen stuck to the radiator.

1. Loosen bolt (1) and remove radiator grille (2).
 2. Clean the radiator fins and oil cooler fins clogged with mud, dust and leaves with compressed air. Steam or water may be used instead of compressed air.
- * The rubber hose should be checked at the same time. If the hose is found to have cracks or to be hardened by aging, such hose should be replaced by new one. Further, loosened hose clamp should also be checked.





MAINTENANCE

CHECK AND REFILL AXLE OIL

Carry out this procedure if there is any sign of oil on the axle case.

Remove oil level plug (1), and check that the oil level reaches the bottom of the plug hole. If necessary, add oil through the hole of plug (2).

- * The type of lubricant used depends on the ambient temperature. Select according to the table "FUEL, COOLANT AND LUBRICANTS".
- * Use the same procedure to check and add the oil for the front and rear axles.





CLEAN AXLE CASE BREATHER

Carry out this procedure if there is any mud or dirt stuck around the breather.

Remove all mud and dirt from around the breather with brush.

- * Clean the breathers of the front and rear axles in the same way.




LUBRICATING

Apply grease to the grease fittings shown by arrows.


1. Work equipment control valve linkage (2 points)

If the work equipment control lever is heavy or does not move smoothly, apply grease.



2. Steering column (1 point)

If the play or the steering column is heavy or does not return properly, apply grease.




CLEAN CONDENSER OF AIR CONDITIONER

If there is mud or dust on the air conditioner condenser, clean it with water.

- * If the water pressure is too high, the fins may get deformed. When washing with a high pressure washing machine, apply the water from a reasonable distance.



WARNING! Do not wash the condenser with a stream cleaner. Otherwise, the condenser will get hot and may break down.



MAINTENANCE

CHECK AIR CONDITIONER

Check twice a year, in spring and autumn.

CHECK LEVELS OF REFRIGERANT (GAS)




Operate the cooler of the air conditioner for 5 - 10 minutes, then touch the high pressure portion and low pressure portion of the compressor (or high pressure hose and low pressure hose joint) by hand. At the same time, inspect the flow of refrigerant gas (freon 12) through the sight glass to check the gas level.

Please contact your distributor for this inspection.

The sight glass is installed at the side of the window washer tank inside of the cover at the top behind the operator's seat.




WARNING! The cooler refrigerant is colorless and odorless and does not cause pollution of the atmosphere. However, it may cause injury if it gets in the eyes or on the hands, so never loosen any parts of the refrigerant circuit.

Cooler condition	Normal		Abnormal	
Temp of high, and low pressure pipes	High pressure pipe is hot Low pressure pipe is cold. Clear difference in temperature.	High pressure pipe is warm. Low pressure pipe is cold. Little difference in temperature.	High pressure pipe is warm. Low pressure pipe is cold. Little difference in temperature.	Almost no difference in temperature between high and low pressure pipes.
Sight glass	Almost transparent. Any bubbles disappear if the engine speed is raised or lowered. 	Bubbles are always flowing. Sometimes becomes transparent, or white bubbles appear. 	Bubbles are always flowing. Sometimes becomes transparent, or white bubbles appear. 	Misty substance is flowing.
Connections of pipes.	Properly connected.	Some parts dirty with oil.	Some parts very dirty with oil.	
General condition of cooler.	Coolant level correct, no abnormalities. Ready for use.	May be a leak somewhere. Call service repair shop for inspection.	Almost all coolant has leaked out. Contact service repair shop immediately.	

CHECK AND REFILL WINDOW WASHING FLUID

Check the washing fluid level in washer tank (1). When the fluid has run short, add automotive window washing fluid.

- * To prevent the nozzles from clogging, be careful not to let dust get into the fluid.



REPLACING BUCKET TEETH

IF THE BUCKET EQUIPPED WITH BOLT-ON TOOTH.

When the bucket teeth are worn, replace them as follows.

1. Raise the bucket to a convenient height, and put blocks under the bucket to prevent it from coming down.

- * Raise the bucket so that the bottom is horizontal.

2. Remove the bolts and nut (1), (3) then remove the bucket tooth (2).

3. Install the new teeth on the bucket. When installing the teeth, insert the shim so that there is no clearance between teeth and top surface of the bucket.

- * Thickness of shim is 0.5 mm. So the clearance should be less than 0.5 mm.


4. To prevent any clearance between the tooth and the edge of the bucket, tighten the nut partially, then hit the tip of the tooth with a hammer.

- * Tightening torque of mounting bolt:

mounting bolt (1): 92 ± 4 kgm

mounting bolt (3): 63 ± 3 kgm

- * After operating the machine for a few hours, tighten the mounting bolts again.




MAINTENANCE

IF THE BUCKET EQUIPPED WITH TIP TOOTH


Replace the teeth before they wear down as far as the adaptor.

1. Extract pin (2) fitted to the bucket and then remove tooth (1).

* When extracting pin (2), strike the part (either the left or right part) with a sharp object. This will enable the pin to be extracted from the opposite side.



2. Insert the new tooth (1) into the adaptor (3), and insert pin (2) partway as shown in the diagram. Then drive it home by means of a hammer.



REVERSING AND REPLACING BOLT-ON CUTTING EDGE

IF THE BUCKET EQUIPPED WITH BOLT-ON CUTTING EDGE

If the bolt-on cutting edge is worn, turn the edge.

1. Raise the bucket to a convenient height, and put blocks under the bucket to prevent it from coming down.

* Raise the bucket so that the bottom is horizontal.

2. Loosen nut (1) and remove bolt (2). Then turn the cutting edge.


3. Exchange cutting edges (3) and (4), and install edge (5) in the opposite direction.

4. After exchanging, tighten with bolts (2) and nuts (1).

* Tightening torque: 76 ± 11 kgm

* When installing the edge to the bucket, clean the mounting surface.

* After the edge has been turned once, replace it with a new part.




ADJUSTMENT

ADJUSTING PARKING BRAKE

If the effect of the parking brake is poor, adjust as follows.


1. Turn the parking brake switch to OFF, release the parking brake and release caliper (1).
2. Turn adjustment bolt (3) of caliper lever (2) to clockwise so that pad (4) is in contact with disc (5) lightly.
- * If adjustment bolt (3) is turned until pad (4) comes into contact with disc (5) tightly, it causes brake noise and heat generation on disc.
3. Turn adjustment bolt (3) one click to counter-clockwise. The total clearance (a + b) on the both side between pad (4) and disc (5) becomes 0.3 to 0.6 mm.



WARNING! When adjusting, always put blocks under the tires to prevent the wheels from moving.



WARNING! To prevent the parking brake from being applied automatically during adjustment, raise the air pressure, and put a warning tag on the parking brake switch to prevent other people from touching it.




When the pad wears to a thickness of less than 8 mm (including backing plate), replace the pad.

- * Replace two pads as one set, and replace the retraction plate at the same time.
- * Have the pads replaced by your distributor.



WARNING! Do not get any oil or grease on the surface of the brake pad or disc.




MAINTENANCE


ADJUSTING LENGTH OF LEVER

It is possible to adjust the length of the directional lever and speed control lever.


1. Pull out knob (1).



2. Loosen locknut (2) and turn bolt (3) to adjust.
3. After adjusting, tighten locknut (2), and push in knob (1) fully.



* Keep distance l under 43 mm. If it is not screwed in far enough it is dangerous.



TROUBLE SHOOTING GUIDE

This guide is not intended to cover all conditions, however many of the more common possibilities are listed.

ELECTRICAL SYSTEM

Lamp does not glow brightly even when engine runs at high speed.

Lamp flickers while engine runs.

- Check for loose terminals and open-circuit wiring.
- Adjust belt tension.

Charge monitor does not go out even when engine runs at high speed.

- Replace the alternator.
- Inspect and repair wiring.

Unusual noise is emitted from the alternator.

- Replace the alternator.

Starting motor does not turn when starting switch is turned on.

- Inspect and repair the wiring.
- Charge the battery.

The pinion of the starting motor keeps going in and out.

- Charge the battery.

Starting motor turns the engine sluggishly.

- Charge the battery.
- Replace the starting motor.

The starting motor disengages before the engine starts up

- Check and repair the wiring.
- Charge the battery.

The engine pre-heating monitor does not flash.

- Check and repair the wiring.
- Replace the heater relay.
- Replace the monitor.

The engine oil pressure monitor does not light up when engine is stationary (when the starting switch is in ON position.)

- Replace the monitor.
- Replace the monitor switch.

**Charge monitor does not light up when the engine is stationary.
(When the starting switch is in ON position.)**

- Replace the monitor.
- Inspect and repair the wiring.

Outside the electrical intake air heater is not warm when touched with the hand.

- Check and repair the wiring.
- Replace the electrical intake air heater.
- Check and repair the heater switch.

ENGINE

The engine oil pressure monitor flashes when engine speed is raised after completion of warm-up.

- Add the oil to the specified level.
- Replace the element.
- Check oil leakage from the pipe or the joint.
- Replace the monitor.

Steam is emitted from the top of the radiator (the pressure valve).

The radiator cooling water temperature monitor flashes.

- Supply the cooling water and check leakage.
- Adjust fan belt tension.
- Wash out inside of cooling system.
- Clean or repair the radiator fin.
- Replace the thermostat.
- Tighten the radiator cap firmly or replace the gasket of it.
- Replace the monitor.

The engine does not start when the starting motor is turned over.

- Add fuel.
- Repair where air is leaking into fuel system.
- Replace the injection pump or the nozzle.
- Check the valve clearance.
- Check engine compression pressure.
- Refer to the section of electrical system.

Exhaust gas is white or blue.

- Adjust to specified oil quantity.
- Replace with specified fuel.

Exhaust gas occasionally turns black.

- Clean or replace the air cleaner element.
- Replace the nozzle.
- Check engine compression pressure.
- Clean and replace turbocharger.

Combustion noise occasionally changes to breathing sound.

- Replace the nozzle.

Unusual combustion noise or mechanical noise.

- Replace with specified fuel.
- Check over-heating.
- Replace the muffler.
- Adjust valve clearance.

CHASSIS

TRANSMISSION

Engine is running but machine will not move.

- Release parking brake.
- Put directional lever in position properly.
- Add oil to transmission case to the specified level.

Even at full throttle, machine moves slowly and lacks power.

- Add oil to transmission case to the specified level.
- Disassemble transmission strainer and clean.

Oil overheats.

- Add oil to transmission case to the specified level or drain oil.
- Use a suitable gear speed.
- Reduce time using torque converter at stall speed.
- Check engine.

Abnormal noise is produced.

- Add oil to transmission case to the specified level.

AXLE

Abnormal noise is produced.

- Add oil to transmission case to the specified level.

DISC BRAKE

Brake does not work when pedal is depressed.

- Raise air pressure to specified level.
- Replace disc.
- Bleed air from brake system.

Brake drags or stays applied.

- Clean exhaust hole of treadle valve.
- Clean breather of power cluster.
- Check and repair slack adjuster.

Brake slips.

- Replace disc.

PARKING BRAKE

Brake does not work properly.

- Adjust linkage.
- Clean brake pad.
- Replace spring in air cylinder.
- Adjust or replace brake pad.

STEERING

Steering wheel is heavy.

- Adjust steering gear.
- Check linkage, replace parts.

HYDRAULIC SYSTEM

Bucket lacks lifting power.

Bucket lifting speed is slow.

- Add oil.
- Replace filter in hydraulic tank.

Many bubbles form in oil.

- Replace with specified oil.
- Add oil.
- Bleed air from oil line.

Oil pressure is too low.

- Add oil and bleed air.

Cylinder vibrates when operating.

- Add oil.

SERVICE METER

This meter indicates the integrated work hours. So, use it according to the following instructions.


- Record the readings of the start and the end of work, this is the work record of the machine.
- This record will indicate, when periodical maintenance is due.
- It also indicates the integrated working hours when machine problems are encountered.

* How the meter progresses

The service meter progresses by 1 when the engine is operated for one hour, regardless of the engine speed.

Consequently, if the engine is running, the service meter will advance even if the machine does not move.

- While the engine is running, green pilot lamp on the service meter flashes to show the service meter advances.




MACHINE AND ENGINE SERIAL NUMBERS

When calling for a service of mechanic or when making replacement-parts order, be sure to give your distributor the machine and engine serial numbers as well as the service meter reading before mentioned. These numbers are found on the plates shown in the photos below.


- Location of the machine serial number mark

This is seen on the center right of the front frame.



- Location of the engine serial number plate

This is seen on the upper right of the cylinder block, when seen from the fan side.



- * The engine number plates (shown below) show specific information about your engine. The engine serial number (1) and Control Parts List (CPL) (2) provide information for ordering parts and service needs.

Engine No.	S.O. No.				E.C.S.			VEHICLE EMISSION CONTROL INFORMATION: This engine conforms to U.S. EPA and the CARB regulations applicable to 1997 Year New Heavy Duty Duty Engines. This engine has a primary intended use in application as a heavy-duty diesel engine.
Model	Ref. No.	Engine Code	CID	Family	CPL	Injection timing code		
Advertised HP	at	RPM	Engine Code	Family	CPL	Injection torque	inches, lbs	
Cont. No.						Injection travel	inch	Idle Speed
Date of mfg.			Warranty start date			Valve lash code	int	RPM
Manufactured by Cummins Engine Company Inc. U.S.A. 1041 110						Fuel rate at advertised HP	gpm	gpm

↑ 1
 ↑ 2

FUEL, COOLANT AND LUBRICANTS

PROPER SELECTION OF FUEL, COOLANT AND LUBRICANTS

RESERVOIR	KIND OF FLUID	AMBIENT TEMPERATURE										CAPACITY	
		-32 -30	-4 -20	14 -10	32 0	50 10	68 20	86 30	104 40	122°F 50°C	Specified	Refill	
Engine oil pan	Engine oil (See NOTE 1 and 2)	SAE 20W-40, 20W-50										40	32
		SAE 15W-40											
		SAE 10W-30											
		SAE 5W-20, 5W-30 [See NOTE (1-1)]											
Transmission case (1)	Engine oil (See NOTE (3))	SAE 10W										61	59
Hydraulic system (2)		SAE 10W										230	148
Axle (Front and rear) (3)		See NOTE (4)										each 65	each 65
Fuel tank	Diesel fuel	See NOTE (5)										383	-
Cooling system	Coolant	See NOTE (6)										55	-

(1) Includes torque converter, transfer and cooler

ASTM: American Society of Testing and Material

(2) Includes brake system

SAE: Society of Automotive Engineers

(3) Includes differential and planetary gear case

API: American Petroleum Institute

Specified capacity: Total amount of oil including oil for components and oil in piping.

Refill capacity: Amount of oil needed to refill system during normal inspection and maintenance.

NOTE

- (1) The use of quality engine lubricating oils combined with appropriate oil drain and filter change intervals is a critical factor in maintaining engine performance and durability.

Cummins Engine Company, Inc. recommends the use of a high quality SAE 15W-40 heavy duty engine oil (such as Cummins Premium Blue) which meets the American Petroleum Institute (API) performance classification CE.

- * CC/CD or ZCD/SF engine oils can be used in areas where CE oil is not yet available.

A sulfated ash limit of 1.0 mass percent is suggested for optimum valve and piston deposit and oil consumption control. The sulfated ash **must not** exceed 1.85 mass percent.

For further details and discussion of engine lubricating oils Cummins engines, refer to Bulletin No. 3810340, Cummins Engine Oil Recommendations.

The API service symbols are shown in the accompanying illustration. The upper half of the symbol displays the appropriate oil categories; the lower half may contain words to describe oil energy conserving features. The center section identifies the SAE oil viscosity grade.

- * Alternate Oil Grades

10W -20°C to 10°C [-4°F to 50°F]

30 4°C and above [39°F and above]

20W -10°C to 25°C [14°F to 77°F]

40 10°C and above [50°F and above]

- * The use of low viscosity oils, such as 10W or 10W-30, can be used to aid in starting the engine and in providing sufficient oil flow at ambient temperatures below -5°C [23°F]. Continuous use of low viscosity oils can decrease engine life due to wear.

- (1-1) These oils are available commercially with better low temperature properties. Consult your supplier.

- (2) If an engine is operated in ambient temperatures consistently below -23°C [-10°F] and there are no provisions to keep the engine warm when it is not in operation, use a synthetic CE/SF engine oil with adequate low temperature properties such as 5W-20 or 5W-30.

The oil supplier **must** be responsible for meeting the performance service specifications.

- * The use of a synthetic base oil does not justify extended oil change intervals. Extended oil change intervals can decrease engine life due to factors such as corrosion, deposits, and wear.

Special "break-in"; engine lubricating oils are not recommended for new or rebuilt Cummins engines. Use the same type oil during the "break-in" as that which is used in normal operation.

- * A sulfated ash limit of 1.85 percent has been placed on all engine lubricating oils recommended for use in Cummins engines. Higher ash oils can cause valve and/or piston damage and lead to excessive oil consumption.

Additional information regarding lubricating oil availability throughout the world is available in the E.M.A. Lubricating Oils Data Book for Heavy Duty Automotive and Industrial Engines. The data book may be ordered from the Engine Manufacturers Association, One Illinois Center, 111 East Wacker Drive, Chicago, IL U.S.A. 60601. The telephone number is: (312) 644-6610.

- (3) Use API classification CD as engine oil and if API classification CC, reduce the engine oil change interval to half.

- (4) For axle oil, use only recommended oil as follows.

SHELL:	DONAX TT OT TD
CALTEX:	RPM TRACTOR HYDRAULIC FLUID
CHEVRON:	TRACTOR HYDRAULIC FLUID
TEXACO:	TDH OIL
MOBIL:	MOBIL AND SUPER UNIVERSAL

- * It is possible to substitute engine oil CLASS-CD SAE30 for axle oil. If noise comes from the brake, it is no problem of durability.
- (5) Cummins recommends the use of ASTM No. 2D fuel. The use of No. 2 diesel fuel will result in optimum engine performance. At operating temperatures below 0°C [32°F], acceptable performance can be obtained by using blends of No. 2 D and No. 1 D. the use of lighter fuels can reduce fuel economy.

The viscosity of the fuel **must** be kept above 1.3 cSt to provide adequate fuel system lubrication.

For a more detailed description of fuel properties, refer to Fuel For Cummins Engines, Bulletin No. 3379001.



WARNING! Do not mix gasoline or alcohol with diesel fuel. This mixture can cause an explosion.

- (6) Heavy duty diesel engines require a balanced coolant mixture of water, antifreeze, and supplemental coolant additives (supplemental coolant additive recommendations are included in the Section). Drain and replace the mixture every 2 years, 6,000 hours of operation, whichever occurs first.

- DCA4 is recommended for use in all Cummins engines.
- In climates where the temperature is above -37°C [-34°F], use a coolant mixture that contains 50 percent antifreeze. **Antifreeze is essential in any climate.** It broadens the operating temperature range by lowering the coolant freezing point and by raising its boiling point. Do **not** use more than 50 percent antifreeze in the mixture unless additional freeze protection is required. **Never** use more than 68 percent antifreeze under any condition.
- Use low silicate antifreeze which meets Engineering Standard GM 6038-M or which contains no more than 0.1 percent anhydrous alkali metasilicate and meets either Engineering Standard 1828-M or GM 1899-M which are performance specifications.
- Use soft water in the coolant mixture. Contaminants in hard water neutralize the corrosion inhibitor components. Water **must not** exceed 300 ppm hardness or contain more than 100 ppm chloride or sulfate.
- Maintain supplemental coolant additive levels at 1 unit DCA4 per 3.8 liters [1 U.S. gallon] of coolant.

MAINTENANCE

MEMORANDA



SECTION 3

SAFETY AND OPERATION



**WARNING ! REFER TO AND READ ALL
SAFETY PRECAUTIONS IN THIS SECTION.**

SAFETY AND OPERATION


SAFETY HINTS. . . ⚠

Protect yourself and others. Safety is always first.


OPERATION

GENERAL


- Wear well-fitting helmet, safety shoes and working clothes. If the nature of the work requires safety, wear protective goggles or mask, thick gloves, ear plugs or other protection.
- Take care of your health. Do not operate when tired, or after drinking.




- When there is a leader, fix standard signals and always follow these signals when operating.
- Learn the prohibitions, cautions and rules about work procedures in the work site.



- Read the Operation and Maintenance Manual carefully. Learn how to use the control devices, gauges and warning devices. Be sure you understand the meaning of the caution plates.




- Confirm that all gauges and warning devices are functioning correctly, and that the gauge readings are within the prescribed range.
- Learn about the safety devices on your own machine and about how to use them.
- Never allow another person to operate the machine.




- If there should be an accident or fire or any other such unexpected mishap, deal with it quickly, using the nearest apparatus.

Learn beforehand the locations of the first aid boxes and fire extinguishers and how to use them. It is also important to know the emergency contact system.



- Fuel or oil are dangerous substances.


Never handle fuel, oil, grease or oily cloth in places where there is any fire or flame.



CHECKING JOBSITE CONDITIONS


- Examine the lay of the land and the kind of soil at the work site to determine the dangerous points and the best method of operation.

Proceed with the work only after making safety arrangements about the dangerous points.




- Do not work when visibility is reduced by smoke, fog or dust. If the jobsite is dark, install lighting if necessary.
- Keep work site flat!


By continually grading the work site, work efficiency will be improved and machines will be able to drive smoothly over the site. If the work site is very sandy or dusty, sprinkle water over the ground before working on the site.




- Check the load limits of bridges before crossing.



- When operating a machine in water or fording streams, survey the water depth, ground condition and velocity of the water in advance. Do not take the machine in water exceeding the allowable depth (up to the underside of the axle housing).




- The overall height of the machine is restricted by tunnels, roof height or overhead electric wires, so check first whether the jobsite is safe. Be particularly careful when working near power lines as electric shock can be caused if the machine touches the electric cables.



BEFORE STARTING OPERATION

CHECK BEFORE STARTING

- Carry out checks before starting the machine. If any problem is found, do not start the engine, but inform the foreman immediately. Always keep the machine in good condition.




SAFETY AND OPERATION

- Before operating the machine, be sure to check the bar and pins for setting in storage position.


The machine can not be steered with frames locked. (In articulate frame model)

- Always stop the engine when adding fuel. After adding fuel, tighten the fuel cap properly.




- Do not leave parts or tools lying around in the vicinity of or on the floor of the operator's compartment. Keep everything in its proper place.

Wipe off thoroughly any grease, oil or mud on the handrail, floor or control levers. Failure to do this may cause you to slip.




- Inspect the inside of the engine room and remove any dead leaves or papers. Dead leaves or papers are highly inflammable and can cause fires.




PRECAUTIONS WHEN GETTING ON THE MACHINE

- If the machine is fitted with a cab, make sure the windows are clean and check the visibility. Always lock the door before starting operations.




- When getting on or off the machine, use the handrail and step provided. Do not jump up onto or down from the machine.
- If a seat belt is provided, always use it. If the belt is damaged or worn, replace it with a new one.




PRECAUTIONS WHEN STARTING THE ENGINE

- Before starting the engine, confirm that all control levers are in neutral position.




- Exhaust gas is dangerous. When working inside, be particularly careful to have good ventilation.
- To ensure the safety of workers near the machine, always sound the horn to warn them before starting the engine and moving the machine. Be particularly careful to check that the rear is clear before backing the machine.



SAFETY AND OPERATION


CHECKS AFTER STARTING THE ENGINE

- Before starting work, test drive the machine in a safe place and check that the transmission, brakes, accelerator, and steering are working properly. At the same time, check that there is not abnormal noise or vibration, or any abnormality in the instruments and gauges.




DURING OPERATION


- Always sit in the operator's seat when operating the machine.
- Do not allow anyone except the operator on the machine.



- Always be aware of the operating capacity of the machine. Using the machine to do work beyond its capacity will not only damage the machine, but may even cause unexpected accidents.




- The machine condition can be judged from many factors. Changes in the gauges, sound vibration, exhaust gas color or response of the control levers can indicate the occurrence of some disorder. If any disorder occurs, park the machine immediately in a safe place and take appropriate action.




ATTENTION TO SURROUNDINGS


- To ensure the safety of workers near the machine, always sound the horn to warn them before starting the engine and moving the machine. Be particularly careful to check that the rear is clear before backing the machine.




- Do not allow unauthorized persons into the work area.
- Always concentrate. It is extremely dangerous to allow yourself to be distracted or to think of other things when operating a machine.




- When loading trucks or hoppers, be careful not to hit the truck or hopper with the bucket. Do not bring the bucket over people's heads or over the cab of the truck.
- In dangerous places or in places where the visibility is poor, get down from the machine and check that it is safe before continuing the operation.




- The machine should always be operated at a speed where it can be correctly controlled. Never do the following:
 - * Speeding
 - * Sudden starting, sudden braking, sudden turning
 - * Snaking
 - * Coasting



- Always operate slowly in crowded places. On haul roads or in narrow places, give way to loaded machines.




- When traveling, keep the work equipment close to the ground to maintain the stability of the machine. Pay particularly careful attention to the stability of the machine when traveling with a load.
- If the machine has to travel on rough ground, be careful to avoid obstacles as far as possible.
- Always travel at a slow speed, and do not suddenly change direction.
- Do not use the bucket as a brake except in emergencies.




- If the engine stops when the machine is traveling, it is impossible to use the steering. This is dangerous, so apply the brake immediately to stop the machine.

- When traveling on hills with a loaded bucket, travel forward up the hill and in reverse down the hill.




RESTRICTIONS CREATED BY JOBSITE

- Do not approach the edge of the cliff or road shoulder.
- In dangerous places, always work in teams of two; one man to operate the machine, and the other to give instructions.
- On windy days, always load downwind.



- When continuing operations after rain, remember that conditions will have changed from those before the rain started, so proceed with caution.

Be careful when working on the place made of piled soil, after earthquakes or after blasting.




SECTION 3


SAFETY AND OPERATION

Page 12


- Always travel directly up or down slopes. When traveling down a slope, use the same gear speed as when going up the slope. When traveling down a slope, never put the transmission in neutral.



- If the engine stops on a slope, apply the brake quickly and carefully. Next, lower the work equipment to the ground and apply the parking brake. Then put the directional and speed control levers in neutral, and start the engine again.
- Be careful when traveling on planks or steel plates, as these can cause slippage.




- When operating at night, remember the following:
 - * Be sure to arrange an adequate lighting system.
 - * At night it is very easy to make mistakes in assuming the distance and height of objects and land.




PARKING


- Before towing operations, always check the wire rope.
- Before starting towing operations, make sure that no one is near the machine. Start the machine slowly to take up the slack in the wire rope. Then start towing carefully. Do not tow any machine whose brakes or steering have broken down.




- When parking the machine, park it in a safe place outside the working area, or in the specified place. The following factors should be considered when choosing a parking place: it should be on flat firm ground where there is no danger of rockfalls, landslides or floods.



- If the machine has to be parked on a slope, it should be parked facing directly up or down the slope, and chocks should be placed under the tires.



- When leaving the machine, always lower the work equipment completely to the ground, and put all control levers in neutral. Next, apply the parking brake and lock all levers. Then put blocks under the tires.
- After stopping the engine, always remove the starting key.




SAFETY AND OPERATION


PRECAUTIONS FOR MAINTENANCE

GENERAL

- Wear well-fitting helmet, safety shoes and working clothes. When drilling, grinding or hammering, always wear protective goggles.




- When working with others, choose a group leader and work according to his instructions. Do not perform any maintenance beyond the agreed work.




- Hang a caution sign in the operator's compartment (for example "do not start" or "Maintenance in progress").


This will prevent anyone from starting or moving the machine by mistake.




- Smoke only in designated places. Never smoke while working.
- Always keep the work shop in good condition. Make sure there is no mud or oil on the floor.
- Keep oily cloths and other combustible things in a safe place away from fire. In addition, learn the location and method of operation of fire extinguishers.



- Always stop the engine before cleaning the machine or adding fuel.




- Flame should never be used instead of lamps. Never use a naked flame to check leaks or the level of oil, fuel, anti-freeze or electrolyte.
- Always use non-inflammable cleaning agents when cleaning parts.




BEFORE MAINTENANCE


- Before starting work, stop the machine on a firm, level surface, and use blocks to keep the machine from moving during operations.
- Lower the bucket to the ground. If this is impossible, use the safety pin and blocks to hold the work equipment securely in position. In addition, apply the locks to all control levers.



- Always lock the front and rear frames before inspecting and servicing the machine.
(In articulate frame model)




- Remove all oil and mud from the machine. In particular, be sure that the steps, hand grips, and the floor of the operator's compartment are clean.
- Always use the standard ROPS equipment. Do not modify the ROPS equipment.




DURING MAINTENANCE


- When getting on or off the machine, use the steps, hand grips and ladders. Never jump on or off the machine. If the steps, hand grips or ladder cannot be used, use a stand to give firm footing.
- If necessary, remove the cables from the battery terminals. When charging the battery, make sure the area is well ventilated.



- Exhaust gas is dangerous. When working inside, be particularly careful to have good ventilation.
- When opening inspection covers, stop the engine. If the hood or other covers are fitted with a lock, always apply the locks securely when opening or closing the hood or cover.
- Always stop the engine before adjusting belt tension or before checking or servicing the water pump.



- Be particularly careful when removing the radiator cap or the hydraulic oil tank filler cap. If this is done immediately after using the machine, there is a danger that boiling water or oil may spurt out.
- Always release the pressure in the circuit before checking or servicing the oil, water or air circuits.
- When the engine stops, the water and oil in the circuit is hot, so be careful not to get burned. Wait for the water and oil to cool before starting any work on the machine.



MISCELLANEOUS

- Thoroughly wash the machine, particularly the oiling and greasing parts and the vicinity, thereof, in order to prevent the ingress of dust.
- Use genuine replacement parts specified in the parts list.
- Use specified oil and grease. Use oil and grease having the recommended viscosity for the particular ambient temperature.
- Use clean oil and grease and keep them in clean containers to avoid the ingress of dust.
- Inspect or replace oil in a dust free location to prevent the ingress of dirt.
- Drain off used oil after heating it to a suitable temperature (about 20 to 40°C).
- When the strainer is located in the oil filter, the strainer must not be removed while adding oil.
- When adding oil or checking the oil level, check that the oil is at the correct level.
- After greasing up, always wipe off the old grease that was forced out.
- When changing the oil or filter, check the drained oil and filter for any signs of excessive metal particles or other foreign materials.
- When removing parts containing O-rings, gaskets or seals, clean the mounting surface and replace with new sealing parts.
- When washing the machine, ensure that water does not get onto the alternator.
- Special measuring apparatus is needed for testing hydraulic pressure.
- Thoroughly wash the machine. In particular, be careful to clean the filler caps, grease fittings and the area around the dipsticks. Be careful not to let any dirt or dust into the system.
- When checking an open cover there is a risk of dropping things in. Before removing the covers to inspect cover, empty everything from your pockets. Be particularly careful to remove wrenches and nuts.
- When working on the sea shore, carefully clean all electrical equipment to ensure that it does not corrode.
- Before working in muddy water, rain or snow, check that the various plugs, valves, are properly screwed up. Upon completion of work, wash the machine, then check the various parts of the machine for cracking, scratching, loose or missing nuts and bolts. Also, oil and grease the various parts of the machine.
- When working on rocky ground, be careful of damage to the undercarriage, loose nuts and bolts, cracks, wear and other damage.
- When working in a dusty location, be careful of the following:
 - 1) Inspect the dust indicator to see whether the air cleaner is blocked up. Clean the air cleaner as soon as it becomes dirty.
 - 2) Clean the radiator core so that it does not become blocked up.
 - 3) Clean or replace the fuel filter as soon as it becomes dirty.
 - 4) Clean the electrical equipment, particularly the starting motor and alternator, to prevent accumulation of dust.



- When installing car radio and a walkie-talkie or citizen band, contact your distributor.
- When washing the machine, take care not to splash water over the electrical equipment. If it is soaked with water, it may not operate normally.
- After disconnecting the connector, cover it with a vinyl bag to prevent oil or dust from sticking to its contact section.
- When welding, be careful of the following:
 - 1) Turn OFF the power (starting switch).
 - 2) Do not continuously apply more than 200 V.
 - 3) Install the ground cable at least 1 m from the range to be welded.
 - 4) Take care not to install the seals between the grounded point and the range to be welded.
- * Use ordinary automobile washer fluid. Be careful not to let dirt or dust get in.

BUCKET OPERATION


Various types of attachments are available to extend the range of application beyond the application described below.

EXCAVATION


- When loading piled soil or blasted rock, drive the machine forward as follows to load. To prevent cutting of the tires caused by the tires slipping, be careful of the following points during the operation.
 - * Always keep the operating jobsite flat, and remove any fallen rocks.
 - * When working with stockpiles, operate the machine in 1st or 2nd, operate the machine in 1st when loading blasted rock.
1. When driving the machine forward and lowering the bucket, stop the bucket about 30 cm from the ground, then lower it slowly.
 - * If the bucket hits the ground, the front tires will come off the ground, and the tires will slip.
 2. Shift down immediately in front of the material to be loaded. When completing the shift down, depress the accelerator pedal at the same time and thrust the bucket into the load.




3. When the material is in a stockpile, keep the cutting edge of the bucket horizontal; when loading blasted rock, have the bucket tilting slightly down.
- * Be careful not to get blasted rock under the bucket. This will make the front tires come off the ground and slip.
 - * Try to keep the load in the center of the bucket; if the load is on one side of the bucket, the load will be unbalanced.



4. At the same time as thrusting the bucket into the material, raise the lift arm to prevent the bucket from going in too far. By raising the lift arm, ample traction will be produced by the front tires.




5. Check that there is enough material loaded into the bucket, then operate the bucket control lever to tilt the bucket and load the bucket fully.
- * If the bucket edge is moved up and down while pushing in the bucket and digging, the front tires will come off the ground and this will cause the tires to slip.



6. If there is too much material loaded in the bucket, dump and tilt the bucket quickly to remove the excessive load.


This prevents spillage of the load during hauling.




- When digging and loading on level ground, set the bucket edge facing down slightly as follows and drive the machine forward. Always be careful not to load the bucket on one side and cause an unbalanced load.

* This operation should be carried out in 1 st gear.

1. Set the edge of the bucket facing slightly down.



2. Drive the machine forward and operate the lift arm control lever forward to cut a thin layer of the surface each time when excavating the soil.



3. Operate the lift arm control lever slightly up and down to reduce the resistance when driving the machine forward.


When digging with the bucket, avoid imposing the digging force onto only one side of the bucket.



WARNING! Never dig or scoop when the machine body is articulated.

Precautions when scooping up material.


When scooping up materials, be careful not to let the counterweight at the rear touch the ground.



- * Do not allow tires slipping to occur during operation. Tires slipping shortens tire's life.

LEVELING

1. Scoop soil into the bucket. Move the machine backward while spreading soil from the bucket little by little.
 2. Go over the spread soil with the bucket teeth touching the ground and level the ground by back-dragging.
 3. Scoop some more soil into the bucket, put the lift arm in float, level the bucket at ground level, and smooth the ground by moving backward.
- * Always move the machine backward during leveling operations.




WARNING! If leveling by forward travel can not be avoided, do not dump the bucket beyond 20°. This will prevent quick wear and damage of the work equipment and frame.

LOAD AND CARRY OPERATIONS

Load and carry operation is a series of processes (scooping-carrying-loading to a hopper or glory hole) carried out by the wheel loader.

- * Always maintain the road in good condition.



WARNING! Lower the bucket to bring down the center of gravity when carrying material.

LOADING

Select and proceed effective operation which avails less turning and the shortest hauling distance according to ground conditions.

CROSS DRIVE LOADING


When a wheel loader is operated, the digging should be made at a right angle toward accumulated soil. When the scooping is completed, the machine should be traveled backwards as it is. Then, bring the truck between the accumulated soil and the wheel loader for the purpose of loading upon the dump truck.



WARNING! Provide a flat road free of rocks and hollows. When the boom is raised with the bucket loaded, do not make quick turns or quick braking because it is very dangerous.




WARNING! Do not load the bucket by thrusting into a pile of soil or gravel at high speed because it is dangerous.



V-SHAPE LOADING

Stop the truck with the angle of about 60° toward the scooping direction of the wheel loader. After scooping the soil, back the wheel loader in such a way that it makes a right angle to the truck. The loading on the truck is made by the wheel loader going forward.

The smaller the turning angle, the higher the efficiency. However, turning of 90° can be made if necessary.




OPERATING THE AIR CONDITIONER

EQUIPMENT ON CONTROL PANEL

It is possible to use the air conditioner to good effect in dusty jobsites. The outside air is passed through the filter and is sent to the operator's cab to increase the pressure inside the cab. In this way, dust is prevented from entering, so comfortable operating conditions are always maintained for the operator.

FAN SWITCH

- This is used for controlling the air flow when cooling or heating.
- * It can control the air flow to three levels:
LO (low), ME (medium) and HI (High)




AIR CONDITIONER SWITCH

- This is the switch for cooling.

ON: Push the button to carry out dehumidification and cooling. The blue lamp lights up to indicate that the cooling system is on.

OFF: If the system is ON and the button is pressed again, the switch returns to its original position and the air conditioner is switched off.

- * Turn the air conditioner switch on after turning the fan switch on.



AIR INTAKE SELECTOR LEVER

- This switches the air intake port when cooling or heating.

FRESH: Operate the lever to the right.

Fresh air is taken in from outside in addition to the air inside the compartment. (This is used for ordinary cooling or heating, and when pressurizing the inside of the cab.)

RECIRC: Operate the lever to the left.

Only the air inside the compartment is used. (This is mainly used for quick cooling or heating.)

TEMPERATURE CONTROL LEVER

- This is used to control the temperature for cooling or heating.
- * The farther the lever is moved to the left, the lower the temperature of the air blown out from the vent.
- * The farther the lever is moved to the right, the higher the temperature of the air blown out from the vent.
- * If the outside air is extremely dusty, set the fan switch to the H position. This will pressurize the cab and prevent the dust from entering.

METHOD OF OPERATION

OPERATION OF CONTROL PANEL

Lever switch		Fan switch	Air conditioner switch	Temperature control lever	Air intake selector lever
Purpose					
Cooling	Quick	HI	ON	Move fully to left	Left
	Normal	HI - LO	ON	From left side to near center	Right
Dehumidifying, heating		HI - LO	ON	From center to near right side	Right
Heating	Quick	HI	OFF	Move fully to near right side	Left
	Normal	HI - LO	OFF	From center to near right side	Right
Defrosting		HI	ON	From center to near right side (move fully to the right when carrying out quick defrosting or demisting.)	Right
Ventilation or pressurizing		HI - LO	OFF	Move fully to left	Right

SELECTING AIR VENT

Vent	FACE	FOOT	OFF
Purpose			
Cooling	Open	Open or closed	Closed
Heating	Open or closed	Open	Open or closed
Defrosting	Closed	Open or closed	Open
Ventilation	Open	Open	Open

- * The effectiveness of the air conditioning system can be increased by selecting the most suitable vent.
- * Do not turn the fan switch on when all the vents are closed.

PRECAUTIONS FOR USING AIR CONDITIONER

- * When cooling, change the air occasionally.
- Smoking in the air-conditioned cab will cause your eyes to get sore. While smoking, open the window to let the smoke out of the cab.
- While using the air conditioner, open the window once every hour.
- * Be careful not to overcool the cab.
- The cab should feel cool when entering there from the out (5°C lower than the outside temperature). It is not good for the health to have the temperature in the cab too low. Always give careful consideration to temperature regulation.

HANDLING THE AIR CONDITIONER IN SEASON

To use the air conditioner comfortably during its season, ask your distributor to check the air conditioner and add the refrigerant if necessary.

- The standard cleaning cycle for the fresh air filter is EVERY 100 HOURS, but if it becomes clogged, it will be impossible to pressurize the inside of the cab, and in addition, it may cause failures, so check and clean the filter immediately.

For details of cleaning, see PERIODIC MAINTENANCE.

- If a large amount of dirt or dust collects on the condenser, the cooling capacity drops, so check and clean when necessary, for details, see WHEN REQUIRED.

HANDLING THE AIR CONDITIONER IN OFF-SEASONS


To lubricate each part of the compressor during the off-seasons, operate the air conditioner for a few minutes two or three times a month.

OPERATING CAB HEATER**EQUIPMENT ON CONTROL PANEL**

It is possible to use the cab heater to good effect in dusty jobsites. The outside air is passed through the filter and is sent to the operator's cab to increase the pressure inside the cab. In this way, dust is prevented from entering, so comfortable operating conditions are always maintained for the operator.

FAN SWITCH

- This controls the air flow when the car heater is used for heating.
- * There are 3 levels:
LO (Low), ME (Medium) and HI (High)

**TEMPERATURE CONTROL LEVER**


- This is used to control the temperature for cooling or heating.
- * The farther the lever is moved to the right, the higher the temperature of the air blown out from the vent.

AIR INTAKE SELECTOR LEVER

- This switches the air intake port when heating.
- * FRESH: Operate the lever to the right.

Fresh air is taken in from outside in addition to the air inside the compartment. (This is used for ordinary heating, and when pressurizing the inside of the cab.)

- * RECIRC: operate the lever to the left.



Only the air inside the compartment is used. (This is mainly used for quick heating.)

SAFETY AND OPERATION

METHOD OF OPERATION OPERATION OF CONTROL PANEL

Lever switch		Fan switch	Temperature controller	Air intake selector lever
Purpose				
Heating	Quick	HI	Move fully to near right	Left
	Normal	HI - LO	From center to near right side	Right
Defrosting		HI	From center to near right side (move fully to the right when carrying out quick defrosting or demisting.)	Right
Ventilation or pressurizing		HI - LO	Move fully to left	Right

SELECTING AIR VENT

Vent	FACE	FOOT	OFF
Purpose			
Heating	Open or closed	Open	Open or closed
Defrosting	Closed	Open or closed	Open
Ventilation	Open	Open	Open

- * If the outside air is extremely dusty, set the fan switch to the H position. This will pressurize the cab and prevent the dust from entering.
- * The effectiveness of the heating system can be increased by selecting the most suitable vent.
- * Do not turn the fan switch on when all the vents are closed.

LOCKING CAP


A locking cap is available as an optional fuel tank cap or hydraulic tank cap. Open and close locking caps as follows:

1. To open the cap

- 1) Insert the key into the cap.

* Insert the key as far as it will go. If the key is turned before it is inserted all the way, it may break.

- 2) Turn the key counterclockwise and bring the rotor groove in line with the aligning mark on the cap. Turn the cap slowly until a "clicking" sound is made. This releases the lock and allows the cap to be opened.




2. To lock the cap

- 1) Turn the cap into place.

- 2) Turn the key clockwise and take the key out.

* When the cap is locked (against vandalism), it rotates freely.



The fuel tank filler port is equipped with a lock.

* Use the starting key to open and close the cap.


Open and close locking cap, as follows:

• To open the cap

1. Insert the key into the cap.

* Insert the key as far as it will go. If the key is turned before it is inserted all the way, it may break.


2. Turn the key clockwise, align the match mark on the cap with the rotor groove, then remove the cap.



• To lock the cap

1. Turn the cap into place.

2. Turn the key counterclockwise and take the key out.



HANDLING OF BATTERY

PRECAUTIONS FOR CHARGING BATTERY

1. Before charging, disconnect the cable from the negative (-) terminal of the battery. Otherwise, an unusually high voltage will damage the alternator.
2. While charging the battery, remove all battery plugs for satisfactory ventilation.
To avoid gas explosions, do not bring fire or sparks near the battery.
3. If the electrolyte temperature exceeds 45°C, stop charging for a while.
4. Turn off the charger as soon as the battery is charged.

Overcharging the battery may cause the following:

- 1) Overheating the battery
 - 2) Decreasing the quantity of electrolyte.
 - 3) Damaging the electrode plate.
5. If the electrolyte gets on your skin or clothes, immediately wash with plenty of clean water.
 6. Do not mix up cables (positive (+) to negative (-) or negative (-) to positive (+)), as it will damage the alternator.
 7. When inspecting or servicing a battery, be sure to stop the engine and turn the starting switch key to "OFF" position.
 8. When performing any service to battery besides checking the electrolyte level or measuring the specific gravity, disconnect cables from the battery.


REMOVAL AND INSTALLATION OF BATTERY

- When removing battery, first disconnect the cable with black tube from the ground (normally, from the negative (-) terminal). If a tool touches a cable connecting the positive terminal and the chassis, there is danger of sparks being emitted.
- When installing battery, the ground cable should be connected to the ground terminal as the last step.
- The batteries are mounted on both side of the machine. The grounding cable is connected to the left side battery.

STARTING ENGINE WITH A BOOSTER CABLE

When starting up the engine with a booster cable, do as follows:

- Before connecting the booster cable
 - Size of booster cable and clip should be suitable for the battery size.
 - Check cables and clips for breaks, corroded surfaces, etc.
 - Make sure cables and clips are firmly secured.
 - Keep the starting switch in "OFF" position.
 - The battery of the running engine must be the same capacity as that of engine to be started.
- Connect the booster cables in the following manner.



- Connect one clip of booster cable A to the positive (+) terminal of the engine to be started.
- Connect the other clip to the positive (+) terminal to the engine which is running.
- Connect one clip of booster cable B to the negative (-) terminal of the engine which is running.
- Connect the other clip to the engine block to be started.

- * Make sure the clips are firmly connected to battery terminals. Then, start the engine.



WARNING! When connecting the cables, never contact the positive (+) and negative (-) terminals.




WARNING! Make sure that the booster cable connections are correct. Connect the booster cable to the engine block as far as possible from the battery.

3. Starting engine

- Turn the starting switch to START position and start up the engine.
- If the engine doesn't start at first, try again after 2 minutes or so.

After the engine has started, the booster cables should be disconnected in the reverse order in which they were connected.



1. Disconnecting the booster cables

- Disconnect the clip of booster cable B from the engine block which was started.
- Disconnect the other clip from the negative (-) terminal of the running engine.
- Disconnect the clip of booster cable A from the positive (+) terminal of the running engine.
- Disconnect the other clip from the positive (+) terminal of the engine which was started.

TRANSPORTATION

When transporting the machine, observe the various road rules, road transportation vehicle limit ordinances, etc. It is a good idea to obtain a special platform for loading and unloading the machine. When it is unavoidably necessary to use a gangplank, however, at the very least observe the following for the sake of safety.

1. Properly apply the brakes on the trailer and insert blocks beneath the tires to ensure that it does not move. The fix the gangplank in line with the centers of the trailer and the machine.
 - * Make sure the gangplank has sufficient width, length and thickness to enable the machine to be safely loaded and unloaded.
If the gangplank sags appreciably, reinforce it with blocks, etc.
2. Determine the direction of the gangplank, then slowly load or unload the machine.
 - * When transmission cut-off switch is put in OFF, the left brake pedal and accelerator pedal are operated at the same time.



WARNING! Remove the mud from the undercarriage to prevent the machine from slipping to the side on slopes.



WARNING! Do not on any account change the direction of the machine while it is on the gangplank. To change the direction of the machine, first take it down from the gangplank.

3. Correctly load the machine onto the specified part of the trailer.
4. Lower the bucket and lock each control lever using safety lock.
5. Lock front frame and rear frame with safety bar.
6. When transporting the machine, place blocks underneath the front and rear wheels to prevent the machine from moving about. Also, hold it down with chains or wire ropes.
 - * Determine the route for transporting the machine by taking into account the width, height and weight of the machine.



WARNING! When loading the machine, park the trailer on a flat, firm roadbed. Keep a fairly long distance between the road shoulder and the machine.

STORAGE

BEFORE STORAGE

To place the machine in storage for an extended period of time, the following measures must be taken to insure that it can be returned to operation with minimum of service.

- After every part is washed and dried, the machine shall be housed in a dry building. Never leave it outdoors.
In case it is indispensable to leave it outdoors, lay wood plates on the ground, and park the machine on the wood plates and cover it with canvas etc.
- Completely fill fuel tank, lubricate and change oil before storage.
- Apply a thin coat of grease to metal surface (hydraulic piston rods and splined shaft).
- As to batteries, remove the terminals and cover them, or remove them from the machine and store separately.
- Set each control lever to neutral or hold position, lock them and apply the parking brake.

DURING STORAGE

- Operate the engine and move the machine for a short distance once a month so the new oil film will be coated over movable parts and component surfaces.
- Before operating the work equipment, wipe off the grease on the hydraulic piston rod.



WARNING! If it is unavoidably necessary to carry out rust-preventive operation while the machine is indoors, open up doors and windows to improve ventilation and prevent the gas poisoning.

AFTER STORAGE

Carry out the following procedure when taking the machine out of long-term storage.

- Wipe off the grease on the hydraulic piston rod.
- Completely fill fuel tank, lubricate and add oil.
- * If the machine is stored without carrying out the monthly rust prevention operation, request your distributor for service.

SAFETY AND OPERATION

SECTION 3

Page 33

COOLANT AND LUBRICANTS

No.	Supplier Name	Engine Oil (CD) (Except engine oil pan) SAE 10W, SAE30, SAE10W/30, SAE15W/40	Grease (Lithium-Base) NLGI-2	Anti-Freeze Coolant (Ethylene Glycol Base) (Permanent Type)
1	AGiP	Diesel Sigma S Superdiesel Multigrade	GR M	-
2	AMOCO	Amoco 300	Super Permalube Grease	-
3	ARCO	Arco Fleet S-3 Plus	Litholine H-EP	-
4	BP	Vanellus C-3	Energrease L2 Energrease LS2	Antifreeze
5	CALTEX	RPM Delo 300 RPM Delo 400	Marfak Multipurpose Marfak All Purpose	AF Engine Coolant
6	CASTROL	RX Super CRD	LM Grease	Antifreeze
7	CHEVRON	Delo 300 Delo 400	Multi-Motive Grease Ultra Duty Grease 2	-
8	ELF	Multiperformance 3C Performance 3C	Multi EPEXA 2	Glacelf
9	EXXON (ESSO)	Essolube D-3 Essolube XD-3 Essolube XD-3 Extra	Multi Purpose Grease Beacon EP2	-
10	GULF	Super Duty	Gulfcrown Grease No. 2 Gulfcrown EP Special Grease No. 2	Cruisemaster Antifreeze and Summer Coolant
11	MOBIL	Delvac 1300 Delvac 1400 Delvac 1400 Super	Mobilgrease MP Mobilgrease 77 Mobilgrease 532 Mobilux EP2	Permazone
12	PENNZOIL	Supreme Duty Fleet Multi-Duty	Multi-Purpose No. 705 Wheel Bearing No. 707L	Anti Freeze & Summer Coolant
13	SHELL	Rimula Rimula X	Alvania Grease EP	-
14	SUN	Sunfleet Dieselube XL Sunfleet Super C	Sunfleet HP Sun Prestige 742 EP	Sunoco Multi-Season Anti-Freeze
15	TEXACO	Ursa Super Plus Ursa Oil LA Ursa Super LA	Marfak All Purpose Marfak Multi Purpose 2	Startex AF & Summer Coolant
16	TOTAL	Rubia S Rubia x	Multis EP2	Antifreeze
17	UNION	Guardol	Unoba EP	-

SECTION 3

Page 34

SAFETY AND OPERATION

MEMORANDA

PROPOSAL FOR MANUAL REVISION

FOR INTERNAL USE ONLY – No. PMR

P R O P O S E R	NAME OF COMPANY:	LOCATION:		
	DEPARTMENT:	PHONE NO:		
	NAME:	DATE:		
	MANUAL NAME:			
MANUAL NO:				
MACHINE MODEL: S/N IF APPLICABLE:				

PAGE NO:

PROBLEM:

Attach photo or sketch.
 If more space is needed, use another sheet.

FOR INTERNAL USE ONLY

CORRECTIVE ACTION:

--	--	--	--
