

# Operation & Maintenance Manual



# PC128UU-1

## HYDRAULIC EXCAVATOR


SERIAL NUMBERS **PC128UU-1 -1001** and up

This material is proprietary to Komatsu Utility Corporation and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu Utility Corporation.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.





**! WARNING**

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who come in contact with it.

**CALIFORNIA**

**Proposition 65 Warning**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

**CALIFORNIA**

**Proposition 65 Warning**

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer, birth defects and reproductive harm. Wash hands after handling.

## EMISSION CONTROL WARRANTY

### EMISSION CONTROL WARRANTY STATEMENT (APPLIES TO CANADA ONLY)

#### 1. Products Warranted

Komatsu America International Company, Komatsu Mining Systems Inc. and Komatsu Utility Corporation (collectively "Komatsu") produce and/or market products under brand names of Komatsu, Dresser, Dressta, Haulpak and Galion. This emissions warranty applies to new engines bearing the Komatsu name installed in these products and used in Canada in machines designed for industrial off-highway use. This warranty applies only to these engines produced on or after January 1, 2000. This warranty will be administered by Komatsu distribution in Canada.

#### 2. Coverage

Komatsu warrants to the ultimate purchaser and each subsequent purchaser that the engine is designed, built and equipped so as to conform, at the time of sale by Komatsu, with all U.S. Federal emission regulations applicable at the time of manufacture and that it is free from defects in workmanship or material which would cause it not to meet these regulations within five years or 3,000 hours of operation, whichever occurs first, as measured from the date of delivery of the engine to the ultimate purchaser.

#### 3. Limitations

Failures, other than those resulting from defects in materials or workmanship, are not covered by this warranty. Komatsu is not responsible for failures or damage resulting from what Komatsu determines to be abuse or neglect, including, but not limited to: operation without adequate coolant or lubricants; over fueling; over speeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications of the engine. Komatsu is also not responsible for failures caused by incorrect fuel or by water, dirt or other contaminants in the fuel. Komatsu is not responsible for non-engine repairs, "downtime" expense, related damage, fines, all business costs or other losses resulting from a warrantable failure.

### **KOMATSU IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

This warranty, together with the express commercial warranties, are the sole warranties of Komatsu. **THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OR OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

## GARANTIE SUR LE CONTRÔLE DES ÉMISSIONS

### ÉNONCÉ DE GARANTIE SUR LE CONTRÔLE DES ÉMISSIONS (APPLICABLE AU CANADA SEULEMENT):

#### 1. Produits garantis:

Komatsu America International Company, Komatsu Mining Systems Inc. et Komatsu Utility Corporation (collectivement Komatsu) produisent et/ou font la mise en marché de produits portant les noms de marque Komatsu, Dresser, Dressta, Haulpak et Galion. Cette garantie sur les émissions s'applique à tous les nouveaux moteurs portant le nom Komatsu, installés dans ces produits et utilisés au Canada dans des machines conçues pour utilisation industrielle non-routière. Cette garantie s'applique seulement sur les moteurs produits à partir du 1er Janvier 2000. Cette garantie sera administrée par la distribution de Komatsu au Canada.

#### 2. Couverture:

Komatsu garantit à l'acheteur ultime et chaque acheteur subséquent que le moteur est conçu, construit et équipé en toute conformité, au moment de la vente par Komatsu, avec toutes les Réglementations fédérales américaines sur les émissions applicables au moment de la fabrication et qu'il est exempt de défauts de construction ou de matériaux qui auraient pour effet de contrevenir à ces réglementations en dedans de 5 ans ou 3000 heures d'opération, mesuré à partir de la date de livraison du moteur au client ultime.

#### 3. Limitations:

Les bris, autres que ceux résultant de défauts de matériaux ou de construction, ne sont pas couverts par cette Garantie. Komatsu n'est pas responsable pour bris ou dommages résultant de ce que Komatsu détermine comme étant de l'abus ou négligence, incluant mais ne se limitant pas à: l'opération sans lubrifiants ou agent refroidissants adéquats; la suralimentation d'essence; la survitesse; le manque d'entretien des systèmes de lubrification, de refroidissement ou d'entrée; de pratiques non-propices d'entreposage, de mise en marche, de réchauffement, de conditionnement ou d'arrêt; les modifications non-autorisées du moteur. De plus, Komatsu n'est pas responsable de bris causés par de l'essence inadéquate ou de l'eau, des saletés ou autres contaminants dans l'essence. Komatsu n'est pas responsable des réparations non-relées au moteur, des dépenses encourues suite aux temps d'arrêts, des dommages relatifs, amendes, et de tout autre coût d'affaires ou autres pertes résultant d'un bris couvert par la garantie.

### **KOMATSU N'EST PAS RESPONSABLE DES INCIDENTS OU DOMMAGES CONSÉQUENTS.**

Cette garantie, ainsi que les garanties expresses commerciales, sont les seules garanties de Komatsu. **IL N'Y A AUCUNE AUTRE GARANTIE, EXPRESSE OU SOUS-ENTENDUE, MARCHANDABLE OU PROPICE A UNE UTILISATION PARTICULIÈRE.**

**INFORMATION IMPORTANTE SUR LE MOTEUR**  
 CE MOTEUR EST CONFORME AUX NORMES AMERICAINES DEL'EPA (ANNÉE DU MODÈLE) ET DE LA CALIFORNIE POUR LES MOTEURS LARGES NON-ROUTIERS A IGNITION PAR COMPRESSION. CE MOTEUR EST CERTIFIÉ POUR OPERATION A ESSENCE DIESEL.

**AVERTISSEMENT**  
 DES BLESSURES PEUVENT RÉSULTER ET LA GARANTIE S'ANNULER SI LES RPM DU TAUX D'ESSENCE OU L'ALTITUDE EXCEDENT LES VALEURS MAXIMALES PUBLIÉES POUR CE MODÈLE ET SON APPLICATION.

**IMPORTANT ENGINE INFORMATION**  
 THIS ENGINE CONFORMS TO YYYY MODEL YEAR U.S. EPA REGULATION AND THE CALIFORNIA REGULATIONS LARGE NON ROAD COMPRESSION IGNITION ENGINES. THIS ENGINE IS CERTIFIED TO OPERATE ON DIESEL FUEL.

**WARNING**  
 INJURY MAY RESULT AND WARRANTY IS VOIDED IF FUEL RATE RPM OR ALTITUDES EXCEED PUBLISHED MAXIMUM VALUES FOR THIS MODEL AND APPLICATION.

ENGINE MODEL	SERIAL NO.	DISPLACEMENT	LITERS
ENGINE FAMILY		FIRING ORDER	1 - 5 - 3 - 6 - 2 - 4
EXHAUST EMISSION CONTROL SYSTEM		Kw ( HP)	RPM
ADV. LOAD OUTPUT		EX. FUEL RATE AT ADV.	mm <sup>3</sup> /STROKE
VALVE LASH COLD (mm)		RPM	mm <sup>3</sup> /BATTEMENT
INITIAL INJECTION TIMING	DEG. BTDC	FAMILY EMISSION LIMIT	TAUX D'ESSENCE À ADV.
		DATE OF MANUFACTURE	LIMITÉ D'ÉMISSION DE LA FAMILLE
		KOMATSU LTD. MADE IN JAPAN	DATE DE FABRICATION

**KOMATSU**

- MODÈLE DU MOTEUR
- FAMILLE DU MOTEUR
- SYSTÈME DE CONTRÔLE DES ÉMISSIONS D'ÉCHAPPEMENT
- CHARGE DE SORTIE ADV.
- PORTÉE DE VALVE À FROID (mm)
- VITESSE STATIQUE
- RÉGLAGE DE L'ALLUMAGE - INJECTION INITIALE
- DEG. BTDC

KOMATSU LITÉE  
 FABRIQUÉ AU JAPON

ENGINE DATA PLATE - ENGLISH / FRENCH

# 1. INTRODUCTION

---

This manual is a guidebook and has been written so that you may use this equipment safely and effectively.

Please read this manual and thoroughly understand it prior to operating, inspecting or servicing this equipment. Not following the contents of this manual may lead to incidents which cause serious injury.

 **Warning!**

- Improper operation and maintenance of this equipment may lead to serious injury or death.
- Operators and maintenance personnel should read this manual thoroughly prior to operating or servicing this equipment.
- This manual should be kept in a place close to the equipment so that it may be referred to easily. All personnel handling this equipment should read it periodically.
- Do not use this equipment until you are thoroughly familiar with the contents of this manual.
- Always have this manual available nearby and read it repeatedly.
- If you lose this manual or if it is soiled or damaged so that it cannot be used, immediately order a replacement manual from Komatsu or your Komatsu dealer.
- If you sell this equipment to some other party, be sure to give this manual to the new owner.
- Komatsu provides machines that comply with all applicable regulations and standards of the countries to which they have been shipped. If the machine that you purchased was purchased in a different country or from a person or company from another country, it may lack certain safety devices and specifications that are necessary for use in your country.. If there are any questions whether your product complies with the standards and regulations which apply in your country, consult Komatsu or your Komatsu dealer.
- Continuing improvements in this equipment can lead to specific changes which may not be reflected in the contents of this manual. Consult Komatsu or your Komatsu dealer for anything which may be unclear.
- Information on safety is explained in Safety Information on page 0-2 and in the items concerning safety throughout the manual from page 1-1.

## 2. SAFETY INFORMATION

---

Most accidents are caused by failing to follow basic safety rules while operating, inspecting or servicing equipment. Please read and take note of all precautions and safety rules written in this manual or on the equipment itself and thoroughly understand them prior to operating, inspecting, or servicing this equipment.

Do not operate, inspect or service this equipment under any circumstances until you understand these precautions.

The following safety warnings are distinguished in this manual and on labels on the equipment to aid in their understanding.

**⚠ DANGER!** This word of warning is used when there is a high probability of serious injury or death if the danger is not avoided. This is used in safety warning messages in the manual and on safety labels on the machine. These warnings usually describe precautions that must be taken to avoid the hazard.

**⚠ WARNING!** This word of warning is used when there is a potentially dangerous situation which could result in serious injury or death if the hazard is not avoided. This is also used in safety warning messages in the manual and on safety labels on the machine. These warnings usually describe precautions that must be taken to avoid the hazard.

**⚠ CAUTION** This is used to indicate a situation where injury or serious damage to the machine could occur if the hazard cannot be avoided.

**NOTICE** This indicates that damage to the machine or shortening the life of the machine could occur if the instruction is not followed.

Safety items are explained from page 1-1.

Komatsu cannot predict every circumstance that might involve a potential hazard in operating, inspecting and servicing this machine. Therefore, the precautions and warnings in this manual and written on the machine may not include all possible safety precautions. If you operate, inspect or service this equipment in a manner not dealt with in this manual you should consider necessary safety considerations to be entirely your own responsibility.

## **3. OVERVIEW OF THE EQUIPMENT**

---

### **3.1 DESIGNATED USES**

This machine is designed to be used for the following work:

- Excavation
- Digging ditches
- Grading
- Loading
- Digging side ditches

Please see section 13.12 under operations entitled "Work Possible using the Hydraulic Shovel" for further details concerning possible operations.

### **3.2 FEATURES OF THIS MACHINE**

- It is equipped with various controls based on advanced electronics systems.
  - Accident prevention device  
It has a device which stops operation and sounds a warning when the bucket approaches the canopy or the cab.  
Please read the precautions in the safety section and use the machine properly.
  - Arm and boom apparatus automatic stop device  
It has an automatic controller which indicates excavating depth, can designate the amount the boom is to be lowered, can designate how much it can be raised and the left offset position.  
Please refer to section 13.19 "Handling 4 systems" for operation.
  - Daily inspection and breakdown diagnosis with the monitor panel.
  - Digging power and lifting power can be varied by a simple command (optional).  
(Please refer to the operations section for details.)
- An air-conditioned cab for comfortable operation.
- Low noise operation and attractive design and coloring make possible operation with minimal disturbance in residential settings
- High operating performance due to powerful engine and high performance hydraulic pumps.



#### 3.3 BREAK-IN

Your Komatsu machine has been thoroughly calibrated and tested prior to shipment. However, if you initially operate the equipment improperly or subject it to undue stress, performance will rapidly decline and this will shorten the life of the machine. Therefore, be sure to break in the machine for the initial 100 hours (as indicated on the service meter). Break in the machine by paying particular attention to the following items.

- Idle the engine for 5 minutes after starting and operate it with a warm engine.
- Avoid operating with heavy loads or at high speeds.
- Avoid abrupt movements, sudden acceleration, unnecessary sudden stops and sudden changes of direction.

The precautions indicated in this manual for operation, maintenance and safety are only for when the equipment is used for the designated purposes. If you operate, inspect or service this equipment in a manner not dealt with in this manual you should consider necessary safety considerations to be entirely your own responsibility.

Nonetheless, operations that are proscribed in this manual should not be performed under any circumstances.

## **4. MEMO**


---



## 5. LOCATION OF SERIAL NUMBER PLATES, AND FORM TO ENTER SERIAL NUMBER AND NAME OF THE DISTRIBUTOR


### 5.1 LOCATION OF SERIAL NUMBER

On the lower right hand side of the cab



### 5.2 LOCATION OF ENGINE SERIAL NUMBER

On the cover of the engine cylinder head



### 5.3 FORM FOR ENTERING THE CYLINDER NUMBER AND THE KOMATSU DISTRIBUTOR

Serial number of machine	
Engine serial number	
Name of Distributor	
Address	Telephone
Name of Person in charge of service	

Remarks

---

---

---

---

## 6. TABLE OF CONTENTS

---

1. Introduction . . . . .	0-1
2. Safety information . . . . .	0-2
3. Overview of the equipment . . . . .	0-3
4. Memo . . . . .	0-5
5. Location of serial number plates, and form to enter serial number and name of the distributor . . . . .	0-7

### Safety

7. Basic Precautions . . . . .	1-2
8. Precautions for operating . . . . .	1-7
8.1 Before starting the engine . . . . .	1-7
8.2 After starting the engine . . . . .	1-9
8.3 Transporting the vehicle . . . . .	1-14
8.4 Battery . . . . .	1-15
8.5 Towing . . . . .	1-16
8.6 Bucket with hook . . . . .	1-17
9. Precautions for maintenance . . . . .	1-20
9.1 Prior to performing maintenance . . . . .	1-20
9.2 During maintenance . . . . .	1-23
10. Where safety labels have been attached . . . . .	1-27
10.1 Where safety labels are located . . . . .	1-27

### Operation

11. The name of each part . . . . .	2-2
11.1 General diagram of the vehicle . . . . .	2-2
11.2 General view of controls and gauges . . . . .	2-3

12. Explanation of each device . . . . .	2-4
12.1 Vehicle monitor panel . . . . .	2-4
12.2 Switches . . . . .	2-11
12.3 Control levers/pedals . . . . .	2-15
12.4 Engine hood . . . . .	2-19
12.5 Front window . . . . .	2-20
12.6 Sliding door . . . . .	2-22
12.7 Fuse box . . . . .	2-23
12.8 Fusible link . . . . .	2-23
12.9 Locking cap and covers . . . . .	2-24
12.10 Tool box . . . . .	2-25
12.11 Grease gun holder . . . . .	2-25
12.12 Controllers . . . . .	2-25
12.13 Ashtray (optional) . . . . .	2-25
12.14 Rear under view mirror (optional) . . . . .	2-25
12.15 Using the car radio . . . . .	2-26
12.16 Using the air conditioner . . . . .	2-31

## 6. TABLE OF CONTENTS

---

13. Operation	
13.1 Checks before starting the engine	2-32
13.2 Starting the engine	2-41
13.3 Checks and tasks to be performed after starting the engine	2-43
13.4 Moving the machine	2-46
13.5 Steering the machine	2-48
13.6 Stopping the machine	2-50
13.7 Swinging	2-51
13.8 Prohibited actions while operating the machine	2-52
13.9 Precautions during operation	2-55
13.10 Precautions when climbing or descending slopes	2-56
13.11 Extricating the machine from mud	2-58
13.12 Operations that can be performed with the hydraulic shovel	2-59
13.13 Changing the bucket	2-61
13.14 Parking the machine	2-62
13.15 Checks after completing operation	2-63
13.16 Stopping the engine	2-63
13.17 Checks after the engine has been stopped	2-64
13.18 Locking	2-64
13.19 Using the 4 systems	2-65
13.20 Using rubber track shoes (for machines specified for use with rubber tracks)	2-76
14. Transporting	
14.1 How to load and unload the vehicle	2-81
14.2 Precautions when carrying things	2-83
14.3 Precautions when transporting	2-84
15. Handling in cold weather	2-85
15.1 Preparation for low temperatures	2-85
15.2 Precautions after completing operations	2-86
15.3 Preparing the car heater	2-87
15.4 After cold weather season is over	2-87
16. Long-term storage	2-88
16.1 Before storing the machine	2-88
16.2 During storage	2-89
16.3 After storage	2-89

17. Troubleshooting	2-90
17.1 Phenomena that are not breakdowns	2-90
17.2 How to tow with the machine or be towed	2-92
17.3 How to use the hook for towing light objects	2-92
17.4 Precautions for special job sites	2-92
17.5 When the battery is dead	2-93
17.6 When this phenomenon occurs	2-97

### Checks and Maintenance

18. Precautions in performing checks and maintenance	3-2
19. Basic maintenance	3-5
19.1 Essential information on oil, fuel and coolant	3-5
19.2 Summary of electrical system	3-9
19.3 Summary of hydraulic system	3-10
20. Consumable Supplies	3-11
21. Usage of fuel and lubricating grease according to ambient temperature	3-12
21.1 Fuel/oil	3-12
21.2 Coolant	3-12
22. Standard tightening torques for bolts and nuts	3-13
22.1 List of tools necessary	3-13
22.2 Torque table	3-13
23. About regular replacement of important components	3-15
24. List of maintenance	3-17
24.1 Maintenance schedule	3-17
24.2 Service time when using the hydraulic breakers	3-19
25. Service procedures	3-20
25.1 Initial service after 250 hours of operation	3-20
25.2 Maintenance that is not regularly scheduled	3-21
25.3 Checks before starting operations	3-45
25.4 Service to be performed after every 50 hours of operation	3-49
25.5 Service to be performed after every 100 hours of operation	3-50
25.6 Service to be performed after every 250 hours of operation	3-53
25.7 Service to be performed after every 500 hours of operation	3-60
25.8 Service to be performed after every 1000 hours of operation	3-65
25.9 Service to be performed after every 2000 hours of operation	3-68
25.10 Service to be performed after every 4000 hours of operation	3-75
26. Inspections required	3-76
26.1 Before beginning work (Checks prior to starting operations)	3-76
26.2 Checks before beginning work (Checks prior to starting operations)	3-76



**Specifications**

27. Specifications . . . . . 4-2

**Optional Parts, Attachments**

28. General precautions . . . . . 5-2

    28.1 Safety precautions . . . . . 5-2

    28.2 Precautions when attachments are installed . . . . . 5-3

29. Using the bucket with hook . . . . . 5-4

    29.1 Checking the bucket with hook attached for damage . . . . . 5-4

    29.2 Operations that should not be performed . . . . . 5-4

    29.3 Precautions during operation . . . . . 5-4

30. Using seat belts . . . . . 5-7

    30.1 Seat belts . . . . . 5-7

31. Information on optional attachments . . . . . 5-9

    31.1 Information on optional attachments . . . . . 5-9

    31.2 Attachment combination table . . . . . 5-10

    31.3 Selecting tracks . . . . . 5-11

    31.4 Using rubber pad tracks . . . . . 5-12

    31.5 Using the automatic leveling device . . . . . 5-13

    31.6 Using the mono-boom . . . . . 5-23

    31.7 Using vehicles to which attachments can be installed (mono-boom) . . . . . 5-25

    31.8 Switching operation patterns  
        (on machines which have a pattern switching valve installed) . . . . . 5-32

# Safety

**⚠ Warning!**

**Read and observe all safety precautions. Failure to do so may lead to accidents resulting in serious injury or loss of life.**

Precautions for optional parts and attachments are included in this section on safety.

## 7. BASIC PRECAUTIONS

**⚠ Warning!** Follow these precautions to ensure safety.

### Strictly observe safety rules in the work place


- Only trained and qualified personnel can operate and maintain this equipment.
- Follow all safety rules, precautions and procedures when operating or performing maintenance on this machine.
- When working with another operator or under the direction of another person, perform the operation with the designated signals.

### Always install safety devices

- Be sure all guards and covers are in the proper position. If damaged, have them repaired immediately.
- Thoroughly understand the operation of all safety devices such as locking levers and seat belts and use them properly.
- Never remove safety devices. Always maintain them so that they function properly.  
**Safety lock lever → See item 13.14 "Parking the machine."**  
**Seat belts → See item 30 "How to use the seat belts"**
- Improper use of safety devices could lead to accidents and result in serious injury.

### Use proper clothing and protective items

- Do not wear loose fitting clothing, items of adornment or other items which can be caught on control levers or in moving parts of the equipment. Do not wear work clothes that are soiled with oil as they are flammable and are easily ignited.
- Always wear a helmet, safety glasses, safety shoes, masks and gloves as required by the operation. Always wear protective items like safety goggles, a helmet and gloves particularly when performing such tasks as pounding in pins with a hammer and cleaning elements with compressed air which are likely to scatter metal fragments or foreign matter. Also make sure that there is no one nearby.  
**Pounding in pins → See item 13.13 "Changing the bucket"**  
**Cleaning elements → See item 25.2 "Unscheduled maintenance"**




Do not modify

- Modifications not recommended by Komatsu may lead to safety problems
- Consult Komatsu or your Komatsu dealer before making any modifications. Komatsu will not be responsible for any breakdowns or incidents resulting in injury caused by unauthorized modifications.

Always lock the machine when standing up from the operator's seat


- Make sure that the safety lock lever is in the locked position when standing up from the operator's seat. If you accidentally touch the lever for moving the machine or rotating the arm and boom apparatus and it is not locked, there may be a sudden movement which may result in serious injury.
- When leaving the machine, make sure that the arm and boom apparatus has been lowered to the ground, place the safety lock in the locked position and secure all locks after stopping the engine. Always take the key with you.

Position of the arm and boom apparatus → See item 13.14 "Parking the machine."




Use the handrail to dismount the machine

- Do not jump on or off the machine. Above all, never mount or dismount the machine when it is moving.
- When mounting or dismounting, face the machine and use the handrails, steps on the track frame and the tracks.
- Do not grasp the operating control levers when mounting or dismounting.
- Always grasp the handrail and use the steps and tracks, maintaining contact in at least three places to make sure the body is securely supported while mounting or dismounting.
- Always maintain the handrails, steps and track shoes in a clean condition and remove any oil or mud that may be soiling them. Repair any damage and tighten any bolts that may have become loose.
- If you grasp the inside of the door when mounting and dismounting or moving on the track, the door will move and you may fall if it is not completely open and locked in that position. Make sure that the door is locked securely in the open position.



AM000030



AM000040

## 7. BASIC PRECAUTIONS

### Keep flames away from fuel and oil

Flames may ignite fuel, oil and anti-freeze if they are in close proximity. Fuel is particularly flammable and hazardous.

- Do not smoke or light matches near flammable materials.
- Refuel after stopping the engine and extinguishing cigarettes.
- Tighten all fuel and oil caps securely.
- Store fuel and oil in well-ventilated areas.
- Fuel and oil should be kept in designated places and unauthorized persons should not be allowed entry.



### Precautions when handling at high temperatures


- Immediately after operation, engine coolant, engine oil and transmission oil are hot and build up pressure. Serious burns may be caused if caps are removed, oil or coolant is drained or filters are changed in this condition. Wait until the temperature has gone down and perform these operations following the prescribed procedures.
- To prevent hot coolant from boiling over
  - 1) Stop the engine
  - 2) Wait until the temperature of the coolant has gone down.
  - 3) Remove the cap after slowly rotating it and releasing the pressure.
- To prevent hot oil from escaping.
  - 1) Stop the engine
  - 2) Wait until the temperature of the oil has gone down.
  - 3) Remove the cap after slowly rotating it and releasing the pressure.



Be careful about asbestos dust

Inhaling air that includes asbestos dust may lead to lung cancer. This machine does not use asbestos but you should follow the precautions noted below if you are handling material that might have asbestos in it.

- Do not use compressed air for cleaning.
- Use water for cleaning so that asbestos dust will not be scattered in the air.
- When operating the machine in a situation when there may be asbestos dust in the air always be upwind.
- Wear a designated respirator when necessary.




Prevent being crushed or cut by the arm and boom apparatus

Do not get between moving parts such as between the arm and boom apparatus and the machine or between the arm and boom apparatus and the cylinders or put your hands, arms or other extremities there. When the arm and boom apparatus is moved clearance will change and this may lead to an accident involving serious injury.



Have a fire extinguisher and first aid kit on hand

- Be prepared for fires by having fire extinguishers on hand. Read the label on them so you will know how to use them.
- Have a first aid kit on hand and decide where to store it.
- Decide what should be done in the event of an accident or a fire.
- Decide who to contact in case of an emergency and copy down the telephone numbers in advance.



## 7. BASIC PRECAUTIONS

### Precautions for optional parts and attachments

- If you are going to use the machine with optional attachments installed please read the operating manual for the attachments and the section concerning attachments in this manual.
- Do not use attachments that have not been authorized by Komatsu or by Komatsu distributors. Use of unauthorized attachments may not only create safety problems but may also adversely affect the proper operation of the machine and the useful life of the machine.
- Komatsu will not be responsible for any injuries, accidents or equipment breakdowns that are caused by the use of unapproved attachments.


## **8. PRECAUTIONS FOR OPERATING!**

### **8.1 BEFORE STARTING THE ENGINE**

#### **Ensure safety of the work site**

- Make sure that there are no hazardous conditions before beginning work.
- Decide on the optimal method for performing the operation after studying the terrain and the soil conditions of the work site.
- Level inclines as much as possible and then proceed with operations.
- When working on roads or highways, ensure the safety of passing vehicles and pedestrians by cordoning off the area to be worked on and utilizing personnel to direct traffic.
- When you will be performing operations where there are likely to be under ground water, gas or high voltage electrical power lines, contact the appropriate utility companies, ascertain the locations and conduct operations so that these underground lines are not damaged.
- If you will be operating in water or will be crossing a stream or shallow body of water ascertain the condition of the ground subsidence, the depth of the water and the speed of the current and do not exceed the permissible water depth.

**Permissible water depth → See item 13.9 Precautions in operating**



AM000050

#### **Prevent fires**

- Flammable material like wood chips, leaves, and paper trash should be kept from accumulating on or near the engine as they can cause a fire.
- Check for leaks in the fuel, lubrication and hydraulic systems and have them repaired. Wipe up oily residues.

**Where to check → See item 13.1.1 Visual checks**

- Make sure of the location of fire extinguishers and how to use them.




#### **Check the operator's cab**

- Do not leave parts and tools lying around in the cab. This will damage control levers and switches and may cause accidents.
  - Wipe up mud, oil and snow from the floor, levers, handrails and steps as they will become slippery if these things are allowed to adhere to them.
  - Put on the seat belts after checking them and the associated hardware for damage or wear.
- Seat belts → See item 30. Using seat belts**




## 8. PRECAUTIONS FOR OPERATING

 **Warning!** Follow these precautions to ensure safety

### Have sufficient ventilation in enclosed areas

Exhaust gas from the engine is dangerous.

- When running the engine in enclosed areas, open window and entrances and improve ventilation.



### Adjust and clean mirrors and window glass so that you can see clearly

- Remove dirt from the surface of window glass and lights so that you can see properly
- Clean the surface and adjust the rear under view mirror (optional) so that the lower portion of the rear of the vehicle may be best seen from the cab. If the glass is broken, replace it.
- Make sure that the head lights and operating lights are installed so that the work planned may be performed. Check to make sure they light up properly.

## 8.2 AFTER STARTING THE ENGINE

### Start engine after signal


- Make sure that there is no one near the vehicle before mounting or dismounting
- Do not start the engine if a warning tag is attached to the controls
- Sound the horn as a warning prior to starting the engine
- Always sit in the operator's seat when starting and operating the machine.
- Do not allow anyone other than the driver to ride in the cab or on the body of the machine.

### Check the direction of the tracks before moving the machine

Check the direction of the track frame before moving the forward/reverse travel control lever to move the machine. When the sprocket is at the front, the forward/reverse travel control levers are reversed.

How to move the machine → See 13.4 Moving the machine


In reverse position



Sprocket

### Make sure that no one is nearby when rotating or traveling in reverse

- Use a signalman in dangerous places or when it is difficult to see
- Do not allow anyone in the swing radius or in the direction of travel
- Before moving, sound the horn and use signals to warn people from coming close to the machine
- Because there are blind spots where you cannot see behind the machine, if necessary, swing the machine to make sure there is no one there before proceeding in reverse.




## 8. PRECAUTIONS FOR OPERATING

 **Warning!** Follow these precautions to ensure safety


### Precautions when moving the machine

- Place the arm and boom apparatus in the position shown in the diagram below and keep it at a height of 40 to 50 cm above the ground when moving.
- If you must operate the control level for the arm and boom apparatus while moving do not make any sudden movements with it.
- When traveling on uneven terrain do so at low speed and avoid sudden changes in course.

#### Position for moving the machine



AM000070




AM000080

### How to travel on slopes and inclines


- Be careful of slipping sideways and tipping over when traveling on a slope
  - When traveling on an incline, carry the bucket closer to the ground at approximately 20 to 30 cm. Carry the bucket so that you may drop it and stop the vehicle quickly in an emergency.
  - Do not change direction or travel across slopes. Move the machine safely by returning to a level area and then taking a roundabout way.
- How to travel on slopes → See 13.10 Precautions when climbing and descending slopes**
- Wet steel tracks will slip sideways surprisingly easily on grass and leaves so keep the body of the machine as much as possible so that it is not sideways and travel at moderate speeds.

#### Ascending slope




AM000090

#### Descending slope




AM000100




**Do not perform dangerous operations**

- Do not excavate under an overhang as it is dangerous and dirt and sand will come down on the machine.
- Do not excavate directly up to base of the machine. The ground will be unstable and the machine might fall.



AM000110




AM000120

**Do not get close to high voltage power lines**

- Coming close to high voltage power lines may result in electric shock. Maintain the safe distances from power lines noted below.
- The following are effective in preventing accidents
  - 1) Wear shoes with leather or rubber soles.
  - 2) Use a signalman to warn you when you have come too close to a power line.
- If the arm and boom apparatus should, in some eventuality, come in contact with power lines, the operator should not leave the cab.
- Do not let anyone come close to the machine when operating near high voltage power lines.
- Check with the power company about the voltage of the lines at the work site.

Voltage of power lines	Minimum safe distance
6.6kV	3 m
33.0kV	4 m
66.0kV	5 m
154.0kV	8 m
275.0kV	10 m



AM000130

## 8. PRECAUTIONS FOR OPERATING



Warning! Follow these precautions to ensure safety

### Operate so that you do not hit the boom

- Be sufficiently careful to avoid hitting the boom or arm on anything when operating in places with restricted space like tunnels, on bridges or under power lines.

### Ensure good visibility

- When operating in dark places turn on the operating light and head lights and if necessary provide additional lighting.
- When visibility is poor due to fog, snow or rain postpone operations and wait until visibility improves so that there is nothing obstructing the operation.

### Be careful operating on packed snow


- The machine will slip sideways very easily on snow or icy road surfaces so travel at low speeds and avoid sudden starts, stops and sudden swings of the boom.
- Proceed carefully when clearing snow because there are objects buried in the snow which cannot be seen.

### You are likely to fall over if the machine is working on unstable ground

- As much as possible, avoid coming near cliffs, road shoulders and deep ditches as the ground near them is unstable. If the ground collapses from the weight and vibration of the machine it might tip over or fall. Be particular careful because the ground is unstable after rain or blasting.
- Areas where there is dirt piled on the ground and areas near ditches which have been excavated are unstable and may collapse from the weight and vibration of the machine so that it tips.
- When working in areas where there is likely to be falling rock and dirt, wear a head guard.

**Working on slopes**

- When working on slopes there is the danger of losing the balance of the machine when operating the arm and boom apparatus or rotating it so that the machine tips over. Be very careful when performing these operations.
- Do not swing the arm and boom apparatus to the downhill side of the machine when the bucket is filled. This can be dangerous. (See the diagram at the right.)
- If the machine must be used on a slope, build a mound of soil so that the machine may be kept in a horizontal position as much as possible.



**Mounding on a slope → See item 13.10 Precautions when climbing and descending slopes**


**Parking the machine**

- Park the machine on a level road surface when possible. When you must park the machine on a slope, block the tracks and imbed the teeth of the bucket in the ground so the vehicle will not move. (See diagram at right.)
- When parking the vehicle on public roads, use flags, barriers and lights or other marker devices that do not interfere with traffic so that other vehicles will know that it is there and can avoid it.
- When leaving the machine, make sure that the arm and boom apparatus has been lowered to the ground, engage the safety lock in the locked position, and lock everything up after stopping the engine. Always take the keys with you.

**Parking procedure → See item 13.14 Parking the machine**

**Position of arm and boom → See item 13.14 Parking the machine**


**What to lock → See item 13.18 Locking**



### 8.3 TRANSPORT THE VEHICLE

#### Precautions when loading and unloading the vehicle

- Loading and unloading the machine for transport is especially hazardous. Be especially cautious.
- When loading and unloading, the engine should be idling slowly and should be run in low gear.
- Select a firm, level place for loading and make sure that it is a sufficient distance from the shoulder of the road.
- Use ramps that are of adequate strength and make sure that they are sufficiently wide, long and thick for safe loading and unloading. If the ramps are likely to bend significantly, reinforce them with blocks.
- Remove oil residues and foreign matter that may be stuck to the ramps so that the machine will not slide. Remove mud from around the tracks.
- Never correct the position of the tracks on the ramp while on the ramp. If you need to correct the position of the tracks, back off of the ramp, correct the position of the tracks and the remount the ramp.
- If you are going to swing the arm and boom apparatus on the trailer, do so with caution as the machine's footing is unstable.
- After the machine has been loaded, secure the vehicle with wedges and wire rope.  
How to load and unload → See item 14. Transporting  
How to secure → See item 14. Transporting




#### Precautions when transporting

- Transport the vehicle safely in accordance with all pertinent regulations.
- Consider the maximum width, height and weight of the machine when it is loaded on the trailer when deciding on a route to transport the vehicle.

## 8.4 BATTERY

### Take care when handling the battery


- Battery electrolyte contains sulfuric acid and can burn the skin and ruin clothing. If you spill acid on yourself, immediately flush the area with water.
- If you get battery fluid in your eyes, flush them immediately with water and see a physician as soon as possible.
- If you accidentally drink battery fluid, drink a large quantity of water, milk, or vegetable oil or eat raw eggs. See a doctor as soon as possible.
- Always wear safety glasses when handling batteries.
- Because batteries emit hydrogen gas there is the danger that an explosion might occur. Do not light cigarettes around batteries or do anything that would cause sparks.
- Check and service batteries after stopping the engine and turning the ignition switch to the OFF position.
- Be careful not to short circuit the poles of a battery by contacting them both with a metallic object like a tool.
- There is a danger of explosion from sparks caused by poor contacts when terminals are loose. When installing terminals, install them securely.
- Make sure you know which is the positive and which is the negative terminal when installing and removing terminals.
- Tighten battery caps securely.



### Follow the proper procedure when using booster cables to start

- Wear safety glasses when using booster cables to start the engine.
- When using another vehicle to start the engine make sure that the other vehicle does not touch your vehicle.
- When attaching the cables, attach the cable to the plus terminal first and conversely when removing the cables, remove the grounded cable (normally the negative terminal) first.
- Be careful so that there is no tool contacting both the positive terminal and the body of the vehicle as this will cause a spark and is dangerous.
- Do not make mistakes in connecting the booster cables. Never, ever connect a positive terminal with a negative terminal.
- The final connection is to the upper rotating frame. Make sure that this is as far from the battery as possible as this will cause a spark.

Procedure for starting with booster cables → See item 17.5 When the battery is dead






### 8.5 TOWING


**Attach wire to frame when towing**

- Improper towing can result in injury
- Use a wire rope of sufficient strength relative to the weight of your machine or if you use another vehicle to tow your machine.
- Never tow on a slope.
- Do not use a wire rope with kinks or twists in it or one which is damaged.
- Do not straddle the cable or wire rope used in towing.
- Do not allow anyone in between the towing vehicle and the machine to be towed when they are being connected or are connected.
- Keep the towing connection on the machine and the connected part of the towing vehicle in a straight line.
- Place wooden bumpers between the wire rope and the body to prevent damage to either the wire rope or the body.
- Do not use the hook for towing light weight objects to tow the vehicle.

**How to tow the machine → See item 17.2 How to tow the vehicle**



AM000170




AM000180

## 8.6 BUCKET WITH HOOK

### 8.6.1 General precautions

#### Special hook

- A special hoisting hook is necessary for performing hoisting operations.
- The following operations should never be done.
  - Loads should never be lifted suspended by wire rope hooked onto the teeth of the bucket.
  - Loads should never be lifted when wire rope is wrapped around the boom or arm.



#### Checking the hook

- Make sure there is nothing wrong with the hook by performing the following inspection prior to hoisting operations.
  - Make sure there are no cracks or irregularities in the hoisting hardware
  - Check to see whether there are any abnormalities in the lifting hardware at the time of periodic inspections (semi-annually or monthly) and make a record of this.

#### Make sure that the wire rope is securely attached to the hook

- Make sure that the wire rope is securely attached to the hook when performing hoisting operations.

#### Be careful when selecting a place to perform the operation

- Select a firm, level place and make certain in advance that the ground and the soil qualities of that place are such that the machine will not tip over or fall. Make sure that the surroundings are safe.

#### Do not do anything other than the task to be performed

- Never raise or lower people in hoisting operations.

#### Do not allow anyone in the working area

- Do not allow anyone in the working area during hoisting operations as there is the danger that the load may fall or they may be hit by the load.

## 8. PRECAUTIONS FOR OPERATING



Warning! Follow these precautions to ensure safety

### Designate a supervisor for the operation

- Designate a supervisor for hoisting operations and always execute the operations according to his instructions.
  - The method and procedures of the operation will follow his direction.
  - Designate a supervisor for signaling and follow those signals.

### Handling wire ropes etc.

- Use leather gloves when handling wire rope.
- When using wire rope for use in slinging work, handle it in accordance with the Labor safety and health regulations

### 8.6.2 Precautions for hoisting operations

#### Perform hoisting operations slowly


- Perform hoisting operations slowly with the engine running at low RPM
- Avoid sudden movements of the control levers and sudden acceleration.
- Rotation speed is 3 or 4 times that of mobile cranes. Exercise special caution when rotating.

#### Do not leave the operator's seat


- Do not leave the operator's seat when a load has been lifted and is suspended in the air.

#### Do not perform unreasonable operations

- Operations that exceed the capabilities of the machine may cause accidents or breakdowns.
- Perform hoisting operations within the specified load limits
- Do not perform operations which might damage the equipment such as hoisting loads exceeding the specified load limits or shock load.
- Do not move a load laterally or longitudinally or pull the arm in as these movements are dangerous.



AM000190



AM000200

#### Do not move the machine while hoisting loads

- Do not move the machine while performing hoisting operations.

#### Be careful of position for hoisting operations

- There is the danger that the wire rope or hoisting ring may come off the hook if the bucket is not in the proper position. Be careful and make sure the bucket is in the proper position so that the hook is at the proper angle and wire rope and rings will not come off.

## **9. PRECAUTIONS FOR MAINTENANCE**



### **9.1 PRIOR TO PERFORMING MAINTENANCE**

#### **Display warning tag when inspecting or servicing**

If someone other than the person performing checks and maintenance on the machine unexpectedly starts the engine or touches the control levers, this may lead to serious injury or death.

Attach a warning tag to the control lever for the boom and arm which says "Do not operate."  
Attach additional tags around the vehicle if necessary.

Warning tag part number 009963-03000



#### **Use proper tools**

It is very dangerous to use damaged or inferior tools or to use tools for purposes other than for which they were intended. Use only tools suited to the maintenance task.

Types of Tools → See 22.1 Necessary tools





#### **Regular replacement of parts important for safety**

- Replace the following fire-related parts at regular intervals  
Fuel system: Fuel hose, fuel overflow hose, and fuel line cap.  
Hydraulic system: Pump outlet hose, and front and rear branch hoses
- Replace these parts with new ones at regular intervals even though there may be nothing wrong with them. They deteriorate over time.
- Replace or repair parts that are defective or are causing problems even though they have not been installed for the specified period.

Replacement of parts important for safety → See item 23 Regular replacement of important parts


Stop the engine before performing inspections and maintenance


- Always stop the machine before performing inspections and maintenance.
- Always use two people for maintenance operations that require the engine to be running such as flushing the radiator and secure the safety lock lever in the locked position. One should be in the operator's seat so that he can stop the engine at any time. He should be extremely careful not to touch any levers other than those necessary for the operation.
- Persons performing service should be careful so that they do not or their clothing does not touch any moving parts.



Items to be strictly observed when refueling or adding oil

- Spilled fuel and oil is dangerous as it may cause personnel to slip. Wipe it up immediately.
- Tighten the fuel and oil caps securely.
- Do not use fuel for cleaning parts.
- Refuel and replace oil in a well ventilated place.




 Warning! Failure to follow these safety precautions may lead to an accident

## 9. PRECAUTIONS FOR MAINTENANCE


### Radiator coolant level

- If you need to add coolant to the radiator, do so after stopping the engine and waiting for it to cool down.
- Slowly loosen the cap before removing to allow pressure to escape.



### Lighting for the service operations

Use explosion proof lighting for checking fuel, oil, coolant and battery fluid levels. If you fail to do so the material may be ignited and there will be the danger of explosion.



## 9.2 DURING MAINTENANCE

Do not allow other persons in the work area other than those involved in the maintenance operation

Persons other than necessary, authorized personnel should not be allowed in the work area. Be careful of persons in the surrounding area. Extra caution should be exercised when performing grinding, and welding operations or when using a sledge hammer.

Attachments that have been removed

When removing attachments or reinstalling them make sure that they are placed in a stable position so that they do not fall over.




Working under the machine

- Before working under the machine, always lower the boom and arm to the ground or to the lowest position.
- Always secure the tracks of the vehicle with blocks so they cannot move.
- Never work under the machine if the machine is not properly supported.



Always keep the machine clean

- Oil that has spilled, excess grease and scattered metal fragments are dangerous.
- Always keep the machine clean.
- Allowing water to get into electrical system is dangerous and may cause improper and faulty operation.
- Do not use water or steam to clean sensors, connectors or the inside of the cab.





## 9. PRECAUTIONS FOR MAINTENANCE

### Precautions with battery

Remove the connection to the negative terminal to stop the flow of electrical current if you are going to repair the electrical system or do electric welding.




### Handling high pressure hoses

- Do not bend or clamp hard objects on high pressure hoses. Do not use piping, tubes or hoses with bends or cracks as they may rupture.
- Always repair fuel hoses and hydraulic hoses that have breaks or have soft spots.

### Be careful of hydraulic fluid under high pressure

- Always remember that hydraulic lines for the boom and arm are under pressure.
- Do not add fluid, drain fluid, check or engage in repair operations until the pressure gauge reads zero.
- Leaks of hydraulic fluid under pressure from small holes can be dangerous if it gets on the skin or in the eyes. Wear safety glasses and thick gloves, and use a piece of card board or a sheet of plywood to test the leak that you wish to check.
- If you are hit by a jet of hydraulic fluid under pressure see a doctor immediately.



**Be careful when performing maintenance when the engine is hot or there is high pressure**

Engine coolant, engine oil, transmission fluid, and hydraulic fluid are hot and under pressure immediately after turning off the machine. Serious burns may be caused if caps are removed, oil or coolant is drained or filters are changed in this condition. Wait until the temperature has gone down and perform these operations following the prescribed procedures.


- |  |   |
|--|---|
| Cleaning the cooling system                                  | → See item 25.2 Non-scheduled maintenance             |
| Checking the levels of the coolant and hydraulic fluid tanks | → See item 25.3 Checks before starting operations     |
| Checking lubricating oil, adding oil                         | → See items 25.3-25.9 Regularly scheduled maintenance |
| Changing oil and filters                                     | → See items 25.3-25.9 Regularly scheduled maintenance |

**Be careful of high pressure grease when adjusting track tension**

Grease is pumped into the track tension adjustment system at high pressure. If the tracks are adjusted in a manner other than by the prescribed maintenance procedure the plugs and grease fittings may fly out and cause injury to personnel.


- When loosening plugs for allowing grease to escape, do not loosen them more than one turn
- Do not put your face, hands, feet or other part of your body directly in front of any grease drain plug or valve.


Adjusting track tension → See item 25.2 Unscheduled maintenance



**Rotating fans and belts**

- Do not let anything that might easily get caught in the fan get close to where it is rotating.
- Never, ever, touch the fan blade or the fan belts as tools and body parts may be cut off if allowed to contact these things.




 Warning! Failure to follow these safety precautions may lead to an accident

## 9. PRECAUTIONS FOR MAINTENANCE

### Waste materials


- Do not discard waste oil in sewer systems or in a river.
- Always put used oil drained from the machine in a container. Never allow oil to drain directly on the ground
- Follow applicable laws and regulations when disposing of hazardous materials such as oil, fuel, coolant, solvents, filters and batteries.



## 10. WHERE SAFETY LABELS HAVE BEEN ATTACHED


Always keep these labels clean. If they are lost re-attach them or replace them with new ones. As shown below, there are other labels other than the safety labels and they should be handled in the same way.

### 10.1 WHERE SAFETY LABELS ARE LOCATED




## 10. WHERE SAFETY LABELS HAVE BEEN ATTACHED


### 1. Warning to operator when leaving the cab.

 **WARNING!**

To prevent accidents resulting from unlocked control levers being inadvertently moved, lower the bucket and boom to the ground and place the safety lock lever (on the left side of the cab) to the locked position **BEFORE GETTING UP FROM THE OPERATOR'S SEAT**. Serious injury or death may result if the machine suddenly moves or moves in a way not desired by the operator.

### 2. Warning before operating the machine

 **WARNING!**



Always do the following before moving the machine or the boom and bucket to prevent serious injury or death.

- Sound the horn to alert people nearby.
- Make sure that there is no one on the machine, near it or within the swing radius of the bucket and boom.
- If it is necessary in order to maintain visibility of the direction of travel, rotate the upper frame.
- Use a spotter if visibility is poor.

Always observe the above precautions even though you may have an alarm indicating movement of the machine and mirrors.

### 3. Handling preventive devices


#### Handling preventive devices

**Check prior to operating**

Perform the following check prior to operating to ensure proper operation of preventive devices

1. Make sure of the following when starting the engine


	Caution light*	Buzzer
When turning key to ON	Lights for 3 seconds	Sounds for 1 second
When starting engine	Light goes out	Does not sound




2. Open left console box and make sure that the boom and bucket cannot be moved.

3. Check to make sure that the boom, arm and offset operated independently automatically stop operating when you bring the bucket near the cab (canopy) as they should.


Boom operated independently  
Front of cab



Arm operated independently  
Front of cab



Offset operated independently  
Side of cab



4. In cold weather always perform the following before operating


1. Warm up the engine for 5 minutes (moderate rpm)
2. In order to warm up the hydraulic fluid for another 5 minutes move the bucket back and forth in place.

**Precautions while operating**

1. If the electrical system caution light comes on or if the buzzer sounds or you cannot get the machine to work, immediately cease operations and check the machine. If you need to temporarily move the machine to a safer place, do so by turning the override switch on and then moving the machine. (However, do not use the override switch other than in an emergency)


2. Be careful not to smash or hit the sensors on the boom and arm. Preventive devices will not operate properly if you do.

3. If you change the boom and arm to a slide arm/ long arm specified by Komatsu always have this done by a Komatsu service facility. If you install attachments other than those specified by Komatsu, the preventive devices and the automatic control devices on the boom and arm will not work properly so be careful.



Emergency position  
Normal position  
Location of switch


### 4. Warning when opening front window

 **WARNING!**

When opening the front window, be sure to lock the pins on both sides of the window.


Injury may occur if the window slips and falls out.


5. Precaution when adjusting track tension

 **WARNING!**

Track adjustment cylinders are under high pressure and are dangerous.  
Do not loosen the plug more than one turn when adjusting track tension.  
Turning further could cause injury from the plug and grease flying out.  
Refer to the manual for the proper adjustment procedure.

7. Precautions for high voltage

 **DANGER!**




Be careful of high voltage

- Serious fatal accidents may occur if the machine or its attachments get too close to power lines

Line voltage	Safe distance
6.6 kv	at least 3 meters
66.0 kv	at least 5 meters
275.0 kv	at least 10 meters


6. Precaution when window comes out or is damaged

 **WARNING!**

To prevent danger to the operator, do not operate the machine if the window comes out or is broken. Repair it immediately.

10. WHERE SAFETY LABELS HAVE BEEN ATTACHED

8. Precautions for operation, checks and maintenance


 **WARNING!**

Improper operation and maintenance may cause serious injury or fatal accidents.

Read the manual and stickers before operating or performing checks and maintenance and follow these instructions and warnings.

Keep the manual in the cab of the machine for quick reference, and if you need a new manual, contact your Komatsu dealer.


9. Precautions about hot coolant

 **WARNING!**

Be careful of hot coolant  
To prevent hot coolant from spurting out:

- Turn off engine
- Allow coolant to cool down
- Slowly loosen the cap and allow pressure to escape before removing it.

10. Precautions about opening and closing the hood

 **CAUTION**

Observe the following precautions when the engine is running.


1. Do not open the cover
2. Do not get near the fan or fan belt


11. Keeping out of the swing area

**KEEP OUT OF SWING AREA**

12. Precautions about hot oil

**HYDRAULIC FLUID**



 **WARNING!**

Be careful of hot oil  
To prevent hot oil from spurting out:

- Turn off engine
- Allow oil to cool down
- Slowly loosen the cap and allow pressure to escape before removing it.


# **OPERATION**




# 11. THE NAME OF EACH PART

## 11.1 GENERAL DIAGRAM OF THE VEHICLE

Arrows indicate direction in this manual.



11.2 GENERAL VIEW OF CONTROLS AND GAUGES




## 12. EXPLANATION OF EACH DEVICE

Each device necessary for operation is explained.

The most important thing for proper, safe and smooth operation is to properly understand the ways to operate these devices and to understand what the gauges mean.

### 12.1 VEHICLE MONITOR PANEL



The monitor panel shows the basic items that must be checked before starting the engine.

Lights will come on for anything that is abnormal on the monitor panel.

The light will go out when the engine is started even if there is something abnormal.

#### A. Emergency stop items (12.1.1)

When the engine is running and there is something abnormal the item that needs to be taken care of will be indicated.

The monitor light will flash and a buzzer will sound when something is abnormal.

**⚠ Caution!**

Immediately cease operations and check and repair the problem when these monitors flash.

**B. Gauges (12.1.2)**

Indicates the amount of coolant and fuel remaining in the engine.

**C. 4 systems (12.1.3)**

Indicates and sets the preventive devices for the bucket cab and canopy and the automatic control devices for the arm and boom apparatus.

**D. Indicator lamps (12.1.4)**

Indicates preheat condition

**E. Basic check items (12.1.5) (Optional)**

Of the items that should be checked prior to starting the engine, displays the oil level.

If there is an abnormality the monitor for that item will light up.


When the engine is started the light will go out even though there is an abnormality.

**Additional explanation**

The engine oil level indicator is an optional item so that on those vehicles that do not have this optional item installed there will be no indication even when the level is low.

Check the oil level before starting the engine.

## 12. EXPLANATION OF EACH DEVICE




### 12.1.1 A Emergency stop items



Caution!

If the monitor is flashing, stop the engine immediately and do the following.



#### 1. Engine oil pressure

When the engine lubricating oil pressure goes below normal, this indicator will light up and a buzzer will sound. If it lights up, stop the engine and check in accordance with item 17.6., "When this phenomenon occurs"

#### Additional explanation


When the ignition switch is in the ON position when the engine is not running, the indicator will light up but there is nothing wrong.

## 2. Battery charge

If the battery is not charging properly while the engine is running the indicator will light up and a buzzer will sound. If the indicator light comes on, stop the engine, check the tension of the V belt and if it is abnormal, refer to item 17.6 "When this phenomenon occurs."

### Additional explanation


When the ignition switch is in the ON position when the engine is not running, the indicator will light up but there is nothing wrong.



## 12.1.2 B Gauges

### 1. Engine coolant temperature gauge


This gauge indicates the temperature of engine coolant. If the temperature is normal while the engine is running the green light will come on. When it reaches the highest level the light will flash and a buzzer will sound. If the red light comes on or flashes, run the engine at a low idle and wait for the temperature to go down to the green range. After starting the engine, warm up the engine until the gauge is in the green range.



### 2. Fuel gauge

This gauge indicates the amount of fuel in the fuel tank. If the fuel level is normal while the engine is running, the light will come on in the green range. The light will flash only when it is in the red range. If the light flashes in the red range while the engine is running, this indicates that there is less than 33 ℓ of fuel remaining and that you should check and refuel the tank.

After turning the ignition switch to the ON position, the gauge will not show the correct amount for a short period but this does not indicate that there is anything wrong.



## 12. EXPLANATION OF EACH DEVICE

### 3. Service Meter


This gauge indicates the amount of time the vehicle has been run.

Set the interval for regular maintenance with the display.

The service meter will advance even if the machine does not move if the engine is running.

When the engine is running the indicator (1) above the meter will come on and this indicates that the meter is running.

Regardless of the speed the engine is running when the engine is run for 1 hour the meter will advance 1 numeral.




### 12.1.3 C 4 systems

#### 1. Electrical system


If there is anything abnormal in the 4 systems (Preventative systems and automatic control device for the boom and arm) the gauge will light up or flash and a buzzer will sound. Stop the engine. The cause of the abnormality will be indicated in the depth display section as an error code so check in accordance with section "17.6 When this happens."

When the ignition switch is ON and the engine is being started or stopped, the light will come on for a second and the buzzer will sound but this does not indicate that there is anything abnormal.




#### 2. Mode selection switch

This is a switch that enable you to select one of the following modes: Depth display 0 set mode, depth mode, height mode, offset mode.



#### 3. Set switch

This is a switch that sets or clears the mode selected by the mode selection switch.




**4. Depth display mode**

This indicates the depth of the bucket from the surface of the ground.

"UP" is always displayed when the bucket is above ground.


It also indicates the depth from a standard plane when a standard plane height has been set below the surface of the ground (when in depth display 0 set mode).

When there is something wrong in the 4 systems the numeral in the second column will indicate the location of the problem.




**5. Depth mode indicator**

This gauge will be lit when how much the boom is to be lowered is set. This will come on when the mode selection switch is set to "depth" and indicates that the amount that the boom is to be lowered is set.




**6. Height mode indicator**

This gauge is lit when the height the boom is to be raised is set. This indicator will come on when the mode selection switch is set to "height" and indicates that the height the boom is to be raised is set.



**7. Offset mode indicator**

This gauge is lit when the amount offset to the left is set.






## 12. EXPLANATION OF EACH DEVICE

### 8. Override/ Clear switch

**Warning!**

Do not operate the machine when the override/clear switch is ON. Because the 4 systems do not work and the arm and boom apparatus will not stop automatically there is danger that it will hit the body.



Use this switch to move the boom and arm apparatus when there is a problem with the 4 systems and the boom and arm apparatus has stopped.

- (1) ON: Clear/ Override automatic stop
- (2) OFF: Normal operation


When the switch is in the ON position, removing your hand from it will automatically return it to the OFF position.

### 12.1.4 D Display lights

#### 1. Preheat monitor

This will indicate the preheating time required when endeavoring to start the engine when ambient temperature is below 0°C.


This light will come on when the preheat switch is placed in the HEAT position and after approximately 18 seconds will go out indicating that preheating has been completed.



### 12.1.5 E Basic check items (optional)

#### 1. Engine oil amount


This light will come on when there is insufficient oil in the engine oil pan. Check the amount of oil in the engine oil pan and add when necessary.



#### Additional explanation

The vehicle has an oil volume display but if there is a problem in those vehicles without this optional part, the monitor light will not come on because this is an option.

12.2 SWITCHES



1. Ignition switch

Used to start and stop the engine.

OFF position


The ignition key may be inserted or removed in this position, the electrical systems switch is turned off and the engine is off or will stop running when placed in this position.

ON position

Current will flow to the charging system and light system. Keep the switch in this position when the engine is running.

START position

This is the position that starts the engine. Place the switch in this position while the engine is cranking and release the switch as soon as the engine starts. It will automatically return to the ON position.



## 12. EXPLANATION OF EACH DEVICE

---

### HEAT position

Place the switch in this position when starting the engine in cold weather.


When the switch is placed in the HEAT position, the preheat monitor light will come on. Maintain the switch in this position until the preheat monitor light goes out. As soon as the preheat monitor light goes out release your grip on the key. When you release the key the switch will return to the OFF position so move the switch to the START position and start the engine.

### 2. Swing lock brake release switch

Use this switch to release the parking brake if it is set for the swing mechanism.


OFF position: Release

ON position: Automatic



### 3. Horn switch

The horn will sound if you press the center of the knob of the right control lever for the arm and boom apparatus.




### 4. Light switch

This turns on the head lights and the lights on the instrument panel.

Position 1: Instrument panel lights go on.

Position 2: Instrument panel lights and head lights go on.

OFF position: Lights are off.




### 5. Cab heater switch

Use this switch to turn on and regulate the heating in the cab.  
The switch can be set to two fan positions.

HI position: High fan volume

LO position: Low fan volume

This heater works off of the engine coolant so that it can be used after the engine coolant has warmed up.




### 6. Windshield wiper switch

This switch is used to operate the windshield wipers

ON position: Windshield wipers are on

OFF position: Windshield wipers are off



#### Additional explanation

When the optional window washer device is installed, washer fluid will be sprayed on the windshield if the windshield wiper switch is pressed beyond the ON position. Observe the following precautions when using this device.


- Do not press the switch continuously for more than 10 seconds.
- Do not press the switch to the wash position when the washer fluid tank is empty.

### 7. Interior light switch

The lights in the cab will come on when activated.

When ON: Lights will come on.

Do not forget to turn off the switch since the lights will remain on even when the ignition key is in the OFF position.




## 12. EXPLANATION OF EACH DEVICE

---

### 8. Knob switch (optional)

The knob switch on the left control lever for the boom and arm apparatus is used for instantly increasing power for excavating operations.

Push once and continue to push (single click). The increased excavating power lasts for a maximum of 8.5 seconds.




### 9. Auto diesel release switch (optional)

This is a switch that functions to automatically reduce engine RPM and reduce fuel consumption when the control lever is in neutral and at other times when engine output is not needed.

ON position: Auto diesel is on.

OFF position: Auto diesel is off.



You may select on or off by alternating the switch position.


**⚠ Warning!**

**Be cautious when operating the control lever in the diesel range as engine RPM will suddenly increase.**

Engine RPM for the forward and reverse travel control levers, the right and left arm and boom apparatus control levers and the blade lever will change as follows by the use of the auto diesel feature.

- When each of these levers is in the neutral position and the fuel adjustment control lever is set higher than medium speed, engine RPM will decrease to medium speed. If any of the levers is moved, engine RPM will increase to the level set by the fuel adjustment control lever.


## 12.3 CONTROL LEVERS/ PEDALS



## 1. Lock lever (for the left and right arm and boom apparatus control levers)

## ⚠ Warning!

- Make sure that the lock lever is in the locked position when standing up from the operator's seat. If you accidentally touch the lever and it is not locked serious injury may result.
- If the lock lever is not exactly in the locked position the control levers may not be locked. Make sure that the lever is in the position shown in the diagram.



## ⚠ Warning!

- The machine may be moved and the blade operated even though the lock lever is locked as they are not locked by this lever.
- Make sure that you do not touch the control levers for the arm and boom apparatus when pulling up the lock lever. It is dangerous if the lock lever is not pulled all the way to the top as the arm and boom apparatus may move or swing.


12. EXPLANATION OF EACH DEVICE

**Warning!**

Be careful not to touch the control levers for the arm and boom apparatus when pushing the lock lever down.

This is a device which locks the arm and boom apparatus and prevents it from swinging. If the lever is pulled up, the lever stand will go up and lock.

This locking lever is a hydraulic type lock so that when placed in the locked position, the control levers for the arm and boom apparatus will move but the arm and boom apparatus itself and the swing motor will not.



**Warning!**

The method of operating the control levers for the arm and boom apparatus and the movement of this apparatus is prescribed by JIS. The hydraulic hoses and the valves etc. may not be modified.


- Prevent accidents from improper operation.
- This does not conform to the directives of the Construction Ministry.

2. Left arm and boom apparatus control lever

This lever controls the operation of the arm and the upper swing structure.

- |               |                  |
|---------------|------------------|
| Arm operation | Swing operation  |
| A Extend      | C Swing to right |
| B Retract arm | D Swing to left  |

N (Neutral: The upper swing structure and arm will not move and will be maintained in that same position.




3. Right arm and boom apparatus control lever

This lever controls the operation of the boom and the bucket.

- |                |                  |
|----------------|------------------|
| Boom operation | Bucket operation |
| 1 Raise        | 3 Dump           |
| 2 Lower        | 4 Bite           |


N (Neutral: The boom and bucket will not move and will be maintained in that same position.



4. Fuel control lever

This lever controls the RPM and the output of the engine.


- 1 Low idling: Move the lever as far as it will go forward
- 2 Full RPM: Pull the lever as far as it will go toward you



5. Blade control lever

This lever controls the blade.


1. Lower
2. Raise




6. Forward/ Reverse Travel lever

**Warning!**

When the track frame is facing backwards, the positions of this lever are reversed. Before using the forward/ reverse travel lever, make sure you know which way the track frame is facing. (When the sprocket is in the rear the track frame is facing forward)



- 1 Forward: Push the lever forward
  2. Reverse: Pull the lever towards you
- Neutral position: The vehicle does not move either forward or in reverse.




7. Pedal lock (for operating the boom offset)

**Warning!**

When not operating the boom offset, keep it locked with the pedal lock. A serious accident can be caused if the pedal for operating the boom offset is accidentally moved when it is not locked.

This is a device for locking the pedal for operating the boom offset.

The pedal is locked by covering it with a plate.






## 12. EXPLANATION OF EACH DEVICE

---

### 8. Boom offset pedal


The boom is offset with this pedal

1. Right offset
2. Left offset




### 9. Travel speed accelerator

Pressing this pedal down accelerates the forward/ reverse travel speed.




## 12.4 ENGINE HOOD


1. Raising engine hood release lever (1), unlocks the hood.



2. Pulling up on hood (2) will open it.



3. When closing the hood, quietly lower the hood and fasten the lock.



### NOTICE

Keep the hood locked at all times other than when you need to open it.

## 12.5 FRONT WINDOW

**Warning!**

Always grip the front window firmly with both hands when you open it. If your hands slip when opening it they may be pinched between the window and the frame.


You may pull up and secure the front window (the top of it) to the roof of the cab.

### When opening


**Warning!**

When the front window is open there is the danger that it may fall so always lock it with the left and right lock pins.

1. Place the arm and boom apparatus down on level ground and stop the engine.




2. Lock the safety lock lever securely.




3. Disconnect the windshield wiper motor wires at outlet B.

### NOTICE


If you try to open the window but do not disconnect the wires from the outlet, the wires will be pulled out.




4. Pull the lock pins A on the top right and left sides of the window and release the locks.



- From inside the cab grasp the lower grip on the window with the left hand and the upper grip with the right hand and pull up. Push it into catch C so that it is secured.



- Lock with lock pins A




**When closing**


**Warning!**

Lower the window slowly so that you do not get your hands pinched.


- Place the arm and boom apparatus down on level ground and stop the engine.
- Lock the safety lock lever securely.



- Unfasten lock pins A




- Grasp the lower grip on bottom the window with the left hand and the upper grip on the top of the window with the right hand and push catch C with the thumb of your right hand. Lower the front window slowly so that the top upper grip comes down. You can release catch C by pushing release lever D in the direction of the arrow.





## 12. EXPLANATION OF EACH DEVICE

5. Securely fasten lock pins A on the right and left of the window
6. Connect the windshield wiper motor wires at outlet B.



- **Removing the front window (lower part)**

You may remove the lower part of the front window when the top part of the front window is open by releasing lock pin E. Store this in the rear of the cab.




## 12.6 SLIDING DOOR

**Warning!**

On vehicles that come with a cab always make sure that the sliding door is locked whether the door is open or closed. Always open or close the door when you are on level ground. The force needed to open or close the door on a slope may vary suddenly so avoid trying to open or close it on a slope.

- **Door lock**

When closing the door, pull the handle initially back and release the lock then pull the door forward.



### 12.7 FUSE BOX


#### NOTICE

Always disconnect electrical power (turn the ignition switch to OFF) before changing fuses.

Fuses protect electrical equipment and wires from burning up and damage from excess heat.


If fuses have corroded, if they have white powder on them or if they have become loose in the fuse holder, replace them.

Use fuses of the same capacity when replacing.



Fuse capacity and name of circuit

No.	Fuse Capacity	Name of Circuit	Remarks
1	30 A	Engine control system	—
2	20 A	Electrical system controller, Monitor panel, Knob switch (optional)	—
3	20 A	Electrical system redundant circuits	—
4	30 A	Heater, horn, windshield wipers, interior light, radio, auto diesel motor	—
5	30 A	Operating light, reset power, air conditioner, swing brake, buzzer, TVC solenoid valve, forward/reverse travel accelerator solenoid valve	—




### 12.8 Fusible link

When the ignition switch is turned to the ON position and there is no power, it may be a broken wire-type fusible link 2 so open up side cover 1 on the left side of the body and check and replace it if necessary.

#### Additional explanation

A fusible link refers to the large fuse circuit installed in circuits which have high current flows. Similar to ordinary fuses, it protects electrical equipment and circuits from burning up from unusually heavy flows of current.



## 12.9 LOCKING CAP AND COVERS

The fuel tank cap, the cab, the engine hood, the left side cover and right side cover are all outfitted with locks.

Use the ignition switch key to remove and replace the fuel tank cap.

### 12.9.1 How to remove and replace the locking cap for refueling the fuel tank




#### ■ To remove

1. Insert the key
2. Turn the key in a counterclockwise direction and align the opening of the rotor groove with the mark on the cap and you may remove the cap.

#### ■ To lock

1. Screw in the cap.
2. Turn and remove the key.

Turn the key only after fully inserting it. If you turn it when not fully inserted, you may bend and damage the key.



### 12.9.2 How to open and close covers with locks

#### ■ To open (when they are locked)


1. Insert the key.
2. Turn the key in a counterclockwise direction, and if you can grasp the cover handle you can open it.

#### ■ To lock

1. Close the cover and insert the key.
2. Turn the key in a clockwise direction and remove it.


### 12.10 TOOL BOX

Place tools in this.



### 12.11 GREASE GUN HOLDER

This is inside the battery compartment (on the left side of the vehicle). Hang the grease gun in here when not using it.




### 12.12 CONTROLLERS

Controllers for controlling the arm and boom apparatus are installed.


#### NOTICE

- Do not allow water, mud or drinks to get on the controllers as this will cause breakdowns.
- If problems arise with the controllers, do not attempt to repair them yourself. Consult with Komatsu or your Komatsu dealer.



### 12.13 ASHTRAY (OPTIONAL)

This is on the right side of the cab.  
Always close the cover after extinguishing cigarettes.




### 12.14 REAR UNDER VIEW MIRROR (OPTIONAL)

Sit in the operator's seat, and adjust the mirror so that you can see behind the counterweight.

#### NOTICE

The mirror may protrude from the swing radius (approximately 100 mm) depending on the direction.






12. EXPLANATION OF EACH DEVICE

12.15 USING THE CAR RADIO


12.15.1 Explanation of each feature



1. ON/OFF and volume control button (push ON/VOL)


Turn the radio on by pressing this button. Lights will come on on the display panel and the frequency (1) will be displayed. Pressing this button will turn off the power to the radio.

Turning the button in a clockwise direction when the radio is on will increase the volume. Turning it in a counter clockwise direction will decrease volume.




2. Tone quality control button (TONE)

Turning this button in a clockwise direction from the neutral position will enhance the treble sounds. Turning it in the opposite direction will enhance the bass sounds.




3. Display button (DISP)

If you push this button while the radio is on, the set frequency being received will be displayed for 5 seconds.




4. Channel selection, time set buttons (TUNE)

When selecting channels, change frequency using these buttons. Each time the up-button  $\wedge$  is pressed, frequency increases 9 kHz, and each time the down-button  $\vee$  is pressed, frequency decreases 9 kHz. If these buttons are pressed continuously for more than 2 seconds the channel selector will automatically scan and select a channel. These buttons are also used to change the hour and second displayed when setting the clock.




5. Preset buttons (1,2,3,4,5,6)

You may select a desired channel by pressing a button when these buttons have been set to desired channels in advance.




6. Time set button (T. ADJ)

Press this button to set the time




7. Time information button (RESET)

If you press this button you can reset the clock to 0.



8. Display panel


Displays the frequency, the time and the preset numbers.



**12.15.2 How to operate the radio**

■ **How to set the preset buttons**

1. Press the ON/OFF switch. The frequency will be displayed in the display section.
2. Adjust the channel select buttons (Λ or V) to the desired frequency.
3. Press buttons of the number you wish to store in memory continuously for at least 2 seconds.  
When the sound dies out and then resounds, the number has been entered in memory and the preset number will be displayed in display section 2.




After the number has been stored and the preset button is pressed and released (less than 2 seconds) the frequency of the broadcast station that was stored with that number will be heard.

One station may be stored for each preset button.

■ **How to tune manually**

Press the channel select buttons gently and select the desired frequency. Each time the button is pressed the frequency changes 9 kHz.

- Λ button: Moves in the direction of higher frequencies
- V button: Moves in the direction of lower frequencies




■ **How to select automatically**

Press the channel select button continuously for at least 2 seconds and release. When a broadcast channel is detected the scan will automatically stop on that channel.

To search for the next channel again press the channel select button continuously for at least 2 seconds and release.


- Λ button: Moves in the direction of higher frequencies
- V button: Moves in the direction of lower frequencies

When the signal of the channel is weak and is not selected, find the channel manually.




### ■ Setting the time

1. While pressing the time set button (1), press the button for setting the hour (2). The hour displayed will change so when the hour you wish to have displayed appears, release the button.
2. While pressing the time set button (1), press the button for setting the minute (3). The minute displayed will change so when the minute you wish to have displayed appears, release the button.



### ■ How to use the clock reset button

To set the clock with a time signal announcement or to standard time, press the reset button (1), and the clock will instantly show the correct hour. From 1 to 29 minutes after the hour, the time will go back to the hour. From 30 to 59 minutes after the hour, the time will move forward to the next hour.



Example:

10:29 → 10:00 (goes back)


10:30 → 11:00 (goes forward)

### ■ Antenna

Extend the antenna when the signal is weak or when there is static. When set to a strong signal, retract the antenna and adjust to a weaker signal.

### NOTICE

Retract antenna prior to transporting the vehicle, or putting it in a garage so that it will not get in the way.



### 12.15.3 Precautions in using

- For purposes of safety, while operating the machine, adjust the volume level so that sounds outside the vehicle are audible.
- Be careful so that water does not get on the speaker cases or in the car radio (auto tuning) because this will cause malfunctioning.
- Never use solutions such as benzine or thinners to clean the dial or buttons. These should be cleaned with a soft, dry cloth. (Use a cloth dipped in alcohol for extremely soiled surfaces).
- Reset preset settings after replacing the battery as all of them will be cleared when the battery is removed.

### 12.15.4 Specifications

Tuning system:	PLL synthesizer system
Receiving frequencies:	522 kHz - 1629 kHz
Intermediate frequency:	450 kHz
Rated output:	3 W
Maximum output:	5 W
Current consumed:	less than 2 A
External dimensions:	width, 178 mm; height, 50 mm; depth 110 mm
Weight:	640 g

## 12.16 USING THE AIR CONDITIONER


### 12.16.1 Using the control panel

#### 1. Fan knob

As the knob is moved from L to M to H, more air is circulated.

#### 2. Temperature control knob

As the knob is move to the right, cooler air will be delivered.



### 12.16.2 Precautions in use

Observe the following precautions so that the air conditioner will work efficiently.

When the vehicle has been parked for a long time when it is extremely hot and the temperature in the interior of the cab is very high, open the windows and doors to air out the cab and then use the air conditioner.

Keep the doors and windows closed while using the air conditioner.

The air conditioner will not cool the air well if there is mud and dirt on the condenser. Clean such things off the condenser when checking or cleaning the vehicle and improve its exposure to the air.

The optimal setting for the air conditioner from a health standpoint is when the person entering the cab feels a slight chill (a temperature difference of about 5-6°C from ambient temperature). Adjust the temperature carefully.

## 13. OPERATION

### 13.1 CHECKS BEFORE STARTING THE ENGINE


#### 13.1.1 Visual check

Before starting the engine visually inspect the environs and under side of the vehicle to see if there are any loose bolts and nuts, oil or fuel leaks and check the condition of the arm and boom apparatus and the hydraulic system. Check to see if there are any loose wires, messy spots or accumulations of dust in places where the temperature will likely be high.

**Warning!**

Accumulation of flammable material near the battery and engine components that run at high temperatures like the muffler and turbo's and leaks of fuel and oil may cause fires in the vehicle. Check carefully and if there is a problem, always correct it or contact Komatsu or your Komatsu distributor.

Perform the checks in this section once daily prior to starting the engine.



#### 1. Check the sensors for damage

Check the sensors for damage and if anything is abnormal have it inspected and repaired by Komatsu or your Komatsu distributor.

#### 2. Check the arm and boom apparatus, cylinders, linkage and hoses for damage, wear and play.

Check the arm and boom apparatus, cylinders, linkage and hoses for cracks and excessive wear and play. If any thing is wrong have it repaired.

**3. Remove dirt and dust from around the engine, battery and radiator.**

Check to see whether any dust or dirt has accumulated around the engine and radiator. Also check to see if any flammable materials (dead leaves, twigs etc.) are near the battery and engine components that run at high temperatures like the muffler and turbocharger. Get rid of all dust or accumulations of flammable materials found.

**4. Check to see if there are any water leaks or fuel leaks around the engine.**

Check to see if there are fuel leaks from the engine or any water leaks from the cooling system. If anything is wrong have it repaired.

**5. Check for leaks from the hydraulic equipment, the hydraulic tank, hoses and joints.**

Check to see whether there are any oil leaks and if anything is wrong have it repaired.

**6. Check the undercarriage (the tracks, sprocket and idler) for damage, wear, loose bolts and oil leaks from the rollers.**

**7. Check the handrails for loose bolts**

If anything is wrong have it repaired. Tighten up loose bolts.

**8. Check the gauges and monitors for damage and loose bolts.**

Check to see whether there is any damage to gauges and monitors and if anything is wrong replace them. Clean the surfaces of these gauges and monitors so that they are free from dirt and grime.

**9. Check and clean the rear under view mirror (optional)**

Check for damage to the rear underview mirror and if there is damage replace it with a new one. Make sure that the surface of the mirror is clean and adjust the mirror so that the lower part of the rear of the vehicle is visible from the operator's seat.

**10. Check seat belts and fastening hardware (optional).**

Check seat belts and fastening hardware and if there is damage, replace them with new ones.

**11. Check to make sure that the window is in place and not damaged**

Check to make sure that the window is in place and not damaged. If damaged replace it with a new one. If the window comes off or is damaged during operations, do not continue operations. Repair it or restore it immediately.



## 13. OPERATION

### 13.1.2 Checks before beginning operations

Perform these checks once daily prior to starting the engine the first time.


#### ■ Check the coolant level and add if necessary



**Warning!**



Do not remove the radiator cap. When the engine is cold, coolant level may be checked with the reserve tank.

1. Open the engine hood and check to see whether the coolant level in the reserve tank (1) is between FULL and LOW. If the level is low add coolant to reserve tank (1) until it is at the full level.
2. Tighten the cap securely when you have finished adding coolant.
3. If the reserve tank is empty check for leaks. Then check the coolant level in the radiator. If low add coolant to the radiator and then to the reserve tank.



#### ■ Check the oil in the engine oil pan and add if needed.

1. Open the engine hood
2. Remove dipstick (G) and wipe it off with a rag.
3. Reinsert dipstick (G) as far as it will go and then remove.
4. If there is oil on the dipstick (G) between H and L, the level is satisfactory. If the level is below L add oil at (F).



For the oil to use see item 21, "Use of fuel and lubricants by ambient temperatures".

5. If the level is above H remove the excess oil from drain plug (P) and recheck the oil level.
6. If the oil level is correct, replace the cap, tighten it securely and close the engine hood.


#### Additional explanation

If you are checking the oil level after the engine has been operating, wait for at least 15 minutes after stopping the engine before performing the check.


#### ■ Check the fuel level

#### ⚠ Warning!

Do not allow the fuel tank to overflow when refueling as this can cause a fire. Clean up any spillage if it occurs. Do not stand directly above the opening to the fuel tank when refueling. Fuel may spurt out from the tank breather hole.



1. Insert the key in ignition switch (1), turn it to the ON position and allow the monitor light to come on.
2. Ascertain the amount of fuel remaining from fuel gauge (2). If there is insufficient fuel, fill the fuel tank while observing sight gauge (G).




#### Capacity of fuel tanks 135 ℓ

For the fuel you should use see item 21, "Use of fuel and lubricants by ambient temperatures".

3. After finishing, replace the cap and tighten it securely.

#### Additional explanation

If the breather holes (3) become clogged, pressure in the tank will decrease and fuel will not flow. Clean these holes from time to time.




## 13. OPERATION


- Check the oil level in the hydraulic oil tank and add if necessary.

### Warning!

- Unscrew the cap to the hydraulic tank slowly and allow pressure to escape before removing it as oil can spurt out at this time.
- If you accidentally add oil so that it is above the H level, stop the engine and wait for the hydraulic fuel to cool. Then drain it from drain plug (P).



1. If the vehicle is not in the position shown in the diagram on the right, start the engine and while it is running at low speed, lower the blade to the ground, retract the arm and bucket cylinders, lower the boom and stop the engine with the teeth of the bucket touching the ground.
2. Check sight gauge (G) and if the oil level is between H and L it is satisfactory.




### NOTICE

Do not add oil above the H line. This will damage the hydraulic lines and will cause oil to spurt out.

3. If the hydraulic oil level is below L, remove the cover on the top of the hydraulic oil tank, and add oil from filler port (F).

For the oil you should use see item 21, "Use of fuel and lubricants by ambient temperatures".




### Additional explanation

The oil level will vary with the temperature of the oil so use the following criteria to check the oil:

- Prior to operation, around the L level (oil temperature from 10 to 30°C)
- During normal operation, near the H level (oil temperature from 50 to 80°C)


■ Check the dust indicator

1. Open the left side cover and check to see whether a red piston is protruding where the arrow is pointing on the dust indicator (1).
2. If the red piston is protruding immediately clean the element or replace it.



For how to clean the element, see item 25.2.1 "Inspecting, cleaning and replacing the air cleaner".

3. After checking, cleaning or replacing the air cleaner, push the knob of dust indicator (1) and return the red piston to its original position.



■ Checking the electrical circuits

**Warning!**

**If fuses blow frequently and there is evidence of short circuits in the wiring, do not fail to ascertain the cause and correct it.**

Check for blown fuses, breaks in the wiring and evidence of short circuits. Check also for loose terminals, and if found, tighten them.

In particular, check the

- Battery
  - Starter
  - Alternator
- etc.

Consult with Komatsu or your Komatsu distributor for locating and correcting the problem.

**Warning!**

**Always remove any flammable materials like dead leaves, twigs and grass that may have accumulated around the battery as they can cause fires.**

Always check around the battery for flammable materials that may have accumulated when doing visual checks and checks prior to beginning operations and remove them if there are any.

### 13.1.3 Adjustments prior to beginning operations

- Adjust the operator's seat forward or backward

**Warning!**


Adjust prior to operating or when changing operators.

The seat and the console box move backwards and forwards.

Move lever (1) toward the left side and when the seat is in a comfortable position, release the lever.

Adjustable distance: 80 mm (5 positions)


Adjust the operator's seat to conform with the nature of the work to be performed. For example, when performing deep excavating operations, sliding the seat forward will facilitate a better view of the area below the front of the machine.




### 13.1.4 Checks and tasks to be performed before starting the engine

**⚠ Warning!**

The machine and its apparatus may move suddenly if the control levers are accidentally touched. Make sure that the locking lever is in the locked position before standing up from the driver's seat.




1. Check to make sure that the locking lever (1) is in the locked position
2. Check the position of each lever  
Put the control lever in the neutral position.



3. Insert the key in the ignition switch, rotate the key to the ON position and perform the following checks.

- 1) The buzzer will sound for approximately 1 second and the following monitors and gauges will light up for approximately 3 seconds.
  - Engine oil level monitor (3) (optional)
  - Charging monitor (4)
  - Engine oil pressure monitor (5)
  - Electrical systems monitor (6)
  - Engine coolant temperature gauge (7)
  - Fuel gauge (8)



#### Additional Remarks

The engine oil level indicator is an optional item so that on those vehicles that do not have this optional item installed there will be no indication even when the level is low.

If the gauges or meters do not light up there may be burned out bulbs or a break or loose connection in the wiring. Consult Komatsu or your Komatsu distributor for service.

After approximately 3 seconds the following gauges will remain on and the others will go out.


- Engine coolant level (7)
- Fuel gauge (8)

## 13. OPERATION

---

- 2) Turn the light switch (9) in a clockwise direction and check to see whether the lights come on.

If the lights do not come on there may be burned out bulbs or a break or loose connection in the wiring. Consult Komatsu or your Komatsu distributor for service.




F17021

## 13.2 STARTING THE ENGINE

### 13.2.1 Normal starting

**Warning!**

Start the engine after making sure there is no one or any obstacles in the area around the machine and sounding the horn.




#### NOTICE


Do not turn the starter motor over continuously for more than 20 seconds.

If the vehicle fails to start wait for approximately 2 minutes and try again.


1. Pull the fuel control level (1) back to a position between low idling and full power.



2. Turn the key in the ignition switch (2) to the START position. The engine will start.



3. After the engine starts, release the key in the ignition switch. The key will automatically return to the ON position.





13.2.2 Starting in Cold Weather

**Warning!**  
 Start the engine after making sure there is no one or any obstacles in the area around the machine and sounding the horn.




NOTICE

Do not turn the starter motor over continuously for more than 20 seconds.

If the vehicle fails to start wait for approximately 2 minutes and try again.

Start the engine with the following procedure in cold weather



1. Pull the fuel control level (1) back to a position between low idling and full power.
2. Turn the key in the ignition switch (2) to the HEAT (preheat) position and make sure that the preheat monitor light (3) comes on. After approximately 18 seconds the preheat monitoring light will go out signaling that preheating has been completed.



Additional explanation

When the key is placed in the HEAT position, monitor and gauge lights will come on but this does not indicate that anything is wrong.

3. When the preheat monitor light (3) goes out, place the key in the starting switch (2) in the START position and start the machine.
4. After the engine starts, release your grip on the key in starting switch (2). The key will automatically return to the ON position.



### 13.3 CHECKS AND TASKS TO BE PERFORMED AFTER STARTING THE ENGINE

**Warning!**

- If operations are performed without warming up the machine in cold weather, the automatic stop feature of the accident prevention device may slip out of position. Always run the machine on warm up after starting.
- When checking the operation of the accident prevention device, move the levers slowly.

**NOTICE**

Normal operating temperature for hydraulic oil is between 50 and 80°C. If operations have to be conducted under cold temperatures, wait until the temperature of the oil has risen to 20°C before moving on to normal operations.

**NOTICE**



Do not make sudden movements with the control levers when the temperature of the hydraulic fluid is below 20°C.

**NOTICE**

Do not suddenly accelerate the running speed of the engine until the warming up operation has been completed. Do not allow the engine to run at low idle or high idle for more than 20 minutes. This may cause oil leaks from the turbocharger oil supply lines. When it is necessary to idle the engine, occasionally apply a load or run it at moderate speeds.


After the engine has been started, do not immediately begin operations but perform the following tasks and checks.

1. Pull the fuel adjustment control lever (1) to a position between low idle and full speed, and run the engine for about 5 minutes at medium speed without a load.




13. OPERATION

2. Set the locking lever (2) to the free position and raise the bucket from the ground.




3. Move the right arm and boom apparatus control lever (3) slowly and move the bucket cylinder to the end of the stroke and maintain it there for 5 minutes.




4. After warming up the machine, make sure that each of the monitor lamps and gauges are as follows:

- Engine coolant temperature gauge (4) . . . . . In the green range
- Fuel gauge (5) . . . . . In the green range
- Engine oil pressure monitor (6) . . . . . Light is out
- Charge level monitor (7) . . . . . Light is out
- Engine oil level monitor (8) . . . . . Light is out (optional)
- Electrical system monitor (9) . . . . . Light is out




5. Make sure there is no abnormal color to the exhaust gas, unusual sounds or vibrations. If something is abnormal repair it.


6. Place the locking lever (2) in the locked position and make sure that the arm and boom apparatus cannot be operated with the left and right control levers and that it cannot be swung.




7. Place the locking lever (2) in the free position and check the accident prevention device as follows.




- Place the arm and boom apparatus in the position as shown in the diagram to the right, raise the boom and move it so that you can see whether the apparatus automatically stops when it approaches the cab. If it stops, lower the boom and turn off the automatic stop feature.



- Place the arm and boom apparatus in the position as shown in the diagram to the right, move the arm toward the cab and move it so that you can see whether the apparatus automatically stops when it approaches the cab. If it stops, extend the arm and turn off the automatic stop feature.



- Place the arm and boom apparatus in the position as shown in the diagram to the right, operate the left offset to see whether the apparatus automatically stops when it approaches the cab. If it stops, operate the right offset and turn off the automatic stop feature.



When checking and there seems to be something abnormal, perform task 3 (Move the right arm and boom apparatus control lever slowly and move the bucket cylinder to the end of the stroke and maintain it there for 5 minutes), warm up the hydraulic fluid and try again.


If the problem continues to occur, stop the vehicle in a safe place, stop the engine, and request that Komatsu or your Komatsu distributor check and inspect it.

### 13.4 MOVING THE MACHINE


#### 13.4.1 Moving the machine forward

**Warning!**


- Ascertain the direction of the track frame before operating the forward/ reverse travel levers. If the sprocket is at the front, the operation of the forward/ reverse travel levers is reversed.
- Make sure that the area around the machine is safe and sound the horn before moving it.
- Do not allow personnel near the machine.
- Clear obstacles from the path of the machine.



1. Pull the fuel control lever back to the full position to increase engine speed.





2. Place the locking lever (2) in the free position, retract the arm and boom apparatus and raise it 40 to 50 cm off the ground.



3. Raise the blade.

4. Operate the right and left forward/ reverse travel control levers as follows:


- When the sprocket is at the rear of the machine  
Move lever (3) forward slowly to move the machine.
- When the sprocket is at the front of the machine  
Move lever (3) back slowly to move the machine.




### 13.4.2 Moving the machine backward

**Warning!**


- Ascertain the direction of the track frame before operating the forward/ reverse travel levers. If the sprocket is at the front, the operation of the forward/ reverse travel levers is reversed.
- Make sure that the area around the machine is safe and sound the horn before moving it.
- Do not allow personnel near the machine.
- Clear obstacles from the path of the machine.
- There is a blind spot behind the machine so when moving in reverse exercise extreme caution.



1. Pull the fuel control lever back to the full position to increase engine speed.




2. Place the locking lever (2) in the free position, retract the arm and boom apparatus and raise it 40 to 50 cm off the ground.
3. Raise the blade.




4. Operate the right and left forward/ reverse travel control levers as follows:

- When the sprocket is at the rear of the machine  
Move lever (3) backward slowly to move the machine.



- When the sprocket is at the front of the machine  
Move lever (3) forward slowly to move the machine.



### 13.5 STEERING THE MACHINE


#### 13.5.1 Steering (changing the direction of advance)

**Warning!**  
Ascertain the direction of the track frame before operating the forward/ reverse travel levers. If the sprocket is at the front, the operation of the forward/ reverse travel control levers is reversed.

Operate the forward/ reverse travel control levers to change direction.

As much as possible avoid sudden changes of direction. Particularly when executing counter rotation (spin turns), stop the machine first and then change direction.

Operate the two forward/ reverse travel control levers as follows:




■ **Changing the direction of the machine when it is not moving**

When turning to the left, push the right travel control lever forward. Pulling that lever back will make turn the vehicle left in reverse.

**Additional explanation**

When turning to the right operate the left travel control lever in the same way.




■ **Changing the direction of the machine when traveling (when both the left and right forward/ reverse travel control levers are inclined in the same direction)**

To turn left, return the left travel control lever to the neutral position and the machine will turn left.

**Additional explanation**

When turning to the right operate the left travel control lever in the same way.




- When executing spin turns

To execute a spin turn to the left pull the left travel control lever back and push the right travel control lever forward.

**Additional explanation**

To execute a spin turn to the right pull the right travel control lever back and push the left travel control lever forward.






### 13.6 STOPPING THE MACHINE

**⚠ Caution!**

Avoid stopping suddenly and allow yourself ample room to stop.


**⚠ Warning!**

- Choose a firm level place to stop.
- Do not stop on slopes.
- When you must park the machine on a slope, block the tracks so that they will not move and thrust the bucket into the ground.





**⚠ Warning!**

The machine and its apparatus may move suddenly if the control levers are accidentally touched. Make sure that the locking lever is in the locked position before standing up from the driver's seat.




1. Place the right and left forward/ reverse travel control levers in the neutral position. The machine will stop.




## 13.7 SWINGING

**Warning!**

Check to make sure that the area is safe before swinging the arm and boom apparatus.



1. Operate the left arm and boom apparatus control lever to swing it.
2. When not swinging the apparatus, bring the superstructure and track frame into parallel and place the left arm and boom apparatus control lever (1) in N (neutral). The swing brake will engage.




### 13.8 PROHIBITED ACTIONS WHILE OPERATING THE MACHINE

**Warning!**

If you must operate the control levers for the arm and boom apparatus while traveling, stop traveling temporarily and then operate the arm and boom apparatus.


- Do not use the swing power of the machine in operations.

Never use the arm and boom apparatus while it is swinging to level ground, knock down mud walls or dig the teeth of the bucket into the ground while swinging the apparatus. You will damage the arm and boom apparatus if you do.




- Do not use the forward/ reverse travel power in operations.

Inordinate strain is placed on the body of the machine if you try to excavate by moving the vehicle while the bucket is in the ground.




- Be careful of operations done at the end of the stroke of the hydraulic fluid cylinder

If the arm and boom are operated when the cylinder is at the end of its stroke, considerable strain is placed on the stopper inside the cylinder and this will shorten the life of the machine. Allow a certain amount of space at the end of the stroke.




- Never use the dropping force of the bucket

Do not use the dropping force of the arm and boom apparatus for excavating or use the bucket for work that would be done by a pick axe or jack hammer or use the bucket to pound in pilings or stakes as this will place inordinate stress on the body of the vehicle. This will not only damage the body, it is also dangerous.



- Never use the dropping force of the body of the machine

Do not use the dropping force of the body of the machine.




- **Excavating hard pan**

Excavating hard pan after breaking it up by some other means will cause less damage to the machine and is more cost-effective.

- **Do not perform hoisting operations**


Using this machine to perform hoisting operations is prohibited by the Labor Safety and Hygiene regulations.

The exception which is approved is the removal of pilings and when this is to be done special fittings for hoisting are necessary. Consult with Komatsu or your Komatsu distributor for details.




- **Be careful of striking objects with the blade**

Do not allow the blade to strike rocks and rock piles etc. This will cause damage to the blade and to the cylinders.




- **Be careful when retracting the arm and boom apparatus**

When retracting the boom for moving or for transporting the machine be careful so that the bucket and blade do not strike each other.




- **Support both sides of the blade**

When using the blade as an outrigger, do not support only one side of the blade.



- **Be careful not to hit the blade when doing deep excavation**

When the blade is in front and performing deep excavation make sure that the boom cylinders do not strike the blade and other than when necessary perform deep excavation operations with the blade at the rear of the vehicle.




## 13. OPERATION

---


- **Be careful that the arm cylinder does not hit any obstacles**

When the arm is moved, the rear position of the arm cylinder varies. Be careful so that it does not get hung up on power lines or contact anything unintended.



- **Do not move the travel speed control lever suddenly when accelerating speed.**

- (1) Do not move the lever suddenly so that the machine lurches forward.
- (2) Do not move the lever suddenly when going from forward to reverse (or from reverse to forward)
- (3) Do not move the lever suddenly (by releasing the lever suddenly) so that a sudden stop occurs when the vehicle is traveling at maximum speed.




### 13.9 PRECAUTIONS DURING OPERATION

#### ■ Precautions when traveling

Crawling over obstacles like fallen rocks and stumps cause major shocks to the body (particularly the undercarriage) and cause damage. Do everything possible to avoid obstacles so that you do not travel over them or remove them.

If they cannot be avoided, decrease the travel speed, lower the arm and boom apparatus so that it is close to the ground and travel over them so that they are in the center of the tracks.



#### ■ Be careful when accelerating travel speed



When traveling over hard uneven road beds or on routes with many large rocks, do not use the speed accelerator pedal. Decrease speed in such circumstances.

#### ■ Permissible water depth

#### NOTICE

When climbing out of water, the rear of the superstructure will be immersed in the water if the angle of the incline is greater than 15°. The radiator fan which is running at this time will strike the water and the water will be carried upward by the movement of the fan. This is likely to damage the fan. Be careful when emerging from water.



Use the machine up to a depth equal to center of the upper carrier roller. Grease the parts that have been used in water for extended periods so that the old grease will be forced out from the bearing. (particularly around the bucket pins).



13.10 PRECAUTIONS WHEN CLIMBING OR DESCENDING SLOPES


**Warning!**

- Raise the bucket about 20 to 30 cm from the ground when traveling. Do not travel downhill in reverse.
- When traversing over levees and other obstacles, keep the boom and arm apparatus close to the ground and travel slowly.
- Never change direction when traveling on a slope and never traverse a slope. Always move the machine safely by going down to a place where it is level and taking a round-about route etc.
- If the machine begins to slide or becomes unstable, immediately lower the bucket to apply a braking effect.
- As much as possible avoid swinging the arm and boom apparatus or operating that apparatus when performing operations on a slope as there is the danger that the machine will lose its balance and topple over.  
It is particularly dangerous to swing the bucket downhill, away from the slope when the bucket is filled.
- If such operations must be carried out on a slope, build a mound of soil on the slope so the machine can perform the operations on as level a platform as possible.
- Do not try to climb an incline of over 30° as there is the danger that the machine may topple over.




1. When descending a steep decline, use the travel control levers and the fuel control levers to act as brakes and keep the speed down.

If the decline is greater than 15° put the arm and boom apparatus in the position shown in the diagram to the right and reduce the engine speed.



2. If climbing a slope and the incline is greater than 15°, put the arm and boom apparatus in the position shown in the diagram to the right before moving.



- **Breaking when traveling downhill**

To brake the speed of the descent of the machine when traveling downhill, place the travel control levers in the neutral position. This will automatically brake the speed of the machine's descent.

- **If the tracks slip**

If the tracks slip when climbing a slope and the machine cannot climb by these alone, the power of the arm and boom apparatus can be used to help climb by pulling with the arm.

- **If the engine stalls**

If the engine stalls while climbing a slope, throw the forward/reverse travel control levers into the neutral position and start the engine.

- **Precautions on slopes**

Do not try to open or close the sliding doors while on a slope. The strength needed to do this may change suddenly.

Always keep the sliding doors in a locked position [either open or closed so they cannot move].



### 13.11 EXTRICATING THE MACHINE FROM MUD

Operate the machine so that you do not get stuck in mud. If you accidentally get stuck in the mud, extricate the machine using the following procedure.

#### 13.11.1 When one side is stuck

If only one side is stuck, put the bucket down on the side that is stuck and push it down to raise the tracks up. Place logs or lumber under them, raise the bucket and climb out.



#### NOTICE

When using the boom and arm to raise the machine, push against the ground with the bottom of the bucket. (Do not use the teeth of the bucket)

The angle between the boom and arm should be 90 to 100°.

#### 13.11.2 When both sides are stuck

When both tracks are stuck in the mud and the machine slips in place and will not move, place logs or lumber under the tracks according to the procedure explained above. Then dig the bucket into the ground in front of the vehicle and using the same motion as when excavating, pull the arm toward the machine, place the forward/ reverse travel control levers in the forward position and climb out.





## 13.12 OPERATIONS THAT CAN BE PERFORMED WITH THE HYDRAULIC EXCAVATOR

If you install various attachments, the machine may be used for many other tasks besides those noted below.

### 13.12.1 Excavation operations


When the arm and boom apparatus are as shown in the diagram to the right and the bucket cylinder and the link and the arm cylinder and the arm are at  $90^\circ$  angles, the excavation power is greatest. Use this angle effectively to improve efficiency of excavation.

The range for excavating with the arm is from  $45^\circ$  out beyond this position to  $30^\circ$  in from it. There may be some difference depending on the depth to be excavated but try to use the arm within this range without getting the arm cylinder out to the end of its stroke.



### 13.12.2 Ditch digging operations


The operation will be more efficient if you install a bucket suitable for ditch digging and set the tracks parallel to the ditch that you will be digging. For a wide ditch the usual procedure is to excavate both sides first and then dig out the center.



### 13.12.3 Loading operations


This sort of operation can be efficiently performed when the swing angle is restricted by placing a dump truck in a spot where the operator can easily see it.

It is easier to load a dump truck by beginning at the front of the bed and proceeding to the rear than it is to load from the side. You can also fill up the truck better.



### 13.12.4 Grading operations

When finished excavating and replacing the soil, perform grading operations with the blade.




## 13. OPERATION

---

### 13.12.5 Ditch digging operations from the side

By offsetting the boom, ditches can be dug from the side in narrow places without swinging the apparatus.




### 13.12.6 Operations in restricted places

If the machine is placed in a position as shown in the diagram shown at the right, when performing operations in restricted spaces, the apparatus can be rotated freely if the tracks can get into the space.

#### Minimal swing position:

1. Offset the boom to the right.
2. Place the arm cylinder, and the bucket cylinder in the fully extended position.
3. Place the boom cylinder in the fully extended position.
4. Offset the boom to the left and move it up to the point just before it triggers the accident prevention device.



### 13.13 CHANGING THE BUCKET

**Warning!**

- Metal filings will fly when pounding the pins with a hammer and if they get in the eye can cause serious injury. Use protective clothing like safety goggles, helmets and glove when performing this task.
- Place the bucket so that it is stable and secure after removing it.

Perform this operation in a level place with firm footing. When this is done together with other personnel, perform the operation with clear signals and give sufficient heed to safety concerns.

1. Lower the bucket onto level ground.

#### Additional explanation

When removing the pins place the bucket lightly on the ground. If the weight of the bucket is entirely on the ground they will be more difficult to get out.

2. Remove the stopper bolts and nuts, remove pins (A) and (B) and detach the bucket.

#### NOTICE



Be careful not to get sand and mud on the pins that have been removed. Also be careful not to damage the dust seals that are in both ends of the bushing.

3. Align the arm with hole (1), then align the link with hole (2) and install pins (A) and (B) after you have coated them with grease.

#### Additional explanation

When attaching the bucket, the O rings are easily damaged so fit the O rings to the position shown in the diagram at the right. When pounding in the pins drop the O rings in the proper groove.


4. Install the stopper bolts and nuts for each pin and grease the pins.




### 13.14 PARKING THE MACHINE

**⚠ Caution!**  
Avoid sudden stops. Give yourself ample room when stopping.


**⚠ Warning!**  
Park the machine in a firm, level place. Avoid parking on slopes. When you must park the machine on a slope, block the tracks and imbed the teeth of the bucket in the ground so the vehicle will not move.




**⚠ Warning!**  
Always make sure that the safety lock lever is in the locked position before standing up from the operator's seat. If you accidentally touch the lever for moving the machine or rotating the arm and boom apparatus and it is not locked, there may be a sudden movement which may result in serious injury.



1. Place the right and left forward/ reverse travel control levers (1) in the neutral position.




2. Put the fuel control lever (2) in the low idling position.




3. Put the bottom of the bucket so that it is level and parallel to the ground and lower it to the ground.

4. Drop the blade to the ground.




- Place locking lever (3) in the locked position.



### 13.15 CHECKS AFTER COMPLETING OPERATION

Check the engine coolant temperature, engine oil pressure and the amount of fuel remaining on the monitors.




### 13.16 STOPPING THE ENGINE


#### NOTICE

Do not stop the engine abruptly except when there is an emergency. Stopping the engine abruptly before it has cooled will shorten the life of various engine components. If the engine has overheated do not stop the engine suddenly. Allow it to run at moderate speed and stop it after it has gradually cooled down.

- Run the engine for 5 minutes at a low idle and allow it to cool down gradually.



- Turn the key in the ignition switch (1) to the OFF position.
- Remove the key from the ignition switch (1).



## 13. OPERATION

---

### 13.17 CHECKS AFTER THE ENGINE HAS BEEN STOPPED

1. Make a visual check for oil and water leaks, visually check the arm and boom apparatus, around the undercarriage and exterior equipment. If there are leaks or any problems have them repaired.
2. Top off the fuel tank
3. Remove any paper or debris from the engine compartment as they may cause a fire.
4. Remove any mud etc. that may have become stuck to the undercarriage.


### 13.18 LOCKING

Always lock the following items on the machine.

- (1) The door of the cab  
Always close the window.
- (2) The fuel tank cap.
- (3) The engine hood.
- (4) The left side cover (battery compartment)
- (5) The right side cover (the pump compartment)

#### Additional explanation

The ignition key is used for all of these locks.




### 13.19 USING THE 4 SYSTEMS

The 4 systems are the bucket-cab, canopy accident prevention device and the automatic control system for the arm and boom apparatus.

Always observe the following precautions so that these devices will operate properly.

**⚠ Warning!**


- Do not remove sensors, modify their installation or overhaul them as this may lead to faulty operation of the accident prevention devices. Always rely upon Komatsu or your Komatsu distributor for servicing these.
- If a sensor is hit or is discovered to have exterior damage, check the operation of the automatic stop system. If there is a problem request inspection and repair service from Komatsu or your Komatsu dealer.
- Do not perform any operations that will immerse the sensors in water. If by some chance the sensors have been immersed check the operation of the automatic stop system. If there is a problem request inspection and repair service from Komatsu or your Komatsu dealer.
- Do not use the automatic stop override switch other than when there is a problem with the four systems and you are moving the machine to a safe place.
- The 4 systems will not operate normally if you convert from the standard arm and boom apparatus to special attachments. If you are planning on using attachments other than those specified by Komatsu please consult with Komatsu or your Komatsu distributor.





### NOTICE

- If there is an abnormality in the 4 systems the controller will perform a self-diagnosis, flash the light on the monitor for the electrical system monitor on the monitor panel, sound a buzzer and display an error code on the depth indicator display.
- Depending on what has gone wrong with the 4 systems, though the controller has not performed a self-diagnosis, you may not be able to manipulate the arm and boom apparatus. After moving the machine to a safe location, ask Komatsu or your Komatsu distributor to check the machine.



### NOTICE

Before using the 4 systems, always perform the checks required before and after starting the engine.

In cold weather, use the systems after warming up sufficiently. If the hydraulic fluid is cold, the automatic stop positions will be off.

### 13.19.1 The bucket - cab accident prevention device

When apparatus is offset to the left the arm and boom come back too far and when the apparatus is offset to the right and the offset, arm and boom have been drawn back this device warns that the bucket will hit the cab and automatically stops operation of the boom and arm apparatus.


**⚠ Warning!**

This is equipment designed to prevent accidents in rare circumstances and performing operations relying on this device can be dangerous. Always be careful and operate the machine so that the arm and boom does not come near the cab.

#### ■ Operation of the accident prevention device


Reduced operating speed areas (forward and reverse directions only).

When performing operations and the arm and boom apparatus approaches the cab and the bucket enters the area A in the diagram at the right, the speed of the arm and boom apparatus will be reduced. This is to prevent the dirt and sand in the bucket from spilling which would occur if the arm and boom apparatus were stopped.



#### Automatic stop

If the bucket approaches the cab more closely and enters the range B shown in the diagram at the right, the movement of the arm and boom apparatus will automatically stop.




#### Emergency stop

If for some reason the arm and boom apparatus does not stop automatically when it enters range B, all operations (boom, arm, bucket, swing) will cease when the bucket reaches the area denoted by C in the diagram at the right.

At this time "91" will be displayed on the depth display of the monitor panel and self-diagnosis will be performed. The bucket can be moved forward or to the right and self diagnosis discontinued with the override switch.

However, when this happens have the machine inspected immediately.



■ Automatic stop operation

**Warning!**



After using the override switch to end the automatic stop condition, do not raise the boom, retract the arm or operate the offset to the left.

Using this feature will make it so that you cannot raise the boom, retract the arm or operate the offset to the left.

After moving the arm and boom apparatus forward or to the right and freeing the machine from this condition, you may use the machine.


**Additional explanation**

- (1) After the apparatus has been automatically stopped, you will not be able to raise the boom, dig with the arm or operate the offset to the left even though the apparatus is moved 5 to 10 cm forward or to the right. This does not mean that the apparatus has broken down however.
- (2) After the apparatus has been automatically stopped and the apparatus has been moved forward 50 cm, raising the boom and operating the arm for excavation operations will be slow ( when the engine is running at a low idle, you may not be able to raise the boom or excavate with the arm). Perform operations after the apparatus has moved forward more than 50 cm.
- (3) When not operating the machine, lower the arm and boom apparatus to the ground. If the apparatus goes down by itself, the bucket will enter the emergency stop area and the arm and boom apparatus will not operate when you start up again.
- (4) When transporting the machine, do not set the left offset. If the apparatus goes down by itself, the bucket will enter the emergency stop area and the arm and boom apparatus will not operate when you start up again.




### 13.19.2 Using the automatic control device


**Depth display** Displays the depth from the surface of the ground




**Depth display 0 set mode** Displays the depth from a standard surface




**Depth mode** Designates the depth to which the boom will go.



**Height mode** Designates the height to which the boom will go.



**Offset mode** Determines the position of the left offset for ditch excavation etc.



Both the depth display and the depth display 0 set mode explained above may be designated together with the other 3 modes. Make the settings which are suitable for the task at hand.

## 13. OPERATION

---

### ■ Depth display (depth from the surface of the ground)



Except when this is set to Depth 0 set mode, the depth from the surface of the ground will always be displayed when the ignition switch is in the ON position.

When the apparatus is above the ground UP will be displayed.

### Additional explanation


Since the depth will be displayed when the top of the bucket is perpendicular to the ground, if the bucket is in the position shown in the diagram to the right, there will be a slight discrepancy from the actual depth.

Have the machine on level ground when measuring depth.




■ **Setting Depth 0 set mode**


Will display the depth of a standard surface that has been arbitrarily chosen as 0 and will display the depth from that surface.




1. Set the mode selection switch (1) to the depth 0 set mode position.




2. Have the machine on level ground, align the bucket with where you want to have the standard surface. The way the bucket is placed at the time you align it with the surface will be the standard for displaying depth.



3. Place the setting switch in the SET position. The display will show a depth of 0.0 m.



4. Move the bucket to the place where you want to measure depth (the measuring surface).



5. When resetting so that depth from the ground surface will be displayed, set the mode selection switch (1) to the depth 0 set mode position and turn the set switch (2) to CLEAR. Depth will be displayed from the surface of the ground.

**Additional explanation**




- Place the bucket in the same position at the place you wish to measure the depth as you did when the bucket was aligned with the standard surface.
- If you turn the ignition switch to OFF without changing the mode setting, the mode setting will be cancelled.

## 13. OPERATION

### ■ Setting Depth mode

If you lower the bucket to the depth arbitrarily set, movement of the boom any lower or any pulling movement of the arm will automatically cease.

1. Place the mode selection switch (1) in the depth mode position.
2. Lower the boom to the designated position.
3. Place set switch (2) in the SET position. A buzzer will sound twice and the light of indicator (3) will come on.
4. If you raise the bucket and then lower it, it will stop at the designated depth.



### Additional explanation

The location where the bucket will stop will vary slightly with the following conditions.



- (1) When lowering the boom slowly, the bucket will stop moving will stop before it gets to the designated position
- (2) In cold weather the bucket will sometimes stop moving after it has gone past the designated position so the machine should be sufficiently warmed up and the hydraulic fluid warmed. See item 13.3 " Things to be done and checked after starting the engine" for details about warming up the engine.

### NOTICE

When the depth has been measured when the arm is pulled in and in the position seen in the diagram on the right, be careful because the bucket will go to a greater depth when the arm is moved forward.

### NOTICE


Be careful not to damage buried objects because when the depth is measured when the bucket is pushed forward as shown in the diagram on the right, it will go deeper when pulled in.



5. To clear the depth mode, place the mode selection switch (1) to the depth mode position and the setting switch (2) to CLEAR. The light on indicator (3) will go out.

**Additional explanation**

Even though you may have set a mode, if you turn the ignition switch to the OFF position the mode setting will be cleared.








## 13. OPERATION

### ■ Setting height mode


If you raise the boom to the height arbitrarily set, the apparatus will automaticall stop.

1. Place the mode selection switch (1) in the height mode position.
2. Raise the boom to the designated position.
3. Place set switch (2) in the SET position. A buzzer will sound twice and the light of indicator (3) will come on.
4. If you lower the boom and then raise it, it will stop at the designated height.



### NOTICE


In height mode the height the boom will rise to is set. If the height is set when the arm and bucket are retracted as shown in the diagram to the right, the height of the apparatus may be greater when the arm and bucket are extended forward. Be careful not to make undesired contact with objects surrounding the machine.



5. To clear the height mode, place the mode selection switch (1) to the depth mode position and the setting switch (2) to CLEAR. The light on indicator (3) will go out.

### Additional explanation

Even though you may have set a mode, if you turn the ignition switch to the OFF position the mode setting will be cleared.







### ■ Setting offset mode

If you set move the apparatus to the arbitrarily set left offset it will automatically stop.

1. Place the mode selection switch (1) in the offset mode position.
2. Place the apparatus in the designated offset position.
3. Place set switch (2) in the SET position. A buzzer will sound twice and the light of indicator (3) will come on.
4. If you move to the right offset and then move back to left offset the apparatus will stop at the designated left offset position.
5. To clear the offset mode, place the mode selection switch (1) to the depth mode position and the setting switch (2) to CLEAR. The light on indicator (3) will go out.

#### Additional explanation

Even though you may have set a mode, if you turn the ignition switch to the OFF position, the mode setting will be cleared.



## 13.20 USING RUBBER TRACK SHOES (FOR MACHINES SPECIFIED FOR USE WITH RUBBER TRACKS)

### 13.20.1 How to use rubber track shoes properly

Rubber track shoes have some qualities superior to steel track shoes but if they are used in the same way as steel track shoes these qualities cannot be fully realized. Proceed with a task in a way that conforms to the area to be worked in and the demands of the task itself.

#### A Comparison of Rubber track shoes and Steel track shoes

	Rubber track shoes	Steel track shoes
Low vibration	◎	△
Run smoothly (no squeaking)	◎	○
Low noise	◎	△
Do not damage paved surfaces	◎	△
Easy to handle	◎	△
Easily damaged	△	◎
Good towing strength	◎	◎

◎: Especially good

○: Good

△: Average

The obverse side of the fact that rubber track shoes have many advantages due to the special performance of these materials is that they are not as resilient. Consequently, if you are sufficiently cognizant of the peculiarities of rubber track shoes do not use them in operations not recommended and follow precautions in handling them, you can prolong the life of rubber track shoes and make use of the advantages that rubber track shoes offer.

Before using them please refer to item 13.21.3 "Precautions in using rubber track shoes."

### 13.20.2 Concerning the warranty on Rubber track shoes

The warranty does not apply if damage occurs due to the fault of the customer by failing to service and inspect and maintain proper track tension or failing to observe precautions in use or by performing prohibited operations such as operating on sharp surfaces such as "steel pilings, U shaped ditches, on sharp angles like blocks, on the edges of cut stone or rocks, steel rods, and other objects that may cut the track shoes."

### 13.20.3 Precautions in using rubber track shoes

#### ■ Prohibited operations

Do not perform the following operations

- Operations on surfaces or swinging the arm and boom apparatus on surfaces with sharp rocks, sharply uneven hard rock surfaces, steel cables, on scrap iron, close to edges of steel plates will damage the rubber track shoes
- In operations in places with many large and small fallen rocks like river beds, stones will cut into the rubber and cause damage to the track shoes and make the track shoes likely to come off. Pushing dirt which requires slipping of the tracks will also shorten the track life.
- Operate so that oil, fuel and chemical solutions do not adhere to the track shoes. If the track shoes come in contact with these, they should be wiped off immediately. Do not travel through puddles of oil etc. that have accumulated on the roads.
- Store the machine inside in a place where the track shoes will not be exposed to direct sunlight and rain when storing the vehicle for a long period (more than 3 months)
- Do not go into situations where there are high temperatures such as near fires, on steel plates that have been left scorching in the sun, over hot asphalt that has been spread.
- Moving the machine on one track when the arm and boom apparatus has been used to raise the other track may cause the tearing or damaging of track shoes.


### 13.20.4 Precautions in use

Observe the following precautions when using.


- Avoid swinging on concrete road surfaces.
- Avoid making sudden changes of direction when traveling as this causes wear and damage to the rubber track shoes.
- Avoid crossing differences in grade level on an angle. When crossing between different levels cross at right angles to the difference in level.
- When the arm and boom apparatus has been used to raise the machine, lower it gently.
- When the material to be handled is something that is oily when crushed (like beans, corn, or the sediment from making vegetable oil, do not use the vehicle or if used, wash it off with water following the operation.
- When the material to be handled is salt, ammonium sulphate, potassium chloride, or double superphosphate there will be substantial corrosion of parts so do not use the vehicle or if used wash it off with water follow the operations.
- Do not use for operations on the seacoast as there will be substantial corrosion of parts due to the salt.
- When handling salt, sugar, wheat or beans etc. and there are deep tears in the rubber track shoes, there is the danger that these things will get into lugs etc. through the tears in the rubber so repair these tears before carrying out the operation.
- Do not rub up against concrete levees.
- Though the track shoes are made of rubber, they will slip quite readily on compacted snow and frozen road surfaces. Be careful of sliding when performing operations on slopes or paved surfaces.
- The properties of the rubber in the track shoes will change in operations in extremely cold areas and will shorten their life.
- Use the rubber track shoes where the temperature range of the rubber will be from -25 to +55°C.
- Be careful not to hit the rubber track shoes with the bucket during operations.

- To prevent the rubber track shoes from coming off, always use them adjusted to the proper tension. When the tracks are loose they may come off in the following circumstances. Even when the tension is properly adjusted exercise sufficient caution.


1. Avoid rotating the arm and boom apparatus when there are large differences in grade like on curbs or crags (more than 20 cm). When traveling over differences in grade, approach them at 90° angles.




2. When climbing a slope in reverse and at the point where level ground meets the slope, do not rotate the arm and boom apparatus while climbing. When climbing a slope and you must rotate the boom do so slowly.



3. Do not travel with one track raised on a slope (with the machine inclined at 10° or more) and the other track on level ground. Travel with both tracks on the same surface so that you will not damage the rubber tracks.




4. Do not rotate the arm and boom apparatus when the rubber tracks are sagging or are as shown in the diagram on the right.




13. OPERATION

(The mechanism by which tracks come off)


1) A gap is created between the track roller and the rubber tracks when passing over things. Rubber tracks may come off at this time.




2) Traveling further in reverse there will be a gap between the track rollers, the idler and the rubber tracks.




- When the arm and boom apparatus has been rotated when the rubber tracks cannot move laterally because of the item over which the track is passing or some other item.
- When the idler and track roller get off due to the misalignment of the rubber tracks



• Rubber tracks will come off if you back up in this condition.



• Rubber tracks will come off if you rotate the apparatus while the machine is in this condition.



## 14. TRANSPORTING

Observe the pertinent regulations when transporting the vehicle and do so safely.

### 14.1 HOW TO LOAD AND UNLOAD THE VEHICLE

#### ⚠ Warning!

- Be particularly careful when loading and unloading the vehicle as this can be dangerous.
- Load and unload the vehicle after reducing the engine speed and move the vehicle slowly at low travel speed.
- Select a firm, level place for loading and make sure that it is a sufficient distance from the shoulder of the road.
- Use ramps that are of adequate strength and make sure that they are sufficiently wide, long and thick for safe loading and unloading. If the ramps are likely to bend significantly, reinforce them with blocks.
- Remove oil residues and foreign matter that may be stuck to the ramps so that the machine will not slide. Remove mud from around the tracks.
- Never correct the position of the tracks on the ramp while on the ramp. If you need to correct the position of the tracks, back off of the ramp, correct the position of the tracks and the remount the ramp.
- If you are going to rotate the boom while on the trailer, do so with caution as the machine's footing is unstable.

#### ⚠ Caution!


- Always make sure that the sliding door on vehicles that come with a cab is locked whether the door is open or closed.
- Always open or close the door when you are on level ground.
- The strength needed to open or close the door on a slope or on a ramp may vary suddenly so avoid trying to open or close it on an incline.

Always use ramps or a loading platform for loading and unloading and do so as follows:

1. Make sure that the trailer's brake is engaged. Block the wheels so that they cannot move. Fix the ramps in place and make sure that they are set so that the center of the machine and the trailer are aligned. Make sure that both the right and left ramps are of the same height.

Use the ramps so that the angle of incline is less than 15°.

Set the distance between the ramps so that the center of each track will be on the center of its ramp.





## 14. TRANSPORTING

---

2. Reduce engine rpm with the fuel adjustment control lever
3. Align the machine with the ramps and proceed slowly. Load and unload the machine with the arm and boom apparatus in as low a position as possible so that it does not hit the trailer. Do not use the accelerator pedal.

Do not use any other control levers other than the forward/reverse travel control lever.

4. Load the machine into the designated position on the trailer.

When the arm and boom apparatus is attached load the front end on first. When there is no arm and boom apparatus load the rear end first.


## 14.2 PRECAUTIONS WHEN CARRYING THINGS

After placing the machine in the designated position on the trailer, secure it as follows.


1. Lower the blade.
2. Fully extend the bucket and arm cylinders and then slowly lower the boom.
3. Stop the engine and remove the key from the ignition switch.

### NOTICE

To prevent damage to the bucket cylinder during transport of the vehicle, place a wedge under either end of the bucket cylinder so that it will not touch the bed of the trailer.



4. Lock each control lever with the locking lever.
5. To ensure that the machine will not move during transport, place wedges in front of and behind the tracks and secure the vehicle with chains or wire rope. Secure it firmly so that it will not slip to the side in particular.



## 14. TRANSPORTING

### 14.3 PRECAUTIONS WHEN TRANSPORTING

**Warning!**

- Take into consideration the width of the road, the height of obstacles on it and the weight that it can bear when selecting a route for transporting the vehicle.
- Always make sure that the door to the cab as well as both the right and left side covers are locked before transporting the vehicle.


#### NOTICE

Always retract the antenna of the car radio.

When transporting the vehicle consult Komatsu or your Komatsu distributor as there are the following regulations set by law.

#### Regulations

Total weight: Less than 20 tons  
See the diagram at right for height and width



## **15. HANDLING IN COLD WEATHER**

---

### **15.1 PREPARATION FOR LOW TEMPERATURES**

When temperatures drop, starting becomes more difficult and coolant freezes etc. so the following should be done.

#### **15.1.1 Fuel and lubrication**

Change to fuel and oil with low viscosity for all components. See item 21 "Use of fuel and lubricants according to ambient temperatures" for specific viscosities.

##### ■ Coolant

 **Warning!**

Coolant is flammable so keep flames away from it. Do not smoke when handling coolant.

#### **NOTICE**

**Do not use methanol, ethanol or propanol based anti-freeze.**

For details about when to change anti-freeze and the coolant mixture see 25.2 "Maintenance that is not regularly scheduled."

#### **Additional explanation**

Komatsu's special Supercoolant (AF-ACL) has been added to the coolant water and need not be changed as it is effective to -10°C.

When the temperature is expected to go below -10°C, see item 25.2 "Non-scheduled maintenance" and adjust the concentration accordingly.

## 15. HANDLING IN COLD WEATHER

---

### ■ Battery

**⚠ Warning!**

- Because batteries emit flammable gases, do not bring open flames close to them.
- Battery fluid is hazardous. Be careful so that it does not get in your eyes or on the skin. If it does, flush them with water and consult a physician.

When temperatures drop battery capacity drops. If the charge is low there is the danger that the battery fluid may freeze. Maintain the battery charge as close as possible to 100 per cent and be careful to maintain temperature to prepare for starting the following morning.

#### Additional explanation

Measure the specific gravity and calculate the rate of charge from the following table

Rate of charge (%)	Temperature of fluid (°C)			
	20	0	-10	-20
100	1.28	1.29	1.30	1.31
90	1.26	1.27	1.28	1.29
80	1.24	1.25	1.26	1.27
75	1.23	1.24	1.25	1.26

### 15.2 PRECAUTIONS AFTER COMPLETING OPERATIONS

In order to prevent things like mud and water and the undercarriage from freezing which make it impossible to move the machine the following morning, observe the following precautions.

- Remove mud and water etc. adhering to the machine. In particular try to prevent drops of water on the surface of the hydraulic cylinders and mud getting into the seals and damaging them.
- Park the vehicle on firm dry ground.  
If such a place is not available, put plywood planks down on the ground and park on them. This will prevent the ground surface and the undercarriage from freezing and the machine will be able to be moved the next morning.


- Open the drain cock and drain water accumulated in the fuel system to prevent it from freezing.
- Functioning of the battery drops markedly in cold temperatures. To maintain its temperature it should be covered or removed from the machine and placed in a warm place so that it can be re-installed the next morning.  
When the battery fluid level is low, fill the battery with distilled water the next morning prior to starting work. To prevent water in the battery from freezing do not add water at the end of the day after work is finished.

### 15.3 PREPARING THE CAR HEATER

Use the car heater when the temperatures get low.

To use the car heater, turn valve (1) which is attached to the water manifold to the left to open it.

When not using the car heater for long periods turn the valve (1) to the right and close it.



### 15.4 AFTER THE COLD WEATHER SEASON IS OVER

After the seasons change and temperatures get warmer, do the following.

- Change the oil and fuel of each component to the oil and fuel with recommended viscosity specified in item 21 "Use of fuel, coolant and lubricants according to ambient temperature."
- If you have had to use AF-PT anti-freeze (winter one season type), drain all of the anti-freeze from the cooling system, flush the system with water and fill with fresh water.


## 16. LONG-TERM STORAGE

---

### 16.1 BEFORE STORING THE MACHINE

#### NOTICE

Place the machine in the position shown in the diagram on the right to protect the cylinder rods when the machine is not being used. (Prevents the cylinder rods from rusting.)



Store the machine in the following manner when not using for a long time.

- Store inside a building after washing and cleaning each part. If the machine must be left outside, put it on level ground and cover it.
- Fill the fuel tank, grease the machine and change the oil.
- Cover the exposed portions of the piston rods of the hydraulic cylinders with grease.
- Disconnect the negative terminal of the battery and either cover the battery or remove it from the vehicle and store it elsewhere.
- Add anti-freeze to the coolant solution if the temperature will go below freezing. Normally Komatsu's special Supercoolant (AF-ACL) has been added to the coolant water and need not be changed as it is effective to  $-10^{\circ}\text{C}$ . When the temperature is expected to go below  $-10^{\circ}\text{C}$  see item 25.2 "Non-scheduled maintenance" and adjust the concentration accordingly.
- Lock each control lever and pedal with the locking lever and pedal locks.
- Place the stop valve on vehicles that can be fitted with attachments to the "locked" position. Install blind plugs in the elbows.
- Set the selector valve on vehicles that can be fitted with attachments to the "crusher and general attachments" position.

## 16.2 DURING STORAGE

**⚠ Warning!**

**When it is necessary to run the machine indoors to prevent the machine from rusting, open the windows and doors to improve ventilation to prevent poisoning from exhaust gases.**

While the machine is not being used, run the machine once a month, and ensure that parts that need lubrication are lubricated. Charge the battery at the same time. Also run the air conditioner.

## 16.3 AFTER STORAGE

### NOTICE

Consult with Komatsu or your Komatsu distributor if you intend to use the vehicle and have not run the machine once a month to prevent rusting.

When you intend to use the machine after long term storage, do so by handling the machine as follows.

- Wipe the grease off the hydraulic cylinder rods.
- Fill with oil and grease everything.
- Do not use trichloroethylene when washing the fuel tanks since the fuel tanks are plastic. Using trichloroethylene will weaken the fuel tanks.





# 17. TROUBLESHOOTING

## 17.1 PHENOMENA THAT ARE NOT BREAKDOWNS




The following phenomena are not breakdowns:

- 1) When the arm is pulled in, the arm will move slightly more slowly when it reaches a nearly vertical position.
- 2) The speed will drop momentarily when the teeth of the bucket are nearly horizontal.
- 3) Sounds will be emitted from the brake valves when the apparatus begins or finishes swinging.
- 4) Sounds will be emitted from the travel motor when descending a steep slope at low speed.




### ■ Phenomena that are not breakdowns of the 4 systems


- 1) Not being able to raise the boom, move the arm or offset to the left even though the apparatus has been moved from 5 to 10 cm forward or to the right after it has been automatically stopped.
- 2) Operating speed of the arm and boom apparatus being slow, after moving it forward about 50 cm after it has automatically stopped, even though the boom can be raised and the arm can be used for excavation. (You may not be able to raise the boom or move the arm for excavation when the engine is running at a low idle.)
- 3) When the apparatus stops automatically in the midst of returning to the original position after moving forward after it has automatically stopped in a left offset operation. (If the apparatus is offset 5 cm to the right, you can return to the original position.)




- 4) When the apparatus cannot be manipulated or be swung or operated in any way after the override switch has been activated when the controller makes a self-diagnosis when the apparatus moves toward the cab after it has been automatically stopped. (error code "91" is displayed)




- 5) When the position where the apparatus automatically stops is off when the apparatus angle sensor has been removed and re-installed.




- 6) When the teeth of the bucket are lowered to the ground and the depth displayed is not 0.0 m.



- 7) When the depth indicated by the position of the bucket is off.



- 8) When depth mode is set and the boom stops before it gets to the designated place (particularly when moving the boom slowly).



- 9) When the position where the apparatus stops is off when the accident prevention device and the automatic control device are activated in cold weather. (When the hydraulic fluid warms up, it will return to normal.)


## 17.2 HOW TO TOW WITH THE MACHINE OR BE TOWED.

**Warning!**

Use wire rope of sufficient strength for the weight to be towed.

If the machine gets stuck in the mud and cannot get out of its own power or when towing a heavy object with the machine use wire rope as is shown in the diagram at the right. Place wooden bumpers between the wire rope and the body to prevent damage to the body.

Do not use a hook for towing light weight objects to tow the vehicle.




## 17.3 HOW TO USE THE HOOK FOR TOWING LIGHT OBJECTS

**Warning!**

1. Always use a shackle.
2. The wire rope should be horizontal and should be aligned with the track frame.
3. Move the machine slowly.

The track frame has been equipped with a hook to pass a shackle for towing light objects.



## 17.4 PRECAUTIONS FOR SPECIAL JOB SITES

**Warning!**

Do not perform any operations that will immerse the sensors in water. If by some chance the sensors have been immersed check the operation of the automatic stop system. If there is a problem request inspection and repair service from Komatsu or your Komatsu dealer.


1. Grease the arm and boom apparatus mounting pins every time the machine is to be used in excavation in water.
2. Grease the arm and boom apparatus mounting pins every time the machine is to be used in heavy excavation or deep excavation operations.

After greasing, operate the boom, arm, bucket and blade several times and then grease the pins again.

## 17.5 WHEN THE BATTERY IS DEAD

**⚠ Warning!**

- Stop the engine and turn the key in the ignition switch to the OFF position when checking or handling the battery.
- Because batteries emit hydrogen gas there is the danger that an explosion might occur. Do not light cigarettes around batteries or do anything that would cause sparks.
- Battery electrolyte contains sulfuric acid and can burn the skin and ruin clothing. If you spill acid on yourself, immediately flush the area with water.
- If you get battery fluid in your eyes, flush them immediately with water and see a physician as soon as possible.
- Always wear safety glasses when handling batteries.
- When attaching the cables, attach the cable to the plus terminal first and conversely when removing the cables, remove the grounded cable (normally the negative terminal) first.
- Be careful so that there is no tool contacting both the positive terminal and the body of the vehicle as this will cause a spark and is dangerous.
- There is a danger of explosion from sparks caused by poor contacts when terminals are loose. When installing terminals, install them securely.
- Make sure you know which is the positive and which is the negative terminal when installing and removing terminals.




### 17.5.1 Starting the engine using booster cables

Observe the following procedure when starting the engine using booster cables

■ Precautions in connecting and removing booster cables

**Warning!**

- Never connect the positive terminal to the negative terminal when attaching cables
- Wear safety glasses when using booster cables to start the engine.
- When using another vehicle to start the engine make sure that the other vehicle does not touch your vehicle. Because batteries emit hydrogen gas there is the danger that an explosion might occur if sparks are generated near the battery.
- Do not make mistakes in connecting the booster cables. Never, ever connect a positive terminal with a negative terminal.
- The final connection should be to the frame of the rotating arm and boom. Make sure that this is as far from the battery as possible as this will cause a spark. (However, do not connect the cable to the arm and boom apparatus as conductivity is poor)
- When disconnecting booster cables, do not allow the respective clips of the two cables to contact each other or to contact the body of the machine.




**NOTICE**

- Use cables and clips of a size suitable for the battery.
- The battery of the assisting vehicle should be of the same capacity as that of the vehicle to be started.
- Check to see whether there is any damage or corrosion on the cable and clips.
- Fasten the clips securely so there is a good connection.

### ■ Connecting the booster cables

Put the ignition switch in the OFF position and connect the booster cables in accordance with the order of the numbers in the diagram.



1. Place the ignition switches of both vehicles in the OFF position.
2. Connect the clip of booster cable (A) to the positive terminal of the battery of the vehicle with a dead battery.
3. Connect the clip at the other end of booster cable (A) to the positive terminal of the battery of the assisting vehicle.
4. Connect the clip of booster (B) to the negative terminal of the battery of the assisting vehicle.
5. Connect the clip at the other end of booster cable (B) to the engine block of the vehicle with a dead battery.

### ■ Starting the engine


1. Check to make sure that the clips of the booster cables are securely fastened to the battery terminals
2. Start the engine of the assisting vehicle and run it at full throttle.
3. Turn the ignition switch of the vehicle with a dead battery to the START position and start the engine.

See item 13.2 "Starting engine"

### ■ Disconnecting booster cables

After the engine has started disconnect the booster cables in the reverse order that they were connected.

1. Remove the clip of booster cable (B) that was connected to the engine block of the vehicle that had a dead battery.
2. Remove the clip at the other end of booster cable (B) that was connected to the negative terminal of the battery of the assisting vehicle.
3. Remove the clip of booster cable (A) that was connected to the positive terminal of the battery of the assisting vehicle.
4. Remove the clip at the other end of booster cable (A) that was connected to the positive terminal of the battery of the vehicle that had a dead battery.



## 17.6 WHEN THIS PHENOMENON OCCURS

### 17.6.1 Electrical system

- Always contact Komatsu or your Komatsu Distributor for remedies that are in parentheses.
- For other problems or for problems which you think have causes other than those listed below, contact Komatsu or your Komatsu distributor for service.

Problem phenomenon	Chief cause	Remedy
Monitor light is dim even when engine runs at maximum RPM	<ul style="list-style-type: none"> <li>• Defective wiring</li> </ul>	<ul style="list-style-type: none"> <li>(• check for loose terminals, repair disconnected wires)</li> </ul>
Light flickers while engine is running	<ul style="list-style-type: none"> <li>• Fan belt tension not properly adjusted</li> </ul>	<ul style="list-style-type: none"> <li>• Refer to maintenance to be done every 250 hours of operation and adjust fan belt tension</li> </ul>
The charge level monitor light stays lit even when the engine is running.	<ul style="list-style-type: none"> <li>• Defective alternator</li> <li>• Defective wiring</li> </ul>	<ul style="list-style-type: none"> <li>(• Replace)</li> <li>(• Inspect, repair)</li> </ul>
Abnormal noise from the alternator	<ul style="list-style-type: none"> <li>• Defective alternator</li> </ul>	<ul style="list-style-type: none"> <li>(• Replace)</li> </ul>
Starter does not turn over when the ignition switch is turned to start	<ul style="list-style-type: none"> <li>• Defective wiring</li> <li>• Insufficient battery charge</li> </ul>	<ul style="list-style-type: none"> <li>(• Inspect, repair)</li> <li>• Charge</li> </ul>
Pinion of starter motor repeatedly goes in and out (noisily)	<ul style="list-style-type: none"> <li>• Insufficient battery charge</li> </ul>	<ul style="list-style-type: none"> <li>• Charge</li> </ul>
Starter motor turns over engine slowly	<ul style="list-style-type: none"> <li>• Insufficient battery charge</li> <li>• Defective starter</li> </ul>	<ul style="list-style-type: none"> <li>• Charge</li> <li>(• Replace)</li> </ul>
Starter motor disengages before engine starts running	<ul style="list-style-type: none"> <li>• Defective wiring</li> <li>• Insufficient battery charge</li> </ul>	<ul style="list-style-type: none"> <li>(• Inspect, repair)</li> <li>• Charge</li> </ul>
Preheat monitor light does not come on.	<ul style="list-style-type: none"> <li>• Defective wiring</li> <li>• Defective monitor light</li> </ul>	<ul style="list-style-type: none"> <li>(• Inspect, repair)</li> <li>(• Replace)</li> </ul>
Oil pressure monitor light does not come on when the engine is stopped (when the ignition key is in the ON position)	<ul style="list-style-type: none"> <li>• Defective monitor light</li> <li>• Defective oil pressure switch</li> </ul>	<ul style="list-style-type: none"> <li>(• Replace)</li> <li>(• Replace)</li> </ul>
When the exterior of the electric heater is not warm when touched with the hand	<ul style="list-style-type: none"> <li>• Defective wiring</li> <li>• Disconnected wire in electric heater</li> <li>• Defective operation of heater relay switch</li> </ul>	<ul style="list-style-type: none"> <li>(• Inspect, repair)</li> <li>(• Replace)</li> <li>(• Replace)</li> </ul>



**17.6.2 General problems with the machine**

- Always contact Komatsu or your Komatsu Distributor for remedies that are in parentheses.
- For other problems or for problems which you think have causes other than those listed below, contact Komatsu or your Komatsu distributor for service.

Problem phenomenon	Chief cause	Remedy
Travel speed, swing speed, speed of the boom, arm and bucket are slow	<ul style="list-style-type: none"> <li>• Insufficient hydraulic fluid</li> </ul>	<ul style="list-style-type: none"> <li>• Add oil to the specified level, see checks before beginning operations</li> </ul>
Abnormal sound coming from pump	<ul style="list-style-type: none"> <li>• Clogged strainer element in hydraulic fluid tank</li> </ul>	<ul style="list-style-type: none"> <li>• See 2000 hour service, clean</li> </ul>
Temperature of hydraulic fluid gets too hot	<ul style="list-style-type: none"> <li>• Loose fan belt</li> <li>• Dirty oil cooler</li> <li>• Insufficient hydraulic fluid</li> </ul>	<ul style="list-style-type: none"> <li>• See 250 hour service, adjust fan belt tension</li> <li>• See 500 hour service, clean</li> <li>• Add oil to the specified level, see checks before beginning operations</li> </ul>
Tracks come off	<ul style="list-style-type: none"> <li>• Tracks are too loose</li> </ul>	<ul style="list-style-type: none"> <li>• See maintenance that is not regularly scheduled, adjust tension</li> </ul>
Abnormal wear on the sprocket		
Bucket rises slowly or does not rise at all	<ul style="list-style-type: none"> <li>• Insufficient hydraulic fluid</li> </ul>	<ul style="list-style-type: none"> <li>• Add oil to the specified level, see checks before beginning operations</li> </ul>

### 17.6.3 Engine

- Always contact Komatsu or your Komatsu Distributor for remedies that are in parentheses.
- For other problems or for problems which you think have causes other than those listed below, contact Komatsu or your Komatsu distributor for service.

Problem phenomenon	Chief cause	Remedy
Engine oil pressure monitor light comes on	<ul style="list-style-type: none"> <li>• Insufficient oil in the oil pan (taking in air)</li> <li>• Oil filter cartridge is clogged</li> <li>• Leaks due to defective or loose connections in the oil lines or damage in the oil lines</li> <li>• Defective oil pressure sensor</li> <li>• Defective monitor</li> </ul>	<ul style="list-style-type: none"> <li>• Refer to checks before starting operation and add oil to the specified level</li> <li>• Refer to the service that should be done every 250 hours and replace the cartridge</li> <li>(• Inspection, repair)</li> <li>(• Replace sensor)</li> <li>(• Replace)</li> </ul>
<p>Steam escaping from the upper portion of the radiator (the pressure valve)</p> <hr/> <p>The radiator coolant temperature gauge red light comes on.</p>	<ul style="list-style-type: none"> <li>• Coolant level low, leaks</li> <li>• Loose fan belt</li> <li>• Accumulation of dirt and scale in the cooling system</li> <li>• Clogging of radiator fins, or damaged fins</li> <li>• Defective thermostat</li> <li>• Loose radiator filler cap (when operating at high altitudes)</li> </ul>	<ul style="list-style-type: none"> <li>• Refer to checks before starting operation and add coolant mixture to the specified level</li> <li>• Refer to the service that should be done every 250 hours and adjust the tension of the fan belt</li> <li>• Refer to maintenance that is not regularly scheduled, replace coolant mixture, flush cooling system</li> <li>• Refer to service that should be done every 500 hours, clean and repair</li> <li>(• Replace thermostat)</li> <li>• Tighten cap or replace packing</li> </ul>
Though the engine has been operated for a long time, the white light of the engine coolant temperature gauge is on.	<ul style="list-style-type: none"> <li>• Defective thermostat</li> </ul>	(• Replace thermostat)
The engine will not start when the starting motor is cranked.	<ul style="list-style-type: none"> <li>• Out of fuel</li> <li>• Air in the fuel system</li> <li>• Defective fuel injection pump or nozzles</li> <li>• Starter cranks engine slowly</li> <li>• Preheat monitor light does not come on</li> <li>• Insufficient compression <ul style="list-style-type: none"> <li>◦ Poor valve clearance</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>• Refer to checks before starting operation and add fuel</li> <li>• Refer to the service that should be done every 500 hours and repair the spot where air is getting into the system</li> <li>(• Replace pump or nozzles)</li> <li>} See electrical system</li> <li>◦ Adjust valve clearance</li> </ul>

## 17. TROUBLESHOOTING

### Continuation of engine (17.6.3)

Problem phenomenon	Chief cause	Remedy
Exhaust gas is tinted white or blue	<ul style="list-style-type: none"> <li>● Excess oil in oil pan</li> <li>● Defective or improper fuel</li> </ul>	<ul style="list-style-type: none"> <li>● Refer to checks before starting operation and add oil to the specified level</li> <li>● Replace with specified fuel</li> </ul>
Exhaust gas occasionally is black	<ul style="list-style-type: none"> <li>● Clogged air cleaner element</li> <li>● Defective nozzle</li> <li>● Insufficient compression</li> <li>● Defective turbocharger</li> </ul>	<ul style="list-style-type: none"> <li>● Refer to maintenance that is not regularly scheduled, clean or replace</li> <li>(● Replace nozzle)</li> <li>(● Adjust valve clearance)</li> <li>● Clean or replace turbocharger</li> </ul>
Gasping occasionally heard in combustion sound	<ul style="list-style-type: none"> <li>● Defective nozzle</li> </ul>	<ul style="list-style-type: none"> <li>● Replace with specified fuel</li> </ul>
Abnormal sounds (combustion or mechanical)	<ul style="list-style-type: none"> <li>● Low grade fuel</li> <li>● Overheating</li> <li>● Defective muffler</li> <li>● Excessive valve clearance</li> </ul>	<ul style="list-style-type: none"> <li>● Refer to maintenance that is not regularly scheduled, replace coolant mixture, flush cooling system</li> <li>● Refer to service that should be done every 500 hours, clean and repair</li> <li>(● Replace thermostat)</li> <li>● Tighten cap or replace packing</li> <li>● Replace muffler</li> <li>(● Adjust valve clearance)</li> </ul>

### 17.6.4 4 systems

When an error code is displayed in the depth display portion of the monitor panel, follow the chart shown below for self-diagnosis and handling these problems.

Self diagnosis and corresponding countermeasures

Error code	Phenomenon with machine	Presumed cause	Measures to be taken	
S e r v i c e r e r m	31	● Cannot move arm and boom apparatus in direction of obstruction (raising boom, diggin with arm, left offset)	Have it checked immediately after moving the apparatus and machine to a safe place with the override switch.	
	32			
	34			
41	● Swing speed does not go down even though engine rpm have been reduced (maximum pump flow)	Defective engine RPM sensor	May continue operations as is but should be checked immediately.	
e r r o r s / O n l y F i s t e m	51	● Cannot operate the arm and boom apparatus at all ● Cannot swing the superstructure and arm and boom apparatus	Defective base pressure lock solenoid	Have it checked immediately after moving the apparatus and machine to a safe place with the override switch. However, there may be times depending on what is wrong that the apparatus cannot be moved even though the override switch is ON. If this is the case have it checked immediately.
	52	● Cannot move arm and boom apparatus in direction of obstruction	Defective offset lock solenoid	
	54	● Cannot swing the superstructure and arm and boom apparatus (swing park brake ON stays ON)	Defective swingbrake lock solenoid	Have it checked immediately.
	61	Swing speed does not go down even though engine rpm have been reduced (maximum pump flow)	Defective LS, EPC solenoid	May continue operations as is but should be checked immediately.
	62	Raising the boom while traveling significantly affects traveling	Defective LS bleed-off solenoid	
	64	When the power digging switch (optional) is actuated, nothing happens	Defective 2 stage relief solenoid (optional)	
	68	No automatic deceleration (optional)	Defective automatic deceleration relay	
E P C	71	Cannot move arm and boom apparatus in direction of obstruction	Defective boom raising EPC solenoid	Have it checked immediately after moving the apparatus and machine to a safe place with the override switch. However, there may be times depending on what is wrong that the apparatus cannot be moved even though the override switch is ON. If this is the case have it checked immediately.
	72	Cannot lower boom	Defective boom lowering EPC solenoid	

## 17. TROUBLESHOOTING

### Continuation of Self diagnosis and corresponding countermeasures

Error code	Phenomenon with machine	Presumed cause	Measures to be taken
E P C  e r r o r  E l e m e n t s  d i s t i n g	74	Much shock when swing to the left is stopped quickly	May continue operations as is but should be checked immediately.
	78	Much shock when swing to the right is stopped quickly	
	81	Cannot move arm and boom apparatus in direction of obstruction	Have it checked immediately after moving the apparatus and machine to a safe place with the override switch. However, there may be times depending on what is wrong that the apparatus cannot be moved even though the override switch is ON. If this is the case have it checked immediately.
	91	Cannot operate the arm and boom apparatus at all	By using the override switch, you can move the bucket forward or to the right, cancel self-diagnosis and can operate the apparatus but you should have it checked immediately.
When you cannot operate the arm and boom apparatus at all or swing the superstructure or when there significant shock when stopping the superstructure from swinging and no error codes are displayed.			Have it checked immediately.

# **CHECKS AND MAINTENANCE**

## **18. PRECAUTIONS IN PERFORMING CHECKS AND MAINTENANCE**

---

Do not perform any checks or maintenance operations other than those specified in this manual.

Park the machine on firm, level ground before performing inspections and maintenance operations.

**Check the service meter:**

Check the service meter every day to see if the time has come for any necessary maintenance to be performed.

**Genuine Komatsu parts (for replacement parts):**

Use genuine Komatsu replacement parts specified in the Parts List for replacement parts.

**Genuine Komatsu Oils (for lubrication):**

Use genuine Komatsu oils for lubrication. Use products with the proper viscosity specified according to ambient temperature.

**Use clean washer fluid:**

Use washer fluid for use in automobiles and ensure that dirt and foreign matter do not get in it.

**Use clean oil and grease:**

Use clean oil and grease, and keep containers and grease guns clean so that dirt and foreign materials cannot get mixed with oil and grease.

**Keep the machine clean:**

Wash the machine and keep it clean so that problems with components can be easily diagnosed. In particular, keep grease fittings, breathers and oil level gauges clean. Keep dirt from getting mixed into the oil and grease.

**Be careful of hot water and oil:**

Draining oil and water and changing filters immediately after stopping the machine while it is still hot is dangerous. Wait until the temperature of the engine has cooled down before doing these tasks. Conversely, if the oil has to be drained when it is cold, warm up the engine some and then drain it. (approximately 20 to 40°C.

**Check the drained oil and filters:**

After changing oil and filters, check the oil that was drained and the filter that was replaced to make sure that there were no large quantities of metal particles or other foreign matter.

**Precautions when adding oil:**

If your machine is equipped with a strainer over the filler port, do not remove this strainer while filling the machine with oil

**Be careful so that dirt does not get in:**

Check the oil and replace the filters in places where there is not likely to be much dust and prevent dirt and other foreign matter from getting in.

**Attach Warning tags:**

Put a warning tag in the cab to prevent others from mistakenly starting the machine when the oil and water have been drained from it.

**Observe all precautions:**

Observe the precautions that are indicated on the machine when performing maintenance operations on it.

**Precautions when repairing by welding:**

- Turn off power (turn off ignition switch)
- Do not apply more than 200 V continuously
- Have a ground within 1 meter of the component to be welded
- Do not have bearings or seals etc., between the portion to be welded and the ground
- Do not place the ground near the pins of the arm and boom apparatus or on the hydraulic cylinders.

**Be careful of fire:**

Use a nonflammable cleaner or a light oil for cleaning parts. If you use light oil, keep cigarettes or flames away.

**Keep clamped faces clean:**

When components that have O-rings and gasket seals are uncoupled, keep the facing portions clean and replace O-rings and gasket seals with new one.

**Do not allow things in your pockets to fall into the machine:**

Remove objects from your pockets so that they will not fall into the innards of the machine when you remove the covers and are bending over doing inspections and performing maintenance.

**Check the undercarriage:**

Be on the lookout for damage to the undercarriage, loose nuts and bolts, cracks, wear and dents when working in an area with many rocks and boulders and slacken the track tension slightly.



## 18. PRECAUTIONS IN PERFORMING CHECKS AND MAINTENANCE

### **Precautions when washing the vehicle:**

- Never spray steam directly on mechatronic parts or connectors.
- Do not get water on the controllers or monitor panel in the cab.
- Do not direct high pressure washer at the radiator or oil cooler.
- The left side of the cab, the overhead window and the back of the cab are made of acrylic so do not wipe these areas with dirty rags, or chemicals (thinner, gasoline, etc.) If they accidentally are torn, rub them with compound. When cleaning, wash off mud and dust etc. with clean rag while flushing with water.
- Since the fuel tank is made of plastic, do not use trichloroethylene when washing it. This will make it deteriorate.

### **Checks and inspections prior to and after work:**

Make sure that all plugs and cocks are tightly in place prior to conducting operations in mud, rain, on the seashore or in snow. After finishing work, wash the machine, check to see whether there is cracking, damage, or whether there are loose nuts and bolts or if they have come off. Lubricate each component and in particular lubricate pins for the arm and boom apparatus daily that will be under water.

### **When working in dusty work sites:**

Observe the following precautions when working in places where there is much dust.

- Check carefully with a dust indicator to see whether the air cleaner is blocked. Clean the air cleaner element frequently.
- Clean the radiator core frequently to ensure that it will not get clogged.
- Clean and replace the fuel filter frequently.
- Clean the electrical components, particularly the starter and the alternator so that dust does not accumulate.

### **Do not mix oils:**

Never mix oils made by different manufacturers or types of oil. When adding oil change all of the oil.

## 19. BASIC MAINTENANCE

---

- Use genuine Komatsu parts for replacement
- Do not use different oils when adding oil or changing oil
- Unless otherwise specified, the oil and coolant used when the vehicle is shipped from the factory will be as shown in the table below.

Item	Type
Engine oil	SAE 15W-40, Classification CD
Swing machinery Final drive case PTO gear case	SAE 30, Classification CD
Hydraulic tank	SAE 10W, Classification CD
Fuel	JIS 2, in winter (October -March) JIS 3
Radiator	Komatsu Super Coolant (AF-ACL) 41 % water added

### 19.1 ESSENTIAL INFORMATION ON OIL, FUEL AND COOLANT

#### 19.1.1 Oil

- Oil is used in the engine and the arm and boom apparatus under extremely severe conditions (high temperature, high pressure) and it deteriorates with use.  
Always use an oil that matches the grade and temperature use range specified in the manual.  
Always change the oil at the specified interval even if it is not dirty.
- Pay careful attention and handle oil so that impurities (water, iron filings, dirt etc.) do not get in it. Think of it as corresponding to blood in the human body.  
Most mechanical problems are traceable to impurities in the oil.  
Pay particular attention to keeping out foreign matter when storing or when adding oil.
- Do not mix different grades or different brands of oil.

## 19. BASIC MAINTENANCE

---

- Always add the specified amount of oil.  
Too much oil as well as too little oil will cause problems.
- If the oil is cloudy or murky, air or water may be getting into the system. Consult with Komatsu or your Komatsu dealer.
- Always replace the filter when changing oil.
- We recommend that you periodically have the oil analyzed in order to ascertain the condition of the vehicle. If you would like to have this done please contact Komatsu or your Komatsu dealer.
- When the vehicle is shipped from the factory, it comes equipped with SAE10WCD oil in the hydraulic system. If you wish to use HO46-HM hydraulic oil change all of the oil in the system and replace with the specified amount of oil. Do not use oils other than those recommended by Komatsu as these will cause the filters to become clogged.  
If the new oil is mixed with the amount of oil remaining in the lines and cylinder this will not cause a problem.

Hydraulic oil HO46-HM specified brands are as follows

Name of Manufacturer	Name of oil product
Esso Petroleum	Unipower SQ46K
Cosmo Petroleum	Cosmo Hydro KW46
General Petroleum	General Hydrofluid KM46
Mobil Petroleum	Mobil DTE25
Nippon Kogyo Petroleum	Hydrak K46
Mitsubishi Petroleum	Diamond Power Hydro 46
Showa Shell Petroleum	Hydroconto oil K
Nippon Sun Petroleum	SUN VIS846
Fuji Kosan	Fukkol super hydro K46
Kygnus Petroleum	Unit oil WR46

### 19.1.2 Fuel

- The fuel pump is a precision instrument and will not operate properly if you use fuel that contains water and foreign matter.
- Be careful so that impurities do not get into the fuel when storing or taking on fuel.
- Always use the fuel specified in the Operation and maintenance manual. Since fuel will tend to thicken depending on the temperature at which it is used (particularly at low temperatures below  $-15^{\circ}\text{C}$ ), you will need to change to a fuel which matches the temperature.
- Top off the fuel tank every day at the end of work to ensure that water does not get into the fuel from air in the fuel tank containing moisture that condenses.
- Before starting the engine or after about 10 minutes have passed after refueling, drain water and sediments from the fuel tank.
- When you have replaced the fuel filter or have accidentally run out of fuel you will need to bleed air from the fuel lines.

### 19.1.3 Coolant

- River water contains calcium and other impurities. If this is used, scale will build up in the engine and radiator leading to faulty heat exchange and may cause over heating. Do not use water that is not suitable for drinking.
- Observe precautions noted in this manual when using anti-freeze.
- Komatsu's vehicles are shipped with Komatsu's special anti-freeze in the coolant. This anti-freeze is also effective in preventing the corrosion of the parts in the cooling system. This anti-freeze may be used for 2 years or for 4000 hours of continuous use. Thus, it may also be used in hot climates.
- Be careful of flames because anti-freeze is flammable.
- The mixture to be used of anti-freeze and water will vary depending on the temperatures to be expected. See item 25.2.2 "Flushing the cooling systems"
- If overheating has occurred, replenish the coolant mixture after the engine has cooled down.
- Insufficient coolant in the cooling system will cause overheating and will also lead to corrosion of the parts of the system due to air in the system.

### 19.1.4 Grease

- Grease prevents wear in joints and noise from being emitted from them.
- Nipples not included in the regular maintenance section of the manual do not need to be greased as they are nipples for overhaul. However, if a joint becomes sluggish after being the machine has been used for a long time, grease it.
- Wipe off old grease that has been forced out during greasing operations. Be especially careful to wipe off grease from places where wear on moving parts will be accelerated by the adhesion of sand and dirt.

### 19.1.5 Storing oil and fuel

- Store fuel and oil inside where moisture, dirt and other impurities are not likely to get in.
- If you store drums for long periods, place them on their sides so that opening to the drum will be on its side. (This will prevent moisture from getting in. If you have to store the drums outside, be particularly careful and cover the drums with a waterproof sheet etc.
- To prevent deterioration of the oil in long term storage, follow the first in, first out practice of using the oldest oil first.

### 19.1.6 Filters

- Filters are very important safety valves that prevent trouble from occurring from impurities in oil, fuel and air lines from getting into important instruments. Change them regularly in accordance with the Operation and Maintenance manual. When operating in severe work environments, it is necessary to change them more frequently depending on the oil and fuel (sulphur content) being used.
- Never clean filters (cartridge type) and use them again.
- When changing filters check the old filter that has been removed for iron filings etc. Consult with Komatsu or your Komatsu dealer if you find iron filings or other foreign matter on the filter.
- Do not open the packages of replacement filters until immediately prior to use.
- Always use genuine Komatsu filters.

## 19.2 SUMMARY OF ELECTRICAL SYSTEM

- If electrical parts get wet or their insulation is damaged they will be very dangerous as they will leak electricity and cause improper operation and malfunction of the machine.
- Checks and maintenance of the electrical system involve checking fan belt tension, making sure that there is no damage to the belts and checking the level of fluid in the battery.
- Do not under any circumstances remove instruments (electrical parts) or disassemble instruments that have been installed in the machine.
- Do not install any electrical components other than those that have been provided by Komatsu.
- Ensure that electrical components do not get wet when washing the vehicle or when it rains.
- Since the controller for the 4 systems will malfunction due to interference from external radio frequencies, consult with Komatsu or your Komatsu distributor before installing a wireless device in your machine.
- Maintain the electrical system carefully when operating on or near the seashore to prevent corrosion.
- Do not connect an optional power source to fuses, starter switches or battery relays, etc.

### 19.3 SUMMARY OF HYDRAULIC SYSTEM

- The hydraulic system will be hot during operation and after finishing operations. Pay attention to the following items when performing checks and maintenance on the hydraulic system since the system is also under high pressure while in operation.
  - Park on level ground and lower the bucket to the ground so that there will not be pressure in the cylinder lines.
  - Always stop the engine.
  - Begin maintenance operations after the oil temperature has gone down in each component since hydraulic fluid and lubricating oils will be hot and under high pressure immediately after ceasing operations. Remove plugs and screws slowly and loosen hose connections slowly, keeping them away from your face and body to release pressure since there still may be some pressure even though the temperature has gone down.
  - Always bleed the air from the hydraulic fluid tank to release pressure when inspecting or repairing hydraulic lines.
- Checks and maintenance of the hydraulic system involve checking the level of hydraulic fluid, replacing filters and replacing hydraulic fluid.
- When uncoupling high pressure hoses, check the O-rings for damage and replace them if they are damaged.
- It is necessary to bleed the air from the circuits after you have replaced and cleaned the hydraulic fluid filter element/ strainer or have repaired, replaced hydraulic instruments or removed hydraulic lines.

## 20. CONSUMABLE SUPPLIES

Replace parts that are to be replaced regularly like filter elements and bucket teeth etc. during regularly scheduled maintenance or before they reach their limits of wear. Make the machine more cost-effective by making sure that parts are replaced regularly. Use superior genuine Komatsu replacement parts. Check the part number with the parts list when requesting parts.

### List of regularly replaced parts

Items in parentheses indicate other parts that should be replaced at the same time

Item	Part number	Name of part	Quantity	Frequency of replacement
Hydraulic oil filter	07063-0110 (07000-05155)	Element (O-ring)	1 (1)	Every 250 hours
Engine oil filter	600-211-5241	Cartridge	1	Every 250 hours
Fuel filter	600-311-8221	Cartridge	1	Every 500 hours
Air cleaner	600-181-9460	Single element	1	—
Additional filter for breaker (Optional for monoboomb)	203-973-5820	Element (including O-ring)	1 (1)	—
Electric heater	6136-11-4820	Gasket	2	—
Bucket	205-70-74272 (205-70-74281) (205-70-74291)	Vertical pin type tooth (Pin) (Lock)	4 (4) (4)	—
Bucket	202-70-63161 202-70-63171 (208-32-11231) (01803-02228)	Side cutter (left) Side cutter (right) (Bolt) (Nut)	1 1 (8) (8)	—
Bucket	205-70-19570 (09244-02496)	Horizontal pin type Tooth (Pin)	4 (4)	—
Blade	21Y-71-11C90	Edge	1	—



## 21. USAGE OF FUEL AND LUBRICATING GREASE ACCORDING TO AMBIENT TEMPERATURE

### 21.1 FUEL/ OIL

Use them in accordance with the table below.

The prescribed amount of oil is the total amount of oil including the amount in oil lines of each device etc. The change amount is the amount of oil to be changed during checks and maintenance.

When starting the engine at temperatures below 0°C always use SAE10W, SAE10W-30 or SAE15W-40 even when the temperature will rise to 10°C during the day.

### 21.2 COOLANT

Genuine Komatsu Supercoolant (AF-ACL) has been added to the coolant fluid so that there is no need to change it if the temperature does not go below -10°C.

When the temperature goes below -10°C, see item 25.2 of the manual " Maintenance that is not regularly scheduled" and adjust the concentration accordingly.


Reservoir	Type of fluid	Temperature °C								(ℓ) Refill	(ℓ) Change amount
		-30	-20	-10	0	10	20	30	40		
Engine oil pan	Engine oil				SAE30CD				12	11	
			SAE10W CD								
			SAE10W-30CD								
			SAE15W-40CD								
Swing machinery case	Engine oil								2.5	2.5	
Final drive case			SAE30CD							Left, right each 2.5	Left, right each 2.5
PTO gear case										0.75	0.75
Hydraulic oil system	Engine oil		SAE10W CD							140	92
			SAE10W-30CD								
			SAE15W-40CD								
	Hydraulic oil		HO46-HM*								
Fuel tank	Light oil		JIS number 2							135	-
			JIS number 3								
			JIS number 3								
Cooling system	Water	Add Genuine Komatsu Supercoolant (AS-ACL)								15.7	-

\*Note: For HO46-HM use oils recommended by Komatsu. For the change amount see item 19.1.1 "Oil".

## **22. STANDARD TIGHTENING TORQUES FOR BOLTS AND NUTS**

### **22.1 LIST OF TOOLS NECESSARY**

The following tools are necessary when performing maintenance.

	Name of tool	Part number	Remarks
1	Wrench	09002-01417 09002-01922 09002-02427 09002-03032	Sizes 14mm-17mm 19mm-22mm 24mm-27mm 30mm-32mm 
2	Screwdriver	09033-00190	Interchangeable flat-head Phillips head type
3	Socket wrench set	09020-10286	Sizes 10mm, 13mm, 14mm, 17mm 19mm, 22mm, 24mm Extension, Handle
4	Wrench	09002-03641	Sizes 36mm-41mm
5	Hexagon wrench	09007-01040 09007-00836	Sizes 10mm Sizes 8mm
6	Filter wrench	09019-10080	For fuel filter cartridge
7	Filter wrench	09019-10093	For engine oil filter cartridge
8	Grease gun	07952-70002	For greasing work
9	Nozzle	203-98-61110	For rubber track shoes (only for vehicles with rubber track shoes)
10	Grease cartridge	07950-90403	(Lithium type grease, 400 g.)

When any of the tools listed above are broken or lost, order replacements from Komatsu or your Komatsu dealer.


## 22.2 TORQUE TABLE

Unless specified elsewhere, tighten metric bolts and nuts to the torque shown in the table.

The width across the flats (b) of bolts and nuts determines the applicable tightening torque.

Always use a genuine Komatsu replacement part of the same size as the one being replaced when it becomes necessary to replace a bolt or nut.

(mm) (a) Thread diameter of bolt	(mm) (b) Width across flat	Tightening torque (kgm)	
		Desired value	Allowable range
6	10	1.35	1.2-1.5
8	13	3.2	2.8-3.5
10	17	6.7	6.0-7.5
12	19	11.5	10.0-12.5
14	22	18.0	16.0-20.0
16	24	28.5	25.0-31.5
18	27	39.0	35.0-43.5
20	30	56.0	50.0-62.0
22	32	76.0	67.5-84.5
24	36	94.5	84.0-105.0
27	41	135.0	120.0-150.0
30	46	175.0	155.0-195.0
33	50	225.0	200.0-250.0
36	55	280.0	250.0-310.0
39	60	335.0	295.0-370.0



### NOTICE

Be cautious when tightening bolts or nuts on panel fixtures which are made of resins as tightening them too much will damage the fixtures.

## 23. ABOUT REGULAR REPLACEMENT OF IMPORTANT COMPONENTS

---

We request that those using the machine always perform regular maintenance on it to ensure safety at all times, during operations or when driving it. In order to improve safety further, we also request that the parts listed on the important components list on the following page be replaced on a regular basis, particularly those relating to fire prevention.

The materials in these parts change with the passage of time and tend to deteriorate or wear. Since it is difficult to judge how much this has occurred from periodic service, even though there may be nothing recognizably wrong with the parts, it is necessary to replace them with new ones after they have been used for a designated period of time to ensure that they will function properly at all times. Nonetheless, if these parts show abnormalities prior to the time they are scheduled to be replaced they should be repaired or replaced as always.

Replace hose clamps at the same time as hoses if they are bent, have cracks or show signs of deterioration.

Perform the following inspections on hoses other than those which are regularly replaced and if something is abnormal, tighten them or replace them etc.

Replace O-rings, and gaskets at the same you replace hoses.

Rely on Komatsu or your Komatsu dealer to replace important components.


Inspect the hydraulic oil hoses and fuel hoses at the time of the following regular scheduled checks.

Category of check	Items to be checked
Check before starting operations	<ul style="list-style-type: none"><li>● Connectors of fuel and hydraulic hoses/ leaks from caulked portions</li></ul>
Monthly check	<ul style="list-style-type: none"><li>● Connectors of fuel and hydraulic hoses/ leaks from caulked portions</li><li>● Damage to fuel and hydraulic hoses (cracks, wear, nicks)</li></ul>
specific independent checks (Annual checks)	<ul style="list-style-type: none"><li>● Connectors of fuel and hydraulic hoses/ leaks from caulked portions</li><li>● Fouling, tears, deteriorations, kinks, damage, (cracks, abrasions, nicks) in fuel and hydraulic hoses</li></ul>


## 23. ABOUT REGULAR REPLACEMENT OF IMPORTANT COMPONENTS

### ■ List of important components

No.	Regularly replaced item	Qty	Frequency of replacement
1	Fuel hose (fuel tank to fuel injection pump)	1	Every 2 years or every 4000 hours whichever comes first
2	Fuel hose (fuel injection pump to fuel filter)	2	
3	Fuel hose (fuel injection pump to fuel cooler)	1	
4	Fuel hose (fuel cooler to fuel tank)	1	
5	Fuel hose (fuel tank to fuel filler port)	4	
6	Overflow hose (nozzle to fuel tank)	1	
7	Overflow hose (between nozzles)	3	
8	Overflow cap	1	
9	Hydraulic hose (main pump delivery)	1	
10	Hydraulic hose (control pump delivery)	1	



AM001130



AM001110

## 24. LIST OF MAINTENANCE

### 24.1 MAINTENANCE SCHEDULE

Item to be Serviced	Page
<b>■ Service after the initial 250 hours (first service performed only once on new vehicle)</b>	
Replace fuel filter cartridge	3-60
Check and adjust engine valve clearance	3-74
<b>■ Maintenance that is not regularly scheduled</b>	
Check, clean or replace air cleaner element	3-21
Flush cooling system	3-23
Check electric heater	3-27
Check and tighten track bolts (for steel track machines)	3-27
Check and adjust track tension (for steel track machines)	3-28
Check rubber track shoes (for rubber track machines)	3-31
Check and adjust track tension (for rubber track machines)	3-33
Replace rubber track shoes (for rubber track machines)	3-35
Replace bucket teeth (vertical pin type)	3-38
Replace bucket teeth (horizontal pin type)	3-41
Adjust bucket clearance	3-42
Check and repair air conditioner	3-43
Check and replenish window washer fluid (optional)	3-44
<b>■ Checks before beginning operation</b>	
Check and replenish coolant	3-45
Check and replenish engine oil	3-45
Check amount of fuel	3-46
Check and replenish hydraulic fluid in tank	3-47
Check dust indicator	3-48
Check electrical system	3-48
<b>■ Service every 50 hours</b>	
Drain water and sediment from fuel tank	3-49
<b>■ Service every 100 hours</b>	
Grease blade cylinder foot pin (2 points)	3-50
Grease blade cylinder rod end pin (2 points)	3-50
Grease blade foot pin (2 points)	3-50
Grease first boom foot pin (2 points)	3-50
Grease boom cylinder foot pin (2 points)	3-50
Grease first boom/ second boom connector pin (2 points)	3-50

24. LIST OF MAINTENANCE


Item to be Serviced	Page
<b>■ Service every 100 hours continued</b>	
Grease boom cylinder rod end pin (2 points)	3-50
Grease offset cylinder foot pin (1 point)	3-50
Grease offset cylinder rod end pin (1 point)	3-50
Grease sub-link connector pin (2 points)	3-50
Grease second boom third bracket connector pin (2 points)	3-51
Grease arm cylinder foot pin (2 points)	3-51
Grease arm cylinder rod end pin (1 point)	3-51
Grease third bracket/ arm connector pin (1 point)	3-51
Grease bucket cylinder foot pin (1 point)	3-51
Grease bucket cylinder rod end pin (1 point)	3-51
Grease arm/ link connector pin (1 point)	3-51
Grease link connector pin (2 points)	3-51
Grease bucket/ link connector pin (2 points)	3-51
Grease arm/ bucket connector pin (1 point)	3-51
Check and replenish oil in swing machinery case	3-52
<b>■ Service every 250 hours</b>	
Check and replenish oil in final drive	3-53
Check battery fluid level	3-54
Replace filter for engine oil pan and engine oil filter cartridge Replace hydraulic fluid filter	3-56
Check and adjust fan belt tension	3-58
Check and adjust the compressor belt for the air conditioner	
<b>■ Service every 500 hours</b>	
Replace fuel filter cartridge	3-60
Check and grease the swing pinion	3-62
Grease swing circle (2 points)	3-62
Clean and check radiator fins, oil cooler fins and condenser fins	
Clean air conditioner filter	3-64
<b>■ Service every 1000 hours</b>	
Replace oil in swing machinery case	3-65
Replace oil in final drive case	3-66
Inspect all tighteners on the turbocharger	3-67
Check play of turbocharger rotor	3-67
Grease fuel cut solenoid linkage	3-67

Item to be serviced	Page
<b>■ Service every 2000 hours</b>	
Check and replenish oil in PTO gear case	3-68
Replace hydraulic tank oil and clean strainer	3-69
Clean and inspect turbocharger	3-74
Check alternator and starter	3-74
Check and adjust engine valve clearance	3-74
<b>■ Service every 4000 hours</b>	
Check water pump	3-75

### 24.2 SERVICE TIME WHEN USING HYDRAULIC BREAKERS

Deterioration of hydraulic fluid is much more rapid when hydraulic breakers are installed than with normal bucket excavation operations. Set the maintenance intervals as follows:

- **Replacing hydraulic fluid filter element**  
Replace between 100 and 150 hours for the first time on a new machine and then replace the element in accordance with the table on the right.
- **Replacing hydraulic fluid in the tank**  
Replace the hydraulic fluid in accordance with the table on the right
- **Replacement of additional filter element for breaker**  
Replace the element in accordance with the table on the right with every 250 hours of breaker use as a guideline (when the breaker is operated more than 50 % of the time)





## **25. SERVICE PROCEDURES**

---

### **25.1 INITIAL SERVICE AFTER 250 HOURS OF OPERATION**

Perform the following maintenance on a new machine only once after the initial 250 hours of operation.

- Replace fuel filter cartridge
- Check and adjust engine valve clearance


Refer to the service to be performed after 500 and 2000 hours of service for how to perform this service.

## 25.2 MAINTENANCE THAT IS NOT REGULARLY SCHEDULED

### 25.2.1 Check and clean or replace air cleaner


**Warning!**

- Do not clean or replace the air cleaner while the engine is running.
- Wear safety glasses or safety goggles when cleaning the air cleaner element with compressed air. Cleaning the air cleaner with compressed air will scatter dirt and dust which may get into the eyes.





#### ■ Inspection

Open the left side cover and check dust indicator (1). If the dust indicator (1) is showing the color red, clean the air cleaner element.



#### ■ How to clean the element

1. Open the rear engine hood and center hood and remove partition panel (2).
2. Remove wing nut (3) and remove element (4). Cover the air connector side behind the body of the air cleaner with a clean cloth or tape to prevent dirt from getting in.
3. Clean the inside of the body of the air cleaner.
4. Direct a stream of dry compressed air (less than 7 kg/cm) from inside of the element (4) on the folds and then blow it direct the stream of compressed air against the folds of the element from outside. Then clean the inside of the element again.
  - (1) Each time you clean the element tear off one seal.
  - (2) When the element has been clean 6 times or when a year has passed, replace the element.
  - (3) If the dust indicator shows the color red soon after cleaning replace the element even though it may not have been cleaned 6 times.




## 25. SERVICE PROCEDURES

5. Replace the element if you find small holes on the inside of the element after cleaning it and then checking it by illuminating the inside of the element with a light bulb.


### NOTICE

Do not strike the element with anything or beat it against anything when cleaning it.

Do not use an element whose folds, gaskets or seals are damaged. Store unused elements wrapped or packaged and keep them in a dry place.





6. Remove the cloth or tape that you placed on the air connector opening in step 2.
7. Place the cleaned element in the cleaner and secure it with the wing nut.
8. Remove the evacuator valve (5) and clean it with compressed air.
9. Press the button of the dust indicator (1) in and return the piston showing the color red to the original position.



### ■ Replacing the element

1. Open the rear engine hood and center hood and remove partition panel (2).
2. Remove wing nut (3) and remove element (4). Cover the air connector side behind the body of the air cleaner with a clean cloth or tape to prevent dirt from getting in.
3. Clean the inside of the body of the air cleaner. Remove the cloth or tape that you placed on the air connector opening in step 2.
4. Place a new clean element in the cleaner and secure it with the wing nut.
5. After replacing the element press the button of the dust indicator (1) in and return the piston showing the color red to the original position.



### 25.2.2 Flushing the cooling system

**⚠ Warning!**

- Allow the engine to cool off before draining coolant from it. Coolant is still very hot immediately after the engine has been running and you will be burned if you try to drain it immediately.
- Do not get behind the machine while the engine is running to flush the cooling system. This is dangerous as it may move. There is also the danger of touching the fan while the hood is open and the engine is running.
- Do not remove the radiator cap when the coolant in the radiator is hot. The coolant may spurt out. Remove the cap slowly to allow pressure to be released after the coolant has cooled off.

Use the table below when flushing the coolant from the cooling system and replacing it.

Type of coolant	Flushing cooling system and replacing coolant
Supercoolant AF-ACL anti-freeze (anti-corrosion all season type)	Every 2 years (alternate years in the autumn) or every 4000 hours of operation whichever comes first
AF-PTL anti-freeze (all season type)	Every year (autumn) or every 2000 hours of operation whichever comes first.
AF-PT anti-freeze (all season type)	Every 6 months (Spring, Fall), use anti-freeze only in the Fall.
When not using anti-freeze	Every 6 months or every 1000 hours of operation whichever comes first.

## 25. SERVICE PROCEDURES

---

Park the machine in a level place to flush the cooling system and replace the coolant.

Supercoolant (AF-ACL) prevents the coolant from freezing and also prevents corrosion.

The mixture of anti-freeze and water in the coolant should differ with the temperatures to be expected but it should be at least a minimum of 30% to obtain the anti-corrosion effect.

Find out what the lowest temperature that your area experienced in the past was and use the table shown below to determine the amount of anti-freeze to mix with water.

Use a figure about 10°C lower than the minimal temperature when consulting the table.

Table of mixtures of coolant and water

Minimum temperature (centigrade)	-10	-15	-20	-25
Amount of mixture (liters)				
Amount of coolant	4.7	5.6	6.4	7.2
Amount of water	11.0	10.1	9.3	8.5

**Warning!**

Coolant is flammable so be careful of flames.


Use water from the public water supply. Consult with Komatsu or your Komatsu dealer if you have to use water from a river or a well.

We recommend using an anti-freeze concentration gauge to achieve the proper proportions.

**Warning!**

Be careful so that you do not get coolant on you when removing the drain plug from the radiator.

- Have a container which holds at least 15.7ℓ into which you can drain the coolant and a hose available.
1. Slowly turn the radiator cap and remove it.
  2. Remove the cover under the radiator, then place a container to catch the coolant under the drain cock (2) and drain plug (3). Open the drain cock (2) in lower part of the radiator and drain the coolant from the radiator. Open the engine hood and the center hood. Remove the drain plug from the engine block (3) and drain the coolant from it.
  3. After completely draining the coolant, reinsert the drain plug (3) and close the drain cock and fill the cooling system with water.
  4. Remove the drain plug (3) and open the drain cock (2) and run the engine at a low idle and flush the system with water for 10 minutes. Make sure that the amounts of water entering the system and being drained from it are such that it is always full. Watch the water hose while flushing the engine to make sure that it does not come out of the radiator filler port.
  5. After flushing the cooling system, stop the engine, turn off the water and after it has all drained out, reinsert the drain plug (3) and close the drain cock (2)
  6. After draining the system, use a cleaning agent to clean the system. Follow the directions of the directions for the cleaning agent you use for the proper method of cleaning.
  7. After cleaning the system, remove the drain plug (3) and open the drain cock (2) and allow all of the fluid to drain from the system. Then fill the system with water so that it comes up close to the filler port.




## 25. SERVICE PROCEDURES

---

- When the water level approaches the filler port, open the drain cock (2) and remove the drain plug (3), run the engine at a low idle and flush the system with water until clear water comes out.

Make sure that the amounts of water entering the system and being drained from it are such that it is always full. Watch the water hose while flushing the engine to make sure that it does not come out of the radiator filler port.

- When clear water comes out, stop the engine, close the drain cock (2) and reinsert the drain plug (3) after wrapping it with sealing tape.
- Reinstall the undercover.
- Fill the system with water until it overflows.
- Run the engine for 5 minutes at a low idle and then for another 5 minutes at a high idle to remove the air from the system. (Keep the radiator cap off at this time.)
- Drain the coolant water from the reserve tank, clean the inside of the reserve tank and fill it to a point between low and full.
- Stop the engine, fill the radiator with water for about 3 minutes until the level approaches the filler port, tighten the radiator cap and close the engine hood.



### 25.2.3 Checking the electric heater

Once a year before cold weather arrives, ask Komatsu or your Komatsu dealer to check and repair the electric heater for loose wires or accumulations of dirt.

### 25.2.4 Check and tighten track shoe bolts (steel shoe machines)



Tighten the bolts (1) on loose shoes as soon as you find them as using while they are loose will break or damage them.

#### ■ How to tighten

1. First tighten with a torque of  $20 \pm 2$  kg and check to see whether the nut and the shoe are flush with the link contact surface.
2. After making sure of this, then tighten another  $120 \pm 2$  degrees.

#### ● Tightening order

Tighten bolts in accordance with the order shown in the diagram on the right. After tightening, check to see whether the nut and the shoe are flush with the link contact surface.





### 25.2.5 Check and adjust track tension (steel track vehicles)

**⚠ Warning!**

Perform this operation with two people. The operator of the vehicle must follow the signals being given by the other person. Track tension is adjusted by raising the machine. If the machine is lowered accidentally while checking the track tension, it can be extremely dangerous. Never, ever move the machine while the tension is being measured.

Whenever the occasion calls for it, track tension should be checked and adjusted, since the wear in the pins and bushings on the undercarriage will vary with the nature of the work being done and the soil properties of the work site. Perform checks and adjustments under the same conditions as operating (with the tracks clogged with mud if the work site is one in which they tend to get clogged with mud).

■ **Checking**



1. Raise the body of the machine with the arm and the boom. Move the control levers slowly when doing this.
2. Measure the clearance between the bottom of the track frame and the top of the shoes in a position where it will be safe even if the machine were to come down by accident.

The standard clearance is  $240 \pm 20$  mm.

Places to measure

Measure the fourth track roller from the sprocket

If the tension is other than the standard tension, adjust it as follows.



## ■ Adjusting tension



### ⚠ Warning!

There is the danger that the grease under high pressure inside the mechanism may fly out. Do not loosen the lubricator (1) more than 1 turn when loosening it. Do not loosen any other parts than the lubricator (1) at this time. Do not have your face in front of the lubricator (1). If track tension is not relieved by following the procedures here, contact Komatsu or your Komatsu dealer for assistance.

### ● How to increase tension

Prepare a grease gun.

1. Pump grease from the grease gun into grease fitting (2).
2. To check for the proper tension, move the machine backwards and forwards.
3. Check the tension of the track again and if it is still not as it should be adjust it again.
4. Pump grease in until S is 0 mm. If the tension is still too loose, there will be greater wear on the pins and bushings and they will need to be either reversed or replaced. Ask Komatsu or your Komatsu dealer for assistance in this repair.




- How to decrease tension

**⚠ Warning!**

Forcing grease out by any other method than that described below is extremely dangerous. If track tension is not relieved by following the procedures here, contact Komatsu or your Komatsu dealer for assistance.

1. Loosen the lubricator (1) little by little and release some of the grease.
2. Turn lubricator (1) a maximum of one turn.
3. When grease does not appear to come out easily, move the machine back and forth a bit.
4. Tighten lubricator (1).
5. To check for the proper tension, move the machine backwards and forwards.
6. Check the tension of the track again and if it is still not as it should be adjust it again.



### 25.2.6 Checking the rubber track shoes (machines with rubber track shoes)

Repair or replacement of rubber track shoes will be necessary under the following circumstances. Seek the assistance of Komatsu or your Komatsu dealer for this service.

#### ■ Lug height

- When lug height "a" decreases from wear, traction will decrease. When "a" is less than 5 mm, replace the track shoes.
- Replace the track when the lugs have worn and more than 2 rings of the steel cords inside the shoes have been exposed.

#### ■ Parting of steel cord

Replace the rubber track when more than half of the steel cord layer on one side has parted.






#### ■ Separation of tips

Replace rubber track shoes whose tips have separated in more than one place.

#### ■ Tension of rubber tracks

Replace rubber tracks that are loose even after pumping in grease under pressure or replace the seal in the cylinder.

When you can only adjust the tension so that the rubber tracks are so loose that they readily come off, it is not merely a problem of the rubber tracks stretching; the grease cylinder may also be defective.




■ **Cracks in rubber track shoes**

Repair cracks in rubber track shoes when they grow to be 60 mm in length. However track shoes that have small short cracks in which the steel cord can be seen should be repaired immediately.

There is no need to repair cracks that are less than 30 mm long or that are less than 10 mm deep.

Consult with Komatsu or your Komatsu dealer about the criteria for replacing, repairing or continuing to use rubber track shoes.



### 25.2.7 Checking and adjusting tension of rubber track shoes (for machines with rubber track shoes)

**⚠ Warning!**

Perform this operation with two people. The operator of the vehicle must follow the signals being given by the other person. Track tension is adjusted by raising the machine. If the machine is lowered accidentally while checking the track tension, it can be extremely dangerous. Never, ever move the machine while the tension is being measured.




Rubber tracks will wear differently depending upon the work being performed and the properties of soils so track tension should be checked from time to time or whenever it would seem warranted.

In particular, the first check of newly installed tracks should be done after 30 hours of operation.

■ **Inspection**

1. Move the tracks so that the seam (where there is an M mark) is on top between the front and rear wheels.
2. Raise the body of the machine with the boom and arm. Move the control lever slowly when doing this.
3. The standard tension is when the clearance between the track and the flange of 4th roller from the sprocket is between 34 and 44 mm.

Operating the machine when rubber tracks are loose (when the clearance is greater than 50 mm) will cause the tracks to come off or premature wear of the tips.



▶ 1/138

## 25. SERVICE PROCEDURES

When the track tension is other than the standard value, adjust it as follows

### ■ Adjusting tension


#### ⚠ Warning!

There is the danger that the grease under high pressure inside the mechanism may fly out. Do not loosen the lubricator (1) more than 1 turn when loosening it. Do not loosen any other parts than the lubricator (1) at this time. Do not have your face in front of the lubricator (1). If track tension is not relieved by following the procedures here, contact Komatsu or your Komatsu dealer for assistance.

### ● How to increase tension

Prepare a grease gun.

1. Pump grease from the grease gun into grease fitting (2). At this time replace the nozzle at the tip of the grease gun nozzle with a check type nozzle of the associated fixture (that goes down into the grease fitting)
2. To check for the proper tension, move the machine backwards and forwards.
3. Check the tension of the track again and if it is still not as it should be adjust it again.
4. If you pump in grease and the rubber tracks are still loose it will be necessary to replace the rubber tracks or the seal in the grease cylinder. Seek the assistance of Komatsu or your Komatsu dealer for this service.




- How to decrease tension

**Warning!**

Forcing grease out by any other method than that described below is extremely dangerous. If track tension is not relieved by following the procedures here, contact Komatsu or your Komatsu dealer for assistance.

1. Loosen the lubricator (1) little by little and release some of the grease.
2. Turn lubricator (1) a maximum of one turn.
3. When grease does not appear to come out easily, move the machine back and forth a bit.
4. Tighten lubricator (1).
5. To check for the proper tension, move the machine backwards and forwards.
6. Check the tension of the track again and if it is still not as it should be adjust it again.




### 25.2.8 Replacing Rubber tracks (for machines with rubber tracks)

**Warning!**

Perform this operation with two people. The operator of the vehicle must follow the signals being given by the other person. Replacing tracks is accomplished by raising the machine. If the machine is lowered accidentally while replacing tracks, it can be extremely dangerous. Never, ever move anything other than the track being replaced when replacing tracks.

There is the danger that the grease under high pressure inside the mechanism may fly out. Do not loosen the lubricator (1) more than 1 turn when loosening it. Do not loosen any other parts than the lubricator (1) at this time. Do not have your face in front of the lubricator (1). If track tension is not relieved by following the procedures here, contact Komatsu or your Komatsu dealer for assistance.






**NOTICE**

It is possible to change from steel tracks to rubber tracks or vice-versa but installation or removal of guards is necessary. Always seek the assistance of Komatsu or your Komatsu dealer for this service.


- Grease gun
- Have some steel pipe on hand
- Removing rubber tracks

**Warning!**


- Forcing grease out by any other method than that described below is extremely dangerous. If track tension is not relieved by following the procedures here, contact Komatsu or your Komatsu dealer for assistance.
- Before removing rubber tracks, check to make sure that all grease has been removed and then move the sprocket.



1. Raise the body of the machine with the boom and arm. Move the control lever slowly when doing this.
2. Loosen the lubricator (1) little by little and release some of the grease.
3. Turn lubricator (1) a maximum of one turn.







4. Stick the steep pipe under the rubber tracks and move the sprocket in reverse. When the rubber tracks slip off of the idler because of the steel pipes, slide the tracks off and remove them.



■ **Installing rubber tracks**

1. Raise the body of the machine with the boom and arm. Move the control lever slowly when doing this.
2. Fit the rubber tracks on the sprocket and place them on the idlers.
3. Move the sprocket in reverse, press down the rubber tracks and stop rotating the sprocket.
4. Stick a steel pipe under the rubber track and move the sprocket again and make sure that the rubber tracks are on the idlers.
5. Stop turning the sprocket and make sure that the rubber tracks are on the sprocket and the idlers.
6. Adjust the tension of the rubber tracks following item 25.2.8 "Checking and adjusting rubber tracks"
7. Lower the machine back down on the ground after making sure that the rubber tracks are properly fitted to the sprocket and idlers and that the tension is proper.




### 25.2.9 Replacing bucket teeth (Vertical pin type)


Replace bucket teeth as they wear, before the bucket itself begins to wear.

**Warning!**


It is dangerous if the arm and boom apparatus is accidentally moved while replacing bucket teeth. Place the arm and boom apparatus where it is stable and will not move, stop the engine and lock the control levers securely.



1. Place blocks under the bottom of the bucket so that the pins of the teeth (1) may be removed. Make sure that the arm and boom apparatus is stable and lock the control levers. Place the bucket so that the bottom of the bucket is horizontal.




2. Use a hammer and punch and knock out the pin (2). (If the punch is facing the rubber pin lock (3) when you strike it, the rubber pin lock may break so face the back of the pin.)
3. Make sure that you have a locking pin (2) and a rubber pin lock (3) after you have removed the pin.




If you use the following kinds of locking pins and rubber pin locks, teeth may come off while the bucket is being operated. Replace them with new ones.


- A locking pin which is too short



- Rubber pin locks which have tears and whose steel balls will soon fall out.




- Steel balls go in when pressed by the hand.




4. Remove dirt from the adapter with a putty knife.
5. Push the rubber pin lock into the adapter hole with your hand or a hammer.

Be careful when doing this so that the rubber pin lock does not fly off of the adapter.



6. Clean the inside face of tooth (a) and install it on adapter (4). If it has mud on it or if it protrudes, the teeth will not go all the way into the adapter and there will not be good contact where they are supposed to be together.
7. Put the teeth (1) into adapter (4) and push the teeth in firmly and make sure that rear face of the pin hole of the teeth (1) is nearly in a straight line with the rear face of the adapter hole.





## 25. SERVICE PROCEDURES

---

If the rear hole face of the pin for tooth (1) is protruding out in front from the rear hole face of the pin for the adapter (4) do not pound the pin in. When this is the case, there is something that is preventing adapter (4) from getting all the way into tooth (1). This should first be found and removed and when the tooth (1) satisfactorily goes in the adapter, pound in the locking pin (2).

8. Place the locking pin (2) in the pin hole of the tooth and pound it until the top of the locking pin is the same height as the surface of the tooth (1).
9. Always check the following after replacing bucket teeth.
  - 1) Check to make sure that the locking pin that has been pounded in is secured by the tooth and the surface.
  - 2) Tap the locking pin in the direction opposite to that which it was pounded in.
  - 3) Tap the tip of the tooth lightly up, down and from each side.
- 4) The locking pin (2) and the rubber pin lock (3) must be in the positions shown in the diagram to the right.

The teeth will wear uniformly and life of them can be extended so that they are replaced less frequently by turning them over. Replace the rubber pin locks and locking pins at the same time you replace teeth. This will prevent the bucket from losing teeth.




### 25.2.10 Replacing bucket teeth (horizontal pin type)


Replace bucket teeth as they wear, before the adapter begins to wear.

**Warning!**

It is dangerous if the arm and boom apparatus is accidentally moved while replacing bucket teeth. Place the arm and boom apparatus where it is stable and will not move, stop the engine and lock the control levers securely.




1. Place blocks under the bottom of the bucket so that the pins of the teeth (1) may be removed. Make sure that the arm and boom apparatus is stable and lock the control levers. Place the bucket so that the bottom of the bucket is horizontal.




2. Use a hammer and a rod and knock out and remove the pin (2).

#### Additional explanation

Use a round rod which is smaller in diameter than the pin.




3. Clean the surface where the tooth is to be mounted. Fit a new tooth in the adapter and insert pin (2) halfway. Pound it to attach the new tooth to the bucket.




### 25.2.11 Adjusting Bucket clearance

**Warning!**

It is dangerous if the arm and boom apparatus is accidentally moved while adjusting bucket clearance. Place the arm and boom apparatus where it is stable and will not move, stop the engine and lock the control levers securely.




1. Place the arm and boom apparatus in the position shown in the diagram to the right. Stop the engine and place the safety lock lever in the locked position
2. Move the O-ring (1) out of place on the link and measure the play (a). It is easier to measure if you move the bucket to one side so that the play is all in one place (in the diagram the bucket is on the right side). You can measure this accurately and easily with a feeler gauge.
3. Loosen the 4 bolts that hold the plate (2) and loosen plate (3). You can do this without removing the bolts completely because the shims are the split type.
4. Remove shims (4) corresponding to the amount of play (a).



**Example**

If the amount of play is 3 mm, remove 2 sets of 1.0 mm shims (4) and 1 set of 0.5 (2) and the play will be 0.5 mm.

Four sets of 1.0 mm ( 8 pieces) shim, 2 sets of 0.5 mm (4 pieces) shim are installed. Two pieces make one set. Do not calibrate when the play is less than one shim.



5. Tighten 4 bolts (2). If the bolts (2) are too stiff to tighten, remove the pin stopper bolt (5) and they will be easier to tighten.


### 25.2.12 Checking and calibrating the air conditioner

**Warning!**

The refrigerant is colorless and odorless and is harmless in the air but if it gets in the eyes or on the skin it could cause blindness or frostbite so never loosen any parts of the refrigerant lines.

■ **Check the amount of refrigerant (gas)**

The air conditioner will not cool properly if there is insufficient refrigerant (gas). Normally there are no bubbles visible in the sight glass (for visual inspection) which is mounted on the receiver of the condenser unit in front of the oil cooler. When there are bubbles visible there is insufficient refrigerant in the system. Have your dealer replenish the amount of refrigerant.



■ **Clogging of the condenser**

Cooling efficiency of the condenser will decline significantly if the condenser fins are dirt and caked with mud and dirt. Since the air conditioner's cooling capabilities will also decline, clean the mud and dirt from the condenser and when the fins are damaged, repair the driver etc.

■ **Checking when not in use**

Run the compressor at low speed for a few minutes once a week in the off-season when the unit is not being used to supply lubricant to the various parts of the compressor. (When running the engine at low speed, turn the temperature control knob on the air conditioner all the way to the left.


Be careful not to suddenly run the compressor at high speed when the temperature is cold outside as this will cause breakdowns. When the outside temperature is between 2 and 6.5°C the air compressor will not run even though the air conditioner switch is turned on.



**25.2.13 Check and replenish wind shield washer fluid (optional)**

If air gets into the windshield washer fluid, check the amount of fluid in the reservoir (1) and if it is below the acceptable level, fill the reservoir with the washer fluid used in automobiles.

Be careful so that no dirt gets in when filling.



- Proportions to mixture water and washer fluid

Replenish the washer fluid by mixing with water according to the following proportions which will differ depending on the ambient temperature.

Area, season	Mixture ratio	Freezing temperature
Normal	Washer fluid 1/3, 2/3 water	-10 °C
Winter in a cold area	Washer fluid 1/2, water 1/2	-20 °C
Winter in extremely cold areas	Only washer fluid	-30 °C

There are 2 types of washer fluid depending on the temperature at which it will freeze: -10°C (for general use) and -30°C (for use in colder areas). Select the one appropriate for your area and season.


## 25.3 CHECKS BEFORE STARTING OPERATIONS

### 25.3.1 Check and replenish coolant level

**Warning!**



Under normal circumstances, do not remove the radiator cap. Check the coolant level in the reserve tank when the engine is cold.

1. Open the engine hood and check to see whether the coolant level in the reserve tank (1) is between FULL and LOW. (See diagram at right) If the level is low add coolant to reserve tank (1) until it is at the full level.
2. Tighten the cap securely when you have finished adding coolant.
3. If the reserve tank is empty check for leaks. Then check the coolant level in the radiator. If low add coolant to the radiator and then to the reserve tank.



### 25.3.2 Check the oil in the engine oil pan and add if needed

1. Open the engine hood.
2. Remove dipstick (G) and wipe it off with a rag.
3. Reinsert dipstick (G) as far as it will go and then remove.
4. If there is oil on the dipstick (G) between H and L, the level is satisfactory. If the level is below L add oil at (F).



For the oil to use see item 21. "Use of fuel and lubricants by ambient temperatures"

## 25. SERVICE PROCEDURES

- If the level is above H remove the excess oil from drain plug (P) and recheck the oil level.
- If the oil level is correct, replace the cap, tighten it securely and close the engine hood.

### Additional explanation



If you are checking the oil level after the engine has been operating, wait for at least 15 minutes after stopping the engine before performing the check.

### 25.3.3 Check the fuel level

#### Warning!

Do not allow the fuel tank to overflow when refueling as this can cause a fire. Clean up any spillage if it occurs. Do not stand directly above the opening to the fuel tank when refueling. Fuel may spurt out from the tank breather hole.

- Insert the key in the ignition switch (1), turn it to the ON position and allow the monitor light to come on.
- Ascertain the amount of fuel remaining from the fuel gauge (2). If there is insufficient fuel, fill the fuel tank while observing the sight gauge (G).




Capacity of fuel tanks 135 ℓ

For the fuel you should use see item 21. "Use of fuel and lubricants by ambient temperatures"

- After finishing, replace the cap and tighten it securely.

### Additional explanation


If the breather holes (3) become clogged, pressure in the tank will decrease and fuel will not flow. Clean these holes from time to time.




### 25.3.4 Check and replenish the oil in the hydraulic oil tank

**⚠ Warning!**

- Unscrew the cap to the hydraulic tank slowly and allow pressure to escape before removing it as oil can spurt out at this time.
- If you accidentally add oil so that it is above the H level, stop the engine and wait for the hydraulic fuel to cool. Then drain it from drain plug (P).



1. If the vehicle is not as shown in the diagram on the right, start the engine and while it is running at low speed, lower the blade to the ground, retract the arm and bucket cylinders, lower the boom and stop the engine with the teeth of the bucket touching the ground.
2. Check sight gauge (G) and if the oil level is between H and L, it is satisfactory.



**NOTICE**

Do not add oil above the H line. This will damage the hydraulic lines and will cause oil to spurt out.


3. If the hydraulic oil level is below L, remove the cover on the top of the hydraulic oil tank, and add oil from filler port (F)

For the oil you should use see item 21. "Use of fuel and lubricants by ambient temperatures"

**Additional explanation**

The oil level will vary with the temperature of the oil so use the following criteria to check the oil

- Prior to operation, around the L level (oil temperature from 10 - 30°C)
- During normal operation, near the H level (oil temperature from 50 to 80°C)





### 25.3.5 Check the dust indicator

1. Open the left side cover and check to see whether a red piston is protruding at the arrow sign of the dust indicator (1) .
2. If red piston is protruding immediately clean the element or replace it.

For how to clean the element, see item 25.2.1 "Inspecting, cleaning and replacing the air cleaner."

3. After checking, cleaning or replacing the air cleaner, push the knob of dust indicator (1) and return the red piston to its original position.



### 25.3.6 Check the electrical circuits

**Warning!**

If fuses blow frequently and there is evidence of short circuits in the wiring, do not fail to ascertain the cause and correct it.

Check for blown fuses, breaks in the wiring and evidence of short circuits. Check also for loose terminals, and if found, tighten them.

In particular, check the

- Battery
  - Starter
  - Alternator
- etc.

Consult with Komatsu or your Komatsu distributor for locating and correcting the problem.



**Warning!**

Always remove any flammable materials like dead leaves, twigs and grass that may have accumulated around the battery as they can cause fires.

Always check around the battery for flammable materials that may have accumulated when doing visual checks and checks prior to beginning operations and remove them if there are any.

**25.4 SERVICE TO BE PERFORMED AFTER EVERY 50 HOURS OF OPERATION****25.4.1 Drain water and sediments from fuel tank**

1. Do this before operating
2. Have a container on hand to catch the fuel that will drain.
3. Loosen the two bolts (2) to the cover under the machine and open the cover.
4. Open the valve on the underside of the tank and drain the water and sediment accumulated there together with the fuel that comes out. Be careful not to get fuel on yourself.
5. Close the valve when the fuel draining out is clean.

**NOTICE**


Do not use trichloroethylene to clean the inside of the tank.

## 25.5 SERVICE TO BE PERFORMED AFTER EVERY 100 HOURS OF OPERATION


Perform this service together with the service procedures to be carried out after every 50 hours of operation.

### 25.5.1 Greasing


1. Place the arm and boom apparatus on the ground in this position for greasing shown on the right and stop the engine.
2. Grease the fittings indicated by the arrow with a grease gun.
3. Wipe up old grease that has been forced out after finishing greasing.




- 1) Grease blade cylinder foot pin (2 points)
- 2) Grease blade cylinder rod end pin (2 points)
- 3) Grease blade foot pin (2 points)




- 4) Grease first boom foot pin (2 points)
- 5) Grease boom cylinder foot pin (2 points)
- 6) Grease first boom/ second boom connector pin (2 points)




- 7) Grease boom cylinder rod end pin (2 points)
- 8) Grease offset cylinder foot pin (1 point)
- 9) Grease offset cylinder rod end pin (1 point)
- 10) Grease sub-link connector pin (2 points)



- 11) Grease second boom third bracket connector pin (2 points)
- 12) Grease arm cylinder foot pin (2 points)
- 13) Grease arm cylinder rod end pin (1 point)
- 14) Grease third bracket/ arm connector pin (1 point)



- 15) Grease bucket cylinder foot pin (1 point)
- 16) Grease bucket cylinder rod end pin (1 point)
- 17) Grease arm/ link connector pin (1 point)
- 18) Grease link connector pin (2 points)
- 19) Grease bucket/ link connector pin (2 points)
- 20) Grease arm/ bucket connector pin (1 point)



4. Move the boom up and down a number of times after greasing and then grease the first boom foot pin (2 points) again.




### 25.5.2 Check and replenish the oil in the swing machinery case


**⚠ Warning!**

Oil is hot after operating the machine. Begin this operation after the oil has cooled down.

1. Open the engine hood and the center hood. Open the cover in the bottom of the tool box.



2. Remove the dipstick (G) and wipe it off with a rag.
3. Reinsert the dipstick (G) as far as it will go.
4. Remove the dipstick. If there is oil on the dipstick (G) between H and L, the level is satisfactory.
5. If the level is below L. Reinsert the dipstick and add engine oil at filler port (F). Remove the air bleeder plug (2) while adding oil.



For the oil to use see item 21. "Use of fuel and lubricants by ambient temperatures"

6. If the level is above H, loosen the drain plug (P) and remove the excess oil.
7. After checking and replenishing the oil, reinsert the dipstick and reinstall the drain plug (2).

## 25.6 SERVICE TO BE PERFORMED AFTER EVERY 250 HOURS OF OPERATION


Perform this service along with the service to be performed after every 50 hours of operation.

### 25.6.1 Check and replenish the oil in the final drive case

**Warning!**

- Oil is hot immediately after operating the machine. Begin this service after oil has cooled down.
- Unscrew the plug slowly to release pressure that may be remaining in the case. If this is done abruptly, the plug may fly out and oil will spurt out with it.

- Have a hexagon wrench handy.
1. Set the sprocket so the plug (F) is above and so that plugs (F) and (P) are in a line perpendicular to the ground surface.
  2. Remove plug (F) with a hexagon wrench. The oil level should be somewhere between the bottom of the drain plug hole and 10 mm below that point.
  3. If the oil level is below that point, reinsert the drain plug (F), use the travel control levers to go forward or backward and rotate the sprocket one full turn to confirm that the level is too low. Follow the procedure described in 2 above.
  4. If the level is still too low, add oil from drain plug (F) until it overflows.



For the oil to use see item 21. "Use of fuel and lubricants by ambient temperatures"

5. After checking and replenishing, reinstall plug (F).

### 25.6.2 Check the battery fluid level

**⚠ Warning!**

- Because batteries emit flammable gas there is the danger that an explosion might occur. Do not light cigarettes around batteries or do anything that would cause sparks.
- Battery electrolyte contains acid and can burn the skin and ruin clothing. Be sure that you do not get any in your eyes or on the skin. If you spill acid on yourself, immediately flush the area with water and see a physician as soon as possible.


Perform this service before starting operations.

1. Open the left side cover and remove cover (1).
2. Remove cap (2) and check the level. If it is below the prescribed level ( 10 to 12 mm above the plates) add distilled water until it reaches the prescribed level.

When you have added so much distilled water that it has overflowed, add a weak solution of sulfuric acid.

3. Clean the air vent holes in the battery caps, re-insert them and tighten them.

To prevent freezing of distilled water in the battery, add it in the morning before beginning work.



### 25.6.3 Replace the oil in engine oil pan and replace the engine oil filter cartridge


**⚠ Warning!**

Do not change the oil immediately after the engine has been operating as all parts of the engine are hot. Change the oil after it has cooled down

Have on hand:

- A container to catch the drained oil that will hold at least 11 ℓ
- 11 ℓ of oil
- An oil filter wrench

1. Remove the cover on the underside of the machine.
2. Place the contain directly under the drain plug (P) located on the underside of the machine.
3. Loosen and then remove the drain plug slowly so that you do not get any oil on yourself and allow the oil to drain out.
4. Check the drained oil and if there is a large amount of metal particles or foreign matter in it seek the assistance of Komatsu or your Komatsu dealer.
5. Reinstall drain plug (P) and reinstall the cover on the underside of the machine.
6. Open the engine hood and from above the engine use a filter wrench to turn the oil filter cartridge (1) to the left. A large amount of oil will come out if you do this immediately after you stopped the engine so wait about 10 minutes before doing this.
7. Clean the mount for the filter and apply a light coating of oil to the surface of the seal or gasket of the new filter cartridge (or coat in with a thin layer of grease) and install the new filter cartridge.
8. After placing the filter cartridge on the mount and the packing surface contacts the seal surface, tighten it at least another half turn.



## 25. SERVICE PROCEDURES

9. After installing a new filter cartridge, add engine oil from filler port (F) until the oil level is between H and L on the dipstick (G)

For the oil to use see item 21. "Use of fuel and lubricants by ambient temperatures"

10. Start the engine and after it has been idling for a while stop it and check to make sure that the oil level is between H and L on the dipstick (G). Refer to item 25.3 "Service to be performed before starting operations"



When the machine is being used, change the oil every 6 months even though the machine may not have been operated 250 hours. Conversely, if the machine has been operated 250 hours and 6 months have not yet passed, change the oil.

### 25.6.4 Replace the hydraulic fluid filter element

**Warning!**


Be sure to turn the cap to the oil filler port slowly to release pressure before removing the cap.

1. Remove the cover (1) on the right side of the machine.
2. Remove the cap to the oil filter port (F) and release pressure.
3. Loosen 4 bolts and remove cover (2). Hold the cover down when removing the bolts because the cover may fly off due to the force of spring (3).
4. After removing spring (3) and valve (4), remove element (5).
5. Clean the parts you removed in kerosene.
6. Put a new element in the place where you removed the old one (5)




7. Place valve (4) and spring (3) on top of the element
8. Place the cover in position, and tighten the mounting bolts while pushing it down with your hand.

9. Extend the cylinders of the boom, arm and bucket as shown in the diagram on the right, and after having removed the filler cap, reinstall the cap and pressurize the tank.
10. Reinstall cover (1).



Deterioration of hydraulic fluid is much more rapid when hydraulic breakers are installed than with normal bucket excavation operations. Replace the element between 100 and 150 hours for the first time on a new machine and then replace the element in accordance with the table on the right. Replace the additional filter element for use with a breaker (optional) in accordance with the table on the right with every 250 hours of breaker use as a guideline (when the breaker is operated more than 50 % of the time)






### 25.6.5 Check and adjust fan belt tension

■ Check

The belt should give about 10 mm when pressed with the thumb (about 6 kg) between the pulley for the alternator and the pulley for the fan.

■ Adjusting


1. Loosen bolts and nuts (2) and (3).
2. Loosen lock nut (4) and move the alternator (1) with the adjustment bolt (5) so that the belt tension will be such that it will give about 10 mm when pressed with a force of 6 kg.
3. Tighten lock nut (4), bolts and nuts (2) and (3) and fix the alternator (1) in position.
4. Check for damage to each of the pulleys, for wear of the groove and wear to the belt. In particular, make sure that the belt is not touching the bottom of the groove in the pulley.
5. Replace the belt if it is stretched and has no room for adjustment or if it is cut or cracked.
6. After you have replaced a belt, readjust it after running the engine for an hour.



### 25.6.6 Check and adjust the tension of the air conditioner compressor belt

#### ■ Checking


The belt should give about 12-15 mm when pressed with the finger (about 6 kg) between the drive pulley and the compressor pulley.




#### ■ Adjusting

Have the following available:

- A bar
- A piece of wood



1. Place the bar in between the compressor (1) and the bracket to secure the compressor (1) in place. When doing this place a piece of wood between the bar and the compressor (1) so that the compressor will not sustain any damage.
2. Loosen bolts (2) and (3).
3. Move the compressor so that the belt will give about 12- 15 mm when pushed with a force of approximately 6 kg.
4. Tighten bolts (2) and (3) to hold the compressor (1) in place.
5. Check for damage to each of the pulleys, for wear of the groove and wear to the belt. In particular, make sure that the belt is not touching the bottom of the groove in the pulley.
6. Replace the belt if it is stretched and has no room for adjustment or if it is cut or cracked.
7. After you have replaced a belt, readjust it after running the engine for an hour.





## 25.7 SERVICE TO BE PERFORMED AFTER EVERY 500 HOURS OF OPERATION

Perform this service together with the service to be performed after every 50, 100 and 250 hours of operation.

### 25.7.1 Replace fuel filter cartridge

**Warning!**

- Do not replace filter immediately after the engine has been running as all of the components are hot. Do this after the engine has cooled down.
- Be careful of open flames and cigarettes and do not have them nearby.
- When cranking the engine to bleed out air, make sure that the area around the engine is safe because the engine may start.


Have a filter wrench and a container for catching fuel on hand for the procedure.

1. Place the container under the fuel filter cartridge.
2. Turn the fuel filter cartridge (1) to the left with a filter wrench and remove it.
3. Clean the filter mounting and fill the new filter cartridge with fuel. Coat the packing surface with oil and install the cartridge in the filter mounting.
4. After placing the filter cartridge on the mount and the packing surface contacts the seal surface, tighten it approximately 2/3 of a turn.

Tighten the filter the proper amount because if it is tightened too much, the packing will be damaged which will lead to a fuel leak. If the filter is too loose it will also leak.




5. Bleed air from the system after the new cartridge has been installed.

Bleed the air using the following procedure.



- Procedure for bleeding air from fuel system

- 1) Fill the fuel tank so that it is full (so that the gauge reads FULL).
- 2) Loosen the knob on the engine fuel pump (1) and move it up and down 5 or 6 times and push in the air bleeder knob and tighten it.
- 3) Turn the ignition switch to START, and hold it there for 15 to 20 seconds. By holding the ignition switch in the START position the air will automatically be bled off.
- 4) The engine will start if the ignition switch is returned momentarily to OFF and then turned to the START position.
- 5) If the engine will not start, repeat steps 2) through 4) until it does start.



#### NOTICE

Do not crank the starter motor for more than 20 seconds. Wait for 2 minutes and then turn it over again.

#### Additional explanation


Use this same method to bleed out air if you have run out of fuel.

6. After replacing the cartridge, start the engine and check for leaks around the filter seal. If there are leaks, make sure that the cartridge has been properly tightened. If it still leaks, remove the cartridge following steps 1 and 2 and check for damage to the face of the cartridge.

If there is damage to the packing or foreign matter caught in it, replace the cartridge with a new one and repeat steps 3 through 6.

### 25.7.2 Check and replenish the amount of grease in the swing pinion

- Have a scale available for this procedure.
- 1. Remove bolts (2) on the top of the revolving frame and remove cover (2).
- 2. Insert a scale in the grease and check to see whether the amount of grease in the portion where the pinion passes is at least 28 mm high. If it is below this level add grease.
- 3. Check to see whether the grease is milky white. If it is the grease should be replaced. Seek the assistance of Komatsu or your Komatsu dealer for this service.




The total volume of grease is 10 ℓ (9 kg)

4. Re-install cover (2) with bolt (1).

### 25.7.3 Grease the swing circle (2 points)


1. Place the arm and boom apparatus on the ground.
2. Grease the grease fittings indicated by the arrows in the diagram on the right with a grease gun.
3. Wipe up old grease that was forced out after finishing the greasing.



### 25.7.4 Check and clean radiator fins, oil cooler fins and condenser fins

**⚠ Warning!**

There is danger of injury from compressed air, steam or water striking the body. Wear safety goggles, masks and safety shoes etc.



1. Open the engine hood and the left side cover of the machine.
2. Blow dust, dirt, leaves and mud clogged in the fins of the radiator, oil cooler and condenser off with compressed air. In addition clean the net in front of the oil cooler at this time. You may use steam or water in place of compressed air.
3. Check rubber hoses and replace those which have cracks or are brittle. Check for loose hose clamps as well.

#### NOTICE

When using compressed air, stand back to avoid damaging the fins. If the fins are damaged, this will lead to water leaks and may cause overheating. Perform this procedure every day when working in a work site with a lot of dust, regardless of the suggested service interval.


### 25.7.5 Clean air conditioner filters

1. Pull filter (1) up and remove.
2. Clean filter (1) with compressed air. If the filter is soiled with oil or is extremely dirty, wash it in water with a neutral washing solution. After washing it, dry it thoroughly before using it.

If clogging of the filter cannot be solved by cleaning with air or by washing, replace it with a new one.

#### NOTICE

Cleaning after 500 hours of operation is a general standard. If the work site where the machine is operated is dusty, clean the filter more frequently.



## 25.8 SERVICE TO BE PERFORMED AFTER EVERY 1000 HOURS OF OPERATION

Perform this service together with the service to be performed after every 50, 100 250, and 500 hours of operation.

### 25.8.1 Replace the oil in swing machinery case



**Warning!**

Oil is hot after operating the machine. Begin this operation after the oil has cooled down.

Have the following on hand for this operation.

- A container to catch the oil to be drained at least 2.5 ℓ
- 2.5 ℓ of new oil

1. Place the container for catching the drained oil under drain plug (P) under the vehicle.
2. Remove the drain plug (P) and after the oil has drained, reinsert it and tighten it up again. The tightening torque for the drain plug is 10 to 19 kgm.
3. Open the engine hood and the center hood. Open the cover in the bottom of the tool box (1). Remove the dipstick (G) and the air bleeder plug. Add the prescribed amount of oil from the place where the dipstick is normally inserted (F).



For the oil to use see item 21. "Use of fuel and lubricants by ambient temperatures"

4. After adding the oil, reinstall the air bleeder plug.
5. Wipe off the dipstick (G) with a rag.
6. Reinsert the dipstick (G) as far as it will go and remove it.
7. If there is oil on the dipstick (G) between H and L, the level is satisfactory. If the level is below L add from the same place as before (F). Remove the air bleeder plug (2) while adding oil.

## 25. SERVICE PROCEDURES

---

- If the level is above H loosen drain plug (P) and remove the excess oil and recheck the oil level.

### Additional explanation

When checking the oil after operating the machine, wait 15 minutes after stopping the engine to do the check.

If the vehicle is on an incline, move it to a level place and then perform the check.

### 25.8.2 Replace oil in final drive case

**Warning!**

- Oil is hot immediately after operating the machine. Begin this service after oil has cooled down.
- Unscrew the plug slowly to release pressure that may be remaining in the case. If this is done abruptly, the plug may fly out and oil will spurt out with it.


Have the following on hand for this procedure

- A container to catch the oil to be drained at least 2.5 ℓ
- 2.5 ℓ of new oil for each right and left
- A hexagon wrench

- Set the sprocket so the plug (F) is above and so that plugs (F) and (P) are in a line perpendicular to the ground surface.
- Place the container to catch the oil under plug (P)
- Remove plugs (F) and (p) with a hexagon wrench. Drain the oil.
- Reinsert plug (P) and tighten it.
- Add the prescribed amount of oil from plug (F)

For the oil to use see item 21. "Use of fuel and lubricants by ambient temperatures"

- Add oil from drain plug (F) until it overflows. Reinstall plug (F).



### 25.8.3 Check all tighteners on the Turbocharger


Seek the assistance of Komatsu or your Komatsu dealer for this service.

### 25.8.4 Check the play of the turbocharger rotor

Seek the assistance of Komatsu or your Komatsu dealer for this service

### 25.8.5 Grease fuel stop solenoid linkage

1. Use a grease gun to grease the grease fitting indicated by the arrow.
2. After greasing, wipe off old grease that has been forced out.





### 25.9 SERVICE TO BE PERFORMED AFTER EVERY 2000 HOURS OF OPERATION


Perform this service together with the service to be performed after every 50, 100, 250, 500 and 1000 hours of operation.

#### 25.9.1 Check and replenish the oil in the PTO gear case


**Warning!**

Oil is hot after operating the machine. Begin this operation after the oil has cooled down.

1. Swing the superstructure and arm and boom apparatus so that the PTO gear case will be midway between the two tracks. Stop the engine and place the safety lock lever in the locked position




2. Remove the cover on the lower right side of the machine.
3. Remove plug (G) and check to see whether the oil is close to the lower lip of the plug hole. If it is it is okay. When the oil level is lower than this, remove plug (F), and add oil from the hole for plug (F) until it comes up to the lower lip of the hole for plug (G).



For the oil to use see item 21. "Use of fuel and lubricants by ambient temperatures"

4. Re-install plugs (G) and (F).
5. Re-install the cover.



## 25.9.2

**Warning!**


Do not change the oil immediately after the engine has been operating as all parts of the engine are hot. Change the oil after it has cooled down

Unscrew the cap to the hydraulic tank slowly and allow pressure to escape before removing it as oil can spurt out at this time.


Have on hand:

- A container to catch the drained oil that will hold at least 92 ℓ
- 92 ℓ of new oil
- A handle for socket wrenches

1. Swing the superstructure and arm and boom apparatus so that the drain plug for draining hydraulic fluid will be midway between the two tracks.




2. If the vehicle is not as shown in the diagram on the right, start the engine and while it is running at low speed, lower the blade to the ground, retract the arm and bucket cylinders, lower the boom and stop the engine with the teeth of the bucket touching the ground.



3. Lower the blade to the ground, place the safety lock lever in the locked position and stop the engine.


4. Remove the cover (1) from the right side of the vehicle, and remove the cap on filler port (F).



5. Place the container for catching the oil under the drain plug under the vehicle. Using a socket wrench, remove the drain plug (P) and drain the hydraulic oil. Check the O-ring on the drain plug (P) and replace it if it is damaged. After draining the oil, re-install the drain plug (P) and tighten.

Tightening torque is  $7 \pm 1$  kgm.

Be careful so that you do not get oil on you when you remove drain plug (P).





## 25. SERVICE PROCEDURES

---

6. Remove 4 bolts and remove cover (2). Hold the cover down while removing the bolts as the cover may fly off from the force of spring (3).
7. Pull the top of rod (4) up, and take out the spring (3) and the strainer (5).
8. Knock off any dirt that is stuck to the strainer (5), and clean it in clean kerosene or a cleaning oil. Replace the strainer (5) if it is damaged.
9. Re-insert the strainer (5) into the part of the tank that is protruding (6).
10. Bolt down cover (2).
11. Add the prescribed amount of engine oil at filler port (F). Check to make sure that the level is between H and L on the sight gauge.

For the oil to use see item 21. "Use of fuel and lubricants by ambient temperatures"


12. As shown in the diagram on the right extend the boom, arm and bucket cylinders fully and after removing the cap to the filler port, reinstall it again and then pressurize the tank.
13. After changing oil, put each of the control levers in neutral, run the engine at a low idle for 2 to 3 minutes and then proceed with operations.



**NOTICE**

Deterioration of hydraulic fluid is much more rapid when hydraulic breakers are installed than with normal bucket excavation operations. Replace oil in accordance with the table on the right.


14. After cleaning or replacing the filter element and strainer, use the following procedure to bleed air from the lines.

**Procedure for bleeding air**

Follow steps 1 through 7 to bleed air from the lines.

**1. Bleed air from pumps**

- 1) Loosen air bleeder (1) that is installed on the drain port and make sure that oil oozes out (this signifies that air has been bled out)
- 2) After air has been bled out, tighten up air bleeder (1)

**NOTICE**

Operating the pump when the pump case is not completely filled with hydraulic fluid will generate extremely high temperatures and may damage the pump prematurely.

**2. Start the engine**

Start the engine according to item 13.2 "Starting the engine" and after running the engine for 10 minutes at a low idle, perform the following procedure.

**3. Bleed air from the cylinders**

- 1) Run the engine at a low idle, and extend and retract each cylinder without going all the way to the end of the stroke (stop at approximately 100 mm from the end of the stroke)
- 2) Next, move each cylinder to the end of its stroke 3 or 4 times.
- 3) Then move each cylinder to the end of its stroke 4 or 5 times and bleed the air out completely.

**NOTICE**

If the engine is initially run at high RPM and the cylinders are allowed to go to the end of their strokes, the piston packing etc. will be damaged by the air in the cylinder.

**4. Bleed the air from the swing motor**

(Do this only when the oil has been replaced in the swing motor case)

- 1) Run the engine at a low idle, loosen air bleeder plug (1) and make sure that oil oozes out from the air bleeder plug (1) (this signifies that air has been bled out)


**NOTICE**

Do not swing the superstructure and arm and boom apparatus at this time.

- 2) If oil does not ooze out, stop the engine, remove air bleeder plug (1) and fill the motor case with hydraulic fluid.
- 3) After the air has been completely bled out, re-insert air bleeder plug (1) and tighten.
- 4) Run the engine at a low idle and swing the superstructure and arm and boom apparatus slowly and steadily to the right at least 2 times.


**NOTICE**

Failure to bleed the air from the oil in the swing motor may damage the bearings in the motor.




**5. Bleed air from the travel motor  
(do this only after replacing oil in the travel motor case)**

- 1) Run the engine at a low idle and detach hose (1) from port C. If oil flows out re-attach it.



- 2) Keeping the engine running at a low idle, swing the superstructure and arm and boom apparatus 90° so that it is perpendicular to the tracks.
- 3) Slowly brace the machine so that a track is slightly raised and run it without a load for 2 minutes and repeat this on both sides. When running the track without a load move it an equal amount forward and reverse.



**6. Bleed air from attachments (When installed)**

When breakers and other attachments are installed, run the engine at a low idle, repeatedly manipulate the attachment pedal (about 10 times) and bleed the air out until air has been completely bled from both the attachment and the lines.

**NOTICE**

**When the manufacturer has stipulated a specific procedure for bleeding air from the attachment, follow that procedure.**

**7. Operation**

- 1) After the air has been bled out from the systems, stop the engine and after waiting at least 5 minutes to resume, start then engine and resume operations. This will allow air bubbles in oil in the tank to escape.
- 2) Check to make sure there are no leaks. Wipe up any oil that was spilled.

### **25.9.3 Clean and check turbocharger**

Seek the assistance of Komatsu or your Komatsu dealer for this service.

### **25.9.4 Check the alternator/ starter**

Seek the assistance of Komatsu or your Komatsu dealer for this service. There is a possibility that brushes have worn and that the bearings have run out of grease. Have this done every 1000 hours if the engine is started frequently.

### **25.9.5 Check and adjust engine valve clearance**

As this requires special tools, seek the assistance of Komatsu or your Komatsu dealer for this service.

## **25.10 SERVICE TO BE PERFORMED AFTER EVERY 4000 HOURS OF OPERATION**

Perform this service together with the service to be performed after every 50, 100, 250, 500, 1000 and 2000 hours of operation.

### **25.10.1 Check the water pump**

Check for noise in the pulley, oil and water leaks and clogging of the drain hole and if anything is amiss, seek the assistance of Komatsu or your Komatsu dealer to repair or replace it.



## **26. INSPECTIONS REQUIRED**

---

### **26.1 Before beginning work (Checks prior to starting operations)**

Check the functioning of the brakes and the clutch.

#### **26.1.1 At least monthly**

1. Whether or not there is abnormal operation of the brakes, clutch, control devices or apparatus.
2. Whether or not there is damage to wire rope and chain etc.
3. Whether or not there is damage to the bucket

### **26.2 Checks before beginning work (Checks prior to starting operations)**

#### **26.2.1 At least monthly**

1. Whether or not there is abnormal operation of the brakes, clutch, control devices or apparatus.
2. Whether or not there is damage to wire rope and chain etc.
3. Whether or not there is damage to the bucket
4. Whether or not there is damage to warning and security devices

#### **26.2.2 At least annually**

Abnormalities of each component

# **SPECIFICATIONS**


## 27. SPECIFICATIONS

### ▪ PC128UU-1

		Vehicles with rubber tracks	Vehicles with steel tracks
Weight			
● Operating weight (not including the operator)		13,000 kg	13,100 kg
Performance			
● Bucket capacity (standard bucket)		0.4 m <sup>3</sup>	
● Width	(Standard bucket)	833 mm	
	(With side cutter)	953 mm	
● Travel speed	(Low speed)	2.4 km/h	
	(High speed)	4.0 km/h	
● Swing speed		10 rpm	
Tracks			
● Rubber tracks		Rubber tracks 500 mm	Triple grouser tracks 500 mm
Engine			
● Name		Komatsu S 4 D95L Diesel engine	
● Rated power		85 PS/2,200 rpm	
● Starter		24 V 5.5 kW	
● Alternator		24 V 24 A	
● Battery		2, 12 V 80Ah	


- Vehicles with rubber tracks
- Vehicles with steel tracks

Figures not in parentheses are those for vehicles with rubber tracks  
 Figures in parentheses are those for vehicles with steel tracks  
 Figures standing alone with corresponding figures in parentheses are the same for vehicles with rubber tracks and vehicles with steel tracks



27. SPECIFICATIONS

- Vehicles with rubber tracks
- Vehicles with steel tracks



AM1001560

# **OPTIONAL PARTS, ATTACHMENTS**

## 28. GENERAL PRECAUTIONS

---

### 28.1 SAFETY PRECAUTIONS

Use of attachments that have not been authorized by Komatsu will not only adversely affect the proper operation of the machine and the useful life of the machine but may also create safety problems. If you are going to install attachments that are not in this manual consult with Komatsu or your Komatsu dealer in advance. Komatsu will not be responsible for any injuries, accidents or equipment breakdowns that are caused by the use of unapproved attachments if you do not contact them in advance.

**⚠ Warning!**

**Precautions in installing and removing**

Observe the following precautions when removing and installing attachments and perform the operation safely.

- Remove or install attachments on firm, level ground.
- If the operation is to be done together by 2 or more persons, decide on signals in advance and follow them during the operation.
- Use a crane to carry heavy objects (weighing more than 25 kg.)
- When removing heavy parts, always support the object before removing it. When hoisting such heavy parts with a crane, be careful of the location of the center of gravity.
- It is dangerous to perform an operation while a heavy object remains suspended from the crane. Always have a platform or stand available and check that it is safe.
- When removing attachments or installing them, make sure that they are placed in a stable position so that they will not fall over.
- Never get under a load that is suspended from a crane. Be in a safe place away from the load so that if it falls there is no danger.

#### NOTICE

The person operating a crane must have the necessary qualifications. Persons without proper qualifications cannot operate them. For details concerning the removal and installation operations seek the assistance of Komatsu or your Komatsu dealer.


## 28.2 PRECAUTIONS WHEN ATTACHMENTS ARE INSTALLED

**Warning!**


Vehicles with long arm and boom apparatus are not as stable, and may lose their balance and topple over when climbing steep slopes or descending them or swinging the superstructure and arm and boom apparatus on an incline.

The following operations are particularly dangerous and should never be done.


- Descending a slope with the arm and boom apparatus raised.



- Traveling across slopes with the machine on a slant



- Swinging the superstructure and arm and boom apparatus on an incline



- When a heavy arm and boom apparatus is installed, the momentum of a such a swinging apparatus is greater so that the distance that the apparatus will travel before it is completely stopped after it has been stopped will increase. This leads to the possibility that operators will misjudge the location where the apparatus will stop and consequently hit something. Operate the machine with a margin of space to where the apparatus will stop. In addition, the hydraulic drift is greatest when a heavy arm and boom apparatus have been installed. Hydraulic drift is the phenomenon of the arm and boom apparatus gradually coming down from its own weight when it has been stopped in mid-air.
- Serious injury or damage may occur if the proper procedure for installing the arm and boom is not followed. Seek the assistance of Komatsu or your Komatsu dealer for this.

When a long arm and boom apparatus is installed, there is danger of mistaking distance and hitting something because the range of arm and boom apparatus has suddenly increased. Operate the machine so that there is ample space between it and surrounding obstacles.



## 29. USING THE BUCKET WITH HOOK

### 29.1 CHECKING THE BUCKET WITH HOOK ATTACHED FOR DAMAGE


Check for damage to the hook, stopper or hook mount. If there is anything wrong seek the assistance of Komatsu or your Komatsu dealer for this service.

### 29.2 OPERATIONS THAT SHOULD NOT BE PERFORMED

#### ■ Do not use for hoisting

The use of this machine for hoisting operations is prohibited. However it can be used for the purposes specified in Article 164 of the Labor Safety and Hygiene Regulations.



In such cases, a special hook for hoisting is necessary. For details seek the assistance of Komatsu or your Komatsu dealer.



### 29.3 PRECAUTIONS DURING OPERATION

#### ■ Precautions during hoisting operations

- Reduce engine RPM during hoisting operations and perform them in precision operation mode.
- Always restrict operations to the hoisting operations specified in Article 164 of the Labor Safety and Hygiene Regulations.
- Always pay attention to the angle of the hook so that the wire or hoisting ring will not come off. They can come off depending on the position of the hook.
- Never change the direction of the machine while engaged in hoisting operations.
- If the bucket with hook attached is inverted it will hit the arm when dumping the contents of the bucket so be careful.
- Do not exceed these weight loads when doing hoisting operations.



Standard Arm	600 kg
Long Arm	500 kg

- If you are on the verge of installing a hook or plan on doing so in the future seek the assistance of Komatsu or your Komatsu dealer for this service.



**MEMO**

---

## 30. USING SEAT BELTS

---


### 30.1 SEAT BELTS

**⚠ Warning!**

- Before fastening seat belts, check the belt and the securing brackets to see if anything is amiss. If they are worn or damaged, replace them.
- Adjust the seat belts and fasten them prior to beginning operations
- Always wear seat belts when operating the machine.
- Untwist the seat belt before fastening them. Do not use them while they are twisted.

#### 30.1.1 Fastening and removing belts

1. Sit in the seat and adjust it so that you can fully operate the pedals and have sufficient leg room while your back is in contact with the back of the seat.
2. After adjusting the seat, sit in the seat, take the female part of the buckle (1) and male part of the buckle (2) in your left and right hands, insert the male part in the female part of the buckle and make sure that it is securely fastened by pulling on the belt.
3. To remove the belt, raise the tip of the lever on the top of the female portion of the buckle (1) and the belt will release.




Adjust both of the belts so that they will fit your body without twisting, and so that the buckle will be midway across the front of your body.

### 30.1.2 Adjusting the belt length

- **Shortening**

Pull the free end of the belt on either the sides of the belt.




- **Lengthening**

Pull the belt while holding it at a right angle to either part of the buckle.

Check to make sure that the bolts which fasten the belt hardware to the chassis are not loose. If they are tighten them.

Tightening torque is  $2.5 \pm 0.5$  kgm.

Replace the seat belts if they appear to be frayed or damaged or if the hardware is damaged or bent.



## 31. INFORMATION ON OPTIONAL ATTACHMENTS

### 31.1 INFORMATION ON OPTIONAL ATTACHMENTS

Name	Specifications, use
Narrow bucket (Vertical pin)	Capacity width .16m 450mm
Narrow bucket (Vertical, horizontal pin)	Capacity width .16m 450mm
Narrow bucket (Vertical, horizontal pin)	Capacity width .16m 450mm
Standard bucket (Horizontal pin)	Capacity width .16m 450mm
Heavy duty bucket (Vertical, horizontal pin)	Capacity width .16m 450mm
Heavy duty bucket (Vertical, horizontal pin)	Capacity width .16m 450mm
Light duty bucket (Vertical, horizontal pin)	Capacity width .16m 450mm
Tracks	Triple track700 mm width triple track600 mm width triple track500 mm width Smooth track480 mm width Wetlands track750 mm width Rubber pad track500 mm width Connecting link type (SSK) rubber track500 mm width
Long arm	Arm length2,430 mm Maximum excavating depth5,140 mm
Cold weather area (B) specifications	Can start 5 minutes after preheating at temperatures of -30°C.
Head guard	A device for protecting the operator which should always be used in job sites where there is the danger of falling rocks and boulders etc.

- Various others are available such as rear underview mirrors, mono-booms, multi-operation patterns (rotary valve type), cab front guards, automatic linear excavation etc. Seek the assistance of Komatsu or your Komatsu dealer for this.

31. INFORMATION ON OPTIONAL ATTACHMENTS

**31.2 ATTACHMENT COMBINATION TABLE**

This is a list of the buckets you can attach to the standard arm and the long arm.

0 means that it can be used

X indicates that it cannot be used

**NOTICE**

Be careful because when the long arm is installed, the bucket will hit the body of the machine if it is pulled in as close to the machine as it can go. It will also hit the undercarriage when excavating diagonally.

**Categories of use**

General excavation: Excavating or loading sand, gravel and clay

Light excavation: Digging or loading dry, loose soil, sand, and mud

Loading: Loading dry, loose soil and sand

- We recommend the heavy duty bucket which is superior in durability and resistance to wear when excavating or loading compacted soils, or soft rock

Name	Type of tooth mounting pin	Capacity (m <sup>3</sup> )	Outside width (body) (mm)	Outside width (side cutter) (mm)	Model	Use	Standard Arm	Long Arm
					PC128UU			
Narrow bucket	(Vertical pin)	0.16	450	570	OP	For narrow width excavation	○	○
Narrow bucket	(Vertical, horizontal pin)	0.26	600	720	OP OP	For narrow width excavation	○	○
Narrow bucket	(Vertical, horizontal pin)	0.33	700	820	OP OP	For narrow width excavation	○	○
Standard bucket	(Horizontal pin)	0.40	833	953	Standard OP	For general excavation	○	X
Heavy duty bucket	(Vertical, horizontal pin)	0.40	833	953	OP OP	For heavy duty excavation	○	X
Heavy duty bucket	(Vertical, horizontal pin)	0.45	859	979	— —	For heavy duty excavation	○	X
Light duty bucket	(Vertical, horizontal pin)	0.45	859	979	OP OP	For general excavation	○	X

OP: Indicates option

### 31.3 SELECTING TRACKS

Select suitable tracks according to the conditions and demands of the operation.

#### ■ How to select tracks

Select the applicable use from the next table and then select the track from succeeding table. Categories "B" and "C" have limited uses since they are wide shoes. Select the appropriate tracks, taking into account the precautions necessary at the time they will be used and based on a thorough study of the conditions under which they will be used.

When selecting track widths, select as narrow a track as possible within a range which will not be a problem with the floating of the body or compaction of the soil. If you use tracks that are wider than necessary there will be a greater load on the tracks, tracks will bend, links will crack, pins break, and bolts will loosen.

Category	Use	Precautions necessary when using
A	Rocky soil, river beds, normal soil	<ul style="list-style-type: none"> <li>Use low speed range on rough ground that has large obstacle like boulders and fallen trees.</li> </ul>
B	Normal soil, soft soils	<ul style="list-style-type: none"> <li>Cannot use on rough ground that has large obstacle like boulders and fallen trees.</li> <li>The accelerator pedal is only used for travel on level ground, if obstacles must be traversed, reduce speed and travel by 1/2 in low.</li> </ul>
C	Extremely soft soils (wetlands)	<ul style="list-style-type: none"> <li>Use only in places in which A and B tracks would sink and could not be used.</li> <li>Cannot use on rough ground that has large obstacle like boulders and fallen trees.</li> <li>The accelerator pedal is only used for travel on level ground, if obstacles must be traversed, reduce speed and travel by 1/2 in low.</li> </ul>
D	Paved surfaces	<ul style="list-style-type: none"> <li>Must be careful because climbing ability is poor as tracks are flat and smooth.</li> </ul>
E	Paved surfaces	<ul style="list-style-type: none"> <li>Cannot be used where there are fragments of concrete, gravel, in river beds with many rocks or on the surface of rocks.</li> <li>Be careful of sliding on wet surfaces or on ice and snow</li> <li>Refer to 31.4 "Using rubber pad tracks"</li> </ul>
F	Paved surfaces	<ul style="list-style-type: none"> <li>Refer to 13.20 "Using rubber tracks"</li> </ul>


	Specification	Category
Standard	500 Rubber track	F
Optional	500 Triple	A
Optional	600 Triple	B
Optional	700 Triple	C
Optional	750 Wetlands	C
Optional	480 Flat	D
Optional	500 Rubber pad	E
Optional	500 connecting link	F



### 31.4 USING RUBBER PAD TRACKS

When using rubber pad tracks, always observe the following precautions in handling.

- **Work site conditions**
  - Use rubber pad tracks mainly for work on paved surfaces. If used on surfaces other than pavement, the rubber will tear and crack and durability will drop significantly. In particular avoid working under the following conditions:
    - On broken concrete fragments or on gravel
    - On sharp protruding things like iron rods and glass (especially pilings that have been driven into the ground)
    - Over the edge of shoulders of concrete roads, on the surface of rocks or river beds with many rocks.
  - Be careful of slipping on road surfaces covered with water, ice, snow or gravel. Be particularly careful of this when unloading the vehicle.
  - Because of the physical properties of rubber, use rubber pad tracks between -25°C to 65°C.
  
- **Operating Conditions**
  - Operations such as those shown in the diagram in which there is a significant strain on the tracks, side digging operations, operations on slopes and driving and frequently changing direction will place an undue burden on the rubber and cause damage.
  - When special kinds of arm and boom apparatuses are installed the durability of the rubber cannot be guaranteed.




### 31.5 USING THE AUTOMATIC LEVELING DEVICE

**Warning!**

Automatic operation with the wrong method may lead to unpredictable movement of the arm and boom apparatus and cause a serious accident involving injury or death.

#### 31.5.1 Explanation of each device




#### 1. Display

Displays the gradient when automatic leveling is being done. (Displayed in degrees) The way gradient is displayed is as shown in the diagram on the right.

#### Additional explanation


When the automatic leveling device is set, all three indicator lights will flash.



### 31. INFORMATION ON OPTIONAL ATTACHMENTS

#### 2. Automatic leveling device setting switch



Use this when you are going to perform automatic leveling. If you push it once it will turn ON, if you push it again it will then turn off. When it is ON, you can perform automatic leveling by double clicking the knob switch.



#### 3. Bucket position select switch

This is a switch that is used to select a bucket position with respect to the slope that is going to be graded when using the automatic leveling device.



- Flat face: Fixes the bucket position with respect to the surface to be excavated.
- Blade edge: Fixes the bucket position with respect to the arm
- Automatic: Before excavation begins, automatically judges from the bucket position whether it is to be flat face or blade edge and proceeds to excavate.



#### 4. Excavation direction select switch


This is a switch that is used to select the direction to be excavated when using the automatic leveling device.

- Pull in: Will excavate with the arm pulling in.
- Pushing out: Will excavate with the arm pushing out
- Automatic: Before excavation begins, automatically judges from the position of the arm whether it is to be pulling in or pushing out and proceeds to excavate.




#### 5. Increase /decrease gradient switch

This is a switch to fine tune gradient when automatic leveling is being done. The up arrow indicates increase, the down arrow indicates decrease.



**6. Knob switch (option)**


The knob switch on the level control lever for the arm and boom apparatus is used for instantly increasing excavation power and for activating the automatic leveling feature.



How to use the knob switch


**1. For increasing excavation power**

Push it once and continue pushing (single click). The increase in excavation power will last a maximum of 8.5 seconds.



**2. Automatic leveling feature**


After pushing it lightly once and then removing the hand push the knob switch again (double click) and continue pushing. This feature will only be activated while the switch is being pushed. Press it the first and second times within an interval of 2 seconds.



### 31.5.2 Using the automatic features

**⚠ Warning!**

- If the automatic features are used without proper warming up of the machine, the features will not work properly, so always warm up. Particularly in cold weather, warm up the machine sufficiently.
- Automatic operation with the wrong method may lead to unpredictable movement of the arm and boom apparatus and cause a serious accident involving injury or death.
- The only buckets that can be used are Genuine Komatsu Buckets with optional settings for the PC128UU.
- When using the STD buckets (Genuine Komatsu 0.4 M<sup>3</sup>) data does not need to be rewritten. When using the Genuine Komatsu 0.45 M<sup>3</sup> bucket data will need to be rewritten so seek the assistance of Komatsu or your Komatsu dealer for this service.
- Do not use the automatic operation when the bucket is reversed.
- When the arm is changed, calibration will be necessary just as it would be if the bucket was changed. Seek the assistance of Komatsu or your Komatsu dealer for this service. The device will not operate properly if arms other than those recommended by Komatsu are used.
- The automatic features will not operate properly if the standard arm and boom apparatus is replaced by attachments. If you are planning to use attachments other than those specified by Komatsu use them after seeking the assistance of Komatsu or your Komatsu dealer.
- Do not remove sensors, install them or take them apart. This will cause faulty operation of the automatic features. Always seek the assistance of Komatsu or your Komatsu dealer for this service.
- If you strike the sensors on something or discover that they have been damaged, check the operation of the automatic features. If anything is amiss, seek the assistance of Komatsu or your Komatsu dealer for inspection and repair service.



**Warning!**

- Do not perform any operations that will immerse the sensors in water. If by some chance the sensors have been immersed check the operation of the automatic stop system.
- If there is a problem request inspection and repair service from Komatsu or your Komatsu dealer.

**NOTICE**



- If there is an abnormality in the system the controller will perform a self-diagnosis, and display an error code on the monitor panel.
- Depending on what has gone wrong with the systems, the controller will not perform a self-diagnosis and you may not be able to manipulate the arm and boom apparatus. After moving the machine to a safe location, ask Komatsu or your Komatsu distributor to check the machine.
- Before using the automatic features, always perform the checks before starting and after starting the machine. In cold weather use the features after warm up operation. If the amount of hydraulic fluid is low, the features will not operate properly.

- Before operating the feature

- Double click

When using the automatic features, many of them use the knob switch on the left control lever for the arm and boom apparatus. To use the automatic feature "double click" this switch.




Double clicking means after pushing it lightly once and then removing the hand push the knob switch again (double click) and continue pushing. This feature will only be activated while the switch is being pushed. Press it the first and second times within an interval of 2 seconds.




■ **Automatic operation**


Linear excavation with the bucket blade edge or flat face with the desired gradient can be done and the following finishing operations can be done.

- Finishing of surfaces on which roads will be paved.
- Finishing of ditch bottom surface
- Raking operations
- Surface grading operations
- Spreading and filling in operations






1. Move the bucket to place the bucket blade angle at the gradient that you want to finish.




2. Push the automatic leveling setting switch (1). The monitor display will change from displaying depth and will display the desired gradient (in degrees) and the lights for depth, height and offset will all three flash and a buzzer will sound 2 times at the same time.




3. You can modify the desired gradient with the gradient increase/ decrease switch (4).

4. Place the fuel adjustment control lever in the full (MAX) position.





5. After lightly pressing the knob switch on the left control lever once and then releasing it and pressing it again and continuing to press (double clicking), a buzzer will sound twice and leveling will begin. If you release pressure on the knob switch, leveling will cease.





## 31. INFORMATION ON OPTIONAL ATTACHMENTS

6. If you once again press the leveling set switch (1) the automatic leveling feature will be turned off and the lights on the depth, height and offset indicators will come on and return to displaying depth.
7. Excavation angle is determined with the position of the excavation direction selection switch (3).
  - Pulling in: The arm will excavate in the pulling in direction
  - Pushing out: Will excavate with the arm pushing out
  - Automatic: Before excavation begins, automatically judges from the position of the arm whether it is to be pulling in or pushing out and proceeds to excavate.
8. The position of the bucket is determined with the position of the bucket position selection (2).
  - Flat face: Fixes the bucket position with respect to the surface to be excavated.
  - Blade edge: Fixes the bucket position with respect to the arm
  - Automatic: Before excavation begins, automatically judges from the bucket position whether it is to be flat face or blade edge and proceeds to excavate.
9. After the automatic feature has been started, operating the control levers (other than the travel control levers and the swing control lever) will end the operation of the feature as operating the levers will override the feature.
10. To display the actual gradient, hold the knob switch on the left control lever. Be careful though because if you mistakenly push the knob twice within 2 seconds the automatic excavation will begin.



### NOTICE

- When the temperature is cold, warm up the machine prior to using this feature. When the machine is not sufficiently warmed up, the straight lines will not be as precise.
- Perform leveling excavation with the fuel adjustment control lever in the full position. When the machine is not running at full power, the straight lines will not be as precise.
- When the soil is hard and compacted and when the load on the bucket is large, the straight lines will not be as precise.

- The feature is set so that it will be sufficiently precise when there is a load ( when the bucket is pushing with its bottom)
- There is an inclination gauge installed on the machine which compensates for the inclination of the machine fore and aft. The tolerance value is an inclination of the machine at  $\pm 17$  degrees. If this is exceeded the gradient will not be as precise.
- The inclination gauge only measures the inclination fore and aft so that if the machine is leaning to the side there will an error in the gradient set.
- Put the right and left control levers for the arm and boom apparatus in neutral when double clicking the knob switch to start linear excavation. If these levers are not in the neutral position, linear excavation will not begin.
- When excavating with the bottom of the bucket, because of the position, the bucket will reach the end of the stroke on its cylinder when the arm is only in mid-stroke of its cylinder so that excavation will cease.
- In operations in which lifting and lowering is nearly vertical, the automatically chosen direction of excavation will sometimes be the direction opposite from what the operator intends. If this happens, fix the setting for direction of excavation.
- Automatic deceleration will not operate while automatic leveling is operating.
- If the ignition switch is turned OFF, and the display goes off, the memory for the gradient set will be cleared.
- Depth, height and offset modes cannot be set at the same time.
- Operation will not be as precise when the feature is operated automatically near the end of the stroke of the arm cylinder. Avoid operating near the end of the stroke.

### 31.5.3 Troubleshooting the automatic leveling system

When error codes other than for the standard vehicle (those of the 4 systems) are displayed on the display of the monitor panel, refer to the table below.

Error code	Problem phenomenon	Chief cause	Corrective measure
42	Cannot excavate automatically	Defective bucket potentiometer	Normal operations can be performed but should be checked immediately
44		Defective inclination gauge	
64		Defective automatic excavation solenoid	
82	Cannot dump arm	Defective arm dump EPC solenoid	After moving the machine to a safe place with the override switch, have it checked immediately
84	Cannot excavate automatically	Defective bucket excavation EPC solenoid	Normal operations can be performed but should be checked immediately
88		Defective bucket excavation EPC solenoid	
A1		Defective boom H pressure sensor	
A2		Defective boom B pressure sensor	
A4		Defective boom H pressure sensor	
A8	Defective boom B pressure sensor		


### 31.6 USING THE MONO-BOOM

#### 31.6.1 Service to be performed after every 100 hours of operation


For other maintenance follow the maintenance items for standard vehicles.

■ Greasing


1. Stop the engine after placing the machine in the position for greasing shown below and the arm and boom apparatus is set in place.
2. Grease the apparatus at the grease fittings indicated by the arrows using a grease gun.
3. Wipe off old grease that has been forced out after greasing.



1. Grease boom cylinder foot pin (2 points)




2. Grease boom foot pin (2 points)
3. Grease boom cylinder rod end pin (2 points)
4. Grease arm cylinder foot pin (1 points)




### 31. INFORMATION ON OPTIONAL ATTACHMENTS

---


- 5. Grease boom/ arm connector pin (1 point)
- 6. Grease arm cylinder rod end pin (1 point)
- 7. Grease bucket cylinder foot pin (1 point)



- 8. Grease arm/ link connector pin (1 point)
- 9. Grease arm/ bucket connector pin (1 point)




- 10. Grease link connector pin (1 point)
- 11. Grease bucket cylinder rod end pin (1 point)
- 12. Grease bucket/ link connector pin (2 points)



### 31.7 USING VEHICLES TO WHICH ATTACHMENTS CAN BE INSTALLED (MONO-BOOM)

#### 31.7.1 Explanation of each device




AE057930

#### 1. Stop valve

This is a valve which stops the flow of hydraulic fluid

- (1) Free: Hydraulic fluid flows
- (2) Locked: Hydraulic fluid stops

Place this valve in the locked position when removing or installing attachments.




F20248

#### 2. Switch valve

This valve switches the flow hydraulic fluid.

- Position (1): When using a breaker
- Position (2): When using general attachments (crusher, etc.)




AE057940

## 31. INFORMATION ON OPTIONAL ATTACHMENTS

### 3. Pedal lock (for the pedal used for operating attachments)

**Warning!**

When not operating the attachments, lock the pedal. If the pedal is mistakenly moved when it is not locked serious incidents may occur.




This is a device which locks the pedal used for operating attachments.

Lock the plate in position so that it covers the pedal.


### 4. Operating pedal

This pedal operates the attachments



### 5. Flow volume adjustment pins

Adjusting the height of the right and left pins (A) of the operating pedal adjusts the flow volume. Remove beater pin (B) and pin (C) and set pin (A) in position (1) or (2) and stop with pin (c) and beater pin (B).




### NOTICE

There are pins in two different places. Adjust both the right and left pin to the same height.

Position (1): Full flow volume (when using crushers, power rippers and other attachments with large flow volumes)


Position (2): Half flow volume (when using breakers and other attachments with a small flow volume)



### 6. Additional filter for the breaker

This prevents the deterioration of hydraulic fluid when using the breaker.

Hydraulic fluid will only flow through this when the switch valve is set in the breaker position.








## 31. INFORMATION ON OPTIONAL ATTACHMENTS

### ■ The flow path of the hydraulic fluid

The pedal movements and the flow path of the hydraulic fluid are as shown in the diagram below.



### 31.7.3 Operation


**⚠ Warning!**

- Be careful because on vehicles which have automatic deceleration (this is optional equipment) installed, the engine RPM may suddenly increase when operating the pedal in the deceleration range.
- Do not place your foot on the pedal except when operating it. If you operate the machine with your foot resting on the pedal you may accidentally depress the pedal which would cause the attachment to move suddenly which is very dangerous and may lead to an accident causing serious injury.


Operate the attachment as follows.

### 31.7.4 When using the breaker


Place the pedal lock in the free position. Depress the pedal to operate the breaker.




- Precautions when using
  - Make sure that the stop valve is in the free position.



- Make sure that the switch valve is set in position for using the breaker.



- Make sure that the stopper bar (1) for the switch valve spool is installed in the breaker position.




## 31. INFORMATION ON OPTIONAL ATTACHMENTS

Refer to 31.7.2 "Hydraulic lines" for the flow of the path of the hydraulic lines.


- Decide whether or not you need to install an accumulator for the attachment by consulting with the manufacturer of the attachment.
- For other precautions in using breakers, follow the directions specified by the manufacturer of the breaker in the operations and maintenance manual and use the breaker properly.
- Since the deterioration of hydraulic fluid is much more rapid when using a breaker than when doing normal operations, perform maintenance service on the hydraulic fluid and the filter element more frequently than normal. See 24.2 "Service times when using hydraulic breakers."

### 31.7.5 When using general attachments such as crushers

Place the pedal lock in the free position. Depress the pedal to operate the breaker.




- Precautions when using
- Make sure that the stop valve is in the free position.




- Make sure that stopper bar for the switch valve has been installed in the general attachment/ crusher position.

Refer to 31.7.2 "Hydraulic lines" for the flow of the path of the hydraulic lines.



- Make sure that the switch valve is set in position for using the crusher and other general attachments.
- For other precautions in using attachments, follow the directions specified by the manufacturer of the attachment in the operations and maintenance manual and use the attachment properly.



### 31.7.6 Using the Accumulator

**⚠ Warning!**

The accumulator is filled with nitrogen gas under high pressure. Improper handling is extremely dangerous. Observe the following precautions strictly.


- Do not make a hole in the accumulator or expose it to flames.
- Do not weld any boss to the accumulator.
- You should release the gas in the accumulator when disposing of it. Seek the assistance of Komatsu or your Komatsu dealer for this service.

### 31.7.7 Long term storage

When you do not intend to use the machine for a long time do the following:

- Place the stop valve in the locked position.
- Install the blind plug in the valve.
- Place the switch valve in the setting for crushers and other general attachments.

If you depress the pedal when the breaker and other general attachments are not installed on the machine, this will cause the machine to overheat etc.




### 31.7.8 Specifications

Hydraulic specifications

- Flow volume

Position of flow volume control pin	Flow volume
(1)	200 ℓ/min.
(2)	100 ℓ/min.



- Safety valve crack pressure

When using a breaker: 175 kg/cm<sup>2</sup>  
 When using other attachments: 250 kg/cm<sup>2</sup>

### 31.8 SWITCHING OPERATION PATTERNS (ON MACHINES WHICH HAVE A PATTERN SWITCHING VALVE INSTALLED)

When a pattern switching valve is installed, the patterns for operating the right and left control levers for the arm and boom apparatus can be switched to follow the preference of the person operating the machine.

**Warning!**

Before starting the engine, check the positions of the pattern switching valve to see which operating pattern is in effect.




#### 31.8.1 Switching patterns

1. If you move the floor mat on the left side of the operator's seat where you climb in and out of the cab, there is a switch for the pattern switching valve.
2. Change the pattern according to the caution plate that is on the floor cover and on the pattern switching valve.


You may switch to one of the following four patterns with the pattern switching valve.

#### Operating patterns


- Komatsu pattern
- ISO pattern



- Mitsubishi pattern




- Kobe Steel pattern



2. Place an operating sheet (magnetic type) in the cab that conforms to the pattern selected.

- Where to place the operating sheet

Place the operating sheet on the right side of the driver's seat in the approximate location indicated by the arrow in the diagram on the right.





**DataKom Publishing Corporation**  
 440 North Fairway Drive  
 Vernon Hills, IL 60061-8112 U.S.A.  
 Attn: Service Publications  
 Fax No. (847) 970-4186

**PROPOSAL FOR MANUAL OR CSS REVISION**

DATE:	FOR INTERNAL USE ONLY -- No. PMR					
P R O P O S E R	NAME OF COMPANY:	CITY:				
	DEPARTMENT:	STATE OR PROVINCE::				
	NAME:	COUNTRY:				
		FAX NO:				
MANUAL DESCRIPTION:	CSS PROGRAM - e.g: Lookup, Parts or Service					
MANUAL OR CSS CD NO:	CSS PROGRAM RELEASE VERSION:					
MANUAL OR CSS CD ISSUE DATE:	CSS BOOK PUBLISHER:					
BOOK DESCRIPTION MACHINE MODEL & S/N:						
MANUAL SECTION/PAGE NUMBERS OR CSS REFERENCE & PAGE NUMBERS:						
PROBLEM:						
<p>Attach photo or sketch.          If more space is needed, use another sheet.</p>						
<div style="border: 1px solid black; display: inline-block; padding: 2px;">FOR INTERNAL USE ONLY</div>						
CORRECTIVE ACTION:		<table border="1" style="width: 100%; height: 40px; border-collapse: collapse;"> <tr> <td style="width: 25%;"></td> <td style="width: 25%;"></td> <td style="width: 25%;"></td> <td style="width: 25%;"></td> </tr> </table>				
