


Chapter 5



Gearbox

TABLE OF CONTENTS

- 5A10 - ML260 - General
- 5A11 - ML260 - Error codes
- 5A12 - ML260 - Diagrams and plans
- 5A13 - ML260 - Layout of components
- 5A14 - ML260 - Tests and diagnostics
- 5A15 - Section intentionally left blank
- 5A16 - ML260 - Adjustments, bleeding and calibrations
- 5A17 - ML260 - Disassembly and reassembly
- 5A18 - ML260 - Service tools

5A10

ML260 - General

TABLE OF CONTENTS

A. General	3
B. Transmission operating principle	3
C. Transmission operating principle diagrams	8

A. General

ML 260 type transmission

M	Marshall, the original engineer of this development
L	Power distribution between the mechanical and hydraulic parts
260	Average power that can be transmitted to the wheels

The Dyna-VT transmission is a forward and reverse continuous transmission. The switch from Hare/Tortoise range with synchronisation is built into the transmission. The Tortoise range permits forward speeds of 0 to 32 kph. The Hare range permits forward speeds of 0 to 50 kph (depending on country regulations). The standard maximum speed is electronically limited to 40 kph. The Tortoise range is intended for heavy traction work at low forward speeds, below 18 kph. The Hare range is intended for driving on roads (transport). At 50 kph, the transmission ratio is controlled electronically according to engine speed. Power transmission can be hydrostatic OR mechanical or hydrostatic AND mechanical. In simple terms:

- Slow forward travel: Power transmission is mainly hydrostatic/partially mechanical.
- Fast forward travel: Power transmission is partially hydrostatic/mainly mechanical.

For detailed explanations, see the transmission operating diagram.

B. Transmission operating principle

Power transmission hydrostatic system

The Dyna-VT transmission unit is elastically suspended inside the transmission housing. The latter also acts as an oil tank for the hydrostatic transmission.

Filling: Terrac Extra or Terrac Tractran 9/Fluid 9 oil, or any other oil complying with the standard CMS M1143 or CMS M1145.

The lubrication pump sucks oil through the suction strainer. The temperature sensor (X19) monitors the temperature of the transmission oil. Put simply, if the transmission oil is cold, a small amount of oil passes into the cooler and a lot of oil passes through the bypass valve. This valve opens at a differential pressure of approximately 3.5 bar. The temperature of the hydraulic oil is monitored by the temperature sensor (X19). The service pump produces the system pressure for the Dyna-VT control spool valves and the accessory control solenoid valves. The system pressure of approximately 18 bar is limited by a pressure relief valve with throttling port.

Two different pressures are present in the system:

- Low pressure for the Dyna-VT transmission control and auxiliary pressure for the rear PTO clutch and differential lock. The measurement point of this pressure is approximately 18 bar.
- High pressure inside the Dyna-VT transmission. Pressure measurement point: approx. 530 + 20 bar max.

Oil filter blockage is monitored by a pressure switch according to the transmission oil temperature. When this temperature is below 50°C, oil filter blockage is not monitored.

Cooled transmission oil enters the high-pressure system alternately via two non-return valves. Hot transmission oil leaves the high-pressure system via the pressure relief valve.

The following can be found inside the high-pressure system: a variable displacement pump and two hydrostatic motors, two non-return valves, two controlled high-pressure limiter valves, a relief valve, a coupler function solenoid valve, a clutch function controlled valve and a check connector. The adjustment rams for the pump and the motor are controlled by two 4/3 spool valves. These 4/3 spool valves are mechanically controlled by the cam channel control shaft. The control shaft is rotated as required by the control unit, which defines the flow rate and therefore the hydraulic power.

The variable displacement pump and the hydrostatic motors pivot proportionally. In limp home position, the adjustment shaft is manually activated from the operator's cab. In limp home position, the transmission is automatically locked on approximately 30 kph after engine start-up. If the clutch pedal, parking brake or neutral switch is used, the high-pressure system is automatically relieved by means of two high-pressure relief valves. The coupler function is controlled by the pressure relief valve.


The control unit

The control unit operates the cam channel control shaft, which modifies the Dyna-VT transmission ratio.

The control unit comprises the following components:

- Limp home mode control (required in the event of electronic control failure)
- Coupling for the incremental angle of rotation sensor control with a digital resolution of 8000 pulses per revolution
- Epicyclic gear train transmission $i = 192:1$ (electric motor for the adjustment shaft)
- 12 VDC electric motor, 0.4 to 7 amps, control unit maximum speed without load 4500 rpm
- Friction clutch 2.5 to 3.5 Nm, with limp home lever end fitting, 4 to 5 Nm.

After switching on the ignition, the control unit searches for the reference point (approximate neutral point between forward and reverse drive).




1006199

Fig. 1

Sensors

Engine sensor (X25)

Measures engine speed. In the event of a fault, only the limp home mode can be used.



1006201

Fig. 2

Hall sensor for collector shaft (X10) and pinion (X8)

Measures the speed and recognises the direction of rotation.




1006202

Fig. 3

High-pressure sensor (X34) and (X9)

Transmits the instantaneous oil pressure in the high-pressure system to the electronic system (Fig. 4). A second high-pressure sensor has been added. It is used for the shifting and DTM functions (Dynamic Transmission Management).




1006203

Fig. 4

Throttle pedal sensor

Transmits the throttle pedal position to the electronic system and compares it to the engine speed. This angle sensor will be used for load regulation.



1006206

Fig. 5

Clutch pedal potentiometer sensor:

Electronically monitors the clutch pedal travel.



1006208

Fig. 6

Hare/Tortoise position sensor (X17)

Electronically monitors the position of the range selector switch.




1006209

Fig. 7

Temperature sensor

Monitors the temperature of the transmission oil. Temperatures greater than 110°C are stored with an error code.



1006211

Fig. 8

HP filter blockage sensor (X20)

Monitors the blockage status of the high-pressure filter.




1006212

Fig. 9

C. Transmission operating principle diagrams


- (E) Planet carrier, driven by the heat engine
- (F) Ring gear, drives the hydrostatic pump
- (G) Planet gear
- (H) Sun gear, drives the collector shaft



1006219

Fig. 10

Epicyclic gear train/Power distribution




1006220

Fig. 11

- (A) Transmission of mechanical force
- (B) Transmission of hydrostatic force
- (C) Power take-off drive
- (D) Front axle drive
- (1) Epicyclic gear train.
- (2) Hydrostatic pump
- (3) Collector shaft
- (4) Hydrostatic motors
- (5) Range shifting

Dynamic stop



1006221


Fig. 12

Engine started, tractor at standstill

- (A) Transmission of mechanical force
- (B) Transmission of hydrostatic force

- The heat engine drives the planet carrier (E) (Fig. 10).
- The ring gear (F) turns, driving the pump (2) which has a zero flow rate.
- The hydrostatic motors (4) do not turn
- The sun gear (H) does not turn because it is locked by the tractor wheels via the rear axle crown wheel and pinion.

Start-up




1006222

Fig. 13

99% transmission of hydrostatic power, 1% transmission of mechanical power.

- (A) Transmission of mechanical force
- (B) Transmission of hydrostatic force
- The pump (2) is angled and supplies flow to the motors (4).
- The motors (4) drive the rear axle.
- The sun gear starts to turn and the ring gear speed decreases

Average forward speed



1006223


Fig. 14

50% transmission of hydrostatic power, 50% transmission of mechanical power.

- (A) Transmission of mechanical force
- (B) Transmission of hydrostatic force

- The angle of the pump (2) increases.
- The pump flow rate increases and the angle of the motors (4) is reduced.
- The sun gear speed increases, which increases the speed of the crown wheel and pinion.
- The planet carrier speed is constant.
- The ring gear speed decreases.

Transport



1006224

Fig. 15


Reduced engine speed, 100% transmission of mechanical power.

(A) Transmission of mechanical force

(B) Transmission of hydrostatic force

- The angle of the motors (4) is zero and the flow from the pump is blocked.
- The pump (2) does not turn; therefore the ring gear does not turn.
- The planet carrier turns.
- The sun gear turns, driving the crown wheel and pinion alone.

Reverse



1006226

Fig. 16

Average speed, 100% transmission of hydrostatic power, the ring gear turns faster than the heat engine.

(A) Transmission of mechanical force

(B) Transmission of hydrostatic force

- The flow from the pump (2) is reversed (pump tilted to the opposite angle)
- The motors (4) turn in the opposite direction.
- The sun gear therefore turns in the opposite direction to the planet carrier, also driving the crown wheel and pinion in the opposite direction.
- The ring gear speed increases

Layout of the hydrostatic components


For conventional hydrostatic components, the angle of rotation reaches only 30°.

Example of a conventional variable displacement pump with axial pistons.

In contrast to the hydrostatic components, this system is specially designed to provide an angle of rotation of 45° .

Example of a special variable displacement pump with axial pistons. This represents:

- Higher intrinsic yield of hydrostatic components with respect to conventional components.
- An angle of rotation of 45° offers the possibility of increasing the scope of the forward speed, resulting in a reduced number of mechanical ranges.



1007084

Fig. 17










5A11

ML260 - Error codes

TABLE OF CONTENTS

- A. Reading error codes 19
- B. Transmission error codes 20
- C. 4WD/Differential lock error codes 22
- D. Armrest error codes 23
- E. Instrument panel error codes 24

A. Reading error codes

ERROR CODES DISPLAYED ON THE INSTRUMENT PANEL				
	DISPLAY with Dash Control Center			DISPLAY without Dash Control Center
Instrument panel		+	Letter D (Dashboard)	Letter D (Dashboard)
Engine		+	Letter E (Engine)	Letter E (Engine)
SCR system	no icon		Letter U (Urea)	Letter U (Urea)
Transmission/4WD/PTO		+	Letter T (Transmission)	Letter T (Transmission)
Lights module		+	Letter L (Light)	Letter L (Light)
ParkLock		+	Letter P (ParkLock)	Letter P (ParkLock)
Front axle		+	Letters FA (Front Axle)	Letters FA (Front Axle)
Linkage		+	Letters R (Linkage)	Letter R (Linkage)
Electrohydraulic		+	Letters H (Hydraulics)	Letter H (Hydraulics)
Cab		+	Letters C (Cab)	Letter C (Cab)
Auto-Guide		+	Letters A (Auto-Guide)	Letter A (Auto-Guide)
Control Arm		+	Letters AR (ARmrest)	Letter AR (ARmrest)

OTHER DISPLAYS	
Automatic air conditioning	Displayed on the air conditioning module.

B. Transmission error codes

No.		Components concerned	Causes
T	4105	X34 - Transmission oil high pressure sensor 2	Signal error - 8.5 V supply error
T	4107	X9 - Transmission oil high pressure sensor 1	Signal error - 8.5 V supply error
T	4108	X17 - Hare/Tortoise range position sensor	Signal error - 8.5 V supply error
T	4121		Signal error
T	4127	X10 - Collecting shaft speed sensor	Signal error
T	4128	X18 - Transmission control module	Signal error
T	412A	X8 - Bevel gear theoretical speed sensor	Signal error
T	412B	X123 - Hare/Tortoise range shift switch	Signal error
T	4131	X10 - Collecting shaft speed sensor	Direction of rotation signal error
T	4142		Rotation speed signal error
T	4144	X25 - Engine speed sensor	Signal error
T	4145	X8 - Bevel gear theoretical speed sensor	Signal error
T	4150	X20 - Transmission filter blockage switch	Filter blocked
T	4153	X19 - Transmission hydraulic oil temperature sensor	Transmission oil temperature higher than 110°C
T	4156	X20 - Transmission filter blockage switch	Signal error
T	4158	Transmission slip monitor	The transmission output speed indicates over 30% slippage compared to the value given
T	4159	Engagement of limp home mode	Manual engagement of limp home mode without reason Limp home mode error
T	4161	X14 - Tortoise range solenoid valve	Control error when shifting from Hare to Tortoise mode
T	4162	X13 - Hare range solenoid valve	Control error when shifting from Tortoise to Hare mode
T	4163	X11 - Solenoid valve limiting speed to 30 kph	Control error
T	4164	X12 - Coupler function solenoid valve	PWM control error
T	4172	X20 - Transmission filter blockage switch	Signal error
T	4173	X19 - Transmission hydraulic oil temperature sensor	Signal error
T	4182	X8 - Bevel gear theoretical speed sensor X10 - Collecting shaft speed sensor	Inconsistent speeds
T	4183	X8 - Bevel gear theoretical speed sensor X10 - Collecting shaft speed sensor	Inconsistent direction of rotation.
T	4185	X25 - Engine speed sensor	Inconsistent speed
T	4186	X9 - Transmission oil high pressure sensor 1 X34 - Transmission oil high pressure sensor 2	Inconsistent values
T	4189	X19 - Transmission hydraulic oil temperature sensor	Inconsistent value
T	4192	X67 - Right-hand brake pedal sensor	Data transfer interrupted
T	4193	X66 - Left-hand brake pedal sensor	Data transfer interrupted
T	41A0	X18 - Transmission control module	Control of control module interrupted
T	41A1	X18 - Transmission control module	The angle of rotation is limited, but not by the speed limiting solenoid valve
T	41A2	X18 - Transmission control module X174 - Autotronic 4 transmission controller	The CAN network control is interrupted
T	41A3	X18 - Transmission control module	Increment sensor signal (internal actual position sensor) interrupted or illogical
T	41A4	X18 - Transmission control module	Autotronic 4 signal interrupted or illogical
T	41A5	X18 - Transmission control module	Reference output (Position "0") not found at start-up
T	41A6	X18 - Transmission control module	Reference point signal interrupted during operation

No.		Components concerned	Causes
T	41B0	CAN network	Initialisation error
T	41B1	X174 - Autotronic 4 transmission controller	Illogical range shift
T	41B2	X174 - Autotronic 4 transmission controller	Faulty programming
T	41B3	X174 - Autotronic 4 transmission controller	Faulty programming
T	41B4	X174 - Autotronic 4 transmission controller	Faulty programming
T	41B5	X174 - Autotronic 4 transmission controller	Faulty programming
T	41C1	X174 - Autotronic 4 transmission controller	The engine has stalled due to transmission overload
T	41CF	X174 - Autotronic 4 transmission controller	Internal error (RAM/EEPROM)
T	41E0	X174 - Autotronic 4 transmission controller	Coupler function reference curve incorrectly interpreted, faulty programming
		X12 - Coupler function solenoid valve	Signal error
T	41E1	X174 - Autotronic 4 transmission controller	Faulty programming
T	41E2	X174 - Autotronic 4 transmission controller	Faulty programming
T	41E3	X174 - Autotronic 4 transmission controller	Faulty programming
T	41E4	X174 - Autotronic 4 transmission controller	Faulty programming
T	41E5	X174 - Autotronic 4 transmission controller	Faulty programming
T	41E6	X174 - Autotronic 4 transmission controller	Faulty programming
T	41E7	X174 - Autotronic 4 transmission controller	Faulty programming
T	41E9	X174 - Autotronic 4 transmission controller	Faulty programming
T	41EA	X174 - Autotronic 4 transmission controller	Faulty programming
T	41EB	X17 - Hare/Tortoise range position sensor	Calibration error or sensor value out of tolerance ranges
T	41EE	X174 - Autotronic 4 transmission controller	Faulty programming
T	41EF	X174 - Autotronic 4 transmission controller	Faulty programming
T	41FF	X174 - Autotronic 4 transmission controller	Internal error (RAM/EEPROM)

C. 4WD/Differential lock error codes

No.		Components concerned	Causes
T	5131	X137 - 4WD switch	Incorrect manual engagement signal
T	5132		Incorrect automatic engagement signal
T	5133	X5 - 4WD solenoid valve	Control error
T	5151	X136 - Differential lock switch	Signal error
T	5153	X6 - Differential lock solenoid valve	Control error
T	5154	X66 - Left-hand brake pedal sensor	Signal error
T	5555	X67 - Right-hand brake pedal sensor	Signal error

D. Armrest error codes

No.		Components concerned	Causes
AR	01	X104 - Armrest Autotronic 5	10 V output fault
AR	02	X104 - Armrest Autotronic 5	VIN Error - Vehicle electronic identification incorrect
AR	11	X307 - FingerTIP 1	Short circuit 0 V
AR	12		Short circuit to 12 V
AR	21	X308 - FingerTIP 2	Short circuit 0 V
AR	22		Short circuit to 12 V
AR	31	X108 - FingerTIP 3	Short circuit 0 V
AR	32		Short circuit to 12 V
AR	41	X109 - FingerTIP 4	Short circuit 0 V
AR	42		Short circuit to 12 V
AR	51	X110 - FingerTIP 5	Short circuit 0 V
AR	52		Short circuit to 12 V
AR	61	X130 - FingerTIP 6 front linkage function	Short circuit 0 V
AR	62		Short circuit to 12 V
AR	71	X122 - Hand throttle	Short circuit 0 V
AR	72		Short circuit to 12 V
AR	81	X121 - Rear linkage height/depth adjustment thumb wheel	Short circuit 0 V
AR	82		Short circuit to 12 V
AR	91	X106 - Transmission lever in armrest	Short circuit 0 V
AR	92		Short circuit to 12 V

E. Instrument panel error codes

No.		Component(s) concerned	Cause(s)
D	121		Alternator regulator voltage too high (filtered battery signal)
D	122		Alternator regulator voltage too low (filtered battery signal)
D	127	X197 - Diesel fuel gauge	Electrical signal too high
D	128		Electrical signal too low
D	129		Battery voltage too high (non-filtered battery signal)
D	130		Battery voltage too low (non-filtered battery signal)
D	133	X71 - Throttle pedal sensor	Electrical signal too high
D	134		Electrical signal too low
D	135	X56 - Power Control lever X71 - Throttle pedal sensor	Electrical signal too high - C.N.
D	136		Electrical signal too low - C.N.
D	137	X106 - Transmission lever in armrest	Electrical signal too high
D	138		Electrical signal too low
D	139	X68 - Clutch pedal sensor	Electrical signal too high
D	140		Electrical signal too low
D	141	X25 - Engine speed sensor	Engine speed signal not at maximum level
D	142	X68 - Clutch pedal sensor	Short circuit to + 12 V AC
D	143		Short circuit to + 12 V AC - C.N.
D	144	X56 - Power Control lever	Electrical signal too high
D	145		Electrical signal too low
D	146		Electrical signal too high
D	147		Electrical signal too low
D	148	X55 - Instrument panel	Attempt to program with engine running
D	149		CAN network deactivated (CAN bus off)
D	150		CAN messages lost
D	151		Tractor speed too high
D	152	X55 - Instrument panel	Hourmeter error for engine maintenance
D	153		Parameter table error
D	154		CAN communications from Autotronic 4 to DCC3 - C.N. Special failed
D	155	X55 - Instrument panel	Incorrect tractor code selected
D	156	X68 - Clutch pedal sensor	TOC stuck open
D	157	X25 - Engine speed sensor	No electrical signal
D	158	X106 - Transmission lever in armrest	Incorrect calibration of armrest lever
D	159	X56 - Power Control lever	Neutral switch error in neutral - C.N. position
D	160		Neutral switch error outside neutral - C.N. position
D	164		CAN communications from EEM to DCC3 failed
D	170	X122 - Hand throttle	
D	183	X235 - Front axle steering sensor (WAS sensor)	Electrical signal too high
D	184		Electrical signal too low
D	185	X57 - DOT Matrix keyboard	Electrical signal too high
D	186		Electrical signal too low
D	189	X55 - Instrument panel	9.5 V output - electrical signal too high
D	190		9.5 V output - electrical signal too low
D	191	X168 - Pneumatic brake system pressure sensor	Electrical signal too high
D	192		Electrical signal too low

No.		Component(s) concerned	Cause(s)
D	193	X144 - Variable steering setting potentiometer (fast steering)	Electrical signal too high
D	194		Electrical signal too low
D	195	X55 - Instrument panel	Electrical signal too high
D	196		Electrical signal too low
D	197	X1 - Auxiliary hydraulic oil temperature sensor	Electrical signal too high
D	198		Electrical signal too low

5A12

ML260 - Diagrams and plans

TABLE OF CONTENTS

A. Hydraulics diagrams.	29
B. Electrical diagrams.	40

A. Hydraulics diagrams

Different systems

- (1) Valve block (fuel lift/lubrication)
- (2) Hydrostatic loop
- (3) Settings
- (4) Transmission control unit
- (5) Rear axle
- (6) Solenoid valve block on rear axle

Pumps

- (1P1) Service pump
- (1P2) Lubrication pump
- (2P1) Hydrostatic pump

Drive components

- (2A1) Hydrostatic motor
- (2A2) Hydrostatic motor
- (3A1) Piston for setting the hydrostatic pump displacement
- (3A2) Piston for setting the hydrostatic motor displacement
- (3A3) Forward speed limiter in limp home mode
- (4A1) Forward range selector
- (6A1) Rear PTO clutch
- (6A3) 1000 rpm PTO selector piston
- (6A4) Front axle clutch
- (6A5) Rear axle differential lock
- (6A6) 750 rpm PTO selector piston
- (6A7) Front axle differential lock

Sensors

- (1S1) Transmission oil temperature sensor
- (1S2) Pressure filter blockage switch
- (4S1) HP loop pressure sensor
- (4S2) Pressure sensor

Other components

- (1Z1) Intake filter with bypass
- (1Z2) Pressure filter with bypass
- (1Z3) Transmission oil cooler
- (1Z4) Transmission lubrication
- (3Z1) Cam channel adjustment shaft
- (3Z2) Control unit
- (4Z1) Clutch pedal with clutch master cylinder
- (4Z2) Accumulator
- (5Z2) Rear PTO lubrication
- (5Z3) Differential and right-hand brake lubrication
- (5Z4) Differential and left-hand brake lubrication

Valves (or spool valves/solenoid valves)

- (1V1) Cooler bypass valve
- (1V2) Flushing pressure relief valve
- (1V3) Fuel lift pressure relief valve
- (1V4) Lubricating pressure relief valve
- (1V5) Service pump pressure relief valve
- (1V6) System pressure relief valve
- (2V1) Reverse fuel lift non-return valve
- (2V2) Forward fuel lift non-return valve
- (2V3) Forward high-pressure relief valve
- (2V4) Reverse high-pressure relief valve
- (2V5) Flushing valve
- (2V6) Shuttle valve
- (3V1) Hydrostatic pump control spool valve
- (3V2) Hydrostatic motor control spool valve
- (4V1) Hare range solenoid valve

Valves (or spool valves/solenoid valves)

- (4V2) Tortoise range solenoid valve
- (4V3) Forward speed limiting solenoid valve
- (4V4) Coupler function solenoid valve
- (4V5) Clutch function spool valve
- (4V6) Rear axle pressure relief spool valve
- (6V1) Rear PTO clutch solenoid valve
- (6V3) 540 (or 750) rpm PTO control solenoid valve (depending on equipment)
- (6V4) Front axle clutch solenoid valve
- (6V5) Differential lock solenoid valve
- (6V6) 1000 rpm PTO control solenoid valve

Measurement points

- (M1) Pressure upstream of cooler
- (M2) Lubricating pressure
- (M3) Flushing pressure
- (M4) Fuel lift pressure
- (M5) Service pump pressure
- (M6) Transmission system pressure
- (M7) Range 1 engaging pressure (Tortoise)
- (M8) Range 2 engaging pressure (Hare)
- (M9) High pressure
- (M10) Rear axle and brake system pressure
- (M11) PTO clutch pressure
- (M13) 540 (or 750) rpm PTO selector pressure (depending on equipment)
- (M14) Front axle clutch pressure
- (M15) Differential lock pressure
- (M16) 1000 rpm PTO selector pressure
- (M18) Lubricating pressure
- (M22) Oil leak from clutch or coupler function valve

A.1 Transmission hydraulics diagram





Fig. 1

A.2 Forward/reverse high-pressure relief valves

The purpose of the high-pressure relief valves is to regulate the increase in HP pressure. They protect the transmission components (hydrostatic motors and pump).



1008328

Fig. 2

- (A) Coupler and clutch functions inactive: identical pressure in both chambers. The spool is held in closed position by the spring.
- (B) Coupler and clutch functions active: the pressure drop caused by the restrictor (nozzle) applies a force to the spool that is greater than the force of the spring. The spool moves to the right, bringing PH into contact with ES (charge).
- (C) HP pressure is limited by the coupler and clutch spools.

A.3 Flushing valve

This valve "rinses" the oil inside the hydrostatic loop.

Operation

Pressure at A and B: max.. 500 bar

Pressure at T: max. 50 bar.


Opening pressure: $\Delta p = 7$ bar between A and B

Transmission in "neutral"

$p_A = p_B$, $\Delta p < 7$ bar


The spool is held in "mid" position by the spring.

The two channels (A and B) are closed.



1008329

Fig. 3



1008330

Fig. 4

"Pulling" phase

$p_A > p_B$, $\Delta p > 7 \text{ bar}$

The spool moves upwards via the control port XA.


Channel B is linked to T. The hot oil coming from the low pressure side B can therefore be "rinsed" and flow through the cooler via port T.

"Pushing" phase

$p_A < p_B$, $\Delta p > 7 \text{ bar}$


The spool moves downwards via the control port XB.

Channel A is linked to T. The hot oil coming from the low pressure side A can therefore be "rinsed" and flow through the cooler via port T.



1008331

Fig. 5



1008332


Fig. 6

A.4 Control spool valve

Pressure relief valve - 4V4 / Y004 coupler function

The coupler function valve (4V4) regulates the increase in hydrostatic pressure (PH) in proportion to the engine speed. This component simulates the coupler effect. The coupler function valve is fitted to the control unit where the hydrostatic loop PH and tank return junction is located. If this junction is not closed, the pressure in the hydrostatic loop cannot increase, and the tractor does not reach its maximum pulling power. The junction between the hydrostatic loop PH and tank is closed by the coupler function valve (4V4).

The coupler function valve is controlled by the electronic unit. The current supplied depends on the engine speed and changes as shown in the following table:



1009393

Fig. 7

Engine speed in rpm	Current supplied at A	Max. PH	Note
800	0	0 bar	Transmission in neutral
800	approx. 0.46	78 bar	Transmission "active"
1200	1.23	105 bar	
from 1400	1.71	540 bar	

The increase in pressure inside the HP loop depends on the electrical supply and the seal provided by the coupler function valve.

To check the sealing of this valve, it is possible to mechanically lock the seal.
Tighten the internal Allen screw.

Pressure relief valve - 4V5 clutch function


The clutch function valve is fitted to the control unit where the PH hydrostatic loop and tank return junction is located. This clutch function valve is also used to restrict the maximum PH pressure inside the hydrostatic loop to 550 bar (± 15 bar). Due to this clutch function valve, when the clutch pedal is not activated, the junction between the hydrostatic loop and the tank return is closed. By operating the clutch pedal, the clutch function valve opens and the hydrostatic loop is connected to the tank return channel. This results in a drop in pressure in the hydrostatic loop (interruption of the pulling effort), proportional to how far in the clutch pedal is pressed (comparable to a mechanical forward clutch).

With the clutch pedal fully depressed, High pressure PH = 0 bar

Maximum pressure inside the hydrostatic loop is dependent on perfect operation of the clutch valve (4V5).



Fig. 8



1008333

Fig. 9

Control unit

If maximum pressure is not reached when measuring the HP pressure, the transmission module may be defective, but it is also possible that internal sealing of the control unit is the cause of the problem. To ensure that it is necessary to disassemble the transmission module, it is recommended to first check the sealing of the spool valve unit (transmission control).

The pressure in the hydrostatic loop can only increase if the pressure relief valve seals are tight.


- Coupler function (4V4 / Y004)
- Clutch function (4V5)

When the following conditions are met, the coupler function valve authorises a pressure increase inside the hydrostatic loop:

- Engine speed above 1400 rpm (PWM - Signal)
- Limp home mode activated

- Valve mechanically locked (tighten the internal Allen screw or move the lever).


The clutch function valve is closed (increase in HP pressure is possible) when the clutch pedal is not activated.



1008334

Fig. 10

Sealing of the 2 pressure relief valves (4V4 and 4V5) can be controlled by the T union.



1008335

Fig. 11

B. Electrical diagrams

B.1 Identification of electrical connectors and harnesses

Identification of electrical connectors

- X1** - Auxiliary hydraulic oil temperature sensor
- X2** - Auxiliary hydraulic oil filter blockage switch
- X3** - 540 rpm PTO speed solenoid valve
- X4** - 1000 rpm PTO speed solenoid valve
- X5** - 4WD solenoid valve
- X6** - Differential lock solenoid valve
- X7** - Rear PTO solenoid valve
- X8** - Bevel gear theoretical speed sensor
- X9** - Transmission oil high pressure sensor 1
- X10** - Collecting shaft speed sensor
- X11** - Solenoid valve limiting speed to 30 kph
- X12** - Coupler function solenoid valve
- X13** - Hare range solenoid valve
- X14** - Tortoise range solenoid valve
- X15** - PTO clutch speed sensor
- X16** - PTO shaft speed sensor
- X17** - Hare/Tortoise range position sensor
- X18** - Transmission control module
- X19** - Transmission hydraulic oil temperature sensor
- X20** - Transmission filter blockage switch
- X21** - ParkLock brake pressure sensor
- X22** - Radar
- X23** - Steering pressure sensor
- X24** - Auxiliary hydraulic oil gauge
- X25** - Engine speed sensor
- X26** - Pneumatic brake solenoid valve
- X27** - Rear linkage lifting solenoid valve
- X28** - Rear linkage lowering solenoid valve
- X29** - Dual Control socket connector
- X30** - Rear linkage position sensor
- X31** - Rear linkage right-hand draft sensor
- X32** - Rear linkage left-hand draft sensor
- X33** - Transmission harness CAN junction
- X34** - Transmission oil high pressure sensor 2
- X35** - ParkLock hydraulic system pressure sensor
- X36** - LS signal breaker solenoid valve
- X37** - ParkLock pressure reversing solenoid valve
- X38** - Trailer braking proportional solenoid valve
- X39** - Trailer braking safety solenoid valve
- X40** - Front linkage single/double acting function solenoid valve
- X41** - Divider solenoid valve 1
- X42** - Divider solenoid valve 2
- X43** - Auto-hitch lifting solenoid valve
- X44** - Auto-hitch lowering solenoid valve
- X45** - Bleed for pneumatic suspended cab front and rear systems
- X46** - Rear left-hand ram position sensor for cab suspension
- X47** - Rear right-hand unit for suspended cab
- X48** - Rear left-hand unit for suspended cab
- X49** - Suspended cab rear lowering solenoid valve
- X50** - Suspended cab front lowering solenoid valve
- X51** - Transmission harness earth (chassis)

- X52** - Engine harness/transmission harness junction
- X53** - Cab transmission harness/transmission harness junction
- X54** - Suspended cab lifting solenoid valve
- X55** - Instrument panel
- X56** - Power Control lever
- X57** - DOT Matrix keyboard
- X58** - Windscreen wiper and indicator control unit
- X59** - DOT Matrix keyboard connection on instrument panel
- X60** - Engine harness/instrument panel harness junction
- X61** - Cab transmission harness/engine harness junction
- X62** - Instrument panel harness/cab transmission harness junction
- X63** - Instrument panel harness connection on fuse box
- X64** - Instrument panel harness connection on fuse box
- X65** - Front windscreen wiper motor
- X66** - Left-hand brake pedal sensor
- X67** - Right-hand brake pedal sensor
- X68** - Clutch pedal sensor
- X69** - Cab interior temperature sensor
- X70** - Solar radiation sensor
- X71** - Throttle pedal sensor
- X72** - ParkLock switch on Power Control lever
- X73** - Buzzer Control
- X74** - Buzzer Supply (+12 V APC)
- X75** - Pillar harness/right-hand fender harness junction
- X76** - Rear right-hand indicator
- X77** - Rear right-hand side light and stop light
- X78** - Work light on rear right-hand fender
- X79** - -
- X80** - -
- X81** - -
- X82** - -
- X83** - -
- X84** - -
- X85** - -
- X86** - -
- X87** - Linkage lifting/lowering switch on right-hand fender
- X88** - Rear right-hand NA indicator extension
- X89** - Earth (chassis)
- X90** - Pillar harness/left-hand fender harness junction
- X91** - Rear left-hand indicator
- X92** - Rear left-hand side light and stop light
- X93** - Work light on rear left-hand fender
- X94** - PTO ON/OFF switch on left-hand fender
- X95** - PTO Stop switch on left-hand fender
- X96** - Hydraulic spool valve switch on left-hand fender
- X97** - Linkage lifting/lowering switch on left-hand fender
- X98** - Rear left-hand NA indicator extension
- X99** - PTO and linkage console harness/cab transmission harness junction
- X100** - Instrument panel harness earth (chassis)
- X101** - Instrument panel harness/electric rear-view mirror harness junction
- X102** - Right-hand fender lighting harness/trailer connector harness junction
- X103** - Armrest harness/cab transmission harness junction
- X104** - Armrest Autotronic 5
- X105** - Datatronic CCD

- X106** - Transmission lever in armrest
- X107** - Headland mode switch (headland function)
- X108** - FingerTIP 3
- X109** - FingerTIP 4
- X110** - FingerTIP 5
- X111** - DTM dynamic transmission mode switch
- X112** - Joystick
- X113** - Armrest 6-button keyboard
- X114** - Supply on fuse box for 3rd spool valve
- X115** - Supply on fuse box for 4th spool valve
- X116** - +12 V battery supply (for lighting module)
- X117** - Isobus +12 V battery power socket
- X118** - Automatic PTO switch
- X119** - Rear linkage lifting/lowering switch
- X120** - Datatronic CCD navigation keyboard
- X121** - Rear linkage height/depth adjustment thumb wheel
- X122** - Hand throttle
- X123** - Hare/Tortoise range shift switch
- X124** - Pedal/lever mode switch
- X125** - SV1 speed setting potentiometer
- X126** - SV2 speed setting potentiometer
- X127** - Front PTO ON/OFF switch
- X128** - Rear PTO ON/OFF switch
- X129** - Fuse box +12 V battery connection
- X130** - FingerTIP 6 front linkage function
- X131** - Front linkage suspension solenoid valve
- X132** - Instrument panel harness/armrest harness junction
- X133** - Console harness/cab transmission harness junction
- X134** - Console harness/pillar harness junction
- X135** - Braking pressure sensor
- X136** - Differential lock switch
- X137** - 4WD switch
- X138** - Hazard warning lights indicator light and switch
- X139** - Suspended front axle switch
- X140** - Suspended front axle setting potentiometer
- X141** - Suspended cab switch
- X142** - Suspended cab setting potentiometer
- X143** - Variable steering switch (fast steering)
- X144** - Variable steering setting potentiometer (fast steering)
- X145** - PTO/linkage console
- X146** - Rear linkage suspension switch
- X147** - Roof harness/pillar harness junction
- X148** - Roof harness/pillar harness junction
- X149** - Headlights module (black connector)
- X150** - Pillar harness/cab power socket harness junction
- X151** - Pillar harness/cab power socket harness junction
- X152** - Start switch
- X153** - Non-Isobus implement connector
- X154** - Suspended front axle lifting solenoid valve
- X155** - Cigarette lighter socket (power)
- X156** - Cigarette lighter socket (backlighting)
- X157** - Left-hand side +12 V socket (power)
- X158** - Left-hand side +12 V socket (backlighting)
- X159** - Suspended front axle lowering solenoid valve
- X160** - Console harness earth (chassis)
- X161** - Solenoid valve 1 for suspended front axle suspension

- X162** - Pillar harness connection on fuse box
- X163** - Solenoid valve 2 for suspended front axle suspension
- X164** - Pillar harness/cab transmission harness junction
- X165** - Automatic air conditioning harness/pillar harness junction
- X166** - Suspended front axle position sensor
- X167** - +12 V APC fuse box connection
- X168** - Pneumatic brake system pressure sensor
- X169** - Power socket control switch (in cab)
- X170** - Pillar harness connection on fuse box
- X171** - Cab transmission harness connection on fuse box
- X172** - Cab transmission harness connection on fuse box
- X173** - Cab transmission harness earth
- X174** - Autotronic 4 transmission controller
- X175** - Emergency control switch
- X176** - Earth (Autotronic 4 transmission controller)
- X177** - Autotronic 5 Linkage
- X178** - ParkLock/suspended front axle/passive suspended cab Autotronic 5
- X179** - Main lighting, sidelight/dipped light activation switch
- X180** - Front windscreen washer pump
- X181** - Front linkage single acting / double acting function switch
- X182** - Linkage external lifting switch
- X183** - Diagnostics connector (tractor-Isobus CAN)
- X184** - Diagnostics connector (engine-valve CAN)
- X185** - Sisu EEM unit
- X186** - Starter
- X187** - Engine start relay
- X188** - Engine identification module (ID module)
- X189** - Fuel lift pump
- X190** - Vistronic fan
- X191** - Diesel fuel preheater
- X192** - B + alternator 1
- X193** - B + alternator 2
- X194** - D + alternator 1
- X195** - D + alternator 2
- X196** - In line fuse (225 A)
- X197** - Diesel fuel gauge
- X198** - Pneumatic trailer brake sensor
- X199** - Work light on left-hand step
- X200** - Work light on right-hand step
- X201** - Engine harness earth
- X202** - Front accessory connection socket harness/front function harness junction
- X203** - Engine harness/front headlights harness junction
- X204** - Cooling unit harness/engine harness junction
- X205** - Front axle harness/engine harness junction
- X206** - Sensor detecting water in the diesel fuel
- X207** - Pneumatic seat adjustment control
- X208** - Front linkage suspension switch LED
- X209** - Rear linkage external lowering switch
- X210** - Orbitrol steering sensor (SASA sensor)
- X211** - Rear Dual Control connector
- X212** - Instrument panel harness/armrest harness junction
- X213** - Power socket for additional heating
- X214** - Armrest harness/cab transmission harness junction

- X215** - Trailer connector (right-hand side light and number plate lights)
- X216** - Reversing light
- X217** - Isobus CAN connector
- X218** - External Isobus tool connector
- X219** - Cab Isobus harness/external Isobus harness junction
- X220** - Trailer connector (left-hand side light)
- X221** - Trailer connector (right-hand indicator)
- X222** - Trailer connector (left-hand indicator)
- X223** - Trailer connector (brake lights)
- X224** - Trailer connector (earth)
- X225** - Trailer connector (reversing light)
- X226** - Trailer connector harness earth
- X227** - Console harness/cab transmission harness junction
- X228** - Front linkage single/double-acting function LED
- X229** - 120 Ohm CAN 1 resistor (cab transmission harness)
- X230** - 120 Ohm CAN 2 resistor (cab transmission harness)
- X231** - 120 Ohm CAN 3 resistor (cab transmission harness)
- X232** - 120 Ohm CAN 4 resistor (cab transmission harness)
- X233** - Cab transmission harness/Isobus harness junction
- X234** - 120 Ohm CAN ATC resistor
- X235** - Front axle steering sensor (WAS sensor)
- X236** - Electrohydraulic Orbitrol (grey connector)
- X237** - Electrohydraulic Orbitrol (black connector)
- X238** - Connector 1 for valve harness
- X239** - Connector 2 for valve harness
- X240** - 120 Ohm resistor for electrohydraulic spool valves
- X241** - Sisu engine preheating supply (Grid Heater)
- X242** - Exhaust temperature sensor
- X243** - AdBlue/DEF reservoir (urea) level gauge and temperature sensor
- X244** - CAN SCR harness
- X245** - +12 V APC supply for SCR
- X246** - Auto-Guide external harness/engine harness junction
- X247** - Roof harness/electric rear-view mirror harness junction
- X248** - Right and left-hand electric rear-view mirror adjustment switch
- X249** - External rear-view mirror defroster switch
- X250** - Power socket in cab
- X251** - In line fuse (225 A)
- X252** - Automatic air conditioning condenser
- X253** - Air filter vacuum sensor
- X254** - Horn (earth)
- X255** - Horn
- X256** - Roof harness/hand rail harness junction
- X257** - Side light and indicator on hand rail (right and left)
- X258** - Main beam on hand rail (right and left)
- X259** - Hand rail upper work light
- X260** - Hand rail upper work light
- X261** - Front right-hand unit for suspended cab
- X262** - Front left-hand unit for suspended cab
- X263** - Floating stop relay control (US front-end loader)

- X264** - Front linkage suspension switch
- X265** - Rear linkage suspension switch indicator light
- X266** - Rear linkage diagnostic and lifting/lowering LEDs
- X267** - Switch for left-hand side heater
- X268** - Pillar harness connection on fuse box
- X269** - Cab suspension harness/cab transmission harness junction
- X270** - Front accessories connection socket (rotary beacon)
- X271** - Front accessories connection socket (+12 V battery)
- X272** - Front accessories connection socket (+12 V APC)
- X273** - Front accessories connection socket (main beam light)
- X274** - Front accessories connection socket (main beam light)
- X275** - Front accessories connection socket (work light)
- X276** - Earth for front accessory connection socket harness
- X277** - Front linkage lifting/lowering external control
- X278** - Front linkage lifting switch (external)
- X279** - Dual Control or TIC position sensor
- X280** - Front linkage rams pressure sensor
- X281** - Solenoid valve for front PTO
- X282** - Roof harness/cab Auto-Guide harness junction
- X283** - TopDock
- X284** - Headlights module keyboard
- X285** - Ad Blue (urea) metering valve
- X286** - Ad Blue (urea) injection valve
- X287** - Ad Blue (urea) reservoir preheating valve
- X288** - 12/24 V converter for SCR system
- X289** - SCR management module
- X290** - Front accessory connection socket harness/front function harness junction
- X291** - Front accessory connection socket harness/front function harness junction
- X292** - Front windscreen washer pump
- X293** - 540 rpm PTO switch
- X294** - 540 eco rpm PTO switch
- X295** - 1000 rpm PTO switch
- X296** - USB connector
- X297** - PTO/linkage console backlighting
- X298** - Headland mode switch (headland function)
- X299** - Linkage lowering speed potentiometer
- X300** - -
- X301** - PTO stop switch on left-hand fender
- X302** - Switch for pre-selected engine speed A
- X303** - Switch for pre-selected engine speed B
- X304** - Instrument panel harness/armrest harness junction
- X305** - Headlights module (grey connector)
- X306** - Switch for pre-selected engine speed A/B
- X307** - FingerTIP 1
- X308** - FingerTIP 2
- X309** - SV1/SV2 speed regulator switch
- X310** - Divider 1 indicator light and solenoid valve (earth)
- X311** - Divider 2 indicator light and solenoid valve (+12 V)
- X312** - SV1/SV2 speed setting potentiometer in armrest
- X313** - Pedal/lever transmission control mode switch and DTM switch
- X314** - Hydraulics switch 1, road/field mode

- X315** - Hydraulics switch 2, road/field mode
- X316** - Headland mode switch (headland function)
- X317** - + battery supply for headlights module
- X318** - Automatic air conditioning compressor
- X319** - + battery supply for headlights module
- X320** - + battery supply on headlights module
- X321** - + battery supply on headlights module
- X322** - + battery supply on headlights module
- X323** - + battery supply on headlights module
- X324** - +12 V APC fuse box connector (battery isolator switch)
- X325** - Pillar harness / non-Isobus implement connector harness junction
- X326** - Pillar harness / non-Isobus implement connector harness junction
- X327** - Battery earth (chassis)
- X328** - Battery isolator switch earth terminal
- X329** - Battery isolator switch earth terminal
- X330** - Battery negative terminal contact (battery isolator switch)
- X331** - Pillar harness connection on fuse box
- X332** - + battery (start switch)
- X333** - Engine harness earth (chassis)
- X334** - Battery isolator switch earth terminal
- X335** - Battery isolator switch earth terminal
- X336** - Battery isolator switch
- X337** - Pneumatic brake ParkLock solenoid valve
- X338** - Earth (battery isolator switch)
- X339** - Pneumatic trailer braking solenoid valve
- X340** - + terminal on battery for fuse box
- X341** - Starter supply
- X342** - Positive battery terminal
- X343** - RS232 diagnostics connector for Auto-Guide
- X344** - Isobus connector in cab
- X345** - Supply for additional terminal (mitron unit)
- X346** - Auto-Guide switch
- X347** - Cab transmission harness connection on fuse box
- X348** - Cab transmission harness connection on fuse box
- X349** - -
- X350** - Front right-hand grille work light
- X351** - Front right-hand grille work light
- X352** - Front right-hand grille work light
- X353** - Front left-hand grille work light
- X354** - Front left-hand grille work light
- X355** - Front left-hand grille work light
- X356** - Right-hand main beam and dipped light
- X357** - Left-hand main beam and dipped light
- X358** - Outside temperature sensor
- X359** - Cab suspension harness/cab transmission harness junction
- X360** - Pillar harness connection on fuse box
- X361** - Pillar harness connection on fuse box
- X362** - Fuse box (+12 V battery)
- X363** - Auto-hitch (Dromone) switch
- X364** - 120 Ohm resistor for Auto-Guide/Isobus CAN network
- X365** - Hand rail lower work light
- X366** - Pneumatic brake harness / transmission harness junction
- X367** - Switch 1 on joystick
- X368** - Switch 2 on joystick

- X369** - Engine speed + switch
- X370** - Engine speed - switch
- X371** - Engine speed stop switch
- X372** - Orbitrol safety solenoid valve
- X373** - Left-hand 12 V socket (cab) (power)
- X374** - Left-hand 12 V socket (cab) (backlighting)
- X375** - Instrument panel harness/cab transmission harness junction
- X376** - Fuse box (reserve for + APC)
- X377** - Fuse box (supply for cab suspension compressor)
- X378** - FNRP lever and button
- X379** - Front left-hand work light on roof
- X380** - Front right-hand work light on roof
- X381** - Front left-hand work light on roof
- X382** - Front right-hand work light on roof
- X383** - Front left-hand roof indicator
- X384** - Front right-hand roof indicator
- X385** - Rear left-hand work light on roof
- X386** - Rear right-hand work light on roof
- X387** - Rear left-hand work light on roof
- X388** - Rear right-hand work light on roof
- X389** - Rear left-hand work lights
- X390** - Rear right-hand work lights
- X391** - Rear left-hand roof indicator
- X392** - Rear right-hand roof indicator
- X393** - Earth
- X394** - Radio aerial connector
- X395** - Radio supply
- X396** - Radio speaker connector
- X397** - Front left-hand speaker
- X398** - Front right-hand speaker
- X399** - Rear left-hand speaker (+ supply)
- X400** - Rear right-hand speaker (+ supply)
- X401** - Rear left-hand speaker (- supply)
- X402** - Rear right-hand speaker (- supply)
- X403** - Rear windscreen wiper motor
- X404** - Door switch
- X405** - Interior light (earth)
- X406** - Interior light (control)
- X407** - Interior light (+12 V battery supply)
- X408** - Right-hand console light
- X409** - Left-hand rotary beacon
- X410** - Right-hand rotary beacon
- X411** - Rear windscreen wiper switch
- X412** - Radio aerial
- X413** - Earth (aerial)
- X414** - Left-hand number plate light
- X415** - Right-hand number plate light
- X416** - Radio supply
- X417** - Radio speaker connector
- X418** - Earth
- X419** - Earth
- X420** - Rotary beacon harness earth (chassis)
- X421** - Earth
- X422** - Roof harness earth (chassis)
- X423** - Left-hand side fan ON/OFF switch
- X424** - Fan speed control knob
- X425** - Air conditioning switch
- X426** - Air conditioning indicator light
- X427** - Manual air conditioning module
- X428** - Electronic thermostat for heating

- X429** - Speed 1relay for fan
- X430** - Speed 2relay for fan
- X431** - Speed 3relay for fan
- X432** - Speed 4relay for fan
- X433** - Left-hand heating resistor
- X434** - Right-hand fan
- X435** - Left-hand fan
- X436** - Left-hand side fan switch
- X437** - Relay for left-hand side fan
- X438** - Earth (automatic air conditioning)
- X439** - Air conditioning control module (blue connector)
- X440** - Air conditioning control module (yellow connector)
- X441** - Heating temperature sensor
- X442** - TT2 sensor
- X443** - Evaporator temperature sensor
- X444** - Right-hand fan adapter module (signal)
- X445** - Left-hand fan adapter module
- X446** - Right-hand fan adapter module (supply)
- X447** - Left-hand fan adapter module (supply)
- X448** - Separation harness for automatic air conditioning
- X449** - Motor for left-hand heating shutter
- X450** - Motor for right-hand heating shutter
- X451** - Motor for heating mixer shutter
- X452** - Relay for heater pump
- X453** - Heater accelerator pump
- X454** - Earth (roof)
- X455** - Roof harness earth
- X456** - Solar panel
- X457** - Earth (Auto-Guide)
- X458** - Cab transmission harness/pillar harness junction
- X459** - Linkage lifting switch on fender
- X460** - Linkage lowering switch on fender
- X461** - Pillar harness/TECU harness junction
- X462** - Supply indicator light for power socket on pillar
- X463** - Earth (Isobus)
- X464** - Pillar harness/armrest harness junction
- X465** - Battery positive terminal contact
- X466** - Active suspended cab Autotronic 5
- X467** - Right-hand electric rear-view mirror
- X468** - Left-hand electric rear-view mirror
- X469** - Additional fan connection
- X470** - Operator presence in seat switch
- X471** - Suspended cab harness connection

Identification of harnesses

- FAI200** - Engine harness
- FAI201** - Front headlights harness
- FAI202** - Suspended front axle harness
- FAI203** - Transmission harness
- FAI204** - Cab/platform linkage external harness
- FAI205** - Electrohydraulic valves harness
- FAI206** - Transmission harness — PTO
- FAI207** - Front Dual Control harness
- FAI208** - Linkage with Dual Control and TIC harness
- FAI209** - Instrument panel harness
- FAI210** - Cab transmission harness
- FAI211** - Cab linkage harness
- FAI212** - Lighting harness
- FAI213** - Cab interior lighting harness
- FAI214** - Armrest harness


FAI215 - Pillar harness
FAI216 - Diagnostics connector harness
FAI217 - Datatronic 3 harness
FAI218 - Fieldstar harness
FAI219 - Cab interior power socket harness
FAI220 - BOC harness — safety switch
FAI221 - Automatic air conditioning harness — instrument panel
FAI222 - Autotronic 5 ParkLock/suspended front axle harness
FAI223 - Roof harness
FAI224 - Hand rail lighting harness
FAI225 - Electric rear-view mirror harness
FAI226 - Roof/external harness
FAI227 - Automatic air conditioning harness - roof
FAI228 - Number plate lighting harness
FAI229 - Xenon light adapter harness
FAI230 - GSPTO harness
FAI231 - Transmission harness — ParkLock
FAI232 - Radio harness
FAI235 - Front accessory connection socket harness
FAI236 - Start-up harness
FAI237 - +12 APC fuse box harness
FAI238 - +12 APC instrument panel harness
FAI239 - Permanent +12 V supply harness
FAI240 - +12 V permanent fuse box harness
FAI241 - Automatic air conditioning adapter harness
FAI242 - Main beams on hand rail adapter harness
FAI243 - Circuit breaker harness
FAI244 - Linkage external controls extension harness
FAI245 - Left-hand linkage external controls harness
FAI246 - Right-hand linkage external controls harness
FAI247 - PTO shunt harness
FAI248 - Linkage external controls harness
FAI249 - Suspended front axle harness
FAI250 - Engine harness
FAI251 - Parking brake harness
FAI252 - +12 V battery harness
FAI253 - Hand rail harness
FAI254 - Windscreen wiper harness
FAI255 - Windscreen wiper harness
FAI256 - High-visibility roof heating harness
FAI257 - High-visibility roof heating harness
FAI258 - Roof earth harness
FAI260 - Cooling unit harness
FAI261 - Isobus harness
FAI262 - Auto-Guide engine harness
FAI263 - Auto-Guide cab adapter harness
FAI265 - Pneumatic brake harness
FAI267 - Console harness
FAI268 - Front function harness
FAI271 - Cab electric rear-view mirror harness
FAI272 - Active suspended cab harness
FAI273 - Front linkage harness
FAI274 - Rear right-hand lighting harness
FAI275 - Trailer connector harness
FAI276 - Rear left-hand lighting harness
FAI280 - Negative battery harness
FAI281 - Negative battery harness
FAI282 - Negative battery harness
FAI283 - TopDock harness

FAIxxx - Non-Isobus tool connector harness

FAIxxx - Non-Isobus implement connector controller harness

FAIxxx - Additional fan harness


B.2 Fuse box supply with circuit breaker



EFD00112_6

Fig. 12


B.3 Autotronic 4 electrical power supply



EFD00169_5_1

Fig. 13


B.4 Autotronic 5 linkage electrical power supply



EFD00169_5_2

Fig. 14


B.5 Autotronic 5 ParkLock/suspended front axle electrical power supply



EFD00169_5_3

Fig. 15


B.6 DCC3 instrument panel electrical power supply



EFD00169_5_4

Fig. 16


B.7 Autotronic 5 armrest electrical power supply



EFD00169_5_5

Fig. 17


B.8 Autotronic 5 active suspended cab electrical power supply



EFD00169_5_6

Fig. 18


B.9 Sisu EEM electronic unit electrical power supply



EFD00151_13

Fig. 19


B.10 Automatic air-conditioning unit electrical power supply



EFD00117_16

Fig. 20


B.11 Diagnostics connector electrical power supply



EFD00129_6

Fig. 21


B.12 Tractor CAN network



EFD00131_17_01

Fig. 22


B.13 Engine CAN network



EFD00131_17_2

Fig. 23


B.14 Linkage CAN network



EFD00131_17_3

Fig. 24


B.15 Isobus CAN network



EFD00131_17_4

Fig. 25

B.16 Transmission



EFD00111_7_1

Fig. 26

B.17 Transmission





Fig. 27


B.184WD front axle



EFD00100_6

Fig. 28

B.19 Differential lock



EFD00101_6

Fig. 29

5A13

ML260 - Layout of components

TABLE OF CONTENTS

A. Gearbox main components89

A. Gearbox main components

Ref.	Component description	Location
(1)	Transmission module	In the gearbox housing
(2)	Engine speed sensor	On the left-hand side on the engine block
(3)	Hare/Tortoise range sensor	On the left-hand side on the gearbox housing
(4)	Transmission control unit	On the right-hand side on the gearbox housing
(5)	High-pressure filter	On the right-hand side on the transmission control unit
(6)	Transmission control unit	On the right-hand side on the gearbox housing
(7)	Filter blockage sensor	On the right-hand side on the transmission control unit
(8)	Temperature sensor	On the right-hand side on the transmission control unit

A.1 Gearbox main components - diagram




Fig. 1

5A14

ML260 - Tests and diagnostics

TABLE OF CONTENTS


A. Hydraulic tests95
Pressure measurement sheet	103

A. Hydraulic tests

A.1 Accumulator pressure and volume

Type	Volume	Pressure
Front axle left accumulator	1 l (of which 200 ml is oil)	10 bar
Front axle right accumulator	1,4 l	50 bar
ParkLock accumulator	0,75 l	108 bar
Main braking accumulator	0,75 l	44 bar
Passive suspended cab accumulator (the pressure cannot be modified)	0,075 l (of which 0,025 l is oil)	30 bar
Semi-active suspended cab accumulator (the pressure cannot be modified)	0,075 l	38 bar
Transmission accumulator (the pressure cannot be modified)	0,3 l	10 bar

A.2 Supply pressure measurements



1008344

Fig. 1

Measurement points	Reference on component	Description
M1	KV	Cooler upstream pressure
M2	SM	Lubricating pressure
M3	AS	Flushing pressure
M4	ES	Fuel lift pressure
M5	PU	Service pump pressure
M6	P	Transmission system pressure
M7	I	Tortoise range engaging pressure
M8	II	Hare range engaging pressure

Measurement points	Reference on component	Description
M9	PH	High pressure (HP)
M10	PHA	Rear axle and brake system pressure
M22	T	Oil leak on clutch function spool valve / coupler function solenoid valve

Precaution to be taken during the pressure measurements: the oil temperature must be between 35°C and 45°C.

IMPORTANT: When measuring the transmission pressure, raise all wheels of the tractor to prevent accidents.

1. Set transmission ratio (hare/tortoise) to speed of 0.
2. Release the hand brake.
3. Engage the front axle.
4. Differential lock and PTO clutch are not engaged.

On right-hand side, in the middle of the tractor:

5. Remove right-hand rear wheel and the protection plate.
6. Connect a pressure gauge. Measure the pressures set out below according to the different engine speeds (see settings table below)
 - PU Pressure (M5). Pressure measuring point located between the service pump and the pressure filter.
 - P Pressure (M6). System pressure downstream of pressure filter.
 - ES charge pressure.
 - AS flushing or discharge pressure.
 - SM transmission lubricating pressure.

Set values for pressure measurement

Engine speeds	PU (M5)	P (M6)	ES (M4)	AS (M3)	SM (M2)
800	25 bar ± 2 bar	25 bar ± 2 bar	16 bar ± 2 bar	9 bar ± 2 bar	2 bar ± 0.4 bar
1200	26 bar ± 2 bar	25.5 bar ± 2 bar	19 bar ± 2 bar	11 bar ± 2 bar	3 bar ± 0.5 bar
1600	27 bar ± 2 bar	26 bar ± 2 bar	21 bar ± 2 bar	13 bar ± 2 bar	4.2 bar ± 0.6 bar
2000	28 bar ± 2 bar	27 bar ± 2 bar	24.5 bar ± 3 bar	16 bar ± 2.5 bar	5.5 bar ± 0.8 bar

A.3 High pressure (HP) measurements



DANGER: High pressure measurements must never exceed a maximum of 5 seconds, to prevent the oil from heating.

Preliminary steps

Engage hare range and set the starting speed to maximum, or transmission to limp home mode (do not turn the control unit by more than 15° in order to avoid heating the oil).

Measurement points	Engine speed	Specified value:
PH (M9)	1600	540 bar + 20 bar

NOTE: Load the hydrostatic loop for a maximum of 5 seconds before taking the following measurements.

Measurement points	Engine speed	Specified value
P (M6)	1600	26 bar ± 2 bar
ES (M4)	1600	22 bar ± 2 bar
AS (M3)	1600	15 bar ± 2 bar
SM (M2)	1600	3.5 bar ± 0.4 bar

NOTE: If the high pressure PH is not reached, but the AS and ES pressures are correct, check the clutch pressure relief valves 4V4 and 4V5.


A.4 Shifting pressure measurements

Measurement points	Engine speed	Specified value:
In Hare or Tortoise range (M7/M8)	1600	26 bar ± 2 bar

NOTE: Alternately supply solenoid valves 1 (4V1) and 2 (4V2) with a 12 V (DC) supply

A.5 Rear PTO, differential lock and front axle clutch solenoid valve measurement

NOTE: The unit is located on the rear axle housing, behind the spool valves. Access is limited, so great care must be taken.



1008345


Fig. 2

- M10 Rear axle, brakes and front PTO system pressure
- M11 Rear PTO clutch
- M13 750 rpm PTO selector pressure
- M14 Front axle clutch (4WD)
- M15 Differential lock
- M16 1000 rpm PTO selector pressure
- M18 Rear axle lubricating pressure

The pressure connectors can be accessed from the rear of the tractor.

NOTE: Run the engine at 1200 rpm. Simultaneously check the pressure at unions M10 and M18 (SM).

Switching status of components that consume electricity	Measurement points	M10 system pressure	M18 lubricating pressure
Power take-off - On / Off	M11	18 bar ± 0.2 bar	2 bar ± 0.3 bar
Differential lock - On/Off	M15	18 bar ± 0.2 bar	2 bar ± 0.3 bar
Front axle (4WD) - On / Off	M14	18 bar ± 0.2 bar	2.1 bar ± 0.3 bar
Activation of locked brake pedal		18 bar ± 0.2 bar	1.2 bar ± 0.3 bar




1008346

Fig. 3

- (1) Rear PTO clutch (M12 - 1.5 union)
- (2) Rear axle lubricating pressure (M10 - 1 union)
- (3 - 4) 750 or 540 speed selection (M10 - 1 union)


In order to check the rear PTO, it is also possible to measure pressure levels at the unions located at the rear right and left-hand sides of the rear axle housing.



1008347

Fig. 4

Diagram showing the pressure connectors on the valve block




1008349

Fig. 5

- (1) Service pump check
- (2) Speed limiting solenoid valve
- (3) PH pressure check
- (4) Clutch function controlled valve
- (5) Supply pressure for Hare/Tortoise range check
- (6) Tortoise range solenoid valve
- (7) Hare range solenoid valve
- (8) Coupler function solenoid valve
- (9) HP Pressure sensor
- (10) HP Pressure sensor

Valve block with test connections



1008350

Fig. 6

- (1) Lubricating pressure check (SM)
- (2) Charge pressure check (ES)
- (3) Service pump relief valve (50 b)
- (4) Charge valve (6.5 b)
- (5) Cooler bypass valve
- (6) Flushing valve (6 b)
- (7) Temperature sensor
- (8) Lubricating pressure valve (6.5 b)
- (9) Flushing pressure check (AS)
- (10) Service pressure check (PU)

A.6 Checking the hydrostatic loop in the control unit




DANGER: Check the tractor (HP pressure measurement).

1. Remove the right-hand rear wheel and the protection plate located behind it.
2. Remove the T union.
3. Fit a pressure gauge to measure pressures higher than 540 bar at the PH union.

Checking procedure:

4. Start the engine.
5. Activate limp home mode by pressing in the clutch pedal fully and pressing the button.



1008341

Fig. 7

6. Apply the hand brake.



1008342


Fig. 8

7. Use the limp home mode lever to start the transmission.

PH	T union	Possible causes
250 bar	No oil flow to the T union	Transmission module error (shuttle valve, pressure pipe union). =>Remove the module.
250 bar	Oil flows from the T union	Coupler function valve (4V4) or clutch function valve (4V5) not tightly sealed. => Change the valve.

Checking the coupler function valve (4V4)

8. Mechanically lock the valve.




1008343

Fig. 9

PH	T union	Possible causes
250 bar	Oil flows from the T union	Clutch function valve (4V5) not tightly sealed => Change the valve.
540 bar	Oil flows from the T union, but the pressure is not constant	Electrically check the coupler function valve > Change the valve if faulty

A.7 Pressure measurement sheet



-VT transmission pressure tests

Dealer number	Customer	Chassis number:	
		Engine number:	
		Entry into service:	
		Number of hours:	

 **Recommendation:** The measurements should be taken with all 4 tractor wheels raised.

CAUTION: Risk of accident

Measuring conditions: Transmission oil temperature between 35°C and 45°C

I. Measuring the supply pressures

Measurement point	Engine speed in rpm	Recommended value in bar/PSI		Measurement in bar/PSI	Note
		Measurement	Tolerance		
PU	800	25 bar	2 bar		
	1200	26 bar	2 bar		
	1600	27 bar	2 bar		
	2000	28 bar	2 bar		
P	800	25 bar	2 bar		
	1200	25.5 bar	2 bar		
	1600	26 bar	2 bar		
	2000	27 bar	2 bar		
ES	800	16 bar	2 bar		
	1200	19 bar	2 bar		
	1600	21 bar	2 bar		
	2000	24.5 bar	2 bar		
AS	800	9 bar	2 bar		
	1200	11 bar	2 bar		
	1600	13 bar	2 bar		
	2000	16 bar	2 bar		



-VT transmission pressure tests

SM	800	2 bar	2 bar		
	1200	3 bar	2 bar		
	1600	4.2 bar	2 bar		
	2000	5.5 bar	2 bar		

II. Measuring the high pressures. (Measure the pressures in forward gear and reverse gear, with a maximum measuring time of 5 seconds.)

Measurement point	Engine speed in rpm	Recommended value/bar		Measurement in bar	Remarks
		Measurement	Tolerance		
Forward/reverse PH	1600	500 bar	+ 20 bar -40 bar		
P		26 bar	+ 2 bar		
ES		13 bar	± 2 bar		
AS		12 bar	± 2 bar		
SM		1.6 bar	± 0.4 bar		

III Measuring the engagement of hare and tortoise ranges. Solenoid valves 1 and 2 supplied alternately with 12 V DC

Measurement point	Engine speed in rpm	Recommended value/bar		Measurement in bar	Remarks
		Measurement	Tolerance		
Hare	1600	26 bar	± 2 bar		
Tortoise	1600	26 bar	± 2 bar		

Date:	Signature:
-------	------------

5A15

Section intentionally left blank

Section intentionally left blank

5A16

ML260 - Adjustments, bleeding and calibrations

TABLE OF CONTENTS

A. Calibrations	109
B. Bleeding.....	118

A. Calibrations

A.1 Forward speed display.


This calibration allows improved precision of forward speed depending on:

- the different tyre sizes available
- radar (if fitted)

1. Mark out a 100 m (depending on the unit of measurement selected) on a firm surface.
2. Start up the tractor, then press and hold the display selector switch (A) for 15 seconds.

NOTE: The daily hourmeter resets to 0 after 5 seconds.

3. "CAL" should appear on the screen (Fig. 1).
4. Drive the tractor forwards at normal working speed.
5. Press the display selector switch when crossing the starting line of the 100 m course.



1007510

Fig. 1


6. "run" should appear on the screen (Fig. 2).
7. Press the display selector switch when crossing the finish line of the course.
8. Press the display selector switch; the constant forward speed (theoretical) measured during calibration is displayed.
9. Press the display selector switch again; the actual constant forward speed (radar) measured during calibration is displayed on tractors fitted with radar.
10. Press the display selector switch a final time to return the instrument panel to normal operating mode.

NOTE: The tractor must always be moving before starting out on the measured course; otherwise calibration will be incorrect.

A.2 Throttle pedal potentiometer

The calibration of the throttle pedal potentiometer must be carried out each time one of the following elements is replaced or modified:

- throttle potentiometer
- instrument panel.



1007511

Fig. 2

Preliminary steps

11. Switch on the ignition, with ParkLock engaged.
12. The power take-off must be disengaged.

Calibration

The calibration is carried out in two successive steps so as to determine the minimum and maximum engine speeds in relation to the pedal position.

Minimum speed

13. Pedal fully released, minimum engine speed.
14. Press and hold down the differential lock switch for 5 seconds.
15. An alarm sounds. This indicates the end of the first calibration phase (pedal fully released).
Release the differential switch.

Maximum speed

16. Pedal fully depressed, maximum engine speed.
17. Press and hold down the differential lock switch for 5 seconds.
18. An alarm sounds. This indicates the end of the second calibration phase (pedal fully depressed).
Release the differential switch.

A.3 Forward lever on armrest

Input at level 2 - CAL 2




To select CAL2:


1. Switch on the ignition (do not start the engine).
2. Engage and release the clutch pedal in order to delete the "TC" "DC" display from the screen on the right-hand side of the instrument panel.
3. Within the next 5 seconds, simultaneously press keys



on the DOT MATRIX control keyboard.

The screen (Fig. 3) is displayed with 5 available texts and icons:

-  Calibration of the forward lever on the armrest
-  Calibration of the automatic differential disengagement function
-  Calibration of the suspended cab
- "DC": Clears the error codes stored in DCC3



1007461

Fig. 3

- "TC": Clears the error codes stored in TC (Autotronic 4)
- "VL": Clears the calibration values

The selected function is displayed in reverse video.



- Select the required function using keys on the DOT MATRIX control keyboard and then press "OK".

Calibrating the forward lever on the armrest

The calibration of the armrest lever must be carried out each time one of the following elements is replaced or modified:

- Armrest lever potentiometer
- DCC3.



Select the icon and press "OK". The screen (Fig. 4) is displayed:

- The value on the first line indicates the current position of the lever, i.e. Neutral.
- Push the lever fully forward to "+", and the value of the first line will change. When the lever reaches its stop, validate the position by pressing the arrow at the top of the control keyboard.
- Move the lever back to Neutral, and the value on the first line will change back until it reaches this position. Validate the position by pressing the "OK" key on the control keyboard.
- Pull the lever fully backwards towards the rear of the cab to validate the limit position. When it reaches its back stop, press the arrow at the bottom of the control keyboard.
- When calibration is complete, the values can be checked by moving the lever to the three positions "+", "0" and "-" and comparing the value on the first line with the selected position.
- To quit this mode, press the "House" icon on the control keyboard.
- Switch off the ignition for at least 5 seconds to validate calibration.**


NOTE: If "ERROR" is displayed, repeat the procedure, making sure to observe the time of action and the lever position.

A.4 Automatic disengagement of the differential

Input at level 2 - CAL 2

To select CAL2:

- Switch on the ignition (do not start the engine).



1007462




Fig. 4

2. Engage and release the clutch pedal in order to delete the "TC" "DC" display from the screen on the right-hand side of the instrument panel
3. Within the next 5 seconds, simultaneously press keys




on the Dash Control Center keypad.

The screen (Fig. 3) is displayed with 5 available texts and icons:

-  Calibration of the forward lever on the armrest
-  Calibration of the automatic differential disengagement function
-  Calibration of the suspended cab
- "DC": Erase the error codes stored in the instrument panel
- "TC": Clears the error codes stored in TC (Autotronic 4)
- "VL": Clears the calibration values

The selected function is displayed in reverse video.

4. Select the required function using keys  on the Dash Control Center keypad and then press "OK".

Calibrating the automatic differential disengagement function


This function must be calibrated whenever one of the following elements is replaced or modified:

- angular sensor in the front axle
- front axle

NOTE: Before any calibration operations, move the front axle to central position. Switch off the engine in order to return to the CAL2 screen.



Select the icon and press "OK". The screen (Fig. 6) is displayed:



1007461

Fig. 5


1. The value on the first line is the reference value of the central position.
2. Press the "OK" key on the control keyboard to display this value. When the two values are identical, the calibration is considered to be correct.
3. To quit this mode, press the "House" icon on the control keyboard.

A.5 Autotronic 4 - Hare/Tortoise range - Transmission - Coupler function - Power take-off

Calibration of the following Autotronic 4 functions is necessary for optimum performance:

- Hare/Tortoise range
- transmission
- coupler function

Calibration of the power take-off is also possible with special tools if there is a problem when starting.



1007463

Fig. 6

Input at level 1 - CAL 1

IMPORTANT: In order to carry out a calibration, any error codes must be corrected.

If an error code is active: the calibration returns an error immediately.

To select CAL1:

1. Start the engine.
2. Engage and release the clutch pedal in order to delete the "TC" "DC" display from the screen on the right-hand side of the instrument panel
3. Within the next 5 seconds, simultaneously press keys



on the Dash Control Center keypad.

4. The screen (Fig. 9) appears, displaying the 4 symbols of the functions to be calibrated:



Hare/Tortoise range



Transmission




Coupler function



Power take-off

The selected function is displayed in reverse video.

5. Before starting calibration, ensure that the tractor is in a suitable condition.



1007464

Fig. 7

6. Select the function to be calibrated using keys



on the Dash Control Center keypad and then press "OK".

NOTE: This procedure must be repeated for each calibration.

Hare/Tortoise range

Calibration procedure

This calibration must be carried out systematically after changing any of the following:


- Hare range solenoid valve
- Tortoise range solenoid valve
- Range position sensor
- Autotronic 4

Preliminary conditions

1. Hand brake or ParkLock disengaged.
2. Power Control lever in neutral position.
3. Clutch pedal pressed down.
4. Engine speed less than 1000 rpm.

Calibration




5. Having selected  in the CAL1 screen (Fig. 9), press "OK" to start calibration.
6. The calibration lasts for approximately 6 minutes and takes place in 3 steps, shown one after the other on the screen (Fig. 10):
 - Step 0: Tortoise range
 - Step 1: Hare range
 - Step 2: Neutral (intermediate position)
7. The calibration result is displayed:
 - "OK": successful calibration (since the calibration procedure is ended by placing the transmission in neutral, the Hare/Tortoise symbols flash alternately on the right-hand screen)
 - "ERROR": calibration failed (repair the fault before resuming the procedure)
8. **IMPORTANT:** Switch off the ignition for at least 30 seconds in order to validate the calibration.

Transmission

Calibration procedure

This calibration must be carried out systematically after changing any of the following:

- transmission control module
- transmission
- transmission high pressure sensor
- Autotronic 4



1007465


Fig. 8


Preliminary conditions

Calibration must be carried out just after the range has been calibrated:

1. Hand brake applied or ParkLock engaged.
2. Power Control lever in neutral position.
3. Hare/Tortoise range in neutral (Hare/Tortoise symbols flash alternately on the right-hand screen).
The Hare/Tortoise range should be in neutral because calibration of the range has been carried out in the previous step.

Calibration

4. Having selected  in the CAL1 screen (Fig. 9), press "OK" to start calibration.
5. Engine speed automatically adjusts to 1600 rpm.
6. Hare/Tortoise symbols continue to flash alternately.
7. The calibration lasts for approximately 6 seconds and takes place in 7 steps, shown one after the other on the screen (Fig. 11).
These 7 steps allow calibration of the hydraulic motors and pumps.



1007466

Fig. 9

8. The calibration result is displayed:
 - "OK": successful calibration (Fig. 12)
 - "ERROR": calibration failed (repair the fault before resuming the procedure)
9. **IMPORTANT:** Switch off the ignition for at least 30 seconds in order to validate the calibration.

Coupler function

Calibration procedure

This calibration must be carried out systematically after changing any of the following:

- coupler function solenoid valve
- transmission oil high pressure sensor
- Autotronic 4

Preliminary conditions

1. Transmission temperature higher than or equal to 40°C (recommendation: do not cancel calibration if the value is too low).


There are 2 ways to view the transmission temperature:

- The value can be viewed on the gearbox screen of the diagnostic tool.
- Use the instrument panel DIAG mode via the Dash Control Center:
 - Press the top arrow for 3 seconds.
 - Select DATA (in reverse video) then press "OK".
 - The value is indicated by the "Trans Temp" line.

2. Hand brake applied or ParkLock engaged.
3. Power Control lever in neutral position.
4. Hare range engaged.

Calibration



5. Having selected  in the CAL1 screen (Fig. 9), press "OK" to start calibration.
6. Engine speed automatically adjusts to 1100 rpm.



1007467

Fig. 10

7. The calibration lasts for approximately 2 minutes and takes place in 9 steps, shown one after the other on the screen (Fig. 13).
These 9 steps allow calibration of the solenoid valve current.
8. The calibration result is displayed:
 - "OK": successful calibration
 - "ERROR": calibration failed (repair the fault before resuming the procedure)
9. **IMPORTANT:** Switch off the ignition for at least 30 seconds in order to validate the calibration.

Power take-off

Calibration procedure


- This calibration must be performed only in the event of a starting problem with a high-inertia implement
- when changing the PTO solenoid valve
- when changing the Autotronic 4


Preliminary conditions

1. Hand brake applied or ParkLock engaged.
2. Power Control lever in neutral position.
3. Select a PTO speed (540, 540ECO or 1000 rpm) depending on the implement.

Calibration




4. Having selected  in the CAL1 screen (Fig. 9), press "OK" to start calibration.
5. Engage the PTO.
6. Calibration takes place automatically, and the time taken depends on the implement (Fig. 14).
7. The calibration result is displayed:
 - "OK": successful calibration
 - "ERROR": calibration failed
8. **IMPORTANT:** Switch off the ignition for at least 30 seconds in order to validate the calibration.



1007468

Fig. 11



1007469

Fig. 12

B. Bleeding

B.1 Gearbox clutch control bleed device

9. Empty the clutch reservoir using a syringe.
10. Obtain a transparent pipe to connect to the bleed device (1) (Fig. 25)
11. Obtain an oil pump or a piston burette (measuring glass).
12. Obtain hydraulic clutch fluid type Pentosin CHS 11S


13. Remove the protective plug
14. Connect one end of the pipe to the clutch bleed device and connect the other end of the pipe to the burette.
15. Fill the burette with clutch fluid.
16. Open the bleed device.
17. Activate the burette in order to fill the clutch reservoir up to the maximum level
18. Close the bleed device.
19. Disconnect the pipe.

NOTE: Do not forget to refit the protective plug on the bleed device.

B.2 Filling the transmission unit

1. Unscrew the plug marked PU.

Essential instructions prior to bleeding




1009734

Fig. 13



1009733

Fig. 14



1008323

Fig. 15


2. Connect the filling station.

NOTE: Using the external filling station it is possible to avoid dry operation of the hydrostatic pump and hydrostatic motor.

3. Use the correct quantity and type of oil.

NOTE: During the filling process, swivel the hydrostatic pumps and motors. Ensure the hydraulic unions are completely sealed. Fill the transmission oil with a filling station.

4. Smear the contact face of the transmission housing with sealant (ref. X903.050.074).



1008324

Fig. 16


5. Fit the cover.

6. Tighten the M12 screws to a torque of:

7. Repeat the removal operations for the wiring, electrical connectors, hydraulic pipes and pneumatic system in reverse order.

8. Check all the levels.

9. Check that there are no leaks



1008325

Fig. 17

5A17

ML260 - Disassembly and reassembly

TABLE OF CONTENTS

A. Disassembling the Dyna-VT unit	123
B. Assembling the Dyna-VT unit	135
C. Removing and refitting the forward/reverse high pressure relief valves	146
D. Removing/refitting the flushing valve	147
E. ML260 gearbox - Removing the clutch control	148
F. ML260 gearbox - Refitting the clutch control	151

A. Disassembling the Dyna-VT unit

Preliminary steps

1. Drain the transmission oil (approx. 65 l).
2. Disassemble the cab.



DANGER: Before disconnecting the pipes, it is necessary to release the pressure in the brake accumulator by pumping on the pedals.

3. Remove the unions after emptying, taking all necessary precautions to prevent any dirty particles from entering the air conditioning system

NOTE: It is recommended to raise the cab slightly before splitting it.

4. Pinch the heating pipes closed to avoid draining the system.
5. Attach the cab to a suitable lifting system and raise it.




CAUTION: Take care not to damage the roof cap.

6. Disconnect the cables and hydraulic unions, taking care to mark them.
7. Remove the spool valve block.



CAUTION: Mark all parts at disassembly.

8. Raise and move the cab.
9. Remove all the pipes passing over the transmission cover.
10. Remove the spool valve assembly.



1008252

Fig. 1

11. Move the range selector to neutral.
12. Remove the limp home console from the right-hand side of the transmission.




Fig. 2

13. Remove the limp home mode cable support from the left-hand side of the transmission.





Fig. 3

14. Remove the control cable connection then the cable.



Fig. 4


- 15.** Unscrew the three attachment screws from the control unit, then remove it.



1008256

Fig. 5

- 16.** Remove the pipe between the filter support and the hydraulic unit.




1008257

Fig. 6

- 17.** Disconnect and mark all the connectors from the filter carrier.

- 18.** Remove the filter (two screws).


NOTE: Ensure there is an oil drip pan underneath the filter when disassembling.



1008258

Fig. 7


- 19.** Remove six screws from the filter support.
- 20.** Install two guide studs (M8x80).
- 21.** Remove the two remaining screws.



1008259

Fig. 8


- 22.** Remove the filter support by sliding it over the two guide studs.



1008260

Fig. 9

- 23.** Disconnect and mark all the connectors from the unit.
- 24.** Remove four screws from the hydraulic unit.
- 25.** Fit two guide studs.
- 26.** Remove the two remaining screws.




1008261

Fig. 10

- 27.** Remove the hydraulic unit, sliding it over the guide studs.


NOTE: Ensure there is an oil drip pan underneath the filter when disassembling.



1008262

Fig. 11


- 28.** Using external circlip pliers, remove all the circlips from the transmission hydraulic outlets.



1008263

Fig. 12

- 29.** Disconnect the electrical connector and remove the screws from the collector shaft sensor.



1008264

Fig. 13

30. Loosen the seal and remove the sensor.




1008265

Fig. 14

31. Unscrew the cover plate screws.


32. Raise the cover using the M10 eye-bolt.



1008266

Fig. 15


33. Using two screws, release the cover plate.



1008267

Fig. 16


34. Using a hoist, lift the cover plate.



1008268

Fig. 17

35. Remove the retaining screw from the control shaft.




1008269

Fig. 18

- (1) Reverse high pressure sensor slotted line
- (2) Rear axle system pressure
- (3) Hare range shifting pressure
- (4) Forward speed limit
- (5) Tortoise range shifting pressure
- (6) System pressure
- (7) Control pipe for the high-pressure limiter valves

36. Mark all the hydraulic hoses.



1008270

Fig. 19

37. Unscrew the two hoses with threaded end fittings, then push out the other hoses towards the inside of the gearbox.




Fig. 20

38. Remove the two connecting sleeves.




Fig. 21

39. Take the control shaft out of its housing.

NOTE: Do not lose the connecting ring (left arrow).




Fig. 22


- 40.** Attach the hydraulic hoses together using a plastic clip to assist disassembly.



1008274

Fig. 23


- 41.** Using internal circlip pliers, remove the circlip from the motor shaft.



1008275

Fig. 24

- 42.** Take the shaft out of its housing, pushing it out towards the inside of the gearbox.




1008276

Fig. 25

43. Unscrew the 3 M8 screws from the planet carrier.

44. Push the shaft towards the rear axle.




1008277

Fig. 26

45. Remove the pinion circlip.


46. Push the circlip, washer and socket towards the pinion, as indicated by the arrow.



1008278

Fig. 27


47. Swivel the hydrostatic motors and the pump inwards using a lever.



1008279

Fig. 28

48. Unscrew the 2 nuts (see arrows) located on the left and right.



1008281


Fig. 29

49. Unscrew the upper M12 lock screws.

50. On the inner surface of the gearbox housing, unscrew the 2 closing plugs.

51. Recover the oil.

52. Unscrew the 2 lock screws on the lower shaft.



1008282

Fig. 30

53. Install a lifting device (3 anchor points).


54. Slightly raise the hydraulic module, ensuring the lifting device remains under a certain level of tension.



1008283

Fig. 31

55. Using a slide hammer puller on the M20 threads, extract the flexible suspension shafts.



1008284

Fig. 32

56. Take the transmission module carefully out of the gearbox housing using the hoist.

57. Be aware of the movement of other parts.



DANGER: Do not stand under heavy loads.



1008286


Fig. 33

B. Assembling the Dyna-VT unit



CAUTION: Before reassembly, all components, mating faces and grooves must be clean. Any rust, mud or water must be removed.

58. Raise the transmission unit with a hoist, after securing it.
59. Move the range selector (Hare / Tortoise) (arrow (Fig. 34)) to "Neutral" (middle position).



1008287

Fig. 34

60. Clean any oil or seal fragments from the transmission housing mating face.

61. Move the range selector finger (arrow (Fig. 35)) to "Neutral" (middle position).

If necessary:



1008288

Fig. 35

- 62. Fit the circlip and washer on the shoulder of the pinion.
- 63. Push the socket onto the pinion.
- 64. Fit the flange on the connecting shaft (PTO drive) and fit the link shaft.



1008289

Fig. 36

- 65. Fit the transmission module in the transmission housing. Be aware of the movement of other parts.
- 66. Fit the two shafts into the bores of the transmission housing and transmission module.

NOTE: The two shafts are of different lengths; the longer one is fitted at the base of the gearbox housing.



1008290

Fig. 37

- 67. Check the sockets (flexible) for wear, and fit new sockets if necessary.
- 68. Fit the sockets home in the bores.



1008291

Fig. 38

- 69.** Fit the ring, with the bore turned towards the flexible socket.
- 70.** Tighten the M20 nut.
- 71.** Carry out the same assembly operation on the three other threads.




1008292

Fig. 39

- 72.** Tighten the four M20 nuts to a torque of:

NOTE: When tightening, hold the opposite nut still.

- 73.** Unhook the hoist.



1008293

Fig. 40

- 74.** Install a planet gear of the power transmission epicyclic gear train turned upwards.
- 75.** Centre the transmission module. The distance between the ring gear and the transmission housing must be identical on either side.



1008294

Fig. 41

76. Tighten the 4 locking screws to a torque of:

77. Check that the Hare/Tortoise range shifting operates correctly (check finger positioning).


78. Turn the transmission module until a tooth of the disc, intended for the Hall sensor, is at the centre of the bore (arrow).

79. Smear the contact face of the Hall sensor with sealant (ref. X903.050.553) (non-hardening) and insert the sensor into its housing.

80. Tighten the attachment screws to a torque of:


81. Reconnect the electrical connector.

NOTE: If the Hall sensor is being reused, insert 2 strips of paper 0.9 mm thick into the Hall sensor groove (these strips ensure centring).




1008295

Fig. 42



1008296


Fig. 43



1008297

Fig. 44

82. Swivel the hydrostatic motors to their stop (45°).




1008298

Fig. 45

83. Pull the pinion socket forwards to release the groove from the circlip. Insert the circlip into the groove.


NOTE: If the socket does not engage, chock a front wheel and turn it until the socket is engaged.



1008299

Fig. 46

84. Fit the flange on the epicyclic gear train. Tighten the M8 screws to a torque of:




1008300

Fig. 47

85. Insert the hydraulic hoses into the bores on the front right-hand side of the transmission housing.


NOTE: To assist in the assembly of hoses, an M10 threaded rod can be screwed onto the end of the hose (arrow).



1008301

Fig. 48

- (1) Reverse high pressure sensor slotted line
 - (2) Rear axle system pressure
 - (3) Hare range shifting pressure
 - (4) Forward speed limit
 - (5) Tortoise range shifting pressure
 - (6) System pressure
 - (7) Control pipe for the high-pressure limiter valves
- 86.** Insert the pressure pipes in the bores in the right-hand side of the transmission housing.
- 87.** Secure the hoses using circlips (opening facing downwards).
- 1- short blue hose (flushing)
 - 2 long blue hose (charging)
 - 3 black hose (lubricating)




1008270

Fig. 49

88. Fit the M8x80 guide studs where specified by the arrows.


At the front on top of the transmission housing:



1008302

Fig. 50


- 89.** Fit the ring in the groove of the shaft.
- 90.** Push the shaft forwards. Install the washer.
- 91.** Fit the circlip in the pinion groove.



1008303

Fig. 51


- 92.** Fit the hydraulic pipe (supply pressure of auxiliary functions).



1008304

Fig. 52


- 93.** Fit new "O" rings.
- 94.** Stick seals in the block using grease.



1008305

Fig. 53


- 95. Fit the control unit using two guide studs.
- 96. Tighten the attachment screws (from the inside to the outside) to a torque of:



1008306

Fig. 54

- 97. Fit new "O" rings to the connecting pipe.



1008307

Fig. 55

- 98. Smear the "O" rings with grease, and insert the pipe into the transmission housing.



1008309

Fig. 56

99. Fit new "O" rings.

100. Stick seals in the block using grease.



1008312

Fig. 57

101. Fit the valve block using two guide studs.

102. Tighten the attachment screws (from the inside to the outside) to a torque of:




1008313

Fig. 58

103. Fit the filter support fitted with new "O" rings.

104. Tighten the attachment screws (from the inside to the outside) to a torque of:


105. Connect the connectors and hydraulic pipes.



1008315

Fig. 59

106. Fit the control shaft, fitted with the connecting ring.




1008316

Fig. 60

107. Turn the shaft until the lock screw thread can be seen.

NOTE: Smear the thread of the Allen screw with plastic binder (LOCTITE) (Ref. X 903.050.084) and tighten the screw to the following torque:




1008317

Fig. 61

108. Fit the pre-assembled control unit on the transmission housing.

109. Tighten the M8 cylindrical screws to a torque of:

110. Reconnect the electrical connector.



1008318

Fig. 62

111. Refit the blanking plugs to the underside of the transmission housing.

112. Fill the transmission unit.



1008319

Fig. 63

C. Removing and refitting the forward/reverse high pressure relief valves

1. Drain the transmission oil.
 - (V) Forward high pressure relief valve
 - (R) Reverse high pressure relief valve
2. Loosen the 2 hexagonal head plugs located under the transmission housing.
3. Use a wrench to remove the high pressure relief valves.



1008336

Fig. 64

The high pressure relief valve is a controlled pressure relief valve
Adjustment pressure when new: 540 bar +20 bar.
Only replace "O" rings if they are damaged. Do not move the thrust collar. Tighten the pressure relief valve to a torque of:

NOTE: Fill the transmission oil at an external filling station.




1008337

Fig. 65

D. Removing/refitting the flushing valve

1. Drain the transmission oil.
2. Remove the plug located under the transmission housing.
3. Use a wrench to remove the flushing valve.



1008339

Fig. 66

Only replace "O" rings if they are damaged. Do not move the thrust collars. The thrust collars are positioned facing each other. Tighten the flushing valve to a torque of 200 Nm + 10 Nm

NOTE: The new flushing valve with a seal groove is provided as a replacement. Tighten to the required torque of:

4. Fill the transmission oil at an external filling station.




1008340

Fig. 67

E. ML260 gearbox - Removing the clutch control

Steps required before disassembly

5. Remove the bonnet
6. Remove the trim under the steering wheel
7. Empty the clutch fluid reservoir using a syringe.
8. Inside the cab, remove the cotter pin retaining the clutch pedal shaft joint (1) (Fig. 68).




1009724

Fig. 68

9. Loosen the hydraulic union (1) (Fig. 69)

NOTE: Take care not to lose the hydraulic union seals.



1009725

Fig. 69

10. Protect the surrounding area underneath the clutch reservoir.
11. Disconnect the hydraulic union.



1009726

Fig. 70

12. Remove the lower attachment screw from the clutch master cylinder.



1009727

Fig. 71

13. Remove the upper attachment screw from the clutch master cylinder.



1009728

Fig. 72

14. Remove the clutch master cylinder.

NOTE: The control clevis is removed with the master cylinder



1009729

Fig. 73

- 15.** Measure and note down the distance from the support face of the master cylinder and the end of the control clevis.



1009730

Fig. 74


- 16.** Immobilise the control clevis and loosen the counter-nut by one half-turn.



1009731

Fig. 75

- 17.** Remove the control clevis.




1009732

Fig. 76

F. ML260 gearbox - Refitting the clutch control


18. Fit the control clevis, observing the dimension measured at the time of removal.
19. Tighten the counter-nut.



1009730

Fig. 77


20. Fit the master cylinder assembly and clevis.




1009729

Fig. 78

21. Fit the master cylinder attachment screws and torque



tighten them to




1009727

Fig. 79

- 22.** Fit the hydraulic union (1) (Fig. 80) and its 2 copper seals.

NOTE: Check the condition of the copper seals; it is preferable to fit new seals.




1009725

Fig. 80

- 23.** Fit the control pin (1) into the clevis (3) (Fig. 81).

NOTE: Observe the correct fitting position of the spacer (2).

- 24.** Refit the pin and lock it in place by bending it.
25. Refit the trim under the steering wheel.
26. Refit the bonnet.
27. Bleed the clutch control.



1009724

Fig. 81

5A18

ML260 - Service tools

TABLE OF CONTENTS

A. General	155
B. ML260 - Service tools	156

A. General

The tools described in this section can be ordered from the AGCO spare parts department or by contacting the tooling division of Beauvais by referring to AGCOnet bulletin Trac 60/07.

The prices will then be sent out to you.

B. ML260 - Service tools

Ref.	AG01
Description	Hydraulics test kit
Order	AGCO Stoneleigh

Contents


See Service Bulletin ADM 08/04

Ref.	X899.980.255.000
Description	External filling station
Order	Parts Division



1009102


Fig. 1



1008324

Fig. 2

Ref.	X899.980.255.100
Description	Replacement filter
Order	Parts Division




1012084

Fig. 3

Ref.	4315657M1
Description	Cab lifting sling
Order	AGCO Beauvais

Contents

Ref.	Description	Qty
	L2M actuator lever, 2 t	1-
A	Round slings 1 t - length 2 m	2
B	Hooks	2
C	13 connecting link	1-
D	16 shackle	1-
E	Round slings 3 t - length 1 m	2
F	"10" connecting links	2
G	Locking hooks with 01 eye	2
H	Round slings 1 t - length 0,5 m	2



1008688

Fig. 4

