


# Chapter 7



## Power take-off

### TABLE OF CONTENTS

- 7A10 - HA260/Power take-off - General
- 7A11 - HA260/Power take-off - Error codes
- 7A12 - HA260/Power take-off - Diagrams and plans
- 7A13 - HA260/Power take-off - Layout of components
- 7A14 - HA260/Power take-off - Tests and diagnostics
- 7A15 - Section intentionally left blank
- 7A16 - HA260/Power take-off - Adjustments, bleeding and calibrations
- 7A17 - HA260/Power take-off - Disassembly and reassembly
- 7A18 - HA260/Power take-off - Service tools
- 7B10 - Zuidberg front power take-off - General
- 7B11 - Section intentionally left blank
- 7B12 - Zuidberg front power take-off - Diagrams and plans
- 7B13 - Zuidberg front power take-off - Layout of components
- 7B14 - Zuidberg front power take-off - Tests and diagnostics
- 7B15 - Section intentionally left blank
- 7B16 - Zuidberg front power take-off - Adjustments, bleeding and calibrations
- 7B17 - Zuidberg front power take-off - Disassembly and reassembly
- 7B18 - Zuidberg front power take-off - Service tools



7A10

**HA260/Power take-off - General**

**TABLE OF CONTENTS**

A. General .....3




---

## A. General

---

### Description

The PTO drive mechanism is fitted in the rear part of the axle, behind the differential. The gear assembly rests on tapered roller bearings supported by the axle housing at the front and by the removable PTO cover plate at the rear. The assembly is activated directly by the engine via a multidisc clutch. The movement is recovered at the end of the primary shaft of the gearbox.




1007500

Fig. 1

### Clutch

This is located at the top of the PTO housing. It is supported by two straight bearings (2) and (36) fitted inside the axle housing on one side and inside the PTO cover plate on the other side.



1007501


Fig. 2

**Upper shaftline**

The upper shaftline of the PTO transfers the engine speed to the driving gears via the clutch. The clutch/engine shaft connection is provided by means of a splined shaft (47). The system acting on the clutch is located on the PTO housing side.

The assembly comprises the clutch (100), the mechanism (200) and a shaft gear (35) with an integral gear (25).

The input shaft drives the clutch bell housing (3), which transfers the movement to the driving gears (25) and (35) through the clutch discs (10). The clutch mechanism (200) holds the disc assembly together (100) according to the hydraulic pressure acting on the piston (13). The return of the piston is governed by the spring washers (9).




1007502

Fig. 3

The clearance of the bearings supporting the upper shaftline is adjusted by means of shims (1) inserted between the cup and the rear axle housing; the bearings are kept in motion by rings with rectangular sections (37).

A gallery inside the housing provides lubricating oil to the bearings and the driving gears.



1007503

Fig. 4


**Lower shaftline**

The lower shaftline is supported at the front by a bearing (101) force fitted into the housing, and at the rear by a hub turning in a bearing (123).

The shaftline's output shaft is lubricated by an internal gallery.

The shaft sealing is provided by a lip seal (126) fitted inside the cover plate of the PTO housing.

The plate (118) differs depending on the PTO option selected: 540 rpm or 750 rpm.



1007504

Fig. 5





7A11










## **HA260/Power take-off - Error codes**

### **TABLE OF CONTENTS**

A. Reading error codes . . . . .	9
B. PTO error codes . . . . .	10
C. Instrument panel error codes . . . . .	11



## A. Reading error codes

ERROR CODES DISPLAYED ON THE INSTRUMENT PANEL				
	DISPLAY with Dash Control Center			DISPLAY without Dash Control Center
Instrument panel		+	Letter D (Dashboard)	Letter D (Dashboard)
Engine		+	Letter E (Engine)	Letter E (Engine)
SCR system	no icon		Letter U (Urea)	Letter U (Urea)
Transmission/4WD/PTO		+	Letter T (Transmission)	Letter T (Transmission)
Lights module		+	Letter L (Light)	Letter L (Light)
ParkLock		+	Letter P (ParkLock)	Letter P (ParkLock)
Front axle		+	Letters FA (Front Axle)	Letters FA (Front Axle)
Linkage		+	Letters R (Linkage)	Letter R (Linkage)
Electrohydraulic		+	Letters H (Hydraulics)	Letter H (Hydraulics)
Cab		+	Letters C (Cab)	Letter C (Cab)
Auto-Guide		+	Letters A (Auto-Guide)	Letter A (Auto-Guide)
Control Arm		+	Letters AR (ARmrest)	Letter AR (ARmrest)

OTHER DISPLAYS	
Automatic air conditioning	Displayed on the air conditioning module.

## B. PTO error codes

No.		Components concerned	Causes
T	6101	<b>X128</b> - Rear PTO ON/OFF switch	Signal error
T	6103	<b>X94</b> - PTO ON/OFF switch on left-hand fender	Signal error
T	6104	<b>X7</b> - Rear PTO solenoid valve	Control error
T	6105	<b>X15</b> - PTO clutch speed sensor	Signal error
T	6110	<b>X16</b> - PTO shaft speed sensor	Signal error
T	6111	<b>X118</b> - Automatic PTO switch	Signal error
T	6113	<b>X16</b> - PTO shaft speed sensor	Overspeed
T	6115	<b>X145</b> - PTO/linkage console	Signal error
T	6116	<b>X145</b> - PTO/linkage console	Signal error
T	6117	<b>X145</b> - PTO/linkage console	Signal error
T	6118	<b>X145</b> - PTO/linkage console	Signal error
T	611A	<b>X3</b> - 540 rpm PTO speed solenoid valve	Control error
T	611B	<b>X3</b> - 540 rpm PTO speed solenoid valve	Control error
T	611C	<b>X4</b> - 1000 rpm PTO speed solenoid valve	Control error
T	6141	<b>X128</b> - Rear PTO ON/OFF switch	Pressed down for over 30 seconds, mechanical or electrical error on switch
T	6143	<b>X94</b> - PTO ON/OFF switch on left-hand fender	Pressed down for over 30 seconds, mechanical or electrical error on switch
T	6145	<b>X15</b> - PTO clutch speed sensor	NEUTRAL speed selection, PTO not activated, X15 displays a speed, the clutch disc does not separate, PTO brake does not engage selected speed, PTO clutch 100% engaged, over 20% difference between PTO clutch speed and engine speed. PTO clutch disc slips: clutch slippage. PTO clutch speed is lower than output shaft speed, X15 sensor supply voltage error.
T	6150	<b>X16</b> - PTO shaft speed sensor	The PTO shaft speed is higher than 1300 rpm, signal error (X16 or X15). The selected speed is lower than the PTO output shaft speed, X16 sensor supply voltage error, speed solenoid valve (X4, X3) locked in "de-activated" position.
T	6155	<b>X145</b> - PTO/linkage console	Pressed down for over 30 seconds, mechanical or electrical error on switch
T	6156	<b>X145</b> - PTO/linkage console	Pressed down for over 30 seconds, mechanical or electrical error on switch
T	6157	<b>X145</b> - PTO/linkage console	Pressed down for over 30 seconds, mechanical or electrical error on switch
T	6158	<b>X145</b> - PTO/linkage console	Pressed down for over 30 seconds, mechanical or electrical error on switch
T	6160	<b>X15</b> - PTO clutch speed sensor <b>X16</b> - PTO shaft speed sensor	Difference of at least 12% between the output shaft speed and PTO clutch speed, speed solenoid valve (X4, X3) incorrectly connected or seized up. Mechanical fault with speed selection. Signal error to sensors (X15, X16)
T	61A1	<b>X128</b> - Rear PTO ON/OFF switch	Communication error
T	61B0	<b>X128</b> - Rear PTO ON/OFF switch	Initialisation error
T	61B5	<b>X145</b> - PTO/linkage console	Communication error
T	61B6	<b>X145</b> - PTO/linkage console	Communication error
T	61B7	<b>X145</b> - PTO/linkage console	Communication error
T	61B8	<b>X145</b> - PTO/linkage console	Communication error
T	61E0	<b>X174</b> - Autotronic 4 transmission controller	Faulty programming
T	61E1	<b>X174</b> - Autotronic 4 transmission controller	Faulty programming

## C. Instrument panel error codes

No.		Component(s) concerned	Cause(s)
D	121		Alternator regulator voltage too high (filtered battery signal)
D	122		Alternator regulator voltage too low (filtered battery signal)
D	127	<b>X197</b> - Diesel fuel gauge	Electrical signal too high
D	128		Electrical signal too low
D	129		Battery voltage too high (non-filtered battery signal)
D	130		Battery voltage too low (non-filtered battery signal)
D	133	<b>X71</b> - Throttle pedal sensor	Electrical signal too high
D	134		Electrical signal too low
D	135	<b>X56</b> - Power Control lever <b>X71</b> - Throttle pedal sensor	Electrical signal too high - C.N.
D	136		Electrical signal too low - C.N.
D	137	<b>X106</b> - Transmission lever in armrest	Electrical signal too high
D	138		Electrical signal too low
D	139	<b>X68</b> - Clutch pedal sensor	Electrical signal too high
D	140		Electrical signal too low
D	141	<b>X25</b> - Engine speed sensor	Engine speed signal not at maximum level
D	142	<b>X68</b> - Clutch pedal sensor	Short circuit to + 12 V AC
D	143		Short circuit to + 12 V AC - C.N.
D	144	<b>X56</b> - Power Control lever	Electrical signal too high
D	145		Electrical signal too low
D	146		Electrical signal too high
D	147		Electrical signal too low
D	148	<b>X55</b> - Instrument panel	Attempt to program with engine running
D	149		CAN network deactivated (CAN bus off)
D	150		CAN messages lost
D	151		Tractor speed too high
D	152	<b>X55</b> - Instrument panel	Hourmeter error for engine maintenance
D	153		Parameter table error
D	154		CAN communications from Autotronic 4 to DCC3 - C.N. Special failed
D	155	<b>X55</b> - Instrument panel	Incorrect tractor code selected
D	156	<b>X68</b> - Clutch pedal sensor	TOC stuck open
D	157	<b>X25</b> - Engine speed sensor	No electrical signal
D	158	<b>X106</b> - Transmission lever in armrest	Incorrect calibration of armrest lever
D	159	<b>X56</b> - Power Control lever	Neutral switch error in neutral - C.N. position
D	160		Neutral switch error outside neutral - C.N. position
D	164		CAN communications from EEM to DCC3 failed
D	170	<b>X122</b> - Hand throttle	
D	183	<b>X235</b> - Front axle steering sensor (WAS sensor)	Electrical signal too high
D	184		Electrical signal too low
D	185	<b>X57</b> - DOT Matrix keyboard	Electrical signal too high
D	186		Electrical signal too low
D	189	<b>X55</b> - Instrument panel	9.5 V output - electrical signal too high
D	190		9.5 V output - electrical signal too low
D	191	<b>X168</b> - Pneumatic brake system pressure sensor	Electrical signal too high
D	192		Electrical signal too low

No.		Component(s) concerned	Cause(s)
D	193	<b>X144</b> - Variable steering setting potentiometer (fast steering)	Electrical signal too high
D	194		Electrical signal too low
D	195	<b>X55</b> - Instrument panel	Electrical signal too high
D	196		Electrical signal too low
D	197	<b>X1</b> - Auxiliary hydraulic oil temperature sensor	Electrical signal too high
D	198		Electrical signal too low

7A12

## **HA260/Power take-off - Diagrams and plans**

### **TABLE OF CONTENTS**

A. Hydraulics diagram .....	15
B. Electrical diagrams .....	18





## A. Hydraulics diagram

### *Different systems*

- (1) Valve block (fuel lift/lubrication)
- (2) Hydrostatic loop
- (3) Settings
- (4) Transmission control unit
- (5) Rear axle
- (6) Solenoid valve block on rear axle

### *Pumps*

- (1P1) Service pump
- (1P2) Lubrication pump
- (2P1) Hydrostatic pump

### *Drive components*

- (2A1) Hydrostatic motor
- (2A2) Hydrostatic motor
- (3A1) Piston for setting the hydrostatic pump displacement
- (3A2) Piston for setting the hydrostatic motor displacement
- (3A3) Forward speed limiter in limp home mode
- (4A1) Forward range selector
- (6A1) Rear PTO clutch
- (6A3) 1000 rpm PTO selector piston
- (6A4) Front axle clutch
- (6A5) Rear axle differential lock
- (6A6) 750 rpm PTO selector piston
- (6A7) Front axle differential lock

### *Sensors*

- (1S1) Transmission oil temperature sensor
- (1S2) Pressure filter blockage switch
- (4S1) HP loop pressure sensor
- (4S2) Pressure sensor

### *Other components*

- (1Z1) Intake filter with bypass
- (1Z2) Pressure filter with bypass
- (1Z3) Transmission oil cooler
- (1Z4) Transmission lubrication
- (3Z1) Cam channel adjustment shaft
- (3Z2) Control unit
- (4Z1) Clutch pedal with clutch master cylinder
- (4Z2) Accumulator
- (5Z2) Rear PTO lubrication
- (5Z3) Differential and right-hand brake lubrication
- (5Z4) Differential and left-hand brake lubrication

### *Valves (or spool valves/solenoid valves)*

- (1V1) Cooler bypass valve
- (1V2) Flushing pressure relief valve
- (1V3) Fuel lift pressure relief valve
- (1V4) Lubricating pressure relief valve
- (1V5) Service pump pressure relief valve
- (1V6) System pressure relief valve
- (2V1) Reverse fuel lift non-return valve
- (2V2) Forward fuel lift non-return valve
- (2V3) Forward high-pressure relief valve
- (2V4) Reverse high-pressure relief valve
- (2V5) Flushing valve
- (2V6) Shuttle valve
- (3V1) Hydrostatic pump control spool valve
- (3V2) Hydrostatic motor control spool valve
- (4V1) Hare range solenoid valve

### *Valves (or spool valves/solenoid valves)*

- (4V2) Tortoise range solenoid valve
- (4V3) Forward speed limiting solenoid valve
- (4V4) Coupler function solenoid valve
- (4V5) Clutch function spool valve
- (4V6) Rear axle pressure relief spool valve
- (6V1) Rear PTO clutch solenoid valve
- (6V3) 540 (or 750) rpm PTO control solenoid valve (depending on equipment)
- (6V4) Front axle clutch solenoid valve
- (6V5) Differential lock solenoid valve
- (6V6) 1000 rpm PTO control solenoid valve

### *Measurement points*

- (M1) Pressure upstream of cooler
- (M2) Lubricating pressure
- (M3) Flushing pressure
- (M4) Fuel lift pressure
- (M5) Service pump pressure
- (M6) Transmission system pressure
- (M7) Range 1 engaging pressure (Tortoise)
- (M8) Range 2 engaging pressure (Hare)
- (M9) High pressure
- (M10) Rear axle and brake system pressure
- (M11) PTO clutch pressure
- (M13) 540 (or 750) rpm PTO selector pressure (depending on equipment)
- (M14) Front axle clutch pressure
- (M15) Differential lock pressure
- (M16) 1000 rpm PTO selector pressure
- (M18) Lubricating pressure
- (M22) Oil leak from clutch or coupler function valve



A.1 Transmission hydraulics diagram




Fig. 1

## B. Electrical diagrams

### B.1 Identification of electrical connectors and harnesses

Identification of electrical connectors

- X1** - Auxiliary hydraulic oil temperature sensor
- X2** - Auxiliary hydraulic oil filter blockage switch
- X3** - 540 rpm PTO speed solenoid valve
- X4** - 1000 rpm PTO speed solenoid valve
- X5** - 4WD solenoid valve
- X6** - Differential lock solenoid valve
- X7** - Rear PTO solenoid valve
- X8** - Bevel gear theoretical speed sensor
- X9** - Transmission oil high pressure sensor 1
- X10** - Collecting shaft speed sensor
- X11** - Solenoid valve limiting speed to 30 kph
- X12** - Coupler function solenoid valve
- X13** - Hare range solenoid valve
- X14** - Tortoise range solenoid valve
- X15** - PTO clutch speed sensor
- X16** - PTO shaft speed sensor
- X17** - Hare/Tortoise range position sensor
- X18** - Transmission control module
- X19** - Transmission hydraulic oil temperature sensor
- X20** - Transmission filter blockage switch
- X21** - ParkLock brake pressure sensor
- X22** - Radar
- X23** - Steering pressure sensor
- X24** - Auxiliary hydraulic oil gauge
- X25** - Engine speed sensor
- X26** - Pneumatic brake solenoid valve
- X27** - Rear linkage lifting solenoid valve
- X28** - Rear linkage lowering solenoid valve
- X29** - Dual Control socket connector
- X30** - Rear linkage position sensor
- X31** - Rear linkage right-hand draft sensor
- X32** - Rear linkage left-hand draft sensor
- X33** - Transmission harness CAN junction
- X34** - Transmission oil high pressure sensor 2
- X35** - ParkLock hydraulic system pressure sensor
- X36** - LS signal breaker solenoid valve
- X37** - ParkLock pressure reversing solenoid valve
- X38** - Trailer braking proportional solenoid valve
- X39** - Trailer braking safety solenoid valve
- X40** - Front linkage single/double acting function solenoid valve
- X41** - Divider solenoid valve 1
- X42** - Divider solenoid valve 2
- X43** - Auto-hitch lifting solenoid valve
- X44** - Auto-hitch lowering solenoid valve
- X45** - Bleed for pneumatic suspended cab front and rear systems
- X46** - Rear left-hand ram position sensor for cab suspension
- X47** - Rear right-hand unit for suspended cab
- X48** - Rear left-hand unit for suspended cab
- X49** - Suspended cab rear lowering solenoid valve
- X50** - Suspended cab front lowering solenoid valve
- X51** - Transmission harness earth (chassis)
- X52** - Engine harness/transmission harness junction
- X53** - Cab transmission harness/transmission harness junction
- X54** - Suspended cab lifting solenoid valve
- X55** - Instrument panel
- X56** - Power Control lever
- X57** - DOT Matrix keyboard
- X58** - Windscreen wiper and indicator control unit
- X59** - DOT Matrix keyboard connection on instrument panel
- X60** - Engine harness/instrument panel harness junction
- X61** - Cab transmission harness/engine harness junction
- X62** - Instrument panel harness/cab transmission harness junction
- X63** - Instrument panel harness connection on fuse box
- X64** - Instrument panel harness connection on fuse box
- X65** - Front windscreen wiper motor
- X66** - Left-hand brake pedal sensor
- X67** - Right-hand brake pedal sensor
- X68** - Clutch pedal sensor
- X69** - Cab interior temperature sensor
- X70** - Solar radiation sensor
- X71** - Throttle pedal sensor
- X72** - ParkLock switch on Power Control lever
- X73** - Buzzer Control
- X74** - Buzzer Supply (+12 V APC)
- X75** - Pillar harness/right-hand fender harness junction
- X76** - Rear right-hand indicator
- X77** - Rear right-hand side light and stop light
- X78** - Work light on rear right-hand fender
- X79** - -
- X80** - -
- X81** - -
- X82** - -
- X83** - -
- X84** - -
- X85** - -
- X86** - -
- X87** - Linkage lifting/lowering switch on right-hand fender
- X88** - Rear right-hand NA indicator extension
- X89** - Earth (chassis)
- X90** - Pillar harness/left-hand fender harness junction
- X91** - Rear left-hand indicator
- X92** - Rear left-hand side light and stop light
- X93** - Work light on rear left-hand fender
- X94** - PTO ON/OFF switch on left-hand fender
- X95** - PTO Stop switch on left-hand fender
- X96** - Hydraulic spool valve switch on left-hand fender
- X97** - Linkage lifting/lowering switch on left-hand fender
- X98** - Rear left-hand NA indicator extension
- X99** - PTO and linkage console harness/cab transmission harness junction
- X100** - Instrument panel harness earth (chassis)
- X101** - Instrument panel harness/electric rear-view mirror harness junction
- X102** - Right-hand fender lighting harness/trailer connector harness junction
- X103** - Armrest harness/cab transmission harness junction
- X104** - Armrest Autotronic 5

- X105** - Datatronic CCD  
**X106** - Transmission lever in armrest  
**X107** - Headland mode switch (headland function)  
**X108** - FingerTIP 3  
**X109** - FingerTIP 4  
**X110** - FingerTIP 5  
**X111** - DTM dynamic transmission mode switch  
**X112** - Joystick  
**X113** - Armrest 6-button keyboard  
**X114** - Supply on fuse box for 3rd spool valve  
**X115** - Supply on fuse box for 4th spool valve  
**X116** - +12 V battery supply (for lighting module)  
**X117** - Isobus +12 V battery power socket  
**X118** - Automatic PTO switch  
**X119** - Rear linkage lifting/lowering switch  
**X120** - Datatronic CCD navigation keyboard  
**X121** - Rear linkage height/depth adjustment thumb wheel  
**X122** - Hand throttle  
**X123** - Hare/Tortoise range shift switch  
**X124** - Pedal/lever mode switch  
**X125** - SV1 speed setting potentiometer  
**X126** - SV2 speed setting potentiometer  
**X127** - Front PTO ON/OFF switch  
**X128** - Rear PTO ON/OFF switch  
**X129** - Fuse box +12 V battery connection  
**X130** - FingerTIP 6 front linkage function  
**X131** - Front linkage suspension solenoid valve  
**X132** - Instrument panel harness/armrest harness junction  
**X133** - Console harness/cab transmission harness junction  
**X134** - Console harness/pillar harness junction  
**X135** - Braking pressure sensor  
**X136** - Differential lock switch  
**X137** - 4WD switch  
**X138** - Hazard warning lights indicator light and switch  
**X139** - Suspended front axle switch  
**X140** - Suspended front axle setting potentiometer  
**X141** - Suspended cab switch  
**X142** - Suspended cab setting potentiometer  
**X143** - Variable steering switch (fast steering)  
**X144** - Variable steering setting potentiometer (fast steering)  
**X145** - PTO/linkage console  
**X146** - Rear linkage suspension switch  
**X147** - Roof harness/pillar harness junction  
**X148** - Roof harness/pillar harness junction  
**X149** - Headlights module (black connector)  
**X150** - Pillar harness/cab power socket harness junction  
**X151** - Pillar harness/cab power socket harness junction  
**X152** - Start switch  
**X153** - Non-Isobus implement connector  
**X154** - Suspended front axle lifting solenoid valve  
**X155** - Cigarette lighter socket (power)  
**X156** - Cigarette lighter socket (backlighting)  
**X157** - Left-hand side +12 V socket (power)  
**X158** - Left-hand side +12 V socket (backlighting)  
**X159** - Suspended front axle lowering solenoid valve  
**X160** - Console harness earth (chassis)  
**X161** - Solenoid valve 1 for suspended front axle suspension  
**X162** - Pillar harness connection on fuse box  
**X163** - Solenoid valve 2 for suspended front axle suspension  
**X164** - Pillar harness/cab transmission harness junction  
**X165** - Automatic air conditioning harness/pillar harness junction  
**X166** - Suspended front axle position sensor  
**X167** - +12 V APC fuse box connection  
**X168** - Pneumatic brake system pressure sensor  
**X169** - Power socket control switch (in cab)  
**X170** - Pillar harness connection on fuse box  
**X171** - Cab transmission harness connection on fuse box  
**X172** - Cab transmission harness connection on fuse box  
**X173** - Cab transmission harness earth  
**X174** - Autotronic 4 transmission controller  
**X175** - Emergency control switch  
**X176** - Earth (Autotronic 4 transmission controller)  
**X177** - Autotronic 5 Linkage  
**X178** - ParkLock/suspended front axle/passive suspended cab Autotronic 5  
**X179** - Main lighting, sidelight/dipped light activation switch  
**X180** - Front windscreen washer pump  
**X181** - Front linkage single acting / double acting function switch  
**X182** - Linkage external lifting switch  
**X183** - Diagnostics connector (tractor-Isobus CAN)  
**X184** - Diagnostics connector (engine-valve CAN)  
**X185** - Sisu EEM unit  
**X186** - Starter  
**X187** - Engine start relay  
**X188** - Engine identification module (ID module)  
**X189** - Fuel lift pump  
**X190** - Vistronic fan  
**X191** - Diesel fuel preheater  
**X192** - B + alternator 1  
**X193** - B + alternator 2  
**X194** - D + alternator 1  
**X195** - D + alternator 2  
**X196** - In line fuse (225 A)  
**X197** - Diesel fuel gauge  
**X198** - Pneumatic trailer brake sensor  
**X199** - Work light on left-hand step  
**X200** - Work light on right-hand step  
**X201** - Engine harness earth  
**X202** - Front accessory connection socket harness/front function harness junction  
**X203** - Engine harness/front headlights harness junction  
**X204** - Cooling unit harness/engine harness junction  
**X205** - Front axle harness/engine harness junction  
**X206** - Sensor detecting water in the diesel fuel  
**X207** - Pneumatic seat adjustment control  
**X208** - Front linkage suspension switch LED  
**X209** - Rear linkage external lowering switch  
**X210** - Orbitrol steering sensor (SASA sensor)  
**X211** - Rear Dual Control connector

- X212** - Instrument panel harness/armrest harness junction
- X213** - Power socket for additional heating
- X214** - Armrest harness/cab transmission harness junction
- X215** - Trailer connector (right-hand side light and number plate lights)
- X216** - Reversing light
- X217** - Isobus CAN connector
- X218** - External Isobus tool connector
- X219** - Cab Isobus harness/external Isobus harness junction
- X220** - Trailer connector (left-hand side light)
- X221** - Trailer connector (right-hand indicator)
- X222** - Trailer connector (left-hand indicator)
- X223** - Trailer connector (brake lights)
- X224** - Trailer connector (earth)
- X225** - Trailer connector (reversing light)
- X226** - Trailer connector harness earth
- X227** - Console harness/cab transmission harness junction
- X228** - Front linkage single/double-acting function LED
- X229** - 120 Ohm CAN 1 resistor (cab transmission harness)
- X230** - 120 Ohm CAN 2 resistor (cab transmission harness)
- X231** - 120 Ohm CAN 3 resistor (cab transmission harness)
- X232** - 120 Ohm CAN 4 resistor (cab transmission harness)
- X233** - Cab transmission harness/Isobus harness junction
- X234** - 120 Ohm CAN ATC resistor
- X235** - Front axle steering sensor (WAS sensor)
- X236** - Electrohydraulic Orbitrol (grey connector)
- X237** - Electrohydraulic Orbitrol (black connector)
- X238** - Connector 1 for valve harness
- X239** - Connector 2 for valve harness
- X240** - 120 Ohm resistor for electrohydraulic spool valves
- X241** - Sisu engine preheating supply (Grid Heater)
- X242** - Exhaust temperature sensor
- X243** - AdBlue/DEF reservoir (urea) level gauge and temperature sensor
- X244** - CAN SCR harness
- X245** - +12 V APC supply for SCR
- X246** - Auto-Guide external harness/engine harness junction
- X247** - Roof harness/electric rear-view mirror harness junction
- X248** - Right and left-hand electric rear-view mirror adjustment switch
- X249** - External rear-view mirror defroster switch
- X250** - Power socket in cab
- X251** - In line fuse (225 A)
- X252** - Automatic air conditioning condenser
- X253** - Air filter vacuum sensor
- X254** - Horn (earth)
- X255** - Horn
- X256** - Roof harness/hand rail harness junction
- X257** - Side light and indicator on hand rail (right and left)
- X258** - Main beam on hand rail (right and left)
- X259** - Hand rail upper work light
- X260** - Hand rail upper work light
- X261** - Front right-hand unit for suspended cab
- X262** - Front left-hand unit for suspended cab
- X263** - Floating stop relay control (US front-end loader)
- X264** - Front linkage suspension switch
- X265** - Rear linkage suspension switch indicator light
- X266** - Rear linkage diagnostic and lifting/lowering LEDs
- X267** - Switch for left-hand side heater
- X268** - Pillar harness connection on fuse box
- X269** - Cab suspension harness/cab transmission harness junction
- X270** - Front accessories connection socket (rotary beacon)
- X271** - Front accessories connection socket (+12 V battery)
- X272** - Front accessories connection socket (+12 V APC)
- X273** - Front accessories connection socket (main beam light)
- X274** - Front accessories connection socket (main beam light)
- X275** - Front accessories connection socket (work light)
- X276** - Earth for front accessory connection socket harness
- X277** - Front linkage lifting/lowering external control
- X278** - Front linkage lifting switch (external)
- X279** - Dual Control or TIC position sensor
- X280** - Front linkage rams pressure sensor
- X281** - Solenoid valve for front PTO
- X282** - Roof harness/cab Auto-Guide harness junction
- X283** - TopDock
- X284** - Headlights module keyboard
- X285** - Ad Blue (urea) metering valve
- X286** - Ad Blue (urea) injection valve
- X287** - Ad Blue (urea) reservoir preheating valve
- X288** - 12/24 V converter for SCR system
- X289** - SCR management module
- X290** - Front accessory connection socket harness/front function harness junction
- X291** - Front accessory connection socket harness/front function harness junction
- X292** - Front windscreen washer pump
- X293** - 540 rpm PTO switch
- X294** - 540 eco rpm PTO switch
- X295** - 1000 rpm PTO switch
- X296** - USB connector
- X297** - PTO/linkage console backlighting
- X298** - Headland mode switch (headland function)
- X299** - Linkage lowering speed potentiometer
- X300** - -
- X301** - PTO stop switch on left-hand fender
- X302** - Switch for pre-selected engine speed A
- X303** - Switch for pre-selected engine speed B
- X304** - Instrument panel harness/armrest harness junction
- X305** - Headlights module (grey connector)
- X306** - Switch for pre-selected engine speed A/B
- X307** - FingerTIP 1
- X308** - FingerTIP 2
- X309** - SV1/SV2 speed regulator switch

- X310** - Divider 1 indicator light and solenoid valve (earth)  
**X311** - Divider 2 indicator light and solenoid valve (+12 V)  
**X312** - SV1/SV2 speed setting potentiometer in armrest  
**X313** - Pedal/lever transmission control mode switch and DTM switch  
**X314** - Hydraulics switch 1, road/field mode  
**X315** - Hydraulics switch 2, road/field mode  
**X316** - Headland mode switch (headland function)  
**X317** - + battery supply for headlights module  
**X318** - Automatic air conditioning compressor  
**X319** - + battery supply for headlights module  
**X320** - + battery supply on headlights module  
**X321** - + battery supply on headlights module  
**X322** - + battery supply on headlights module  
**X323** - + battery supply on headlights module  
**X324** - +12 V APC fuse box connector (battery isolator switch)  
**X325** - Pillar harness / non-Isobus implement connector harness junction  
**X326** - Pillar harness / non-Isobus implement connector harness junction  
**X327** - Battery earth (chassis)  
**X328** - Battery isolator switch earth terminal  
**X329** - Battery isolator switch earth terminal  
**X330** - Battery negative terminal contact (battery isolator switch)  
**X331** - Pillar harness connection on fuse box  
**X332** - + battery (start switch)  
**X333** - Engine harness earth (chassis)  
**X334** - Battery isolator switch earth terminal  
**X335** - Battery isolator switch earth terminal  
**X336** - Battery isolator switch  
**X337** - Pneumatic brake ParkLock solenoid valve  
**X338** - Earth (battery isolator switch)  
**X339** - Pneumatic trailer braking solenoid valve  
**X340** - + terminal on battery for fuse box  
**X341** - Starter supply  
**X342** - Positive battery terminal  
**X343** - RS232 diagnostics connector for Auto-Guide  
**X344** - Isobus connector in cab  
**X345** - Supply for additional terminal (mitron unit)  
**X346** - Auto-Guide switch  
**X347** - Cab transmission harness connection on fuse box  
**X348** - Cab transmission harness connection on fuse box  
**X349** - -  
**X350** - Front right-hand grille work light  
**X351** - Front right-hand grille work light  
**X352** - Front right-hand grille work light  
**X353** - Front left-hand grille work light  
**X354** - Front left-hand grille work light  
**X355** - Front left-hand grille work light  
**X356** - Right-hand main beam and dipped light  
**X357** - Left-hand main beam and dipped light  
**X358** - Outside temperature sensor  
**X359** - Cab suspension harness/cab transmission harness junction  
**X360** - Pillar harness connection on fuse box  
**X361** - Pillar harness connection on fuse box  
**X362** - Fuse box (+12 V battery)  
**X363** - Auto-hitch (Dromone) switch  
**X364** - 120 Ohm resistor for Auto-Guide/Isobus CAN network  
**X365** - Hand rail lower work light  
**X366** - Pneumatic brake harness / transmission harness junction  
**X367** - Switch 1 on joystick  
**X368** - Switch 2 on joystick  
**X369** - Engine speed + switch  
**X370** - Engine speed - switch  
**X371** - Engine speed stop switch  
**X372** - Orbitrol safety solenoid valve  
**X373** - Left-hand 12 V socket (cab) (power)  
**X374** - Left-hand 12 V socket (cab) (backlighting)  
**X375** - Instrument panel harness/cab transmission harness junction  
**X376** - Fuse box (reserve for + APC)  
**X377** - Fuse box (supply for cab suspension compressor)  
**X378** - FNRP lever and button  
**X379** - Front left-hand work light on roof  
**X380** - Front right-hand work light on roof  
**X381** - Front left-hand work light on roof  
**X382** - Front right-hand work light on roof  
**X383** - Front left-hand roof indicator  
**X384** - Front right-hand roof indicator  
**X385** - Rear left-hand work light on roof  
**X386** - Rear right-hand work light on roof  
**X387** - Rear left-hand work light on roof  
**X388** - Rear right-hand work light on roof  
**X389** - Rear left-hand work lights  
**X390** - Rear right-hand work lights  
**X391** - Rear left-hand roof indicator  
**X392** - Rear right-hand roof indicator  
**X393** - Earth  
**X394** - Radio aerial connector  
**X395** - Radio supply  
**X396** - Radio speaker connector  
**X397** - Front left-hand speaker  
**X398** - Front right-hand speaker  
**X399** - Rear left-hand speaker (+ supply)  
**X400** - Rear right-hand speaker (+ supply)  
**X401** - Rear left-hand speaker (- supply)  
**X402** - Rear right-hand speaker (- supply)  
**X403** - Rear windscreen wiper motor  
**X404** - Door switch  
**X405** - Interior light (earth)  
**X406** - Interior light (control)  
**X407** - Interior light (+12 V battery supply)  
**X408** - Right-hand console light  
**X409** - Left-hand rotary beacon  
**X410** - Right-hand rotary beacon  
**X411** - Rear windscreen wiper switch  
**X412** - Radio aerial  
**X413** - Earth (aerial)  
**X414** - Left-hand number plate light  
**X415** - Right-hand number plate light  
**X416** - Radio supply  
**X417** - Radio speaker connector  
**X418** - Earth  
**X419** - Earth  
**X420** - Rotary beacon harness earth (chassis)

**X421** - Earth  
**X422** - Roof harness earth (chassis)  
**X423** - Left-hand side fan ON/OFF switch  
**X424** - Fan speed control knob  
**X425** - Air conditioning switch  
**X426** - Air conditioning indicator light  
**X427** - Manual air conditioning module  
**X428** - Electronic thermostat for heating  
**X429** - Speed 1relay for fan  
**X430** - Speed 2relay for fan  
**X431** - Speed 3relay for fan  
**X432** - Speed 4relay for fan  
**X433** - Left-hand heating resistor  
**X434** - Right-hand fan  
**X435** - Left-hand fan  
**X436** - Left-hand side fan switch  
**X437** - Relay for left-hand side fan  
**X438** - Earth (automatic air conditioning)  
**X439** - Air conditioning control module (blue connector)  
**X440** - Air conditioning control module (yellow connector)  
**X441** - Heating temperature sensor  
**X442** - TT2 sensor  
**X443** - Evaporator temperature sensor  
**X444** - Right-hand fan adapter module (signal)  
**X445** - Left-hand fan adapter module  
**X446** - Right-hand fan adapter module (supply)  
**X447** - Left-hand fan adapter module (supply)  
**X448** - Separation harness for automatic air conditioning  
**X449** - Motor for left-hand heating shutter  
**X450** - Motor for right-hand heating shutter  
**X451** - Motor for heating mixer shutter  
**X452** - Relay for heater pump  
**X453** - Heater accelerator pump  
**X454** - Earth (roof)  
**X455** - Roof harness earth  
**X456** - Solar panel  
**X457** - Earth (Auto-Guide)  
**X458** - Cab transmission harness/pillar harness junction  
**X459** - Linkage lifting switch on fender  
**X460** - Linkage lowering switch on fender  
**X461** - Pillar harness/TECU harness junction  
**X462** - Supply indicator light for power socket on pillar  
**X463** - Earth (Isobus)  
**X464** - Pillar harness/armrest harness junction  
**X465** - Battery positive terminal contact  
**X466** - Active suspended cab Autotronic 5  
**X467** - Right-hand electric rear-view mirror  
**X468** - Left-hand electric rear-view mirror  
**X469** - Additional fan connection  
**X470** - Operator presence in seat switch  
**X471** - Suspended cab harness connection

Identification of harnesses

**FAI200** - Engine harness  
**FAI201** - Front headlights harness  
**FAI202** - Suspended front axle harness  
**FAI203** - Transmission harness  
**FAI204** - Cab/platform linkage external harness  
**FAI205** - Electrohydraulic valves harness  
**FAI206** - Transmission harness — PTO


**FAI207** - Front Dual Control harness  
**FAI208** - Linkage with Dual Control and TIC harness  
**FAI209** - Instrument panel harness  
**FAI210** - Cab transmission harness  
**FAI211** - Cab linkage harness  
**FAI212** - Lighting harness  
**FAI213** - Cab interior lighting harness  
**FAI214** - Armrest harness  
**FAI215** - Pillar harness  
**FAI216** - Diagnostics connector harness  
**FAI217** - Datatronic 3 harness  
**FAI218** - Fieldstar harness  
**FAI219** - Cab interior power socket harness  
**FAI220** - BOC harness — safety switch  
**FAI221** - Automatic air conditioning harness — instrument panel  
**FAI222** - Autotronic 5 ParkLock/suspended front axle harness  
**FAI223** - Roof harness  
**FAI224** - Hand rail lighting harness  
**FAI225** - Electric rear-view mirror harness  
**FAI226** - Roof/external harness  
**FAI227** - Automatic air conditioning harness - roof  
**FAI228** - Number plate lighting harness  
**FAI229** - Xenon light adapter harness  
**FAI230** - GSPTO harness  
**FAI231** - Transmission harness — ParkLock  
**FAI232** - Radio harness  
**FAI235** - Front accessory connection socket harness  
**FAI236** - Start-up harness  
**FAI237** - +12 APC fuse box harness  
**FAI238** - +12 APC instrument panel harness  
**FAI239** - Permanent +12 V supply harness  
**FAI240** - +12 V permanent fuse box harness  
**FAI241** - Automatic air conditioning adapter harness  
**FAI242** - Main beams on hand rail adapter harness  
**FAI243** - Circuit breaker harness  
**FAI244** - Linkage external controls extension harness  
**FAI245** - Left-hand linkage external controls harness  
**FAI246** - Right-hand linkage external controls harness  
**FAI247** - PTO shunt harness  
**FAI248** - Linkage external controls harness  
**FAI249** - Suspended front axle harness  
**FAI250** - Engine harness  
**FAI251** - Parking brake harness  
**FAI252** - +12 V battery harness  
**FAI253** - Hand rail harness  
**FAI254** - Windscreen wiper harness  
**FAI255** - Windscreen wiper harness  
**FAI256** - High-visibility roof heating harness  
**FAI257** - High-visibility roof heating harness  
**FAI258** - Roof earth harness  
**FAI260** - Cooling unit harness  
**FAI261** - Isobus harness  
**FAI262** - Auto-Guide engine harness  
**FAI263** - Auto-Guide cab adapter harness  
**FAI265** - Pneumatic brake harness  
**FAI267** - Console harness  
**FAI268** - Front function harness  
**FAI271** - Cab electric rear-view mirror harness  
**FAI272** - Active suspended cab harness



- FAI273** - Front linkage harness
- FAI274** - Rear right-hand lighting harness
- FAI275** - Trailer connector harness
- FAI276** - Rear left-hand lighting harness
- FAI280** - Negative battery harness
- FAI281** - Negative battery harness
- FAI282** - Negative battery harness
- FAI283** - TopDock harness
- FAIxxx** - Non-Isobus tool connector harness
- FAIxxx** - Non-Isobus implement connector controller harness
- FAIxxx** - Additional fan harness



**B.2 Fuse box supply with circuit breaker**




EFD00112\_6

Fig. 2



**B.3 Autotronic 4 electrical power supply**




EFD00169\_5\_1

Fig. 3



**B.4 Autotronic 5 linkage electrical power supply**




EFD00169\_5\_2

Fig. 4





**B.5 Autotronic 5 ParkLock/suspended front axle electrical power supply**




EFD00169\_5\_3

Fig. 5



**B.6 DCC3 instrument panel electrical power supply**




EFD00169\_5\_4

Fig. 6



**B.7 Autotronic 5 armrest electrical power supply**




EFD00169\_5\_5

Fig. 7



**B.8 Autotronic 5 active suspended cab electrical power supply**



EFD00169\_5\_6

Fig. 8










**B.10 Automatic air-conditioning unit electrical power supply**




EFD00117\_16

Fig. 10



**B.11 Diagnostics connector electrical power supply**




EFD00129\_6

Fig. 11



B.12 Tractor CAN network




EFD00131\_17\_01

Fig. 12





B.13 Engine CAN network




EFD00131\_17\_2

Fig. 13



B.14 Linkage CAN network




EFD00131\_17\_3

Fig. 14



**B.15 Isobus CAN network**




EFD00131\_17\_4

Fig. 15



B.16 Rear power take-off (PTO)



EFD00106\_9

Fig. 16





7A13

## **HA260/Power take-off - Layout of components**

### **TABLE OF CONTENTS**

A. Power take-off (PTO) components - parts list .....	57
B. Rear power take-off components - diagram .....	61



## A. Power take-off (PTO) components - parts list

Ref.	Component description	Location
(A) <sup>(1)</sup>	PTO assembly	At the rear of the rear axle
(B) <sup>(1)</sup>	ON control selector switch	On the armrest in the cab
(C) <sup>(1)</sup>	OFF control selector switch	On the armrest in the cab
(D) <sup>(1)</sup>	Automatic mode selector switch	On the armrest in the cab
(E) <sup>(1)</sup>	PTO speed selector switch	In the cab
(F) <sup>(1)</sup>	PTO external control	Rear fenders
(G) <sup>(1)</sup>	PTO external control	Rear fenders
(H) <sup>(1)</sup>	Solenoid valve unit	On the rear axle
(I) <sup>(1)</sup>	1000 rpm solenoid valve	On the rear axle
(J) <sup>(1)</sup>	750 rpm solenoid valve	On the rear axle
(K) <sup>(1)</sup>	PTO clutch solenoid valve	On the rear axle
(1)	Shim	In front of the PTO clutch
(2)	Roller bearing	In front of the PTO clutch
(3)	Clutch bell housing	PTO top section
(4)	Screw	Under the PTO clutch bell housing
(5)	Shim	In the PTO clutch
(6)	Clutch inner shaft	In the PTO clutch
(8)	Shim	In the PTO clutch
(9)	Spring washer	In the PTO clutch
(10)	Set of discs and backing plates	In the PTO clutch
(11)	Thrust plate	In the PTO clutch
(12)	Disc	In the PTO clutch
(13)	Piston	In the PTO clutch
(14)	Ring	In the PTO clutch
(16)	Seal	In the PTO clutch
(18)	Plate	In the PTO clutch
(19)	Seal	In the PTO clutch
(20)	Shaft	Behind the PTO clutch
(21)	Screw	Behind the PTO clutch
(22)	Lock washer	Behind the PTO clutch
(23)	Socket	Behind the PTO clutch
(25)	Gear	Behind the PTO clutch
(28)	Roller bearing	Behind the PTO clutch
(29)	Nozzle	At the end of the shaft
(31)	Circlip	Behind the PTO clutch
(32)	Seal	Behind the PTO clutch
(35)	Brake disc	Behind the PTO clutch
(36)	Bearing	In front of the PTO clutch
(37)	Ring with square section	In the PTO clutch
(38)	Grub screw	At the end of the shaft
(39)	Nozzle	At the rear of the clutch
(40)	Sensor	On the PTO housing
(42)	Primary shaft	In front of the clutch
(101)	Roller bearing	PTO secondary shaft
(102)	Shim	PTO secondary shaft

Ref.	Component description	Location
(104)	Drive body	PTO secondary shaft
(105)	Roller	PTO secondary shaft
(107)	Circlip	PTO secondary shaft
(108)	Washer	PTO secondary shaft
(109)	Needle roller cage (X2)	PTO secondary shaft
(110)	Spacer	PTO secondary shaft
(112)	Circlip	PTO secondary shaft
(113)	Bearing	PTO secondary shaft
(114)	Circlip	PTO secondary shaft
(115)	Screw	PTO secondary shaft
(116)	Stop	PTO secondary shaft
(118)	Gear (1000 rpm)	PTO secondary shaft
(118a)	Gear (540 or 750 rpm)	PTO secondary shaft
(120)	Shaft	PTO secondary shaft
(121)	Circlip	PTO secondary shaft
(122)	Washer	PTO secondary shaft
(123)	Roller bearing	PTO secondary shaft
(124)	Shim	PTO secondary shaft
(125)	Grub screw	PTO secondary shaft
(126)	Seal	PTO secondary shaft
(127)	Seal	PTO secondary shaft
(128)	Bearing cover	PTO secondary shaft
(129)	Screw	PTO secondary shaft
(132)	Spacer	PTO secondary shaft
(133)	Threaded stud M10-50 - cl 10.9	PTO secondary shaft
(134)	Nut M10-10	PTO secondary shaft
(135)	PTO protection	On PTO output shaft
(137)	Output shaft	PTO lower section
(139)	Sensor	On the bearing cover
(140)	Screw	On the bearing cover
(201)	Actuator plate	Behind the PTO secondary shaft
(202)	Nut	Behind the PTO secondary shaft
(203)	Screw	Behind the PTO secondary shaft
(205)	Screw	Behind the PTO secondary shaft
(206)	Nut	Behind the PTO secondary shaft
(207)	Spacer	Behind the PTO secondary shaft
(210)	Nut	Behind the PTO secondary shaft
(211)	Counter-nut	Behind the PTO secondary shaft
(212)	Washer	Behind the PTO secondary shaft
(213)	Nut	Behind the PTO secondary shaft
(214)	Roller	Behind the PTO secondary shaft
(216)	Screw	Behind the PTO secondary shaft
(217)	Ram	Behind the PTO secondary shaft
(218)	"O" ring	Behind the PTO secondary shaft
(219)	Seal ring	Behind the PTO secondary shaft
(220)	Seal ring	Behind the PTO secondary shaft
(221)	Spring	Behind the PTO secondary shaft
(222)	Piston	Behind the PTO secondary shaft

---

<b>Ref.</b>	<b>Component description</b>	<b>Location</b>
(224)	Piston	Behind the PTO secondary shaft
(225)	Screw	Behind the PTO secondary shaft
(226)	Ram	Behind the PTO secondary shaft

(1) Depending on equipment



**B. Rear power take-off components - diagram**




Fig. 1





7A14

## **HA260/Power take-off - Tests and diagnostics**


### **TABLE OF CONTENTS**

A. Hydraulic tests .....65



## A. Hydraulic tests

### A.1 Supply pressure measurements



1008344

Fig. 1

Measurement points	Reference on component	Description
M1	KV	Cooler upstream pressure
M2	SM	Lubricating pressure
M3	AS	Flushing pressure
M4	ES	Fuel lift pressure
M5	PU	Service pump pressure
M6	P	Transmission system pressure
M7	I	Tortoise range engaging pressure
M8	II	Hare range engaging pressure
M9	PH	High pressure (HP)
M10	PHA	Rear axle and brake system pressure
M22	T	Oil leak on clutch function spool valve / coupler function solenoid valve

Precaution to be taken during the pressure measurements: the oil temperature must be between 35°C and 45°C.

**IMPORTANT:** When measuring the transmission pressure, raise all wheels of the tractor to prevent accidents.

1. Set transmission ratio (hare/tortoise) to speed of 0.
2. Release the hand brake.
3. Engage the front axle.
4. Differential lock and PTO clutch are not engaged.

On right-hand side, in the middle of the tractor:

5. Remove right-hand rear wheel and the protection plate.
6. Connect a pressure gauge. Measure the pressures set out below according to the different engine speeds (see settings table below)
  - PU Pressure (M5). Pressure measuring point located between the service pump and the pressure filter.
  - P Pressure (M6). System pressure downstream of pressure filter.
  - ES charge pressure.
  - AS flushing or discharge pressure.
  - SM transmission lubricating pressure.

**Set values for pressure measurement**

Engine speeds	PU (M5)	P (M6)	ES (M4)	AS (M3)	SM (M2)
800	25 bar ± 2 bar	25 bar ± 2 bar	16 bar ± 2 bar	9 bar ± 2 bar	2 bar ± 0.4 bar
1200	26 bar ± 2 bar	25.5 bar ± 2 bar	19 bar ± 2 bar	11 bar ± 2 bar	3 bar ± 0.5 bar
1600	27 bar ± 2 bar	26 bar ± 2 bar	21 bar ± 2 bar	13 bar ± 2 bar	4.2 bar ± 0.6 bar
2000	28 bar ± 2 bar	27 bar ± 2 bar	24.5 bar ± 3 bar	16 bar ± 2.5 bar	5.5 bar ± 0.8 bar

**A.2 High pressure (HP) measurements**



**DANGER: High pressure measurements must never exceed a maximum of 5 seconds, to prevent the oil from heating.**

Preliminary steps

Engage hare range and set the starting speed to maximum, or transmission to limp home mode (do not turn the control unit by more than 15° in order to avoid heating the oil).

Measurement points	Engine speed	Specified value:
PH (M9)	1600	540 bar + 20 bar

**NOTE:** Load the hydrostatic loop for a maximum of 5 seconds before taking the following measurements.

Measurement points	Engine speed	Specified value
P (M6)	1600	26 bar ± 2 bar
ES (M4)	1600	22 bar ± 2 bar
AS (M3)	1600	15 bar ± 2 bar
SM (M2)	1600	3.5 bar ± 0.4 bar

**NOTE:** If the high pressure PH is not reached, but the AS and ES pressures are correct, check the clutch pressure relief valves 4V4 and 4V5.


### A.3 Shifting pressure measurements

Measurement points	Engine speed	Specified value:
In Hare or Tortoise range (M7/M8)	1600	26 bar $\pm$ 2 bar

**NOTE:** Alternately supply solenoid valves 1 (4V1) and 2 (4V2) with a 12 V (DC) supply

### A.4 Rear PTO, differential lock and front axle clutch solenoid valve measurement

**NOTE:** The unit is located on the rear axle housing, behind the spool valves. Access is limited, so great care must be taken.



1008345


Fig. 2

M10	Rear axle, brakes and front PTO system pressure
M11	Rear PTO clutch
M13	750 rpm PTO selector pressure
M14	Front axle clutch (4WD)
M15	Differential lock
M16	1000 rpm PTO selector pressure
M18	Rear axle lubricating pressure

The pressure connectors can be accessed from the rear of the tractor.

**NOTE:** Run the engine at 1200 rpm. Simultaneously check the pressure at unions M10 and M18 (SM).

Switching status of components that consume electricity	Measurement points	M10 system pressure	M18 lubricating pressure
Power take-off - On / Off	M11	18 bar ± 0.2 bar	2 bar ± 0.3 bar
Differential lock - On/Off	M15	18 bar ± 0.2 bar	2 bar ± 0.3 bar
Front axle (4WD) - On / Off	M14	18 bar ± 0.2 bar	2.1 bar ± 0.3 bar
Activation of locked brake pedal		18 bar ± 0.2 bar	1.2 bar ± 0.3 bar




1008346

Fig. 3

- (1) Rear PTO clutch (M12 - 1.5 union)
- (2) Rear axle lubricating pressure (M10 - 1 union)
- (3 - 4) 750 or 540 speed selection (M10 - 1 union)


In order to check the rear PTO, it is also possible to measure pressure levels at the unions located at the rear right and left-hand sides of the rear axle housing.



1008347

Fig. 4

Diagram showing the pressure connectors on the valve block




1008349

Fig. 5

- (1) Service pump check
- (2) Speed limiting solenoid valve
- (3) PH pressure check
- (4) Clutch function controlled valve
- (5) Supply pressure for Hare/Tortoise range check
- (6) Tortoise range solenoid valve
- (7) Hare range solenoid valve
- (8) Coupler function solenoid valve
- (9) HP Pressure sensor
- (10) HP Pressure sensor



Valve block with test connections



1008350

Fig. 6

- (1) Lubricating pressure check (SM)
- (2) Charge pressure check (ES)
- (3) Service pump relief valve (50 b)
- (4) Charge valve (6.5 b)
- (5) Cooler bypass valve
- (6) Flushing valve (6 b)
- (7) Temperature sensor
- (8) Lubricating pressure valve (6.5 b)
- (9) Flushing pressure check (AS)
- (10) Service pressure check (PU)

**A.5 Checking the hydrostatic loop in the control unit**




**DANGER: Check the tractor (HP pressure measurement).**

1. Remove the right-hand rear wheel and the protection plate located behind it.
2. Remove the T union.
3. Fit a pressure gauge to measure pressures higher than 540 bar at the PH union.

*Checking procedure:*

4. Start the engine.
5. Activate limp home mode by pressing in the clutch pedal fully and pressing the button.



1008341

Fig. 7

6. Apply the hand brake.



1008342


Fig. 8

7. Use the limp home mode lever to start the transmission.

PH	T union	Possible causes
250 bar	No oil flow to the T union	Transmission module error (shuttle valve, pressure pipe union). =>Remove the module.
250 bar	Oil flows from the T union	Coupler function valve (4V4) or clutch function valve (4V5) not tightly sealed. => Change the valve.

*Checking the coupler function valve (4V4)*

8. Mechanically lock the valve.



1008343

Fig. 9

---

<b>PH</b>	<b>T union</b>	<b>Possible causes</b>
250 bar	Oil flows from the T union	Clutch function valve (4V5) not tightly sealed => Change the valve.
540 bar	Oil flows from the T union, but the pressure is not constant	Electrically check the coupler function valve > Change the valve if faulty



7A15

**Section intentionally left blank**

*Section intentionally left blank*

---

7A16

## **HA260/Power take-off - Adjustments, bleeding and calibrations**

### **TABLE OF CONTENTS**

A. Autotronic 4 - Hare/Tortoise range - Transmission - Coupler function - Power take-off .....79





## A. Autotronic 4 - Hare/Tortoise range - Transmission - Coupler function - Power take-off

Calibration of the following Autotronic 4 functions is necessary for optimum performance:

- Hare/Tortoise range
- transmission
- coupler function

Calibration of the power take-off is also possible with special tools if there is a problem when starting.

### Input at level 1 - CAL 1

**IMPORTANT:** In order to carry out a calibration, any error codes must be corrected.

If an error code is active: the calibration returns an error immediately.

To select CAL1:

1. Start the engine.
2. Engage and release the clutch pedal in order to delete the "TC" "DC" display from the screen on the right-hand side of the instrument panel
3. Within the next 5 seconds, simultaneously press keys



on the Dash Control Center keypad.

4. The screen (Fig. 9) appears, displaying the 4 symbols of the functions to be calibrated:



Hare/Tortoise range



Transmission



Coupler function



Power take-off


The selected function is displayed in reverse video.

5. Before starting calibration, ensure that the tractor is in a suitable condition.
6. Select the function to be calibrated using keys



on the Dash Control Center keypad and then press "OK".

**NOTE:** This procedure must be repeated for each calibration.



1007464

Fig. 1

## Hare/Tortoise range

### Calibration procedure

This calibration must be carried out systematically after changing any of the following:


- Hare range solenoid valve
- Tortoise range solenoid valve
- Range position sensor
- Autotronic 4


### Preliminary conditions

1. Hand brake or ParkLock disengaged.
2. Power Control lever in neutral position.
3. Clutch pedal pressed down.
4. Engine speed less than 1000 rpm.

### Calibration



5. Having selected  in the CAL1 screen (Fig. 9), press "OK" to start calibration.
6. The calibration lasts for approximately 6 minutes and takes place in 3 steps, shown one after the other on the screen (Fig. 10):
  - Step 0: Tortoise range
  - Step 1: Hare range
  - Step 2: Neutral (intermediate position)
7. The calibration result is displayed:
  - "OK": successful calibration (since the calibration procedure is ended by placing the transmission in neutral, the Hare/Tortoise symbols flash alternately on the right-hand screen)
  - "ERROR": calibration failed (repair the fault before resuming the procedure)
8. **IMPORTANT:** Switch off the ignition for at least 30 seconds in order to validate the calibration.



1007465

Fig. 2

## Transmission

### Calibration procedure

This calibration must be carried out systematically after changing any of the following:

- transmission control module
- transmission
- transmission high pressure sensor
- Autotronic 4

### Preliminary conditions


Calibration must be carried out just after the range has been calibrated:


1. Hand brake applied or ParkLock engaged.
2. Power Control lever in neutral position.
3. Hare/Tortoise range in neutral (Hare/Tortoise symbols flash alternately on the right-hand screen).

The Hare/Tortoise range should be in neutral because calibration of the range has been carried out in the previous step.

**Calibration**



4. Having selected  in the CAL1 screen (Fig. 9), press "OK" to start calibration.
5. Engine speed automatically adjusts to 1600 rpm.
6. Hare/Tortoise symbols continue to flash alternately.
7. The calibration lasts for approximately 6 seconds and takes place in 7 steps, shown one after the other on the screen (Fig. 11).  
These 7 steps allow calibration of the hydraulic motors and pumps.



1007466

Fig. 3

8. The calibration result is displayed:
  - "OK": successful calibration (Fig. 12)
  - "ERROR": calibration failed (repair the fault before resuming the procedure)
9. **IMPORTANT:** Switch off the ignition for at least 30 seconds in order to validate the calibration.

**Coupler function**

**Calibration procedure**

This calibration must be carried out systematically after changing any of the following:

- coupler function solenoid valve
- transmission oil high pressure sensor
- Autotronic 4

**Preliminary conditions**

1. Transmission temperature higher than or equal to 40°C (recommendation: do not cancel calibration if the value is too low).

There are 2 ways to view the transmission temperature:

- The value can be viewed on the gearbox screen of the diagnostic tool.
- Use the instrument panel DIAG mode via the Dash Control Center:



1007467


Fig. 4

- Press the top arrow for 3 seconds.
- Select DATA (in reverse video) then press "OK".
- The value is indicated by the "Trans Temp" line.

2. Hand brake applied or ParkLock engaged.
3. Power Control lever in neutral position.
4. Hare range engaged.

*Calibration*



5. Having selected  in the CAL1 screen (Fig. 9), press "OK" to start calibration.
6. Engine speed automatically adjusts to 1100 rpm.
7. The calibration lasts for approximately 2 minutes and takes place in 9 steps, shown one after the other on the screen (Fig. 13).  
These 9 steps allow calibration of the solenoid valve current.
8. The calibration result is displayed:
  - "OK": successful calibration
  - "ERROR": calibration failed (repair the fault before resuming the procedure)
9. **IMPORTANT:** Switch off the ignition for at least 30 seconds in order to validate the calibration.

**Power take-off**

*Calibration procedure*


- This calibration must be performed only in the event of a starting problem with a high-inertia implement
- when changing the PTO solenoid valve
- when changing the Autotronic 4


*Preliminary conditions*

1. Hand brake applied or ParkLock engaged.
2. Power Control lever in neutral position.
3. Select a PTO speed (540, 540ECO or 1000 rpm) depending on the implement.

*Calibration*




4. Having selected  in the CAL1 screen (Fig. 9), press "OK" to start calibration.
5. Engage the PTO.



1007468

Fig. 5

6. Calibration takes place automatically, and the time taken depends on the implement (Fig. 14).
7. The calibration result is displayed:
  - "OK": successful calibration
  - "ERROR": calibration failed
8. **IMPORTANT:** Switch off the ignition for at least 30 seconds in order to validate the calibration.



1007469

Fig. 6



7A17

## **HA260/Power take-off - Disassembly and reassembly**

### **TABLE OF CONTENTS**

A. Disassembling the power take-off . . . . .	87
B. Reassembling the power take-off . . . . .	94






## A. Disassembling the power take-off

### Preparation


1. Lower the rear linkage.
2. Drain the transmission oil (65 l).
3. Remove the trailer linkage (depending on equipment).
4. Mark and remove the PTO connectors (arrows).



1008585

Fig. 1

5. Unscrew all retaining nuts.
6. Take the silicone out of the threaded bores and tighten two M12 screws (arrows).
7. Support the cover using a lifting device and push it back using the two screws.




1008586

Fig. 2

8. Take off the rear PTO transmission cover.


**IMPORTANT:** Take care of the adjustment shims (arrow), which are used to adjust the bearing clearance.



1008587

Fig. 3


9. Push back the clutch bell housing (3) using two M10 screws.



1008588

Fig. 4


10. Remove the nozzle (29).



1008589

Fig. 5


- 11.** Fit the compression tool (ref. X899.980.145.000) and compress the clutch.
- 12.** Extract the locking half-rings (30).
- 13.** Release the clutch.
- 14.** Remove the disc carrier and the set of discs (10).



1008590

Fig. 6


- 15.** Remove the adjustment shims (8), the set of Belleville washers (9) and the ring (14).



1008591

Fig. 7


- 16.** Remove the piston (13).



1008592

Fig. 8


**17.** Remove the screw (21) and take off the blade (18).



1008593

Fig. 9


**18.** Take off the circlip (31) and remove the brake disc (20).



1008594

Fig. 10


**19.** Take off the brake disc.



1008595

Fig. 11


- 20.** Extract the bearing (101) using a puller.
- 21.** Remove the washer.



1008596

Fig. 12


- 22.** Unscrew the nuts (210 and 211).
- 23.** Note the values of the nuts (210 and 211) if required.
- 24.** Remove the stops (116).
- 25.** Take out the control mechanism.



1008597

Fig. 13

- 26.** Remove the gears (118) and (118a).




1008598

Fig. 14

**27.** Take out the shaft (35).


**28.** If required, take off the external rings of the bearing.



1008599

Fig. 15


**29.** If necessary, remove the ram (217) and / or (226).



1008600

Fig. 16


**30.** Take off the circlip (107), washer (108) and gears.



1008601

Fig. 17

- 31.** Remove the circlip (112).
- 32.** Release the gear (118).




1008602

Fig. 18

## B. Reassembling the power take-off

**IMPORTANT:** Before reassembly, all components, mating faces and grooves must be clean. Any rust, mud or water must be removed.


1. Fit home the bearing (113) in the gear (118a) and lock with the circlip (114), then fit the gear (118) to its stop.



1008603

Fig. 19

2. Fit the circlip (112) on the opposite side.




1008604

Fig. 20




3. Fit home the internal ring of the bearing (123) on the shaft (120).
4. Position the washer (122).
5. Fit the circlip (121).
6. Smear the two grub screws (125) with threadlock Loc-tite 242 and tighten them until the internal ring of the bearing (123) reaches its stop. The washer (122) must be fitted home.



1008605

Fig. 21

7. Fit the first needle roller cage (109), the spacer (110) and the second needle roller cage (109) on the shaft (120).
8. Fit the shaft (120).
9. Position the washer (108).
10. Fit the circlip (107).




1008607

Fig. 22

11. Fit new seals (219) in the ram (217).
12. Fit a new "O" ring (218) in the groove of the ram (217). Smear the oil tight seals with miscible grease.
13. Insert the piston (222) and spring (221) into the ram (217) as indicated.

**NOTE:** The oil tight seal (219) is comprised of two parts: an "O" ring on the outside and a piston strip guide on the inside.




1008608

Fig. 23

14. Fit new seals (220) in the ram (226).
15. Fit a new "O" ring (218) in the groove of the ram (226).
16. Smear the oil tight seals with miscible grease.
17. Insert the piston (224) and spring (221) as indicated in the ram (226).


**NOTE:** The oil tight seal (219) is comprised of two parts: an "O" ring on the outside and a piston strip guide on the inside.



1008609

Fig. 24


18. Fit the rams (217 and 226).
19. Smear the thread of the screws (216 and 225) with threadlock Loctite 242 and tighten the screws to the corresponding torque:
20. Refit the hydraulic pipes which have been removed in the housing cover (316).



1008610

Fig. 25


21. If the housing is fitted with a new cover (316), screw the nozzle (29) to its stop in the threaded bore.
22. Fit home the external ring of the bearing (36).



1008611

Fig. 26


- 23.** Smear two new rings (37) with miscible grease and install and lock them in the grooves of the shaft (35).
- 24.** Fit home the internal ring of the bearing (36).
- 25.** When assembling a new shaft (35), smear the thread of the threaded stud (38) with threadlock Loctite 242, and screw to its stop.
- 26.** Tighten the nozzle (29) to its stop.



1008612

Fig. 27


- 27.** Fit the pre-assembled shaft (35) in the housing cover (316). If required, fit compensating shims (124) and fit home the external ring of the bearing (123).



1008613

Fig. 28

- 28.** Fit the pair of ring gears and the gear (25).



1008614

Fig. 29

*Pre-assembling the stirrup*

**29.** Smear the thread of the screws (205) with threadlock Loctite 242.

**30.** Fit the spacers (207) and rollers (214).

**31.** Tighten the nuts (206).




Fig. 30

**32.** Insert the rollers (105) into the clutch body (104).

**33.** Smear the thread of the screws (203) with threadlock Loctite 242.

**34.** Fit the stirrup tight to an identical distance, then loosen each screw (203) by 1/6 of a turn and lock them in this position.




Fig. 31

**35.** Screw the nuts (ref. 210, 211 and 213) onto the rods of the pistons (222, 224).

**36.** Fit the washers (212) with their chamfer turned upwards.





Fig. 32


- 37. Fit the pre-assembled stirrup (201).
- 38. Fit the washers (212) with their chamfer turned downwards.
- 39. Unscrew the nuts (210 and 211).



1008618

Fig. 33


- 40. Smear the thread of the screws (224) with threadlock Loctite 242.
  - 41. Fit the stops (116) and lock the screws (224).
- NOTE:** The following must be carried out before setting stirrup travel:



1008619

Fig. 34


- 42. The oblong hole in the stirrup (201) must be turned towards the ram (226).
- 43. Screw and lock the nuts (211, 210) to their stop.



1008620

Fig. 35

- 44. Screw a locally made M12 eye nut onto the piston rod of the ram (217). Using a lifting tool, pull hard on the piston rod. (Coupling at 750 or 540 rpm).
- 45. Check the clearance of the clutch body (104). Specified value: 0.1 mm to 0.2 mm clearance.



1008621

Fig. 36

*If outside the specified clearance:*


- 46. Adjust with M12 nuts (top and bottom) until a clearance of 0.1 mm to 0.2 mm is obtained.



1008622

Fig. 37


- 47.** Take off the lifting tool and unscrew the M12 eye nut.



1008623

Fig. 38

- 48.** Push the piston rod of the ram (226) fully in using a clamp, until the nuts (213) reach their stop. (Lifting limit, 1000 rpm position).
- 49.** Check the clearance of the clutch body (104).  
Specified value: 0.1 mm to 0.2 mm clearance.




1008624

Fig. 39

*If outside the specified clearance:*

**50.** Adjust the nuts (213) until a clearance of 0.1 mm to 0.2 mm is obtained.



1008625

Fig. 40


**51.** Take off the clamp.

**52.** The coupling shifts to "Neutral" position.

**53.** The 750 or 540 and 1000 rpm ring gears should be able to turn freely.

**54.** The upward and downward free travel of the coupling should be identical.

**55.** If not, readjust the coupling.




1008626

Fig. 41

**56.** Fit the shim (102).

**57.** Fit the internal ring of the bearing (101) up against the shaft (120).




1008627

Fig. 42




- 58.** Fit the gear (25).
- 59.** Smear a new "O" ring with miscible grease and fit it in the groove of the shaft (35).
- 60.** Check the brake disc (20) for wear. If necessary, fit a new brake disc (20).



1008628

Fig. 43


- 61.** Fit the circlip (31).
- 62.** Smear a new lip seal (19) with miscible grease and fit it in the brake disc groove, with the seal lips turned towards the oil chamber.



1008629

Fig. 44

- 63.** Fit the blade (18).
- 64.** Smear the thread of the screw (21) with threadlock Loctite 242, and fit the lock washer (22) and socket (23).
- 65.** Tighten the screw.



1008630

Fig. 45

- 66.** Smear a new lip seal (16) with miscible grease and fit it in the inner groove of the piston, with the seal lips turned towards the oil chamber.




1008631

Fig. 46

- 67.** Fit the pre-assembled piston (13).

- 68.** Fit the ring (14).



1008632

Fig. 47

- 69.** Fit 5 Belleville washers (9), with the large external diameters facing each other, and the compensating shims (8).

**NOTE:** The external diameter of the first Belleville washer (9) should be turned towards the ring (14) of the piston (13). If required, for example if compensating shims (8) are lost, set the preload of the Belleville washer set (9).




1008633

Fig. 48

*Setting the preload of the Belleville washer set*


- 70.** Remove the shim (5) from the internal disc carrier (6).
- 71.** Smear the thread of the screw (4) with threadlock Loctite 242 and tighten it.



1008634

Fig. 49

- 72.** Fit the pre-assembled disc carrier (6).
- 73.** Measure and note the distance between the disc carrier (6) and the end of the shaft (35). Example: 23.2 mm.



1008635

Fig. 50

- 74.** Fit the compression tool (ref. X 899.980.145) and compress the set of Belleville washers (9).
- 75.** Fit the locking half-rings (30).
- 76.** If the locking half-rings (30) are chamfered on just one side, the chamfered side must face the disc carrier (6).
- 77.** Remove the compression tool (ref. X 899.980.145.000)



1008636

Fig. 51


**78.** Measure and note the distance between the disc carrier (6) and the end of the shaft (35). Example: 25.8 mm.

If the washer set gives compensating clearance of approximately 2.5 mm when completely compressed, the preload is correct.

**79.** If not, correct it with compensating shims.

**Installing the set of discs (10) on the disc carrier (6)**

For references, see the "General" section in the "Rear power take-off" chapter.




1008637

Fig. 52

**80.** Start with an external blade.

**81.** Next alternate with an internal blade (11). Each internal blade (11) should be fitted according to the narrow slot (pos. 2) while the wide slot (pos. 3) should be positioned alternately on either side.


**NOTE:** Total number of discs: seven external discs (12) and six internal discs (11).



1008638

Fig. 53

**82.** Fit the disc carrier (6) together with the set of Belleville washers (9).



1008639

Fig. 54

- 83.** Fit the compression tool (ref. X 899.980.145.000).
- 84.** Compress the clutch.
- 85.** Fit the locking half-rings (30). If the locking half-rings are chamfered on just one side, the chamfered side must face the disc carrier (6).


**NOTE:** If the disc carrier (6) does not fit into place, fit it without the set of discs (10) and mark the teeth.



1008640

Fig. 55


- 86.** Push the set of discs home, ensuring it is correctly centred.
- 87.** Measure the distance (uncoupling clearance) using shims. Specified values: 1.75 mm to 3.50 mm clearance.
- 88.** If the minimum distance of 1.75 mm is not obtained, the discs are warped.
- 89.** Fit a new set of discs (10).



1008641

Fig. 56

- 90.** Smear the thread of the nozzle (29) with threadlock Loctite 242.
- 91.** Tighten the nozzle (29) to a torque of:



1008642

Fig. 57

**92.** If necessary, fit the bearing (28) to its stop with its closed part facing upwards into the interior of the clutch bell housing (3).



1008643

Fig. 58


**93.** Fit the bearing (2) up against the clutch bell housing (3).



1008644

Fig. 59

**94.** Adjust the position of the external discs (12) and fit the clutch bell housing (3) to its stop.



1008645

Fig. 60


- 95. Fit compensating shims (1) on the bearing (2).
- 96. Measure and note the distance between the mating faces. For example: 178.6 mm.



1008646

Fig. 61

- 97. The distance between the flange face and the mating face of the journal is written in white on the top part of the rear axle housing. Example: 178.71.
- 98. The distance between the journal of the bearing (2) and the flange face of the housing cover should be less than 0.1 mm to 0.2 mm, as the written value indicates.  
This means that the journal clearance must be 0.1 mm to 0.2 mm.
- 99. If not, correct it with compensating shims (1).




1008647

Fig. 62

- 100. The distance between the flange face and the mating face of the journal of the lower shaft is written in white on the lower part of the rear axle housing. Example: 148.75.


**NOTE:** This value is not necessary in case of repair, because a dial gauge must be used to measure the bearing clearance. Check the bearing clearance of the lower shaft (120).



1008648

Fig. 63

- 101.**Fit the compensating shims (1) in the upper bore.
- 102.**Smear four new "O" rings with miscible grease and fit them at the position of the oil pressure pipes (arrows).



1008649

Fig. 64


- 103.**Clean the housing mating face.
- 104.**Check the two centring pins are fitted correctly (arrows).
- 105.**Smear the mating face with Loctite 549.



1008650

Fig. 65

- 106.**Carefully raise the housing cover and fit it on the rear axle housing.




1008587

Fig. 66



**107.**Tighten the M18 screws and nuts to a torque of:

If necessary:



1008651

Fig. 67

**108.**Smear the outside of a new shaft sealing ring (126) with a thin layer of sealing product and, with the seal lips turned towards the oil chamber, insert it into the cover (128) until it comes to a gentle stop. Depth approximately 5 mm.

**109.**Fill the lip seals 2/3 full with miscible grease.




1008652

Fig. 68

**110.**Fit the corresponding compensating shims (124).

**111.**Smear new "O" rings (127) with miscible grease and fit them in the groove of the cover (128).

**112.**Smear the thread of the screws (129) with threadlock Loctite 242 and tighten them.



1008653

Fig. 69

**113.** Rotate the shaft (120) ten times.

**114.** Fit a dial gauge.

**115.** Push in the shaft (120) once and note clearance value J2.



1008654

Fig. 70


**116.** Rotate the shaft (120) ten times.

**117.** Fit a dial gauge.

**118.** Pull once on the shaft (120) and note clearance value J1.

$$\text{Total clearance } J = J1 + J2$$

$$0.02 \text{ mm} < J < 0.07 \text{ mm}$$



1008655

Fig. 71

**119.** If not, correct it with compensating shims (124).



1008656

Fig. 72

**120.** PTO end-fitting with 6 x 1 3/8" splines

Also compatible:

- PTO end-fitting with 21 x 1 3/8" splines
- PTO end-fitting with 6 x 1 3/4" splines
- PTO end-fitting with 20 x 1 3/4" splines

**NOTE:** The PTO end-fitting has 4 drive holes for the PTO sensor (arrow).




1008657

Fig. 73

**121.** Fit the end-fitting (137).

**122.** Fit the spacer (132).

**123.** Top up the transmission oil level (see Operator Instruction Book).



1008658

Fig. 74

**124.** Lock the end-fitting (137) with an M16 screw (arrow) (for easier assembly).

**125.** Tighten the nuts (134) (M0-10) to a torque of:

**126.** Top up the transmission oil level (see Operator Instruction Book).



1008659

Fig. 75



7A18

## **HA260/Power take-off - Service tools**

### **TABLE OF CONTENTS**

A. General .....	117
B. HA260/Power take-off - Service tools .....	118



---

## **A. General**

---

The tools described in this section can be ordered from the AGCO spare parts department or by contacting the tooling division of Beauvais by referring to AGCOnet bulletin Trac 60/07.


The prices will then be sent out to you.

---

**B. HA260/Power take-off - Service tools**

---

Ref.	X899.980.145.000
Description	Securing system for rear power take-off (PTO) clutch
Order	Parts Division



1009420

Fig. 1



7B10

## Zuidberg front power take-off - General

### TABLE OF CONTENTS

A. General .....	121
B. Principles of operation .....	122
C. Schematic diagrams .....	125



---

## A. General


---

### Description

The power take-off unit (1) (Fig. 1) comprises a housing, which serves as the oil tank.

The housing contains the following parts:

- the power take-off drive gears
- a multidisc clutch
- a gear pump to ensure clutch engagement and gear lubrication
- a solenoid valve for engaging the clutch
- an oil filter
- a pressure relief valve for the clutch system
- a pressure relief valve for the cooling system




1010381

Fig. 1

## B. Principles of operation

### Mechanical


The front power take-off is driven from the front pulley of the engine via a shaft (2) fitted with two shock absorbers (3) (Fig. 2).



1010385

Fig. 2


The power take-off clutch is controlled by a solenoid valve (4) .



1010382

Fig. 3

Power take-off clockwise




1010383

Fig. 4

Reduction is obtained by a series of straight-cut gears. The reduction comprises 3 or 4 gears, depending on the type of power take-off (clockwise or anti-clockwise). The driving gear (5) drives the clutch (7) via one or two layshaft gears (6).


Power take-off anti-clockwise



1010384

Fig. 5

**Hydraulics**



1010386

Fig. 6

The power take-off clutch (7) is a wet multidisc type. It drives a hydraulic gear pump (8), which provides the pressure for engaging the clutch, lubricating the system and cooling.


The front power take-off hydraulic system is self-contained. The clutch unit (8) drives the pump gears (11) via the gear (10). The system pressure is limited by a valve (12) set to 20 bar. The cooling system (14) is protected by a valve (13) set to 6 bar. The solenoid valve (4) directs the pressure to the clutch or the tank.

**NOTE:** The pump flow is around 4 l/min.

---

## **C. Schematic diagrams**

---



1010492

Fig. 7



- 1..... Housing
- 2..... Shaft
- 5..... Input gear
- 6..... Idler gear
- 7..... Clutch
- 8..... Hydraulic system



7B11

**Section intentionally left blank**

**TABLE OF CONTENTS**

*Section intentionally left blank*

---

7B12

# Zuidberg front power take-off - Diagrams and plans

## TABLE OF CONTENTS

A. Plans .....	133
B. Hydraulic diagrams .....	139
C. Electrical diagrams.....	140




---

**A. Plans**

---

Blown-up view of the PTO unit




1010409

Fig. 1




Blown-up view of the hydraulic pump and the PTO clutch



1010410

Fig. 2

Blown-up view of the drive shaft and the oil cooler



1010412


Fig. 3

---

1.....	Housing
2.....	Shaft
3.....	Shock absorber
4.....	Solenoid valve
5.....	Input gear
6.....	Idler gear
7.....	Clutch
8.....	Hydraulic system
9.....	Filter
10.....	Gear
11.....	Gear pump
12.....	Valve 20 bar
13.....	5 bar valve
14.....	Cooler
15.....	Seal
16.....	Seal ring
17.....	Plug
18.....	"O" ring
19.....	Plug
20.....	Plug
21.....	Screw
22.....	Plug
23.....	Screw
24.....	Screw
25.....	Plug
26.....	Seal ring
27.....	Seal
28.....	Screw
29.....	Bearing
30.....	Bearing
31.....	Pin
32.....	Centring pin
33.....	Shim
34.....	Bearing
35.....	Circlip
36.....	Ring
37.....	Washer
38.....	Spring washer
39.....	Screw
40.....	"O" ring
41.....	"O" ring
42.....	Connecting pipe
43.....	Breather
44.....	Key
45.....	Hub
46.....	Screw
47.....	Screw
48.....	Hub
49.....	Screw
50.....	Screw
51.....	Spacer
52.....	Support
53.....	Output shaft
54.....	Circlip
55.....	Bearing
56.....	Circlip
57.....	Shim
58.....	Bearing
59.....	Bearing
60.....	Thrust plate
61.....	Seal
62.....	Bearing
63.....	Circlip

64.....	Piston
65.....	"O" ring
66.....	Cylinder
67.....	Centring pin
68.....	Spring
69.....	"O" ring
70.....	Disc
71.....	Thrust plate
72.....	Centring pin
73.....	Spring

**B. Hydraulic diagrams**



1010387

Fig. 4

- 1..... Housing
- 4..... Solenoid valve
- 5..... Input gear
- 6..... Idler gear
- 7..... Clutch
- 9..... Filter
- 11..... Gear pump
- 12..... 20 bar valve
- 13..... 5 bar valve
- 14..... Cooler

---

## C. Electrical diagrams

---

### C.1 Identification of electrical connectors and harnesses

Identification of electrical connectors

- X1** - Auxiliary hydraulic oil temperature sensor
- X2** - Auxiliary hydraulic oil filter blockage switch
- X3** - 540 rpm PTO speed solenoid valve
- X4** - 1000 rpm PTO speed solenoid valve
- X5** - 4WD solenoid valve
- X6** - Differential lock solenoid valve
- X7** - Rear PTO solenoid valve
- X8** - Bevel gear theoretical speed sensor
- X9** - Transmission oil high pressure sensor 1
- X10** - Collecting shaft speed sensor
- X11** - Solenoid valve limiting speed to 30 kph
- X12** - Coupler function solenoid valve
- X13** - Hare range solenoid valve
- X14** - Tortoise range solenoid valve
- X15** - PTO clutch speed sensor
- X16** - PTO shaft speed sensor
- X17** - Hare/Tortoise range position sensor
- X18** - Transmission control module
- X19** - Transmission hydraulic oil temperature sensor
- X20** - Transmission filter blockage switch
- X21** - ParkLock brake pressure sensor
- X22** - Radar
- X23** - Steering pressure sensor
- X24** - Auxiliary hydraulic oil gauge
- X25** - Engine speed sensor
- X26** - Pneumatic brake solenoid valve
- X27** - Rear linkage lifting solenoid valve
- X28** - Rear linkage lowering solenoid valve
- X29** - Dual Control socket connector
- X30** - Rear linkage position sensor
- X31** - Rear linkage right-hand draft sensor
- X32** - Rear linkage left-hand draft sensor
- X33** - Transmission harness CAN junction
- X34** - Transmission oil high pressure sensor 2
- X35** - ParkLock hydraulic system pressure sensor
- X36** - LS signal breaker solenoid valve
- X37** - ParkLock pressure reversing solenoid valve
- X38** - Trailer braking proportional solenoid valve
- X39** - Trailer braking safety solenoid valve
- X40** - Front linkage single/double acting function solenoid valve
- X41** - Divider solenoid valve 1
- X42** - Divider solenoid valve 2
- X43** - Auto-hitch lifting solenoid valve
- X44** - Auto-hitch lowering solenoid valve
- X45** - Bleed for pneumatic suspended cab front and rear systems
- X46** - Rear left-hand ram position sensor for cab suspension
- X47** - Rear right-hand unit for suspended cab
- X48** - Rear left-hand unit for suspended cab
- X49** - Suspended cab rear lowering solenoid valve
- X50** - Suspended cab front lowering solenoid valve
- X51** - Transmission harness earth (chassis)

- X52** - Engine harness/transmission harness junction
- X53** - Cab transmission harness/transmission harness junction
- X54** - Suspended cab lifting solenoid valve
- X55** - Instrument panel
- X56** - Power Control lever
- X57** - DOT Matrix keyboard
- X58** - Windscreen wiper and indicator control unit
- X59** - DOT Matrix keyboard connection on instrument panel
- X60** - Engine harness/instrument panel harness junction
- X61** - Cab transmission harness/engine harness junction
- X62** - Instrument panel harness/cab transmission harness junction
- X63** - Instrument panel harness connection on fuse box
- X64** - Instrument panel harness connection on fuse box
- X65** - Front windscreen wiper motor
- X66** - Left-hand brake pedal sensor
- X67** - Right-hand brake pedal sensor
- X68** - Clutch pedal sensor
- X69** - Cab interior temperature sensor
- X70** - Solar radiation sensor
- X71** - Throttle pedal sensor
- X72** - ParkLock switch on Power Control lever
- X73** - Buzzer Control
- X74** - Buzzer Supply (+12 V APC)
- X75** - Pillar harness/right-hand fender harness junction
- X76** - Rear right-hand indicator
- X77** - Rear right-hand side light and stop light
- X78** - Work light on rear right-hand fender
- X79** - -
- X80** - -
- X81** - -
- X82** - -
- X83** - -
- X84** - -
- X85** - -
- X86** - -
- X87** - Linkage lifting/lowering switch on right-hand fender
- X88** - Rear right-hand NA indicator extension
- X89** - Earth (chassis)
- X90** - Pillar harness/left-hand fender harness junction
- X91** - Rear left-hand indicator
- X92** - Rear left-hand side light and stop light
- X93** - Work light on rear left-hand fender
- X94** - PTO ON/OFF switch on left-hand fender
- X95** - PTO Stop switch on left-hand fender
- X96** - Hydraulic spool valve switch on left-hand fender
- X97** - Linkage lifting/lowering switch on left-hand fender
- X98** - Rear left-hand NA indicator extension
- X99** - PTO and linkage console harness/cab transmission harness junction
- X100** - Instrument panel harness earth (chassis)
- X101** - Instrument panel harness/electric rear-view mirror harness junction
- X102** - Right-hand fender lighting harness/trailer connector harness junction
- X103** - Armrest harness/cab transmission harness junction
- X104** - Armrest Autotronic 5
- X105** - Datatronic CCD

- X106** - Transmission lever in armrest
- X107** - Headland mode switch (headland function)
- X108** - FingerTIP 3
- X109** - FingerTIP 4
- X110** - FingerTIP 5
- X111** - DTM dynamic transmission mode switch
- X112** - Joystick
- X113** - Armrest 6-button keyboard
- X114** - Supply on fuse box for 3rd spool valve
- X115** - Supply on fuse box for 4th spool valve
- X116** - +12 V battery supply (for lighting module)
- X117** - Isobus +12 V battery power socket
- X118** - Automatic PTO switch
- X119** - Rear linkage lifting/lowering switch
- X120** - Datatronic CCD navigation keyboard
- X121** - Rear linkage height/depth adjustment thumb wheel
- X122** - Hand throttle
- X123** - Hare/Tortoise range shift switch
- X124** - Pedal/lever mode switch
- X125** - SV1 speed setting potentiometer
- X126** - SV2 speed setting potentiometer
- X127** - Front PTO ON/OFF switch
- X128** - Rear PTO ON/OFF switch
- X129** - Fuse box +12 V battery connection
- X130** - FingerTIP 6 front linkage function
- X131** - Front linkage suspension solenoid valve
- X132** - Instrument panel harness/armrest harness junction
- X133** - Console harness/cab transmission harness junction
- X134** - Console harness/pillar harness junction
- X135** - Braking pressure sensor
- X136** - Differential lock switch
- X137** - 4WD switch
- X138** - Hazard warning lights indicator light and switch
- X139** - Suspended front axle switch
- X140** - Suspended front axle setting potentiometer
- X141** - Suspended cab switch
- X142** - Suspended cab setting potentiometer
- X143** - Variable steering switch (fast steering)
- X144** - Variable steering setting potentiometer (fast steering)
- X145** - PTO/linkage console
- X146** - Rear linkage suspension switch
- X147** - Roof harness/pillar harness junction
- X148** - Roof harness/pillar harness junction
- X149** - Headlights module (black connector)
- X150** - Pillar harness/cab power socket harness junction
- X151** - Pillar harness/cab power socket harness junction
- X152** - Start switch
- X153** - Non-Isobus implement connector
- X154** - Suspended front axle lifting solenoid valve
- X155** - Cigarette lighter socket (power)
- X156** - Cigarette lighter socket (backlighting)
- X157** - Left-hand side +12 V socket (power)
- X158** - Left-hand side +12 V socket (backlighting)
- X159** - Suspended front axle lowering solenoid valve
- X160** - Console harness earth (chassis)
- X161** - Solenoid valve 1 for suspended front axle suspension



- X162** - Pillar harness connection on fuse box
- X163** - Solenoid valve 2 for suspended front axle suspension
- X164** - Pillar harness/cab transmission harness junction
- X165** - Automatic air conditioning harness/pillar harness junction
- X166** - Suspended front axle position sensor
- X167** - +12 V APC fuse box connection
- X168** - Pneumatic brake system pressure sensor
- X169** - Power socket control switch (in cab)
- X170** - Pillar harness connection on fuse box
- X171** - Cab transmission harness connection on fuse box
- X172** - Cab transmission harness connection on fuse box
- X173** - Cab transmission harness earth
- X174** - Autotronic 4 transmission controller
- X175** - Emergency control switch
- X176** - Earth (Autotronic 4 transmission controller)
- X177** - Autotronic 5 Linkage
- X178** - ParkLock/suspended front axle/passive suspended cab Autotronic 5
- X179** - Main lighting, sidelight/dipped light activation switch
- X180** - Front windscreen washer pump
- X181** - Front linkage single acting / double acting function switch
- X182** - Linkage external lifting switch
- X183** - Diagnostics connector (tractor-Isobus CAN)
- X184** - Diagnostics connector (engine-valve CAN)
- X185** - Sisu EEM unit
- X186** - Starter
- X187** - Engine start relay
- X188** - Engine identification module (ID module)
- X189** - Fuel lift pump
- X190** - Vistronic fan
- X191** - Diesel fuel preheater
- X192** - B + alternator 1
- X193** - B + alternator 2
- X194** - D + alternator 1
- X195** - D + alternator 2
- X196** - In line fuse (225 A)
- X197** - Diesel fuel gauge
- X198** - Pneumatic trailer brake sensor
- X199** - Work light on left-hand step
- X200** - Work light on right-hand step
- X201** - Engine harness earth
- X202** - Front accessory connection socket harness/front function harness junction
- X203** - Engine harness/front headlights harness junction
- X204** - Cooling unit harness/engine harness junction
- X205** - Front axle harness/engine harness junction
- X206** - Sensor detecting water in the diesel fuel
- X207** - Pneumatic seat adjustment control
- X208** - Front linkage suspension switch LED
- X209** - Rear linkage external lowering switch
- X210** - Orbitrol steering sensor (SASA sensor)
- X211** - Rear Dual Control connector
- X212** - Instrument panel harness/armrest harness junction
- X213** - Power socket for additional heating
- X214** - Armrest harness/cab transmission harness junction

- X215** - Trailer connector (right-hand side light and number plate lights)
- X216** - Reversing light
- X217** - Isobus CAN connector
- X218** - External Isobus tool connector
- X219** - Cab Isobus harness/external Isobus harness junction
- X220** - Trailer connector (left-hand side light)
- X221** - Trailer connector (right-hand indicator)
- X222** - Trailer connector (left-hand indicator)
- X223** - Trailer connector (brake lights)
- X224** - Trailer connector (earth)
- X225** - Trailer connector (reversing light)
- X226** - Trailer connector harness earth
- X227** - Console harness/cab transmission harness junction
- X228** - Front linkage single/double-acting function LED
- X229** - 120 Ohm CAN 1 resistor (cab transmission harness)
- X230** - 120 Ohm CAN 2 resistor (cab transmission harness)
- X231** - 120 Ohm CAN 3 resistor (cab transmission harness)
- X232** - 120 Ohm CAN 4 resistor (cab transmission harness)
- X233** - Cab transmission harness/Isobus harness junction
- X234** - 120 Ohm CAN ATC resistor
- X235** - Front axle steering sensor (WAS sensor)
- X236** - Electrohydraulic Orbitrol (grey connector)
- X237** - Electrohydraulic Orbitrol (black connector)
- X238** - Connector 1 for valve harness
- X239** - Connector 2 for valve harness
- X240** - 120 Ohm resistor for electrohydraulic spool valves
- X241** - Sisu engine preheating supply (Grid Heater)
- X242** - Exhaust temperature sensor
- X243** - AdBlue/DEF reservoir (urea) level gauge and temperature sensor
- X244** - CAN SCR harness
- X245** - +12 V APC supply for SCR
- X246** - Auto-Guide external harness/engine harness junction
- X247** - Roof harness/electric rear-view mirror harness junction
- X248** - Right and left-hand electric rear-view mirror adjustment switch
- X249** - External rear-view mirror defroster switch
- X250** - Power socket in cab
- X251** - In line fuse (225 A)
- X252** - Automatic air conditioning condenser
- X253** - Air filter vacuum sensor
- X254** - Horn (earth)
- X255** - Horn
- X256** - Roof harness/hand rail harness junction
- X257** - Side light and indicator on hand rail (right and left)
- X258** - Main beam on hand rail (right and left)
- X259** - Hand rail upper work light
- X260** - Hand rail upper work light
- X261** - Front right-hand unit for suspended cab
- X262** - Front left-hand unit for suspended cab
- X263** - Floating stop relay control (US front-end loader)

- X264** - Front linkage suspension switch
- X265** - Rear linkage suspension switch indicator light
- X266** - Rear linkage diagnostic and lifting/lowering LEDs
- X267** - Switch for left-hand side heater
- X268** - Pillar harness connection on fuse box
- X269** - Cab suspension harness/cab transmission harness junction
- X270** - Front accessories connection socket (rotary beacon)
- X271** - Front accessories connection socket (+12 V battery)
- X272** - Front accessories connection socket (+12 V APC)
- X273** - Front accessories connection socket (main beam light)
- X274** - Front accessories connection socket (main beam light)
- X275** - Front accessories connection socket (work light)
- X276** - Earth for front accessory connection socket harness
- X277** - Front linkage lifting/lowering external control
- X278** - Front linkage lifting switch (external)
- X279** - Dual Control or TIC position sensor
- X280** - Front linkage rams pressure sensor
- X281** - Solenoid valve for front PTO
- X282** - Roof harness/cab Auto-Guide harness junction
- X283** - TopDock
- X284** - Headlights module keyboard
- X285** - Ad Blue (urea) metering valve
- X286** - Ad Blue (urea) injection valve
- X287** - Ad Blue (urea) reservoir preheating valve
- X288** - 12/24 V converter for SCR system
- X289** - SCR management module
- X290** - Front accessory connection socket harness/front function harness junction
- X291** - Front accessory connection socket harness/front function harness junction
- X292** - Front windscreen washer pump
- X293** - 540 rpm PTO switch
- X294** - 540 eco rpm PTO switch
- X295** - 1000 rpm PTO switch
- X296** - USB connector
- X297** - PTO/linkage console backlighting
- X298** - Headland mode switch (headland function)
- X299** - Linkage lowering speed potentiometer
- X300** - -
- X301** - PTO stop switch on left-hand fender
- X302** - Switch for pre-selected engine speed A
- X303** - Switch for pre-selected engine speed B
- X304** - Instrument panel harness/armrest harness junction
- X305** - Headlights module (grey connector)
- X306** - Switch for pre-selected engine speed A/B
- X307** - FingerTIP 1
- X308** - FingerTIP 2
- X309** - SV1/SV2 speed regulator switch
- X310** - Divider 1 indicator light and solenoid valve (earth)
- X311** - Divider 2 indicator light and solenoid valve (+12 V)
- X312** - SV1/SV2 speed setting potentiometer in armrest
- X313** - Pedal/lever transmission control mode switch and DTM switch
- X314** - Hydraulics switch 1, road/field mode

- X315** - Hydraulics switch 2, road/field mode
- X316** - Headland mode switch (headland function)
- X317** - + battery supply for headlights module
- X318** - Automatic air conditioning compressor
- X319** - + battery supply for headlights module
- X320** - + battery supply on headlights module
- X321** - + battery supply on headlights module
- X322** - + battery supply on headlights module
- X323** - + battery supply on headlights module
- X324** - +12 V APC fuse box connector (battery isolator switch)
- X325** - Pillar harness / non-Isobus implement connector harness junction
- X326** - Pillar harness / non-Isobus implement connector harness junction
- X327** - Battery earth (chassis)
- X328** - Battery isolator switch earth terminal
- X329** - Battery isolator switch earth terminal
- X330** - Battery negative terminal contact (battery isolator switch)
- X331** - Pillar harness connection on fuse box
- X332** - + battery (start switch)
- X333** - Engine harness earth (chassis)
- X334** - Battery isolator switch earth terminal
- X335** - Battery isolator switch earth terminal
- X336** - Battery isolator switch
- X337** - Pneumatic brake ParkLock solenoid valve
- X338** - Earth (battery isolator switch)
- X339** - Pneumatic trailer braking solenoid valve
- X340** - + terminal on battery for fuse box
- X341** - Starter supply
- X342** - Positive battery terminal
- X343** - RS232 diagnostics connector for Auto-Guide
- X344** - Isobus connector in cab
- X345** - Supply for additional terminal (mitron unit)
- X346** - Auto-Guide switch
- X347** - Cab transmission harness connection on fuse box
- X348** - Cab transmission harness connection on fuse box
- X349** - -
- X350** - Front right-hand grille work light
- X351** - Front right-hand grille work light
- X352** - Front right-hand grille work light
- X353** - Front left-hand grille work light
- X354** - Front left-hand grille work light
- X355** - Front left-hand grille work light
- X356** - Right-hand main beam and dipped light
- X357** - Left-hand main beam and dipped light
- X358** - Outside temperature sensor
- X359** - Cab suspension harness/cab transmission harness junction
- X360** - Pillar harness connection on fuse box
- X361** - Pillar harness connection on fuse box
- X362** - Fuse box (+12 V battery)
- X363** - Auto-hitch (Dromone) switch
- X364** - 120 Ohm resistor for Auto-Guide/Isobus CAN network
- X365** - Hand rail lower work light
- X366** - Pneumatic brake harness / transmission harness junction
- X367** - Switch 1 on joystick
- X368** - Switch 2 on joystick

- X369** - Engine speed + switch
- X370** - Engine speed - switch
- X371** - Engine speed stop switch
- X372** - Orbitrol safety solenoid valve
- X373** - Left-hand 12 V socket (cab) (power)
- X374** - Left-hand 12 V socket (cab) (backlighting)
- X375** - Instrument panel harness/cab transmission harness junction
- X376** - Fuse box (reserve for + APC)
- X377** - Fuse box (supply for cab suspension compressor)
- X378** - FNRP lever and button
- X379** - Front left-hand work light on roof
- X380** - Front right-hand work light on roof
- X381** - Front left-hand work light on roof
- X382** - Front right-hand work light on roof
- X383** - Front left-hand roof indicator
- X384** - Front right-hand roof indicator
- X385** - Rear left-hand work light on roof
- X386** - Rear right-hand work light on roof
- X387** - Rear left-hand work light on roof
- X388** - Rear right-hand work light on roof
- X389** - Rear left-hand work lights
- X390** - Rear right-hand work lights
- X391** - Rear left-hand roof indicator
- X392** - Rear right-hand roof indicator
- X393** - Earth
- X394** - Radio aerial connector
- X395** - Radio supply
- X396** - Radio speaker connector
- X397** - Front left-hand speaker
- X398** - Front right-hand speaker
- X399** - Rear left-hand speaker (+ supply)
- X400** - Rear right-hand speaker (+ supply)
- X401** - Rear left-hand speaker (- supply)
- X402** - Rear right-hand speaker (- supply)
- X403** - Rear windscreen wiper motor
- X404** - Door switch
- X405** - Interior light (earth)
- X406** - Interior light (control)
- X407** - Interior light (+12 V battery supply)
- X408** - Right-hand console light
- X409** - Left-hand rotary beacon
- X410** - Right-hand rotary beacon
- X411** - Rear windscreen wiper switch
- X412** - Radio aerial
- X413** - Earth (aerial)
- X414** - Left-hand number plate light
- X415** - Right-hand number plate light
- X416** - Radio supply
- X417** - Radio speaker connector
- X418** - Earth
- X419** - Earth
- X420** - Rotary beacon harness earth (chassis)
- X421** - Earth
- X422** - Roof harness earth (chassis)
- X423** - Left-hand side fan ON/OFF switch
- X424** - Fan speed control knob
- X425** - Air conditioning switch
- X426** - Air conditioning indicator light
- X427** - Manual air conditioning module
- X428** - Electronic thermostat for heating

- X429** - Speed 1relay for fan
- X430** - Speed 2relay for fan
- X431** - Speed 3relay for fan
- X432** - Speed 4relay for fan
- X433** - Left-hand heating resistor
- X434** - Right-hand fan
- X435** - Left-hand fan
- X436** - Left-hand side fan switch
- X437** - Relay for left-hand side fan
- X438** - Earth (automatic air conditioning)
- X439** - Air conditioning control module (blue connector)
- X440** - Air conditioning control module (yellow connector)
- X441** - Heating temperature sensor
- X442** - TT2 sensor
- X443** - Evaporator temperature sensor
- X444** - Right-hand fan adapter module (signal)
- X445** - Left-hand fan adapter module
- X446** - Right-hand fan adapter module (supply)
- X447** - Left-hand fan adapter module (supply)
- X448** - Separation harness for automatic air conditioning
- X449** - Motor for left-hand heating shutter
- X450** - Motor for right-hand heating shutter
- X451** - Motor for heating mixer shutter
- X452** - Relay for heater pump
- X453** - Heater accelerator pump
- X454** - Earth (roof)
- X455** - Roof harness earth
- X456** - Solar panel
- X457** - Earth (Auto-Guide)
- X458** - Cab transmission harness/pillar harness junction
- X459** - Linkage lifting switch on fender
- X460** - Linkage lowering switch on fender
- X461** - Pillar harness/TECU harness junction
- X462** - Supply indicator light for power socket on pillar
- X463** - Earth (Isobus)
- X464** - Pillar harness/armrest harness junction
- X465** - Battery positive terminal contact
- X466** - Active suspended cab Autotronic 5
- X467** - Right-hand electric rear-view mirror
- X468** - Left-hand electric rear-view mirror
- X469** - Additional fan connection
- X470** - Operator presence in seat switch
- X471** - Suspended cab harness connection

Identification of harnesses

- FAI200** - Engine harness
- FAI201** - Front headlights harness
- FAI202** - Suspended front axle harness
- FAI203** - Transmission harness
- FAI204** - Cab/platform linkage external harness
- FAI205** - Electrohydraulic valves harness
- FAI206** - Transmission harness — PTO
- FAI207** - Front Dual Control harness
- FAI208** - Linkage with Dual Control and TIC harness
- FAI209** - Instrument panel harness
- FAI210** - Cab transmission harness
- FAI211** - Cab linkage harness
- FAI212** - Lighting harness
- FAI213** - Cab interior lighting harness
- FAI214** - Armrest harness

- FAI215** - Pillar harness
- FAI216** - Diagnostics connector harness
- FAI217** - Datatronic 3 harness
- FAI218** - Fieldstar harness
- FAI219** - Cab interior power socket harness
- FAI220** - BOC harness — safety switch
- FAI221** - Automatic air conditioning harness — instrument panel
- FAI222** - Autotronic 5 ParkLock/suspended front axle harness
- FAI223** - Roof harness
- FAI224** - Hand rail lighting harness
- FAI225** - Electric rear-view mirror harness
- FAI226** - Roof/external harness
- FAI227** - Automatic air conditioning harness - roof
- FAI228** - Number plate lighting harness
- FAI229** - Xenon light adapter harness
- FAI230** - GSPTO harness
- FAI231** - Transmission harness — ParkLock
- FAI232** - Radio harness
- FAI235** - Front accessory connection socket harness
- FAI236** - Start-up harness
- FAI237** - +12 APC fuse box harness
- FAI238** - +12 APC instrument panel harness
- FAI239** - Permanent +12 V supply harness
- FAI240** - +12 V permanent fuse box harness
- FAI241** - Automatic air conditioning adapter harness
- FAI242** - Main beams on hand rail adapter harness
- FAI243** - Circuit breaker harness
- FAI244** - Linkage external controls extension harness
- FAI245** - Left-hand linkage external controls harness
- FAI246** - Right-hand linkage external controls harness
- FAI247** - PTO shunt harness
- FAI248** - Linkage external controls harness
- FAI249** - Suspended front axle harness
- FAI250** - Engine harness
- FAI251** - Parking brake harness
- FAI252** - +12 V battery harness
- FAI253** - Hand rail harness
- FAI254** - Windscreen wiper harness
- FAI255** - Windscreen wiper harness
- FAI256** - High-visibility roof heating harness
- FAI257** - High-visibility roof heating harness
- FAI258** - Roof earth harness
- FAI260** - Cooling unit harness
- FAI261** - Isobus harness
- FAI262** - Auto-Guide engine harness
- FAI263** - Auto-Guide cab adapter harness
- FAI265** - Pneumatic brake harness
- FAI267** - Console harness
- FAI268** - Front function harness
- FAI271** - Cab electric rear-view mirror harness
- FAI272** - Active suspended cab harness
- FAI273** - Front linkage harness
- FAI274** - Rear right-hand lighting harness
- FAI275** - Trailer connector harness
- FAI276** - Rear left-hand lighting harness
- FAI280** - Negative battery harness
- FAI281** - Negative battery harness
- FAI282** - Negative battery harness
- FAI283** - TopDock harness


**FAIxxx** - Non-Isobus tool connector harness

**FAIxxx** - Non-Isobus implement connector controller harness

**FAIxxx** - Additional fan harness



C.2 Fuse box supply with circuit breaker




EFD00112\_6

Fig. 5



C.3 Autotronic 4 electrical power supply




EFD00169\_5\_1

Fig. 6



C.4 Autotronic 5 linkage electrical power supply




EFD00169\_5\_2

Fig. 7



C.5 Autotronic 5 ParkLock/suspended front axle electrical power supply




EFD00169\_5\_3

Fig. 8





C.6 DCC3 instrument panel electrical power supply




EFD00169\_5\_4

Fig. 9



C.7 Autotronic 5 armrest electrical power supply




EFD00169\_5\_5

Fig. 10



C.8 Autotronic 5 active suspended cab electrical power supply




EFD00169\_5\_6

Fig. 11



C.9 Sisu EEM electronic unit electrical power supply




EFD00151\_13

Fig. 12





C.10 Automatic air-conditioning unit electrical power supply




EFD00117\_16

Fig. 13



C.11 Diagnostics connector electrical power supply




EFD00129\_6

Fig. 14



C.12 Tractor CAN network




EFD00131\_17\_01

Fig. 15



C.13 Engine CAN network




EFD00131\_17\_2

Fig. 16





C.14 Linkage CAN network



EFD00131\_17\_3


Fig. 17







C.16 Front power take-off



EFD000107\_6

Fig. 19



7B13

## **Zuidberg front power take-off - Layout of components**

### **TABLE OF CONTENTS**

A. Location of the Zuidberg front power take-off components .....	183
---	-----






---

**A. Location of the Zuidberg front  
power take-off components**

---

Location of the front power take-off components



1010568

Fig. 1

- 1..... Housing
- 2..... Shaft
- 3..... Shock absorber
- 5..... Input gear
- 6..... Idler gear
- 7..... Clutch
- 8..... Hydraulic system
- 14..... Cooler
- 52..... Support
- 53..... Output shaft
- A ..... Front PTO engagement  
switch
- B ..... Front PTO indicator light



7B14

# Zuidberg front power take-off - Tests and diagnostics

## TABLE OF CONTENTS

A. Hydraulic tests .....	189
B. Electrical tests .....	190



## A. Hydraulic tests

- C Clutch pressure connector
- P Pump pressure connector

### Clutch pressure test

Using a pressure gauge (30 bar (435.12 lbf/in minimum)) and a suitable union (M10x1), check the pressure of the PTO clutch according to the following values:


PTO disengaged	0 bar
PTO engaged	22 bar ± 1 bar

### Pump pressure test

Using a pressure gauge (30 bar (435.12 lbf/in minimum)) and a suitable union (M10x1), check the pressure of the pump delivery:

PTO disengaged and engaged	24 bar ± 1 bar
----------------------------	----------------

Pressure connectors



1010563

Fig. 1

---

## B. Electrical tests


---

### Checking the solenoid valve

Using a multimeter, check the resistance at the solenoid valve terminals:

Resistance	5.3 to 5.6 Ohms
------------	-----------------

Checking the solenoid valve



1010563

Fig. 2



7B15

**Section intentionally left blank**

**TABLE OF CONTENTS**



7B16

# **Zuidberg front power take-off - Adjustments, bleeding and calibrations**

## **TABLE OF CONTENTS**

A. Adjustments and bleeding ..... 195



## A. Adjustments and bleeding

### Draining and changing the filter

#### Draining


- 1) To drain the PTO, remove the two screws (1).
- 2) Remove the oil cooler (4) in order to drain it.

#### Changing the filter


- 3) To change or clean the filter, remove the circlip and the screw securing the plug (2). Remove the filter to clean (at each draining) or replace it. Carry out the operations in reverse order to refit.

#### Filling

- 4) Refit the oil cooler (4) then fill it with oil (approximate capacity 0,5 l).
- 5) To top up the oil, remove the plug (3). The level should be flush with the port.
- 6) Start up and allow the engine to run for several minutes to bleed the cooling system.
- 7) Check the oil level at the plug (3). Top up if necessary.



007960



1011313

Fig. 1



7B17

## **Zuidberg front power take-off - Disassembly and reassembly**

### **TABLE OF CONTENTS**

A. Removing and refitting the front PTO .....	199
B. Removing and refitting the front PTO shaft. ....	208
C. Disassembling and reassembling the front PTO .....	212





---

## **A. Removing and refitting the front PTO**


---

### **Removing the front PTO**



**Removing the front PTO**


- 1) Drain the front PTO housing.
- 2) Disconnect the hoses from the auxiliary oil cooler.  
Block the ports using suitable plugs.
- 3) Disconnect the oil cooler hoses from the power take-off.  
Block the ports using suitable plugs.
- 4) Remove the coolers.
- 5) Support the radiators using a locally made tool (L-shaped iron fitting with a 8 mm to 400 mm diameter hole in the edge).
- 6) Remove the support rams from the radiators.



1010619

Fig. 2


- 7) Remove the retaining screws from the cooler support plate and then remove the support plate.



1010620

Fig. 3


8) Mark and disconnect the front PTO/linkage harness.



1010621

Fig. 4

9) Mark and disconnect the hydraulic unions from the linkage rams.



1010622

Fig. 5

10) Remove the screws of the shock absorber (3) on the PTO.



1010623

Fig. 6

- 11) Remove the covers from the front couplers and the coupler screws.



1010632

Fig. 7

- 12) Sling the PTO/front linkage assembly.



1010641

Fig. 8


- 13) Remove the nuts (A) and the screws (B).  
14) Remove the PTO/front linkage assembly.



1010637

Fig. 9

- 15) Remove the screws (C) and then separate the PTO unit from the front linkage structure.




1010644

Fig. 10

### Refitting the front PTO

- 16) Position blocks under the PTO unit (approx. 150 mm).



1010665

Fig. 11

- 17) In order to align the PTO on the front linkage, place the threaded rods and M16 nuts on the front linkage structure.  
Sling the front linkage using the same method as for removal.



1010676

Fig. 12

- 18) Place the front linkage above the PTO.  
Using the threaded rods, centre and bring together the unit and the front linkage.



1010677

Fig. 13


- 19) Refit the PTO/front linkage assembly. Tighten the screws (A) to 700 Nm and the screws (B) to 560 Nm.



1010678

Fig. 14


- 20) Fit the screws of the shock absorber (3) onto the PTO.  
Tighten the screws to 220 Nm.



1010644

Fig. 15

21) Refit the coupler screws. Tighten the screws to 30 Nm. Refit the front coupler covers.



1010632

Fig. 16

22) Connect the linkage ram hydraulic unions.



1010641

Fig. 17

23) Connect the front PTO/linkage harness.




1010623

Fig. 18




24) Refit the cooler support plate.



1010622

Fig. 19


25) Refit the coolers and their hoses.



1010621

Fig. 20

26) Fill the front PTO with oil.



1010619


Fig. 21

---

## **B. Removing and refitting the front PTO shaft**

---

### **Removing the front PTO shaft**



1010412

Fig. 22

1) Remove the front PTO [Removing the front PTO](#).

- 2) Remove the engine fan cowling screws.
- 3) Disconnect the fan harness and remove the harness support.
- 4) Protect the radiator with cardboard.
- 5) Remove the fan attachment screws.



1010682

Fig. 23

- 6) Fit the fan up against the radiator in order to remove the fan cowling.
- 7) Remove the fan.
- 8) Remove the radiator mounting flanges from each side of the radiator.



1010683

Fig. 24

- 9) Using a jack and suitable wedges, lift the engine radiator by approx. 50 mm.



1010684

Fig. 25

- 10) Remove the screws from the shock absorber (3) on the engine side.
- 11) Remove the PTO shaft.




1010685

Fig. 26

### Refitting the front PTO shaft

- 12) Carry out the removal steps in reverse order.  
Tighten the shock absorber screws on the engine side to 147 Nm.
- 13) Refit the front PTO [Refitting the front PTO](#)



1010686

Fig. 27


---

## **C. Disassembling and reassembling the front PTO**

---

### **Disassembling the front PTO**


Blown-up view of the PTO unit



1010409

Fig. 28

Blown-up view of the hydraulic pump and the PTO clutch



1010410

Fig. 29




**NOTE:** The PTO shown may differ slightly from the disassembled model. However, the procedure is identical.

**Disassembling the front PTO**

- 1) Remove the front PTO [Removing the front PTO](#).
- 2) Place the PTO unit (1) on a workbench.
- 3) On the rear face, remove the two pump attachment screws.
- 4) Gently tap on the rear of the pump (8) to release it and then take it out through the front.

**NOTE:** Do not leave the seals (40) and (41) in the PTO housing once the pump has been removed.


- 5) Remove the screws (28) from the half-housings. Separate the housing into two.



1010688

Fig. 30


- 6) Place the rear section of the housing on a workbench.
- 7) Using two screwdrivers, prise loose and remove the complete clutch (7).
- 8) Recover the connecting pipe (42) with the seal and the spring.



1010689

Fig. 31


- 9) Place the clutch (7) on a press with the output shaft facing downwards. Using a shim, compress the clutch by pressing on the shaft (53).
- 10) Using two screwdrivers, prise loose and remove the bearing (62).



1010690

Fig. 32

- 11) Check the bearing face of the connecting pipe (42) on the shaft (53). If the surface is worn excessively, the shaft must be replaced.
- 12) Using a press and a locally made tool, slightly compress the piston (64) and remove the circlip (63).
- 13) Remove the complete cylinder (66).



1010691

Fig. 33

- 14) Remove the discs (70) and the backing plates (71).
- 15) Using a press, separate the output shaft (53) from the clutch unit. Recover the bearing (58).
- 16) Remove the piston (64) from the cylinder (66). Check the condition of the centring pins (52).
- 17) Check the parts. Check the condition of the wear points, replace the defective parts and all the seals.



1010692


Fig. 34

**Reassembling the front PTO**

- 18) Carefully clean the parts that will be refitted.
- 19) Place the output shaft (53) in the clutch unit with the bearings (55) and (59) and the circlip (56).
- 20) Place the discs (70) and the backing plates (71) alternately in the clutch unit.
- 21) Position the pins (67) and their springs (68).

**IMPORTANT:** The pins have a rounded side which should be fitted facing upwards.

- 22) Position the springs (73).




1010694

Fig. 35

- 23) Position the cylinder and piston assembly (64) (66) on the clutch unit. Compress the piston slightly using a press and a locally made tool. Position the circlip (63).
- 24) Check the clutch operation with compressed air.
- 25) Using a press, fit the bearings (58) and (62) onto the clutch.

**NOTE:** Do not forget the washer (57) underneath the bearing (58).




1010697

Fig. 36

- 26) Fit the seal rings (16) and (26) of the input and output shafts onto each half-housing.
- 27) Check that the three ball bearings under the thrust plate (60) are present. The thrust plate must rotate freely.

**NOTE:** The thrust plate (60) allows the output shaft to turn to provide assistance in hitching implements.


- 28) Check the fitting of the screws (39) securing the thrust plate (60). The screws are fitted with a spring washer (38) and a large washer (37). Tighten the screws to 5 Nm.
- 29) Position the connecting pipe (42) with a new seal. Check that it slides properly in the housing.



1010702

Fig. 37

- 30) Lubricate the mating face of the housing (1) to support the seal (15).
- 31) Position the clutch (7) and the input gear (5). Position the idler gear(s) (6) (according to model).




1010703

Fig. 38

- 32) Position the upper half-housing. Secure the two sections using a hammer.
- 33) Fit the screws (28) and tighten to 42 Nm.

**NOTE:** Replace the sealing washers on the drain holes.

- 34) On the pump unit (8), position the new "O" rings (40) and (41) using grease to keep them in place.
- 35) Fit the pump (8) in the housing (1), keeping an eye on the "O" rings. Refit the two pump attachment screws.
- 36) Refit the PTO to the tractor.



1010704

Fig. 39





7B18

## **Zuidberg front power take-off - Service tools**

### **TABLE OF CONTENTS**

