


Converter C2000



SPICER OFF-HIGHWAY COMPONENTS



FOREWORD

This manual has been prepared to provide the customer and the maintenance personnel with information and instructions on the maintenance and repair of the **CLARK** Torque Converter.

Extreme care has been exercised in the design, selection of materials and manufacturing of these units. The slight outlay in personal attention and cost required to provide regular and proper lubrication, inspection at stated intervals, and such adjustments as may be indicated will be reimbursed many times in low cost operation and trouble free service.

In order to become familiar with the various parts of the torque converter, its principal of operation, trouble shooting and adjustments, it is urged that the mechanic study the instructions in this manual carefully and use it as a reference when performing maintenance and repair operations.

Whenever repair or replacement of component parts is required, only Clark Components International approved parts as listed in the applicable parts manual should be used. Use of "will-fit" or non-approved parts may endanger proper operation and performance of the equipment. Clark Components International does not warrant repair or replacement parts, nor failures resulting from the use there of, which are not supplied by or approved by Clark Components International. **IMPORTANT: Always furnish the Distributor with the Converter serial and model number when ordering parts.**

TABLE OF CONTENTS

HOW THE UNITS OPERATE	3
SECTIONAL VIEWS AND PARTS IDENTIFICATION	
Torque Converter Assembly (Cross Section)	Fig. A
Internal Oil Flow	Fig. B
Torque Converter Assembly – Exploded View	Fig. C
Assembly Instructions	Fig. D
Assembly Instructions	Fig. E
DISASSEMBLY OF TORQUE CONVERTER	9
CLEANING AND INSPECTION	17
REASSEMBLY OF TORQUE CONVERTER	18
PRESSURE AND LUBRICATION SPECIFICATIONS	27
IRREGULARITIES IN PERFORMANCE	28
CONVERTER TO ENGINE INSTALLATION	30

NOTE: Metric Dimensions Shown in Brackets [].

HOW THE UNITS OPERATE

The torque converter portion of the power train enacts an important role in delivering engine power to the driving wheels. In order to properly maintain and service these units it is important to first understand their function and how they operate.

The torque converter and transmission function together and operate through a common hydraulic system. To obtain maximum serviceability they have been designed and built as separate units. It is necessary, however, to consider both units in the study of their function and operation.

To supplement the text herein, and for reference use therewith, the following illustrations are provided.

Torque Converter Assembly -Cross Section	Fig. A
Internal Oil Flow -Torque Converter	Fig. B
Torque Converter Assembly -Exploded View	Fig. C
Assembly Instructions	Fig. D

The torque converter is composed of four members: The impeller which is the driving member, the drive disc or impeller cover; the turbine, which is the driven member and the reaction member. The reaction member option is splined to the converter support and does not rotate in either direction or can be free wheeling, depending on the application. The impeller and drive disc form the outer shell. The turbine runs within the outer shell and is connected to the output shaft. The oil is the only connection between the turbine and impeller member.

Three pump drive gears are bearing mounted in the converter housing and meshed with a gear on the impeller hub. With the engine running the pump drive gears rotate at engine speed. The pumps are externally mounted on the converter housing and are connected to the pump shafts by a pump drive sleeve.

With the engine running, the converter charging pump draws oil from the transmission sump and directs it through oil filters to the pressure regulating valve located on top of the converter. From the regulating valve it is then directed to the transmission clutches and into the converter.

The pressure regulating valve remains closed until required pressure is delivered to the transmission for actuating the direction and speed clutches. This regulator valve consists of a hardened valve spool operating in a closely fitted bore. The valve spool is backed up by a spring to hold the valve spool against its seat until the oil pressure overrides the spring force. The valve spool moves toward the spring until a port is exposed in the side of the bore. The oil can flow through this port into a distributor which directs the oil through a passage into the converter.

After entering the converter, the oil is directed into the converter support through the impeller bearing and to the converter cavity.

Three members of the torque converter are composed of a series of blades. The blades are curved in such a manner as to force the oil to circulate from the impeller to the turbine, through the reaction member and again into the impeller. This circulation causes the turbine to turn in the same direction as the impeller. Oil enters the inner diameter of the impeller and exits from the outer diameter into the outer diameter of the turbine, then exits from the inner diameter of the turbine and through the reaction member. The oil again enters the inner diameter of the impeller.

The oil exits between the turbine shaft and reaction member support and through an oil distributor which directs the oil out of the converter, and to the oil cooler. After leaving the cooler the oil is directed to the lubricating oil inlet on the transmission and through a series of tubes to the transmission bearings, and clutches. The oil is internally returned to the transmission sump.

The converter lube and leakage oil is returned to the transmission sump by a flexible hose installed in the lowest pipe tap hole in the converter housing. This line must have a continuous drop to allow by gravity flow, leakage oil to return to the transmission sump.

A safety valve is built in the pressure regulating valve and will open to bypass oil only if an excessive pressure is built up due to a blocked passage.

With the engine operating at any speed and the turbine and output shafts stationary, the converter is in a "stall" condition. Full power or wide open throttle "stalls" for more than 30 seconds at a time will generate excessive heat and may cause converter or transmission seal damage.





FIGURE A
TORQUE CONVERTER ASSEMBLY -CROSS SECTION







FIGURE C

(Items 102 thru 133 are various options)

C-2000 CONVERTER WITH OFFSET OUTPUT

ITEM	DESCRIPTION	QTY.	ITEM	DESCRIPTION	QTY.
1	Pump Gear Snap Ring	3	51	Output Bearing Retainer Stud	2
2	Pump Drive Gear	3	52	Output Bearing Retainer "O" Ring	1
3	Breather	1	53	Output Shaft Rear Bearing	1
4	Name Plate	1	54	Rear Bearing Retainer Ring	1
5	Name Plate Screw	2	55	Output Shaft	1
6	Pressure Regulating Valve to Housing Gasket	1	56	Output Shaft Gear	1
7	Valve to Housing "O" Ring	1	57	Output Shaft Front Bearing	1
8	Safety Valve Spring	1	58	Front Bearing Retainer Ring	1
9	Safety Valve Plunger	1	59	Converter Out Pressure Port	1
10	Safety Valve Seat	1	60	Converter Housing	1
11	Pressure Port Pipe Plugs	2	61	Oil Baffle "O" Ring	1
12	Valve Stop "O" Ring	1	62	Oil Baffle	1
13	Valve Stop	1	63	Oil Baffle Oil Seal	1
14	Roll Pin	1	64	Impeller Hub "O" Ring	1
15	Regulating Valve to Housing Screw Lockwasher	4	65	Impeller Hub Gear	1
16	Regulating Valve to Housing Screw	4	66	Impeller Hub Gear Bearing	1
17	Regulating Valve Assembly	1	67	Support Oil Sealing Ring	1
18	Roll Pin	1	68	Sealing Ring Expander Spring	1
19	Regulating Valve Spring (Outer)	1	69	Support Screw	6
20	Regulating Valve Spring (Inner)	1	70	Support Screw Lockwasher	6
21	Regulating Valve Piston	1	71	Reaction Member Support	1
22	Valve Stop "O" Ring	1	72	Turbine Shaft Oil Sealing Ring	1
23	Valve Stop	1	73	Turbine Shaft	1
24	Pump Drive Front Bearing	3	74	Turbine Shaft Bearing	1
25	Pump Shaft Spacer	3	75	Bearing Retainer Ring	1
26	Pump Drive Rear Bearing	3	76	Turbine Shaft Gear	1
27	Rear Bearing Locating Ring	3	77	Gear Retainer Ring	1
28	Pump Drive Shaft	3	78	Impeller	1
29	Rear Bearing Retainer Ring	3	79	Impeller to Hub Screw Lock Tab	4
30	Pump Shaft Retaining Washer	3	80	Impeller to Hub Screw	8
31	Pump Shaft Retaining Ring	3	81	Reaction Member Spacer	1
32	Pump Drive Sleeve Assembly	1	82	Reaction Member	1
33	Pump Gasket	1	83	Reaction Member Retainer Ring	1
34	Charging Pump	1	84	Turbine Locating Ring	1
35	Pump Mounting Screw	3	85	Turbine	1
36	Pump Mounting Screw Lockwasher	3	86	Turbine Hub Bearing Locating Ring	1
37	Pipe Plug	3	87	Turbine Hub Bearing	1
38	Converter "Out" Temperature Port	1	88	Bearing Retainer Washer	1
39	Oil Baffle Screw Lockwasher	3	89	Impeller Cover "O" Ring	1
40	Oil Baffle Screw	3	90	Impeller Cover	1
41	Output Shaft Oil Seal	1	91	Turbine Retaining Ring	1
42	Output Bearing Retainer Lockwasher	3	92	Bore Plug "O" Ring	1
43	Output Bearing Retainer Screw	3	93	Impeller Cover Bore Plug	1
44	Output Flange Nut	1	94	Bore Plug Retaining Ring	1
45	Output Flange Washer	1	95	Flexplate Assembly	1
46	Flange Washer "O" Ring	1	96	Flexplate	1
47	Output Flange	1	97	Flexplate Mounting Screw	10
48	Bearing Retainer Stud Nut	2	98	Flexplate Mounting Screw Lockwasher	10
49	Bearing Retainer Stud Nut Lockwasher	2	99	Backing Ring	1
50	Output Bearing Retainer	1	100	Impeller Cover to Impeller Screw	24
			101	Impeller Cover to Impeller Screw Lockwasher	24



OVERHAUL INSTRUCTIONS FOR TORQUE CONVERTER

The following instructions will cover the disassembly and reassembly of the torque converter in a sequence that would normally be followed after the unit is removed from the machine and is to be completely overhauled.

CAUTION: Cleanliness is of extreme importance and an absolute must in the repair and overhaul of this unit. Before attempting any repairs, the exterior of the unit must be thoroughly cleaned to prevent the possibility of dirt and foreign matter entering the mechanism.

DISASSEMBLY OF THE TORQUE CONVERTER




Figure 1
Remove flexplate mounting screws and washers.




Figure 3
Remove impeller cover bore plug retainer ring.




Figure 2
Remove flexplate and backing ring.




Figure 4
Using two small screw drivers as shown, remove bore plug.




Figure 5
Through bore plug hole, remove turbine retaining ring. See Figure 6.




Figure 8
Remove impeller cover and bearing assembly. Remove turbine.




Figure 6




Figure 9
Remove turbine locating ring.




Figure 7
Remove impeller cover to impeller bolts.







Figure 10
Remove reaction member retainer ring.

**Figure 11**


Remove reaction member and spacer. If reaction member is free wheeling remove as an assembly. (See Fig. 42 for freewheel disassembly).

**Figure 14**


Loosen oil baffle bolts (qty. 3). Tap lightly on each bolt. This will loosen oil baffle from converter housing.

**Figure 12**

Straighten corner of impeller to hub screw lock tabs. Remove impeller hub bolts and lock tabs.

**Figure 15**

When baffle is loose remove baffle bolts. Remove oil baffle from housing.

**Figure 13**

Remove impeller.

**Figure 16**

Remove impeller hub from housing.




Figure 17
Remove charging pump to converter housing bolts.




Figure 20
Remove adaptors.




Figure 18
Remove charging pump.



Figure 21
Remove pump shaft retaining ring.



Figure 19
Remove accessory pump drive adaptor bolts.



Figure 22
Remove pump shaft retaining washer.




Figure 23
Remove pump drive gear retainer ring.




Figure 26
Using an impact wrench (if available) remove output flange nut. If impact wrench is not available a flange retainer bar must be used to hold flange from turning while removing flange nut.



Figure 24
Tap on pump shaft. Remove pump drive gear.




Figure 27
Remove flange nut, washer, "O" ring and flange from output shaft.



Figure 25
From rear of housing remove pump drive shaft and bearing assembly.



Figure 28
Remove output shaft bearing retainer bolts, stud nuts and washers.




Figure 29
From front of housing drive output shaft assembly from converter housing.



Figure 32
Remove support and turbine shaft assembly. **NOTE:** If converter housing has a bore plug in the rear center line, remove plug. Remove turbine shaft gear retainer ring. Remove support and turbine shaft assembly. Turbine shaft gear will remain in rear of housing. This is a special ratio gear and is larger than the support bore.




Figure 30
Output shaft, gear and bearing pressed from bearing retainer.




Figure 33
Remove turbine shaft gear retainer ring and gear. See note above.




Figure 31
Remove reaction member support bolts.



Figure 34
Remove turbine shaft bearing retainer ring from support.




Figure 35
Remove turbine shaft and bearing from support.



Figure 38
If support bearing is to be removed procedure shown with split puller is recommended.



Figure 36
Remove turbine shaft oil sealing ring.




Figure 39
Remove pressure regulating valve to housing screws and lockwashers.




Figure 37
Remove support oil sealing ring and sealing ring expander spring.



Figure 40
Remove pressure regulating valve, safety valve plunger and spring.




Figure 41

If pressure regulating is to be disassembled, compress valve spring stop. Tap roll pin from valve housing. **CAUTION:** Spring stop is under spring pressure. Remove spring stop, inner and outer spring and valve piston.




Figure 43

Remove freewheel assembly from the reaction member. **NOTE:** The freewheel assembly cannot be serviced. If the freewheel is damaged it must be replaced as an assembly.

FREEWHEEL DISASSEMBLY



Figure 42

If either the reaction member or the freewheel assembly is to be replaced remove the front outer race to reaction member retainer ring.

CLEANING AND INSPECTION

CLEANING

Clean all parts thoroughly using solvent type cleaning fluid. It is recommended that parts be immersed in cleaning fluid and moved up and down slowly until all old lubricant and foreign material is dissolved and parts are thoroughly cleaned.

CAUTION: Care should be exercised to avoid skin rashes, fire hazards and inhalation of vapors when using solvent type cleaners.

Bearings

Remove bearings from cleaning fluid and strike larger side of cone flat against a block of wood to dislodge solidified particles of lubricant. Immerse again in cleaning fluid to flush out particles. Repeat above operation until bearings are thoroughly clean. Dry bearings using moisture-free compressed air. Be careful to direct air stream across bearing to avoid spinning. Do not spin bearings when drying. Bearings may be rotated slowly by hand to facilitate drying process.

Freewheel Assembly

Clean the complete freewheel assembly the same as cleaning bearings. NOTE: Do not disassemble free wheel assembly-If freewheel assembly is damaged it must be replaced with a complete assembly. After cleaning and drying freewheel assembly dip complete assembly in automatic transmission fluid and wrap in a clean lintless cloth or paper to protect until assembled.

Housings

Clean interior and exterior of housings, bearing caps, etc" thoroughly. Cast parts may be cleaned in hot solution tanks with mild alkali solutions providing these parts do not have ground or polished surfaces. Parts should remain in solution long enough to be thoroughly cleaned and heated. This will aid the evaporation of the cleaning solution and rinse water. Parts cleaned in solution tanks must be thoroughly rinsed with clean water to remove all traces of alkali. Cast parts may also be cleaned with steam cleaner.

CAUTION: Care should be exercised to avoid skin rashes and inhalation of vapors when using alkali cleaners.

Thoroughly dry all parts cleaned immediately by using moisture-free compressed air or soft, lintless absorbent wiping rags free of abrasive materials such as metal filings, contaminated oil or lapping compound.

INSPECTION

The importance of careful and thorough inspection of all parts cannot be overstressed. Replacement of all parts showing indication of wear or stress will eliminate costly and avoidable failures at a later date.

Bearings

Carefully inspect all rollers, cages and cups for wear, chipping or nicks to determine fitness of bearings for further use. Do not replace a bearing cone or cup individually without replacing the mating cup or cone at the same time. After inspection, dip bearings in clean light oil and wrap in clean lintless cloth or paper to protect them until installed.

Oil Seals, Gaskets, Etc.


Replacement of spring load oil seals, " 0 " Rings, metal sealing rings, gaskets and snap rings is more economical when unit is disassembled then premature overhaul to replace these parts at a future time. Further loss of lubricant through a worn seal may result in failure of other more expensive parts of the assembly. Sealing members should be handled carefully, particularly when being installed. Cutting, scratching, or curling under of lip of seal seriously impairs its efficiency. Apply a thin coat of Permatex No.2 on the outer diameter of the oil seal to assure an oil tight fit into the retainer. When assembling new metal type sealing rings, same should be lubricated with coat of chassis grease to stabilize rings in their grooves for ease of assembly of mating members. Lubricate all " 0 " Rings and seals with Automatic Transmission Fluid before assembly.

Gears and Shafts

If magna-flux process is available, use process to check parts. Examine teeth on all gears carefully for wear, pitting, chipping, nicks, cracks or scores. If gear teeth show spots where case hardening is worn through or cracked, replace with new gear. Small nicks may be removed with suitable hone. Inspect shafts and quills to make certain they are not sprung, bent, or splines twisted, and that shafts are true.

Housing, Covers, etc.


Inspect housings, covers and bearing caps to be certain they are thoroughly cleaned and that mating surfaces, bearing bores, etc-, are free from nicks or burrs. Check all parts carefully for evidence of cracks or conditions which would cause subsequent oil leaks or failures.

**Figure 44**


Install outer race and sprag assembly in reaction member. **NOTE:** Undercut shoulder of race must go toward the rear of the reaction member.

**Figure 45**


Install outer race to reaction member retainer ring.

**Figure 46**

REASSEMBLY OF TORQUE CONVERTER

**Figure 47**


If pressure regulating valve was disassembled, reassemble as follows: Install new "O" ring on valve spring stop (one on each end, only one shown). Insert piston in housing. Install inner and outer valve springs. Install spring stop on spring. Depress spring stop and install spring stop roll pin.

**Figure 48**


Position safety valve spring and plunger in converter housing.

**Figure 49**

Install new gasket on converter housing, and new "O" ring on valve housing. Position valve assembly on converter housing.

**Figure 50**


Install valve screws and lockwashers. Tighten 23 to 25 ft.lbs. torque [31,2 - 33,8 N.m.].

**Figure 51**


Apply a light coat of Permatex on the outer diameter of the output shaft oil seal. Press oil seal in bearing retainer from inside of retainer as shown and to dimension shown. See assembly instruction sheet, page 8.

**Figure 52**


Press output rear bearing in bearing retainer. Secure with retainer ring. Press output shaft into bearing retainer. Use caution as not to damage oil seal. Position output gear on shaft. Press front output bearing on shaft. **NOTE: Use bearings with full inner race shoulder only. Do not use bearing with seal or shield grooves on inner race.** Install bearing retainer ring.

**Figure 53**

Install output flange, "O" ring, washer and flange nut. Tighten nut 200 to 250 ft.lbs. torque [271,2 - 338,9 N.m.]. Install new "O" ring on output shaft bearing retainer. Position output assembly on converter housing.

**Figure 54**

Install lockwashers, cap screws and stud nuts. Tighten stud nuts 41 to 45 ft.lbs. torque [55,6 - 61,0 N.m.]. Tighten capscrews 37 to 41 ft.lbs. torque [50,2 - 55,5 N.m.].

**Figure 55**

Install new oil sealing ring expander spring and oil sealing ring on reaction member support.

**Figure 56**

Install bearing on support. **NOTE: Bearing part number must be up.** Press bearing into position.



Figure 57

If turbine shaft bearing was removed, press bearing on shaft. **NOTE:** Ball bearing loading notches must be away from shoulder of turbine shaft. Install new turbine shaft oil sealing ring.




Figure 58

Install turbine shaft assembly in reaction member support. Use caution as not to damage turbine shaft oil sealing ring.



Figure 59

Install turbine shaft bearing retaining ring.




Figure 60

Position turbine shaft gear on shaft. Install gear retaining ring. See note on page 14 and reassemble accordingly.



Figure 61

Install reaction member support and turbine shaft assembly in converter housing.






Figure 62

Install support washers and screws. Torque screws 57 to 63 ft.lbs. torque [77,3 - 85,4 N.m.].

**Figure 63**


Install pump shaft rear bearing locating ring. Press rear bearing on pump shaft with bearing snap ring toward rear of shaft. Install bearing spacer and press front bearing on shaft until its shoulders against bearing spacer.

**Figure 66**

Install retainer washer snap ring.

**Figure 64**


Install pump shaft and bearing assembly in converter housing. From front of converter housing start pump drive gear on shaft.

**Figure 67**

Install pump drive gear retainer rings.

**Figure 65**

Install pump shaft rear bearing retainer washer.

**Figure 68**

Position impeller hub gear on reaction member support. **NOTE:** Use extreme caution as not to cut, break or unhook the oil sealing ring on the support.




Figure 69

Install new oil baffle oil seal as shown in assembly instruction sheet on page 8. Install new oil baffle "O" ring. Align three (3) oil baffle bolt holes with bolt holes in converter housing.




Figure 71

Oil baffle installed.




Figure 72

Install new impeller to impeller hub "O" ring.





Figure 70

Install three (3) oil baffle bolts and lockwashers. Tighten baffle bolts evenly to prevent damaging oil baffle "O" ring.



Figure 73

Install impeller on impeller hub. Use caution as not to damage "O" ring.

**Figure 74**

Install impeller to impeller hub lock tabs and cap screws. Tighten cap screws 23 to 25 ft.lbs. torque [31,2 - 33,8 N.m.].


**Figure 75**

Bend one corner of the lock tab over a flat side of the impeller to hub screws to prevent screws from loosening.


**Figure 76**

Install reaction member spacer and reaction member on reaction member support. If free-wheeling reaction member is used it will require a different spacer than the one used with a fixed reaction member.


**MUST FREEWHEEL IN
CLOCKWISE ENGINE ROTATION**

**Figure 77**

Check rotation of freewheeling reaction member to be sure of proper freewheel assembly.

**Figure 78**

Install reaction member to support retainer ring.

**Figure 79**

Install turbine locating ring on turbine shaft.




Figure 80
Install turbine on shaft.




Figure 81
If the impeller cover bearing retaining washer or bearing was replaced, use the following procedure for reassembly. Heat cover 200° to 250° F [93°-121°C]. Position snap ring in groove. Place bearing retainer washer in cover. While cover is hot press bearing into position spreading ears on snap ring at the same time. Align snap ring groove in bearing with snap ring. Release snap ring. Check ring to be certain it is in full position in groove.




Figure 82
Position new "O" ring on impeller cover.




Figure 83
Install impeller cover assembly on impeller. Use caution as not to damage "O" ring. Bearing retainer plate must be aligned with turbine shaft.




Figure 84
Install impeller cover to impeller capscrews and washers.
Tighten 11" impeller cover capscrews 12 to 16 ft.lbs. torque [16,3 - 21,6 N.m].
Tighten 12" impeller cover capscrews 23 to 25 ft.lbs. torque [31,2 - 33,8 N.m].




Figure 85
Install turbine retainer ring. See Figure 86.




Figure 86




Figure 87

Position new "O" ring on impeller cover bore plug. Lubricate ring to facilitate assembly. Install plug in cover.




Figure 88

Install bore plug retainer ring.




Figure 89

Position drive plate and weld nut assembly on impeller cover with weld nuts toward cover. Align intermediate drive plate and backing ring with holes in impeller cover. **NOTE:** Two dimples 180° apart in backing ring must be out (toward engine flywheel). Install capscrews and washers.







Figure 90

Tighten flex plate capscrews 23 to 25 ft.lbs. torque [31,2 - 33,8 N.m.]. Install pump adaptors, charging and accessory pumps.

1. TIGHTEN OUTPUT OR TURBINE SHAFT NUT 200 TO 250 LBS. FT. [271.63-338.96 N M] TORQUE.
2. ALL LEAD-IN CHAMFERS FOR OIL SEALS, PISTON RINGS & O-RINGS MUST BE SMOOTH AND FREE FROM BURRS. INSPECT AT ASSEMBLY.
3. LUBRICATE ALL PISTON RINGS & O-RINGS AT ASSEMBLY.
4. USE PERMATEX & CRANE SEALER ONLY WHERE SPECIFIED.
5. APPLY VERY LIGHT COAT OF PERMATEX NO. 2 TO O.D. OF ALL OIL SEALS BEFORE ASSEMBLY.
6. AFTER ASSEMBLY OF USING PERMATEX OR CRANE SEALER, THERE MUST BE NO FREE OR EXCESS MATERIAL THAT COULD ENTER THE OIL CIRCUIT.





REGULATOR VALVE



STRAIGHT THRU DRIVE

LUBE HOLES TO BE CHECKED PRIOR TO ASSEMBLY. HOLES MUST BE FREE OF DIRT & BURRS.

NEEDLE BEARING TO BE PRESSED .03-.06 [0,8-1,5] BELOW END OF GEAR.



POWER TAKE-OFF & GOVERNOR DRIVE

NOTE: METRIC DIMENSIONS SHOWN IN BRACKETS []

FIGURE E

**OIL PRESSURE AND LUBRICATION SPECIFICATIONS
FOR C-2000 SERIES CONVERTERS**

Converter Out Pressure Converter outlet oil temperature 180° 200° F. [82,3° 93,3° C] Transmission in NEUTRAL.

Operating specifications :
25 P.S.I. [172,4 kPa] minimum pressure at 2000 R.P.M. engine speed AND a maximum of
70 PS.I. [482,6 kPa] outlet pressure with engine operating at no-load governed speed.

Converter outlet pressure equals the total pressure drop of the cooler, cooler lines and back pressure of the transmission lubrication system.

Converter Lube Flow Disconnect CONVERTER DRAIN BACK line at transmission with engine running at 2000 RPM
and measure oil into a gallon container. Measure oil leakage for 15 seconds and multiply the volume of oil by four to
get gallons per minute leakage.

Leakage in Converter Leakage in C-2000 series not to exceed 2 gal. max

LUBRICATION

**RECOMMENDED LUBRICANTS FOR CLARK POWER SHIFTED TRANSMISSION AND
TORQUE CONVERTERS**

Prevailing Ambient Temperature

Type of Oil : See
Lube Chart


Capacity:
Consult Operator's Manual on applicable machine model
for system capacity. Torque Converter, Transmission
and allied hydraulic system must be considered as a
whole to determine capacity

Check Period :
Check oil level DAILY with engine running at 500-600
RPM and oil at 180° to 200° F [82,2°-93,3° C]. Maintain
oil level to FULL mark.

Normal Drain Period: .
Every 500 hours, change oil filter element Every 1000
hours, drain and refill system as follows. Drain with oil at
150° to 200° F. [65,6°-93,3° C].

NOTE: It is recommended that filter elements be
changed after 50 and 100 hours of operation on new
and rebuilt or repaired units.

- (a) Drain transmission and remove sump
screen. Clean screen thoroughly and replace, using
new gaskets
- (b) Drain oil filters, remove and discard filter elements.
Clean filter shells and install new
elements.
- (c) Refill transmission to LOW mark
- (d) Run engine at 500-600 RPM to prime
converter and lines.
- (e) Recheck level with engine running at 500-600 RPM
and add oil to bring level to LOW mark When oil
temperature is hot (180°-200° F) [82,2°-93,3° C]
make final oil level check. BRING OIL LEVEL TO
FULL MARK.



*Dexron is a registered trademark of
General Motors Corporation.

Temperature Range "1"	(a) C-2 Grade 30 (b) C-3 Grade 30 (c) Engine Oil:- Grade 30 API-CD/SE or CD/SF (d) MIL-L-2104C-Grade 30 (e) MIL-L-2104D-Grade 30
Temperature Range "2"	(a) MIL-L-2104C-Grade 10 (b) MIL-L-2104D-Grade 10 (c) C-2 Grade 10 (d) C-3 Grade 10 (e) Engine Oil:- Grade 10 API-CD/SE or CD/SF (f) Quintolubric 822-220 (Non Phosphate Ester Fire Resistant Fluid)
Temperature Range "3"	(a) * Dexron (b) * Dexron II D - See Caution Below
Temperature Range "4"	(a) MIL-L-46167 (b) MIL-L-46167 A
Temperature Range "5"	(a) Conoco Polar Start DN-600 Fluid

NOTES: Temperature ranges "2" and "3" may be
used to lower ambient temperatures when sump
preheaters are used.
Temperature range "4" should be used only in
ambient temperature range shown.

MODULATED SHIFT TRANSMISSIONS: H125, H200,
H500, H600, 18000, 24000, 28000, 32000 & 34000 series
transmissions with modulated shift use only C-3 or tem-
perature range 3 items (a) & (b) * Dexron or * Dexron II D.
SEE CAUTION BELOW. 3000, 4000, 5000, 6000, 8000 &
16000 series transmissions with modulated shift use only
C-3 or temperature range 3 item (a) only * Dexron. Do NOT
use * Dexron II D. **SEE CAUTION BELOW.**

**CAUTION: *Dexron II D is not compatible with
graphitic clutch plate friction material UNLESS IT
MEETS THE APPROVED C-3 SPECIFICATIONS.
*Dexron II D cannot be used in the 3000, 4000,
5000, 6000, 8000 or 16000 series power shift
transmissions, or the HR28000, HR32000 & HR34000
series having converter lock-up, or the C-270 series
converter having lock-up UNLESS IT MEETS THE
APPROVED C-3 SPECIFICATIONS.**

Any deviation from this lube chart must have written
approval from the application department of the
Clark Components International Engineering and Mar-
keting Dept.

Normal drain periods and filter change intervals are for average environmental and duty-cycle conditions. Severe or sustained high operating temperatures or very dusty atmospheric conditions will cause accelerated deterioration and contamination. For extreme conditions judgment must be used to determine the required change intervals.

IRREGULARITIES IN PERFORMANCE

C-2000 Series Converters

Make all checks with converter outlet temperature at least 180° 200° F. [82,3 93,3° C.]

TROUBLE	PROBABLE CAUSE	REMEDY
1. Low converter OUT pressure (Below 25 P.S.I. [172,4 kPa] with engine at 2000 RPM -NO LOAD). (See Converter Pressure Specifications).	Worn oil sealing and "O" rings.	Trouble is internal and will require a complete tear-down of the converter.
	Worn oil pump. Safety Valve stays open.	Replace. Clean and check valve spring and valve
2. Suction line taking air.	Low oil level.	Fill to proper level
	Suction line connections taking air.	Check oil line connections and tighten securely
	Worn oil pump	Replace.
3. High converter OUT pressure (Above 70 P.S.I.) [482,6 kPa] with engine operating at no-load governed speed. (See Converter Pressure Specifications)	Oil cooler or oil lines restricted.	Check oil cooler line and oil cooler for restrictions. Clean or replace.
	Oil too heavy.	Check oil weight. See oil recommendations.
	Cold oil.	Converter pressure in cold weather will vary. As soon as converter gets ho" pressure should drop
4. Over-heating.	See items No 1 & 2.	Clean and check oil cooler and oil cooler lines. Replace if necessary
	Oil cooler or oil cooler lines restricted causing safety valve to stay open.	Replace with larger cooler.
	Oil cooler too small.	Replace oil pump.
	Worn oil pump.	Install at lowest drain opening in converter housing. Line must maintain constant gradual drop to oil sump for gravity drain.
	Converter drain line to transmission or oil sump not installed properly.	Replace.
	A complete teardown will be necessary to determine this	Replace if necessary.
5 Noisy Converter.	Worn oil pump.	Replace.
	Damaged bearing	Replace.
	Worn drive gears.	Close pressure line to transmission control valve. If clutch pressure returns to normal, trouble is in transmission.
	Transmission malfunction	Replace.
6. Low clutch pressure. (See pressure specifications).	Clean and check valve for worn or dirty parts, replace if necessary.	
	Worn oil pump	
	Regulator valve stuck open.	

IRREGULARITIES IN PERFORMANCE (Cont'd)

C-2000 Series Converters

TROUBLE	PROBABLE CAUSE	REMEDY
7 High clutch pressure (See pressure specifications).	Regulator valve stuck closed.	Clean and check valve for worn or dirty parts, replace if necessary.
8. Lack of power	Improper engine function.	Tune engine.
	Engine stall speed below normal.	Tune engine. Check governor
	Low converter out pressure.	See item No.1.
	Air in the oil.	See item No.2.
	Improper oil.	See oil recommendations.
9 Oil in engine flywheel housing	"O" ring between impeller cover and impeller damaged.	Replace.
	Oil baffle "O" ring damaged.	Replace.
	Oil baffle oil seal damaged.	Replace.
	Impeller cover bore plug "O" ring damaged.	Replace
		Replace

GENERAL INFORMATION:

Use Clark 1533614 Oil Filter only.

Use Clark 215502 Oil Filter Element only.

Use minimum number of Pipe and Hose Fittings.

Gravity drain from Converter Sump to Transmission must be of minimum length and have no "U" bends to trap air or oil

Cooler capacity for normal application, 30 per cent of net Engine Horsepower at Governed Speed.

Check oil level with engine idling and transmission in neutral.

TRANSMISSION CLUTCH OIL PRESSURE P.S.I.

The C-2000 Converter will be equipped with one of three variations involving the clutch regulating valve. They are as follows

1 Inlet cover for Converter oil only with clutch pressure valve in transmission control cover 180 to 220 P.S.I. [1241,1 -1516,8 kPa] pressure range (See note)


2. Pressure regulator valve on Converter with a 240 to 280 P.S.I. [1654,8 -1930,5 kPa] pressure range (See Note) 3 Pressure regulator valve on Converter with a 180 to 220 P.S.I. [1241,1 -1516,8 kPa] pressure range. (See Note)

NOTE: All pressure must be equal within 5 P.S.I. [34,4 kPa]. If clutch pressure varies in anyone clutch more than 5 P.S.I. [34,4 kPa] repair clutch All pressures must be taken with two clutches engaged.

CONVERTER TO ENGINE INSTALLATION PROCEDURE

Measure the " A " dimension (Bolt Circle diameter) and order Drive Plate Kit listed below.

Note three (3) kits have two (2) intermediate drive plates and one (1) drive plate and weld nut assembly. One (1) kit with three intermediate drive plates.



" A " Dimension (Bolt Circle Diameter)

- 1138" [288,9 mm] Diameter
Kit No 802229
- 13125" [333,375 mm] Diameter Kit
No 802230
- 1350" [342,900 mm] Diameter Kit
No 802231

" A " Dimension (Bolt Circle Diameter)

- 13.50" [342,900 mm] Diameter
Kit No.802232

Each Kit will include the following parts .

- 2 Intermediate Drive Plates.
- 1 Drive Plate and Weld Nut Assembly.
- 1 Backing Ring
- 10 Screw and Lockwasher Assembly
- 1 Instruction Sheet

Kit will include the following parts

- 3 Intermediate Drive Plates.
- 1 Backing Ring
- 10 Screw and Lockwasher Assembly.
- 1 Instruction Sheet

TO FACILITATE ASSEMBLY ALIGN SMALL HOLES IN DRIVE PLATES -SEE ILLUSTRATION

ABOVE

Position drive plate and weld nut assembly on impeller cover with weld nuts toward cover Align intermediate drive plate and backing ring with holes in impeller cover. NOTE: Two dimples 180° apart in backing ring must be out (toward engine flywheel) Install capscrews and washers. Tighten 23 to 25 ft.lbs. torque [31,2 -33,8 Nm.]

1. Remove all burrs from flywheel mounting face and nose pilot bore. Clean drive plate surface with solvent.
2. Check engine flywheel and housing for conformance to standard S.A.E. # 3 -S.A.E. J-927 tolerance specifications for pilot bore size, pilot bore run out and mounting face flatness. Measure and record engine crankshaft end play.

3. Install two 2.50 [63,50 mm] long transmission to flywheel housing guide studs in the engine flywheel housing as shown. Rotate the engine flywheel to align a drive plate mounting screw hole with the flywheel housing access hole.

- *4. Install a 4-00 [101,60 mm] long drive plate locating stud -3750-24 fine thread in a drive plate nut. Align the locating stud in the drive plate with the flywheel drive plate mounting screw hole positioned in step No.3.

5. Locate transmission on flywheel housing aligning drive plate to flywheel and transmission to flywheel housing. **NOTE:** Fig. 4 installation, align drive plate holes with flywheel studs.

Install transmission to flywheel housing screws. Tighten screws to specified torque Remove transmission to engine guide studs. Install remaining screws and tighten to specified torque.

- *6. Remove drive plate locating stud.

7. Install drive plate attaching screw and washer. Snug screw but do not tighten. **NOTE:** Fig 4 installation, install drive plate attaching washers and nuts Tighten each nut 28 to 30 ft.lbs. torque [38,0 40,6 N.m.]. Some engine flywheel housings have a hole located on the flywheel housing circumference in line with the drive plate screw access hole. A screwdriver or pry bar used to hold the drive plate against the flywheel will facilitate installation of the drive plate screws. Rotate the engine flywheel and install the remaining seven (7) flywheel to drive plate attaching screws. Snug screws but do not tighten. After all eight (8) screws are installed torque each one 25 to 30 ft.lbs. torque [33,9 40,6 N.m.] This will require torquing each screw and rotating the engine flywheel until the full amount of eight (8) screws have been tightened.

8. Measure engine crankshaft end play after transmission has been completely installed on engine flywheel. This value must be within .001 [0,025 mm] of the end play recorded in step No.2.

* Does not apply to units having 3 intermediate drive plates. See Fig. 4.




FIG 1




FIG 2

SPECIAL STUD, WASHER AND SELF LOCK NUT FURNISHED BY ENGINE MANUFACTURER.




FIG 3

FIG 4