



*Operating Instructions for MAN Marine Diesel engines
Bedienungsanleitung für MAN-Schiffsdieselmotoren
Instrucciones de servicio para Motores Diesel MAN para barcos
Instruction de service pour Moteurs Diesel marins MAN
Norme di servizio per Motori Diesel MAN per applicazioni navali*

D 2840 LE 301

D 2842 LE 301

Operating Instructions –
MAN Marine Diesel Engines





Dear Customer,

these Operating Instructions are intended to familiarize you with your new MAN Diesel engine and how it operates.

This manual is supplemented by the publication “Fuels, Lubricants and Coolants for MAN Diesel Engines” and the “Service record book”.

Note:

All three publications belong to the engine and must always be kept ready to hand near the engine in the engine room.

Comply in full with instructions relating to operation, prevention of accidents and environmental protection.

MAN Diesel engines are developed and manufactured in line with the latest state of the art. However, trouble-free operation and high performance can only be achieved if the specified maintenance intervals are observed and only approved fuels, lubricants and coolants are used.

It is imperative and in your own interest to entrust your MAN Local Service Centre with the removal of any disturbances and with the performance of checking, setting, and repair work.

Yours faithfully,
MAN Nutzfahrzeuge Aktiengesellschaft
Werk Nürnberg

Subject to change to keep abreast with technological progress.

© 1999 MAN Nutzfahrzeuge Aktiengesellschaft
No parts of this publication may be reproduced or translated without prior written permission of MAN. MAN explicitly reserves all rights according to copyright law.



Contents

	Page
Declaration	7
Nameplates	8
Safety regulations	9
Commissioning and operation	14
Engine views	14
First commissioning	16
Commissioning	18
Starting	19
Operation monitoring system	21
Shutting down	21
Maintenance and care	22
Lubrication system	22
Fuel system	25
Cooling system	28
V-belts	30
Alternator	32
Temporary decommissioning of engines	32
Technical data	34
Troubleshooting table	39
Index	40

Declaration

In accordance with Article 4, paragraph 2, in conjunction with Appendix II, section B, of Directive 89/392/EEC, version 93/44/EEC

MAN Nutzfahrzeuge Aktiengesellschaft,

hereby declares that the engine described below is destined for installation in a machine as defined in the EC directive on machines.

Engine model:

Design:

For data see original declaration

Engine number:

If required this declaration is enclosed with the delivery note.

Rating / speed:

Note:

The manufacturer of the complete ready-to-use machine in which this engine is to be installed must take the further action necessary in the context of indirect safety-related engineering and provision of instructions to ensure that the ready-to-use machine complies with the requirements of the EC directive on machines.

The engine must not be put into operation until the complete machine satisfies the conditions laid down in the EC directive on machines 89/392/EEC, most recently amended by 93/44/EEC, or the latest amendment of said directive.


MAN Nutzfahrzeuge Aktiengesellschaft

Vogelweiherstraße 33

D-90441 Nürnberg



Nameplates



In all your correspondence please always quote engine model, serial number and job number (Order number).

For this reason it is advisable to read off the data from the engine type plates before putting the engine into operation and to enter them in the appropriate spaces.

The engine type plates are on the crankcase (see illustration).

MAN Nutzfahrzeuge Aktiengesellschaft	
Typ	<input type="text"/>
Motor-Nr. / Engine No.	<input type="text"/>
	NI/II
<input type="text"/>	<input type="text"/>

Model

.....

delivered on

.....

installed on


.....

Engine serial number

.....

Order number

.....



		MAN Nutzfahrzeuge Aktiengesellschaft	
		Werk Nürnberg Germany	
DIESEL ENGINE			
Bauj. Year	Typ	Model	Motor-Nr. Serial No
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Werk-Nr.	Job No	Leistung kW Rating kW	Drehz. 1/min Speed rpm
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Temp.°C	Leistg. PS Rating BHP	Aufstellhöhe m uNN Altitude m	
<input type="text"/>	<input type="text"/>	<input type="text"/>	
-0219			

General notes

Day-to-day use of power engines and the service products (fuels, lubricants, coolants) necessary for running them presents no problems if the persons occupied with their operation, maintenance and care are given suitable training and think as they work.

This summary is a compilation of the most important regulations. These are broken down into main sections which contain the information necessary for preventing injury to persons, damage to property and pollution. In addition to these regulations those dictated by the type of engine and its site are to be observed also.


Important:

If, despite all precautions, an accident occurs, in particular through contact with caustic acids, fuel penetrating the skin, scalding from hot oil, anti-freeze being splashed in the eyes etc., ***consult a doctor immediately.***

1. Regulations designed to prevent accidents with injury to persons

During commissioning, starting and operation


- Before putting the engine into operation for the first time, read the operating instructions carefully and familiarize yourself with the “critical” points. If you are unsure, ask your MAN representative.
- For reasons of safety we recommend you attach a notice to the door of the engine room prohibiting the access of unauthorized persons and that you draw the attention of the operating personal to the fact that they are responsible for the safety of persons who enter the engine room.
- The engine must be started and operated only by authorized personnel. Ensure that the engine cannot be started by unauthorized persons.
- When the engine is running, do not get too close to the rotating parts. Wear close-fitting clothing.
- Do not touch the engine with bare hands when it is warm from operation – risk of burns.
- Exhaust gases are toxic. Comply with the instructions for the installation of MAN Diesel engines which are to be operated in enclosed spaces. Ensure that there is adequate ventilation and air extraction.



- Keep vicinity of engine, ladders and stairways free of oil and grease. Accidents caused by slipping can have serious consequences.

During maintenance and care

- Always carry out maintenance work when the engine is switched off. If the engine has to be maintained while it is running, e.g. changing the elements of change-over filters, remember that there is a risk of scalding. Do not get too close to rotating parts.
- Change the oil when the engines is warm from operation.
Caution:
There is a risk of burns and scalding. Do not touch oil drain plugs or oil filters with bare hands.
- Take into account the amount of oil in the sump. Use a vessel of sufficient size to ensure that the oil will not overflow.
- Open the coolant circuit only when the engine has cooled down. If opening while the engine is still warm is unavoidable, comply with the instructions in the chapter entitled "Maintenance and Care".
- Neither tighten up nor open pipes and hoses (lube oil circuit, coolant circuit and any additional hydraulic oil circuit) during the operation. The fluids which flow out can cause injury.
- Fuel is inflammable. Do not smoke or use naked lights in its vicinity. The tank must be filled only when the engine is switched off.
- When using compressed air, e.g. for cleaning the radiator, wear goggles.
- Keep service products (anti-freeze) only in containers which can not be confused with drinks containers.
- Comply with the manufacturer's instructions when handling batteries.
Caution:
Accumulator acid is toxic and caustic. Battery gases are explosive.



2. Regulations designed to prevent damage to engine and premature wear

Do not demand more from the engine than it is able to supply in its intended application. Detailed information on this can be found in the sales literature. The injection pump must not be adjusted without prior written permission of MAN Nürnberg.

If faults occur, find the cause immediately and have it eliminated in order to prevent more serious damage.

Use only genuine MAN spare parts. MAN will accept no responsibility for damage resulting from the installation of other parts which are supposedly “just as good”.

In addition to the above, note the following points:

- Never let the engine run when dry, i.e. without lube oil or coolant.
- When starting do not use any additional starting aids (e.g. injection with starting pilot).
- Use only MAN-approved service products (fuel, engine oil, anti-freeze and anti-corrosion agent). Pay attention to cleanliness. The Diesel fuel must be free of water. See “Maintenance and care”.
- Have the engine maintained at the specified intervals.
- Do not switch off the engine immediately when it is warm, but let it run without load for about 5 minutes so that temperature equalization can take place.
- Never put cold coolant into an overheated engine. See “Maintenance and care”.
- ***Do not add so much engine oil that the oil level rises above the max. marking on the dipstick. Do not exceed the maximum permissible tilt of the engine.***
Serious damage to the engine may result if these instructions are not adhered to.
- Always ensure that the testing and monitoring equipment (for battery charge, oil pressure, coolant temperature) function satisfactorily.
- Comply with instructions for operation of the alternator. See “Maintenance and care”.
- Do not let the raw water pump run dry. If there is a risk of frost, drain the pump when the engine is switched off.

3. Regulations designed to prevent pollution

Engine oil and filter elements / cartridges, fuel / fuel filter

- Take old oil only to an old oil collection point.
- Take strict precautions to ensure that no oil or Diesel fuel gets into the drains or the ground.
The drinking water supply could be contaminated.
- Filter elements are classed as dangerous waste and must be treated as such.

Coolant

- Treat undiluted anti-corrosion agent and / or anti-freeze as dangerous waste.
- When disposing of spent coolant comply with the regulations of the relevant local authorities.

4. Notes on safety in handling used engine oil *

Prolonged or repeated contact between the skin and any kind of engine oil decreases the skin. Drying, irritation or inflammation of the skin may therefore occur. Used engine oil also contains dangerous substances which have caused skin cancer in animal experiments. If the basic rules of hygiene and health and safety at work are observed, health risks are not to the expected as a result of handling used engine oil.

Health precautions:

- Avoid prolonged or repeated skin contact with used engine oil.
- Protect your skin by means of suitable agents (creams etc.) or wear protective gloves.
- Clean skin which has been in contact with engine oil.
 - Wash thoroughly with soap and water. A nailbrush is an effective aid.
 - Certain products make it easier to clean your hands.
 - Do not use petrol, Diesel fuel, gas oil, thinners or solvents as washing agents.
- After washing apply a fatty skin cream to the skin.
- Change oil-soaked clothing and shoes.
- Do not put oily rags into your pockets.



Ensure that used engine oil is disposed of properly – Engine oil can endanger the water supply –

For this reason do not let engine oil get into the ground, waterways, the drains or the sewers. Violations are punishable.

Collect and dispose of used engine oil carefully. For information on collection points please contact the seller, the supplier or the local authorities.

* Adapted from "Notes on handling used engine oil".

Engine views D 2842 LE 301



- 1 Heat exchanger and coolant surge tank
- 2 Coolant filler neck
- 3 Relief valve on coolant surge tank
- 4 Intercooler
- 5 Oil filler neck
- 6 Oil separator valve for crankcase breather
- 7 Air Cleaner
- 8 Turbocharger
- 9 Exhaust pipe
- 10 Starter motor
- 11 Oil sump
- 12 Engine cranking device
- 13 Alternator
- 14 Water pump (engine coolant circuit)
- 15 Oil drain plug
- 16 Oil dipstick
- 17 Oil cooler
- 18 Oil filter

First commissioning

When putting a new or overhauled engine into operation for the first time pay attention to the “Installation instructions for MAN marine diesel engines” without fail.

It is recommended that new or overhauled engines should not be operated at a load higher than about 75% maximum load during the first few hours of operation. Initial run-in should be at varying speeds. After this initial run-in, the engine should be brought up to full output gradually.

Note:

Use only approved fuels, lubricants etc. (see brochure “Fuels, lubricants etc.”).
Otherwise the manufacturer’s warranty will become null and void.

Filling with fuel

Caution:

Fill the tank only when the engine is switched off. Pay attention to cleanliness.
Do not spill fuel.
Use only approved fuels (see “Fuels, Lubricants etc.”)

Filling-in of coolant

Fill the cooling system of the engine with a mixture of drinkable tap water and anti-freeze agent on ethylene glycole basis or anti-corrosion agent.

See Publication “Fuels, Lubricants and Coolants for MAN Diesel Engines”.

- Pour in coolant slowly via expansion tank, see page 29
- For coolant filling quantity, see “Technical data”

Raw water pump

Do not let raw water pump run dry.

Make sure that all valves / cocks in the raw water circuit are open.


If there is a risk of frost, drain the raw water pump.

Filling with engine oil

Caution:

Do not add so much engine oil that the oil level rises above the max. marking on the dipstick. Overfilling will result in damage to the engine.

The engines are as a rule supplied without oil.
Pour oil into engine via filler neck (arrow), see page 23.
For the quantity required see “Technical Data”.



Commissioning

Before daily starting the engine, check fuel level, coolant level and engine oil level and replenish, if necessary.

Note:

Use only approved fuels, lubricants etc. (see brochure “Fuels, lubricants etc.”). Otherwise the manufacturer’s warranty will become null and void.

Checking oil level

Check engine oil level only approx. 20 minutes after the unit has been switched off.



- Pull out dipstick
- wipe it with a clean, lintfree cloth
- and push it in again up to the stop
- Pull out dipstick again

The oil level should be between the two notches in the dipstick and must never fall below the lower notch. Top up oil as necessary.

Caution:

Do not add so much engine oil that the oil level rises above the max. marking on the dipstick. Overfilling will result in damage to the engine.

Ensure utmost cleanliness when handling fuels, lubricants and coolants.



Starting



Danger:

Before starting make sure that no-one is in the engine's danger area.

Caution:

When starting do not use any additional starting aids (e.g. injection with starting pilot).

Ensure that the gearbox is in neutral.

Insert starter key and turn it to position "I". The check lamp comes on to show that the engine is ready for operation.

Turn starter key further to position "II" (pre-glow). The display lamp (usually in the driver's station) comes on.




After the pre-glow period the display lamp begins to flash. This signalizes that the engine is ready for starting.

Note:

If the engine is not equipped with a pre-glowing function, immediately turn the starter key through to position "III".

Turn key further up to the stop (position "III"). The display lamp goes out. The starter motor is actuated.

Lube oil pressure must build up at the oil pressure gauge. If it does not, switch off the engine immediately.



Do not operate starter for longer than 10 seconds at a time.

After ignition of the engine, release the starter button and adjust control lever for desired speed.

If engine fails to start, release the key, wait about 30 seconds, then operate starter again.



For repeated starting turn the key back to OFF.

If the engine is kept idling for long periods it may cool down and thus start to emit white or blue smoke.

We therefore recommend that you do not let the engine idle for more than 5 minutes.

It is well known that with any internal combustion engine wear is higher during idling.

Idling for longer periods is also an environmental nuisance.




Operation monitoring system

Caution:

Do not overload the engine. Do not exceed the maximum permissible engine tilt. If faults occur, find their cause immediately and have them eliminated in order to prevent more serious damage!

During operation the oil pressure in the engine lubrication system must be monitored. If the monitoring (Fig. 2512) devices register a drop in the lube oil pressure, switch off the engine immediately.




Shutting down

After the engine has been running at a high load level, do not shut it down immediately but allow it to idle about 5 minutes so that temperatures may equalize.

Set deck switch to "Neutral" and switch off the engine at the stop button / ignition key.

Remove key from starting lock.



Danger:

Ensure that the engine can not be started by unauthorized persons.

Lubrication system

Ensure utmost cleanliness when handling fuels, lubricants and coolants.

Note:

Use only approved fuels, lubricants etc. (see brochure “Fuels, lubricants etc.”).
Otherwise the manufacturer’s warranty will become null and void.

Engine oil change



Danger:

The oil is hot- risk of scalding.
Do not touch the oil drain plug
with bare fingers. Oil is an envi-
ronmental hazard. Handle it with
care!

With the engine at operating temperature, remove the oil drain plugs on the oil sump and the oil filter bowl and allow the old oil to drain off completely.

Use a vessel of sufficient size to ensure that the oil does not overflow.


As the oil drain plug is often not accessible, a manually operated vane pump may be attached to the engine for draining the oil.

Pump the old oil out of the sump while the engine is still warm. Remove oil drain plugs in oil filter bowl and let old oil drain out of oil filters. Use a vessel of sufficient size to ensure that the oil does not overflow.


Refit the oil drain plugs with new gaskets.

Note:

Change the oil filter elements every time the engine oil is changed.



4580



4354

Refilling with oil

Caution:

Do not add so much engine oil that the oil level rises above the max. marking on the dipstick. Overfilling will result in damage to the engine.

Refill with fresh engine oil at the oil filler neck (arrow).

After filling start the engine and let it run for a few minutes at low speed.

Caution:

If no oil pressure builds up after approx. 10 seconds switch off the engine immediately.

Check oil pressure and check that there is no oil leakage.

Then shut down the engine. After about 20 minutes, check the oil level.


- Pull out dipstick
- wipe it with a clean, lintfree cloth
- and push it in again up to the stop
- Pull out dipstick again

The oil level should be between the two notches in the dipstick and must never fall below the lower notch. Top up oil as necessary.


Changing oil filter

A changeover-type oil filter, the filter elements of which can be replaced even during operation, can be fitted on request.


However, oil filter cartridges must be changed at every oil change.




4578



4579



2510



4581

During continuous operation position the selector lever that both filter halves are in operation.

Observe positions of selector lever!

Caution:

Do not leave selector lever in any intermediate position because this would be liable to interfere with oil supply. If in doubt stop engine to change oil filter.

Renewal of filter cartridges

- Allow the filter content to run off along drain plugs (4).
Hold a suitable vessel under hole



Danger:

The oil is hot and under pressure when the drain plug is opened. Risk of burns and scalds.



- After releasing the clamping bolts (8) remove filter bowls (7)
- Renew filter cartridges (5). Thoroughly clean all other parts in cleaning fluid (do not allow cleaning fluid to enter the oil circuit)
- Use new gaskets (6) for reassembly of filter bowls

Note:

To prevent the seal (6) from twisting hold the filter bowl (7) firmly when tightening the tensioning screw (8).

Caution:

Used oil filters are classed as dangerous waste and must be disposed of accordingly.



- 1 Oil filter, standard design (non-changeover)
- 2 Oil filter, changeover-type
- 3 Selector cock
- 4 Oil drain plugs
- 5 Filter cartridge
- 6 O-ring
- 7 Filter bowl
- 8 Clamping bolt

Fuel system

Fuel

If Diesel fuel which contains moisture is used the injection system and the cylinder liners / pistons will be damaged. This can be prevented to some extent by filling the tank as soon as the engine is switched off while the fuel tank is still warm (formation of condensation is prevented). Drain moisture from storage tanks regularly. Installation of a water trap upstream of the fuel filter is also advisable. Do not use any additives to improve flow properties in winter.

Injection pump

No alterations must be made to the injection pump. If the lead seal is damaged the warranty on the engine will become null and void.


Faults

We urgently recommend that you have faults in the injection pump rectified only in an authorised specialist workshop.


Cleaning fuel pre-cleaner

Strip the fuel pre-cleaner:

- Remove filter housing (1)
- Wash out filter housing (1) and gauze filter (2) in clean Diesel fuel and blow them out with compressed air
- Reassemble using new seal
- Screw on filter housing and tighten it to 10 – 12 Nm



- Actuate plunger of hand priming pump until the overflow valve of the injection pump opens audibly
- Start engine
- Check fuel pre-cleaner for leaks




Fuel filter

Changing fuel filter

Only when engine is switched off

- Loosen filter cartridge by means of tape wrench, unscrew it by hand and take it off
- Moisten the seals on the new filter cartridge with fuel
- Screw on the filter cartridges and tighten them vigorously by hand
- Bleed fuel system
- Check filter for leaks



Caution:


Used fuel filters are classed as dangerous waste and must be disposed of accordingly.

Change-over fuel filter

Where the changeover-type filter is installed, the servicing procedure is for the filter side requiring to be shut off with the engine running. During continuous operation, the selector lever should be placed in a position where both filter halves are in operation.

Caution:

Do not leave selector lever in any intermediate position because this would be liable to interfere with fuel supply. If in doubt stop the engine to change the fuel filter.




Changing fuel filter

- Loosen filter cartridge by means of tape wrench, unscrew it by hand and take it off
- Moisten the seals on the new filter cartridge with fuel
- Screw on the filter cartridges and tighten them vigorously by hand
- Bleed fuel system
- Check filter for leaks

Caution:

Used fuel filters are classed as dangerous waste and must be disposed of accordingly.





Bleeding the fuel system

Note:

To bleed the fuel system switch on the "ignition" so that the EHAB will be open.

An arrow on the filter head indicates the direction of fuel flow.

- Unscrew bleed screw of first filter in direction of flow by one or two turns
- Actuate tappet of hand primer until fuel emerges without bubbles
- Close bleed screw again
- Repeat this procedure at the second bleed screw
- Check fuel system for leaks



Cooling system




Danger:
Draining hot coolant involves a risk of scalding.

Draining the cooling system



Caution:

Drain coolant into a suitable container and dispose of it in accordance with regulations.

Drain coolant as follows when cooling system has cooled down:



- Briefly open cap (1, large cap) on the filler neck of the expansion tank for pressure compensation
- Remove drain plug in crankcase (4), oil cooler housing (3) and exhaust manifold (2)
- Then remove cap (1)
- Drain coolant into a container of adequate size
- Refit screw plugs
- Fill / bleed the cooling system



Fill / bleed the cooling system (only when engine has cooled down)

Fill the cooling system of the engine with a mixture of drinkable tap water and anti-freeze agent on ethylene glycole basis or anti-corrosion agent.


See Publication “Fuels, Lubricants and Coolants for MAN Diesel Engines”.

Coolant must be added at the filler neck only (1, large cap).

When topping up do not add cold coolant if the engine is still warm from operation.

Ensure that the ratio of water to anti-freeze is correct.

- Remove cap (1, large cap)
- Slowly fill up with coolant until correct coolant level is reached
- Refit end cover
- Let engine run at a speed of 2,000 rpm for approx. 15 minutes
- Switch off engine, carefully turn cap (1) with safety valve to the first detent to relieve pressure and then carefully remove cap and top up with coolant



Danger:

Risk of scalding and burning yourself!

- Before the engine is next put into operation (with the engine cold) check the coolant level and top up if necessary
- Repeat this procedure until no more coolant can be added



Danger:

If, in an **exceptional** case, the coolant level has to be checked in an engine that has reached operating temperature, first carefully turn the cap (1, large cap) with safety valve to the first stop, let off pressure, then open carefully.

V-belts

Checking condition

- Check V-belts for cracks, oil, overheating and wear
- Change damaged V-belts

Checking tension

Use V-belt tension tester to check V-belt tension.




- Lower indicator arm (1) into the scale
- Apply tester to belt at a point midway between two pulleys so that edge of contact surface (2) is flush with the V-belt
- Slowly depress pad (3) until the spring can be heard to disengage. This will cause the indicator to move upwards

If pressure is maintained after the spring has disengaged a false reading will be obtained!

Reading of tension

- Read of the tensioning force of the belt at the point where the top surface of the indicator arm (1) intersects with the scale
- Before taking readings make ensure that the indicator arm remains in its position

If the value measured deviates from the setting value specified, the V-belt tension must be corrected.




Drive belt width	Tensioning forces according to the kg graduation on the tester		
	New installation		When servicing after long running time
	Installation	After 10 min. running time	
2/3VX	90–100	70–80	60

Tensioning and changing V-belt

Alternator 120A

- Remove mounting nut ①
- Turn setting screw ② in clockwise direction until the tension of the V-belts is correct
- Retighten mounting nut

To change the V-belts turn the setting screw anti-clockwise.




4359

55 A alternator on heat exchanger

- Remove fixing bolts ①
- Remove lock-nut ②
- Adjust nut ③ until V-belts have correct tensions
- Retighten lock-nut and fixing bolts

To replace the V-belts loosen lock-nut and swing alternator inwards.




4360

Tension pulley at bottom right

- Remove fixing bolts ①
- Remove lock-nut ②
- Adjust nut ③ until V-belts have correct tensions
- Retighten lock-nut and fixing bolts

To change the V-belts turn the adjusting nut back and swing the tension pulley inwards.




4361

55 A alternator at bottom right

- Remove fixing bolts ①
- Remove lock-nut ②
- Adjust nut ③ until V-belts have correct tensions
- Retighten lock-nut and fixing bolts

To replace the V-belts loosen lock-nut and swing alternator inwards.



4362

Alternator

The alternator is maintenance-free.

Nevertheless, it must be protected against dust and, above all, against moisture.

In order to avoid damage to the alternator, observe the following instructions:

While the engine is running

- Do not de-energize the main battery switch!
- Do not disconnect the battery or pole terminals or the cables!
- If, during operation, the battery charge lamp suddenly lights up, stop the engine immediately and remedy the fault in the electrical system!
- Do not run the engine unless the battery charge control is in satisfactory order!
- Do not short-circuit the connections of the alternator with those of the regulator or said connections with ground, not even by briefly bringing the connections into contact!
- Do not operate the alternator without battery connection!

Temporary decommissioning of engines

Temporary anti-corrosion protection according to MAN works norm M 3069 is required for engines which are to be put out of service for fairly long periods.

The works standard can be obtained from our After-Sales Service department in Nuremberg.



A series of horizontal dotted lines for writing notes, spanning the width of the page.



Technical data

Model	D 2840 LE 301	
Design	V 90°	
Cycle	4-stroke Diesel with turbocharging / intercooling and wastegate	
Combustion system	Direct injection	
Turbocharging	Turbocharger with intercooling and wastegate	
Number of cylinders	10	
Bore	128 mm	
Stroke	142 mm	
Swept volume	18 270 cm ³	
Compression ratio	15.5 : 1	
Rating	see engine nameplate	
Firing order	1 - 6 - 5 - 10 - 2 - 7 - 3 - 8 - 4 - 9	
Valve clearance (cold engine)		
Intake	0.50 mm	
Exhaust	0.60 mm	
Valve timing		
Intake opens	24° before TDC	
Intake closes	36° after BDC	
Exhaust opens	63° before BDC	
Exhaust closes	27° after TDC	
Fuel system		
Injection	In-line pump, V-saddle-mounted	
Governor	Electronic speed governor (GAC)	
Injectors	six-hole nozzles	
Opening pressure of injector		
New nozzle holder:	295 + 8 bar	
Used nozzle holder:	280 + 8 bar	
Start of delivery ± 1° crank angle before TDC (Speed constant = without timing adjustment)		
	with optimised consumption	with optimised NO _x
1500 1/min, constant	14°	10°
1800 1/min, constant	15°	12°

Technical data



Engine lubrication	Force feed
Oil capacity in oil sump (litres) deep	min. max. 26 l 30 l
Oil change quantity (with filter)	33 l
Oil pressure during operation (depending on oil temperature, oil viscosity class and engine rpm)	must be monitored by oil pressure monitors / gauges
Oil filter	Full flow filter with two paper cartridges
Engine cooling system	Liquid cooling
Operating temperature	80 - 90°C, temporarily 95°C allowed
Coolant filling quantity	80 l
Electrical equipment	
Starter	24 V; 6.5 kW
Alternator	28 V; 55, 120 A



Technical data

Model	D 2842 LE 301	
Design	V 90°	
Cycle	4-stroke Diesel with turbocharging / intercooling and wastegate	
Combustion system	Direct injection	
Turbocharging	Turbocharger with intercooling and wastegate	
Number of cylinders	12	
Bore	128 mm	
Stroke	142 mm	
Swept volume	21 930 cm ³	
Compression ratio	15.5 : 1	
Rating	see engine nameplate	
Firing order	1 - 12 - 5 - 8 - 3 - 10 - 6 - 7 - 2 - 11 - 4 - 9	
Valve clearance (cold engine)		
Intake	0.50 mm	
Exhaust	0.60 mm	
Valve timing		
Intake opens	24° before TDC	
Intake closes	36° after BDC	
Exhaust opens	63° before BDC	
Exhaust closes	27° after TDC	
Fuel system		
Injection	In-line pump, V-saddle-mounted	
Governor	Electronic speed governor (GAC)	
Injectors	six-hole nozzles	
Opening pressure of injector		
New nozzle holder:	295 + 8 bar	
Used nozzle holder:	280 + 8 bar	
Start of delivery ± 1° crank angle before TDC (Speed constant = without timing adjustment)		
	with optimised consumption	with optimised NO _x
1500 1/min, constant	14°	10°
1800 1/min, constant	16°	13°

Technical data



Engine lubrication	Force feed
Oil capacity in oil sump (litres) deep	min. max. 24 l 32 l
Oil change quantity (with filter)	35 l
Oil pressure during operation (depending on oil temperature, oil viscosity class and engine rpm)	must be monitored by oil pressure monitors / gauges
Oil filter	Full flow filter with two paper cartridges
Engine cooling system	Liquid cooling
Operating temperature	80 - 90°C, temporarily 95°C allowed
Coolant filling quantity	96 l
Electrical equipment	
Starter	24 V; 6.5 kW
Alternator	28 V; 55, 120 A



Troubleshooting table

Fault										
Engine does not start, or starts only with difficulty										
Engine starts but does not reach full speed or stalls										
Engine idles out of true when warm, misfiring										
Engine speed fluctuates during operation										
Power output unsatisfactory										
Coolant temperature too high, coolant being lost										
Lube oil pressure too low										
Lube oil pressure too high										
Black smoke accompanied by loss of power										
Blue smoke										
White smoke										
Knocking in the engine										
Engine "too loud"										
Reason										
•										Fuel tank empty
•										Fuel cock closed
•	•	•	•					•		Air in fuel system
•	•	•	•					•		Fuel pre-filter / pre-cleaner clogged
•										Condensation in fuel
•	•		•			•				Air filter clogged
•										Electric circuit interrupted
•										Batteries flat
•										Starter / solenoid switch defective
•	•					•		•	•	Start of delivery not correct / incorrectly set
•										Injection nozzles clogged
•										Internal damage to engine (piston seized, possibly caused by water in fuel)
	•		•					•		Fuel quality not in accordance with specifications or fueled severely contaminated
		•								Lower idling speed set too low
•	•							•	•	Valve clearance incorrect
		•								Injection nozzles of injection pipes leaking
		•								Too little fuel in tank
		•								Rev. counter defective
		•				•		•		Injection nozzles defective or carbonized
			•							Engine being asked to do more than it has to
			•							Fuel supply faulty, fuel too warm
							•			Oil level in sump too high
			•							Incorrect rated speed setting
				•						Coolant level too low
				•						Air in coolant circuit



Fault									
Engine does not start, or starts only with difficulty									
Engine starts but does not reach full speed or stalls									
Engine idles out of true when warm, misfiring									
Engine speed fluctuates during operation									
Power output unsatisfactory									
Coolant temperature too high, coolant being lost									
Lube oil pressure too low									
Lube oil pressure too high									
Black smoke accompanied by loss of power									
Blue smoke									
White smoke									
Knocking in the engine									
Engine "too loud"									
Reason									
								●	Tension of water-pump V-belts incorrect (slip)
								●	Cap with working valves on expansion tank / radiator defective or leaking
								●	Temperature gauge defective
								●	Coolant pipes leaking, blocked or twisted
								●	Oil level in sump too low
								●	Engine temperature too high
								●	Oil filter clogged
								● ●	Oil pressure gauge defective
								● ●	Selected oil viscosity not suitable for ambient temperature (oil too thin)
								●	Oil in sump too thin (mixed with condensation or fuel)
								●	Engine cold
								● ●	Engine, coolant or intake air still too cold
								●	Lube oil getting into combustion chamber (piston worn, piston rings worn or broken)
								●	Overpressure in crankcase (crankcase breather clogged)
								●	long operation under a low load
								●	Coolant getting into combustion chamber (cylinder head / gasket leaking)
								●	Engine operating temperature incorrect
								●	Intake or exhaust pipe leaking



Index

A		I	
Alternator	32	Injection pump	25
B		L	
Bleeding the fuel system	27	Lubrication system	22–24
C		M	
Changing oil filter	23	Maintenance and care	22–32
Checking oil level	18	N	
Checking V-belts	30–31	Nameplates	8
Cleaning fuel pre-cleaner	25	O	
Commissioning	18	Operation monitoring system	21
Commissioning and operation	14–21	R	
Cooling system	28–29	Raw water pump	16
D		Refilling with oil	23
Declaration	7	S	
Draining the cooling system	28	Safety regulations	9–13
E		Handling used engine oil	13
Engine oil change	22	Preventing accidents with injury to persons ...	9
Engine views	14	Preventing damage	
F		to engine and premature wear	11
Fill / bleed the cooling system	29	Preventing environmental damage	12
Filling with engine oil	17	Shutting down	21
Filling with fuel	16	Starting	19–20
Filling-in of coolant	16	T	
First commissioning	16	Technical data	34–37
Fuel filter	26	Temporary decommissioning	32
Fuel filters, Changing fuel filter	26, 27	Troubleshooting table	38–39
Fuel system	25–27		



MAN Nutzfahrzeuge Aktiengesellschaft

**Vogelweiherstraße 33
D-90441 Nürnberg**

Printed in Germany

51.99493-8500