




**Operating Instructions for MAN Industrial Diesel Engines  
Bedienungsanleitung für MAN-Industriedieselmotoren  
Instrucciones de servicio para motores Diesel industriales MAN  
Instruction de service pour moteurs Diesel industriels MAN  
Norme di servizio per Motori Diesel industriali MAN**

**D 2876 LE 101 / 103 / 104 / 105**



Operating Instructions –  
MAN Industrial Diesel Engines





Dear Customer,

these Operating Instructions are intended to familiarize you with your new MAN Diesel engine and how it operates.

The Publication “Fuels, Lubricants and Coolants for MAN Diesel Engines” supplements these Operating Instructions.



**Note:**

Both publications apply to the engine and must always be kept to hand in its vicinity in the engine room.

Please read this Manual and the “Instructions for the installation of MAN Diesel Engines” before you put the new engine into operation.

Comply in full with instructions relating to operation, prevention of accidents and environmental protection.

MAN Diesel engines are developed and manufactured in line with the latest state of the art. However, trouble-free operation and high performance can only be achieved if the specified maintenance intervals are observed and only approved fuels, lubricants and coolants are used.

It is imperative and in your own interest to entrust your MAN Local Service Centre with the removal of any disturbances and with the performance of checking, setting, and repair work.

Yours faithfully,  
MAN Nutzfahrzeuge Aktiengesellschaft  
Werk Nürnberg

Subject to change to keep abreast with technological progress.

© 2003 MAN Nutzfahrzeuge Aktiengesellschaft  
No parts of this publication may be reproduced or translated without prior written permission of MAN. MAN explicitly reserves all rights according to copyright law.

Important instructions which concern technical safety and protection of persons are emphasised as shown below.

**Danger:**

This refers to working and operating procedures which must be complied with in order to rule out the risk to persons.

**Caution:**

This refers to working and operating procedures which must be complied with in order to prevent damage to or destruction of material.

**Note:**

Explanations useful for understanding the working or operating procedure to be performed.

### Fitting flat seals / gaskets

Flat seals / gaskets are often inserted with sealing agents or adhesives to make fitting them easier or to achieve better sealing. Flat seals may slip in operation due to the “sewing-machine” effect, in particular if they are used between parts with different rates of linear expansion under heat (e.g. aluminium and cast iron), and leaks may then occur.

**Example:**

the cap of the front crankshaft seal. If a sealing agent or an adhesive is used here the flat seal will move inwards in the course of time as a result of the different expansion rates of the materials. Oil will be lost, for which the shaft seal may be thought to be responsible.

**Flat seals / gaskets can be fitted properly only if the following points are observed:**

- Use only genuine MAN seals / gaskets
- The sealing faces must be undamaged and clean
- Do not use any sealing agent or adhesive – as an aid to fitting the seals a little grease can be used if necessary so that the seal will stick to the part to be fitted
- Tighten bolts evenly to the specified torque

---

	Page
<b>Declaration</b> .....	8
<b>Nameplates</b> .....	9
<b>Safety regulations</b> .....	10
<b>Commissioning and operation</b> .....	14
First commissioning .....	14
Commissioning .....	15
Starting .....	16
Operation monitoring system .....	17
Shutting down .....	17
<b>Maintenance and care</b> .....	18
Lubrication system .....	18
Fuel system .....	22
Cooling system .....	25
V-belts .....	27
Turbocharger .....	31
Intercooler .....	31
Starter motor .....	31
Temporary decommissioning of engines .....	31
<b>Technical data</b> .....	32
<b>Maintenance chart</b> .....	34
<b>Troubleshooting chart</b> .....	36
<b>Index</b> .....	40

## Declaration

In accordance with Article 4, paragraph 2, in conjunction with Appendix II, section B, of Directive 89/392/EEC, version 93/44/EEC

### **MAN Nutzfahrzeuge Aktiengesellschaft,**

hereby declares that the engine described below is destined for installation in a machine as defined in the EC directive on machines.

Engine model:

Design:

*For data see original declaration*

Engine number:

*If required this declaration is enclosed with the delivery note.*

Rating / speed:



**Note:**

The manufacturer of the complete ready-to-use machine in which this engine is to be installed must take the further action necessary in the context of indirect safety-related engineering and provision of instructions to ensure that the ready-to-use machine complies with the requirements of the EC directive on machines. The engine must not be put into operation until the complete machine satisfies the conditions laid down in the EC directive on machines 89/392/EEC, most recently amended by 93/44/EEC, or the latest amendment of said directive.

**MAN Nutzfahrzeuge Aktiengesellschaft**

**Vogelweiherstraße 33**

**D-90441 Nürnberg**



# Nameplates



In all your correspondence please always quote engine model, serial number and job number (Order number).

For this reason it is advisable to read off the data from the engine type plates before putting the engine into operation and to enter them in the appropriate spaces.

The engine type plates are on the crankcase.

Model .....

delivered on .....

installed on .....

Engine serial number .....

Order number .....

MAN Nutzfahrzeuge Aktiengesellschaft  
 Typ   
 Motor-Nr. / Engine No.  NI/II

MAN Nutzfahrzeuge Aktiengesellschaft  
 Werk Nürnberg Germany  
**DIESEL ENGINE**

Bauj. Year	Typ	Model	Motor-Nr.	Serial No
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Werk-Nr.	Job No	Leistung kW Rating kW	Drehz. 1/min	Speed rpm
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Temp.°C	Leistg. PS Rating BHP	Aufstellhöhe m uNN Altitude m		
<input type="text"/>	<input type="text"/>	<input type="text"/>		

-0219

## General notes

***Handling diesel engines and the necessary resources is no problem when the personnel commissioned with operation and maintenance are trained accordingly and use their common sense.***

This summary is a compilation of the most important regulations. These are broken down into main sections which contain the information necessary for preventing injury to persons, damage to property and pollution. In addition to these regulations those dictated by the type of engine and its site are to be observed also.

### **Important:**

If, despite all precautions, an accident occurs, in particular through contact with caustic acids, fuel penetrating the skin, scalding from hot oil, anti-freeze being splashed in the eyes etc., ***consult a doctor immediately.***

## 1. Regulations designed to prevent accidents with injury to persons

### During commissioning, starting and operation

- Before putting the engine into operation for the first time, read the operating instructions carefully and familiarize yourself with the “critical” points. If you are unsure, ask your MAN representative.
- For reasons of safety we recommend you attach a notice to the door of the engine room prohibiting the access of unauthorized persons and that you draw the attention of the operating personal to the fact that they are responsible for the safety of persons who enter the engine room.
- The engine must be started and operated only by authorized personnel. Ensure that the engine cannot be started by unauthorized persons.
- When the engine is running, do not get too close to the rotating parts. Wear close-fitting clothing.
- Do not touch the engine with bare hands when it is warm from operation – risk of burns.
- Exhaust gases are toxic. Comply with the instructions for the installation of MAN Diesel engines which are to be operated in enclosed spaces. Ensure that there is adequate ventilation and air extraction.
- Keep vicinity of engine, ladders and stairways free of oil and grease. Accidents caused by slipping can have serious consequences.



## During maintenance and care

- Always carry out maintenance work when the engine is switched off. If the engine has to be maintained while it is running, e.g. changing the elements of change-over filters, remember that there is a risk of scalding. Do not get too close to rotating parts.
- Change the oil when the engine is warm from operation.  
**Caution:**  
There is a risk of burns and scalding. Do not touch oil drain plugs or oil filters with bare hands.
- Take into account the amount of oil in the sump. Use a vessel of sufficient size to ensure that the oil will not overflow.
- Open the coolant circuit only when the engine has cooled down. If opening while the engine is still warm is unavoidable, comply with the instructions in the chapter entitled "Maintenance and Care".
- Neither tighten up nor open pipes and hoses (lube oil circuit, coolant circuit and any additional hydraulic oil circuit) during the operation. The fluids which flow out can cause injury.
- Fuel is inflammable. Do not smoke or use naked lights in its vicinity. The tank must be filled only when the engine is switched off.
- When using compressed air, e.g. for cleaning the radiator, wear goggles.
- Keep service products (anti-freeze) only in containers which can not be confused with drinks containers.
- Comply with the manufacturer's instructions when handling batteries.  
**Caution:**  
Accumulator acid is toxic and caustic. Battery gases are explosive.





### 2. Regulations designed to prevent damage to engine and premature wear

Do not demand more from the engine than it is able to supply in its intended application. Detailed information on this can be found in the sales literature. The injection pump must not be adjusted without prior written permission of MAN Nürnberg.

If faults occur, find the cause immediately and have it eliminated in order to prevent more serious damage.

Use only genuine MAN spare parts. MAN will accept no responsibility for damage resulting from the installation of other parts which are supposedly "just as good".

In addition to the above, note the following points:

- Never let the engine run when dry, i.e. without lube oil or coolant.
- When starting do not use any additional starting aids (e.g. injection with starting pilot).
- Use only MAN-approved service products (fuel, engine oil, anti-freeze and anti-corrosion agent). Pay attention to cleanliness. The Diesel fuel must be free of water. See "Maintenance and care".
- Have the engine maintained at the specified intervals.
- Do not switch off the engine immediately when it is warm, but let it run without load for about 5 minutes so that temperature equalization can take place.
- Never put cold coolant into an overheated engine. See "Maintenance and care".
- ***Do not add so much engine oil that the oil level rises above the max. marking on the dipstick. Do not exceed the maximum permissible tilt of the engine.***  
Serious damage to the engine may result if these instructions are not adhered to.
- Always ensure that the testing and monitoring equipment (for battery charge, oil pressure, coolant temperature) function satisfactorily.
- Comply with instructions for operation of the alternator. See "Maintenance and care".

### 3. Regulations designed to prevent pollution

#### Engine oil and filter elements / cartridges, fuel / fuel filter

- Take old oil only to an old oil collection point.

- Take strict precautions to ensure that no oil or Diesel fuel gets into the drains or the ground.

**Caution:**

The drinking water supply could be contaminated.

- Filter elements are classed as dangerous waste and must be treated as such.

### Coolant

- Treat undiluted anti-corrosion agent and / or anti-freeze as dangerous waste.
- When disposing of spent coolant comply with the regulations of the relevant local authorities.

#### 4. Notes on safety in handling used engine oil \*

Prolonged or repeated contact between the skin and any kind of engine oil decreases the skin. Drying, irritation or inflammation of the skin may therefore occur. Used engine oil also contains dangerous substances which have caused skin cancer in animal experiments. If the basic rules of hygiene and health and safety at work are observed, health risks are not to the expected as a result of handling used engine oil.

#### Health precautions:

- Avoid prolonged or repeated skin contact with used engine oil.
- Protect your skin by means of suitable agents (creams etc.) or wear protective gloves.
- Clean skin which has been in contact with engine oil.
  - Wash thoroughly with soap and water. A nailbrush is an effective aid.
  - Certain products make it easier to clean your hands.
  - Do not use petrol, Diesel fuel, gas oil, thinners or solvents as washing agents.
- After washing apply a fatty skin cream to the skin.
- Change oil-soaked clothing and shoes.
- Do not put oily rags into your pockets.

**Ensure that used engine oil is disposed of properly  
– Engine oil can endanger the water supply –**

For this reason do not let engine oil get into the ground, waterways, the drains or the sewers. Violations are punishable.

Collect and dispose of used engine oil carefully. For information on collection points please contact the seller, the supplier or the local authorities.

\* Adapted from "Notes on handling used engine oil".

### First commissioning

At the time of initial commissioning of a new or overhauled engine make sure to have observed the “Technical Information for the installation of MAN Diesel engines”.

It is recommended that new or overhauled engines should not be operated at a load higher than about 75% maximum load during the first few hours of operation. Initial run-in should be at varying speeds.

After this initial run-in, the engine should be brought up to full output gradually.

**Note:**

Use only approved fuels, lubricants etc. (see brochure “Fuels, lubricants etc.”). Otherwise the manufacturer’s warranty will become null and void.

### Filling with fuel

**Caution:**

Fill the tank only when the engine is switched off. Pay attention to cleanliness. Do not spill fuel. Use only approved fuels, see brochure “Fuels, lubricants etc.”.

### Filling-in of coolant

Fill the cooling system of the engine with a mixture of drinkable tap water and anti-freeze agent on the ethylene glycole basis or anti-corrosion agent.

See Publication “Fuels, Lubricants and Coolants for MAN Diesel Engines”.

- Observe / adhere to vehicle manufacturer’s filling specifications
- Slowly pour in coolant (max. 10 ltr./min)

### Filling with engine oil

**Caution:**

Do not add so much engine oil that the oil level rises above the max. marking on the dipstick. Overfilling will result in damage to the engine.

The engines are as a rule supplied without oil.

Pour oil into engine via filler neck, see page 19.

For the quantity required see “Technical Data”.

**Note:**

Before putting the hydraulic pump into operation for the first time fill it with oil. Heed the manufacturer’s instructions!

## Commissioning

Before daily starting the engine, check fuel level, coolant level and engine oil level and replenish, if necessary.



**Note:**



Use only approved fuels, lubricants etc. (see brochure “Fuels, lubricants etc.”). Otherwise the manufacturer’s warranty will become null and void.

### Checking oil level

Check the oil level when the engine is horizontal, but only if at least 20 minutes have passed since the machine was switched off.

- Pull out dipstick (arrow)
- wipe it with a clean, lintfree cloth
- and push it in again up to the stop
- Pull out dipstick again


The oil level should be between the two notches in the dipstick and must never fall below the lower notch. Top up oil as necessary.



**Caution:**

Do not add so much engine oil that the oil level rises above the max. marking on the dipstick. Overfilling will result in damage to the engine.

Ensure utmost cleanliness when handling fuels, lubricants and coolants.



### Starting

**Danger:**

Before starting make sure that no-one is in the engine's danger area.

**Caution:**

When starting do not use any additional starting aids (e.g. injection with starting pilot).

- Ensure that no load is on the engine before starting it, eg switch off load, disengage clutch, put gearbox into neutral etc.
- Switch on EDC
- Triggering of flame start system
- Starting procedure initiated after preglowing (start assistance) and interrupted after engine starts at approx. 300–400 rpm
- Should the engine not start – starting time restricted to 10–15 seconds
- Repeat start attempt 3–4 x with 15–20 second pause in between
- Fault indication upon unsuccessful start

Avoid running the cold engine for any length of time since in any internal combustion engine this is liable to cause increased wear due to corrosion. Prolonged idling is harmful to the environment.



## Operation monitoring system

**Caution:**

Do not overload the engine. Do not exceed the maximum permissible tilt of the engine. If faults occur, find their cause immediately and have them eliminated in order to prevent more serious damage!

Monitor the oil pressure of the engine lubrication and coolant agent temperature during operations.

If the monitoring devices register a drop in the lube oil pressure, switch off the engine immediately.

## Shutting down

Set engine to idle speed.

After engine has been under a heavy load let it run idle for approx. 5 minutes.

Turn off engine via EDC.

**Danger:**

Ensure that the engine cannot be started by unauthorized persons.

## Lubrication system

Ensure utmost cleanliness when handling fuels, lubricants and coolants.

**Note:**

Use only approved fuels, lubricants etc. (see brochure "Fuels, lubricants etc."). Otherwise the manufacturer's warranty will become null and void.

### Refilling with oil

**Danger:**

The oil is hot- risk of scalding. Do not touch the oil drain plug with bare fingers. Oil is an environmental hazard. Handle it with care!

With the engine at operating temperature, remove the oil drain plugs on the oil sump and the oil filter bowl and allow the old oil to drain off completely.

Use a vessel of sufficient size to ensure that the oil does not overflow.




As the oil drain plug is often not accessible, a manually operated vane pump may be attached to the engine for draining the oil.

Pump the old oil out of the sump while the engine is still warm. Remove oil drain plugs in oil filter bowl and let old oil drain out of oil filters.

**Caution:**

Used oil is dangerous waste. Observe safety regulations to prevent damage to the environment.

Refit the oil drain plugs with new gaskets.



## Refilling with oil



### Caution:

Do not add so much engine oil that the oil level rises above the max. marking on the dipstick. Overfilling will result in damage to the engine.

Refill with fresh engine oil at the oil filler neck ①.

After filling start the engine and let it run for a few minutes at low speed.



### Caution:





If no oil pressure builds up after approx. 10 seconds switch off the engine immediately.

Check oil pressure and check that there is no oil leakage.

Then shut down the engine. After about 20 minutes, check the oil level.

- Pull out dipstick (arrow)
- wipe it with a clean, lintfree cloth
- and push it in again up to the stop
- Pull out dipstick again

The oil level should be between the two notches in the dipstick and must never fall below the lower notch. Top up any missing oil. Do not overfill.



### Changing oil filter

**Caution:**

Used oil and oil filters are classed as dangerous waste. Observe safety regulations to prevent damage to the environment.

Open oil drain plug on oil filter can and use container to catch oil that may emerge.

**Danger:**

Oil filter can and oil filter are filled with hot oil.  
Risk of burns and scalds.

Remove mounting bolt of filter bowl.

Take off filter bowl and clean it internally.

Insert new filter element and fit filter bowl with new seals.

Refit the oil drain plug with a new seal.



Observe tightening torque for mounting bolt.

**Note:**

To prevent the seal from twisting hold the filter bowl firmly when tightening the tensioning screw.

Add engine oil, let engine run for a short time and check for leaks.

Check oil level.



## Changing oil filter



**Caution:**

Used oil and oil filters are classed as dangerous waste. Observe safety regulations to prevent damage to the environment.

Release oil filter cap with special tool until sealing ring ③ is visible, wait approx. 2 minutes until the oil has drained from the filter bowl.



**Danger:**

Oil filter can and oil filter are filled with hot oil.  
Risk of burns and scalds.

Pull out oil filter cap together with filter element and catch escaping oil in a suitable container.

Detach filter element from cap.

Replace sealing rings ①, ② and ③.

Install a new filter element.




**Danger:**

The oil filter cap is made from plastic, do not exceed the specified torque.

Screw in oil filter cap together with filter element and tighten to 25 Nm.

Add engine oil, let engine run for a short time and check for leaks.

Check oil level.



## Fuel system

### Fuel

If Diesel fuel which contains moisture is used the injection system and the cylinder liners / pistons will be damaged. This can be prevented to some extent by filling the tank as soon as the engine is switched off while the fuel tank is still warm (formation of condensation is prevented). Drain moisture from storage tanks regularly.

Installation of a water trap upstream of the fuel filter is also advisable. Do not use any additives to improve flow properties in winter.

### Injection pump

No alterations must be made to the injection pump. If the lead seal is damaged the warranty on the engine will become null and void.



### Faults

We urgently recommend that you have faults in the injection pump rectified only in an authorised specialist workshop.

### Cleaning fuel pre-cleaner

Strip the fuel pre-cleaner ①:

- Remove filter housing ②
  - Wash out filter housing ② and gauze filter ③ in clean Diesel fuel and blow them out with compressed air
  - Reassemble using new seal
  - Screw on filter housing
- 
- Actuate plunger of hand priming pump until the overflow valve of the injection pump opens audibly
  - Screw in and tighten plunger on hand pump
  - Start engine
  - Check fuel pre-cleaner for leaks



## Fuel filter

### Parallel fuel filter

#### **Draining moisture:**

Unscrew drain plugs at every oil change until moisture has been discharged and clean fuel flows out.

#### **Changing fuel filter**





Only when the engine is switched off.

- Loosen filter cartridge by means of tape wrench, unscrew it by hand and take it off
- Moisten the seals on the new filter cartridge with fuel
- Screw on the filter cartridges and tighten them vigorously by hand
- Bleeding the fuel system
- Check filter for leaks



#### **Caution:**

Used fuel filters are classed as dangerous waste and must be disposed of accordingly.



### Bleeding the fuel system


An arrow on the filter head indicates the direction of fuel flow.

- Unscrew bleed screw of first filter in direction of flow by one or two turns
- Actuate tappet of hand primer until fuel emerges without bubbles
- Screw in and tighten plunger on hand pump
- Close bleed screw again
- Repeat this procedure at the second bleed screw
- Check fuel system for leaks

### Fuel service center KSC


#### Cleaning fuel pre-cleaner

- Screw off housing cap ①
- Remove and clean cap and strainer element ③
- Replace sealing ring ②
- Screw in strainer element and cap and tighten down to 25 Nm
- Bleeding the fuel system
- Check filter for leaks



#### Bleeding the fuel system


- Unscrew plunger ① on hand pump and operate until injection pump overflow valve can be heard to open
- Screw in and tighten plunger on hand pump
- Start engine
- Check fuel system for leaks



#### Changing fuel filter

Only when the engine is switched off.

- Screw off housing cap ①
- Remove cap and filter element
- Detach filter element ③ from cap
- Detach sealing ring ②
- Clean cap
- Replace sealing ring
- Attach new filter element
- Screw in filter element and cap and tighten down to 25 Nm
- Bleeding the fuel system
- Check filter for leaks





## Cooling system

**Danger:**

Draining hot coolant involves a risk of scalding.



## Draining the cooling system

**Caution:**

Drain coolant into a suitable container and dispose of it in accordance with regulations.

Drain coolant as follows when cooling system has cooled down:

- Open cap on filler neck of expansion tank for pressure compensation and remove
- Unscrew drain plugs in oil cooler housing
- Then take off the cap
- Drain coolant into a container of adequate size
- Refit screw plugs
- Fill / bleed the cooling system



### Fill / bleed the cooling system (only when engine has cooled down)

Fill the cooling system of the engine with a mixture of drinkable tap water and anti-freeze agent on the ethylene glycole basis or anti-corrosion agent.

See Publication “Fuels, Lubricants and Coolants for MAN Diesel Engines”.

### Coolant must be poured in according to the vehicle manufacturer’s filling specifications.

Do not put cold coolant into an engine which is warm from operation.

Ensure that the ratio of water to anti-freeze is correct.

- Slowly pour in coolant (max. 10 ltr./min)
- Run the engine briefly and then check coolant level once more



**Danger:**


If, in an **exceptional** case, the coolant level has to be checked in an engine that has reached operating temperature, first carefully turn the cap with safety valve to the first stop, let off pressure, then open carefully.

## V-belts

### Checking condition

If, in the case of a multiple belt drive, wear or differing tensions are found, always replace the complete set of belts.


- Check V-belts for cracks, oil, overheating and wear
- Change damaged V-belts




### Checking tension

Use V-belt tension tester to check V-belt tension.

- Lower indicator arm ① into the scale
- Apply tester to belt at a point midway between two pulleys so that edge of contact surface ② is flush with the V-belt
- Slowly depress pad ③ until the spring can be heard to disengage. This will cause the indicator to move upwards



If pressure is maintained after the spring has disengaged a false reading will be obtained!



### Reading of tension

- Read of the tensioning force of the belt at the point where the top surface of the indicator arm ① intersects with the scale
- Before taking readings make ensure that the indicator arm remains in its position

If the value measured deviates from the setting value specified, the V-belt tension must be corrected.


Tension force in cold condition according to kg scale on tester				
Drive belt width		10.0	13.0	2-AVX13
New installation	Installation	45–50	50–55	100–110
	After 10 min. running time	35–40	40–45	80–90
When servicing after long running time		30	35	
Minimum tension force				50
Retensioning value after minimum tension force is reached				70

### Tensioning and changing V-belt

#### Crankshaft – Water pump – Alternator

- Remove fixing bolts ①
- Remove lock-nut ②
- Adjust nut ③ until V-belts have correct tensions
- Retighten lock-nut and fixing bolts


To change the V-belt, turn back the setting nut ③ and swivel the alternator inwards.



#### Water pump – Alternator

- Remove fixing bolts ①
- Remove lock-nut ②
- Adjust nut ③ until V-belts have correct tensions
- Retighten lock-nut and fixing bolts


To change the V-belts, remove the fan, turn back the setting nut ③ and swivel the alternator inwards.



## Fan – Tension pulley

- Remove fixing bolts ①
- Remove lock-nut ②
- Adjust nut ③ until V-belts have correct tensions
- Retighten lock-nut and fixing bolts

To change the V-belts, remove the fan, turn back the setting nut ③ and swivel the tension pulley inwards.




## Fan – Tension pulley

### Automatic tensioner

To change the V-belts, remove the fan.

- Turn back the setting screw (arrowed) until load is removed from the tension spring and slide the V-belts over the tension pulley
- After changing the V-belts, retighten the setting screw as far as it will go




### Ribbed V-belts

#### Checking condition

- Check ribbed V-belts (poly-V-belts) for cracks, fouling by oil, overheating and wear
- Replace damaged ribbed V-belts


#### Checking tension

- Attach setting gauge ① over bolt heads of spring mounting. The pretension on the automatic belt tensioner is correct when the setting gauge can be attached over the bolt heads
- Tension ribbed V-belt if necessary



#### Tensioning ribbed V-belt

- Grip tensioning element with wrench at hexagon ① **firmly** and release mounting bolts ②
- Increase spring pretension at hexagon with wrench until the setting gauge can be fitted over the bolt heads ③ ( $A = 91,5 \pm 1$  mm)
- Tighten down mounting bolts to 35 Nm
- It must be possible to detach the setting gauge without the use of force



#### Replacing ribbed V-belt

- Remove fan
- Grip tensioning element with wrench at hexagon ① **firmly** and release mounting bolts ②
- Relieve tension on ribbed V-belt **slowly** and remove
- Fit a new ribbed V-belt
- Tension ribbed V-belt



#### Note:

To avoid damaging the damper unit, it is important that the damper be released and tensioned slowly. Do not under any circumstances allow the damper to bounce back as this would damage the damper. Check the damper for oil leaks while it is released.

### Turbocharger

At every engine oil change check the oil pipes for leaks and constrictions.

Furthermore, a regular check should be kept on charge air and exhaust gas pipes. Any leakages should be attended to at once because they are liable to cause overheating of the engine.

### Intercooler

If the coolant output is to be retained as far as possible, the intercooler must be cleaned at certain intervals.

### Starter motor

Check that the electric cables are properly fastened and that contacts and plug connections are secure.

In engines fitted with electronic speed pickups at the flywheel (e.g. electronic speed governor and EDC), the speed pickup are to be cleaned too and metal chips that may adhere are to be removed.

**Note:**

Always disconnect the battery earth cable before starting work on the electrical system. Connect up the earth cable last, as there is otherwise a risk of short-circuits.

### Temporary decommissioning of engines

Temporary anti-corrosion protection according to MAN works norm M 3069 is required for engines which are to be put out of service for fairly long periods.

The works norm can be obtained from our After-Sales Service department Nuremberg works.



## Technical data

Model	<b>D 2876 LE 101 / 103 / 104 / 105</b>
Design	in-line vertical
Cycle	4-stroke Diesel with turbocharger and intercooler
Combustion system	Direct injection
Turbocharging	Turbocharger with intercooler
Number of cylinders	6
Bore	128 mm
Stroke	166 mm
Swept volume	12 816 cm <sup>3</sup>
Compression ratio	19 : 1
Rating	
D 2876 LE 101	309 kW / 420 hp at 1700–2000 rpm
D 2876 LE 103	338 kW / 460 hp at 1700–2000 rpm
D 2876 LE 104	265 kW / 360 hp at 1700–2000 rpm
D 2876 LE 105	375 kW / 510 hp at 2000 rpm
Firing order	1–5–3–6–2–4
Valve clearance (cold engine)	
Intake	0.50 mm
Exhaust	0.60 mm
Valve timing	
Intake opens	23° before TDC
Intake closes	12° after BDC
Exhaust opens	60° before BDC
Exhaust closes	30° after TDC
Fuel system	
Injection pump	In-line injection pump with automatic adjustment of start of injection
Governor	Electronically controlled diesel injection
D 2876 LE 101 / 103 / 104	EDC MS5/5.32
D 2876 LE 105	EDC MS 6.1
Start of delivery	4–1° before TDC
Injectors	7-orifice nozzles
Opening pressure of injector:	
New nozzle holder:	320+8 bar
Used nozzle holder:	300+8 bar



## Technical data



Engine lubrication	Force feed
Oil capacity in oil sump (litres)	min.    max.
deep	24 l    30 l
shallow	24 l    30 l
with yoke	33 l    39 l
Oil change quantity (with filter)	
deep / shallow	33 l
with yoke	42 l
Oil pressure during operation (depending on oil temperature, oil viscosity class and engine rpm)	must be monitored by oil pressure monitors / gauges
Oil filter	Full flow filter with paper cartridges
Engine cooling system	Liquid cooling
Coolant temperature	80–90°C, temporarily 95°C allowed
Electrical equipment	
Starter	24 V; 5,4 or 6,5 kW
Alternator	28 V; 55, 80, 100, 140 A



## Maintenance chart

<b>ALWAYS COMPLY WITH SAFETY REGULATIONS !</b>									
<b>Maintenance cycles in hours of operation</b>	<b>Maintenance jobs</b>								
Daily	K								
20	A		C				I	J	
400	A		C	D	E		I	J	
800	A		C		E		I	J	
1200	A1		C				I	J	
1600	A		C		E		I	J	
2000	A		C				I	J	
2400	A1		C		E		I1	J	
2800	A		C				I	J	
3200	A		C		E		I	J	
3600	A1		C				I	J	
4000	A		C		E		I	J	
4400	A		C				I	J	
4800	A1		C		E		I1	J	
5200	A		C				I	J	
5600	A		C		E		I	J	
6000	A1		C				I	J	
6400	A	B	C		E		I	J	
6800	A		C				I	J	
7200	A1		C		E		I1	J	
7600	A		C				I	J	
8000	A		C		E		I	J	
8400	A1		C				I	J	
8800	A		C		E		I	J	
9200	A		C				I	J	
9600	A1		C		E		I1	J	
10000	A		C				I	J	
10400	A		C		E		I	J	
10800	A1		C				I	J	
11200	A		C		E		I	J	
11600	A		C				I	J	
12000	A1		C		E		I1	J	
12400	A		C				I	J	
12800	A	B	C		E	F	I	J	
13200	A1		C				I	J	
13600	A		C		E		I	J	
14000	A		C				I	J	
14400	A1		C		E		I1	J	
14800	A		C				I	J	
15200	A		C		E		I	J	
15600	A1		C				I	J	
16000	A		C		E		I	J	

## Maintenance chart



A	Clean water separator / pre-filter
A1	Change fuel filter, clean water separator, clean pre-filter
B	Check injection nozzles, compression pressure, renewing if required
C	<ul style="list-style-type: none"> <li>● Change oil and oil filter, check that components are tight</li> <li>● Check V-belts for damage, tighten up or change</li> </ul>
D	Tighten cylinder head bolts
E	<ul style="list-style-type: none"> <li>● Check and if necessary adjust valve clearance</li> <li>● Check connection elements (bolts, clamps etc.) and tighten if necessary</li> </ul>
F	Renew axial face seal and bearing on water pump
I	Clean air filter and change filter cartridge, reset maintenance indicator (even earlier depending on accumulation of dust)
I1	Change air filter / filter cartridge
J	Check concentration of coolant, correcting if necessary
K	<ul style="list-style-type: none"> <li>● Check oil level</li> <li>● Check coolant level</li> <li>● Check maintenance display on air filter</li> <li>● Check water separator (if there is one)</li> <li>● Check regarding pending EDC errors</li> <li>● Visual check for exterior damage, stone impact, leakages</li> </ul>
Every 4 years regardless of operating hours	
	<ul style="list-style-type: none"> <li>● Renew coolant</li> <li>● Replace radiator cap (filler valve, service valve)</li> </ul>

The prescribed maintenance intervals presuppose the use of engine oil as per MAN works norms M3277!



**Note:**

The troubleshooting chart applies to engines with EDC MS5/5.32.  
For engines with EDC MS 6.1, not all points are applicable (EDC-specific).

1.	EDC self-diagnosis or flash code output			
2.	Starter turns over engine only slowly or not at all			
3.	Starter turns, engine does not start, engine does not start / difficult to start when cold			
4.	Engine stalls (dies) during operation, no longer starts (starter turns), engine does not start / starts with difficulty when hot			
5.	Sudden, temporary engine shut-down, engine does not reach full revs			
6.	Engine only runs at idle speed, no throttle response			
7.	Engine only runs at increased idle speed, no throttle response			
8.	Rated engine speed distinctly reduced (even under no load)			
9.	Reduced output in all ranges			
10.	Irregular engine operation, traction loss			
11.	Unstable idle speed, engine hunting, misfiring, knocking in engine			
12.	Engine judder			
13.	Unusual combustion noise			
14.	Excessive smoke emission: White smoke / blue smoke			
15.	Excessive smoke emission: Black smoke			
16.	Engine temperature too high (coolant loss)			
17.	Intermediate engine speed control cannot be activated / does not switch off, engine revs too high			
18.	Fuel consumption too high			
19.	Lubricating oil pressure too low			
20.	Lubricating oil pressure too high			
21.	Lubricating oil consumption too high			
22.	Engine too loud / mechanical noise			
				<b>Possible causes</b>
x	x			Batteries discharged, battery lead connections loose or corroded, break in power circuit
x				Crank gear blocked
x	x			Starter solenoid switch sticks (clicks) / defective, cable connection loose or damaged
x	x			Starter / starter interlock relay defective (carbon brushes worked loose / worn, winding defective, short to ground)
x			x x x	Engine oil viscosity unsuitable, not suitable for ambient temperature, lubricating oil quality does not correspond to specifications
x		x		Oil level in sump too high
x			x	Oil level in sump too low, oil in sump too thin (mixed with condensate or fuel)
			x	Engine temperature too high
			x	Oil filter clogged
			x x	Oil pressure gauge faulty
			x	Safety valve in oil circuit defective (does not close, spring fatigued or broken)
			x	Bearing wear
			x	Oil pump gears worn
			x	Crankshaft timing gears worn, tooth flank backlash too great
	x	x	x	Engine cold
		x		Lubricating oil entering combustion chamber (piston rings worn, piston rings broken) – valve stem guide worn – overpressure in crankcase (crankcase vent clogged)
			x	Relief valve in oil circuit faulty (does not open), oil lines / oil galleries clogged
			x	Leaks in lubricating oil circuit, particularly at turbocharger and oil cooler
	x	o	x	Piston rings heavily worn, broken
	x		x	Piston pin or crankshaft bearing loose
		o	x	Valve stems worn, bent
x	x		x	Valve clearance not correct
x	x			Valves jam

x = Probable  
o = Possible

# Troubleshooting chart



1.	EDC self-diagnosis or flash code output								
2.	Starter turns over engine only slowly or not at all								
3.	Starter turns, engine does not start, engine does not start / difficult to start when cold								
4.	Engine stalls (dies) during operation, no longer starts (starter turns), engine does not start / starts with difficulty when hot								
5.	Sudden, temporary engine shut-down, engine does not reach full revs								
6.	Engine only runs at idle speed, no throttle response								
7.	Engine only runs at increased idle speed, no throttle response								
8.	Rated engine speed distinctly reduced (even under no load)								
9.	Reduced output in all ranges								
10.	Irregular engine operation, traction loss								
11.	Unstable idle speed, engine hunting, misfiring, knocking in engine								
12.	Engine judder								
13.	Unusual combustion noise								
14.	Excessive smoke emission: White smoke / blue smoke								
15.	Excessive smoke emission: Black smoke								
16.	Engine temperature too high (coolant loss)								
17.	Intermediate engine speed control cannot be activated / does not switch off, engine revs too high								
18.	Fuel consumption too high								
19.	Lubricating oil pressure too low								
20.	Lubricating oil pressure too high								
21.	Lubricating oil consumption too high								
22.	Engine too loud / mechanical noise								
						<b>Possible causes</b>			
	x	x		x	x	Compression deficient, or more than 3–4 bar pressure difference between individual cylinders			
	x			x	x	Valve seats leaking			
	o	x			x	Increased power consumption due to faulty secondary consumers such as hydraulic pumps, fan etc., power take-off engaged			
		x	x		x	x	Air cleaner soiled or clogged, charge-air system leaking, air inlet / exhaust lines clogged / leaking		
	x	x	x	x	x	x	Fuel low pressure system: fuel tank, prefilter, water trap faulty / clogged / mould / fungal attack, fuel unsuitable / heavily contaminated (paraffin added)		
	x	x	x		x	x	Fuel low pressure system: Fuel lines leaking, broken, clogged		
	x	x	x		x	x	Fuel low pressure system: AIR in the system (turn on ignition when bleeding the system)		
	x	x	x		x	x	Fuel low pressure system: delivery pump, overflow valve, main filter		
	x			x	x	x	o	x	Fuel high pressure system: nozzles faulty / clogged / leaking / coked
				x	x	x	o	Fuel high pressure system: pressure lines – constriction, cavitation, leaking	
	x			x	o	x	x	o	Fuel high pressure system: injection pump worn / incorrectly set
				o	x	o	o	Fuel high pressure system: injection pump constant-pressure control valve / return flow constrictor faulty	
	x	x	x		o	x		Safety relay defective, drive faulty	
	o	o		o	x	o	x	x	Injection pump / engine synchronisation: start of delivery incorrect (basic installation), start of delivery set incorrectly
x	x	x	x		o	x	o		Injection pump controller: stiff movement – fuel volume regulator (control deviation)
x	x	x	x		o				Control rod position sensor in regulator: connection lines, break, short-circuit
	o				o			o	Control rod position sensor in regulator: set incorrectly
x	x	o							Control rod position sensor in regulator: capacitance reserve of the wiring harness too low (e.g. water penetrated wiring harness)
				x	o	x	o	o	Injection pump: fuel volume set incorrectly / uniform delivery, lower idle speed set too low
x	o	x	x					x	Fuel volume actuating solenoid in regulator: connection lines, break, short-circuit
x			x		o	o	o		CAN control system has failed / is defective: Connection lines, short-circuit, break
x									EDC rpm sensor defective, implausible with auxiliary rpm sensor, line defective
					x	o			EDC rpm sensor, polarity reversed
x									EDC auxiliary rpm sensor defective, implausible with rpm sensor, line defective
x	x	x	x	o		o	o	o	EDC detects incorrect engine speed (interference signal on rpm sensor line)
x	x	x	x			o			Both rpm sensors faulty, line fault

x = Probable  
o = Possible



# Troubleshooting chart

1. EDC self-diagnosis or flash code output										
2. Starter turns over engine only slowly or not at all										
3. Starter turns, engine does not start, engine does not start / difficult to start when cold										
4. Engine stalls (dies) during operation, no longer starts (starter turns), engine does not start / starts with difficulty when hot										
5. Sudden, temporary engine shut-down, engine does not reach full revs										
6. Engine only runs at idle speed, no throttle response										
7. Engine only runs at increased idle speed, no throttle response										
8. Rated engine speed distinctly reduced (even under no load)										
9. Reduced output in all ranges										
10. Irregular engine operation, traction loss										
11. Unstable idle speed, engine hunting, misfiring, knocking in engine										
12. Engine judder										
13. Unusual combustion noise										
14. Excessive smoke emission: White smoke / blue smoke										
15. Excessive smoke emission: Black smoke										
16. Engine temperature too high (coolant loss)										
17. Intermediate engine speed control cannot be activated / does not switch off, engine revs too high										
18. Fuel consumption too high										
19. Lubricating oil pressure too low										
20. Lubricating oil pressure too high										
21. Lubricating oil consumption too high										
22. Engine too loud / mechanical noise										
				<b>Possible causes</b>						
x		x		EDC boost pressure sensor: faulty, incorrect, implausible with atmospheric pressure sensor, line fault						
		x	x	o	x	Exhaust turbocharger leaking or faulty				
					x	Turbine and compressor rotor in turbocharger dirty (out-of-balance, irregular running)				
		x			x	Intercooler leaking, faulty				
	x				x	Flame starting system defective				
x	o		x	o		EDC coolant temperature sensor: faulty, line fault				
x			x	o		EDC charge-air temperature sensor: faulty, line fault				
o			x			Radiator dirty or cooling system failure (temperatures too high)				
	x				x	Coolant level too low, air in coolant circuit				
					x	V-belt for water pump drive not tensioned correctly				
					x	Incorrect V-belt tension				
					x	Water pump leaking, faulty / thermostat faulty, does not open				
					x	Coolant lines leaking, clogged or twisted				
					x	Coolant entering combustion chamber (cylinder head / gasket leaking)				
				x		Resistor bank EDC control unit pin 51				
x	x	x	o		o	Power supply to control unit interrupted or battery voltage too low / Relay K1 faulty				
	x	x	o		o	Line terminal 15 to EDC control unit (pin 47) interrupted / loose contact				
						x	Line defective: Pin 23 or 41			
x	o	o	o			EDC control unit faulty (internal fault)				
	x		o	x	x	o	o	o	x	Incorrect EDC control unit (check MAN part number)
				x	x				o	Incorrect intermediate speed switched on
				x						EOL programming terminated / voltage interrupt
x										Afterrunning not completed (e.g. shutdown via EMERGENCY STOP)
									x	EOL programming: configuration incorrect
								x		Engine bearings worn

x = Probable  
o = Possible



---

A series of horizontal dotted lines for writing notes.

---

<b>B</b>		<b>M</b>	
Bleeding the fuel system	23, 24	Maintenance and care	18–29
		Maintenance chart	34–35
<b>C</b>		<b>N</b>	
Changing oil filter	20, 21	Nameplates	9
Checking oil level	15	<b>O</b>	
Cleaning fuel pre-cleaner	22, 24	Operation monitoring system	17
Commissioning	15	<b>R</b>	
Commissioning and operation	14–17	Refilling with oil	18, 19
Cooling system	25–26	Ribbed V-belts	30–31
<b>D</b>		<b>S</b>	
Declaration	8	Safety regulations	10–13
Draining the cooling system	25	Handling used engine oil	13
<b>F</b>		Preventing accidents with injury to persons	10
Fill / bleed the cooling system	26	Preventing damage to engine and premature wear	12
Filling with engine oil	14	Preventing environmental damage	12
Filling with fuel	14	Shutting down	17
Filling-in of coolant	14	Starter motor	31
First commissioning	14	Starting	16
Fuel filter	23	<b>T</b>	
Changing fuel filter	23, 24	Technical data	32–33
Draining moisture	23	Temporary decommissioning of engines	31
Fuel service center	24	Troubleshooting chart	36–38
Fuel system	22–24	Turbocharger	31
<b>I</b>		<b>V</b>	
Injection pump	22	V-belts	27–29
Instructions	6		
Intercooler	31		
<b>L</b>			
Lubrication system	18–21		







MAN Nutzfahrzeuge AG  
Geschäftseinheit Motoren  
Vogelweiherstraße 33  
D-90441 Nürnberg

**Ein Unternehmen der MAN Gruppe**

Printed in Germany

51.99493-8565