

SHOP MANUAL

KOMATSU

PC05-6, PC07-1 PC10-6, PC15-2

MACHINE MODEL	SERIAL No.
PC05-6	11301 and up
PC07-1	10001 and up
PC10-6	10501 and up
PC15-2	10001 and up

This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

CONTENTS

	No. of page
10 STRUCTURE AND FUNCTION	10-1
20 TESTING AND ADJUSTING	20-1
30 DISASSEMBLY AND ASSEMBLY	30-1
40 MAINTENANCE STANDARD	40-1

020M06

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	00-1	④	●	10-25	④		10-65	②		20-27	③		30-20	③
	00-2	①		10-26	②		10-67	②		20-28	③		30-21	③
●	00-2-1	④	●	10-27	④		10-68	②		20-29	③		30-22	③
	00-2-2	③		10-28	②		10-69	②		20-30	③		30-23	③
	00-3			10-29	②		10-70	②		20-31	③		30-24	③
	00-4			10-30	②		10-71	②		20-32	③		30-25	③
	00-5			10-31	②		10-72	②		20-33	③		30-26	③
	00-6			10-32	②		10-73	②		20-34	③		30-27	③
	00-7			10-33	②		10-74	②		20-35	③		30-28	③
	00-8			10-34	②		10-75	②		20-36	③		30-29	③
	00-9			10-36	②		10-76	②		20-38	③		30-30	③
	00-10			10-37	②					20-39	③		30-31	③
	00-12	②		10-38	②		20-1	③		20-40	③		30-32	③
	00-13	②		10-39	②		20-2	③		20-41	③		30-33	③
	00-14	②		10-40	②		20-3	③		20-42	③		30-34	③
				10-42	②		20-4	③		20-43	③		30-35	③
	10-1	②		10-43	②		20-5	③		20-44	③		30-36	③
	10-2	②		10-44	②		20-6	③		20-45	③		30-37	③
	10-3	②		10-45	②		20-7	③					30-38	③
	10-4	②		10-46	②		20-8	③		30-1	③		30-39	③
	10-6	②		10-47	②		20-9	③		30-2	③		30-40	③
	10-7	②		10-48	②		20-10	③		30-3	③		30-41	③
	10-8	②		10-49	②		20-11	③		30-4	③		30-42	③
	10-9	②		10-50	②		20-12	③		30-5	③		30-43	③
	10-10	②		10-51	②		20-13	③		30-6	③		30-44	③
	10-11	②		10-52	②		20-14	③		30-7	③		30-45	③
	10-12	②		10-53	②		20-15	③		30-8	③		30-46	③
	10-13	②		10-54	②		20-16	③		30-9	③		30-47	③
	10-15	②		10-55	②		20-17	③		30-10	③		30-48	③
	10-16	②		10-56	②		20-18	③		30-11	③		30-49	③
	10-17	②		10-57	②		20-19	③		30-12	③		30-50	③
	10-18	②		10-58	②		20-20	③		30-13	③		30-51	③
	10-19	②		10-59	②		20-21	③		30-14	③		30-52	③
●	10-20	④		10-60	②		20-22	③		30-15	③		30-53	③
●	10-21	④		10-61	②		20-23	③		30-16	③		30-54	③
●	10-22	④		10-62	②		20-24	③		30-17	③		30-55	③
	10-23	②		10-63	②		20-25	③		30-18	③		30-56	③
	10-24	②		10-64	②		20-26	③		30-19	③		30-57	③

020M06



Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
○	30-58	③	40-36		②									
○	30-59	③	40-37		②									
○	30-60	③	40-38		②									
○	30-61	③	40-39		②									
○	30-62	③	40-40		②									
○	30-63	③	40-41		②									
○	30-64	③	40-42		②									
○	30-65	③	40-43		②									
○	30-66	③	40-44		②									
○	30-67	③	40-45		②									
○	30-68	③												
○	30-69	③												
○	30-70	③												
○	30-71	③												
○	30-72	③												
○	30-73	③												
○	30-74	③												
○	30-75	③												
	40-1	②												
	40-2	②												
	40-3	②												
	40-4	②												
	40-5	②												
	40-6	②												
	40-7	②												
	40-8	②												
	40-9	②												
	40-10	②												
	40-11	②												
	40-12	②												
	40-13	②												
	40-14	②												
	40-15	②												
	40-16	②												
	40-17	②												
	40-18	②												
	40-19	②												
	40-20	②												
	40-22	②												
	40-23	②												
	40-24	②												
	40-25	②												
	40-26	②												
	40-27	②												
	40-28	②												
	40-29	②												
	40-30	②												
	40-31	②												
	40-32	②												
	40-33	②												
	40-34	②												

020M06



IMPORTANT SAFETY NOTICE

Proper service and repair is extremely important for the safe operation of your machine. The service and repair techniques recommended by Komatsu and described in this manual are both effective and safe methods of operation. Some of these operations require the use of tools specially designed by Komatsu for the purpose.

To prevent injury to workers, the symbols  and  are used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.

SAFETY

GENERAL PRECAUTIONS

Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully BEFORE operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions given on the decals which are fixed to the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR signs on the controls in the operator's compartment.
5. Keep all tools in good condition and learn the correct way to use them.

6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.

PREPARATIONS FOR WORK

7. Before adding oil or making any repairs, park the machine on hard, level ground, and block the wheels or tracks to prevent the machine from moving.
8. Before starting work, lower blade, ripper, bucket or any other work equipment to the ground. If this is not possible, insert the safety pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.
9. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out.
Before disconnecting or removing components of the oil, water or air circuits, first remove the pressure completely from the circuit.
12. The water and oil in the circuits are hot when the engine is stopped, so be careful not to get burned.
Wait for the oil and water to cool before carrying out any work on the oil or water circuits.
13. Before starting work, remove the leads from the battery. Always remove the lead from the negative (–) terminal first.
14. When raising heavy components, use a hoist or crane.
Check that the wire rope, chains and hooks are free from damage.
Always use lifting equipment which has ample capacity.
Install the lifting equipment at the correct places. Use a hoist or crane and operate slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
15. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.
16. When removing components, be careful not to break or damage the wiring. Damaged wiring may cause electrical fires.
17. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips on to the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip, or can even start fires.
18. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.
19. Be sure to assemble all parts again in their original places.
Replace any damaged parts with new parts.
 - When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.
20. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also, check that connecting parts are correctly installed.
21. When assembling or installing parts, always use the specified tightening torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
22. When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
23. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurements.
24. Take care when removing or installing the tracks of track-type machines.
When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.

FOREWORD

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into chapters for each main group of components; these chapters are further divided into the following sections.

STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Troubleshooting charts correlating "Problems" to "Causes" are also included in this section.

DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

NOTICE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your KOMATSU distributor for the latest information.

HOW TO READ THE SHOP MANUAL

VOLUMES

Shop manuals are issued as a guide to carrying out repairs. They are divided as follows:

- Chassis volume:** Issued for every machine model
- Engine volume:** Issued for each engine series
- Electrical volume :** Each issued as one volume to cover all models
- Attachments volume :** Each issued as one volume to cover all models


These various volumes are designed to avoid duplicating the same information. Therefore to deal with all repairs for any model, it is necessary that chassis, engine, electrical and attachment volumes are ready.

DISTRIBUTION AND UPDATING


Any additions, amendments or other changes will be sent to KOMATSU distributors. Get the most up-to-date information before you start any work.

FILING METHOD


1. See the page number on the bottom of the page. File the pages in correct order.
2. Following examples shows how to read the page number.
Example 1 (Chassis volume):



Example 2 (Engine volume):



3. Additional pages: Additional pages are indicated by a hyphen (-) and number after the page number. File as in the example.
Example:



REVISED EDITION MARK (①②③.....)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

REVISIONS


Revised pages are shown at the LIST OF REVISED PAGES on the between the title page and SAFETY page.

SYMBOLS

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing the work.
		Extra special safety precautions are necessary when performing the work because it is under internal pressure.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.
	Weight	Weight of parts or systems. Caution necessary when selecting hoisting wire, or when working posture is important, etc.
	Tightening torque	Places that require special attention for the tightening torque during assembly.
	Coat	Places to be coated with adhesives and lubricants etc.
	Oil, water	Places where oil, water or fuel must be added, and the capacity.
	Drain	Places where oil or water must be drained, and quantity to be drained.

HOISTING INSTRUCTIONS



⚠ Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is indicated clearly with the symbol kg

1. If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:
 - Check for removal of all bolts fastening the part to the relative parts.
 - Check for existence of another part causing interference with the part to be removed.

2. Wire ropes


- 1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

Wire ropes (Standard "Z" or "S" twist ropes without galvanizing)	
Rope diameter (mm)	Allowable load (tons)
10	1.0
11.2	1.4
12.5	1.6
14	2.2
16	2.8
18	3.6
20	4.4
22.4	5.6
30	10.0
40	18.0
50	28.0
60	40.0

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.

- 2) Sling wire ropes from the middle portion of the hook.

Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result. Hooks have maximum strength at the middle portion.



FS0064


- 3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.

⚠ Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

- 4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.

When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.





FS0065



STANDARD TIGHTENING TORQUE

1. STANDARD TIGHTENING TORQUE OF BOLTS AND NUTS

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in sections of "Disassembly and Assembly".

Thread diameter of bolt (mm)	Width across flat (mm)		
		kgm	Nm
6	10	1.35±0.15	13.2±1.4
8	13	3.2±0.3	31.4±2.9
10	17	6.7±0.7	65.7±6.8
12	19	11.5±1.0	112±9.8
14	22	18.0±2.0	177±19
16	24	28.5±3	279±29
18	27	39±4	383±39
20	30	56±6	549±58
22	32	76±8	745±78
24	36	94.5±10	927±98
27	41	135±15	1320±140
30	46	175±20	1720±190
33	50	225±25	2210±240
36	55	280±30	2750±290
39	60	335±35	3280±340

This torque table does not apply to the bolts with which nylon packings or other non-ferrous metal washers are to be used, or which require tightening to otherwise specified torque.

★ Nm (newton meter): 1Nm \approx 0.1 kgm

2. TIGHTENING TORQUE OF SPLIT FLANGE BOLTS


Use these torques for split flange bolts.

Thread diameter of bolt (mm)	Width across flats (mm)	Tightening torque	
		kgm	Nm
10	14	6.7±0.7	65.7±6.8
12	17	11.5±1	112±9.8
16	22	28.5±3	279±29

STANDARD TIGHTENING TORQUE

3. TIGHTENING TORQUE FOR NUTS OF FLARED

Use these torques for nut part of flared.



FS0068

Thread diameter of nut part (mm)	Width across flats of nut part (mm)	Tightening torque	
		kgm	Nm
14	19	2.5±0.5	24.5±4.9
18	24	5±2	49±19.6
22	27	8±2	78.5±19.6
24	32	14±3	137.3±29.4
30	36	18±3	176.5±29.4
33	41	20±5	196.1±49
36	46	25±5	245.2±49
42	55	30±5	294.2±49

COATING MATERIALS



The recommended coating materials prescribed in Komatsu Shop Manuals are listed below.

Nomenclature	Komatsu code	Applications
Adhesives	LT-1A	Used to apply rubber pads, rubber gaskets, and cork plugs.
	LT-1B	Used to apply resin, rubber, metallic and non-metallic parts when a fast, strong seal is needed.
	LT-2*	Preventing bolts, nuts and plugs from loosening and leaking oil.
	LT-3	Provides an airtight, electrically insulating seal. Used for aluminum surfaces.
Gasket sealant	LG-1	Used with gaskets and packings to increase sealing effect.
	LG-3	Heat-resistant gasket for precombustion chambers and exhaust piping.
	LG-4	Used by itself on mounting surfaces on the final drive and transmission cases. (Thickness after tightening: 0.07 – 0.08 mm)
	LG-5	Used by itself to seal grease fittings, tapered screw fittings and tapered screw fittings in hydraulic circuits of less than 50 mm in diameter.
Antifriction compound (Lubricant including molybdenum disulfide)	LM-P	Applied to bearings and taper shafts to facilitate press-fitting and to prevent sticking, burning or rusting.
Grease (Lithium grease)	G2-LI	Applied to bearings, sliding parts and oil seals for lubrication, rust prevention and facilitation of assembling work.
Vaseline	—	Used for protecting battery electrode terminals from corrosion.

*LT-2 is also called LOCTITE in the shop manuals.



ELECTRIC WIRE CODE

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires. This wire code table will help you understand WIRING DIAGRAMS.

Example: 05WB indicates a cable having a nominal number 05 and white coating with black stripe.


CLASSIFICATION BY THICKNESS

Nominal number	Copper wire			Cable O.D. (mm)	Current rating (A)	Applicable circuit
	Number strands	Dia. of strands (mm)	Cross section (mm ²)			
01	11	0.32	0.88	2.4	12	Starting, lighting, signal etc.
02	26	0.32	2.09	3.1	20	Lighting, signal etc.
05	65	0.32	5.23	4.6	37	Charging and signal
15	84	0.45	13.36	7.0	59	Starting (Glow plug)
40	85	0.80	42.73	11.4	135	Starting
60	127	0.80	63.84	13.6	178	Starting
100	217	0.80	109.1	17.6	230	Starting

CLASSIFICATION BY COLOR AND CODE

Priority	Circuits		Starting	Charging	Lighting	Signal	Instrument	Other
	Classification							
1	Primary	Code	B	W	R	G	Y	L
		Color	Black	White	Red	Green	Yellow	Blue
2	Auxiliary	Code	BW	WR	RW	GW	YR	LW
		Color	Black & White	White & Red	Red & White	Green & White	Yellow & Red	Blue & White
Code		BY	WB	RB	GR	YB	LR	
Color		Black & Yellow	White & Black	Red & Black	Green & Red	Yellow & Black	Blue & Red	
Code		BR	WL	RY	GY	YG	LY	
Color		Black & Red	White & Blue	Red & Yellow	Green & Yellow	Yellow & Green	Blue & Yellow	
Code		—	WY	RG	GB	YL	LB	
Color		—	White & Yellow	Red & Green	Green & Black	Yellow & Blue	Blue & Black	
Code		—	WG	RL	GL	YW		
Color		—	White & Green	Red & Blue	Green & Blue	Yellow & White		

WEIGHT TABLE

 This weight table is a guide for use when transporting or handling components.

Unit: kg

Machine model	PC05-6		PC07-1	PC10-6	PC15-2
	Serial No.	11301–11700	11701 and up	10001 and up	10501 and up
Engine assembly	123	123	123	159	184
·Engine	110	110	110	130	155
·Engine mount	—	—	—	12	12
·PTO	7.5	7.5	7.5	9	9
·Hydraulic pump	5.3	5.3	5.3	7.7	7.7
Radiator assembly	4.2	4.2	4.2	6.6	7.3
Revolving frame	130	200	262	338	478
Canopy	21.5	21.5	21.5	23	23
Operator's cab	—	—	—	155	155
Operator's seat	7.5	7.5	7.5	10	10
Fuel tank	11	11	11	17	17
Hydraulic tank	20	20	20	34	34
1-spool control valve	4.3	4.3	—	—	—
2-spool control valve	—	—	—	6	6
5-spool control valve	—	—	—	14.5	14.5
6-spool control valve	—	—	—	16	16
7-spool control valve	16	16	16	—	—
8-spool control valve	—	18.5	18.5	—	—
Swing-boom swing selector valve					
Swing circle assembly	18	19	19	38.4	38.4
Swing motor assembly	13.5	13.5	13.5	17	28
Center swivel joint	7.5	7.5	7.5	7.5	7.5

020M06

Unit: kg

Machine model	PC05-6		PC07-1	PC10-6	PC15-2
Serial No.	11301—11700	11701 and up	10001 and up	10501 and up	10001 and up
Track frame assembly	257	184	187	359	398
· Track frame	90.5	90.5	93	223	262
· Idler	7.5 x 2	7.5 x 2	7.5 x 2	20 x 2	20 x 2
· Idler cushion	7 x 2	7 x 2	7 x 2	11 x 2	11 x 2
· Track roller	3.5 x 6	3.5 x 6	3.5 x 6	6 x 6	6 x 6
· Sprocket	5.5 x 2	5.5 x 2	5.5 x 2	8 x 2	8 x 2
Travel motor assembly	15 x 2	15 x 2	15 x 2	30 x 2	30 x 2
Track shoe assembly					
· Track shoe	70 x 2	78.5 x 2	78.5 x 2	136 x 2	157 x 2
· Track shoe with rubber	100 x 2	—	—	—	—
· Rubber shoe	43 x 2	57 x 2	57 x 2	112 x 2	112 x 2
Boom swing bracket assembly	14.5	14.5	15.5	37	41
Boom assembly	38.4	38.4	39	73	88
Arm assembly	19.4	19.4	23.2	40	40
Bucket assembly	19	24.3	26.4	45	45
Blade assembly	30.4	39.5	40	108	109
Boom cylinder assembly	10	10	10.7	18.5	20
Arm cylinder assembly	9	9	10.1	18.2	17
Bucket cylinder assembly	8.5	8.5	8.5	14.5	14.5
Boom swing cylinder assembly	8	8	8	18.5	18.5
Blade cylinder assembly	6.3	6.5	6.5	9.8	9.8

020M06

LIST OF LUBRICANT AND WATER

RESERVOIR	KIND OF FLUID	AMBIENT TEMPERATURE					CAPACITY (ℓ)	
		14 -10	32 0	50 10	68 20	86°F 30°C	Specified	Refill
Engine oil pan	Engine oil	SAE 30					PC05: 3.65	PC05: 3.65
		SAE 10W					PC07: 3.65	PC07: 3.65
					PC10: 3.1	PC10: 3.1		
					PC15: 4.7	PC15: 4.7		
Final drive case (each)							PC05: 0.3	PC05: 0.3
							PC07: 0.3	PC07: 0.3
Track roller (1 piece)		SAE 30					PC10: 0.6	PC10: 0.6
							PC15: 0.6	PC15: 0.6
Idler (1 piece)							0,02	—
Hydraulic tank		SAE 10W					0,02	—
	SAE 10W-30					PC05: 24.8	PC05: 18.3	
						PC07: 25.3	PC07: 18.3	
	SAE 15W-40					PC10: 46	PC10: 29	
Fuel tank	Diesel fuel						PC15: 46	PC15: 29
		ASTM D975 No.2					PC05: 20	—
							PC07: 20	—
Cooling system	Water						PC10: 35	—
		Add antifreeze					PC15: 35	—
							PC05: 3.6	—
					PC07: 3.6	—		
					PC10: 3.7	—		
					PC15: 3.7	—		

※ ASTM D975 No.1

ASTM: American Society of Testing and Material
SAE: Society of Automotive Engineers

Specified capacity: Total amount of oil including oil for components and oil in piping.

Refill capacity: Amount of oil needed to refill system during normal inspection and maintenance.

NOTE:

(1) When fuel sulphur content is less than 0.5%, change oil in the oil pan every periodic maintenance hours described in operation and maintenance manual.
Change oil according to the following table if fuel sulphur content is above 0.5%.

Fuel sulphur content	Change interval of oil in engine oil pan
0.5 to 1.0%	1/2 of regular interval
Above 1.0%	1/4 of regular interval

(2) When starting the engine in an atmospheric temperature of lower than 0°C, be sure to use engine oil of SAE10W, SAE10W-30 and SAE15W-40, even through an atmospheric temperature goes up to 10°C more or less in the day time.

(3) Use API classification CD as engine oil and if API classification CC, reduce the engine oil change interval to half.



10 STRUCTURE AND FUNCTION

Radiator	10- 2
Power train	10- 6
Swing circle	10-10
Track frame and recoil spring	10-12
Hydraulic piping	10-15
Hydraulic circuit diagram	10-20
Hydraulic tank	10-29
Hydraulic pump	10-31
7-spool control valve	10-36
8-spool control valve	10-38
1-spool control valve	10-40
5-spool control valve	10-42
6-spool control valve	10-44
2-spool control valve	10-46
Swing—boom swing selector valve	10-47
Swing motor	10-48
Travel motor	10-50
Center swivel joint	10-54
Hydraulic cylinder	10-56
Valve control	10-67
Work equipment	10-72
Electric circuit diagram	10-74

020M06

RADIATOR

PC05-6, PC07-1



020M06

F20M06001



1. Radiator
2. Cap
3. Radiator inlet hose
4. Radiator outlet hose
5. Drain valve

SPECIFICATIONS

- Type: CD-2
- Fin pitch: 4.0 mm
- Cap
 - Relief set pressure: $0.9 \pm 0.15 \text{ kg/cm}^2$
 - Suction set pressure: 0.05 kg/cm^2
- Capacity: 1.35 l

PC10-6

020M06





20NF06005

1. Radiator
2. Cap
3. Radiator inlet hose
4. Radiator outlet hose
5. Drain valve

SPECIFICATIONS

- Type: CD-2
- Fin pitch: 4.0 mm
- Cap
 - Relief set pressure: $0.9 \pm 0.15 \text{ kg/cm}^2$
 - Suction set pressure: 0.05 kg/cm^2
- Capacity: 1.35 l



020M06

20NF06006



1. Radiator
2. Cap
3. Radiator inlet hose
4. Radiator outlet hose
5. Drain valve
6. Oil cooler (Hydraulic piping)

SPECIFICATIONS

- Type: CD-2
- Fin pitch: 4.0 mm
- Cap
 - Relief set pressure: $0.9 \pm 0.15 \text{ kg/cm}^2$
 - Suction set pressure: 0.05 kg/cm^2
- Capacity: 1.35 ℓ

POWER TRAIN

PC05-6, PC07-1




- | | |
|------------------------|------------------------------------|
| 1. Idler | 6. Hydraulic pump |
| 2. Center swivel joint | 7. Swing-boom swing selector valve |
| 3. Swing motor | 8. 7-spool control valve |
| 4. Travel motor | 9. Swing circle |
| 5. Engine | |


F20M06057

020M06

PC05-6, PC07-1





020M06



20MF06005

- | | |
|------------------------|--------------------------|
| 1. Idler | 5. Engine |
| 2. Center swivel joint | 6. Hydraulic pump |
| 3. Swing motor | 7. 8-spool control valve |
| 4. Travel motor | 8. Swing circle |



PC10-6, PC15-2



F20M06058

- | | |
|--------------------------|------------------------------------|
| 1. Idler | 6. 2-spool control valve |
| 2. 5-spool control valve | 7. Engine |
| 3. Center swivel joint | 8. Hydraulic pump |
| 4. Swing motor | 9. Swing-boom swing selector valve |
| 5. Travel motor | 10. Swing circle |

PC10-6, PC15-2





20NF06007

- | | |
|--------------------------|--------------------------|
| 1. Idler | 6. 2-spool control valve |
| 2. 6-spool control valve | 7. Engine |
| 3. Center swivel joint | 8. Hydraulic pump |
| 4. Swing motor | 9. Swing circle |
| 5. Travel motor | |


020N06

SWING CIRCLE

PC05-6, PC07-1




Section A - A




20MF06006

1. Swing circle outer race
2. Ball bearing
3. Swing circle inner race

PC10-6, PC15-2



020M06



Section A - A



Section B - B

20NF06008

- 1. Swing circle outer race
- 2. Ball bearing
- 3. Swing circle inner race

TRACK FRAME AND RECOIL SPRING

PC05-6, PC07-1




020M06


F20M06002

- 1. Idler
- 2. Track frame
- 3. Sliding plate
- 4. Travel motor
- 5. Sprocket
- 6. Track roller
- 7. Track shoe
- 8. Recoil spring
- 9. Guard

PC10-6, PC15-2



020M06




20NF06009

- | | |
|------------------|------------------|
| 1. Idler | 6. Track roller |
| 2. Track frame | 7. Track shoe |
| 3. Sliding plate | 8. Recoil spring |
| 4. Travel motor | 9. Guard |
| 5. Sprocket | |

HYDRAULIC PIPING

PC05-6, PC07-1




- 1. Bucket cylinder
- 2. Arm cylinder
- 3. Boom cylinder
- 4. Boom swing cylinder
- 5. Oil filter
- 6. Hydraulic pump
- 7. Travel motor
- 8. Swing-boom swing selector valve
- 9. Swing motor
- 10. 7-spool control valve
- 11. Center swivel joint
- 12. Blade cylinder

020M06

F20M06003

★ FOR MACHINE EQUIPPED WITH SWING-BOOM SWING SELECTOR PEDAL, FLOW INCREASING CIRCUIT AND ADDITIONAL CIRCUIT

PC05-6, PC07-1




1. Bucket cylinder
2. Arm cylinder
3. Boom cylinder
4. Boom swing cylinder
5. 1-spool control valve
6. Oil filter
7. Flow increasing pump
8. Hydraulic pump
9. Travel motor
10. Swing-boom swing selector valve
11. Swing motor
12. 7-spool control valve
13. Center swivel joint
14. Blade cylinder

020M06

PC05-6, PC07-1


020M06



- 1. Bucket cylinder
- 2. Arm cylinder
- 3. Boom cylinder
- 4. Boom-swing cylinder
- 5. Hydraulic filter
- 6. Hydraulic pump
- 7. Travel motor
- 8. Swing motor
- 9. 8-spool control valve
- 10. Center swivel joint
- 11. Blade cylinder

20MF06007


PC10-6, PC15-2



- 1. Bucket cylinder
- 2. Arm cylinder
- 3. Boom cylinder
- 4. Boom swing cylinder
- 5. R.H. travel motor
- 6. Strainer
- 7. Swing motor
- 8. 2-spool control valve
- 9. Hydraulic pump
- 10. Swing-boom swing selector valve
- 11. L.H. travel motor
- 12. 5-spool control valve
- 13. Center swivel joint
- 14. Blade cylinder

020M06

PC10-6, PC15-2




- 1. Bucket cylinder
- 2. Arm cylinder
- 3. Boom cylinder
- 4. Boom swing cylinder
- 5. R.H. travel motor
- 6. Strainer
- 7. Swing motor
- 8. 2-spool control valve
- 9. Hydraulic pump
- 10. L.H. travel motor
- 11. 6-spool control valve
- 12. Center swivel joint
- 13. Blade cylinder

020M06

20NF06010


HYDRAULIC CIRCUIT DIAGRAM

PC05-6



020M05


PC05-6



020M06


F20M06006A

PC05-6



020M06


PC07-1



020M06


F20M06005B

PC07-1



020M06


PC10-6



020M06

F20M06060A


PC10-6



020M06


20NF06011-1

PC15-2



F20M06061A

PC15-2




020M06

20NF06012-1

HYDRAULIC TANK

PC05-6, PC07-1




F20M06007

1. Hydraulic filter
2. Hydraulic tank
3. Cover
4. Strainer
5. Suction strainer
6. Drain plug
7. Sight gauge

SPECIFICATIONS

- Tank capacity : 26.5ℓ
- Oil amount : 18.3ℓ



020M06

20NF06013


- 1. Sight gauge
- 2. Hydraulic tank
- 3. Cover
- 4. Safety valve
- 5. Hydraulic filter
- 6. Suction strainer
- 7. Drain plug

SPECIFICATIONS

- Safety valve
 - Set pressure: 1.05 ± 0.2 kg/cm²
- Tank capacity: 46 ℓ
- Oil amount: 29 ℓ

HYDRAULIC PUMP

PC05-6 Serial No. 11301 – 11700



020M06

20MF218


- | | |
|---------------|-----------------|
| 1. Drive gear | 8. Drive gear |
| 2. Bracket | 9. Driven gear |
| 3. Gear case | 10. Coupling |
| 4. Carrier | 11. Driven gear |
| 5. Bracket | 12. Oil seal |
| 6. Gear case | 13. Snap ring |
| 7. Cover | |

SPECIFICATIONS

- Type: LAR 6 + 6
- Theoretical delivery: 6.4 + 6.4 cc/rev.
- Rated flow: 11.9 + 11.9ℓ/min. (at 2,000 rpm)

HYDRAULIC PUMP

PC05-6 Serial No. 11701 and up
PC07-1



F20M06008-1

020M06



- | | |
|---------------|-----------------|
| 1. Drive gear | 8. Drive gear |
| 2. Bracket | 9. Driven gear |
| 3. Gear case | 10. Coupling |
| 4. Carrier | 11. Driven gear |
| 5. Bracket | 12. Oil seal |
| 6. Gear case | 13. Snap ring |
| 7. Cover | |

SPECIFICATIONS

- Type: SBR6+6
- Theoretical delivery: 6.4 + 6.4 cc/rev.
- Rated flow

PC05-6:	11.9 + 11.9 l/min. (at 2,000 rpm)
PC07-1:	14.3 + 14.3 l/min. (at 2,400 rpm)

2. FLOW INCREASING PUMP



Section A - A

F20M06009


020M06

1. Bracket
2. Side plate
3. Drive gear
4. Cover
5. Driven gear

SPECIFICATIONS

- Theoretical discharge: 7.9 cc/rev
- Max. discharge pressure: 175 kg/cm²

PC10-6, PC15-2



20NF06014

020M06


- | | |
|---------------|-----------------|
| 1. Drive gear | 11. Drive gear |
| 2. Bracket | 12. Cover |
| 3. Gear case | 13. Driven gear |
| 4. Carrier | 14. Coupling |
| 5. Bracket | 15. Driven gear |
| 6. Gear case | 16. Coupling |
| 7. Drive gear | 17. Driven gear |
| 8. Carrier | 18. Oil seal |
| 9. Bracket | 19. Snap ring |
| 10. Gear case | |

SPECIFICATIONS

- Type: SBR8+8+6
- Theoretical delivery: 8.5 + 8.5 + 6.4 cc/rev.
- Rated flow: 21 + 21 + 16 ℓ/min.
(at 2,000 rpm)

7-SPOOL CONTROL VALVE


PC05-6, PC07-1




020M06

F20M06010


- | | |
|---|---|
| a. A7 port (To swing-boom swing selector valve) | j. B1 port (To boom cylinder head side) |
| b. A6 port (To arm cylinder bottom side) | k. B2 port (To bucket cylinder bottom side) |
| c. A5 port (To L.H. travel motor B Port) | i. B3 port (To R.H. travel motor B port) |
| d. A4 port (To blade cylinder bottom side) | m. B4 port (To blade cylinder head side) |
| e. A3 port (To R.H. travel motor A port) | n. B5 port (To L.H. travel motor A port) |
| f. A2 port (To bucket cylinder head side) | o. B6 port (To arm cylinder head side) |
| g. A1 port (To boom cylinder bottom side) | p. B7 port (To swing-boom swing selector valve) |
| h. T port (To tank) | q. PL port (From hydraulic pump) |
| i. P _R port (From hydraulic pump) | |




Section A - A




Section B - B



Section C - C



Section D - D



Section E - E


020M06

- | | |
|-----------------------------|--------------------------|
| 1. Check valve spring | 9. Spool (R.H. travel) |
| 2. Check valve | 10. Spool (Bucket) |
| 3. Main relief valve | 11. Spool (Boom) |
| 4. Spool (Swing/Boom swing) | 12. Main relief valve |
| 5. Spool (Arm) | 13. Spool return spring |
| 6. Spool (L.H. travel) | 14. Safety-suction valve |
| 7. Center block | 15. Safety-suction valve |
| 8. Spool (Blade) | 16. Safety-suction valve |

F20M06011

8-SPOOL CONTROL VALVE







PL05-6, PC07-1



020M06

20MF06010

- | | |
|---|---|
| a. A8 port (To boom swing cylinder bottom side) | k. B1 port (To boom cylinder head side) |
| b. A7 port (To swing motor B port) | l. B2 port (To bucket cylinder bottom side) |
| c. A6 port (To arm cylinder bottom side) | m. B3 port (To R.H. travel motor B port) |
| d. A5 port (To L.H. travel motor B port) | n. B4 port (To blade cylinder head side) |
| e. A4 port (To blade cylinder bottom side) | o. B5 port (To L.H. travel motor A port) |
| f. A3 port (To R.H. travel motor A port) | p. B6 port (To arm cylinder head side) |
| g. A2 port (To bucket cylinder head side) | q. B7 port (To swing motor A port) |
| h. A1 port (To boom swing cylinder bottom side) | r. B8 port (To boom swing cylinder head side) |
| i. T port (To tank) | s. PL port (From hydraulic pump) |
| j. PR port (From hydraulic pump) | |




020M06

20MF06011

- | | |
|------------------------|--------------------------|
| 1. Check valve | 8. Spool (blade) |
| 2. Check valve spring | 9. Spool (R.H. travel) |
| 3. Main relief valve | 10. Spool (bucket) |
| 4. Spool (boom swing) | 11. Spool (boom) |
| 5. Spool (swing) | 12. Main relief valve |
| 6. Spool (arm) | 13. Spool return spring |
| 7. Spool (L.H. travel) | 14. Safety—suction valve |

1-SPOOL CONTROL VALVE

PC05-6



- a. T port (To tank)
- b. A port (To attachment)
- c. B port (To attachment)
- d. P port (From hydraulic tank)


- 1. Spool
- 2. Spool return spring
- 3. Safety-suction valve
- 4. Check valve
- 5. Check valve spring
- 6. Safety-suction valve

F20M06012

020M06

5-SPOOL CONTROL VALVE


PC10-6, PC15-2



020M06


F20M06062

- | | |
|---|---|
| a. A ₅ port (To arm cylinder head side) | h. A ₂ port (To bucket cylinder bottom side) |
| b. A ₄ port (To L.H. travel motor A port) | i. A ₃ port (To R.H. travel motor B port) |
| c. A ₃ port (To R.H. travel motor A port) | j. A ₄ port (To L.H. travel motor B port) |
| d. A ₂ port (To bucket cylinder head side) | k. A ₅ port (To arm cylinder bottom side) |
| e. A ₁ port (To boom cylinder bottom side) | l. P _L port (From hydraulic pump) |
| f. P _R port (From hydraulic pump) | m. T _o port (To tank) |
| g. A ₁ port (To boom cylinder head side) | |




Section A - A


1 2



Section D - D



Section E - E



Section B - B

Section C - C

10

12


020M06

F20M06063

- | | |
|------------------------|--------------------------|
| 1. Check valve spring | 7. Spool (Bucket) |
| 2. Check valve | 8. Spool (Boom) |
| 3. Main relief valve | 9. Main relief valve |
| 4. Spool (Arm) | 10. Spool return spring |
| 5. Spool (L.H. travel) | 11. Safety-suction valve |
| 6. Spool (R.H. travel) | 12. Safety valve |

6-SPOOL CONTROL VALVE


PC10-6, PC15-2



020M06


20NF06015

- | | |
|---|---|
| a. A ₆ port (To arm cylinder head side) | i. B ₂ port (To boom cylinder head side) |
| b. A ₅ port (To L.H. travel motor A port) | j. B ₃ port (To bucket cylinder head side) |
| c. A ₄ port (To R.H. travel motor A port) | k. B ₄ port (To R.H. travel motor B port) |
| d. A ₃ port (To bucket cylinder bottom side) | l. B ₅ port (To L.H. travel motor B port) |
| e. A ₂ port (To boom cylinder bottom side) | m. B ₆ port (To arm cylinder bottom side) |
| f. A ₁ port (To boom swing cylinder head side) | n. PL port (From hydraulic pump) |
| g. P _R port (From hydraulic pump) | o. T port (To tank) |
| h. B ₁ port (To boom swing cylinder bottom side) | |




1 2

Section A - A




Section B - B



Section C - C


020M06



Section D - D



Section E - E



Section F - F




Section G - G

- | | |
|------------------------|--------------------------|
| 1. Check valve | 8. Spool (Boom) |
| 2. Check valve spring | 9. Spool (Boom swing) |
| 3. Main relief valve | 10. Main relief valve |
| 4. Spool (Arm) | 11. Spool return spring |
| 5. Spool (L.H. travel) | 12. Safety-suction valve |
| 6. Spool (R.H. travel) | 13. Safety valve |
| 7. Spool (Bucket) | 14. Suction valve |

20NF06016

2-SPOOL CONTROL VALVE

PC10-6, PC15-2




- a. T port (To tank)
 - b. A2 port (To swing motor B port)
 - c. A1 port (To blade cylinder bottom side)
 - d. P port (From hydraulic pump)
 - e. B1 port (To blade cylinder head side)
 - f. B2 port (To swing motor A port)
-
- 1. Spool (Swing)
 - 2. Spool (Blade)
 - 3. Main relief valve
 - 4. Spool return spring
 - 5. Safety-suction valve
 - 6. Check valve
 - 7. Check valve spring

20NF06017

020M06

SWING-BOOM SWING SELECTOR VALVE

020M06




- a. B port (From swing/boom swing control valve)
- b. A port (From swing/boom swing control valve)
- c. D port (To boom swing cylinder head side)
- d. C port (To boom swing cylinder bottom side)
- e. F port (To swing motor A port)
- f. E port (To swing motor B port)

- 1. Spool
- 2. Detent spring
- 3. Detent ball
- 4. Body
- 5. Cover

F20M06013

SWING MOTOR

PC05-6, PC07-1, PC10-6



020M06


F20M05021

- | | |
|----------------------|---------------------|
| 1. Output shaft | 8. Disc valve |
| 2. Flange | 9. Bolt |
| 3. Oil seal | 10. Check valve |
| 4. Roller bearing | 11. Valve plate |
| 5. Main drive shaft | 12. Geroler |
| 6. Geroler star | 13. Geroler ring |
| 7. Valve drive shaft | 14. Flange mounting |

SPECIFICATIONS

- Type
 - PC05-6: 2-200DOHV-1E
 - PC07-1: 2-250DOHV-1E
 - PC10-6: 2-200CO4HV-E
- Theoretical delivery
 - PC05-6: 195 cc/rev
 - PC07-1: 244 cc/rev
 - PC10-6: 195 cc/rev

PC15-2



020M06

20NF06018

- | | |
|---------------------------|-------------------|
| 1. Swing pinion | 9. Cylinder |
| 2. Case (ring gear) | 10. End cap |
| 3. No.2 planetary carrier | 11. Valve plate |
| 4. No.2 planetary gear | 12. Center spring |
| 5. No.1 planetary carrier | 13. Swash plate |
| 6. No.1 planetary gear | 14. Output shaft |
| 7. Hosing | 15. No.1 sun gear |
| 8. Piston | 16. No.2 sun gear |


SPECIFICATIONS

- Type PC-100N-19-6-1027A
- Theoretical delivery: 256 cc/rev
- Reduction ratio: 18.83

TRAVEL MOTOR

PC05-6, PC07-1

1. MOTOR (WITH REDUCTION GEAR)



- | | |
|------------------------|----------------------------|
| 1. Cover | 9. Brake valve |
| 2. No.2 planetary gear | 10. Center spring |
| 3. No.1 planetary gear | 11. Swash plate |
| 4. Ring gear | 12. Output shaft |
| 5. Housing | 13. No.1 sun gear |
| 6. Piston | 14. No.2 planetary carrier |
| 7. Cylinder | 15. No.2 sun gear |
| 8. Valve plate | |


SPECIFICATIONS

- Type
PC05-6: PH-100-25-0965A
PC07-1: PH-100-25-0996A
- Theoretical delivery
PC05-6: 13.1 cc/rev
PC07-1: 15.4 cc/rev
- Reduction ratio: 25.26

020M06

F20M06014

2. BRAKE VALVE




020M06

F20M06016

1. Plug
2. Spool return spring
3. Check valve spring
4. Check valve
5. Spool

PC10-5, PC15-2

1. MOTOR (WITH REDUCTION GEAR)



20NF06019


020M06

- | | |
|---------------------------|--------------------|
| 1. Cover | 9. Cylinder |
| 2. No.2 planetary gear | 10. Brake valve |
| 3. No.2 planetary carrier | 11. Valve plate |
| 4. No.1 planetary gear | 12. Center spring |
| 5. No.1 planetary carrier | 13. Swash plate |
| 6. Ring gear | 14. Output shaft |
| 7. Housing | 15. No.1 ring gear |
| 8. Piston | 16. No.2 ring gear |

SPECIFICATIONS

- Type: PH-200N-37-1019A
- Theoretical delivery: 22.1 cc/rev
- Reduction ratio: 36.51

2. BRAKE VALVE





020M06

20NF06020

1. Plug
2. Spool return spring
3. Check valve spring
4. Check valve
5. Spool

CENTER SWIVEL JOINT

PC05-6, PC07-1



020M06





20MF221

1. Shaft
2. Back up ring
3. Rotor
4. O-ring
5. Thrust washer
6. Snap ring
7. Flange


- A1 .From L.H. travel control valve (A port)
 A2 .To L.H. travel motor (A port)
 B1 . From R.H. travel control valve (B port)
 B2 .To R.H. travel motor (B port)
 C1 .From L.H. travel control valve (C port)
 C2 .To L.H. travel motor (C port)
 D1 .From R.H. travel control valve (D port)

- D2 .To R.H. travel motor (D port)
 E1 . From blade control valve (E port)
 E2 . To blade cylinder head side (E port)
 F1 . From blade control valve (F port)
 F2 . To blade cylinder bottom side (F port)
 G1 . To hydraulic tank (G port)
 G2 .From travel motor drain port (G port)

PC10-6, PC15-2



Section A - A



020M06


20NF2022

- | | | |
|-----------|---|---|
| 1. O-ring | A1. From R.H. travel control valve (A port) | D1. From L.H. travel control valve (D port) |
| 2. Shaft | A2. To R.H. travel motor (A port) | D2. To L.H. travel motor (D port) |
| 3. Rotor | B1. From L.H. travel control valve (B port) | E1. From blade control valve (E port) |
| 4. Flange | B2. To L.H. travel motor (B port) | E2. To blade cylinder head side (E port) |
| | C1. From R.H. travel control valve (C port) | F1. From blade control valve (F port) |
| | C2. To R.H. travel motor (C port) | F2. To blade cylinder bottom side (F port) |
| | | G1. To hydraulic tank (G port) |
| | | G2. From travel motor drain port (G port) |

HYDRAULIC CYLINDER

1. BOOM CYLINDER


PC05-6



F20M06017



- | | | |
|------------------------|----------------|-----------------|
| 1. Head side bushing | 5. Rod packing | 9. Piston |
| 2. Bottom side bushing | 6. Piston rod | 10. Piston ring |
| 3. Cylinder head | 7. Cylinder | 11. Wearing |
| 4. Bushing | 8. Plunger | 12. Piston nut |

PC07-1



F20M06064

PC10-6





- | | | |
|----------------------|---------------|-------------------------|
| 1. Head side bushing | 5. Piston rod | 9. Piston ring |
| 2. Cylinder head | 6. Cylinder | 10. Wearing |
| 3. Bushing | 7. Plunger | 11. Piston nut |
| 4. Rod packing | 8. Piston | 12. Bottom side bushing |

F20M06065

020M06



PC15-2 (WITH CANOPY)



F20M06066

2. ARM CYLINDER

PC05-6





F20M06018A

- | | | |
|------------------------|----------------|----------------|
| 1. Head side bushing | 5. Rod packing | 9. Piston ring |
| 2. Bottom side bushing | 6. Piston rod | 10. Wearing |
| 3. Cylinder head | 7. Cylinder | 11. Piston nut |
| 4. Bushing | 8. Piston | |



020M06

PC07-1



F20M06067

PC10-6





F20M06068

- | | | |
|---------------------|----------------|----------------|
| 1. Head side tube | 5. Rod packing | 9. Piston ring |
| 2. Bottom side tube | 6. Piston rod | 10. Wearing |
| 3. Cylinder head | 7. Cylinder | 11. Piston nut |
| 4. Bushing | 8. Piston | |

020M06


PC15-2



F20M06069

3. BUCKET CYLINDER


PC05-6, PC07-1



F20M06019

- | | | |
|------------------------|----------------|----------------|
| 1. Head side bushing | 5. Rod packing | 9. Piston ring |
| 2. Bottom side bushing | 6. Piston rod | 10. Wearing |
| 3. Cylinder head | 7. Cylinder | 11. Piston nut |
| 4. Bushing | 8. Piston | |

PC10-6, PC15-2





F20M06070

020M06

4. BOOM SWING CYLINDER

PC05-6 Serial No. 11301 – 11700





F20M06020

- | | | |
|------------------------|----------------|----------------|
| 1. Head side bushing | 5. Rod packing | 9. Piston ring |
| 2. Bottom side bushing | 6. Piston rod | 10. Wearing |
| 3. Cylinder head | 7. Cylinder | 11. Piston nut |
| 4. Bushing | 8. Piston | |


020M06

PC05-6 Serial No. 11701 and up
PC07-1



F20M06071

PC10-6, PC15-2




F20M06072

- | | | |
|---------------------|----------------|----------------|
| 1. Head side tube | 5. Rod packing | 9. Piston ring |
| 2. Bottom side tube | 6. Piston rod | 10. Wearing |
| 3. Cylinder head | 7. Cylinder | 11. Piston nut |
| 4. Bushing | 8. Piston | |

5. BLADE CYLINDER


PC05-6, PC07-1



F20M06021

020M06

PC10-6, PC15-2



F20M06073

- | | | |
|------------------------|----------------|----------------|
| 1. Head side bushing | 5. Rod packing | 9. Piston ring |
| 2. Bottom side bushing | 6. Piston rod | 10. Wearing |
| 3. Cylinder head | 7. Cylinder | 11. Piston nut |
| 4. Bushing | 8. Piston | |

020M06

SPECIFICATIONS

PC05-6 (FOR MACHINE EQUIPPED WITH SWING-BOOM SWING SELECTOR PEDAL)

Unit: mm

Item	Cylinder		Arm	Bucket	Boom swing	Blade
	With canopy	With cab				
Piston rod outside diameter	30 (30)	—	30	30	30 (30)	30
Cylinder inside diameter	50 (50)	—	50	50	50 (50)	60
Piston stroke	339.2 (353)	—	442	385	287.5 (318)	60
Cylinder max. length	974.2 (988)	—	1,048	1,034	908 (908)	393
Cylinder min. length	635 (635)	—	706	649	620.5 (590)	333
Piston nut width across flat	32 (32)	—	32	32	32 (32)	32

(): 90° right boom swing specification.

PC05-6 (FOR MACHINE WITHOUT SWING-BOOM SWING SELECTOR PEDAL)

Unit: mm

Item	Cylinder	Boom		Arm	Bucket	Boom swing	Blade
		With canopy	With cab				
Piston rod outside diameter	30	30	30	30	30	30	30
Cylinder inside diameter	50	50	50	50	50	50	60
Piston stroke	353	339.2	442	385	318	60	
Cylinder max. length	988	974.2	1,048	1,034	908	393	
Cylinder min. length	635	635	706	649	590	333	
Piston nut width across flat	32	32	32	32	32	32	32

PC07-1

Unit: mm

Item	Cylinder	Boom		Arm	Bucket	Boom swing	Blade
		With canopy	With cab				
Piston rod outside diameter	30	—	30	30	30	30	30
Cylinder inside diameter	60	—	55	50	50	60	
Piston stroke	355	—	435	385	318	60	
Cylinder max. length	982	—	1,141	1,034	908	393	
Cylinder min. length	627	—	706	649	590	333	
Piston nut width across flat	30	—	32	32	32	32	32

020M06

PC10-6

Unit: mm

Item	Cylinder	Boom		Arm	Bucket	Boom swing	Blade
		With canopy	With cab				
Piston rod outside diameter		35	35	40	35	35	35
Cylinder inside diameter		70	70	70	60	70	70
Piston stroke		510	465	475	480	520	135
Cylinder max. length		1,280	1,235	1,210	1,200	1,300	545
Cylinder min. length		770	770	735	720	780	410
Piston nut width across flat		36	36	41	36	41	41

PC15-2


Unit: mm

Item	Cylinder	Boom		Arm	Bucket	Boom swing	Blade
		With canopy	With cab				
Piston rod outside diameter		40	40	40	35	35	35
Cylinder inside diameter		70	70	70	60	70	70
Piston stroke		525	485	475	480	520	135
Cylinder max. length		1,315	1,275	1,215	1,200	1,300	545
Cylinder min. length		790	790	740	720	780	410
Piston nut width across flat		41	41	46	36	41	41

020M06

VALVE CONTROL

PC05-6, PC07-1




020M06

F20M06022

- | | |
|--------------------------------------|------------------------------------|
| 1. Blade control lever | 6. 7-Spool control valve |
| 2. R.H. work equipment control lever | 7. Safety lock lever |
| 3. R.H. travel control lever | 8. Swing—boom swing selector valve |
| 4. L.H. travel control lever | 9. Swing—boom swing selector pedal |
| 5. L.H. work equipment control lever | |

★ FOR MACHINE EQUIPPED WITH SWING-BOOM SWING SELECTOR PEDAL AND ADDITIONAL CIRCUIT

PC05-6, PC07-1




020M06

F20M06023

- | | |
|--------------------------------------|-------------------------------------|
| 1. Blade control lever | 7. Additional control pedal |
| 2. R.H. work equipment control lever | 8. 7-spool control lever |
| 3. R.H. travel control lever | 9. Safety lock lever |
| 4. L.H. travel control lever | 10. Swing-boom swing selector valve |
| 5. L.H. work equipment control lever | 11. Swing-boom swing selector pedal |
| 6. 1-spool control valve | |

PC05-6, PC07-1


020M06



F20M06074

- | | |
|--------------------------------------|-----------------------------|
| 1. L.H. work equipment control lever | 5. Boom swing control lever |
| 2. L.H. travel control lever | 6. Blade control lever |
| 3. R.H. travel control lever | 7. Safety lock lever |
| 4. R.H. work equipment control lever | 8. 8-spool control lever |

PC10-6, PC15-2




020M06

F20M06075

- | | |
|--------------------------------------|-----------------------------------|
| 1. L.H. travel control lever | 6. 2-spool control valve |
| 2. R.H. travel control lever | 7. Swing—boom swing control valve |
| 3. R.H. work equipment control lever | 8. Swing—boom swing control pedal |
| 4. Blade control lever | 9. 5-spool control valve |
| 5. L.H. work equipment control lever | 10. Safety lock lever |

PC10-6, PC15-2

020M06




F20M06076

- | | |
|--------------------------------------|--------------------------------------|
| 1. L.H. travel control lever | 6. L.H. work equipment control lever |
| 2. R.H. travel control lever | 7. 2-spool control lever |
| 3. Boom swing control lever | 8. 6-spool control lever |
| 4. R.H. work equipment control lever | 9. Safety lock lever |
| 5. Blade control lever | |

WORK EQUIPMENT

PC05-6, PC15-2




020M06

F20M06024

- | | |
|--------------------|------------------------|
| 1. Bucket | 6. Boom cylinder |
| 2. Bucket cylinder | 7. Boom swing cylinder |
| 3. Arm | 8. Boom swing bracket |
| 4. Arm cylinder | 9. Blade cylinder |
| 5. Boom | 10. Blade |

020M06




20NF06022

- 1. Bucket cylinder
- 2. Arm
- 3. Arm cylinder
- 4. Boom
- 5. Boom cylinder

- 6. Swing bracket
- 7. Swing cylinder
- 8. Blade cylinder
- 9. Blade
- 10. Bucket


ELECTRICAL CIRCUIT DIAGRAM

PC05-6 Serial No. 11301 - 11700




STARTING SWITCH CONNECTING TABLE

Terminal key position	B	BR	R ₁	R ₂	C	ACC
HEAT	○	○	○			○
OFF	○					
ON	○					○
START	○	○				○




020M06




STARTING SWITCH CONNECTING TABLE

Key position	Terminal position	B	BR	R ₁	R ₂	C	ACC
HEAT		○	○	○			○
OFF		○					
ON		○					
START		○	○		○	○	



F20M06077

PC10-6, PC15-2



020M06

20 TESTING AND ADJUSTING

020M06

Table of judgement standard value	20- 2
Testing and adjusting tool list	20-36
Adjusting valve clearance	
(PC05-6, PC07-1)	20-38
Adjusting valve clearance	
(PC10-6, PC15-2)	20-39
Measuring compression pressure	
(PC05-6, PC07-1)	20-40
Measuring compression pressure	
(PC10-6, PC15-2)	20-41
Testing and adjusting fuel injection	
timing (PC05-6, PC07-1)	20-42
Testing and adjusting fuel injection	
timing (PC10-6, PC15-2)	20-43
Testing and adjusting hydraulic	
pressure (PC05-6, PC07-1)	20-44
Testing and adjusting hydraulic	
pressure (PC10-6, PC15-2)	20-45

TABLE OF JUDGEMENT STANDARD VALUE

• FOR ENGINE


Engine model			3D72-2	
Machine model			PC05-6	
Check item	Conditions, etc.	Unit	Standard value	Permissible value
Engine speed	High idling	rpm	2,150±50	2,150±50
	Low idling	rpm	900±50	900±50
	Rated speed	rpm	2,000±50	2,000±50
Exhaust gas color	Sudden acceleration At high idling	Bosch index Bosch index		
Valve clearance	Intake valve (at 20°C)	mm	0.20	—
	Exhaust valve (at 20°C)	mm	0.20	—
Compression pressure	Oil temperature: 40 — 60°C, SAE30 oil () : Engine speed	kg/cm ²	35	30
		(rpm)	(250)	(250)
Blow-by pressure	Water temperature in operating range At high idling, SAE30 oil	mmH ₂ O		
Oil pressure	Water temperature in operating range			
	At high idling (SAE30 oil, Min. 80°C)	kg/cm ²	—	—
	At low idling (SAE30 oil, Min. 80°C)	kg/cm ²	Min. 1.5	Min. 1.5
	At high idling (SAE10W oil, Min. 80°C)	kg/cm ²	—	—
	At low idling (SAE10W oil, Min. 80°C)	kg/cm ²	—	—
Oil temperature	Whole speed range (inside oil pan)	°C		Max. 105
Fuel injection pressure	Nozzle tester	kg/cm ²	120	120 — 125
Fuel injection timing	Compression B.T.D.C.	degree	11	
Fan belt tension	Slack when pushed with finger force of 6 kg	mm	12	10 — 16

020M06

020M06

3D72-2		3D75-2		3D78-1	
PC07-1		PC10-6		PC15-2	
Standard value	Permissible value	Standard value	Permissible value	Standard value	Permissible value
2,570±50 900±50 2,400±50	2,570±50 900±50 2,400±50	2,800±50 900±50 2,600	2,800±50 900±50 2,600	2,750±50 900±50 2,600	2,750±50 900±50 2,600
0.20 0.20	— —	0.20 0.20	— —	0.20 0.20	— —
35 (250)	30 (250)			30 (250)	26 (250)
— Min. 1.5 — —	— Min. 1.5 — —	3.5 Min. 1.0 — —	3.0 — 4.0 — —	3.5 Min. 1.0 — —	3.0 — 4.0 — —
—	Min. 105				
11	—	16	—	16	—
12	10 — 16	10 — 16		10 — 16	

• FOR CHASSIS


Machine model				PC05-6									
Serial No.				11301 — 11700									
Classification	Item	Condition, etc.		Unit	Standard value			Permissible value					
Engine	Engine speed when one pump circuit oil is relief.	<ul style="list-style-type: none"> Oil temperature: 45 — 55°C Engine coolant temperature: in correct range Engine oil pressure: in correct range 		rpm	2,080±50			2,080±50					
	Engine speed when two pump circuit oil is relief.	<ul style="list-style-type: none"> At one pump relief: Bucket circuit relief At two pump relief: Bucket and arm circuits relief 			2,000±50			2,000±50					
Spool travel	Boom control valve			mm	l	a	b	l	a	b			
	Arm control valve				20	6	6	20	6	6			
	Bucket control valve				—	—	—	—	—	—			
	★ Swing — boom swing control valve				20	6	6	20	6	6			
	★ Swing — boom swing selector valve				—	—	—	—	—	—			
	☆ Swing control valve				—	—	—	—	—	—			
	☆ Boom swing control valve				—	—	—	—	—	—			
	Travel control valve				20	6	6	20	6	6			
Travel of control levers and pedals	Boom control lever	<ul style="list-style-type: none"> At center of lever knob At tip of pedal Measure at end of travel Engine speed: Stopped 		mm	Neutral → Raise and lower			68.5			61.7 — 75.4		
	Arm control lever				Neutral → In and out			68.5			61.7 — 75.4		
	Bucket control lever				Neutral → Curl and dump			76.5			68.9 — 84.2		
	★ Swing — boom swing control lever				Neutral → L.H. and R.H. swing			76.5			68.9 — 84.2		
	★ Swing — boom swing selector pedal				Swing → Boom swing			10.5			9.5 — 11.5		
	☆ Swing control lever				Neutral → L.H. and R.H. swing			—			—		
	☆ Boom swing control lever				Neutral → L.H. and R.H. swing			—			—		
	Blade control lever				Neutral → Raise and lower			70.0			63.0 — 77.0		

Note) ★: For machine equipped with swing — boom swing selector pedal.
 ☆: For machine without swing — boom swing selector pedal.

020M06

020M06

PC05-6						PC07-1						PC10-6					
11701 and up						10001 and up						10501 and up					
Standard value		Permissible value				Standard value		Permissible value				Standard value		Permissible value			
ℓ	a	b	ℓ	a	b	ℓ	a	b	ℓ	a	b	ℓ	a	b	ℓ	a	b
															2,690		2,690
															2,600		2,600
20	6	6	20	6	6	20	6	6	20	6	6	20	6	6	20	6	6
Max. 75						Max. 75						90					
												90					
Max. 80						Max. 80						95					
												105					
Max. 70						Max. 70						90					
Max. 80						Max. 80						70					

Machine model				PC15-2					
Serial No.				10001 and up					
Classification	Item	Condition, etc.	Unit	Standard value		Permissible value			
Engine	Engine speed when one pump circuit oil is relief.	<ul style="list-style-type: none"> Oil temperature: 45 — 55°C Engine coolant temperature: in correct range Engine oil pressure: in correct range 	rpm	2,680		2,680			
	Engine speed when two pump circuit oil is relief.	<ul style="list-style-type: none"> At one pump relief: Bucket circuit relief At two pump relief: Bucket and arm circuits relief 		2,620		2,620			
Spool travel	Boom control valve		mm	l	a	b	l	a	b
	Arm control valve			20	6	6	20	6	6
	Bucket control valve								
	★ Swing — boom swing control valve								
	★ Swing — boom swing selector valve								
	☆ Swing control valve								
	☆ Boom swing control valve								
	Blade control valve								
Travel control valve									
Travel of control levers and pedals	Boom control lever	<ul style="list-style-type: none"> At center of lever knob At tip of pedal Measure at end of travel Engine speed: Stopped 	mm	Neutral — Raise and lower		90			
	Arm control lever			Neutral — In and out		90			
	Bucket control lever			Neutral — Curl and dump		95			
	★ Swing — boom swing control lever			Neutral → L.H. and R.H. swing					
	★ Swing — boom swing selector pedal			Swing ← Boom swing					
	☆ Swing control lever			Neutral → L.H. and R.H. swing		105			
	☆ Boom swing control lever			Neutral → L.H. and R.H. swing		90			
Blade control lever	Neutral → Raise and lower		70						

Note) ★: For machine equipped with swing — boom swing selector pedal.
 ☆: For machine without swing — boom swing selector pedal.

020M06

020M06

Standard value			Permissible value			Standard value			Permissible value			Standard value			Permissible value		
t	a	b	t	a	b	t	a	b	t	a	b	t	a	b	t	a	b

Machine model				PC05-6		
Serial No.				11301 — 11700		
Classification	Item	Condition, etc.		Unit	Standard value	Permissible value
Travel of control levers and pedals	Travel control lever	<ul style="list-style-type: none"> At center of lever knob At tip of pedal Measure at end of travel Engine speed: Stopped 	Neutral — Forward and reverse	mm	68.0	61.5 — 75.0
	Fuel control lever		Stop — Low idling — Low idling — High idling		145	130.5 — 159.5
Control lever and pedal operating force	Boom control lever	<ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Hook push-pull scale on center of control lever knob to measure Measure maximum value in traveling 			1.5 — 2.5	1.5 — 2.5
	Arm control lever				1.5 — 2.5	1.5 — 2.5
	Bucket control lever				1.4 — 2.4	1.4 — 2.4
	★ Swing — boom swing control lever				1.4 — 2.4	1.4 — 2.4
	★ Swing — boom swing selector pedal				13.7 — 15.4	13.7 — 15.4
	☆ Swing control lever				—	—
	☆ Boom swing control lever				—	—
	Blade control lever				1.3 — 2.3	1.3 — 2.3
	Travel control lever				1.5 — 2.5	1.5 — 2.5
	Fuel control lever				2.5 — 3.5	2.5 — 3.5
Hydraulic pressure	Boom circuit	<ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C 1 pump relieved, other pump no load 		kg/cm ²	175 — 180	175 — 180
	Arm circuit				175 — 180	175 — 180
	Bucket circuit				175 — 180	175 — 180
	Boom swing circuit				82 — 88	82 — 88
	Swing circuit				82 — 88	82 — 88
	Blade circuit				175 — 180	175 — 180
	Travel circuit				175 — 180	175 — 180
	Lowered hydraulic pressure	<ul style="list-style-type: none"> Oil temperature: 45 — 55°C Difference oil relief pressure between at engine high idling and at engine a half speed. (Measure pressure when one pump circuit oil is relieved.) 			0	0




Note) ★: For machine equipped with swing — boom swing selector pedal.
 ☆: For machine without swing — boom swing selector pedal.

PC05-6		PC07-1		PC10-6	
11701 and up		10001 and up		10501 and up	
Standard value	Permissible value	Standard value	Permissible value	Standard value	Permissible value
Max. 75		Max. 75		80	
				—	—
80		80		185	
0.8 — 2.5	3.0	0.8 — 2.5	3.0	1.2 — 2.5	1.2 — 2.5
0.8 — 2.5	3.0	0.8 — 2.5	3.0	1.2 — 2.5	1.2 — 2.5
0.8 — 2.5	3.0	0.8 — 2.5	3.0	1.2 — 2.5	1.2 — 2.5
0.8 — 2.5	3.0	0.8 — 2.5	3.0	1.2 — 2.5	1.2 — 2.5
0.8 — 2.5	3.0	0.8 — 2.5	3.0	1.2 — 2.5	1.2 — 2.5
0.8 — 2.5	3.0	0.8 — 2.5	3.0	1.2 — 2.5	1.2 — 2.5
0.8 — 2.5	3.0	0.8 — 2.5	3.0	1.2 — 2.5	1.2 — 2.5
2.5 — 3.5	4.0	2.5 — 3.5	4.0	2.5 — 4.5	2.5 — 4.5
175^{+5}_0	175 ± 5	175^{+5}_0	175 ± 5	175^{+5}_0	175^{+5}_0
175^{+5}_0	175 ± 5	175^{+5}_0	175 ± 5	175^{+5}_0	175^{+5}_0
175^{+5}_0	175 ± 5	175^{+5}_0	175 ± 5	175^{+5}_0	175^{+5}_0
175^{+5}_0	175 ± 5	175^{+5}_0	175 ± 5	175^{+5}_0	175^{+5}_0
85^{+5}_0	85 ± 5	85^{+5}_0	85 ± 5	135^{+5}_0	135^{+5}_0
175^{+5}_0	175 ± 5	175^{+5}_0	175 ± 5	175^{+5}_0	175^{+5}_0
175^{+5}_0	175 ± 5	175^{+5}_0	175 ± 5	175^{+5}_0	175^{+5}_0
Max. 10	Max. 10	Max. 10	Max. 10		

Machine model				PC15-2		
Serial No.				10001 and up		
Classification	Item	Condition, etc.		Unit	Standard value	Permissible value
Travel of control levers and pedals	Travel control lever	<ul style="list-style-type: none"> At center of lever knob At tip of pedal Measure at end of travel Engine speed: Stopped 	Neutral → Forward and reverse	mm	80	
	Fuel control lever		Stop ←			
			Low idling ←			
Control lever and pedal operating force	Boom control lever	<ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Hook push-pull scale on center of control lever knob to measure Measure maximum value in traveling 			1.2 — 2.5	1.2 — 2.5
	Arm control lever				1.2 — 2.5	1.2 — 2.5
	Bucket control lever				1.2 — 2.5	1.2 — 2.5
	★ Swing — boom swing control lever					
	★ Swing — boom swing selector pedal					
	☆ Swing control lever				1.2 — 2.5	1.2 — 2.5
	☆ Boom swing control lever				1.2 — 2.5	1.2 — 2.5
	Blade control lever				1.2 — 2.5	1.2 — 2.5
	Travel control lever				1.2 — 2.5	1.2 — 2.5
	Fuel control lever				2.5 — 4.5	2.5 — 4.5
Hydraulic pressure	Boom circuit	<ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C 1 pump relieved, other pump no load 		kg/cm ²	200 ⁺⁵ ₀	200 ⁺⁵ ₀
	Arm circuit				200 ⁺⁵ ₀	200 ⁺⁵ ₀
	Bucket circuit				200 ⁺⁵ ₀	200 ⁺⁵ ₀
	Boom swing circuit				200 ⁺⁵ ₀	200 ⁺⁵ ₀
	Swing circuit				135 ⁺⁵ ₀	135 ⁺⁵ ₀
	Blade circuit				175 ⁺⁵ ₀	175 ⁺⁵ ₀
	Travel circuit				200 ⁺⁵ ₀	200 ⁺⁵ ₀
	Lowered hydraulic pressure	<ul style="list-style-type: none"> Oil temperature: 45 — 55°C Difference oil relief pressure between at engine high idling and at engine a half speed. (Measure pressure when one pump circuit oil is relieved.) 			0	0

020M06




Note) ★: For machine equipped with swing — boom swing selector pedal.
 ☆: For machine without swing — boom swing selector pedal.

Machine model				PC05-6	
Serial No.				11301 — 11700	
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value
Swing	Swing brake angle	<ul style="list-style-type: none"> Measuring posture  <p>20RF5104</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Put match marks on the swing circle outer race and the track frame. Swing the upper structure 360°, then stop it. Measure the distance between the match marks after the upper structure comes to a stop. 	degree (mm)	Max. 25 (Max. 109)	Max. 25 (Max. 109)
	Time taken to start swing	<ul style="list-style-type: none"> Measuring posture  <p>20RF5104</p>	90°	Max. 2.4	Max. 2.7
		<ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Measure time taken for 90° and 180° swing from starting point. 	180°	—	—
Time taken to swing	<ul style="list-style-type: none"> Measuring posture  <p>20RF5104</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Measure time taken to swing for 5 turns, after swinging one turn as an approach swing. 	sec.	Max. 30	Max. 33	

020M06

020M06




PC05-6		PC07-1		PC10-6	
11701 and up		10001 and up		10501 and up	
Standard value	Permissible value	Standard value	Permissible value	Standard value	Permissible value
30	30	30	30	Max. 20 (Max. 105)	
Max. 2.4	Max. 2.7	Max. 2.5	Max. 2.8	Max. 3.0	
—	—	—	—	Max. 4.5	
Max. 32.8	Max. 35.8	Max. 33.7	Max. 36.8	Max. 35.0	

Machine model				PC15-2	
Serial No.				10001 and up	
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value
Swing	Swing brake angle	<ul style="list-style-type: none"> Measuring posture  <p>Max. reach</p> <p>20RF5104</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Put match marks on the swing circle outer race and the track frame. Swing the upper structure 360°, then stop it. Measure the distance between the match marks after the upper structure comes to a stop. 	degree (mm)	Max. 25 (Max. 130)	
	Time taken to start swing	<ul style="list-style-type: none"> Measuring posture  <p>Max. reach</p> <p>20RF5104</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Measure time taken for 90° and 180° swing from starting point. 	90°	Max. 3.0	
			180°	Max. 4.5	
Time taken to swing	<ul style="list-style-type: none"> Measuring posture  <p>Max. reach</p> <p>20RF5104</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Measure time taken to swing for 5 turns, after swinging one turn as an approach swing. 	sec.	Max. 35.0		

020M06

020M06




Standard value		Permissible value		Standard value		Permissible value	

Machine model				PC05-6	
Serial No.				11301 — 11700	
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value
Swing	Hydraulic drift of swing	<ul style="list-style-type: none"> Measuring posture  <p>20RF5105</p> <ul style="list-style-type: none"> Engine speed: Stopped Oil temperature: 45 — 55°C Stop the machine on 15° slope and set boom at 45° angle across the slope. Write the mach marks on the swing circle outer race and track frame. After 15 minutes, measure the lag of match marks. 	degree (mm)	Max. 90	Max. 90
	Leakage from swing motor	<ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Relieve oil in swing circuit 	l/min		
Travel	Travel speed (1)	<ul style="list-style-type: none"> Measuring posture  <p>20RF5106</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Raise one track off the ground, let it spin one revolution, then measure the time required for it to spin 5 revolutions. Repeat this procedure for the other track. 	sec.	Max. 28	Max. 30
	Travel speed (2)	<ul style="list-style-type: none"> Measuring posture  <p>20RF5107</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C On a flat surface, make an approach run of at least 10 m, then measure the time required for the machine to travel 20 m. 	sec.	Max. 39	Max. 41

020M06

020M06



PC05-6		PC07-1		PC10-6	
11701 and up		10001 and up		10501 and up	
Standard value	Permissible value	Standard value	Permissible value	Standard value	Permissible value
(Max. 180)	(Max. 180)	(Max. 180)	(Max. 180)	(Max. 180)	
Max. 28	Max. 35	Max. 28	Max. 35	36±4	36±8
Max. 37.6	Max. 43.7	Max. 37.6	Max. 43.7	37±4	37±8

Machine model				PC15-2	
Serial-No.				10001 and up	
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value
Swing	Hydraulic drift of swing	<ul style="list-style-type: none"> Measuring posture  <ul style="list-style-type: none"> Engine speed: Stopped Oil temperature: 45 — 55°C Stop the machine on 15° slope and set boom at 45° angle across the slope. Write the mach marks on the swing circle outer race and track frame. <p>After 15 minutes, measure the lag of match marks.</p>	degree (mm)	(Max. 250)	
	Leakage from swing motor	<ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Relieve oil in swing circuit 	l/min		
Travel	Travel speed (1)	<ul style="list-style-type: none"> Measuring posture  <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Raise one track off the ground, let it spin one revolution, then measure the time required for it to spin 5 revolutions. Repeat this procedure for the other track. 	sec.	38±4	38±8
	Travel speed (2)	<ul style="list-style-type: none"> Measuring posture  <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C On a flat surface, make an approach run of at least 10 m, then measure the time required for the machine to travel 20 m. 	sec.	37±4	37±8

020M06

020M06



Standard value	Permissible value	Standard value	Permissible value	Standard value	Permissible value

Machine model				PC05-6	
Serial No.				11301 — 11700	
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value
Travel	Travel deviation	<ul style="list-style-type: none"> Measuring posture  <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C On a flat surface, make an approach run of at least 10 m, then travel another 20 m. Measure the travel deviation. <p style="text-align: right;">202F2303</p> <p>★ Measure dimension <i>l</i>.</p>	mm	Max. 500	Max. 550
	Hydraulic drift of travel	<ul style="list-style-type: none"> Measuring posture  <p style="text-align: right;">20RF5108</p> <ul style="list-style-type: none"> Engine speed: Stopped Oil temperature: 45 — 55°C Stop the machine on 30° slope with setting sprocket on uphill. Measure distance moved by machine in 5 min. 	mm	Max. 500	Max. 550
	Leakage from travel motor	<ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Relieve travel circuit. Measure leakage from travel motor with measuring cylinder. 	l/min.	—	—

020M06

PC05-6		PC07-1		PC10-6	
11701 and up		10001 and up		10501 and up	
Standard value	Permissible value	Standard value	Permissible value	Standard value	Permissible value
500	550	500	550	Max. 500	Max. 550
				Max. 100	






020M06

Machine model				PC15-2	
Serial No.				10001 and up	
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value
	Travel deviation	<ul style="list-style-type: none"> Measuring posture  <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C On a flat surface, make an approach run of at least 10 m, then travel another 20 m. Measure the travel deviation. <p>202F2303</p> <p>★ Measure dimension <i>l</i>.</p>	mm	Max. 500	Max. 550
	Hydraulic drift of travel	<ul style="list-style-type: none"> Measuring posture  <p>20RF5108</p> <ul style="list-style-type: none"> Engine speed: Stopped Oil temperature: 45 — 55°C Stop the machine on 30° slope with setting sprocket on uphill. Measure distance moved by machine in 5 min. 	mm	Max. 120	
	Leakage from travel motor	<ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C Relieve travel circuit. Measure leakage from travel motor with measuring cylinder. 	l/min.		

020M06

020M06






Standard value		Permissible value		Standard value		Permissible value	

Machine model				PC05-6		
Serial No.				11301 — 11700		
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value	
Work equipment	Boom Bucket teeth on the ground ↑ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5109</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C 	RAISE	sec.	2.2 — 2.6	2.2 — 2.6
			LOWER		1.9 — 2.3	1.9 — 2.3
	Arm Cylinder fully retracted ↓ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5110</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C 	ARM IN	sec.	3.7 — 4.4	3.7 — 4.4
			ARM OUT		2.7 — 3.1	2.7 — 3.1
	Bucket Cylinder fully retracted ↑ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5111</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C 	CURL	sec.	3.4 — 4.0	3.4 — 4.0
			DUMP		2.3 — 2.7	2.3 — 2.7
	Blade Blade on the ground ↑ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5112</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C 	RAISE	sec.	0.9 — 1.1	0.9 — 1.1
			LOWER		1.0 — 1.2	1.0 — 1.2
	Boom swing Cylinder fully retracted ↑ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5113</p> <ul style="list-style-type: none"> Engine speed: High idling Oil temperature: 45 — 55°C 	L.H. SWING	sec.	3.1 — 3.7	3.1 — 3.7
			R.H. SWING		3.8 — 4.4	3.8 — 4.4

020M06

020M06

PC05-6		PC07-1		PC10-6	
11701 and up		10001 and up		10501 and up	
Standard value	Permissible value	Standard value	Permissible value	Standard value	Permissible value
Max. 3.3	Max. 3.6	Max. 3.4	Max. 3.7	3.5±0.5	3.5±1.0
Max. 3.2	Max. 3.5	Max. 2.9	Max. 3.2	2.7±0.4	2.7±0.8
Max. 4.5	Max. 4.8	Max. 4.5	Max. 4.8	5.1±0.6	5.1±1.2
Max. 3.2	Max. 3.5	Max. 3.5	Max. 3.8	3.9±0.5	3.9±1.0
Max. 3.9	Max. 4.2	Max. 3.4	Max. 3.7	3.8±0.5	3.8±1.0
Max. 2.8	Max. 3.1	Max. 2.4	Max. 2.7	2.6±0.4	2.6±0.8
Max. 1.1	Max. 1.4	Max. 1.1	Max. 1.4	0.8±0.2	0.8±0.4
Max. 1.3	Max. 1.6	Max. 1.3	Max. 1.6	0.9±0.2	0.9±0.4
Max. 4.5	Max. 4.8	Max. 5.5	Max. 5.8	6.6±0.8	6.6±1.6
Max. 5.1	Max. 5.4	Max. 6.7	Max. 7.0	7.7±0.9	7.7±1.8



Machine model				PC15-2	
Serial No.				10001 and up	
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value
Work equipment	Boom Bucket teeth on the ground ↓ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5109</p>	RAISE	3.5±0.5	3.5±1.0
			LOWER	2.6±0.4	2.6±0.8
	Arm Cylinder fully retracted ↓ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5110</p>	ARM IN	5.1±0.6	5.1±1.2
			ARM OUT	3.7±0.5	3.7±1.0
	Bucket Cylinder fully retracted ↓ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5111</p>	CURL	3.7±0.5	3.7±1.0
			DUMP	2.6±0.4	2.6±0.8
	Blade Blade on the ground ↓ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5112</p>	RAISE	0.8±0.2	0.8±0.4
			LOWER	0.9±0.2	0.9±0.4
	Boom swing Cylinder fully retracted ↓ Cylinder fully extended	<ul style="list-style-type: none"> Measuring posture  <p>20RF5113</p>	L.H. SWING	6.3±0.7	6.3±1.4
			R.H. SWING	7.1±0.8	7.1±1.6

sec.

020M06

020M06



Standard value		Permissible value		Standard value		Permissible value	

Machine model				PC05-6		
Serial No.				11301 — 11700		
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value	
Work equipment	Hydraulic drift	<ul style="list-style-type: none"> Measuring posture  <p>20RF5114</p>	mm	Max. 400	Max. 400	
		Boom cylinder (Retraction of cylinder)		Max. 21	Max. 21	
		Arm cylinder (Extension of cylinder)		<ul style="list-style-type: none"> In the posture shown above, measure the extension and retraction of each cylinder as well as the hydraulic drift at the tip of the bucket teeth. 	Max. 24	Max. 24
		Bucket cylinder (Retraction of cylinder)		<ul style="list-style-type: none"> Work equipment rated load: Flat level surface Control levers in neutral Engine: Stopped Oil temperature: 45 — 55°C Start measuring immediately after setting 	Max. 6	Max. 6
		Blade (Hydraulic drift at the tip of blade)		<ul style="list-style-type: none"> Measure the hydraulic drift every 5 minutes, and make judgement after 15 minutes. 	Max. 12	Max. 12
Work equipment	Time lag	<ul style="list-style-type: none"> Measuring posture  <p>20RF5116</p>	sec.	Max. 2.0	Max. 2.0	
	Boom	<ul style="list-style-type: none"> Engine speed: Low idling Oil temperature: 45 — 55°C Measure the time it takes for the front of the machine to be lifted off the ground, starting from the time the bucket contacts the ground. 				

020M06

020M06




PC05-6		PC07-1		PC10-6	
11701 and up		10001 and up		10501 and up	
Standard value	Permissible value	Standard value	Permissible value	Standard value	Permissible value
Max. 175	350	Max. 175	350	Max. 400	
21	42	21	42	Max. 20	Max. 22
24	48	24	48	Max. 15	Max. 17
6	12	6	12	Max. 10	Max. 11
				Max. 5	Max. 6
0	Max. 1	0	Max. 1	Max. 5	Max. 5

Machine model				PC15-2		
Serial No.				10001 and up		
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value	
Work equipment	Hydraulic drift	<ul style="list-style-type: none"> Measuring posture 	mm	Max. 400		
		Boom cylinder (Retraction of cylinder) <small>20RF5114</small>		Max. 25	Max. 28	
		Arm cylinder (Extension of cylinder)		<ul style="list-style-type: none"> In the posture shown above, measure the extension and retraction of each cylinder as well as the hydraulic drift at the tip of the bucket teeth. 	Max. 15	Max. 17
		Bucket cylinder (Retraction of cylinder)		<ul style="list-style-type: none"> Work equipment rated load: Flat level surface Control levers in neutral Engine: Stopped Oil temperature: 45 — 55°C Start measuring immediately after setting 	Max. 10	Max. 11
		Blade (Hydraulic drift at the tip of blade)		<ul style="list-style-type: none"> Measure the hydraulic drift every 5 minutes, and make judgement after 15 minutes. 	Max. 5	Max. 6
Work equipment	Time lag	<ul style="list-style-type: none"> Measuring posture 	sec.	Max. 5	Max. 5	
	Boom	<ul style="list-style-type: none"> Engine speed: Low idling Oil temperature: 45 — 55°C Measure the time it takes for the front of the machine to be lifted off the ground, starting from the time the bucket contacts the ground. <small>20RF5116</small>				

020M06

020M06




Standard value		Permissible value		Standard value		Permissible value	

Machine model				PC05-6	
Serial No.				11301 — 11700	
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value
Work equipment	Time lag	<ul style="list-style-type: none"> Measuring posture  <p>20RF5117</p>	sec.	Max. 2.0	Max. 2.0
		<ul style="list-style-type: none"> Engine speed: Low idling Oil temperature: 45 — 55°C Time required to momentarily stop the arm. 			
		<ul style="list-style-type: none"> Measuring posture  <p>20RF5118</p>		Max. 1.0	Max. 1.0
	<ul style="list-style-type: none"> Engine speed: Low idling Oil temperature: 45 — 55°C Time required to momentarily stop the bucket. 				
	Blade	<ul style="list-style-type: none"> Measuring posture  <p>20RF5119</p>		Max. 1.0	Max. 1.0
		<ul style="list-style-type: none"> Engine speed: Low idling Oil temperature: 45 — 55°C Measure the time it takes for the rear of the machine to be lifted off the ground, starting from the time the blade contacts the ground. 			
Internal leakage	Each cylinder	<ul style="list-style-type: none"> Oil temperature: 45 — 55°C Oil pressure: 175 kg/cm² 	cc/min.		
	Swivel joint				

020M06

020M06

PC05-6		PC07-1		PC10-6	
11701 and up		10001 and up		10501 and up	
Standard value	Permissible value	Standard value	Permissible value	Standard value	Permissible value
0	Max. 1	0	Max. 1	Max. 5	Max. 5
0	Max. 1	0	Max. 1	Max. 4	Max. 4
0	Max. 1	0	Max. 1	Max. 2	Max. 2
				Max. 1.1	Max. 1.1
				Max. 10	Max. 10

Machine model				PC15-2	
Serial No.				10001 and up	
Classification	Item	Condition, etc.	Unit	Standard value	Permissible value
Work equipment	Time lag	<ul style="list-style-type: none"> Measuring posture  <p style="text-align: right;">20RF5117</p>	sec.	Max. 5	Max. 5
		<ul style="list-style-type: none"> Engine speed: Low idling Oil temperature: 45 — 55°C Time required to momentarily stop the arm. 			
		<ul style="list-style-type: none"> Measuring posture  <p style="text-align: right;">20RF5118</p>		Max. 4	Max. 4
	<ul style="list-style-type: none"> Engine speed: Low idling Oil temperature: 45 — 55°C Time required to momentarily stop the bucket. 				
	Blade	<ul style="list-style-type: none"> Measuring posture  <p style="text-align: right;">20RF5119</p>		Max. 2	Max. 2
		<ul style="list-style-type: none"> Engine speed: Low idling Oil temperature: 45 — 55°C Measure the time it takes for the rear of the machine to be lifted off the ground, starting from the time the blade contacts the ground. 			
Internal leakage	Each cylinder	<ul style="list-style-type: none"> Oil temperature: 45 — 55°C Oil pressure: 175 kg/cm² 	cc/min.	Max. 1.1	Max. 1.1
	Swivel joint			Max. 10	Max. 10

020M06

020M06

Standard value		Permissible value		Standard value		Permissible value	

TESTING AND ADJUSTING TOOL LIST

• FOR ENGINE

No.	Check item	Tool	Part No.	Remarks
1	Engine speed	Multi-tachometer	799-203-8000	Digital display L: 60 — 2,000 rpm H: 60 — 19,999 rpm
2	Water and oil temperature	Thermistor kit	799-101-6000	-50 — 1,200°C
3	Oil pressure	Analog hydraulic tester	799-101-5000	25, 60, 400, 600 kg/cm ²
		Digital hydraulic tester	790-261-1100	500 kg/cm ²
4	Compression pressure	Compression gauge	795-502-1205	0 — 70 kg/cm ²
		• Adapter (3D72-2, 3D75-2)	795-101-1560	
		• Adapter (3D78-1)	795-502-1530	
5	Blow-by pressure	Blow-by checker	799-201-1504	0 — 500 mmH ₂ O
6	Valve clearance	Feeler gauge		0.20 mm
7	Exhaust color	Handy smoke checker	799-201-9000	Discoloration 0 — 70% With standard color (Discoloration % x 1/10 = Bosch index)
		Smoke meter	Commercially available	

020M06

• FOR CHASSIS

No.	Check item	Tool	Part No.	Remarks
1	Oil temperature	Thermistor kit	799-101-6000	-50 — 1200°C
2	Oil pressure	Analog hydraulic tester D	799-101-5000	25, 60, 400, 600 kg/cm ²
		Digital hydraulic tester	790-261-1100	500 kg/cm ²
3	Engine speed	Multi-tachometer	799-203-8000	Digital display L: 60 — 2,000 rpm H: 60 — 19,999 rpm
4	Operating force	Push-pull scale	Commercially available	—
5	Stroke, hydraulic drift	Scale	Commercially available	—
6	Work equipment speed	Stopwatch	Commercially available	—
5	Pump performance	Flowmeter kit	790-303-1002	—

ADJUSTING VALVE CLEARANCE (PC05-6, PC07-1)

1. Remove the cylinder head cover.
2. Rotate the crankshaft in the normal direction (clockwise as seen from the fan) and when No. 3 cylinder (flywheel end) is at compression top dead center, look through the hole in the flywheel housing, and align the line (TDC) on the outside of the flywheel with the position that can be seen.


★ When the crankshaft is rotated, the intake and exhaust valves of the cylinder near the compression top dead center position do not move.

If the intake and exhaust valves of No. 1 cylinder move, rotate further and set to the compression top dead center position.

3. To adjust, loosen locknut (1), and turn adjustment screw (2). Then insert specified feeler gauge A in clearance "c" between the rocker arm and the valve stem and turn the adjustment screw until the clearance is a sliding fit.

★ To check, insert the feeler gauge between rocker arm (3) and valve stem (4) to check if the clearance (gauge thickness) is a sliding fit.




4. Tighten the locknut to hold the adjustment screw in position.

 Locknut: 2.6 ± 0.1 kgm

★ After tightening the locknut, check the valve clearance again.

5. Rotate turn the crankshaft 240° each time, and use the same procedure to check and adjust the valve clearance of next cylinder according to the firing order.

★ Firing order: 3 - 1 - 2




078F201

020M06


ADJUSTING VALVE CLEARANCE (PC10-6, PC15-2)

1. Remove the cylinder head cover.
2. Rotate the crankshaft in the normal direction (clockwise as seen from the fan) to align timing mark (a) with the top dead center (TDC) line (b) on the crankshaft pulley when No. 3 cylinder (at the flywheel end) is at compression top dead center.




★ When the crankshaft is rotated, the intake and exhaust valves of the cylinder near compression top dead center do not move. If the intake and exhaust valves of No. 3 cylinder move, rotate further to align at the compression top dead center.

3. To adjust, loosen locknut (1), and adjustment screw (2), insert feeler gauge A in clearance (C) between the rocker arm and the valve stem, and screw in adjustment screw (2) until the clearance is a sliding fit.



★ When checking, before loosening the locknut, insert feeler gauge between rocker arm (3) and valve stem (4), and check if it is a sliding fit.


4. Tighten the locknut to hold the adjustment screw in position.

 Locknut 2.6 ± 0.1 kgm

★ After tightening the locknut, check the clearance again.

5. Turn the crankshaft 240° each time and check and adjust the valve clearance of the next cylinder in the firing order in the same way.

★ Firing order: 3 — 1 — 2



078F201


020M06

MEASURING COMPRESSION PRESSURE (PC05-6, PC07-1)

⚠ When measuring the compression pressure, be careful not to touch the exhaust manifold or muffler, or to get caught in the rotating parts.

★ Measure the compression pressure with the engine warmed up.
(Oil temperature 40°C – 60°C)


1. Adjust the valve clearance.
For details, see Adjusting valve clearance.
2. Disconnect the fuel injection pipe.
3. Remove the nozzle holder assembly (1) from each cylinder.
 - ★ Be careful not to let dirt or dust get inside.
 - ★ If the nozzle holder assembly is removed, replace the seat gasket.
4. Install adapter A in the nozzle holder mount of the cylinder to be measured, and tighten to the specified tightening torque.

 Tightening torque: 5.2 ± 0.2 kgm

5. Connect compression gauge A to the adapter. Place the fuel control lever at the NO INJECTION position. Crank the engine with the starting motor and measure the compression pressure at the point where the indicator remains steady.

⚠ If the fuel control lever is not placed at the NO INJECTION position, fuel will spurt out.

★ Leakage can be reduced if the adapter mount is coated with a small amount of oil.



020M06

MEASURING COMPRESSION PRESSURE (PC10-6, PC15-2)

⚠ When measuring the compression pressure, be careful not to touch the exhaust manifold or muffler, or to get caught in rotating parts.

★ Measure the compression pressure with the engine warmed up. (Oil temperature 40 — 60°C).

1. Adjust the valve clearance.

★ For details, see ADJUSTING VALVE CLEARANCE.

2. Disconnect fuel injection pipe.

3. Remove nozzle holder assembly (1) from each cylinder.

★ Be careful not to let any dirt or dust get in.

★ If the nozzle holder assembly is removed, replace the seat gasket.

4. Install the adapter in the nozzle holder mount of the cylinder to be measured.


5. Connect the compression gauge to the adapter.

6. Place the fuel control lever in the NO INJECTION position. Crank the engine with the starting motor and measure the compression pressure.

★ Measure the compression pressure at the point where the pressure gauge indicator remains steady.

⚠ If the fuel control lever is not placed in the NO INJECTION position, fuel will spurt out.

★ Coat the adapter mount with a small amount of oil to make it more difficult for the pressure to leak out.



TESTING AND ADJUSTING FUEL INJECTION TIMING (PC05-6, PC07-1)




1. Disconnect the fuel injection pipe.
2. Using crankshaft pulley mounting nut (1), rotate the crankshaft in the normal direction and stop the crankshaft at the point where the fuel level at the tip of the delivery valve holder starts to rise.
3. When the fuel level at the tip of the delivery valve holder starts to rise, check that the line (11° BTDC) on the outside of the flywheel is in the center of the peephole.
4. If the injection timing is not correct, adjust the thickness of the shim (fuel injection timing adjustment plate) between the fuel injection pump and gear case.

INCREASE shim thickness, to RETARD timing

DECREASE shim thickness, to ADVANCE timing

- ★ When adjusting, be careful of the following points.


- (1) The standard thickness of the shims used for adjusting the fuel injection timing is 0.5 mm.
- (2) The adjustment shims have a silicon coating, so use thinner to remove any oil on both faces of the shim or on the pump mounting surface.
- (3) A shim thickness of 0.1 mm changes the position by approx. 1°; the available shim thicknesses are 0.2 mm and 0.3 mm.



020M06

TESTING AND ADJUSTING FUEL INJECTION TIMING (PC10-6, PC15-2)




1. Disconnect fuel injection pipe (1).
2. To bleed the air, run the engine until no more bubbles come out from delivery valve holder (2).
3. Place the fuel control lever at the FULL position, and rotate the crankshaft slowly in the normal direction. Check the point where fuel starts flowing from the delivery valve holder.
4. Check that fuel injection timing line (b) on the crankshaft pulley and timing mark (a) are aligned at the point where the fuel starts flowing.



20NF06051


- ★ BEYOND injection timing line:
Timing RETARDED
- ★ BEFORE injection timing line:
Timing ADVANCED
- ★ If the test shows that the fuel injection timing is not correct, adjust as follows.


- 1) Loosen the mounting nut of the fuel injection pump and adjust the mounting angle of the pump while watching timing lines (c) and (d) on the front plate.
- 2) Rotate the crankshaft slowly in the normal direction and adjust the mounting angle of the pump until fuel injection timing line (b) on the crankshaft pulley and timing mark (a) are aligned correctly at the point where the fuel starts flowing.
- 3) Tighten the injection pump mounting nut.
 - ★ Check the fuel injection timing again to confirm that the injection timing is correctly adjusted.
- 4) Make match marks.



020M06

TESTING AND ADJUSTING HYDRAULIC PRESSURE (PC05-6, PC07-1)

 Lower the work equipment completely to the ground and stop the engine. Operate the control levers several times to release the remaining pressure in the hydraulic piping. Then loosen the oil filler plate slowly to release the pressure inside the hydraulic tank.



1. Measuring

1) Remove the pressure pick-up plugs (1) or (2) from the side to be measured, and install hydraulic pressure gauge A (350 kg/cm²).

★ Plug (1): For boom, bucket, R.H. travel, blade


Plug (2): For L.H. travel, arm, swing, boom swing

2) Run the engine, operate the circuit to be measured, and measure the relief pressure.

★ With the swing circuit, the set pressure of the safety valve is lower than the set pressure of the main relief valve, so the main relief valve is not actuated.

★ When relieving the swing circuit, insert the swing lock pin securely.

When relieving the travel circuit, fit a block (height: 300mm) under the track shoe grouser to lock the track, and measure one side at a time.



F20M06039

2. Adjusting

★ If the result of the measurement shows that there is an abnormality in the set pressure, adjust the set pressure of the main relief valve as follows.

1) Loosen locknut (5) of the main relief valve (3) or (4) on the side to be adjusted, turn adjustment screw (6), and adjust the set procedure.

★ (3): For boom, bucket, R.H. travel, blade


(4): For L.H. travel, arm, swing, boom swing

★ Turn the adjustment screw to adjust as follows.

To INCREASE pressure, turn CLOCKWISE

To DECREASE pressure, turn COUNTERCLOCKWISE

★ One turn of the adjustment screw adjusts by:



20SF151A

020M06

TESTING AND ADJUSTING HYDRAULIC PRESSURE (PC10-6, PC15-2)

- ⚠** Lower the work equipment to the ground and stop the engine. Operate the control levers several times to release the remaining pressure in the hydraulic piping. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Measuring

- Remove pressure pick-up plugs (1), (2), or (3) from the circuit to be measured, and install oil pressure gauge A (350 kg/cm²).
 - Plug (1): For boom swing, boom, bucket, R.H. travel
 - Plug (2): For arm, L.H. travel
 - Plug (3): For blade, swing
- Start the engine, operate the circuit to be measured, and measure the relief pressure.

- ★ With the swing circuit, the set pressure of the safety valve is lower than the set pressure of the main relief valve, so the main relief valve is not actuated.
- ★ When relieving the swing circuit, insert the swing lock pin securely. When relieving the travel circuit, fit a block (height: 300 mm) under the track shoe grouser and measure one side at a time.





2. Adjusting

- ★ If the results of the check show that there is an abnormality in the set pressure, adjust the set pressure of the main relief valve as follows.

- Loosen locknut (7) of main relief valve (4), (5), or (6) of the circuit to be adjusted, then turn adjustment screw (8) to adjust the set pressure.
 - (4): For boom swing, boom, bucket, R.H. travel
 - (5): For arm, L.H. travel
 - (6): For blade, swing

- ★ Turn the adjustment screw to adjust as follows.
To INCREASE pressure, turn CLOCKWISE.
To DECREASE pressure, turn COUNTER-CLOCKWISE.

- ★ One turn of the adjustment screw adjusts by:



20SF151B

020M06

30 DISASSEMBLY AND ASSEMBLY

020M06

RADIATOR		CONTROL VALVE	
Removal	30- 2	Disassembly	30-50
Installation	30- 2	Assembly	30-50
ENGINE		SWING MOTOR	
Removal	30- 6	Removal	30-52
Installation	30- 8	Installation	30-52
SWING CIRCLE		TRAVEL MOTOR	
Removal	30-20	Removal	30-54
Installation	30-24	Installation	30-54
HYDRAULIC PUMP		Disassembly	
Removal	30-36	30-56	
Installation	30-36	Assembly	
7-SPOOL CONTROL VALVE		30-62	
Removal	30-38	CENTER SWIVEL JOINT	
Installation	30-40	Removal	30-68
8-SPOOL CONTROL VALVE		Installation	30-68
Removal	30-42	Disassembly	30-72
Installation	30-44	Assembly	30-72
2-SPOOL CONTROL VALVE		WORK EQUIPMENT	
Removal	30-46	Removal	30-74
Installation	30-46	Installation	30-74
6-SPOOL CONTROL VALVE		BLADE	
Removal	30-48	Removal	30-74
Installation	30-48	Installation	30-74

- ★ Take the following method for air bleeding when you start to operate hydraulic cylinders after reassembling cylinders, pumps and pipings.
1. Start engine and run at low idling.
 2. Operate hydraulic cylinder 4 to 5 times, stopping 100 mm from stroke end.
 3. Next, operate cylinder 3 to 4 times to stroke end.
 4. After doing this, run engine at normal speed.
- ★ After repair or long storage, follow the same procedure.

REMOVAL OF RADIATOR ASSEMBLY (PC05-6, PC07-1)

1. Loosen drain valve (1) and drain cooling water. (See P1)
 - ★ If the coolant contains antifreeze, dispose of it correctly.
2. Open hood (2), and remove gas damper spring (3). (See P2)
3. Remove 4 mounting bolts (4) of hood, then remove hood (2). (See P2)
4. Remove 6 mounting bolts (5) of canopy, then remove canopy assembly (6). (See F1)
5. Disconnect radiator inlet hose (7) and radiator outlet hose (8). (See F2)
6. Remove radiator assembly (9). (See F2)


INSTALLATION OF RADIATOR ASSEMBLY (PC05-6, PC07-1)

1. Install radiator assembly (9). (See F2)
2. Connect radiator inlet hose (7) and radiator outlet hose (8). (See F2)
3. Align canopy assembly (6) with mounting position, and tighten with bolts (5). (See F1)
4. Align hood (2) with mounting position, and tighten with bolts (4). (See P2)
5. Install gas damper spring (3). (See P2)
6. Tighten drain valve (1) and add water through water filler to the specified level. (See P1)
 - ★ Run the engine to circulate the water through the system. Then check the water level again.

P1




P2




020M06

F1



F2



REMOVAL OF RADIATOR ASSEMBLY (PC10-6, PC15-2)

1. Remove gas spring (1), then remove hood (2). (See P1)

2. Remove canopy (3). (See F1)

3. Engine cover

1) Remove cap (4). (See F2)

2) Remove 7 mounting bolts (5), then remove engine cover (6). (See F2)



Engine cover:

★ When removing the bolts, do not forget to remove the bolt at portion (a). It can be removed through the mounting hole of cap (4).

4. Radiator assembly

1) Loosen drain valve and drain cooling water.

★ If the coolant contains antifreeze, dispose of it correctly.

2) Disconnect piping cooler inlet hose (7), outlet hose (8), air intake hose (9), radiator inlet hose (10), and outlet hose (11), then remove bracket mounting bolts (12), and remove radiator assembly (13) together with piping cooler. (See F3)

★ The piping cooler is installed to the PC15-2 only.

INSTALLATION OF RADIATOR ASSEMBLY (PC10-6, PC15-2)

1. Install radiator assembly (13) together with piping cooler, then install bracket mounting bolts (12). (See F3)

2. Install radiator outlet hose (11), inlet hose (10), air intake hose (9), piping cooler outlet hose (8), and inlet hose (7). (See F3)

★ The piping cooler is installed to the PC15-2 only.

3. Align engine cover (6) with mounting position, and tighten 7 mounting bolts (5). (See F2)

★ When tightening the bolts, do not forget to tighten the bolt at portion (a). It can be tightened through the mounting hole of cap (4).

4. Install cap (4). (See F2)


5. Install canopy (3). (See F1)

6. Install hood (2), then install gas spring (1). (See P1)

7. Tighten drain valve and add water through water filler.


★ Run the engine to circulate the water through the system. Then check the water level again.

P1



20NP06008


F1



20NF06052


020M06

F2






20NF06053

F3




20NF06054

REMOVAL OF ENGINE ASSEMBLY (PC05-6 Serial No: 11301-11700)


1. Remove radiator assembly.
For details, see REMOVAL OF RADIATOR ASSEMBLY.
2. Disconnect fuel hose (1). (See P1)
3. Loosen lock bolt (2), and disconnect fuel control cable (3). (See P1)
4. Disconnect cable from negative (–) terminal (4) of battery. (See P2)
5. Disconnect alternator wiring (5). (See P3)
6. Disconnect oil pressure switch wiring (6). (See P4)
7. Disconnect water temperature switch wiring (7). (See P4)
8. Disconnect glow plug wiring (8). (See P5)
9. Disconnect starting motor wiring (9), (10), and (11). (See F1)
10. Disconnect engine ground connection wiring (12). (See P6)
11. Disconnect spill hose (13). (See P7)
12. Hydraulic pump piping
 -  Loosen the oil filler plate slowly to release the pressure inside the hydraulic tank.
 - 1) Remove drain plug (1) and drain oil from hydraulic tank.
 -  Hydraulic tank: Approx. 18.5 ℓ
 - 2) Disconnect piping (14), (15), and (16). (See P8)
13. Sling engine assembly, and remove nuts (17) of mount bolts. (See F2)
14. Lift off engine assembly (18). (See F2)
 -  Engine assembly: 123 kg

P1




P20M06007

P2




P20M06008

P3




P20M06009

P4




P20M06010

P5




P20M06011

F1




F20M06042

P6




P20M06012

P7




P20M06013

P8




P20M06014

F2




F20M06043

INSTALLATION OF ENGINE ASSEMBLY (PC05-6 Serial No: 11301-11700)

1. Install cushion (19). (See P1)
 2. Raise engine assembly (18) and set in mounting position. (See F1)
 3. Tighten nuts (17) of mount bolts. (See F1)
 4. Fit O-rings and connect piping (16), (15), and (14). (See P2)
 5. Connect spill hose (13). (See P3)
 6. Connect engine ground connection wiring (12). (See P4)
 7. Connect starting motor wiring (11), (10), and (9). (See F2)
 8. Connect glow plug wiring (8). (See P5)
 9. Connect water temperature switch wiring (7). (See P6)
 10. Connect oil pressure switch wiring (6). (See P6)
 11. Connect alternator wiring (5). (See P7)
 12. Connect cable to negative (—) terminal (4) of battery. (See P8)
 13. Connect fuel control cable (3). (See P9)
 14. Connect fuel hose (1). (See P9)
 15. Install radiator assembly.
For details, see INSTALLATION OF RADIATOR ASSEMBLY.
 16. Tighten drain plug and add oil through oil filler to the specified level.
 Hydraulic tank: Approx. 18.5 ℓ
- ★ Run the engine to circulate the oil through the system. Then check the oil level again.


020M06

P1



P20M06015

F2




F20M06042

P5




P20M06011

F1




F20M06043

P6




P20M06010

P2




P20M06014

P7




P20M06009

P8



P20M06008

P3




P20M06013

P4






P20M06012

P9




P20M06007

REMOVAL OF ENGINE ASSEMBLY (PC05-6 Serial No: 11701 and up, PC07-1)

1. Remove radiator assembly.
For details, see REMOVAL OF RADIATOR ASSEMBLY.
2. Loosen lock bolt (1), and disconnect fuel control cable (2). (See P1)
3. Disconnect engine stop motor wiring (3). (See P1)
4. Disconnect fuel hoses (4), (5), and (6). (See F1)
5. Disconnect cable from negative (-) terminal (7) of battery. (See P2)
6. Disconnect alternator wiring (8). (See P3)
7. Disconnect oil pressure switch wiring (9). (See P4).
8. Disconnect water temperature switch wiring (10). (See P4)
9. Disconnect glow plug wiring (11). (See P5)
10. Disconnect starting motor wiring (12), (13), and (14). (See F2)
11. Disconnect engine ground connection wiring (15). (See P6)
12. Disconnect spill hose (16). (See P7)
13. Hydraulic pump piping
 -  Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
 - 1) Remove drain plug and drain oil from hydraulic tank.
 -  Hydraulic tank: Approx. 18.5 ℓ
 - 2) Disconnect piping (17), (18), and (19). (See P8)
14. Sling engine assembly, and remove nuts (20) of mounting bolts. (See F3)
15. Lift off engine assembly (21). (See F3)
 -  Engine assembly: 123 kg


P1




P5




F2




F1




P6




P7




P2




P3




P8



P4



F3




020M06

**INSTALLATION OF ENGINE
ASSEMBLY
(PC05-6 Serial No: 11701 and up,
PC07-1)**

1. Install cushion (22). (See P1)
2. Raise engine assembly (21) and set in mounting position. (See F1)
3. Tighten nuts (20) of mounting bolts. (See F1)
4. Fit O-ring and connect piping (19), (18), and (17). (See P2)
5. Connect spill hose (16). (See P3)
6. Connect engine ground connection wiring (15). (See P4)
7. Connect starting motor wiring (14), (13), and (12). (See F2)
8. Connect glow plug wiring (11). (See P5)
9. Connect water temperature switch wiring (10). (See P6)
10. Connect oil pressure switch wiring (9). (See P6)
11. Connect alternator wiring (8). (See P7)
12. Connect cable to negative (-) terminal (7) of battery. (See P8)
13. Connect fuel hoses (6), (5), and (4). (See F3)


020M06

P1



P2OM06015A

F2




F2OM06042A

P5




P2OM06011A

F1



F2OM06043A


P6



P2OM06010A


020M06

P2




P2OM06014A

P7




P2OM06009A

P8




P2OM06008B

P3




P2OM06013A

P4



P2OM06012A

F3



20MF06060


14. Connect engine stop motor wiring (3).
(See P1)
15. Connect fuel control cable (2), and lock with lock bolt (1). (See P1)
16. Install radiator assembly.
For details, see INSTALLATION OF RADIATOR ASSEMBLY.
17. Tighten drain plug and add oil through oil filler of hydraulic tank.



Hydraulic tank: Approx. 18.5 ℓ

- ★ Run the engine to circulate the oil through the system. Then check the oil level again.

P1





020M06

REMOVAL OF ENGINE ASSEMBLY (PC10-6, PC15-2)

1. Remove radiator assembly.
For details, see REMOVAL OF RADIATOR ASSEMBLY.
2. Disconnect fuel control cable (1). (See P1)
3. Disconnect engine stop motor wiring (2). (See P1)
4. Disconnect fuel hoses (3) and (4). (See P1, P2)
★ Fuel will leak out. So fit blind plugs.
5. Disconnect cable from negative (-) terminal (5) of battery. (See P3)
6. Disconnect water temperature sensor wiring (6), alternator wiring (7), and starting motor wiring (8). (See P4)


7. Disconnect oil pressure switch wiring (9). (See P5)
8. Disconnect heater wiring (10). (See P6)

9. Disconnect engine ground connection (11). (See P7)
10. Remove 2 clamps, and disconnect muffler tail pipe (12). (See P8)

11. Pump piping
 - 1) Remove drain plug and drain oil from hydraulic tank.
 Hydraulic tank: Approx. 30 l
 - 2) Remove 2 pump inlet tubes (13) and 3 outlet tubes (14). (See P9)
★ Oil will come out, so loosen the mounting bolts slowly and catch the oil in an oil pan or other container.
12. Remove nuts (15) of mounting bolts, and lift off engine assembly (16). (See F1)
 Engine assembly: 159kg (PC10-6)
184kg (PC15-2)

020M06


P1




P2




P9




P3




P4



F1




P5




P6




P7




P8




INSTALLATION OF ENGINE ASSEMBLY (PC10-6, PC15-2)

1. Raise engine assembly (16) and align with mounting position, then tighten nuts (15) of mounting bolts. (See F1)
 2. Fit O-rings and connect 2 pump inlet tubes (13) and 3 outlet tubes (14). (See P1)
 3. Install muffler tail pipe (12), and secure with 2 clamps (See P2)
 4. Connect engine ground connection (11). (See P3)
 5. Connect heater wiring (10). (See P4)
 6. Connect oil pressure switch wiring (9). (See P5)
 7. Connect starting motor wiring (8), alternator wiring (7), and water temperature sensor wiring (6). (See P6)
 8. Connect cable to negative (-) terminal (5) of battery. (See P7)
 9. Connect fuel hoses (4) and (3). (See P8, P9)
 10. Connect engine stop motor wiring (2). (See P9)
 11. Connect fuel control cable (1). (See P9)
 12. Install radiator assembly.
For details, see INSTALLATION OF RADIATOR ASSEMBLY.
 13. Tighten drain plug and add oil through oil filler of hydraulic tank.
 Hydraulic tank: Approx. 30 l
- ★ Run the engine to circulate the oil through the system. Then check the oil level again.


F1




P6



P7




P1




P8




P9




P2




P3



P4




P5



020M06

REMOVAL OF SWING CIRCLE ASSEMBLY (PC05-6, PC07-1)

 Retract the bucket and arm cylinder rods fully, lower the work equipment completely to the ground and stop the engine. Operate the control levers several times to release the remaining pressure in the hydraulic piping. Then loosen the oil filler plate slowly to release the pressure inside the hydraulic tank.

1. Disconnect boom cylinder hoses (1) and (2). (See P1)

2. Raise boom cylinder assembly (3) and remove connecting pin (4), then lower on to block (height: approx. 500 mm) (See P2)

3. Disconnect 4 arm and bucket cylinder hoses (5). (See P3)

4. Disconnect head lamp wiring (6). (See P3)

5. Sling work equipment assembly, and remove connecting pin (7). (See F1)

6. Lift off work equipment assembly (8). (See F1)



Work equipment assembly:

Approx. 130 kg

7. Pull out connecting pin (9), and remove boom cylinder assembly (3). (See F2)

8. Remove drain plug (10) and drain oil from hydraulic tank. (See F3)



Hydraulic tank: Approx. 18.5 ℓ

9. Remove operator's seat (11). (See P4)

10. Remove lever knob (12) and boot (13). (See P4)


11. Remove plate (14). (See F4)

12. Remove safety lock lever (15) and stay (16). (See F4)

13. Remove floor plate (17). (See F4)


14. Remove mounting bolts (18), then remove canopy assembly (19). (See F5)

P1




P2OM6016

F2




F2OM6045

P2




P2OM6017

F3



F2OM6046


P4



P2OM6019


020M06

P3




P2OM6018

F4




F2OM6047

F1



F2OM6044

F5



F2OM6055

15. Remove battery (20). (See P1)
★ Disconnect the cable from the negative (-) terminal of the battery.

22. Remove swing circle mounting bolts (28). (See P5)
23. Using lifting tool, lift off swing circle assembly (29). (See P5)



Swing circle assembly: 29 kg

16. Disconnect 7 hoses (21) at top of swivel joint (See P2)
17. Remove stopper (22). (See P2)
18. Disconnect swing motor hoses (23) and (24), and remove swing motor assembly (25). (See P2)
19. Remove 7-spool control valve assembly and valve control.
For details, see REMOVAL OF 7-SPOOL CONTROL VALVE ASSEMBLY.


20. Rotate revolving frame assembly, and remove mounting bolts (26). (See P3)
★ If all the mounting bolts are removed, the revolving frame will fall over, so leave 2 or 3 mounting bolts in position.

21. Sling revolving frame (27), and remove remaining mounting bolts, then remove revolving frame. (See P4)




Revolving frame assembly:


P1




P5




P2



P3



P4



020M06

INSTALLATION OF SWING CIRCLE ASSEMBLY (PC05-6, PC07-1)

1. Using lifting tool, raise swing circle assembly 290, and set to track frame. (See P1)
 - ★ Set so that the soft zone (S marks) on both the inside and outside rings are the right side.
2. Tighten swing circle mounting bolts (28). (See P1)



Mounting bolt:

Thread tightener (LT-2)



Mounting bolt: 6.75 ± 0.75 kgm

- ★ After installing, coat the inside tooth surface of the swing circle with grease (G2-LI).
3. Raise revolving frame assembly (27), and install. (See P2)
 - ★ Be careful not to catch the swivel joint or hoses when installing the revolving frame.
 - ★ Temporarily tighten 2 or 3 mounting bolts of the revolving frame.

4. Rotate revolving frame assembly, and install mounting bolts (26). (See P3)



Mounting bolt: 6.75 ± 0.75 kgm

5. Install 7-spool control valve assembly and valve control.
For details, see INSTALLATION OF 7-SPOOL CONTROL VALVE ASSEMBLY.
6. Install swing motor assembly (25), and connect hoses (24) and (23). (See P4)
7. Connect stopper (22). (See P4)
8. Connect 7 hoses (21) at top of swivel. (See P4)

9. Align boom cylinder assembly (3) with mounting position, and install connecting pin (9). (See F1)

10. Raise work equipment assembly (8) and align with mounting position. (See F2)

11. Install connecting pin (7), and lock with bolt. (See F2)


12. Connect 4 arm and bucket cylinder hoses (5). (See P5)

13. Connect head lamp wiring (6). (See P5)

14. Sling boom cylinder assembly (3), then extend piston rod, and install connecting pin (4). (See P6)


020M06

P1




P20M06024

F1




F20M06045

P2



P20M06023


F2



F20M06044


020M06

P3




P20M06022

P5




P20M06018

P4



P20M06021

P6



P20M06017

15. Connect boom cylinder hoses (2) and (1).
(See P1)

22. Install operator's seat (11). (See P3)
23. Tighten drain plug (10) and add oil through oil filler to the specified level. (See F3)
★ Run the engine to circulate the oil through the system. Then check the oil level again.


16. Raise canopy assembly (19) and align with mounting position, then install bolts (18).
(See F1)

17. Install floor plate (17). (See F2)
18. Install stay (16) and safety lock lever (15).
(See F2)
19. Install plate (14). (See F2)
20. Install boot (13) and lever knob (12). (See F2)


21. Install battery (20). (See P2)
★ Connect the cable to the negative (–) terminal of the battery.

020M06


P1




P3




F3




F1



F2



P2



020M06

REMOVAL OF SWING CIRCLE ASSEMBLY (PC10-6, PC15-2)



Retract the piston rods of the bucket and arm cylinders fully, then lower the work equipment to the ground and stop the engine. Operate the control levers several times to release the remaining pressure in the hydraulic piping. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Disconnect boom cylinder hoses (1) and (2). (See F1)
2. Raise boom cylinder assembly (3) and remove connecting pin (4), then lower on block (height: approx. 500 mm). (See P1)

3. Disconnect 4 arm and bucket cylinder hoses (5). (See F2)
4. Disconnect head lamp wiring (6). (See F2)

5. Sling work equipment assembly, and remove connecting pin (7). (See F3)
6. Lift off work equipment assembly (8). (See F3)



Work equipment assembly:
191 kg (PC10-6)
205 kg (PC15-2)

7. Pull out connecting pin (9), and remove boom cylinder assembly (3). (See F4)

8. Remove canopy assembly (10). (See P2)
9. Remove operator's seat (11). (See P2)
10. Remove drain plug (12) and drain oil from hydraulic tank. (See F5)




Hydraulic tank: Approx. 30 l

11. Remove seat (13). (See F6)
12. Remove boom swing lever knob (14). (See F6)
13. Remove floor plates (15) and (16). (See F6)
14. Remove seat bracket (17). (See F6)


15. Disconnect 7 hoses (18) at top of swivel. (See P3)
16. Remove stopper (19). (See P3)
17. Disconnect swing motor hose (20), and remove swing motor assembly (21). (See P4)
18. Remove 6-spool control valve assembly, 2-spool control valve assembly, and valve control.

For details, see REMOVAL OF CONTROL VALVE ASSEMBLY.


F1




F4




P1




P2




F5




F2




F6




F3



P3



P4



020M06

19. Rotate revolving frame assembly, and remove mounting bolts (22). (See P1)

- ★ If all the mounting bolts are removed, the revolving frame will tip over, so leave 2 or 3 mounting bolts in position.

20. Sling revolving frame assembly (23), remove remaining mounting bolts, then remove revolving frame assembly carefully. (See F1)

- ★ Be careful not to catch the center swivel joint or hoses.



Revolving frame assembly:


21. Remove swing circle mounting bolts (24).

22. Using lifting tool, lift off swing circle assembly (25). (See P2)




Swing circle assembly: 29 kg


P1



F1




P2



020M06

INSTALLATION OF SWING CIRCLE ASSEMBLY (PC10-6, PC15-2)

1. Using lifting tool, raise swing circle assembly (25), and install to track frame. (See P1)
 - ★ Install so that the soft zones (marked S) of both the inside and outside circles are on the left side.
2. Install swing circle mounting bolts (24). (See P1)


 Mounting bolt: Thread tightener (LT-2)

 Mounting bolt: 11.5 ± 1.0 kgm

- ★ After installing, coat the surface of the swing circle inside teeth with grease (G2-LI).

3. Raise revolving frame assembly (23), and install. (See F1)
 - ★ Be careful not to catch the center swivel joint or hoses.
 - ★ Tighten 2 or 3 mounting bolts of the revolving frame temporarily.

4. Rotate revolving frame assembly and install remaining mounting bolts (22). (See P2)

 Mounting bolt: 11.5 ± 1.0 kgm

5. Install 6-spool control valve assembly, 2-spool control valve assembly, and valve control.

For details, see INSTALLATION OF CONTROL VALVE ASSEMBLY.

6. Install swing motor assembly (21), and connect motor hose (20). (See P3)
7. Install stopper (19). (See P4)
8. Connect 7 hoses (18) at top of swivel. (See P4)


9. Install seat bracket (17). (See F2)
10. Install floor plates (15) and (16). (See F2)
11. Install boom swing lever knob (14). (See F2)
12. Install seat (13). (See F2)

13. Align boom cylinder assembly (3) with mounting position, and install connecting pin (9). (See F3)


14. Raise work equipment assembly (8) and align with mounting position. (See F4)
15. Install connecting pin (7), and lock with bolt. (See F4)

16. Connect 4 arms and bucket cylinder hoses (5). (See F5)
17. Connect head lamp wiring (6). (See F5)


P1




F2




F1




F3




P2




F4




P3



P4



F5



020M06

18. Sling boom cylinder assembly (3), and extend piston rod, then install connecting pin (4).
(See P1)

19. Connect boom cylinder hoses (1) and (2).
(See F1)


- 20. Install operator's seat (11). (See P2)
- 21. Install canopy assembly (10). (See P2)
- 22. Tighten drain plug (12) and add oil through oil filler. (See F2)



Hydraulic tank: Approx. 30ℓ


- ★ Run the engine to circulate the oil through the system. Then check the oil level again.

P1



ZONP06018


F1



ZONF06056


020M06

P2




ZONP06019

F2




ZONF06060

REMOVAL OF HYDRAULIC PUMP ASSEMBLY (PC05-6, PC07-1)

 Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Remove drain plug (1) and drain oil from hydraulic tank. (See F1)


 Hydraulic tank: Approx. 18.5 ℓ

2. Open hood.
3. Disconnect hydraulic pump piping (2), (3), and (4). (See P1)
4. Remove mounting bolts (5), then remove hydraulic pump assembly (6). (See P2)


INSTALLATION OF HYDRAULIC PUMP ASSEMBLY (PC05-6, PC07-1)

1. Install hydraulic pump assembly (6), and tighten mounting bolts (5). (See P2)
2. Connect hydraulic pump piping (4), (3), and (2). (See P1)
3. Tighten drain plug (1) and add oil through oil filler to the specified level. (See F1)
 - ★ Run the engine to circulate the oil through the system. Then check the oil level again.

REMOVAL OF HYDRAULIC PUMP (PC10-6, PC15-2)

 Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Remove drain plug (1) and drain oil from hydraulic tank. (See F2)


 Hydraulic tank: Approx. 30ℓ

2. Open hood.
3. Disconnect 2 hydraulic pump inlet tubes (2) and 3 outlet tubes (3). (See P3)
4. Remove mounting bolts, then remove hydraulic pump assembly (4). (See P4)


INSTALLATION OF HYDRAULIC PUMP ASSEMBLY (PC10-6, PC15-2)

1. Install hydraulic pump assembly (4), and tighten mounting bolts. (See P4)
2. Connect 3 hydraulic pump outlet tubes (3) and 2 inlet tubes (2). (See P3)
3. Tighten drain plug (1) and add oil through
 - ★ Run the engine to circulate the oil through the system. Then check the oil level again.
4. Close hood.


F1




F2



P1




P3




020M06

P2



P4



REMOVAL OF 7-SPOOL CONTROL VALVE ASSEMBLY (PC05-6, PC07-1)



Retract the bucket and arm cylinder rods fully, lower the work equipment completely to the ground and stop the engine. Operate the control levers several times to release the remaining pressure in the hydraulic piping. Then loosen the oil filler plate slowly to release the pressure inside the hydraulic tank.

1. Remove drain plug (1) and drain oil from hydraulic tank. (See F1)



Hydraulic tank: Approx. 18.5 ℓ

2. Remove work equipment hoses (2), (3), (4), (5), (6), and (7). (See P1)

3. Remove lever knob (8) and boot (9). (See F2)

4. Remove plate (10). (See F2)

5. Remove safety lock lever (11) and stay (12). (See F2)

6. Remove floor plate (13). (See F2)

7. Disconnect all tubes (14) and hoses (15) from valve ports. (See P2)

8. Remove mounting bolts from bottom of revolving frame, then remove lever (16). (See P3)


9. Remove bracket (17). (See P3)

10. Remove 7 yokes (18) of spool from bottom of revolving frame. (See P4)


11. Remove 7-spool control valve assembly (19). (See P5)

★ FOR MACHINE EQUIPPED WITH SWING-BOOM SWING SELECTOR PEDAL


F1




P3




P1




P4




F2



P5




P2




020M06

INSTALLATION OF 7-SPOOL CONTROL VALVE ASSEMBLY (PC05-6, PC07-1)


1. Install 7-spool control valve assembly (19). (See P1)
2. Install 7 yokes (18) of spool from bottom of revolving frame. (See P2)
3. Install bracket (17) and bar (16). (See P3)
4. Connect tubes (14) and hoses (15) to valve port. (See P4)
5. Install floor plate (13). (See F1)
6. Install stay (12) and safety lock lever (11). (See F1)
7. Install plate (10). (See F1)
8. Install boot (9) and lever knob (8). (See F1)
9. Install work equipment hoses (7), (6), (5), (4), (3), and (2). (See F5)
10. Tighten drain plug (1) and add oil through oil filler to the specified level. (See F2)
 Hydraulic tank: Approx. 18.5 ℓ
★ Run the engine to circulate the oil through the system. Then check the oil level again.

★ FOR MACHINE EQUIPPED WITH SWING-BOOM SWING SELECTOR PEDAL


P1




F1



P2




P5




020M06


P3



F2



P4



REMOVAL OF 8-SPOOL CONTROL VALVE ASSEMBLY (PC05-6, PC07-1)



Retract the piston rods of the bucket and arm cylinders fully, then lower the work equipment to the ground and stop the engine. Operate the control levers several times to release the remaining pressure in the hydraulic piping. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Remove drain plug (1) and drain oil from hydraulic tank. (See F1)



Hydraulic tank: Approx. 18.5 l

2. Remove work equipment hoses (2), (3), (4), (5), (6), and (7). (See P1)

3. Remove lever knob (8) and boot (9). (See F2)
4. Remove plate (10). (See F2)
5. Remove safety lock lever (11) and stay (12). (See F2)
6. Remove floor plate (13). (See F2)

7. Disconnect all tubes (14) and hoses (15) from valve ports. (See P2)

8. Remove mounting bolts from bottom of revolving frame, then remove lever (16). (See P3)


9. Remove bracket (17). (See P3)

10. Remove 8 yokes (18) of spools from bottom of revolving frame. (See P4)


11. Remove 8-spool control valve assembly (19). (See F3)

★ FOR MACHINE WITHOUT SWING-BOOM SWING SELECTOR PEDAL


F1




P3



P1




P4




020M06


F2




F3



P2




INSTALLATION OF 8-SPOOL CONTROL VALVE ASSEMBLY (PC05-6, PC07-1)


1. Install 8-spool control valve assembly (19).
(See F1)
 2. Install 8 yokes (18) of spools from bottom
of revolving frame. (See P1)
 3. Install bracket (17) and lever (16). (See P2)
 4. Connect tubes (14) and hoses (15) to valve
ports. (See P3)
 5. Install floor plate (13). (See F2)
 6. Install stay (12) and safety lock lever (11).
(See F2)
 7. Install plate (10). (See F2)
 8. Install boot (9) and lever knob (8). (See F2)
 9. Install work equipment hoses (7), (6), (5), (4),
(3), and (2). (See P4)
 10. Tighten drain plug (1) and add oil through
oil filler. (See F3)
 Hydraulic tank: Approx. 18.5 l
- ★ Run the engine to circulate the oil through
the system. Then check the oil level again.

★ FOR MACHINE WITHOUT SWING-BOOM SWING SELECTOR PEDAL


F1




F2



P1




P4




020M06


P2



F3



P3



REMOVAL OF 2-SPOOL CONTROL VALVE ASSEMBLY (PC10-6, PC15-2)

1. Remove drain plug (1) and drain oil from hydraulic tank. (See F1)



Hydraulic tank: Approx. 30ℓ

2. Remove operator's seat (2). (See P1)
3. Remove seat (3). (See F2)
4. Remove swing lever knob (4). (See F2)
5. Remove floor plates (5) and (6). (See F2)
6. Remove seat bracket (7). (See F2)
7. Disconnect all piping (8) from valve ports. (See P2)
8. Disconnect 2 yokes (9) of spools. (See P2)
9. Remove 2-spool control valve assembly (10). (See P2)

INSTALLATION OF 2-SPOOL CONTROL VALVE ASSEMBLY (PC10-6, PC15-2)

1. Install 2-spool control valve assembly (10). (See P2)
2. Connect 2 yokes (9) of spools. (See P2)
3. Connect all piping (8) to valve ports. (See P2)

★ Be careful not to mistake the sets when connecting the piping.


4. Install seat bracket (7). (See F2)
5. Install floor plates (5) and (6). (See F2)
6. Install swing lever knob (4). (See F2)
7. Install seat (3). (See P1)
8. Install operator's seat (2). (See P1)
9. Tighten drain plug (1) and add oil through oil filler.




Hydraulic tank: Approx. 30ℓ

- ★ Run the engine to circulate the oil through the system. Then check the oil level again.


F1




P1



F2



P2



020M06

REMOVAL OF 6-SPOOL CONTROL VALVE ASSEMBLY (PC10-6, PC15-2)

1. Remove drain plug (1) and drain oil from hydraulic tank. (See F1)



Hydraulic tank: Approx. 30ℓ

2. Remove operator's seat (2). (See P1)
3. Remove seat (3). (See F2)
4. Remove swing lever knob (4). (See F2)
5. Remove floor plates (5) and (6). (See F2)
6. Remove seat bracket (7). (See F2)
7. Disconnect all piping (8) from valve ports. (See P2)
8. Disconnect yokes (9) (6 places) of spools. (See P3)
9. Remove 6-spool control valve assembly (10). (See P3)

INSTALLATION OF 6-SPOOL CONTROL VALVE ASSEMBLY (PC10-6, PC15-2)

1. Install 6-spool control valve assembly (10). (See P3)

2. Connect yokes (9) (6 places) of spools. (See P3)

3. Connect all piping (8) to valve ports. (See P2)

★ Be careful not to mistake the sets when connecting the piping.

4. Install seat bracket (7). (See F2)

5. Install floor plates (5) and (6). (See F2)

6. Install swing lever knob (4). (See F2)

7. Install seat (3). (See F2)

8. Install operator's seat (2). (See P1)

9. Tighten drain plug (1) and add oil through oil filler. (See F1)




Hydraulic tank: Approx. 30ℓ

★ Run the engine to circulate the oil through the system. Then check the oil level again.


020M06

F1




20NF06063

P3




20NP06029

P1




20NP06026

F2



20NF06065

P2






20NP06028

020M06


DISASSEMBLY OF CONTROL VALVE ASSEMBLY

- ★ The set pressure of the safety valve cannot be adjusted when it is on the machine, so do not disassemble it.
- 1. Remove main relief valve (1) and safety-suction valve (2). (See F1)
- 2. Remove case (3), then remove spool assembly (4). (See F1)
- 3. Remove plate (5) on opposite side, then remove oil seal (6). (See F1)
- 4. Disassembly of spool
 - 1) Assemble removed spool assembly to body, and remove bolt (7), then remove collar (8), retainer (9), and spring (10). (See F1)
 - 2) Remove retainer (9) and plate (5), then remove oil seal (6) from spool (11). (See F1)
- 5. Remove plug (12), then remove spring (13) and check valve (14). (See F1)

ASSEMBLY OF CONTROL VALVE ASSEMBLY

1. Assemble check valve (14) and spring (13), then fit O-ring and install plug (12). (See F1)
 Plug: 3.5 ± 0.5 kgm
2. Assembly of spool
 - 1) Assemble oil seal (6), plate (5), retainer (9), and spring (10) to spool (11). (See F1)
 - 2) Fit collar (8) and tighten bolt (7) temporarily. (See F1)
 - 3) Insert spool in body, and tighten bolt (7). (See F1) Bolt: 0.85 ± 0.15 kgm
3. Assemble oil seal (16) to opposite side, and install plate (5). (See F1)
4. Install case (3). (See F1)
5. Fit O-rings and install safety-suction valve (2) and main relief valve (1). (See F1)
 Safety-suction valve: 4.5 ± 0.5 kgm
Main relief valve: 5.5 ± 0.5 kgm

F1



020M06

F20M06048

REMOVAL OF SWING MOTOR ASSEMBLY (PC05-6, PC07-1)

1. Remove operator's seat (1). (See P1)
2. Disconnect hoses (2) and (3), and remove swing motor assembly (4). (See P2)

REMOVAL OF SWING MOTOR ASSEMBLY (PC10-6, PC15-2)

1. Remove operator's seat (1). (See P3)
2. Remove seat (2). (See F1)
3. Remove swing lever knob (3). (See F1)
4. Remove floor plates (4) and (5). (See F1)
5. Remove seat bracket (6). (See F1)
6. Disconnect hoses (7), then disconnect swing motor assembly (8). (See P4)

INSTALLATION OF SWING MOTOR ASSEMBLY (PC05-6, PC07-1)


1. Install swing motor assembly (4), and connect hoses (3) and (2).
2. Install operator's seat (1). (See P1)

INSTALLATION OF SWING MOTOR ASSEMBLY (PC10-6, PC15-2)

1. Install swing motor assembly (8), and connect hoses (7). (See P4)
2. Install seat bracket (6). (See F1)
3. Install floor plates (4) and (5). (See F1)
4. Install swing lever knob (3). (See F1)
5. Install seat (2). (See F1)
6. Install operator's seat (1). (See P3)


020M06

P1



P20M06031

P3




PC10
20NP06030

P2




P20M06032

F1



20NF06067

P4



20NP06031

020M06


REMOVAL OF TRAVEL MOTOR ASSEMBLY

1. Remove track shoe assembly.
2. Remove cover (1). (See P1)
3. Disconnect motor tubes (2), (3), and (4).
(See P2)
4. Remove motor mounting bolts (5), and raise travel motor assembly (6), then tap it with a plastic hammer, and remove it together with sprocket. (See P3)


INSTALLATION OF TRAVEL MOTOR ASSEMBLY

1. Install travel motor assembly (6) to track frame, and tighten bolts (5). (See P3)
2. Connect motor tubes (4), (3), and (2).
(See P2)
3. Install cover (1). (See P1)
4. Install track shoe assembly.


P1



P2



P3



020M06


DISASSEMBLY OF TRAVEL MOTOR ASSEMBLY (PC05-6, PC07-1)

DISASSEMBLY OF FINAL DRIVE ASSEMBLY

1. Remove mounting bolts and snap ring, then remove cover (1). (See P1)
2. Remove snap ring, then remove No. 2 sun gear (2). (See P2)
3. Remove O-ring and snap ring.
4. Remove No. 2 planetary carrier assembly (3) together with gear. (See P3)
5. Remove snap ring.
6. Remove thrust washer (4), No. 2 planetary gear (5), and needle bearing (6). (See P4)
7. Remove snap ring, then remove No. 1 sun gear (7). (See P5)
8. Remove snap ring, then remove thrust washer (8), No. 1 planetary gear (9), and needle bearing. (See P6)
9. Tighten final drive flange and hydraulic motor flange in a vice, and remove snap ring (10). (See F1, P7)


020M06

P1




P20M06036

P5




P20M06040

P2




P20M06037

P6




P20M06041

P3




P20M06038

F1




F20M06049

P4



P20M06039

P7



P20M06042

020M06

10. Remove ring gear (11). (See P1)

14. Remove bearing (15) and snap ring (16).
(See F1)

11. Remove floating seal (12) and O-ring. (See
P2)

DISASSEMBLY OF HYDRAULIC MOTOR AND VALVE ASSEMBLY

15. Pull out spool assembly (17) from body.
(See P5)

12. Remove hydraulic motor assembly (13).
(See P3)


16. Remove mounting bolts, then remove valve
body (18) together with valve plate. (See
P6)

13. Remove seal ring (14). (See P4)


17. Remove valve plate (19) from valve body.
(See P7)

020M06


P1




F1



P2




P5




020M06


P3




P6



P4



P7



18. Remove bearing (20) and spring pin. (See P1)

22. Remove snap ring (24) from cylinder, then remove retainer (25) and spring (26). (See F1)

23. Remove holder (27) and pin (28). (See F1)

19. Remove O-ring, then remove cylinder assembly (21). (See P2)


24. Remove swash plate (29). (See P5)

20. Remove piston assembly (22). (See P3)

25. Remove shaft (30). (See P6)


21. Remove piston (23) from shoe holder. (See P4)

P1




P20M06050

F1




F20M06051

P2




P20M06051

P5




P20M06054

P3




P20M06052

P6



P20M06055

P4



P20M06053

020M06

**ASSEMBLY OF TRAVEL MOTOR
ASSEMBLY
(PC05-6, PC07-1)**

**ASSEMBLY OF HYDRAULIC MOTOR
AND VALVE ASSEMBLY**

1. Install shaft (30). (See P1)
 - ★ Coat the surface of the oil seal lip with grease.

2. Install swash plate (29). (See P2)

3. Install pin (28) and holder (27) to cylinder. (See F1)
4. Assemble retainer (25) and spring (26), and secure with snap ring (24). (See F1)

5. Install piston (23) to shoe holder. (See P3)

6. Assemble piston assembly (22) to cylinder. (See P4)


7. Install cylinder assembly (21), then install O-ring. (See P5)
 - ★ Check that the shoe is securely in contact with the swash plate.

8. Install spring pin and bearing (20). (See P6)


9. Install valve plate (19) to valve body. (See P7)
 - ★ Fill the inside of the valve body with approx. 150 cc of engine oil (SAE30-CD).

020M06


P1




P4




P2




P5




F1




P6



P3




P7




020M06

10. Install valve body (18). (See P1)

 Mounting bolt: 2.6 – 3.3 kgm

14. Install hydraulic motor assembly (13). (See P4)

11. Install spool assembly to valve body. (See P2)

 Plug: 17 – 20 kgm

15. Install O-ring and floating seal (12). (See P5)

★ The O-ring is easier to install if it is coated with grease.

ASSEMBLY OF FINAL DRIVE ASSEMBLY

12. Install bearing (15) and snap ring (16) to ring gear. (See F1)

16. Install ring gear (11). (See P6)


13. Install seal ring (14). (See P3)

- ★ Coat the O-ring portion with grease.
- ★ Install with the seal surface at the top.

17. Tighten final drive flange and hydraulic motor flange in a vice, and install snap ring (10). (See F2 and P1 on next page)


★ The preload of the bearing is adjusted by the thickness of the snap ring.

P1




P20M06048

P4



P20M06045

P2




P20M06047

P5




P20M06044

F1




F20M06050

P6




P20M06043

P3



P20M06046

F2



F20M06049

020M06

21. Install No. 2 planetary carrier assembly (3).
(See P5)


18. Install needle bearing, No. 1 planetary gear
(9), and thrust washer (8), and secure with
snap ring. (See P2)

22. Install No. 2 sun gear (2), and secure with
snap ring. (See P6)
23. Install O-ring.

19. Install No. 1 sun gear (7) to No. 2 planetary
carrier, and secure with snap ring. (See P3)


24. Install cover (1), then install snap ring. (See
P7)

★ Be careful not to damage the O-ring.

 Mounting bolt: 1.2 – 1.5 kgm

★ Wind seal tape round the bolt.


25. Add lubrication oil.

 Final drive: Approx. 300 cc

20. Install needle bearing (6), No. 2 planetary
gear (5), and thrust washer (4), and secure
with snap ring. (See P4)


020M06

P1




P20M06042

P5




P20M06038

P2




P20M06041

P6




P20M06037

P3




P20M06040

P7



P20M06036

P4



P20M06039

020M06

REMOVAL OF CENTER SWIVEL JOINT ASSEMBLY (PC05-6, PC07-1)


1. Remove revolving frame assembly.
For details, see REMOVAL OF SWING CIRCLE ASSEMBLY.
2. Raise track frame, and put block (height: approx. 300 mm) under track shoe, then jack up track frame.
3. Disconnect travel motor hoses (1), (2), (3), (4), and (5). (See F1)
4. Disconnect blade cylinder hoses (6) and (7). (See F1)
5. Remove mounting bolts, then remove center swivel joint assembly (8) together with bracket. (See P1)

INSTALLATION OF CENTER SWIVEL JOINT ASSEMBLY (PC05-6, PC07-1)


1. Set center swivel joint assembly (8) in mounting position together with bracket, and tighten mounting bolts. (See P1)
2. Connect blade cylinder hoses (7) and (6). (See F1)
3. Connect travel motor hoses (5), (4), (3), (2), and (1). (See F1)
4. Lower track frame.
5. Install revolving frame assembly.
For details, see INSTALLATION OF SWING CIRCLE ASSEMBLY.

020M06

F1



P1



020M06

REMOVAL OF CENTER SWIVEL JOINT ASSEMBLY (PC10-6, PC15-2)

1. Put block (height: approx. 300 mm) under track shoe, and jack up chassis.



Lower the work equipment to the ground and stop the engine. Operate the control levers several times to release the remaining pressure in the hydraulic piping. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

2. Remove drain plug (1) and drain oil from hydraulic tank. (See F1)



Hydraulic tank: Approx. 30ℓ

3. Remove seat (2). (See F2)
4. Remove swing lever knob (3). (See F2)
5. Remove floor plates (4) and (5). (See F2)
6. Disconnect all piping (6) at top of swivel. (See P1)
7. Remove stopper (7). (See P1)
8. Disconnect all piping (8) at bottom of swivel. (See F3)
9. Remove center swivel joint assembly (9). (See F3)

INSTALLATION OF CENTER SWIVEL JOINT ASSEMBLY (PC10-6, PC15-2)


1. Install center swivel joint assembly (9). (See F3)
2. Connect all piping (8) at bottom of swivel. (See F3)
3. Install stopper (7). (See P1)
4. Connect piping (6) at top of swivel. (See P1)
5. Install floor plates (4) and (5). (See F2)
6. Install swing lever knob (3). (See F2)
7. Install seat (2). (See F2)
8. Tighten drain plug (1) and add oil through oil filler. (See F1)




Hydraulic tank: Approx. 30ℓ

- ★ Run the engine to circulate the oil through the system. Then check the oil level again.
9. Lower chassis to ground.


F1




F2



P1



F3



020M06

DISASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY (PC05-6, PC07-1)

1. Remove flange (1) and O-ring (2). (See F1)
2. Remove snap ring (3), then remove washer (4), and pull out swivel shaft (5) from rotor (6). (See F1)
3. Remove backup ring (7) and O-rings (8) and (9) from rotor (6). (See F1)

ASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY (PC05-6, PC07-1)

- ★ Coat the O-rings with engine oil before assembling.
1. Assemble O-rings (9) and (8), and backup ring (7) to rotor (1). (See F1)
 2. Install swivel shaft (5) to rotor (6), then assemble washer (4), and secure with snap ring (3). (See F1)
 3. Assemble O-ring (2), and install flange (1). (See F1)

DISASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY (PC10-6, PC15-2)


1. Remove flange (1) and O-ring (2). (See F2)
2. Remove snap ring (3), then remove washer (4), and pull out swivel shaft (5) from rotor (6). (See F2)
3. Remove O-ring (7) from rotor (6). (See F2)

ASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY (PC10-6, PC15-2)


- ★ Coat the O-rings with engine oil before assembling.
1. Assemble O-ring (7) to rotor (6). (See F2)
 2. Install swivel shaft (5) to rotor (6), and assemble washer (4), then lock with snap ring (3). (See F2)
 3. Assemble O-ring (2), and install flange (1). (See F2)

020M06

F1




F2



020M06

REMOVAL OF WORK EQUIPMENT ASSEMBLY

 Extend the arm and bucket fully, lower the work equipment assembly completely to the ground and stop the engine. Operate the control levers several times to release the remaining pressure in the hydraulic piping. Then loosen the oil filler plate slowly to release the pressure inside the hydraulic tank.

1. Disconnect boom cylinder hoses (1) and (2). (See P1)
2. Raise boom cylinder assembly (3), then remove connecting pin (4), and lower on to block (height: approx. 500 mm). (See P2)
3. Disconnect 4 arm and bucket cylinder hoses (5). (See P3)
4. Disconnect head lamp wiring (6). (See P3)
5. Sling work equipment assembly, and remove connecting pin (7). (See F1)
6. Lift off work equipment assembly (8). (See F1)

INSTALLATION OF WORK EQUIPMENT ASSEMBLY

1. Raise work equipment assembly (8) and align with mounting position. (See F1)
2. Install connecting pin (7), and secure with bolt. (See F1)
3. Connect 4 arm and bucket cylinder hoses (5). (See P3)
4. Connect head lamp wiring (6). (See P3)
5. Sling boom cylinder assembly (3), then extend piston rod, and install connecting pin (4). (See P2)
6. Connect boom cylinder hoses (2) and (1). (See P1)

REMOVAL OF BLADE ASSEMBLY

1. Sling blade cylinder assembly (1), and remove bottom pin (2), then lower blade cylinder assembly (1). (See P4)
2. Sling blade assembly (3), and remove pin (4). (See P4)
3. Lift off blade assembly (3). (See P4)




Blade assembly: 30 kg


INSTALLATION OF BLADE ASSEMBLY

1. Raise blade assembly (3) and set in position, then install pin (4). (See P4)
2. Raise blade cylinder assembly (1) and set in position, then install bottom pin (2). (See 4)


P1




P4




P2



P3



F1



020M06



40 MAINTENANCE STANDARD

Swing circle	40- 2
Track frame and recoil spring	40- 4
Idler	40- 6
Track roller	40-12
Track shoe	40-15
Hydraulic pump	40-18
7-spool control valve	40-22
8-spool control valve	40-24
1-spool control valve	40-25
5-spool control valve	40-26
6-spool control valve	40-27
2-spool control valve	40-28
Travel motor brake valve	40-29
Hydraulic cylinder	40-30
Work equipment	40-36


020M06

SWING CIRCLE

PC05-6, PC07-1



Section A - A




20MF06014


020M06

				Unit: mm
No.	Check item	Criteria		Remedy
		Standard clearance	Clearance limit	
1	Axial clearance of bearing	0.2 - 0.3	0.6	Replace
2	Backlash between swing pinion and swing circle	0.138 - 0.561	1.0	

PC10-6, PC15-2



020M06





20NF06024
Unit: mm

No.	Check item	Criteria		Remedy
		Standard clearance	Clearance limit	
1	Axial clearance of bearing	0.05 – 0.25	0.4	Replace
2	Backlash between swing pinion and swing circle	0.12 – 0.73	1.4	

TRACK FRAME AND RECOIL SPRING

PC05-6, PC07-1




F20M06026

020M06


Unit: mm

No.	Check item	Criteria				Remedy	
			Standard size	Repair limit			
1	Vertical width of idler guide	Track frame	77 ± 1.0			Rebuild or replace	
		Idler support	75 ± 0.5				
2	Horizontal width of idler guide	Track frame	131				
		Idler	129				
3	Recoil spring	Standard size		Repair limit		Replace	
		Free length	Installed length	Installed load	Free length		Installed load
		200	168	709 kg			

PC10-6, PC15-2



020M06




20NF06025

Unit: mm

No.	Check item	Criteria				Remedy	
			Standard size	Repair limit			
1	Vertical width of idler guide	Track frame	96			Rebuild or replace	
		Idler support	94				
2	Horizontal width of idler guide	Track frame	161				
		Idler	159				
3	Recoil spring	Standard size			Repair limit		Replace
		Free length	Installed length	Installed load	Free length	Installed load	
		209.3	177	1,400 kg	204.5	1,190 kg	

IDLER

PC05-6 Serial No. 11301 – 11700



020M06


20MF023A

020M06

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size		Repair limit			
1	Outside diameter of protrusion	247		241		Rebuild or replace	
2	Outside diameter of tread	227		221			
3	Width of protrusion	23		17			
4	Overall width	60		55			
5	Width of tread	18.5		21.5			
6	Axial play of shaft	Repair limit: 1.3				Replace bushing	
7	Clearance between idler shaft and bushing	Standard size	Tolerance		Standard clearance	Clearance limit	Replace
			Shaft	Hole			
8	Clearance between idler shaft and support	25	0 -0.021	+0.033 0	0 – 0.054	1.5	
		25	0 -0.021	+0.75 0.67	0.67 – 0.771	1.5	

PC05-6 Serial No. 11701 and up
PC07-1




020M06

20MFO6015

Unit: mm

No.	Check item	Criteria				Remedy
		Standard size	Tolerance		Repair limit	
1	Outside diameter of protrusion	247			241	Rebuild of replace
		227			221	
2	Outside diameter of tread	227			221	
3	Width of protrusion	23			17	
4	Overall width	60			55	
5	Width of tread	18.5			21.5	
6	Axial play of shaft	Repair limit: 1.3				Replace bushing
7	Clearance between idler shaft and bushing	Standard size	Tolerance		Standard clearance	Clearance limit
		25	Shaft	Hole		
8	Clearance between idler shaft and support	25	0 -0.021	+0.750 +0.670	0.670 – 0.771	1.5
		25	0 -0.021	+0.033 0	0 – 0.054	

PC10-6, PC15-2



020M06


20NF06026

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size		Repair limit			
1	Outside diameter of protrusion					Rebuild of replace	
		338		330			
2	Outside diameter of tread	300		292			
3	Width of protrusion	28		20			
4	Overall width	64		59			
5	Width of tread	18		22			
	Clearance between idler shaft and bushing	Standard size	Tolerance		Standard clearance	Clearance limit	Replace
			Shaft	Hole			
	35	-0.025 -0.064	+0.142 +0.080	0.105 – 0.206	1.5		
	Clearance between idler shaft and support	35	-0.025 -0.064	+0.060 0	0.025 – 0.124	1.5	
	Axial play of shaft	Repair limit: 2.0				Replace bushing	

TRACK ROLLER

PC05-6 Serial No. 11301 – 11700




20MF022

Unit: mm

No.	Check item	Criteria				Remedy	
1	Outside diameter of flange	Standard size		Repair limit		Rebuild or replace	
		96		90			
		80		74			
		20.5		23.5			
2	Outside diameter of tread	80		74		Rebuild or replace	
3	Width of tread	20.5		23.5			
4	Width of flange	23		20		Replace bushing	
5	Clearance between track roller shaft and bushing	Standard size	Tolerance		Standard clearance		Clearance limit
		25	Shaft	Hole	0.670 – 0.802		1.5
6	Interference between track roller and bushing	Standard size	Tolerance		Standard interference		Interference limit
		35	Shaft	Hole	0.040 – 0.240	–	
7	Side clearance of roller	Standard size		Repair limit		Replace	
		0.25		1.3			

020M06

PC05-6 Serial No. 11701 and up




20MF06016

020M06

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size		Repair limit			
1	Outside diameter of flange	Standard size		Repair limit		Rebuild or replace	
		96		90			
2	Outside diameter of tread	80		74			
3	Width of tread	20.5		23.5			
4	Width of flange	23		20			
5	Clearance between track roller shaft and bushing	Standard size	Tolerance		Standard clearance	Clearance limit	Replace bushing
			Shaft	Hole			
6	Interference between track roller and bushing	Standard size	Tolerance		Standard interference	Interference limit	
			Shaft	Hole			
7	Side clearance of roller	Standard size		Repair limit		Replace	
		0.25		1.3			

PC10-6, PC15-2



20NF06027



020M06

Unit: mm

No.	Check item	Criteria				Remedy
		Standard size		Repair limit		
1	Outside diameter of flange	115		107		Rebuild or replace
2	Outside diameter of tread	85		77		
3	Width of tread	20		23		
4	Width of flange	10.5		7.5		
5	Clearance between track roller shaft and bushing	Standard size	Tolerance		Standard clearance 0.144 – 0.196	Clearance limit 0.009
		25	Shaft 0 –0.013	Hole +0.183 +0.144		
6	Interference between track roller and bushing	Standard size	Tolerance		Standard interference 0.009 – 0.073	Interference limit –
		32	Shaft +0.073 +0.043	Hole –0.039 0		
7	Side clearance of roller	Standard size		Repair limit		Replace
		0.2		2.0		

TRACK SHOE

PC05-6 (FOR MACHINE EQUIPPED WITH SWING-BOOM SWING SELECTOR PEDAL)




20MF024

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size	Tolerance		Repair limit		
1	Link pitch	90			92	Repair or replace	
		16			5		
2	Height of grouser	46			41		
3	Height of link	22			18		
4	Outside diameter of bushing	Standard size	Tolerance		Standard interference		Interference limit
		14	Shaft	Hole	0.100 – 0.104		
5	Interference between link and regular pin	22	+0.154 +0.150	+0.050 0	0.100 – 0.104		Replace
6	Interference between link and bushing	Standard size	Tolerance		Standard clearance	Clearance limit	
7	Clearance between master pin and bushing	14	-0.020 -0.050	+0.300 +0.200	0.202 – 0.305		

020M06

PC05-6 (FOR MACHINE WITHOUT SWING – BOOM SWING SELECTOR PEDAL)
 PC07-1





20MFO6017

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size	Tolerance		Repair limit		
1	Link pitch	90			92	Repair or replace	
2	Height of grouser	15			5		
3	Height of link	46			41		
4	Outside diameter of bushing	22			18		
5	Interference between link and regular pin	Standard size 14	Tolerance		Standard interference 0.100 – 0.105	Interference limit –	
			Shaft	Hole			
6	Interference between link and bushing	22	+0.154 +0.150	+0.050 0	0.100 – 0.154	–	Replace
7	Clearance between master pin and bushing	Standard size 14	Tolerance		Standard interference 0.020 – 0.100	Interference limit 0.8	
			Shaft	Hole			

020M06

PC10-6, PC15-2



20NF06028

Unit: mm


No.	Check item	Criteria				Remedy	
		Standard size		Repair limit			
1	Link pitch	90				Repair or replace	
2	Height of grouser	21		6.5			
3	Height of link	46		55			
4	Outside diameter of bushing	22		26.5			
5	Interference between link and regular pin	Standard size	Tolerance		Standard interference	Interference limit	Replace
		19	Shaft	Hole	0.070 – 0.150	–	
6	Interference between link and bushing	32	+0.150	+0.050	0.070 –	–	
			+0.120	0	0.150		
7	Clearance between master pin and bushing	Standard size	Tolerance		Standard interference	Interference limit	
		19	Shaft	Hole	0.020 – 0.120		
			–0.020	+0.050			
		–0.070	0				

020M06

HYDRAULIC PUMP

PC05-6 (Serial No. 11301 – 11700)

1. MAIN PUMP



20MF226A


020M06

Unit: mm

No.	Check item	Criteria				Remedy
		Standard clearance		Clearance limit		
1	Clearance between side plate and gear	0.05 – 0.10		0.15		Replace if damaged, or deformed
		0.060 – 0.119		0.20		
2	Clearance between I.D. and gear shaft dia.	0.05 – 0.10		0.15		
		0.060 – 0.119		0.20		
3	Delivery (SAE10W 45 – 55°C)	Pump speed (rpm)	Discharge pressure (kg/cm ²)	Standard value (ℓ/min)	Repair limit (ℓ/min)	
		3,500	175	20	17	

PC05-6 (Serial No. 11701 and up)

PC07-1




F20M06027-1

020M06

						Unit: mm
No.	Check item	Criteria				Remedy
1	Clearance between side plate and gear	Standard clearance		Clearance limit		Replace it damaged, or deformed
		0.05 – 0.10		0.15		
2	Clearance between inside diameter and gear shaft diameter	Standard clearance		Clearance limit		
		0.060 – 0.119		0.20		
3	Delivery (SAE10W, 45–55°C)	Pump speed (rpm)	Discharge pressure (kg/cm ²)	Standard value (ℓ/min)	Repair limit (ℓ/min)	
		3,500	175	20	17	

PC10-6, PC15-2



20NF06029



020M06

Unit: mm



No.	Check item		Criteria				Remedy
			Standard clearance		Clearance limit		
1	Clearance between side plate and gear		0.05 – 0.10		0.15		
2	Clearance between bearing inside diameter and shaft outside diameter		0.060 – 0.119		0.20		
3	Delivery (SAE10W, 45–55°C)		Pump speed (rpm)	Discharge pressure (kg/cm ²)	Standard value (ℓ/min)	Repair limit (ℓ/min)	
		SBR8	3,500	210	26.8	25.2	
		SBR6	3,500	210	20.2	19.0	

7-SPOOL CONTROL VALVE

PC05-6, PC07-1




F20M06028



020M06

★ FOR MACHINE EQUIPPED WITH SWING-BOOM SWING SELECTOR PEDAL



F20M06029


020M06

Unit: mm


No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
		Free length	Installed length	Installed load	Free length	Installed load	
1	Main relief valve pilot poppet spring	—	24.9	22.1 kg	—	17.7 kg	Replace, if damaged, or deformed.
2	Main relief valve main valve spring	—	19.0	2.0 kg	—	1.6 kg	
3	Spool return spring	46.2	25.4	10.0 kg	—	8.0 kg	
4	Check valve spring	13.1	6.0	0.2 kg	—	0.16 kg	

8-SPOOL CONTROL VALVE


PC05-6, PC07-1




20MF06018




Section A - A




Section C - C



Section B - B



Section D - D



Section E - E



Section F - F

20MF06019



Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
1	Main relief valve pilot poppet spring	Free length	Installed length	Installed load	Free length	Installed load	Replace, if damaged, or deformed.
		29.6 x 9.5	24.9	22.1 kg	-	17.7 kg	
2	Main relief valve main valve spring	23.3 x 7.2	19.0	2.0 kg	-	1.6 kg	
3	Spool return spring	46.2 x 20.0	25.4	10.0 kg	-	8.0 kg	
4	Check valve spring	18.0 x 12.5	6.0	0.2 kg	-	0.16 kg	



1-SPOOL CONTROL VALVE

PC05-6

020M06




Section B - B



Section A - A

Section C - C




F20M06030

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size		Repair limit			
		Free length x O.D.	Installed length	Installed load	Free length	Installed load	
1.	Spool return spring	46.2 x	25.4	13.0 kg	-	-	Replace if damaged or deformed
2.	Check valve spring	13.1 x	6.0	0.2 kg	-	-	

5-SPOOL CONTROL VALVE

PC10-6, PC15-2




020M06

Unit: mm


No.	Check item	Standard size			Repair limit		Remedy
		Free length X.O.D.	Installed length	Installed load	Free length	Installed load	
1	Main relief valve pilot poppet spring	PC10-5	29.6 x 9.5	24.9	22.1 kg	28.7	Replace if damaged or deformed
		PC15-2	29.6 x 9.5	24.0	22.1 kg	28.7	
2	Main relief valve main valve spring	23.3 x 7.2	19.0	2.0 kg	—	—	
3	Spool return spring	46.2 x 20.0	25.4	10.0 kg	—	—	
4	Check valve spring	18.0 x 12.5	7.5	0.2 kg	—	—	

6-SPOOL CONTROL VALVE


PC10-6, PC15-2



20NF06030



Section A - A 3.5 ± 0.5 kgm



20NF06031A




Unit: mm

No.	Check item	Criteria					Remedy	
		Standard size			Repair limit			
		Free length x O.D.	Installed length	Installed load	Free length	Installed load		
1	Main relief valve pilot poppet spring	PC10-5	29.6 x 9.5	24.9	22.1 kg	28.7	17.7 kg	Replace if damaged or deformed
		PC15-2	29.6 x 9.5	24.0	25.3 kg	28.7	20.2 kg	
2	Main relief valve main valve spring	23.3 x 7.2	19.0	2.0 kg	—	—		
3	Spool return spring (Boom, arm, bucket)	46.2 x 20.0	25.4	10.0 kg	—	—		
4	Spool return spring (Travel)	40.7 x 20.6	25.4	13.0 kg	—	—		
5	Check valve spring	18.0 x 12.5	7.5	0.2 kg	—	—		

020M06

2-SPOOL CONTROL VALVE

PC10-6, PC15-2



20NF06032


Unit: mm

No.	Check item	Criteria				Remedy
		Standard size		Repair limit		
1	Main relief valve pilot poppet spring	Free length x O.D.	Installed length	Installed load	Free length	Installed load
				29.6 x 9.5	24.9	22.1 kg
2	Main relief valve main valve spring	23.3 x 7.2	19.0	2.0 kg	—	—
3	Spool return spring	40.7 x 20.6	25.4	13.0 kg	—	—
4	Check valve spring	18.0 x 12.5	6.0	0.2 kg	—	—

Replace, if damaged, or deformed.

TRAVEL MOTOR BRAKE VALVE

020M06




F20M06032


Unit: mm


No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
		Free length	Installed length	Installed load	Free length	Installed load	
1	Spool return spring	21.9	13.9	13.3 kg	-	-	Replace if damaged, or deformed
2	Check valve spring	13.7	8.0	0.52 kg	-	-	

HYDRAULIC CYLINDER

PC05-6 Serial No. 11301 – 11700

 Boom : 40 ± 4kgm
 Arm : 40 ± 4kgm
 Bucket : 40 ± 4kgm
 Boom swing: 40 ± 4kgm
 Blade : 45 ± 4.5kgm

 Boom : 18 ± 1.8kgm (Width across flats: 32)
 Arm : 25 ± 2.5kgm (Width across flats: 32)
 Bucket : 25 ± 2.5kgm (Width across flats: 32)
 Boom swing: 25 ± 2.5kgm (Width across flats: 32)
 Blade : 25 ± 2.5kgm (Width across flats: 32)




F20M06033

Unit: mm

No.	Check item	Criteria					Remedy	
		Cylinder	Standard size	Tolerance		Standard clearance		Clearance limit
				Shaft	Hole			
1	Clearance between piston rod and bushing	Boom	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Arm	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Bucket	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Boom swing	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Blade	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		2	Clearance between piston rod mounting pin and bushing	Boom	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310
Arm	30			-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
Bucket	30			-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
Boom swing	30			-0.020 -0.050	+0.117 +0.080	0.100 – 0.167	1.0	
Blade	35			-0.170 -0.209	+0.142 +0.080	0.250 – 0.351	1.0	
3	Clearance between cylinder bottom mounting pin and bushing	Boom	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Arm	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Bucket	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Boom swing	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Blade	35	-0.170 -0.209	+0.142 +0.080	0.250 – 0.351	1.0	

020M06

PC05-6 Serial No. 11701 and up




F20M06033


Unit: mm


020M06

No.	Check item	Criteria					Remedy	
		Standard size	Tolerance		Standard clearance	Clearance limit		
Cylinder	Shaft		Hole					
1	Clearance between piston rod and bushing	Boom	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Arm	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Bucket	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Boom swing	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Blade	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
2	Clearance between piston rod mounting pin and bushing	Boom	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	Replace bushing
		Arm	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Bucket	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Boom swing	30	-0.020 -0.053	+0.117 +0.080	0.100 – 0.170	1.0	
		Blade	35	-0.170 -0.209	+0.142 +0.080	0.250 – 0.351	1.0	
3	Clearance between cylinder bottom mounting pin and bushing	Boom	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Arm	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Bucket	30	-0.163 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Boom swing	30	-0.163 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Blade	35	-0.170 -0.209	+0.142 +0.080	0.250 – 0.351	1.0	

PC07-1

-  Boom : 45 ± 4.5kgm
- Arm : 42 ± 4.2kgm
- Bucket : 40 ± 4.0kgm
- Boom swing: 40 ± 4.0kgm
- Blade : 45 ± 4.5kgm

-  Boom : 18 ± 1.8kgm (Width across flats: 30)
- Arm : 27 ± 2.7kgm (Width across flats: 32)
- Bucket : 25 ± 2.5kgm (Width across flats: 32)
- Boom swing: 25 ± 2.5kgm (Width across flats: 32)
- Blade : 25 ± 2.5kgm (Width across flats: 32)




20MF06020

Unit: mm


No.	Check item	Criteria					Remedy	
		Cylinder	Standard size	Tolerance		Standard clearance		Clearance limit
				Shaft	Hole			
1	Clearance between piston rod and bushing	Boom	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Arm	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Bucket	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Boom swing	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
		Blade	30	-0.020 -0.072	+0.133 +0.007	0.027 – 0.205	0.505	
2	Clearance between piston rod mounting pin and bushing	Boom	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	Replace bushing
		Arm	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Bucket	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Boom swing	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Blade	35	-0.170 -0.209	+0.142 +0.080	0.250 – 0.351	1.0	
3	Clearance between cylinder bottom mounting pin and bushing	Boom	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Arm	30	-0.163 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Bucket	30	-0.163 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Boom swing	30	-0.163 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
		Blade	35	-0.170 -0.209	+0.142 +0.080	0.250 – 0.351	1.0	

020M06

PC10-6

 Boom : 55 ± 5.5kgm
 Arm : 55 ± 5.5kgm
 Bucket : 45 ± 4.5kgm
 Boom swing: 55 ± 5.5kgm
 Blade : 55 ± 5.5kgm

 Boom : 63 ± 6.3kgm (Width across flats: 41)
 Arm : 80 ± 8.0kgm (Width across flats: 46)
 Bucket : 43 ± 4.3kgm (Width across flats: 36)
 Boom swing: 66 ± 6.6kgm (Width across flats: 41)
 Blade : 63 ± 6.3kgm (Width across flats: 41)



20NF06034


Unit: mm

020M06

No.	Check item	Criteria					Remedy	
		Cylinder	Standard size	Tolerance		Standard clearance		Clearance limit
				Shaft	Hole			
1	Clearance between piston rod and bushing	Boom	35	-0.025 -0.087	+0.132 +0.006	0.031 – 0.219	0.519	
		Arm	40	-0.025 -0.087	+0.132 +0.006	0.031 – 0.219	0.519	
		Bucket	35	-0.025 -0.087	+0.132 +0.006	0.031 – 0.219	0.519	
		Boom swing	35	-0.025 -0.087	+0.132 +0.005	0.031 – 0.219	0.519	
		Blade	35	-0.025 -0.087	+0.132 +0.005	0.031 – 0.219	0.519	
		2	Clearance between piston rod mounting pin and bushing	Boom	35	0 -0.050	+0.142 +0.080	0.080 – 0.192
Arm	35			0 -0.050	+0.142 +0.080	0.080 – 0.192	1.0	
Bucket	30			0 -0.050	+0.117 +0.080	0.080 – 0.167	1.0	
Boom swing	35			0 -0.050	+0.142 +0.080	0.080 – 0.192	1.0	
Blade	35			0 -0.050	+0.142 +0.080	0.080 – 0.192	1.0	
3	Clearance between cylinder bottom mounting pin and bushing	Boom	35	0 -0.050	+0.142 +0.080	0.080 – 0.192	1.0	
		Arm	35	0 -0.050	+0.142 +0.080	0.080 – 0.192	1.0	
		Bucket	30	0 -0.050	+0.117 +0.080	0.080 – 0.167	1.0	
		Boom swing	35	0 -0.050	+0.142 +0.080	0.080 – 0.192	1.0	
		Blade	35	0 -0.050	+0.142 +0.080	0.080 – 0.192	1.0	

Replace bushing

PC15-2



20NF06035


Unit: mm

No.	Check item	Criteria					Remedy	
1	Clearance between piston rod and bushing	Cylinder	Standard size	Tolerance		Standard clearance	Clearance limit	
				Shaft	Hole			
		Boom	40	-0.025 -0.087	+0.132 +0.006	0.031 - 0.219	0.519	Replace bushing
		Arm	40	-0.025 -0.087	+0.132 +0.006	0.031 - 0.219	0.519	
		Bucket	35	-0.025 -0.087	+0.132 +0.006	0.031 - 0.219	0.519	
		Boom swing	35	-0.025 -0.087	+0.132 +0.006	0.031 - 0.219	0.519	
Blade	35	-0.025 -0.087	+0.132 +0.006	0.031 - 0.219	0.519			
2	Clearance between piston rod mounting pin and bushing	Boom	35	0 -0.050	+0.142 +0.080	0.080 - 0.192	1.0	
Arm		35	0 -0.050	+0.142 +0.080	0.080 - 0.192	1.0		
Bucket		30	0 -0.050	+0.117 +0.080	0.080 - 0.167	1.0		
Boom swing		35	0 -0.050	+0.142 +0.080	0.080 - 0.192	1.0		
Blade		35	0 -0.050	+0.142 +0.080	0.080 - 0.192	1.0		
3	Clearance between cylinder bottom mounting pin and bushing	Boom	35	0 -0.050	+0.142 +0.080	0.080 - 0.192	1.0	
		Arm	35	0 -0.050	+0.142 +0.080	0.080 - 0.192	1.0	
		Bucket	30	0 -0.050	+0.117 +0.080	0.080 - 0.167	1.0	
		Boom swing	35	0 -0.050	+0.142 +0.080	0.080 - 0.192	1.0	
		Blade	35	0 -0.050	+0.142 +0.080	0.080 - 0.192	1.0	


020M06

WORK EQUIPMENT


PC05-6 Serial No. 11301 - 11700




F20M06034



Section A - A




Section B - B




Section C - C




Section D - D



Section E - E




Section F - F




Section G - G


020M06




Section H - H




Section I - I




Section J - J



Section K - K



Section L - L



Section M - M



Section N - N




Section O - O

F20M06035


Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size	Tolerance		Standard clearance		Clearance limit
Shaft	Hole						
1	Clearance between bushing and connecting pin of revolving frame and swing bracket	40	-0.025 -0.064	+0.142 +0.080	0.105 - 0.206	1.0	Replace bushing
2	Clearance between bushing and boom foot pin	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
3	Clearance between bushing and connecting pin of boom and arm	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
4	Clearance between bushing and connecting pin of arm and link	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
5	Clearance between bushing and connecting pin of arm and bucket	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
6	Clearance between bushing and connecting pin of link and link	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
7	Clearance between bushing and connecting pin of link and bucket	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
8	Clearance between bushing and connecting pin of blade and track frame	30	-0.160 -0.193	+0.135 +0.096	0.256 - 0.328	1.0	


PC05-6 Serial No. 11701 and up




F20M06034



Section A - A




Section B - B




Section C - C




Section D - D



Section E - E




Section F - F



Section G - G

020M06




F20M06035


Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size	Tolerance		Standard clearance		Clearance limit
Shaft	Hole						
1	Clearance between bushing and connecting pin of revolving frame and swing bracket	40	-0.025 -0.064	+0.125 +0.071	0.096 – 0.189	1.0	Replace bushing
2	Clearance between bushing and boom foot pin	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
3	Clearance between bushing and connecting pin of boom and arm	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
4	Clearance between bushing and connecting pin of arm and link	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
5	Clearance between bushing and connecting pin of arm and bucket	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
6	Clearance between bushing and connecting pin of link and link	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
7	Clearance between bushing and connecting pin of link and bucket	30	-0.160 -0.193	+0.117 +0.080	0.240 – 0.310	1.0	
8	Clearance between bushing and connecting pin of blade and track frame	30	-0.160 -0.193	+0.135 +0.096	0.256 – 0.328	1.0	

PC07-1




F20M06034




Section A - A



Section B - B




Section C - C




Section D - D



Section E - E




Section F - F




Section G - G


920M06




Section H - H




Section I - I




Section J - J



Section K - K




Section L - L



Section M - M



Section N - N




Section O - O


20MF06021

Unit: mm


No.	Check item	Criteria				Remedy	
		Standard size	Tolerance		Standard clearance		Clearance limit
Shaft	Hole						
1	Clearance between bushing and connecting pin of revolving frame and swing bracket	40	-0.025 -0.064	+0.125 +0.071	0.096 - 0.189	1.0	Replace bushing
2	Clearance between bushing and boom foot pin	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
3	Clearance between bushing and connecting pin of boom and arm	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
4	Clearance between bushing and connecting pin of arm and link	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
5	Clearance between bushing and connecting pin of arm and bucket	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
6	Clearance between bushing and connecting pin of link and link	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
7	Clearance between bushing and connecting pin of link and bucket	30	-0.160 -0.193	+0.117 +0.080	0.240 - 0.310	1.0	
8	Clearance between bushing and connecting pin of blade and track frame	30	-0.160 -0.193	+0.135 +0.096	0.256 - 0.328	1.0	




20NF06036




Section A - A




Section B - B




Section C - C



Section D - D




Section E - E




Section F - F


020M06




Section G - G




Section H - H




Section I - I




Section J - J




Section K - K



Section L - L



Section M - M



Section N - N

20NF06037


Unit: mm

020M06


No.	Check item	Criteria				Remedy
		Standard size	Tolerance		Standard clearance	
Shaft	Hole					
1	Clearance between bushing and connecting pin of revolving frame and swing bracket	60	0 -0.050	+0.178 +0.109	0.109 - 0.228	1.0
2	Clearance between bushing and connecting pin of boom and swing bracket	35	0 -0.050	+0.142 +0.080	0.080 - 0.192	1.0
3	Clearance between bushing and connecting pin of boom and arm	35	0 -0.050	+0.095 +0.044	0.044 - 0.145	1.0
4	Clearance between bushing and connecting pin of arm and link	30	0 -0.050	+0.079 +0.033	0.033 - 0.129	1.0
5	Clearance between bushing and connecting pin of arm and bucket	30	0 -0.050	+0.079 +0.033	0.033 - 0.129	1.0
6	Clearance between bushing and connecting pin of link and link	30	0 -0.050	+0.079 +0.033	0.033 - 0.129	1.0
7	Clearance between bushing and connecting pin of link and bucket	30	0 -0.050	+0.079 +0.033	0.033 - 0.129	1.0
8	Clearance between bushing and connecting pin of blade and track frame	35	0 -0.050	+0.095 +0.044	0.044 - 0.145	1.0

Replace bushing


PC15-2




20NF06036




Section A - A




Section B - B




Section C - C



Section D - D




Section E - E




Section F - F


020M06




Section G - G




Section H - H




Section I - I




Section J - J




Section K - K



Section L - L



Section M - M



Section N - N

20NF06038

Unit: mm

No.	Check item	Criteria				Remedy
		Standard size	Tolerance		Standard clearance	
Shaft	Hole					
1	Clearance between bushing and connecting pin of revolving frame and swing bracket	60	0 -0.050	+0.178 +0.109	0.109 - 0.228	1.0
2	Clearance between bushing and connecting pin of boom and swing bracket	40	0 -0.050	+0.096 +0.045	0.045 - 0.146	1.0
3	Clearance between bushing and connecting pin of boom and arm	35	0 -0.050	+0.095 +0.044	0.044 - 0.145	1.0
4	Clearance between bushing and connecting pin of arm and link	30	0 -0.050	+0.079 +0.033	0.033 - 0.129	1.0
5	Clearance between bushing and connecting pin of arm and bucket	30	0 -0.050	+0.079 +0.033	0.033 - 0.129	1.0
6	Clearance between bushing and connecting pin of link and link	30	0 -0.050	+0.079 +0.033	0.033 - 0.129	1.0
7	Clearance between bushing and connecting pin of link and bucket	30	0 -0.050	+0.079 +0.033	0.033 - 0.129	1.0
8	Clearance between bushing and connecting pin of blade and track frame	35	-0.170 -0.209	+0.142 +0.080	0.250 - 0.351	1.0

Replace bushing

020M06