

Indication	Wrench lamp	Spanner	Detection ECU	Error mode	Phenomenon on vehicle	Described on page
01-1	01-1	Blinking	4Y-ECS	Fuel feedback control error (gasoline) rich	The engine speed is unstable and it may stop.	19-14
01-2	01-2	Blinking	4Y-ECS	Fuel feedback control error (gasoline) lean		
01-3	01-3	Blinking	4Y-ECS	Fuel feedback control error (LPG/CNG) rich		19-18
01-4	01-4	Blinking	4Y-ECS	Fuel feedback control error (LPG/CNG) lean		
01-5	01-5	Blinking	4Y-ECS	O2 sensor open abnormality	The engine speed is unstable and it may stop.	19-23
01-6	01-6	Blinking	4Y-ECS	O2 sensor heater open abnormality	Display only	19-25
02-1	02-1	Blinking	4Y-ECS	Intake temperature sensor open abnormality	The engine may have a problem at low temperatures.	19-27
02-2	02-2	Blinking	4Y-ECS	Intake temperature sensor short abnormality		
03-1	03-1	Blinking	4Y-ECS	Intake pipe pressure sensor open abnormality	The engine may have a problem	19-29
03-2	03-2	Blinking	4Y-ECS	Intake pipe pressure sensor short abnormality		
04-1	04-1	Blinking	4Y-ECS	Coolant temperature sensor open abnormality	The engine may have a problem at low temperatures.	19-31
04-2	04-2	Blinking	4Y-ECS	Coolant temperature sensor short abnormality		
05-1	05-1	Blinking	4Y-ECS	Throttle position sensor 1 open abnormality	Limiting speed of traveling and materials handling due to limited engine power output	19-33
05-2	05-2	Blinking	4Y-ECS	Throttle position sensor 1 short abnormality		
05-3	05-3	Blinking	4Y-ECS	Throttle position sensor 2 open abnormality		
05-4	05-4	Blinking	4Y-ECS	Throttle position sensor 2 short abnormality		
05-5	05-5	Blinking	4Y-ECS	Throttle position sensor offset abnormality		
05-6	05-6	Blinking	4Y-ECS	Throttle position sensor out of range error		
06-1	06-1	Blinking	4Y-ECS	Throttle motor drive circuit open abnormality	Limiting speed of traveling and materials handling due to limited engine power output	19-35
06-2	06-2	Blinking	4Y-ECS	Throttle motor drive circuit short abnormality		
06-3	06-3	Blinking	4Y-ECS	Throttle motor power supply circuit open abnormality		19-37
06-4	06-4	Blinking	4Y-ECS	Throttle motor power supply circuit short abnormality		
06-5	06-5	Blinking	4Y-ECS	Throttle motor seizing abnormality		19-38
06-6	06-6	Blinking	4Y-ECS	Electronic throttle system error		19-40
07-1	07-1	Blinking	4Y-ECS	Air-fuel ratio motor open abnormality	The engine speed is unstable and it may stop.	19-41
08-1	08-1	Blinking	4Y-ECS	Low voltage (battery line open) error	Display only	19-43
09-1	09-1	Blinking	4Y-ECS	Ignition signal error	The engine speed is unstable and it may stop.	19-44
0A-1	0A-1	Blinking	4Y-ECS	Fuel specification determination signal error	Display only	19-47
0A-2	0A-2	Blinking	4Y-ECS	Fuel specification changeover switch error	Display only	
0A-3	0A-3	Blinking	4Y-ECS	Fuel specification type unmatched	Engine may stop	