

MERCEDES Truck Fault Codes AG DTC

0097 Low voltage at terminal 30
0098 Internal fault in the control unit
0099 High voltage at terminal 30
1083 Inadequate transmission
1084 Internal fault in the control unit
1085 Internal fault in the control unit
1086 Internal fault in the control unit
1087 Internal fault in the control unit
1088 Internal fault in the control unit
1089 Internal fault in the control unit
1090 Internal fault in the control unit
1091 Internal fault in the control unit
2220 Fault in the drive control system and slip
2222 Fault in the drive control system and slip
2224 A fault in the ABS control unit or BS
2279 CAN bus from the ABS or BS control unit has an error or malfunction
2320 Fault in system traffic control FR
2322 Fault in system traffic control FR
2324 Fault in system traffic control FR
2326 Fault in system traffic control FR
2336 Fault in system traffic control FR
2349 Fault in system traffic control FR
2369 Fault in system traffic control FR
2379 CAN bus from the control unit FR has an error or malfunction
2409 Fault in system traffic control FR
2428 Fault in system traffic control FR
2449 Fault in system traffic control FR
2478 Fault in system traffic control FR
2479 CAN bus from the control unit FR has an error or malfunction
2500 Faulty switching control system GS gear
2502 Faulty switching control system GS gear
2504 Faulty switching control system GS gear
2506 Faulty switching control system GS gear
2529 Faulty switching control system GS gear
2569 Faulty switching control system GS gear
2579 CAN bus from the GS control unit has an error or malfunction
2729 A fault in the ABS control unit or BS
2749 A fault in the ABS control unit or BS
2769 A fault in the ABS control unit or BS
2779 CAN bus from the ABS or BS control unit has an error or malfunction
2820 Faulty switching control system GS gear
2822 Faulty switching control system GS gear
2824 Faulty switching control system GS gear
2830 Faulty switching control system GS gear
2834 Faulty switching control system GS gear
2842 Faulty switching control system GS gear
2869 Faulty switching control system GS gear
2879 CAN bus from the GS control unit has an error or malfunction
2910 Fault in system traffic control FR
2928 Fault in system traffic control FR
2958 Fault in system traffic control FR

2968 Fault in system traffic control FR
2979 CAN bus from the control unit FR has an error or malfunction
3008 Fault in system traffic control FR
3010 Fault in system traffic control FR
3028 Fault in system traffic control FR
3079 CAN bus from the control unit FR has an error or malfunction
3120 Faulty RS retarder control system
3138 Faulty RS retarder control system
3179 CAN bus from the RS control unit has an error or malfunction
3280 data from the vehicle control unit INS changed or
Error in communication with the control unit INS
In 3281 control unit INS is not available the stored data on the car OR
Error in communication with the control unit INS
3282 CAN communication is faulty OR
Error in communication with the control unit INS
3381 An error in communication with the control unit GS
3382 An error in communication with the MR control unit