
S180W-V
Applied Serial No. :
1100 & Up
6-LAMP ASS'Y (OPTION)
CABIN LAMP ASS'Y (OPT)
OVER LOAD WARNING (OPT)
QUICK CLAMP PARTS
BREAKER/ 2-WAY OPTION PARTS
BREAKER
2-WAY
PEDAL BREAKER
FUEL PUMP (OPT)
ROTATING BEACON (OPT)
CONSOLE ASS'Y (303-00010)
LCD GAUGE PANEL (539-00048C)
EPOS-V CONTROLLER (543-00063)
THROTTLE CONTROLLER (543-00074)
ENG CONTROL MOTOR (523-00006)
A/C CONTROL PANEL (539-00049)
AIRCON UNIT (920-00020B)
ALTERNATOR (2502-9007B) 24V 60A
ALTERNATOR 80A(OPTION) (502-00003)
BATTERY (2506-1104)x2
STARTER (65.26201-7044) 24V 4.5KW
STARTER SWITCH CONNECTION
NOTE.
1. DIODE PART NO.
DIODE 1 , : 548-00003A
DIODE 2 ~ 27 : 2548-1027
DIODE 28 : 548-00002