




## Rear Inner Sill Extension







# Parts List

Quantity	Part Number	Description	Image / Notes
1	1099608-S0-A (LH) 1099609-S0-A (RH)	Rear Inner Sill Extension	
2 rivets needed; order 10 rivets	1062559-00-A	● Structural Rivet, 6.5 mm Medium	All rivets come in packages of 10; order all rivets in multiples of 10.
1	—	Structural Adhesive	<b>⚠ WARNING:</b> Use only Tesla-approved structural adhesive; refer to <a href="#">BR-15-92-008</a> , "Approved Structural Adhesive and Urethane Sealants" for a list of current approved structural adhesives.  Refer to <a href="#">BR-17-92-002</a> , "Obtaining Adhesives, Coolant, and Other Chemicals" for information on how to obtain approved structural adhesive.
1	—	Corrosion-Resistant Epoxy Primer	Source locally; not available from Tesla.
1	—	Seam Sealer	Source locally; not available from Tesla.

These part numbers were current at the time of publication. Use the revisions listed or later, unless otherwise specified in the [Parts Manual](#).



## Repair Information

Repair Information	Warnings and Cautions	Special Tools
<p>This procedure is for the left-hand component; the procedure is identical for the right-hand component.</p>	<p> <b>WARNING:</b> Wear the appropriate personal protective equipment (PPE) when performing this procedure.</p> <p> <b>CAUTION:</b> This procedure involves only steel components. Use the appropriate tools to avoid cross-contamination.</p>	<p>The special tools listed below are required to perform this procedure:</p> <ul style="list-style-type: none"><li>Resistance Spot Welder</li></ul> <p>Use only an approved resistance spot welder. Refer to <a href="#">BR-16-92-007</a>, "Approved Welders" for a list of current approved resistance spot welders.</p> <ul style="list-style-type: none"><li>Frame bench</li></ul> <p>The vehicle must be properly mounted on an approved frame bench to replace this component. Refer to <a href="#">BR-16-92-006</a>, "Approved Frame Bench Systems" for a list of current approved bench repair systems.</p>



## Prerequisites

1

Disconnect 12V and high voltage power (refer to the appropriate section in [BR-17-17-004](#), "Disconnecting 12V and High Voltage Power on Model 3").



**WARNING:** Before disconnecting the 12V power supply, make sure that all windows are at least slightly open. Attempting to open a door with a fully-closed window when the 12V power supply is disconnected could result in door glass shatter.



**NOTE:** Before disconnecting the 12V power supply, make sure that the driver's door window is fully open. Failure to lower the driver's door window before disconnecting the 12V power supply could result in vehicle lockout.





## Prerequisites

2

Remove the [Sill Inner \(Complete\)](#).






## Removal

1

Identify the component materials in the repair area.

 Aluminum

 High-Strength Steel



 Ultra High-Strength Steel



**NOTE:** The ultra high-strength steel Rear Node Reinforcement is outlined in the first image.



**NOTE:** Refer to [BR-17-10-005](#), “Model 3 Body Structure Materials and Allowed Operations”, for information about the material each structural component is made from and the operations that are allowed on each type of material.





## Removal

2 Remove the original component.



A Use a drill with a spot weld bit to drill out the factory spot welds.  
▲ Factory Spot Weld (x17)



**NOTE:** Use a belt sander to sand down any factory spot welds that cannot be reached with a drill.



**NOTE:** Factory spot weld locations shown are approximate. Exact spot weld locations and number vary from vehicle to vehicle.





## Removal

- 2 Remove the original component (continued).
- B Use a hammer and chisel to remove the original component.







## Removal

3

Use a disc sander with a medium-abrasive surface conditioning disc to remove any remaining materials from the bond paths. Use a belt sander with a medium-abrasive belt for any areas that cannot be reached with a disc sander. Vacuum any adhesive dust.



**WARNING:** Remove the epoxy adhesive in a well-ventilated area. Wear suitable personal protective equipment.






## Replacement

- 1 Prepare for installation.
  - A Put the new component into position and align it to the frame bench jig points.



- B Clamp the new component into place.





## Replacement

1 Prepare for installation (continued).


C Mark the fastener locations on the new component.

● Structural Rivet, 6.5 mm Medium (x2)

▲ Installation Spot Weld (x15)



**NOTE:** Mark and drill the structural rivet holes 30 mm (1-3/16 in) down from the top edge of the new Rear Inner Sill Extension to avoid interference with underlying components.





## Replacement

- 1 Prepare for installation (continued).
- C Mark the fastener locations on the new component (continued).




- D Use a drill with a 6.7 mm (17/64 in) bit to drill holes for structural rivets.

- Structural Rivet, 6.5 mm Medium (x2)



**NOTE:** Drill the structural rivet holes 30 mm (1-3/16 in) down from the top edge of the new Rear Inner Sill Extension to avoid interference with underlying components.





## Replacement

1 Prepare for installation (continued).

D Use a drill with a 6.7 mm (17/64 in) bit to drill holes for structural rivets (continued).



E Mark the surface preparation boundary lines on the vehicle and on the new component.







## Replacement

- 1 Prepare for installation (continued).
- F Remove the new component.



- G Mark the bond path areas on the new component and the vehicle. These areas will be prepared for bonding in the next step.
-  Steel-to-Steel Bond Path






## Replacement


1 Prepare for installation (continued).

**G** Mark the bond path areas on the new component and the vehicle. These areas will be prepared for bonding in the next step (continued).



**H** Mark the installation spot weld locations on the new component and on the vehicle.

▲ Installation Spot Weld






## Replacement

1 Prepare for installation (continued).

H Mark the installation spot weld locations on the new component and on the vehicle (continued).








## Replacement

1 Prepare for installation (continued).

H Mark the installation spot weld locations on the new component and on the vehicle (continued).








## Replacement

2 Prepare the surfaces.

A Use a red Scotch-Brite pad or equivalent to scuff the new component and the vehicle in the steel-to-steel bond path areas.

 Steel-to-Steel Bond Path





## Replacement

2 Prepare the surfaces (continued).

**B** Use a disc sander with a medium-abrasive surface conditioning disc to remove the e-coat on the new component and on the vehicle in the weld areas. Use a belt sander with a medium-abrasive belt for any areas that cannot be reached with a disc sander.



**WARNING:** Remove the e-coat in a well-ventilated area. Wear suitable personal protective equipment.



**C** Clean all the bond paths and weld areas on the new component or components and on the vehicle with isopropyl alcohol (IPA).



**WARNING:** Wipe off the remaining isopropyl alcohol with a clean, dry towel immediately after application. Do not let the remaining isopropyl alcohol air dry. Allowing the remaining isopropyl alcohol to air dry can compromise the adhesive bond.





## Replacement

3 Apply structural adhesive.

A Spread a thin coating of structural adhesive as a primer layer on the bond paths on the vehicle and the new component.



**NOTE:** Assembly must be performed while the primer layer is still wet. The drying time of the adhesive varies depending on temperature and humidity.

B While the primer layer is still wet, apply a bead of structural adhesive on top of the primer layer on the new component.






## Replacement

4 Install the new component.

A Put the new component into position and insert the structural rivets to hold it in place.

- Structural Rivet, 6.5 mm Medium (x2)





## Replacement

- 4 Install the new component (continued).
- B Align and temporarily secure the new component to the frame bench jig points.



- C Clamp the new component into place.






## Replacement

**4** Install the new component (continued).

**D** Install the structural rivets.

**E** Wipe off any excess adhesive.





## Replacement

4 Install the new component (continued).

F Perform resistance spot welding.

▲ Installation Spot Weld (x15)




**WARNING:** Failure to follow all welding safety precautions, including the use of personal protective equipment, could result in serious injury or property damage. Only technicians who have successfully met Tesla's requirements for welding training are authorized to weld structural components on Tesla vehicles.



**CAUTION:** Do not weld on a Tesla vehicle with an energized high voltage or 12V system. Welding on a Tesla vehicle with an energized high voltage or 12V system might damage vehicle components.



**CAUTION:** Use only insulated clamps within 200 mm (8 in) of resistance spot weld locations. Do not perform resistance spot welding when there is an uninsulated clamp within 200 mm (8 in) of the spot weld location.







## Replacement

- 4 Install the new component (continued).
- F Perform resistance spot welding (continued).



- G Remove any discoloration from the weld areas.





## Replacement


4 Install the new component (continued).

H


Bake the structural adhesive so that the bonded panels reach a temperature of 60°C–80°C (140°F–176°F) for at least 30 minutes to achieve full strength.



**WARNING:** Do not allow the High Voltage Battery to reach a temperature above 74°C (165°F). Heating the High Voltage Battery above 74°C (165°F) for an extended period could result in injury to personnel and/or damage to the battery.



00:30:00+



60°C–80°C

5

Prime any bare metal that will not be covered with weld-through primer or structural adhesive in a subsequent repair with a suitable corrosion-resistant epoxy primer.



## Replacement

6

Seal the seams in the factory locations, and as necessary.

7

Install the new [Sill Inner \(Complete\)](#).

